

REVISION

MODEL 200 SERIES

1966 THRU 1968

SERVICE MANUAL

REVISION 2

JUNE 1/2004

D606R2-13

**INSERT THE FOLLOWING REVISED
PAGES INTO THE BASIC MANUAL**

Service Manual

200-SERIES

1966 THRU 1968



FAA APPROVAL HAS BEEN OBTAINED ON TECHNICAL DATA IN THIS PUBLICATION THAT AFFECTS AIRPLANE TYPE DESIGN.

REVISION 2 TO THE BASIC MANUAL IS SUPPLIED TO PROVIDE ADDITIONAL INFORMATION NECESSARY TO MAINTAIN THE AIRPLANE AND INCORPORATES TEMPORARY REVISION 1 DATED 1 DECEMBER 1992, TEMPORARY REVISION 2 DATED 3 OCTOBER 1994, TEMPORARY REVISION 3 DATED 7 JANUARY 2000, TEMPORARY REVISION 4 DATED 7 OCTOBER 2002, AND TEMPORARY REVISION 5 DATED 5 APRIL 2004.

THIS MANUAL COVERS MAINTENANCE FOR CESSNA 200-SERIES AIRPLANES, 1966 THRU 1968. FOR COVERAGE OF MODELS PRIOR TO 1966, REFER TO THE 200-SERIES SERVICE MANUAL DATED MARCH, 1965.

Copyright © 2004
Cessna Aircraft Company
Wichita, Kansas, USA

MARCH 1968

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
 SERVICE MANUAL

LIST OF EFFECTIVITY PAGES
INSERT THE LATEST CHANGED PAGES. DESTROY SUPERSEDED PAGES.

Dates of issue for original and revisions are:

Original.....0 March 1968
 Change1 11 December 1975
 Revision2 1 June 2004

Note: The portion of the text affected by the revision is indicated
 by a vertical line in the outer margin of the page.

*The asterisk indicates pages revised, added, or deleted by current revision.

Page No.	Revision No.	Page No.	Revision No.	Page No.	Revision No.
*Title.....	2	5A-58	0	Appendix	
"A" Page.....	2	6-1 thru 6-10	0		
i thru iv	0	6-11.....	1	A1-1 thru A1-2	0
1-1 thru 1-8	0	7-1 thru 7-16	0	A2-1 thru A2-14	0
2-1 thru 2-22	0	8-1 thru 8-8	0	A3-1 thru A3-3	0
* 2-23 thru 2-25.....	2	9-1 thru 9-10	0	A4-1 thru A4-2	0
2-26.....	0	10-1 thru 10-9	0	A5-1 thru A5-2	0
* 2-27 thru 2-30.....	2	11-1 thru 11-4	0	A6-1 thru A6-2	0
3-1 thru 3-22	0	12-1 thru 12-30	0	A7-1 thru A7-2	0
4-1 thru 4-5	0	12A-1 thru 12A-29	0		
4-6.....	1	13-1 thru 13-22	0		
4-7 thru 4-8	0	13A-1 thru 13A-2	0		
5-1 thru 5-26	0	*13A-3.....	2		
* 5A-1	2	13A-4 thru 13A-9	0		
5A-2 thru 5A-48	0	14-1 thru 14-11	0		
5A-48A.....	0	14-12 Blank.....	0		
5A-49	0	15-1 thru 15-13	0		
5A-49A.....	0	* 16-1	2		
5A-50	0	16-2 thru 16-12	0		
5A-50A.....	0	16-12A	0		
5A-51	0	16-13 thru 16-17	0		
5A-51A.....	0	*16-18 thru 16-20C	2		
5A-52	0	*16-20D Blank.....	2		
5A-52A.....	0	16-21 thru 16-22A.....	0		
5A-53	0	16-23 thru 16-26	0		
5A-53A.....	0	17-1 thru 17-26	0		
5A-54	0	18-1 thru 18-32	0		
5A-54A.....	0	19-1 thru 19-5	0		
5A-55	0	19-6 Blank.....	0		
5A-55A.....	0	20-1.....	0		
5A-56	0	1270405 thru 5.1.....	0		
5A-56A.....	0	6.0.....	1		
5A-57	0	6.1 thru 16.1.....	0		
5A-57A.....	0	1270625 thru 16.1	0		

Upon receipt of the second and subsequent changes to this book, personnel responsible for maintaining this publication in current status should ascertain that all previous changes have been received and incorporated.

TABLE OF CONTENTS

SECTION	Page
1 GENERAL DESCRIPTION	1-1
2 GROUND HANDLING, SERVICING, LUBRICATION, AND INSPECTION	2-1
3 FUSELAGE	3-1
4 AIRFRAME	4-1
5 NON-RETRACTABLE LANDING GEAR	5-1
5A RETRACTABLE LANDING GEAR AND HYDRAULIC SYSTEM	5A-1
6 AILERON CONTROL SYSTEM	6-1
7 ELECTRICAL FLAP CONTROL SYSTEMS	7-1
8 ELEVATOR CONTROL SYSTEM	8-1
9 ELEVATOR TRIM CONTROL SYSTEM	9-1
10 RUDDER CONTROL SYSTEM	10-1
11 RUDDER TRIM CONTROL SYSTEMS	11-1
12 POWERPLANT	12-1
12A TURBOCHARGED POWERPLANT	12A-1
13 FUEL SYSTEM (EXCEPT CANTILEVER WING)	13-1
13A FUEL SYSTEM (CANTILEVER WING)	13A-1
14 PROPELLERS	14-1
15 UTILITY SYSTEMS	15-1
16 INSTRUMENTS AND INSTRUMENT SYSTEMS	16-1
17 ELECTRICAL SYSTEMS	17-1
18 STRUCTURAL REPAIR	18-1
19 PAINTING	19-1
20 WIRING DIAGRAMS	20-1
APPENDIX A HYDRAULIC COMPONENTS REPAIR	A1-1

CROSS REFERENCE LISTING OF
POPULAR NAME VS. MODEL
NUMBERS AND SERIALS

All aircraft, regardless of manufacturer, are certificated under model number designations. However, popular names are often used for marketing purposes. To provide a consistent method of referring to the various aircraft, model numbers will be used in this publication unless names are required to differentiate between versions of the same basic model. The following table provides a cross reference listing of popular name vs. model numbers.

POPULAR NAME	MODEL YEAR	MODEL	SERIALS	
			BEGINNING	ENDING
CENTURION	1966	210F	21058716	21058818
	1967	210G	21058819	21058936
	1968	210H	21058937	
TURBO-SYSTEM CENTURION	1966	T210F	T210-0001	T210-0197
	1967	T210G	T210-0198	T210-0307
	1968	T210H	T210-0308	
SUPER SKYWAGON (UTILITY CARGO DOOR)	1966	U206A	U206-0438	U206-0656
	1967	U206B	U206-0657	U206-0914
	1968	U206C	U206-0915	
TURBO-SYSTEM SUPER SKYWAGON (UTILITY CARGO DOOR)	1966	TU206A	U206-0438	U206-0656
	1967	TU206B	U206-0657	U206-0914
	1968	TU206C	U206-0915	
SUPER SKYWAGON (PASSENGER DOOR)	1966	P206A	P206-0161	P206-0306
TURBO-SYSTEM SUPER SKYWAGON (PASSENGER DOOR)	1966	TP206A	P206-0161	P206-0306
SUPER SKYLANE	1966	P206A	P206-0161	P206-0306
	1967	P206B	P206-0307	P206-0419
	1968	P206C	P206-0420	
TURBO-SYSTEM SUPER SKYLANE	1966	TP206A	P206-0161	P206-0306
	1967	TP206B	P206-0307	P206-0419
	1968	TP206C	P206-0420	

FOREWORD

This Service Manual contains factory-recommended procedures and instructions for ground handling, servicing, and maintaining Cessna 200-Series airplanes. These include the various Model 206 and 210 Series configurations. Besides serving as a reference for the experienced mechanic, this Service Manual also covers step-by-step procedures for the less experienced man. This Service Manual should be kept in a handy place for ready reference. If properly used, it will better enable the mechanic to maintain these aircraft and thereby establish a reputation for reliable service.

The information in this Service Manual is based on data available at the time of publication, and is supplemented and kept current by service letters and service news letters published by Cessna Aircraft Company. These are sent to all Cessna Dealers so that they have the latest authoritative recommendations for servicing Cessna airplanes. Therefore, it is recommended that Cessna owners utilize the knowledge and experience of the factory-trained Dealer Service Organization.

In addition to the information in this Service Manual, a group of vendor publications are available from the Cessna Service Parts Center which describe complete disassembly, overhaul and parts breakdown of some of the various vendor equipment items. A listing of the available publications is issued periodically in Service Letters.

MAINTENANCE AND SAFETY SUGGESTIONS

ON ALL 210-SERIES AIRCRAFT

1. When parting any lines, always cap or plug all lines and fittings to avoid entrance of dirt and air into the system. This applies to all test and fill equipment as well.
2. When installing any new lines or equipment, always be certain lines and equipment are clean, have been flushed with clean hydraulic fluid and are as near full of clean fluid as possible to minimize bleeding.
3. Avoid using the airplane hand pump to retract the landing gear.
4. Avoid subjecting the hydraulic system or any component to more than 2200 PSI. It is possible to exceed the pressure limit when an external pump is connected to bypass the Power Pack.
5. Avoid rigging adjustments or maintenance on the landing gear when the airplane is not securely on jacks.
6. Avoid pressure of more than 10 PSI to the Power Pack reservoir during filling operations; otherwise, damage to the reservoir seals may result.
7. Before performing any maintenance in any of the wheel or strut wells, always disconnect the doors to avoid injury from unintentional actuation of the doors.

ON ALL 200-SERIES AIRCRAFT

Avoid using or installing gust locks on the flaps; otherwise, damage may result if flaps are accidentally operated.

SECTION 1

GENERAL DESCRIPTION

1-1. 210 SERIES.

1-2. The Cessna 210 Series airplanes are high-wing monoplanes, of all-metal, semi-monocoque airframe construction. Beginning with 1967, the Model 210 Series have a full cantilever wing with a sealed section to form an integral fuel tank area. The 210 Series employ a fully retractable tricycle landing gear with the familiar spring-steel main gear struts. The steerable nose gear is an air-oil filled oleo strut. The landing gear is hydraulically actuated, and the wing flaps are electrically actuated. Standard seating consists of four individual seats and an individual child's seat located immediately aft of each rear passenger's seat. Optional seating consists of deluxe seats, two of which are individual front seats with one two-place bench type rear seat that has individual backs. The child's seat installation is not available with deluxe seating. The Model 210 is powered by a six-cylinder, horizontally opposed, air-cooled, fuel injection Continental engine driving an all-metal, constant-speed propeller. The Model T210 engine is turbocharged.

1-3. 206 SERIES.

1-4. The Cessna 206 Series airplanes are high-wing monoplanes, of all-metal, semi-monocoque airframe construction. The 206 Series employ a

non-retractable tricycle landing gear with the familiar spring-steel main gear struts. The steerable nose gear is an air-oil filled oleo strut. Wing flaps are electrically actuated. The U206 Super Skywagon Series are equipped with large double cargo doors on the right side of the fuselage and an entrance door on the left side of the cabin. The P206 Super Skywagon Series (1966 only) and P206 Super Skylane Series are equipped with an entrance door on each side of the cabin and a baggage door on the left side of the fuselage. Standard seating on Super Skywagon Series airplanes consists of the pilot's seat, but provisions are made for the addition of optional seats to make a six-place airplane. Super Skylane Series seating consists of six individual seats. Model U206 and P206 airplanes are powered by a six-cylinder, horizontally opposed, air-cooled, fuel-injection Continental engine driving an all-metal, constant-speed propeller. In addition, Model TU206 and TP206 engines are turbocharged.

1-5. Leading particulars of each model, with dimensions based on gross weight, are given in the following charts. If these dimensions are used for constructing a hangar or computing clearances, remember that such factors as nose strut inflation, tire pressures, tire sizes, and load distribution may result in some dimensions that are considerably different from those listed.

MODELS 210F AND T210F

DESIGN GROSS WEIGHT	3300 lb
FUEL CAPACITY (Total)	
Standard	65 gal
Optional	84 gal
OIL CAPACITY (Detergent Only)	12 qt
ENGINE MODEL	
210 (Refer to Section 12 for Engine Data)	CONTINENTAL IO-520 SERIES
T210 (Refer to Section 12A for Engine Data)	CONTINENTAL TSIO-520 SERIES
PROPELLER (Constant Speed)	
Standard (Two Blades)	82" McCauley
Optional (Three Blades)	80" McCauley
LANDING GEAR (Retractable, Hydraulically Actuated)	Tricycle
MAIN WHEEL TIRES	6.00 x 6, 6-ply rating
Pressure	42 psi
NOSE WHEEL TIRE	5.00 x 5, 6-ply rating
Pressure	45 psi
NOSE GEAR STRUT PRESSURE (Strut Extended)	95 psi
WHEEL ALIGNMENT	
Camber	+4° ± 1° 30'
Toe-in	0" to .06"
AILERON TRAVEL	
Up	21° ± 2°
Down	14° 30' ± 2°
WING FLAP TRAVEL (Electrically Actuated)	0° to 40°, +1° - 2°
RUDDER TRAVEL (Measured perpendicular to hinge line)	
Right	27° 13' ± 1°
Left	27° 13' ± 1°
ELEVATOR TRAVEL	
Up	26° 30' ± 1°
Down	18° ± 1°
ELEVATOR TRIM TAB TRAVEL	
Up	20° ± 1°
Down	20° ± 1°
PRINCIPAL DIMENSIONS	
Wing Span	36' 7"
Tail Span	11' 8"
Length	27' 11-3/4"
Fin Height (Maximum with Nose Gear Depressed and Rotating Beacon Installed on Fin)	9' 9"
Track Width	8' 2-1/4"
BATTERY LOCATION	Left Side of Firewall

MODELS 210G AND T210G & ON

DESIGN GROSS WEIGHT	3400 lb
FUEL CAPACITY	
Total	90 gal
OIL CAPACITY (Detergent Only)	12 qt
ENGINE MODEL	
210 (Refer to Section 12 for Engine Data)	CONTINENTAL IO-520 SERIES
T210 (Refer to Section 12A for Engine Data)	CONTINENTAL TSIO-520 SERIES
PROPELLER (Constant Speed)	
Standard (Two Blades)	82" McCAULEY
Optional (Three Blades)	80" McCAULEY
LANDING GEAR (Retractable, Hydraulically Actuated)	Tricycle
MAIN WHEEL TIRES	6:00 x 6, 6-ply rating
Pressure	42 psi
NOSE WHEEL TIRE	5:00 x 5, 6-ply rating
Pressure	45 psi
NOSE GEAR STRUT PRESSURE (Strut Extended)	95 psi
WHEEL ALIGNMENT	
Camber	4° ± 1° 30'
Toe-in	0" to .06"
AILERON TRAVEL	
Up	20° ± 2°
Down	15° ± 2°
WING FLAP TRAVEL (Electrically Actuated)	0° to 30°, + 1° - 2°
RUDDER TRAVEL (Measured perpendicular to hinge line)	
Right	27° 13' ± 1°
Left	27° 13' ± 1°
ELEVATOR TRAVEL	
Up	23° ± 1°
Down	15° ± 1°
ELEVATOR TRIM TAB TRAVEL	
Up	20° ± 1°
Down	5° ± 1°
PRINCIPAL DIMENSIONS	
Wing Span	36' 9"
Tail Span	13'
Length	28' 2-1/2"
Fin Height (Maximum with Nose Gear Depressed and Flashing Beacon Installed on Fin)	9' 7-1/2"
Track Width	8' 2-3/4"
BATTERY LOCATION	Left Side of Firewall

MODEL U206, P206, TU206 AND TP206 SERIES

DESIGN GROSS WEIGHT	3600 lb
FUEL CAPACITY (Total)	
Standard	65 gal
Optional	84 gal
OIL CAPACITY (Detergent Only)	12 qt
ENGINE MODEL	
U206 & P206 (Refer to Section 12 for Engine Data)	CONTINENTAL IO-520 SERIES
TU206 & TP206 (Refer to Section 12A for Engine Data)	CONTINENTAL TSIO-520 SERIES
PROPELLER (Constant-Speed)	
Standard (Two Blades)	82" McCauley
Optional (Three Blades)	80" McCauley
LANDING GEAR (Non-retractable)	Tricycle
MAIN WHEEL TIRES	
Standard	6.00 x 6, 6-ply rating
Pressure	42 psi
Optional	8.00 x 6, 6-ply rating
Pressure	35 psi
NOSE WHEEL TIRE	
Standard	5.00 x 5, 6-ply rating
Pressure	
(Prior to 1967)	45 psi
(1967 & ON)	49 psi
Optional	6.00 x 6, 4-ply rating
Pressure	29 psi
NOSE GEAR STRUT PRESSURE (Strut Extended)	
(Prior to 1967)	95 psi
(1967 & ON)	80 psi
WHEEL ALIGNMENT	
Camber	4°±1° 30'
Toe-in	0" to .06"
AILERON TRAVEL	
Up	21°±2°
Down	14° 30'±2°
WING FLAP TRAVEL (Electrically Actuated)	0° to 40°, +1° -2°
RUDDER TRAVEL (Measured perpendicular to hinge line)	
Right	27° 13'±1°
Left	27° 13'±1°
ELEVATOR TRAVEL	
Up	
(Thru 1967)	26°30'±1°
(1968 Models)	21°±1°
Down	
(Thru 1967)	18°±1°
(1968 Models)	17°±1°
ELEVATOR TRIM TAB TRAVEL	
Up	
(Thru 1967)	15°, +1° -0°
(1968 Models)	25°, +1° -0°
Down	
(Thru 1967)	25°, +1° -0°
(1968 Models)	5°, +1° -0°
PRINCIPAL DIMENSIONS	
Wing Span	36'7"
Tail Span	
(Thru 1967)	11'8"
(1968 Models)	13'
Length (Super Skywagon)	
(Prior to 1967)	27'9"
(1967 & ON)	28'
Length (Super Skylane)	
(Prior to 1967)	28'2"
(1967 & ON)	28'3"
Fin Height (Maximum with Nose Gear Depressed)	
(Rotating Beacon Installed on Fin, thru 1966)	9'9"
(Flashing Beacon Installed on Fin, 1967 & ON)	9'7-1/2"
Track Width	8'1-3/4"
BATTERY LOCATION	Left Side of Firewall







Figure 1-1. Wing Reference Stations



MODELS 210F AND T210F



MODELS 210G AND T210G & ON

Figure 1-2. Fuselage Reference Stations (Model 210 Series)





Figure 1-3. Fuselage Reference Stations (Model 206 Series)

TORQUE VALUES IN POUND-INCHES

FINE THREAD SERIES				
BOLT SIZE (See Note 1)	STANDARD TYPE NUTS		SHEAR TYPE NUTS	
	(See Note 2)	Alternate	MS20364, AN320 AN316, AN7502	Alternate
		Values		Values
		AN310 (See Note 4)		AN320 (See Note 4)
10-32	20-25	20-28	12-15	12-19
1/4-28	50-70	50-75	30-40	30-48
5/16-24	100-140	100-150	60-85	60-106
3/8-24	160-190	160-260	95-110	95-170
7/16-20	450-500	450-560	270-300	270-390
1/2-20	480-690	480-730	290-410	290-500
9/16-18	800-1000	800-1070	480-600	480-750
5/8-18	1100-1300	1100-1600	660-780	660-1060
3/4-16	2300-2500	2300-3350	1300-1500	1300-2200
7/8-14	2500-3000	2500-4650	1500-1800	1500-2900
1-14	3700-5500	3700-6650	2200-3300	2200-4400
1-1/8-12	5000-7000	5000-10000	3000-4200	3000-6300
1-1/4-12	9000-11000	9000-16700	5400-6600	5400-10000

COARSE THREAD SERIES

BOLT SIZE (See Note 1)	STANDARD TYPE NUTS (See Note 3)	SHEAR TYPE NUTS	
		MS20364, AN320, AN316	
8-32	12-15	7-9	
10-24	20-25	12-15	
1/4-20	40-50	25-30	
5/16-18	80-90	48-55	
3/8-16	160-185	95-100	
7/16-14	235-255	140-155	
1/2-13	400-480	240-290	
9/16-12	500-700	300-420	
5/8-11	700-900	420-540	
3/4-10	1150-1600	700-950	
7/8-9	2200-3000	1300-1800	
1-8	3700-5000	2200-3000	
1-1/8-8	5500-6500	3300-4000	
1-1/4-8	6500-8000	4000-5000	

NOTES:

- (1) AN3, AN23, AN42, AN173, MS20004, NAS334, NAS464 Series Bolts; AN502, AN503, NAS220 and NAS517 Series Screws.
- (2) AN310, AN315, AN345, AN362, AN363, MS20365, AN366, NAS679, "EB," "1452," "Z1200," "UWN" and other self-locking nuts.
- (3) AN310, AN340, MS20365, AN366 and other self-locking anchor nuts.
- (4) When using AN310 and AN320 castellated nuts where alignment between bolt and cotter pin holes is not reached using normal torque values, use alternate torque values or replace nut.

These torque values are derived from oil-free cadmium-plated threads, and are recommended for all installation procedures contained in this book except where other values are stipulated. They are not to be used for checking tightness of installed parts during service.

SECTION 2

GROUND HANDLING, SERVICING, LUBRICATION, AND INSPECTION

TABLE OF CONTENTS

	Page
GROUND HANDLING	2-1
Towing	2-1
Hoisting	2-1
Jacking	2-1
Parking	2-2
Tie-Down	2-2
Hanger Storage	2-2
Outside Storage	2-2
Extended Storage	2-2
Returning Airplane to Service	2-5
Leveling	2-5
SERVICING	2-5
Fuel Tanks	2-5
Fuel Drains	2-6
Engine Oil	2-6
Engine Induction Air Filters	2-6
Vacuum System Air Filters	2-7
Battery	2-7
Tires	2-7
Nose Gear Strut	2-7
Nose Gear Shimmy Dampener (Prior to 1967 Models)	2-8
Nose Gear Shimmy Dampener (1967 Models and On)	2-8
Hydraulic Brake Systems	2-9
Hydraulic Reservoir (210 and T210 Series)	2-9
Hydraulic Filter (210 and T210 Series)	2-9
Hydraulic Fluid Sampling (210 and T210 Series)	2-9
Oxygen System	2-9
Face Masks	2-9
CLEANING	2-9
Upholstery and Interior	2-9
Plastic Trim	2-9
Windshields and Windows	2-15
Aluminum Surfaces	2-15
Painted Surfaces	2-15
Engine Compartment	2-15
Propellers	2-15
Wheels	2-15
LUBRICATION	2-15
Nose Gear Torque Links	2-15
Tachometer Drive Shaft	2-15
Wheel Bearing Lubrication	2-15
INSPECTION	2-20

2-1. GROUND HANDLING.

2-2. **TOWING.** Moving the airplane by hand is accomplished by using the wing struts and landing gear struts as push points. A tow bar attached to the nose gear should be used for steering and maneuvering the airplane. When no tow bar is available, press down at the horizontal stabilizer front spar, adjacent to the fuselage, to raise the nose wheel off the ground. With the nose wheel clear of the ground, the airplane can be turned by pivoting it about the main wheels.

CAUTION

When towing the airplane, never turn the nose wheel more than 35 degrees either side of center or the nose gear will be damaged. Do not push on control surfaces or outboard empennage surfaces. When pushing on the tail-cone, always apply pressure at a bulkhead to avoid buckling the skin.

2-3. **HOISTING.** The airplane may be hoisted with hoists of two-ton capacity, either by using hoisting

rings (optional equipment) or by using suitable slings. The front sling should be hooked to the engine lifting eye, and the aft sling should be positioned around the fuselage at the first bulkhead forward of the leading edge of the stabilizer. If the optional hoisting rings are used, a minimum cable length of 60 inches for each cable is required to prevent bending of the eye-bolt type hoisting rings. If desired, a spreader jig may be fabricated to apply vertical force to the eye-bolts.

2-4. **JACKING.** Refer to figure 2-2 for jacking procedures.

CAUTION

When using the universal jack point, flexibility of the gear strut will cause the main wheel to slide inboard as the wheel is raised, tilting the jack. The jack must then be lowered for a second jacking operation. Jacking both wheels simultaneously with universal jack points is not recommended.




Figure 2-1. Typical Tow Bars

2-5. **PARKING.** Parking precautions depend principally on local conditions. As a general precaution, it is wise to set the parking brake or chock the wheels, and install the control lock. In severe weather, and high wind conditions, tie down the airplane as outlined in paragraph 2-6 if a hangar is not available.

2-6. **TIE-DOWN** should be accomplished in anticipation of high winds. Tie down airplanes as follows:

- a. Tie ropes or chains to the wing tie-down fittings located on the underside of each wing. Secure the opposite ends of the ropes or chains to ground anchors.
- b. Secure a rope (no chains or cables) to the upper trunnion of the nose gear and secure opposite end of rope to a ground anchor.
- c. Secure the middle of a rope to tail tie-down ring. Pull each end of rope away at 45-degree angle and secure to ground anchors at each side of tail.
- d. Install surface control locks between wing tip and aileron, and over fin and rudder.
- e. Install control lock on pilot's control column if available; if control lock is not available, tie pilot's control wheel back with front seat belt.

2-7. **HANGAR STORAGE.** An airplane stored in a hangar requires little attention. The following operations will maintain the airplane in a serviceable condition.

NOTE

If the airplane is to be stored for a long period, see paragraph 2-9.

- a. Rotate propeller by hand every few days to maintain an oil film on the internal parts of the engine.
- b. Keep fuel tanks full to retard moisture condensation in the tanks.
- c. Keep battery fully charged to prevent the electrolyte from freezing in an unheated hangar.

2-8. **OUTSIDE STORAGE.** Short-term outside storage of an airplane requires secure tie-down procedures in accordance with paragraph 2-6, as well as the precautions listed in paragraph 2-7. In addition, the pitot tube, air vents, openings in the engine cowling, and other similar openings should have protective covers installed if rain, sleet, snow, or blowing dust are anticipated.

2-9. **EXTENDED STORAGE,** requires the following precautions in addition to secure tie-down or storing the airplane in a hangar.

- a. Operate engine until oil temperature reaches normal operating range. Drain engine oil sump completely and reinstall drain plug.
- b. Fill oil sump with 12 quarts of corrosion preventive oil, which has been pre-heated to 225° F. Continental Motors Corporation recommends Cosmo-line No. 1223, supplied by E. F. Houghton & Co., 305 W. LeHigh Avenue, Philadelphia, Pa.

NOTE


Do not operate the engine at a speed of more than 1500 rpm, when engine is filled with corrosion preventive oil.

- c. Start and operate engine at 1200-1500 rpm for five minutes.

JACK POINTS
ARE REMOV-
ABLE ON
CANTILEVER
WINGS

CAUTION

Since the wing main spar is moved aft on the cantilever wing, the wing jack points are aft of the airplane center-of-gravity. This causes the airplane to be nose heavy when on jacks. Place additional weights (shot bags or sand bags) on the weighted tail stand to hold the tail down.



NOTE

Wing jacks available from the Cessna Service Parts Center are REGENT Model 4939-30 for use with the SE-576 wing stands. Combination jacks are the REGENT Model 4939-70 for use without wing stands. The 4939-70 jack (70-inch) may be converted to the 4939-30 jack (30-inch) by removing the leg extensions and replacing lower braces with shorter ones. The base of the adjustable tail stand (SE-767) is to be filled with concrete for additional weight as a safety factor. The SE-576 wing stand will also accommodate the SANCOR Model 00226-150 jack. Other equivalent jacks, tail stands, and adapter stands may be used.



JACKING THE MODEL 210 & T210 SERIES AIRPLANES

1. Lower the airplane tail so that wing jack and stands can be placed at wing jack points.
2. Raise airplane tail and attach tail stand to tail tie-down ring. BE SURE the tail stand weighs enough to keep the tail down under all conditions and that it is strong enough to support any weight that may be placed upon it.
3. Raise jacks evenly until desired height is reached. When jacking the airplane the main landing gear wheels must be a minimum of 16" above shop floor for landing gear retraction.
4. The universal jack point may be used to raise only one main wheel. Do not use brake casting as a jack point. Flex brake line away from gear strut when using universal jack point.
5. The nose may be raised by weighting down the tail. Place weight on each side of stabilizer, next to fuselage.
6. Whenever the landing gear is to be operated in the shop, use the wing jack and tail jack points to raise the airplane.
7. The airplane may be hoisted as outlined in paragraph 2-3.

REMOVING THE MODEL 210 & T210 SERIES AIRPLANES FROM JACKS

1. Place landing gear control handle in gear down position.
2. Operate ground hydraulic power source or airplane emergency hydraulic hand pump until landing gear is down and locked, the green (DOWN) light is illuminated and landing gear control handle has tripped to down neutral.
3. Disconnect ground hydraulic power source and/or stow emergency hydraulic hand pump handle.
4. Ascertain that green (DOWN) light is illuminated; then place master switch in OFF position.
5. Lower jacks evenly until airplane rests on the landing gear and remove wing jacks and tail stand.
6. Compress nose landing gear shock strut to static position.

Figure 2-2. Jacking Details (Sheet 1 of 2)



NOTE

The same general procedure may be used for jacking the Model 206 Series airplanes, except for deleting all references to retractable landing gear. Since wing jack points are not provided, use the padded blocks shown to protect wings while using wing jacks. Place pads at front spars, just outboard of wing struts.

Figure 2-2. Jacking Details (Sheet 2 of 2)

CAUTION

Monitor cylinder head temperature closely. Temperature shall not exceed maximum allowable.

d. With engine operating and induction air filter removed, spray corrosion-preventive oil into the induction airbox, at the rate of one-half gallon per minute, until smoke comes from the exhaust stack, then increase the spray until the engine is stopped.

CAUTION

Injecting oil too fast can cause a hydrostatic lock.

- e. Do not rotate propeller after completing step "d."
- f. Remove all spark plugs and spray corrosion-preventive oil, which has been pre-heated to 150°F. - 180°F., into all spark plug holes.
- g. Replace lower spark plugs or install solid plugs, and install dehydrator plugs in the upper spark plug holes.
- h. Cover spark plug terminals with shipping plugs or other suitable covers, and cover all other engine and accessory vents, and other openings with a vapor-proof covering material.
- i. Drain corrosion-preventive oil from engine sump and reinstall drain plug.

NOTE

The corrosion-preventive oil is harmful to paint and should be wiped from painted surfaces immediately.

- j. Attach a warning placard on the throttle control knob, to the effect that the engine contains no lubricating oil. Placard the propeller to the effect that it should not be rotated while the engine is in storage.
- k. Lubricate all airframe items, and seal or cover all openings.
- l. Remove battery from airplane and store in a cool place; service battery periodically.
- m. Block up fuselage to remove weight from tires to prevent tires from flat-spotting.

NOTE

Tires will take a set, causing them to be out-of-round, if an airplane is left parked for more than a few days. For this reason, a stored airplane should be blocked up to prevent the tires from flat-spotting.

2-10. RETURNING AIRPLANE TO SERVICE.

After short-term storage, returning the airplane to service is accomplished by completing a thorough pre-flight inspection. After extended storage use the following procedure to return the airplane to service.

- a. Remove airplane from blocks and check tires for correct inflation. Check for correct nose gear strut inflation.
- b. Check battery and install.

- c. Remove all materials used to seal and cover openings.
- d. Remove warning placards posted at throttle and propeller.
- e. Remove and clean engine oil screen, then reinstall and safety. On airplanes equipped with an external oil filter, replace filter element and safety.
- f. Check that oil sump drain plug is installed and safetied, then service the engine with the proper grade and quantity of engine oil.

NOTE

The corrosion-preventive oil will mix with engine lubricating oil, so flushing the oil system is not necessary. Draining the oil sump will remove enough of the corrosion-preventive oil.

- g. Service the induction air filter(s) and install.
- h. Remove dehydrator plugs and spark plugs or plugs installed in spark plug holes and rotate propeller by hand several revolutions to clear corrosion-preventive oil from cylinders.
- i. Install all spark plugs and torque to the value listed in paragraph 12-6 or 12A-6. Connect spark plug leads.
- j. Check fuel strainer. Remove and clean filter screen. Check fuel tanks and fuel lines for moisture condensation and sediment, and drain enough fuel to eliminate.
- k. Model 210 and T210 Series, check hydraulic system for correct amount of hydraulic fluid.
- l. Perform a thorough pre-flight inspection, then start and warm up engine.

2-11. LEVELING. On all models except the U206 Series, remove the scuff plate at the baggage compartment door opening and use the lower sill to level the airplane longitudinally. Also, on all models, the lower surface of the pilot's upper door sill, or the top centerline of the tailcone just aft of station 138.00 may be used to longitudinally level the airplane. Corresponding points on either the upper or lower main door sills may be used to level the airplane laterally. On the U206 Series, corresponding points on the front seat rails may be used to level the airplane laterally.

2-12. SERVICING.

2-13. Servicing requirements are shown in the Servicing Chart (figure 2-4). The following paragraphs supplement figure 2-4 by adding details not included in the chart.

2-14. FUEL TANKS. All models except the Models 210G and on, and T210G and on, may be equipped with optional long range wings which contain larger fuel tanks than those in the standard wings. Beginning with the Models 210G and T210G, an area of each wing is sealed to form an integral fuel tank. Recommended fuel grade is listed in figure 2-4, and fuel capacities are given in the charts in Section 1.

2-15. **FUEL DRAINS** are located at various points in the fuel systems to provide drainage of water and sediment. Refer to Sections 13 and 13A for location of drain plugs and valves on the different models. Beginning with the 1968 models, the strainer drain control is moved from the instrument panel and re-located adjacent to the engine oil dipstick. Access to the control is through the cowling door on the left side of the upper cowl. Also, during daily inspection of the fuel strainer, if water is found in the fuel strainer, there is a possibility that the wing tank sumps, fuel lines, and fuel reservoir tanks contain water. Therefore, all fuel drain plugs should be removed and all water drained from the fuel system.

2-16. **ENGINE OIL.** Check engine lubricating oil with the oil dipstick five to ten minutes after the engine has been stopped. When checking oil level, the aircraft should be as near level as possible. Engine oil should be drained while the engine is still hot and the nose of the aircraft should be raised slightly for more positive draining of any sludge which may have collected in the engine oil sump.

On aircraft equipped with an external oil filter, change engine oil and filter element at 50-hour intervals. On aircraft not equipped with an external oil filter, change engine oil and clean oil screens **EVERY 25 HOURS**. Change oil every four months even though less than the specified hours have accumulated. Reduce these periods for prolonged operation in dusty areas, in cold climates where sludging conditions exist, or where short flights and long idle periods are encountered, which cause sludging conditions. Always change engine oil, clean filter screen, and replace filter element, whenever oil on dipstick appears dirty.

Oil capacity for each model is 12 quarts with a normal operating capacity of 10 quarts. Do NOT operate with less than the minimum-for-flight quantity of 9 quarts. To minimize loss of oil through the crankcase breather line, fill sump to the specified oil level shown on the dipstick for normal operation (flights of less than three hours). For extended flight, fill to full mark on the dipstick. If an external oil filter is installed, ONE additional quart of oil is required when filter element is changed.

New or newly overhauled engines should be operated on aviation grade straight mineral oil until the first oil change. If a detergent or ashless dispersant oil is used in a new engine, or a newly overhauled engine, high oil consumption might possibly be experienced. The anti-friction additives in detergent and ashless dispersant oil will retard "break-in" of the piston rings and cylinder walls. This condition can be avoided by the use of straight mineral oil until the first oil change, then change to detergent or ashless dispersant oil. The aircraft is delivered from Cessna with straight mineral oil of the correct viscosity.

Detergent or ashless dispersant oil conforming to Continental Motors Specification MHS-24A **MUST BE USED** at the first oil change. Multi-viscosity oil may be used to extend the operating temperature range, improve starting, turbocharger controller

operation in cold weather, and improve lubrication of the engine during the critical warm-up period, thus permitting operations through wider ranges of climatic change without the necessity of changing engine oil. The multi-viscosity grades are recommended for aircraft engines subjected to wide variation in ambient air temperatures when cold starting of the engine must be accomplished at temperatures below 40 degrees F. When adding or changing engine oil use aviation grade oil in accordance with figure 2-4.

2-17. **ENGINE INDUCTION AIR FILTERS** keep dust and dirt from entering the induction system. Dust entering the intake system is probably the greatest single cause of early engine wear; therefore, the value of maintaining the induction air filter in good clean condition can never be overstressed. The frequency with which the filter should be removed and cleaned will be determined primarily by aircraft operating conditions. Some operators prefer to hold a spare filter(s) at their home base of operation so that a clean filter(s) is always readily available for use. Under extreme dusty conditions, daily maintenance of the filter is recommended. The non-turbocharged engines use a flock-coated, oil-soaked screen filter, while the turbocharged engines use a dry type filter.

NOTE

Beginning with the 1968 models, the dry type filter is used on the non-turbocharged engine instead of the flock-coated, oil-soaked screen filter. The dry type filter is used as service parts on prior aircraft.

To service the flock-coated, oil-soaked screen filter, proceed as follows:

- a. Remove engine cowling as required, and remove filter(s) from airplane.

NOTE

The Model 210 Series use two induction air filters, located at the upper aft baffle on each side of the engine. The Model 206 Series use an induction air filter, located at the upper left aft baffle.

- b. Wash filter thoroughly, soiled face down in solvent (Federal Specification P-S-661 or equivalent).
- c. Drain and dry filter, then dip flock-coated screen filter in same grade of oil used in engine and allow excess oil to drain off.
- d. Be sure air box is clean, inspect filter and replace if damaged.

NOTE

A damaged filter may have broken filtering panels or the flock coating may be missing from the filtering panels, which will allow unfiltered air to enter the induction system. Any filter that appears doubtful should be replaced.

To service the dry type filter, proceed as follows:

- a. Remove the filter as outlined in paragraph 12A-22.
- b. Clean filter by blowing with compressed air (not over 100 psi) from direction opposite of normal air flow. Arrows on the filter frame indicate direction of normal air flow.

NOTE

Use care to prevent damage to filter element when cleaning with compressed air. Never use air pressure greater than 100 psi to clean filter.

- c. After cleaning as outlined in step "b," filter may be washed, if necessary, in a solution of warm water and a mild household detergent. A cold water solution may be used.

CAUTION

Do not use solvent or cleaning fluids to wash filter. Use only a water and household detergent solution when washing the filter.

NOTE

The dry type filter may be cleaned with compressed air a maximum of 30 times or it may be washed a maximum of 20 times. The filter should be replaced after 500 hours of engine operating time or one year, whichever should occur first. However, the filter should be replaced at anytime it is damaged.

NOTE

A damaged filter may have sharp or broken edges in the filtering panels which would allow unfiltered air to enter the induction system. Any filter that appears doubtful should be replaced.

- d. After washing, rinse filter with clear water until rinse water runs clear from filter. Allow water to drain from filter and dry with compressed air (not over 100 psi).

NOTE

The filtering panels of the filter may become distorted when wet, but they will return to their original shape when dry.

- e. Be sure induction air box and air inlet ducts to the engine are clean, inspect and replace filter if it is damaged.
- f. Install filter as outlined in paragraph 12A-22.

2-18. VACUUM SYSTEM AIR FILTERS. On airplanes equipped with a vacuum system, change the central filter every 500 hours of operation. Also change central air filter whenever suction gage reading drops below 4.6 inches of mercury. Change gyro internal filters whenever gyro instruments are overhauled. Beginning with the 1967 models, different

gyro instruments are used in the vacuum system. These instruments are not equipped with internal filters. The new instruments are smaller with a beveled box type case. Also, these gyro instruments and related plumbing are used as service parts.

2-19. BATTERY. Battery servicing involves adding distilled water to maintain the electrolyte even with the horizontal baffle plate or split ring at the bottom of the filler holes, checking cable connections, and neutralizing and cleaning off any spilled electrolyte or corrosion. Use bicarbonate of soda (baking soda) and clean water to neutralize electrolyte or corrosion. Follow with a thorough flushing with clean water. Do not allow bicarbonate of soda to enter battery. Brighten cable and terminal connection with a wire brush, then coat with petroleum jelly before connecting. Check the battery every 50 hours (or at least every 30 days), oftener in hot weather. Add only distilled water, not acid or "rejuvenators," to maintain electrolyte level in the battery. Inspect the battery box and clean and remove any evidence of corrosion.

2-20. TIRES should be maintained at the air pressure specified in the charts of Section 1. When checking tire pressure, examine tire for wear, cuts, bruises, and slippage.

NOTE


Recommended tire pressure should be maintained. Especially in cold weather, remember that any drop in temperature of the air inside a tire causes a corresponding drop in pressure.

2-21. NOSE GEAR STRUT. The nose gear strut requires periodic checking to ascertain that the strut is filled with hydraulic fluid and is inflated to the correct air pressure. All models except the Model 210 and Model T210 Series are equipped with an air filler extension to provide easier inflation while the strut is installed. To fill the nose gear strut (all models) with hydraulic fluid and air, proceed as follows:

- a. Weight tail to raise nose wheel off ground.
- b. Remove filler valve cap from filler valve or from lower end of valve extension, and depress valve core to completely deflate nose strut.
- c. Remove valve core from filler valve. It will be necessary to disconnect filler valve extension from valve at top of strut.
- d. Attach a rubber hose to the filler valve.
- e. With other end of rubber hose in a container of clean hydraulic fluid, compress and extend strut several times. This will draw fluid from container into the strut, filling strut with hydraulic fluid.
- f. After strut has been cycled several times, allow strut to extend. Holding end of rubber hose above fluid level in container, slowly compress strut, allowing excess fluid to be drained into container.
- g. While strut is compressed, remove hose and install valve core in filler valve. Connect valve extension to valve on Model 206 Series.
- h. Inflate strut to the pressure specified in the charts of Section 1 for a particular model.

NOTE

Valve core remains in strut valve.
An internal flexible cable, in the
valve extension, is used to depress
the valve core in strut valve.



NOSE GEAR STRUT

Figure 2-3. Strut Filler Valve Extension

NOTE

Keep the nose gear shock strut, especially the exposed portion of the strut piston, wiped off with a clean dry cloth to remove dust and grit which may cut the seals in the strut barrel. Do not wipe the strut piston with hydraulic fluid, since this tends to collect even more dust and grit.

2-22. NOSE GEAR SHIMMY DAMPENER (PRIOR TO 1967 MODELS). The shimmy dampener should be serviced at least every 100 hours. The dampener must be filled completely with fluid, free of entrapped air, to serve its purpose. When refilling the shimmy dampener, proceed as follows:

- Remove shimmy dampener from airplane.
- Remove filler plug from dampener.
- Submerge dampener in clean hydraulic fluid and work dampener shaft in and out to remove any entrapped air and ascertain complete filling.
- Reinstall filler plug before removing dampener from hydraulic fluid.
- Wash dampener in cleaning fluid and wipe dry with a cloth.
- Reinstall shimmy dampener in airplane.

NOTE

Keep the shimmy dampener, especially the exposed portions of the dampener shaft, wiped off with a clean dry cloth to remove dust and grit which may cut the seals in the dampener barrel. Do not wipe the shaft with hydraulic fluid, since this tends to collect even more dust and grit.

2-22A. NOSE GEAR SHIMMY DAMPENER. (1967 MODELS AND ON.) The 1967 models are equipped with a different shimmy dampener which contains a compensating mechanism within the hollow piston rod for thermal expansion and contraction of the hydraulic fluid. The shimmy dampener must be filled completely with hydraulic fluid, free of entrapped air with the compensating piston bottomed in the rod. Beginning with the serial number P206-0415, U206-0912, 21058937 and T210-0308 and on, the shimmy dampener filling procedure is changed. It is recommended that 1967 model year aircraft prior to the above mentioned serial numbers have the excessive fluid removed from the compensating mechanism as follows:

- Remove shimmy dampener from the aircraft.

- b. While holding the shimmy dampener in a vertical position with the filler plug pointed upward, loosen the filler plug.
- c. Allow the spring to bottom out the floating piston inside the shimmy dampener rod.
- d. When the fluid stops flowing, insert a length of stiff wire through the air bleed hole in the setscrew at the end of the piston rod until it touches the floating piston. The depth of insertion should be 3-13/16 inches.

NOTE

If the wire insertion is less than 3-13/16 inches, the floating piston is lodged in the shaft. If the wire cannot be used to free the piston, the rod assembly and piston should be replaced.

- e. Tighten filler plug and install shimmy dampener in aircraft.

Service the shimmy dampener as outlined in paragraph 2-22.

2-23. HYDRAULIC BRAKE SYSTEMS should be checked for the correct amount of fluid at least every 100 hours. Add hydraulic fluid at the brake master cylinders. Bleed the brake system of entrapped air whenever there is spongy response to the brake pedals. Refer to paragraph 5-56 for the bleeding procedure.

2-24. HYDRAULIC RESERVOIR (210 AND T210 SERIES). The hydraulic reservoir should be filled as necessary whenever the fluid level in the reservoir sight window shows low. Filling is accomplished by using a pressure brake bleeder or Hydro Fill unit attached to the filler fitting, located on the right firewall. Hydraulic fluid should be pumped into the filler fitting until fluid flows from the reservoir vent line.

2-25. HYDRAULIC FILTER (210 AND T210 SERIES). The hydraulic filter, located on the right firewall in the hydraulic pump pressure line, uses a fine-mesh screen to filter the hydraulic fluid. The filter screen should be removed and cleaned at the first 25, first 50 hours, and thereafter, at 100 hour intervals or whenever improper fluid circulation is suspected.

2-26. HYDRAULIC FLUID SAMPLING (210 AND T210 SERIES). At the first 50 and first 100 hours, thereafter at each 500 hours or one year, whichever should occur first, a sample of fluid should be taken and examined for sediment and discoloration. This may be done as follows:

- a. Place airplane master switch in OFF position.
- b. With landing gear control handle in down-neutral, actuate hydraulic hand pump to supply pressure to open landing gear doors.
- c. Remove door open line from nose gear door actuator cylinder. Using the hydraulic hand pump, drain off a small sample of hydraulic fluid into a non-metallic container.
- d. Reconnect nose gear door actuating cylinder line and analyze fluid sample in accordance with paragraph 5A-34.

2-27. OXYGEN SYSTEM. Refer to Section 15.

2-28. FACE MASKS. Refer to Section 15.

2-29. CLEANING.

2-30. Keeping the airplane clean is important. Besides maintaining the trim appearance of the airplane, cleaning reduces the possibility of corrosion and makes inspection and maintenance easier.


2-31. UPHOLSTERY AND INTERIOR cleaning prolongs the life of upholstery fabrics and interior trim. To clean the interior, proceed as follows:

- a. Empty all the ash trays.
- b. Brush out or vacuum clean the upholstery and carpeting to remove dirt.
- c. Wipe leather and plastic surfaces with a damp cloth.
- d. Soiled upholstery fabrics and carpet may be cleaned with a foam-type detergent, used according to the manufacturer's instructions.
- e. Oily spots and stains may be cleaned with household spot removers, used sparingly. Before using any solvent, read the instructions on the container and test it on an obscure place in the fabric to be cleaned. Never saturate the fabric with a volatile solvent; it may damage the packing and backing material.
- f. Scrape off sticky materials with a dull knife, then spot clean the area.

2-32. PLASTIC TRIM. The instrument panel, plastic trim and control knobs need only be wiped off with a damp cloth. Oil and grease on the control wheel and control knobs can be removed with a cloth moistened with Stoddard solvent.

CAUTION

Do not use gasoline, alcohol, benzene, acetone, carbon tetrachloride, fire extinguisher fluid, de-icer fluid, lacquer thinner or glass window cleaning spray. These solvents will soften and craze the plastic.



RECOMMENDED FUEL:

AVIATION GRADE---100/130 MINIMUM GRADE

*RECOMMENDED ENGINE OIL:

AVIATION GRADE---SAE 30 BELOW 40°F.

SAE 10W30 BELOW 40°F.

SAE 50 ABOVE 40°F.

HYDRAULIC FLUID:

SPEC. NO. MIL-H-5606

OXYGEN:

SPEC. NO. MIL-O-27210

*MULTI-VISCOSITY OIL WITH A RANGE OF SAE 10W30 IS RECOMMENDED FOR IMPROVED STARTING AND TURBOCHARGER CONTROLLER OPERATION IN COLD WEATHER. DETERGENT OR DISPERSANT OIL, CONFORMING TO CONTINENTAL MOTORS SPECIFICATION MHS-24, MUST BE USED.

Figure 2-4. Servicing (Sheet 1 of 4)



DAILY

- 3 FUEL TANKS:**
Fill after each flight. Refer to paragraph 2-14 for details.
- 6 FUEL TANK SUMP DRAINS:**
If quick-drain valves are installed, drain off water and sediment before the first flight of the day.
- 8 OXYGEN CYLINDER:**
Check for anticipated requirements before each flight. Refer to Section 15 for details.
- 9 PITOT AND STATIC PORTS:**
Check for obstructions before first flight of the day.
- 16 OIL DIPSTICK:**
Check on preflight. Add oil as necessary. Refer to paragraph 2-16 for details.
- 21 OIL FILLER CAP:**
Whenever oil is added, check that filler cap is tight and oil filler door is secure.
- 19 FUEL STRAINER:**
Drain off any water and sediment before the first flight of the day.



50 HOURS

- 4 INDUCTION AIR FILTER:**
Service oftener under dusty conditions. Refer to paragraph 2-17 for details.
- 20, 22 ENGINE OIL SYSTEM:**
Change engine oil and external filter element. Without external filter, change oil and clean oil screen EVERY 25 HOURS. Reduce these intervals under severe operating conditions. Refer to paragraph 2-16 for details.
- 14 BATTERY:**
Check level of electrolyte. Check at least every 30 days, oftener in hot weather. Refer to paragraph 2-19 for details.
- 24 HYDRAULIC FILTER:**
See under 100 hours.
- 23 HYDRAULIC FLUID RESERVOIR:**
At first 50 and first 100 hours, thereafter at each 500 hours or one year, whichever comes first, a sample of hydraulic fluid should be examined for sediment and discoloration as outlined in paragraph 5A-34.
- 17 SHIMMY DAMPENER (1967 MODELS AND ON):**
Check shimmy dampener compensating mechanism. Refer to paragraph 2-22A for details.

Figure 2-4. Servicing (Sheet 2 of 4)



100 HOURS

- 1 VACUUM SYSTEM OIL SEPARATOR:**
Remove, flush with solvent, and dry with compressed air.
- 2 FUEL/AIR CONTROL UNIT SCREEN:**
Remove and clean the screen.
- 5 VACUUM RELIEF VALVE FILTER SCREEN:**
Check air inlet screen for cleanliness. Remove, flush with solvent, and dry with compressed air. Remove retaining ring to remove screen.
- 6 FUEL TANK SUMP DRAINS:**
If quick-drain valves are not installed, remove plugs and drain off any water or sediment. Reinstall and resafety plugs.
- 11 FUEL RESERVOIR TANK AND/OR SELECTOR VALVE DRAINS:**
Remove plugs and drain off any water and sediment. Reinstall and resafety plugs. Some airplanes use drain valves instead of drain plugs.
- 13 BRAKE MASTER CYLINDERS:**
Check fluid level and fill as required with hydraulic fluid.
- 17 SHIMMY DAMPENER (PRIOR TO 1967 MODELS):**
Check fluid level and fill as required with hydraulic fluid. Refer to paragraph 2-22 for details.
- 24 HYDRAULIC FILTER:**
Check and clean screen at first 25 and first 50 hours, thereafter at each 100 hours.
- 19 FUEL STRAINER:**
Disassemble and clean strainer bowl and screen.



500 HOURS

- 12 VACUUM SYSTEM AIR FILTERS:**
Replace central air filter. Replace gyro instrument air filters at instrument overhaul. Refer to paragraph 2-18 for details.
- 23 HYDRAULIC FLUID RESERVOIR:**
At first 50 and first 100 hours, thereafter at each 500 hours or one year, whichever comes first, a sample of fluid should be examined for sediment and discoloration as outlined in paragraph 5A-34.



AS REQUIRED

- 10 TIRES:**
Maintain proper tire inflation as listed in the Charts in Section 1. Also refer to paragraph 2-20.
- 18 NOSE GEAR SHOCK STRUT:**
Keep strut filled and inflated to correct pressure. Refer to paragraph 2-21 for details.
- 23 HYDRAULIC FLUID RESERVOIR AND FILLER:**
Check fluid level at least every 25 hours and fill as required. Refer to paragraph 2-24.
- 7 GYRO INSTRUMENT AIR FILTERS:**
Replace instrument air filters when erratic or sluggish responses are noted with normal suction gage readings. Refer to paragraph 2-18 for details.
- 15 GROUND SERVICE RECEPTACLE (PRIOR TO 1967 MODELS) (OPT):**
Connect to 12-volt, DC, negative-ground power unit for cold weather starting and lengthy ground maintenance of the electrical system. Master switch should be turned on before connecting a generator type external power source; it should be turned off before connecting a battery type external power source. Refer to paragraph 12-81.

CAUTION

Be certain that the polarity of any external power source or batteries is correct (positive to positive and negative to negative). A polarity reversal will result in immediate damage to semiconductors in the airplane's electronic equipment.

- 15 GROUND SERVICE RECEPTACLE (1967 MODELS AND ON)(OPT):**
Connect to 12-volt, DC, negative-ground power unit for cold weather starting and lengthy ground maintenance of the airplane's electrical equipment with the exception of electronic equipment. Master switch should be turned on before connecting a generator type or battery type external power source. Refer to paragraph 12-81A.

NOTE

The ground power receptacle circuit incorporates a polarity reversal protection. Power from the external power source will flow only if the ground service plug is connected correctly to the airplane.




Figure 2-5. Construction of Induction Air Filter Servicing Box

2-33. **WINDSHIELD AND WINDOWS** should be cleaned carefully with plenty of fresh water and a mild detergent, using the palm of the hand to feel and dislodge any caked dirt or mud. A sponge, soft cloth, or chamois may be used, but only as a means of carrying water to the plastic. Rinse thoroughly, then dry with a clean moist chamois. Do not rub the plastic with a dry cloth since this builds up an electrostatic charge which attracts dust. Oil and grease may be removed by rubbing lightly with a soft cloth moistened with Stoddard solvent. Volatile solvents, such as mentioned in paragraph 2-32, must never be used since they soften and craze the plastic. After washing, the plastic windshield and windows should be cleaned with an aircraft windshield cleaner. Apply the cleaner with soft cloths, and rub with moderate pressure. Allow the cleaner to dry, then wipe it off with soft flannel cloths. A thin, even coat of wax, polished out by hand with clean soft flannel cloths, will fill in minor scratches and help prevent further scratching. Do not use a canvas cover on the windshield or windows unless freezing rain or sleet is anticipated since the cover may scratch the plastic surface.

2-34. **ALUMINUM SURFACES** require a minimum of care, but should never be neglected. The airplane may be washed with clean water to remove dirt, and with carbon tetrachloride or other non-alkaline grease solvents to remove oil and/or grease. Household type detergent soap powders are effective cleaners, but should be used cautiously since some of them are strongly alkaline. Many good aluminum cleaners, polishers, and waxes are available from commercial suppliers of aircraft products.

2-35. **PAINTED SURFACES.** The painted exterior surfaces of the airplane, under normal conditions, require a minimum of polishing or buffing. Approximately 15 days are required for acrylic or lacquer paint to cure completely and approximately 90 days are required for vinyl paint to cure completely; in most cases, the curing period will have been completed prior to delivery of the airplane. In the event that polishing or buffing is required within the curing period, it is recommended that the work be done by an experienced painter. Generally, the painted surfaces can be kept bright by washing with water and mild soap, followed by a rinse with water and drying with cloths or a chamois. Harsh or abrasive soaps or detergents which cause corrosion or make scratches should never be used. Remove stubborn oil and grease with a cloth moistened with Stoddard solvent. After the curing period, the airplane may be waxed with a good automotive wax. A heavier coating of wax on the leading edges of the wings and tail and on the engine nose cap will help reduce the abrasion encountered in these areas.

2-36. **ENGINE COMPARTMENT** cleaning is essential to minimize any danger of fire, and for proper inspection of engine components. The engine and engine compartment may be washed down with a suitable solvent, then dried thoroughly.

CAUTION

Particular care should be given to electrical equipment before cleaning. Solvent should not be allowed to enter magnetos, starters, alternators, voltage regulators, and the like. Hence, these components should be protected before saturating the engine with solvent. Any oil, fuel, and air openings on the engine and accessories should be covered before washing the engine with solvent. Caustic cleaning solutions should be used cautiously and should always be properly neutralized after their use.

WARNING

Remove insulation blankets from rear exhaust crossover pipe before cleaning the engine with solvent. Use care to prevent saturating the insulation blankets on the nose caps. Insulation blankets saturated with solvent create a possible fire hazard when the engine is started.

2-37. **PROPELLERS** should be wiped occasionally with an oily cloth to remove grass and bug stains from the propeller blades. In salt water areas this will assist in corrosion-proofing the propeller.

2-38. **WHEELS** should be washed periodically and examined for corrosion, chipped paint, and cracks or dents in the wheel castings. Sand smooth, prime, and repaint minor defects.

2-39. LUBRICATION.

2-40. Lubrication requirements are shown on the Lubrication Chart (figure 2-6). Before adding grease to grease fittings, wipe off all dirt. Lubricate until new grease appears around parts being lubricated, and wipe off excess grease. The following paragraphs supplement this figure by adding details.

2-41. **NOSE GEAR TORQUE LINKS.** Lubricate nose gear torque links every 50 hours. When operating in dusty conditions, more frequent lubrication is recommended.

2-42. **TACHOMETER DRIVE SHAFT.** Refer to Section 16 for lubrication.

2-43. **WHEEL BEARING LUBRICATION.** It is now recommended that nose and main wheel bearings be cleaned and repacked at the first 100-hour inspection and at each 500-hour inspection thereafter. If more than the usual number of take-off and landings are made, extensive taxiing is required, or the airplane is operated in dusty areas or under seacoast conditions, it is recommended that cleaning and lubrication of wheel bearings be accomplished at each 100-hour inspection.

FREQUENCY (HOURS)

50

100

500

METHOD OF APPLICATION



HAND



GREASE
GUN



OIL
CAN



SYRINGE
(FOR POWDERED
GRAPHITE)

WHERE NO INTERVAL IS SPECIFIED,
LUBRICATE AS REQUIRED AND
WHEN ASSEMBLED OR INSTALLED.

NOTE

The military specifications listed below are not mandatory,
but are intended as guides in choosing satisfactory materials.
Products of most reputable manufacturers meet or exceed
these specifications.

LUBRICANTS

PG — MIL-G-6711	POWDERED GRAPHITE
GG — MIL-G-7711	GENERAL PURPOSE GREASE
GA — MIL-G-25760	AIRCRAFT WHEEL BEARING GREASE
GH — MIL-G-23827	AIRCRAFT AND INSTRUMENT GREASE
GL — MIL-G-21164	HIGH AND LOW TEMPERATURE GREASE
OG — MIL-L-7870	GENERAL PURPOSE OIL
PL — VV-P-236	PETROLATUM




Figure 2-6. Lubrication (Sheet 1 of 4)




Figure 2-6. Lubrication (Sheet 2 of 4)





Figure 2-6. Lubrication (Sheet 3 of 4)

SPRAY BOTH SIDES OF SHADED AREAS WITH ELECTROFILM LUBRI-BOND "A" WHICH IS AVAILABLE IN AEROSOL SPRAY CANS, OR AN EQUIVALENT LUBRICANT. TORQUE ATTACHING BOLT TO 10-20 LB-IN.

NOSE GEAR
DOWNLOCK
MECHANISM



NOTES

On the Model U206 Series rear cargo doors, do not lubricate the surfaces of the hooks which engage the latch plates on the upper and lower door sills.

Sealed bearings require no lubrication.

McCauley propellers are lubricated at overhaul and require no other lubrication.

Do not lubricate roller chains or cables except under seacoast conditions. Wipe with a clean, dry cloth.

Lubricate unsealed pulley bearings, rod ends, Oilite bearings, pivot and hinge points, and any other friction point obviously needing lubrication, with general purpose oil every 1000 hours or oftener if required.

Paraffin wax rubbed on seat rails will ease sliding the seats fore and aft.

Lubricate door latching mechanism with "Mechanics Miracle White" or equivalent lubricant, applied sparingly to friction points, every 1000 hours or oftener if binding occurs. No lubrication is recommended on the rotary clutch.

Figure 2-6. Lubrication (Sheet 4 of 4)

INSPECTION

To avoid repetition throughout the inspection, general points to be checked are given below. In the inspection, only the items to be checked are listed; details as to how to check, or what to check for, are excluded. The inspection covers several different models. Some items apply only to specific models, and some items are optional equipment that may not be found on a particular airplane. Check FAA Airworthiness Directives and Cessna Service Letters for compliance at the time specified by them. Federal Aviation Regulations require that all civil aircraft have a periodic (annual) inspection as prescribed by the administrator, and performed by a person designated by the administrator. The Cessna Aircraft Company recommends a 100-hour periodic inspection for the airplane.

CHECK AS APPLICABLE:

MOVABLE PARTS for: lubrication, servicing, security of attachment, binding, excessive wear, safetying, proper operation, proper adjustment, correct travel, cracked fittings, security of hinges, defective bearings, cleanliness, corrosion, deformation, sealing, and tensions.

FLUID LINES AND HOSES for: leaks, cracks, dents, kinks, chafing, proper radius, security, corrosion, deterioration, obstructions, and foreign matter.

METAL PARTS for: security of attachment, cracks, metal distortion, broken spotwelds, corrosion, condition of paint, and any other apparent damage.

WIRING for: security, chafing, burning, defective insulation, loose or broken terminals, heat deterioration, and corroded terminals.

BOLTS IN CRITICAL AREAS for: correct torque in accordance with the torque values given in the chart in Section 1, when installed or when visual inspection indicates the need for a torque check.

FILTERS, SCREENS, AND FLUIDS for: cleanliness, contamination and/or replacement at specified intervals.

AIRPLANE FILE.

Miscellaneous data, information, and licenses are a part of the airplane file. Check that the following documents are up-to-date and in accordance with current Federal Aviation Regulations. Most of the items listed are required by the United States Federal Aviation Regulations. Since the regulations of other nations may require other documents and data, owners of exported aircraft should check with their own aviation officials to determine their individual requirements.

To be displayed in the airplane at all times:

1. Aircraft Airworthiness Certificate (Form FAA 1362B).
2. Aircraft Registration Certificate (Form FAA 500A).
3. Aircraft Radio Station License, if transmitter installed (Form FCC 404-2).

To be carried in the airplane at all times:

1. Weight and Balance, and associated papers (Latest copy of the Repair and Alteration Form, Form FAA 337, if applicable).
2. Aircraft Equipment List.

To be made available upon request:

1. Aircraft Log Book and Engine Log Book.

ENGINE RUN-UP.

Before beginning the step-by-step inspection, start, run up, and shut down the engine in accordance with instructions in the Owner's Manual. During the run-up, observe the following, making note of any discrepancies or abnormalities:

1. Engine temperatures and pressures.
2. Static rpm.
3. Magneto drop (See Owner's Manual).
4. Engine response to changes in power.
5. Any unusual engine noises.
6. Propeller response (See Owner's Manual).
7. Fuel tank selector valve; operate engine on each tank position and off position long enough to make sure the valve functions properly.
8. Idling speed and mixture; proper idle cut-off.
9. Alternator and ammeter.
10. Suction Gage.
11. Fuel flow indicator.

After the inspection has been completed, an engine run-up should again be performed to ascertain that any discrepancies or abnormalities have been corrected.

SCOPE AND PREPARATION.

If the airplane is NOT equipped with an external oil filter, the engine oil should be changed and the oil screen cleaned EVERY 25 HOURS.

The 50-hour inspection includes a visual check of the engine, propeller, and aircraft exterior for any apparent damage or defects; an oil change and filter element change on aircraft equipped with an external oil filter; and accomplishment of lubrication and servicing requirements. Remove propeller spinner and engine cowling, and replace after the inspection has been completed.

The 100-hour (or annual) inspection includes everything in the 50-hour inspection. Also loosen or remove all fuselage, wing, empennage, and upholstery inspection doors, plates, and fairings as necessary to perform a thorough, searching inspection of the airplane. Replace after the inspection has been completed.

NOTE

Numbers appearing in the "AS SPECIFIED" column refer to the data listed at the end of the inspection chart.

PROPELLER.

- | | AS SPECIFIED | EACH 100 HOURS | EACH 50 HOURS |
|--------------------------------------|--------------|----------------|---------------|
| 1. Spinner and spinner bulkhead----- | | | |
| 2. Blades ----- | | | |
| 3. Hub ----- | | | |
| 4. Bolts and nuts ----- | | | |
| 5. Governor and control----- | | | |

ENGINE COMPARTMENT.

Check for evidence of oil, hydraulic fluid and fuel leaks, then clean entire engine and compartment, if needed, prior to inspection.

- | | | | |
|---|--|--|--|
| 1. Engine oil, screen, filler cap, dipstick, drain plug and external filter element ----- | | | |
| 2. Oil cooler----- | | | |
| 3. Induction air filter (Also see paragraph 2-17) ----- | | | |
| 4. Induction airbox, air valves, doors, and controls ----- | | | |
| 5. Cold and hot air hoses----- | | | |
| 6. Engine baffles ----- | | | |

1

		AS SPECIFIED	
		EACH 100 HOURS	
		EACH 50 HOURS	
7.	Cylinders, rocker box covers, and push rod housings-----	●	
8.	Crankcase, oil sump, accessory section, and front crankshaft seal -----	●	
9.	All lines and hoses-----	●	
10.	Intake and exhaust systems (Also see paragraphs 12-23 and 12A-26)-----	●	
11.	Ignition harness -----	●	
12.	Spark plugs and compression check -----		●
13.	Crankcase, hydraulic, and vacuum system breather lines -----	●	
14.	Electrical wiring -----	●	
15.	Vacuum pump, oil separator, and relief valve -----	●	
16.	Vacuum relief valve screen -----		●
17.	Engine controls and linkage-----	●	
18.	Engine shock mounts, engine mount structure, and ground straps -----	●	
19.	Cabin heater valves, doors, and controls-----	●	
20.	Starter, solenoid, electrical connections -----	●	
21.	Starter brushes, brush leads, and commutator-----		2
22.	Alternator, drive belt, pulley, and electrical connections -----	●	
23.	Alternator brushes, brush leads, and slip ring-----		2
24.	Voltage regulator mounting and electrical leads -----	●	
25.	Magnetos (externally) and electrical connections -----	●	
26.	Magneto timing -----		3
27.	Magneto breaker compartment (Also see paragraph 12-68)-----		3
28.	Fuel injection fuel-air control unit, fuel pump, fuel manifold valve, fuel lines, and nozzles -----	●	
29.	Fuel-air control unit screen -----		●
30.	Hydraulic pump-----		●
31.	Firewall -----		●
32.	Engine cowling -----	●	
33.	Cowl flaps and control-----	●	

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
 SERVICE MANUAL

	AS SPECIFIED	
	EACH 100 HOURS	
	EACH 50 HOURS	
34. Turbocharger	•	4
35. Turbocharger pressurized vent lines to fuel pump, discharge nozzles, and fuel flow gage ...	•	
36. Turbocharger mounting brackets	•	
37. Waste gate, actuator and linkage, and controller	•	4
38. All oil lines to turbocharger, waste gate, and controller	•	
39. Exhaust system (Also see paragraph 12A-26)	•	
40. Exhaust system insulation blankets (Also see figure 12A-4)	•	
41. Engine fuel injection nozzles.....		10
AIRFRAME		
1. Aircraft exterior	•	
2. Aircraft structure (Also see figure 4-3)	•	
3. Windows, windshield, and doors	•	
4. Seats, stops, seat rails, upholstery, structure, and seat mounting.....	•	
5. Safety belts and attaching brackets.....	•	
6. Control column bearings, sprockets, pulleys, cables, chains, and turnbuckles	•	
7. Control lock, control wheel, and control column mechanism	•	
8. Instruments and markings.....	•	
9. Gyro filters and central air filter (Also see paragraph 2-18).....	•	5
10. Magnetic compass compensation		4
11. Instrument wiring and plumbing	•	
12. Instrument panel, shock mounts, ground straps, cover, and decals and labeling	•	
13. Defrosting, heating, ventilating systems, and controls	•	
14. Cabin upholstery, trim, sun visors, and ashtrays	•	
15. Area beneath floor, lines, hoses, wires, and control cables	•	
16. Electrical horns, lights, switches, circuit breakers, and clock fuse	•	
7. Exterior lights.....	•	

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
 SERVICE MANUAL

	AS SPECIFIED	
	EACH 100 HOURS	
	EACH 50 HOURS	
18. Pitot and static systems	•	
19. Stall warning sensing unit, and pitot and stall warning heaters	•	
20. Radios and radio controls	•	
21. Radio antennas	•	
22. Battery, battery box, and battery cables	•	
23. Battery electrolyte level (Also see paragraph 2-19)	•	
24. Oxygen system	•	6

CONTROL SYSTEMS

In addition to the items listed below, always check for correct direction of movement, correct travel, and correct cable tension.

1. Cables, terminals, pulleys, pulley brackets, cable guards, turnbuckles, and fairleads	•	
2. Chains, terminals, sprockets, and chain guards	•	
3. Trim control wheels, indicators, actuator, and bungee	•	
4. Travel stops	•	
5. All decals and labeling	•	
6. Flap control switch, flap rollers and tracks, flap position transmitter and linkage, electric motor and flap position indicator, flap transmission, and synchronizing system	•	
7. Elevator downspring system	•	
8. Rudder pedal assemblies and linkage	•	
9. Skin and structure of control surfaces and trim tabs	•	
10. Balance weight attachment	•	

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
 SERVICE MANUAL

AS SPECIFIED
EACH 100 HOURS
EACH 50 HOURS

FUEL SYSTEM

- | | | |
|--|---|---|
| 1. Fuel strainer, drain valve and control | • | |
| 2. Fuel strainer screen and bowl | • | |
| 3. Electric fuel pump, throttle switch, and electric connections | • | |
| 4. Fuel tanks, fuel reservoir tanks, fuel lines, drains, filler caps, and placards | • | 4 |
| 5. Drain fuel and check tank interior, attachment and outlet screens | | |
| 6. Fuel vents and vent valves | • | |
| 7. Fuel selector valve and placards | • | |
| 8. Fuel quantity gages and transmitter units | • | |
| 9. Engine primer | • | |
| 10. Vapor return line and check valve | • | |
| 11. Turbocharger vent system | • | |
| 12. Perform a fuel quantity indicating system operational test. Refer to Section 16 for detailed accomplishment instructions. | | 9 |

LANDING GEAR

- | | | |
|--|---|--|
| 1. Brake fluid, lines and hoses, linings, disc and clips, brake assemblies and master cylinders..... | • | |
| 2. Main gear wheels, wheel bearings, step and spring strut, tires and fairings..... | • | |
| 3. Nose gear strut servicing, and shimmy dampener servicing (refer to paragraph 2-22A.) | • | |
| 4. Nose gear wheel, wheel bearings, strut, steering system, shimmy dampener, tire fairing and torque links | • | |
| 5. Parking brake system | • | |

LANDING GEAR RETRACTION SYSTEM

NOTE: When performing inspection of the landing gear retraction system, a hydraulic power source is required. Refer to paragraphs 5A-122 through 5A-139 for Hydro Test operation.

- | | | |
|---|---|---|
| 1. Operate the landing gear through five fault-free cycles, noting cycle time. Refer to paragraphs 5-144 and 5-150..... | • | 7 |
|---|---|---|

AS SPECIFIED
EACH 100 HOURS
EACH 50 HOURS

2. Check landing gear doors for at least ½-inch clearance with any part of landing gear during operation, and for proper fit when closed
3. Check down position of the main gear struts. (Refer to Figure 5A-10.).....
4. Check main gear downlock engagement. (Refer to Figures 5A-10 and 5A-18.)
5. Check overcenter adjustment of retracted main gear downlock. (Refer to Figure 5A-18.).....
6. Check main gear uplock hook operation. (Refer to paragraph 5A-106.).....
7. Check that main gear snubbing action occurs. (Refer to paragraph 5A-51.)
8. Check adjustment and operation of main gear up and down indicator switches, nose gear up and down indicator switches and nose gear safety switch. (Refer to paragraphs 5A-109, 5A-110, 5A-115, 5A-116, and 5A-117.) Also check indicator lights for proper operation.....
9. Check nose gear downlock adjustments. (Refer to paragraph 5A-113.).....
10. Check nose gear uplock operation. (Refer to paragraph 5A-114.)
11. Check adjustment of landing gear handle up-down switch.
(Refer to paragraph 5A-120.)
12. Check all hydraulic system components for security, hydraulic leaks and any apparent damage to components or mounting structure.

NOTE

Hydraulic fluid for the brakes passes through the actuator-to-saddle plate attachment and is sealed by an O-ring. After the bolts are checked for tightness, check that no leakage of brake fluid occurs with pressure applied to the brake pedals.

13. Check gear and door linkage for security, wear of pivot points and bearings, and for distortion or other damage
14. Check main gear strut-to-saddle attachment
15. Check condition of all springs
16. Clean hydraulic filter. (Refer to paragraph 5A-12.)
17. Hydraulic fluid contamination check. (Refer to paragraph 5A-34.).....

7
8

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
SERVICE MANUAL

	AS SPECIFIED
	EACH 100 HOURS
	EACH 50 HOURS
18. Check operation of emergency hand pump	•

SPECIFIED INSPECTIONS

1. Each 25 hours, if NOT equipped with an external filter.
2. Starters each 200 hours; alternators each 500 hours.
3. Check timing each 200 hours; check breaker compartment each 500 hours, unless timing is off.
4. Each 1000 hours or to coincide with engine overhaul.
5. Replace central filter each 500 hours; gyro filters at instrument overhaul.
6. Refer to Section 15 for details.
7. At first 25 hours and first 50 hours of operation; at each 100-hour inspection thereafter.
8. At first 50 and first 100 hours, thereafter at each 500 hours or one year, whichever occurs first.
9. Fuel quantity indicating system operational test is required every 12 months. Refer to Section 16 for detailed accomplishment instructions.
10. At the first 100-hour inspection on new, rebuilt or overhauled engines, remove and clean the fuel injection nozzles. Thereafter, the fuel injection nozzles must be cleaned at 300-hour intervals or more frequently if fuel stains are noted.

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
SERVICE MANUAL

2-44. COMPONENT TIME LIMITS

1. General

- A. Most components listed throughout Section 2 should be inspected as detailed elsewhere in this section and repaired, overhauled or replaced as required. Some components, however, have a time or life limit, and must be overhauled or replaced on or before the specified time limit.

NOTE: The terms overhaul and replacement as used within this section are defined as follows:

Overhaul – Item may be overhauled as defined in FAR 43.2 or it can be replaced.

Replacement – Item must be replaced with a new item or a serviceable item that is within its service life and time limits or has been rebuilt as defined in FAR 43.2.

- B. This section provides a list of items which must be overhauled or replaced at specific time limits. Table 1 lists those items which Cessna has mandated must be overhauled or replaced at specific time limits. Table 2 lists component time limits which have been established by a supplier to Cessna for the supplier's product.
- C. In addition to these time limits, the components listed herein are also inspected at regular time intervals set forth in the Inspection Charts, and may require overhaul/replacement before the time limit is reached based on service usage and inspection results.

2. Cessna-Established Replacement Time Limits

- A. The following component time limits have been established by Cessna Aircraft Company.

Table 1: Cessna-Established Replacement Time Limits

COMPONENT	REPLACEMENT TIME	OVERHAUL
Restraint Assembly Pilot, Copilot, And Passenger Seats	10 years	NO
Trim Tab Actuator	1,000 hours or 3 years, whichever occurs first	YES
Vacuum System Filter	500 hours	NO
Vacuum System Hoses	10 years	NO
Pitot and Static System Hoses	10 years	NO
Vacuum Relief/Regulator Valve Filter (If Installed)	500 hours	NO
Engine Compartment Flexible Fluid Carrying Teflon Hoses (Cessna- Installed) Except Drain Hoses (Drain hoses are replaced on condition)	10 years or engine overhaul whichever occurs first (Note 1)	NO

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
SERVICE MANUAL

COMPONENT	REPLACEMENT TIME	OVERHAUL
Engine Compartment Flexible Fluid-Carrying Rubber Hoses (Cessna-Installed) Except Drain Hoses (Drain hoses are replaced on condition)	5 years or engine overhaul, whichever occurs first (Note 1)	NO
Engine Air Filter	500 hours or 36 months, whichever occurs first (Note 9)	NO
Engine Mixture, Throttle, and Propeller Controls	At engine TBO	NO
Check Valve (Turbocharger Oil Line Check Valve)	Every 1,000 hours of operation (Note 10)	NO
Oxygen Bottle – Lightweight Steel (ICC-3HT, DOT-3HT)	Every 24 years or 4380 cycles, whichever occurs first	NO
Oxygen Bottle – Composite (DOT-E8162)	Every 15 years	NO
Engine-Driven Dry Vacuum Pump Drive Coupling (Not lubricated with engine oil)	6 years or at vacuum pump replacement, whichever occurs first	NO
Engine-Driven Dry Vacuum Pump (Not lubricated with engine oil)	500 hours (Note 11)	NO
Standby Dry Vacuum Pump	500 hours or 10 Years, whichever occurs first (Note 11)	NO

3. Supplier-Established Replacement Time Limits

- A. The following component time limits have been established by specific suppliers and are reproduced as follows:

Table 2: Supplier-Established Replacement Time Limits

COMPONENT	REPLACEMENT TIME	OVERHAUL
ELT Battery	(Note 3)	NO
Vacuum Manifold	(Note 4)	NO
Magnetos	(Note 5)	YES
Engine	(Note 6)	YES
Engine Flexible Hoses (TCM-Installed)	(Note 2)	NO
Auxiliary Electric Fuel Pump	(Note 7)	YES
Propeller	(Note 8)	YES

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
SERVICE MANUAL

NOTES:

NOTE 1: This life limit is not intended to allow flexible fluid-carrying Teflon or rubber hoses in a deteriorated or damaged condition to remain in service. Replace engine compartment flexible Teflon (AE3663819BXXXX series hose) fluid-carrying hoses (Cessna-installed only) every ten years or at engine overhaul, whichever occurs first. Replace engine compartment flexible rubber fluid-carrying hoses (Cessna-installed only) every five years or at engine overhaul, whichever occurs first (this does not include drain hoses). Hoses which are beyond these limits and are in a serviceable condition, must be placed on order immediately and then be replaced within 120 days after receiving the new hose from Cessna.

NOTE 2: For TCM engines, refer to Teledyne Continental Service Bulletin SB97-6, or latest revision.

NOTE 3: Refer to FAR 91.207 for battery replacement time limits.

NOTE 4: Refer to Airborne Air & Fuel Product Reference Memo No. 39, or latest revision, for replacement time limits.

NOTE 5: For airplanes equipped with Slick magnetos, refer to Slick Service Bulletin SB2-80C, or latest revision, for time limits.

For airplanes equipped with TCM/Bendix magnetos, refer to Teledyne Continental Motors Service Bulletin No. 643, or latest revision, for time limits.

NOTE 6: Refer to Teledyne Continental Service Information Letter SIL98-9, or latest revision, for time limits.

NOTE 7: Refer to Cessna Service Bulletin SEB94-7 Revision 1/Dukes Inc. Service Bulletin No. 0003, or latest revision.

NOTE 8: Refer to the applicable McCauley Service Bulletins and Overhaul Manual for replacement and overhaul information.

NOTE 9: The air filter may be cleaned. Refer to Section 2 of this service manual. For airplanes equipped with an air filter manufactured by Donaldson, refer to Donaldson Aircraft Filters Service Instructions P46-9075 for detailed servicing instructions.

The address for Donaldson Aircraft Filters is:

Customer Service
115 E. Steels Corners RD
Stow, OH 44224

Do not overservice the air filter. Overservicing increases the risk of damage to the air filter from excessive handling. A damaged/worn air filter may expose the engine to unfiltered air and result in damage/excessive wear to the engine.

NOTE 10: Replace the turbocharger oil line check valve every 1,000 hours of operation (Refer to Cessna Service Bulletin SEB91-7 Revision 1, or latest revision).

NOTE 11: Replace engine-driven dry vacuum pump not equipped with a wear indicator every 500 hours of operation, or replace according to the vacuum pump manufacturer's recommended inspection and replacement interval, whichever occurs first.

Replace standby vacuum pump not equipped with a wear indicator every 500 hours of operation or replace according to the vacuum pump manufacturer's recommended inspection and replacement interval, whichever occurs first.

For a vacuum pump equipped with a wear indicator, replace pump according to the vacuum pump manufacturer's recommended inspection and replacement intervals.

SECTION 3

FUSELAGE

TABLE OF CONTENTS	Page	SEATS	
WINDOWS AND WINDSHIELDS	3-1	Individual Seats	3-8
Cleaning	3-1	Two-Place Seats	3-13
Waxing	3-1	Power Seats	3-13
Repairs	3-1	Child's Seat	3-13
Scratches	3-1	Repair of Seat Structure	3-13
Cracks	3-2	CABIN UPHOLSTERY	3-15
WINDSHIELDS	3-2	Upholstery Materials and Tools	3-15
Removal	3-2	Soundproofing	3-15
Replacement	3-4	Cabin Headliner Removal	3-15
MOVABLE WINDOWS	3-4	Cabin Headliner Installation	3-15
FIXED WINDOWS	3-4	Upholstery Side Panels	3-15
Wrap-Around Rear Windows	3-4	Windlace (Door Seal)	3-15
Installation of Rear Windows	3-4	Carpeting	3-15
CABIN DOORS	3-4	Baggage Compartment Upholstery	3-16
Removal and Installation	3-4	CARGO TIE-DOWN PROVISIONS	3-16
Cabin Door Weatherstrip	3-4	CARGO PACK - MODEL 206 SERIES	3-17
Adjustment of Cabin Door Wedges	3-4	Removal	3-17
Door Latches	3-4	Installation	3-17
Adjustment	3-4	Removal of Cowl Flap Baffles and	
Door Lock	3-4	Control Extensions	3-17
BAGGAGE DOORS	3-8	Installation of Cowl Flap Baffles and	
Removal and Installation	3-8	Control Extensions	3-19
CARGO DOORS	3-8	GLIDER TOW HOOK	3-19
Removal and Installation	3-8	REAR VIEW MIRROR	3-19
Removal and Installation of Latches	3-8	CASKET CARRIER	3-22
Rigging of Rear Cargo Door Latch	3-8	Installation	3-22
		Removal	3-22

3-1. WINDOWS AND WINDSHIELDS.

3-2. CLEANING. (See paragraph 2-33.)

3-3. WAXING will fill in minor scratches in clear plastic and help protect the surface from further abrasion. Use a good grade of commercial wax applied in a thin, even coat. Bring the wax to a high polish by rubbing lightly with a clean, dry flannel cloth.

3-4. REPAIRS. Damaged window panels and windshield should be removed and replaced if damage is extensive. However, certain repairs as prescribed in the following paragraph can be made successfully without removing the damaged part from the airplane. Three types of temporary repairs for cracked plastic are possible. No repairs of any kind are recommended on highly-stressed or compound curves where the repair would be likely to affect the pilot's field of vision. Curved areas are more difficult to repair than flat areas and any repaired area is both structurally and optically inferior to the original surface.

3-5. SCRATCHES on clear plastic surfaces can be removed by hand-sanding operations followed by buffing and polishing, if the following steps are accomplished carefully.

a. Wrap a piece of No. 320 (or finer) sandpaper or abrasive cloth around a rubber pad or wood block. Rub the surface around the scratch with a circular motion, keeping the abrasive constantly wet with clean water to prevent scratching the surface further. Use minimum pressure and cover an area large enough to prevent the formation of "bull's eyes" or other optical distortions.

b. Continue the sanding operation, using progressively finer grade of abrasives until the scratches disappear.

c. When the scratches have been removed, wash the area thoroughly with clean water to remove all gritty particles. The entire sanded area will be clouded with minute scratches which must be removed to restore transparency.

d. Apply fresh tallow or buffing compound to a motor-driven buffing wheel. Hold the wheel against the plastic surface, moving it constantly over the damaged area until the cloudy appearance disappears. A 2000-foot-per-minute surface speed is recommended to prevent overheating and distortion.

NOTE

Polishing can be accomplished by hand but it will require a considerably longer period of time to attain the same result as a buffing wheel.




Figure 3-1. Repair of Windows and Windshields

e. When buffing is finished, wash the area thoroughly and dry it with a soft flannel cloth. Allow the surface to cool and inspect the area to determine if full transparency has been restored. Then apply a thin coat of hard wax and polish the surface lightly with a clean flannel cloth.

NOTE

Rubbing the plastic surface with a dry cloth will build up an electrostatic charge which attracts dirt particles and may eventually cause scratching of the surface. After the wax has hardened, dissipate this charge by rubbing the surface with a slightly damp chamois. This will also remove the dust particles which have collected while the wax is hardening.

f. Minute hairline scratches can often be removed by rubbing with commercial automobile body cleaner or fine-grade rubbing compound. Apply with a soft, clean, dry cloth or imitation chamois.

3-6. CRACKS. (See figure 3-1.)

a. When a crack appears in a panel, drill a hole at the end of the crack to prevent further spreading. The hole should be approximately 1/8 inch in diameter, depending on the length of the crack and thickness of the material.

b. Temporary repairs to flat surfaces can be effected by placing a thin strip of wood over each side of the surface and then inserting small bolts through the wood and plastic. A cushion of sheet

rubber or airplane fabric should be placed between the wood and plastic on both sides.

c. A temporary repair can be made on a curved surface by placing fabric patches over the affected area. Secure the patches with airplane dope, Specification No. MIL-D-5549; or lacquer, Specification No. MIL-L-7178. Lacquer thinner, Specification No. MIL-T-6094 can also be used to secure the patch.

d. A temporary repair can be made by drilling small holes along both sides of the crack 1/4 to 1/8 inch apart and lacing the edges together with a soft wire. Small-stranded antenna wire makes a good temporary lacing material. This type of repair is used as a temporary measure only, and as soon as facilities are available the panel should be replaced.

3-7. WINDSHIELDS. (See figure 3-2.) Windshields are single-piece, "free-blown" acrylic plastic panels set in sealing strips and held by formed retaining strips that are secured to the fuselage by means of screws and rivets. Presstite No. 579.6 sealing compound used in conjunction with an adhesive-backed felt strip is applied to all edges of the windshield except the wing root area. The wing root fairing has a heavy felt strip that completes the windshield sealing.

3-8. REMOVAL.

- a. Drill out rivets securing the top retainer strip, and remove screws securing the front retainer strip.
- b. Remove wing fairings over windshield edges.
- c. Pull windshield straight forward, out of side retainers.




Figure 3-2. Cabin Window Retainers and Seals

3-9. REPLACEMENT.

- a. Apply felt strip and sealing compound to all edges of windshield to prevent leaks.
- b. Reverse steps listed in preceding paragraph to install a windshield.
- c. When installing a new windshield, check the fit and carefully file or grind away any excess plastic.
- d. Use care not to crack windshield when installing. Starting at an upper corner and gradually working the windshield into position is recommended.

3-10. MOVABLE WINDOWS. (See figure 3-3.)

The movable windows, hinged at the top, are installed in the doors. Window assemblies, that is the clear plastic and frame units, may be replaced by removing the hinge pins and disconnecting the window stop. To remove the frame from the plastic panel, drill out the blind rivets at the frame splice. When replacing the plastic panel in a frame, make sure that the sealing strip and an adequate coating of Presstite No. 579.6 sealing compound is used around all edges of the plastic panel.

3-11. FIXED WINDOWS. (See figure 3-2.) Fixed windows are mounted in sealing strips and sealing compound, and are held in place by various retainer strips. To replace the side windows, remove upholstery and trim panels, then drill out rivets as necessary to remove the retainer strips. All windows on Model 210 and T210 airplanes are double except the three rear windows and the movable window on the cabin door.

3-12. WRAP-AROUND REAR WINDOWS. The fixed windows extend around the rear of the cabin on all 200-Series aircraft. The curved triangular rear side windows are set in retaining and sealing strips and are removed from inside the cabin after rivets securing the retaining strips are drilled out. Removal of the rectangular rear window requires that the three rows of rivets immediately forward and above the window be drilled out. Remove screws securing the retainer strips at each side of the window and deflect retainer strips up and aft from skin splice above the window. Remove window from outside of the airplane.

3-13. INSTALLATION OF REAR WINDOWS. Installation of the "wrap-around" rear windows may be accomplished by reversing the procedures listed in paragraph 3-12, observing the following precautions:

- a. Check the fit of a new window and carefully file or grind away any excess plastic.
- b. Use care not to crack plastic when installing.
- c. Be sure to use sealing strips and sealing compound to prevent leaks.

3-14. CABIN DOORS. (See figure 3-3.)

3-15. REMOVAL AND INSTALLATION. Removal of cabin doors is accomplished either by removing the screws which attach the hinges or by removing the hinge pins. The door stop must also be dis-

connected. Some airplanes are equipped with removeable hinge pins to facilitate door removal. If the permanent hinge pins were removed, they may be replaced by clevis pins secured with cotter pins, or new hinge pins may be installed and "spin-bradded." When fitting a new door, some trimming of the door skin at the edges and some reforming with a soft mallet may be necessary to achieve a good fit.

3-16. CABIN DOOR WEATHERSTRIP is cemented around all edges of the door. New weatherstrip may be applied after mating surfaces of weatherstrip and door are clean, dry and free from oil or grease. Apply a thin, even coat of adhesive to each surface and allow to dry until tacky before pressing strip in place. Minnesota Mining and Manufacturing Co. No. EC-880 cement is recommended.

3-17. ADJUSTMENT OF CABIN DOOR WEDGES.

200-Series aircraft contain wedges at the upper forward edge of the door which aid in preventing air leaks at this point. They engage as the door is closed. Several attaching holes are located in the wedges, and the set of holes which gives best results should be selected.

3-18. DOOR LATCH. (See figure 3-6.) The cabin door latch is a push-pull bolt type, utilizing a rotary clutch for positive bolt engagement. As the door is closed, teeth on the underside of the bolt engage the gear teeth on the clutch. The clutch gear rotates in one direction only, and holds the door until the handle is moved to the LOCK position, driving the bolt into the slot.


3-19. ADJUSTMENT OF DOOR LATCH. Adjustment of latch or clutch cover is afforded by oversize and/or slotted holes. This adjustment ensures sufficient gear-to-bolt engagement and proper alignment.

NOTE

Lubricate door latch per Section 2. No lubrication is recommended for the rotary clutch.

3-20. DOOR LOCK. Standard equipment on 200-Series aircraft includes, in addition to interior locks, a cylinder and key type lock on the left door. If the lock is to be replaced, the new one may be modified to accept the original key. This is desirable, as the same key is used for the ignition switch and the cabin door lock. After removing the old lock from the door, proceed as follows:

- a. Remove lock cylinder from new housing.
- b. Insert original key into new cylinder and file off any protruding tumblers flush with cylinder. Without removing key, check that cylinder rotates freely in housing.
- c. Install lock assembly in door, and check lock operation with door open.
- d. Destroy new key and disregard code number on cylinder.




1. Upholstery Clip
2. Upholstery Panel
3. Wedge
4. Spring
5. Window Stop
6. Window Hinge
7. Latch Plate

8. Cabin Door
9. Window Frame
10. Window
11. Washer
12. Nut
13. Lock Assembly
14. Latch Handle

15. Pin or Rivet
16. Reinforcement
17. Door Stop Arm
18. Stop Assembly
19. Spring - Loaded Plunger
20. Hinge
21. Lower Hinge
22. Upper Hinge

Figure 3-3. Cabin Door



NOTE

The baggage door on the Model P206 and TP206 Series has exterior hinges similar to the cabin door.

The Model 210 and T210 Series baggage door has double windows (See figure 3-2.)

The Model 210G and T210G and on have a flap interrupt switch mounted above the baggage door. Refer to Section 7 for details.

- 1. Latch
- 2. Spacer
- 3. Lock

- 4. Lower Hinge Base
- 5. Shim
- 6. Lower Hinge Arm

- 7. Upper Hinge Base
- 8. Upper Hinge Arm
- 9. Swing Stop

Figure 3-4. Baggage Door Installation




Figure 3-5. Cargo Doors

3-21. BAGGAGE DOORS.

3-22. REMOVAL AND INSTALLATION. Baggage door removal is accomplished by disconnecting the door stop, then removing hinge pins or bolts securing door to hinges. When fitting a new door, some trimming of the door at the edges and some reforming with a soft mallet may be necessary to achieve a good fit.

3-23. CARGO DOORS - MODELS U206 AND TU206. (See figure 3-5.)

3-24. These airplanes are equipped with two cargo doors located on the right side of the fuselage. The forward cargo door is hinged at the rear spar bulkhead, and the aft door is hinged at fuselage station 112. The doors close together at fuselage station 90. The aft door is a structural, load-carrying member when closed and locked. The rear cargo door handle is located in the forward edge of the door and is inaccessible with the forward door closed, thus preventing inadvertent opening during flight. As the rear cargo door handle is moved to the closed position, mechanical linkage causes hooks to engage latch plates on the upper and lower door sills. The over-center action of the handle holds the door tightly closed to permit loads to be transmitted through the load carrying pins of the door structure to their corresponding sockets on the door sills. The forward cargo door is not a load-carrying member. It contains a latching mechanism similar to the cabin door latching mechanism. Telescoping door stops, with detent positions, are used to hold the cargo doors open. An entrance step is located on the fuselage, below the front cargo door. Flight with the cargo doors removed is only permissible when an optional spoiler kit is installed. This spoiler kit consists of a spoiler assembly which attaches to the front cargo door hinge points and deflects air away from the cargo door opening. Addition of screws to the rear wall is required with the installation of the spoiler kit.

NOTE

The aircraft has a flap interrupt switch. Check that flaps operate with the cargo doors closed, but will not operate with doors open. Switch adjustment is provided by means of slotted holes on the front cargo door frame. The spoiler kit contains a switch depressor to retain use of the flaps.

3-25. REMOVAL AND INSTALLATION. Either cargo door may be removed after removing the pins and cotter pins from the hinges. Disconnect the door stops from the cargo doors before removal. When installing the doors, be sure to install the cotter pins in all hinge pins and connect door stops.

3-26. REMOVAL AND INSTALLATION OF LATCHES. Figures 3-5 and 3-6 show details of the cargo door latches and may be used as guides during removal, disassembly, assembly, and installation.

3-27. RIGGING OF REAR CARGO DOOR LATCH. (See figure 3-5.)

- a. Three results must be obtained by rigging:
 1. Hooks must fully engage latch plates, but must clear them .05" minimum as door is opened.
 2. Load-carrying pins must fully engage their sockets when door is locked.
 3. Door must be flush with fuselage skins when door is locked.

NOTE

Adjusting door slightly less than flush is permissible if air leaks around door seal are encountered.

- b. There are four sets of adjustments for rigging:
 1. Adjusting bolts (10). These determine depth of hook engagement and clearance of hooks as door is opened.
 2. Slots in latch plates (3). Plates may be moved inboard or outboard as necessary for full load-carrying pin engagement.
 3. Washers under sockets (7). These may be added as required to make door flush with fuselage skins.
 4. Turnbuckles (11). These must be adjusted to cause both hooks to pull door closed tightly. Handle should snap over-center snugly, but excessive force should not be required for handle operation.

3-28. SEATS. (See figures 3-7 thru 3-10.)

3-29. INDIVIDUAL SEATS. Individual seats are equipped with manually operated reclining seat backs. Rollers permit the seats to slide fore-and-aft on seat rails, and pins which engage various holes in seat rails lock seats in the selected positions. Seat stops limit travel. Removal is accomplished by removing the seat stops, and sliding the seats forward and aft to disengage them from the seat rails. Be sure to replace seat stops after installing a seat. The rearmost seats on Model 206 Series airplanes are not fore-and-aft adjustable.

WARNING

It is extremely important that the pilot's seat stops are installed, since acceleration and deceleration could possibly permit the seat to become disengaged from the seat rails and create a hazardous situation, especially during take-off and landing.

Vertically adjustable individual seats may be installed as optional equipment. A deluxe seat is available on Model 210 and T210 Series aircraft. This seat is equipped with a higher, narrower, structurally contoured seat back. The vertically adjustable seat is also available with this seat back.




Figure 3-6. Door Latch and Rotary Clutch Components

NOTE

The center and rear single seats are similar to the front seat illustrated, although seat legs are shorter and method of attachment is different. The rearmost seats in 206 Series airplanes do not slide fore and aft. Reclining handle (2) is located at the forward corner of the seat on Model 210 and T210 Series aircraft. Configuration of handles (2) and (31) may vary with location.





Figure 3-7. Single Seat



NOTE

Seat bottom, seat back, reclining mechanism, and fore-and-aft adjusting mechanism is similar to the standard seat.


1. Bellcrank
2. Channel
3. Torque Tube

4. Seat Structure
5. Pin
6. Fore-and-Aft Adjustment Handle

7. Seat Roller
8. Adjustment Screw
9. Vertical Adjustment Handle

Figure 3-8. Vertically Adjustable Seat Mechanism (Manual)

- 1 Recline Actuator
- 2 Recline Stop
- 3 Elevating Mechanism
- 4 Motor And Transmission
- 5 Fore-And-Aft Adjustment Handle
- 6 Switch
- 7 Recline Handle



ALL MODELS - PRIOR TO 1967

Figure 3-9. Vertically Adjustable Seat Mechanism (Electrical)

3-30. TWO-PLACE SEATS. Deluxe rear seat bottoms of Model 210 and T210 Series airplanes are combined into a single bench type that is upholstered into a twin "bucket" effect. Individual reclining seat backs are also the narrow, structurally contoured type. The backs are higher than the front seat backs, and are equipped with fold-away head rest pads. The seat may be adjusted fore and aft by means of two individual handles located at each forward corner of the seat. The child's seat installation (standard on Model 210 and T210 Series airplanes) is not available with the deluxe interior. Removal is accomplished by removing the bolts which secure the seat bottom to the fuselage. Use care not to damage upholstery when removing seats. If desired, seat backs may first be removed from seat bottoms. Additional clearance may be obtained by removing one or more arm rests.

NOTE

To help prevent upholstery damage, several thicknesses of waxed heavy paper (waxed is preferred) should be inserted between the seat and the side panel and arm rest during removal and installation of the seat.

3-31. POWER SEATS. (See figure 3-9.) Power seats for the pilot and copilot may be installed on all models prior to 1967. An electric motor, geared to a screwjack actuator, operates the mechanism which raises and lowers the seat vertically. Fore-and-aft

adjustment and seat back reclining adjustment are still accomplished manually. The reclining mechanism is locked automatically in any desired position throughout the travel range of the seat back by releasing the reclining adjustment handle. The seat is removed in the usual manner after disconnecting electrical wires at the quick-disconnects in the floor-board, under the seat. When installing a seat, either electrical wire may be attached to either quick-disconnect without affecting seat operation. No limit switches are needed, as the actuator "free-wheels" at each end of its travel.

3-32. CHILD'S SEAT. (See figure 3-10.) An individual child's seat (standard on Model 210 and T210 Series airplanes without deluxe interior), is located immediately aft of each rear passenger's seat. The seat backs fold into the cushion wells when not in use, to increase the baggage area.

3-33. REPAIR OF SEAT STRUCTURE. Replacement of defective parts is recommended in repair of seats. However, a cracked seat framework may be welded, provided the crack is not in an area of stress concentration (close to a hinge or bearing point). The square-tube aluminum framework is 6061 aluminum, heat-treated to a T-6 condition. Use a heliarc weld on these seats, as torch welds will destroy the heat-treatment of the frame structure. Figure 3-11 gives instructions for replacing defective cams on reclining seat backs.





Figure 3-10. Child's Seat



REPLACEMENT PROCEDURE:

- a. Remove seat from aircraft.
- b. Remove plastic upholstery panels from aft side of seat back, then loosen upholstery retaining rings and upholstery material as required to expose the rivets retaining the old cam assembly.
- c. Drill out existing rivets and insert new cam assembly (2). Position seat back so that pawl (3) engages first cam slot as shown.
- d. Position the cam so each slot bottom aligns with the 2.50" radius as shown.
- e. Clamp securely in this position and check travel of cam. Pawl must contact bottom of each cam slot. Using existing holes in seat frame, drill through new cam and secure with MS20470AD6 rivets.
- f. Reinstall upholstery, upholstery panels and seat.

Figure 3-11. Seat Back Cam Replacement

3-34. CABIN UPHOLSTERY.

3-35. Due to the wide selection of fabrics, styles and colors, it is impossible to depict each particular type of upholstery. The following paragraphs describe general procedures which will serve as a guide in removal and replacement of upholstery. Major work, if possible, should be done by an experienced trim mechanic. If the work must be done by a mechanic unfamiliar with upholstery practices, the mechanic should take careful notes during the removal of each item to facilitate its replacement later.

3-36. UPHOLSTERY MATERIALS AND TOOLS will vary with the job. Scissors for trimming upholstery to size and a dull-bladed putty knife for wedging the material beneath the retainer strips are the only tools required for most trim work. Use industrial rubber cement to hold soundproofing mats and fabric edges in place. Refer to Section 18 for thermoformed plastic repairs.

3-37. SOUNDPROOFING. The airplane is insulated with spun glass mat-type insulation and a sound deadener compound applied to the inner surfaces of the skin in most areas of the cabin and baggage compartment. Some airplanes utilize aluminum foil-backed tape to help reduce noise level in the cabin. All soundproofing material should be replaced in its original position any time it is removed. A soundproofing panel is placed in the gap between the wing and fuselage and held in place by the wing root fairing. Cabin and baggage compartment upholstery and carpeting also assist in reducing noise level.

3-38. CABIN HEADLINER REMOVAL.

- a. Remove sun visors, all inside finish strips and plates, door post upper shields, front spar trim shield, dome light panel, rear baggage shelf and any other visible retainers securing the headliner.
- b. Work edges of headliner free from metal tabs which hold the fabric.
- c. Starting at the front of the headliner, work the headliner down, removing screws through metal tabs which hold the wire bows to the cabin top. Pry loose the outer ends of the bows from the retainers above the doors. Detach each wire bow in succession.

NOTE

Always work from front to rear when removing the headliner: it is impossible to detach the wire bows when working from rear to front. The 210G and T210G and on have metal tubes inserted in the headliner at the main wing spar. The tubes are held in place by tabs as shown in figure 3-12.

- d. Remove the headliner assembly and bows from the airplane.

NOTE

Due to the difference in length and contour of the wire bows, each bow should be tagged to assure proper location in the headliner.

- e. Remove the spun glass soundproofing panels.

NOTE

The lightweight soundproofing panels are held in place with industrial rubber cement.

3-39. CABIN HEADLINER INSTALLATION.

- a. Before installing headliner, check all items concealed by the headliner to see that they are mounted securely. Use wide cloth tape to secure loose wires to the fuselage, and to seal any openings in the wing roots. Straighten any tabs bent during removal of the headliner.
- b. Apply cement to inside of skin in areas where soundproofing panels are not supported by wire bows, and press soundproofing in place.
- c. Insert wire bows into headliner seams, and secure rearmost edges of headliner after positioning the two bows at the rear of the headliner. Stretch the material along the edges to make sure it is properly centered, but do not stretch it tight enough to destroy the ceiling contours or distort the wire bows. Secure the edges of the headliner with sharp tabs or, where necessary, rubber cement.
- d. Work the headliner forward, installing each wire bow in place with the tabs. Wedge the ends of wire bows into the retainer strips. Stretch the headliner just taut enough to avoid wrinkles and maintain a smooth contour.
- e. When all bows are in place and fabric edges are secured, trim off any excess fabric and re-install all items removed.

3-40. UPHOLSTERY SIDE PANELS. Removal of upholstery side panels is accomplished by removing seats for access, then removing parts attaching the panels. Remove screws, retaining strips, and ash trays as required to free the various panels. Automotive type spring clips attach most door panels. A dull putty knife makes an excellent tool for prying loose the clips. When installing upholstery side panels, do not over-tighten sheet metal screws. Larger screws may be used in enlarged holes as long as the area behind the hole is checked for electrical wiring, fuel lines, and other components which might be damaged by using a longer screw.

3-41. WINDLACE (DOOR SEAL) is installed to provide additional sealing and provide an ornamental edging for the door opening. The windlace is held in position by sheet metal screws and is mounted between the upholstery panels or trim and the doorpost structure.

3-42. CARPETING. Cabin area and baggage compartment carpeting is held in place by rubber cement, small sheet metal screws, and retaining strips. When fitting a new carpet, use the old one as a pattern for trimming and marking the screw holes. Utility versions of Model 206 Series aircraft utilize a tough, lightweight, heavy-duty floor covering of vinyl. Thermo-formed plastic is used on the doors and side panels.




Figure 3-12. Cabin Headliner

3-43. **BAGGAGE COMPARTMENT UPHOLSTERY** is washable plastic held in place by screws and retainers. The floor covering is cemented to the floor along the edges. Cargo tie-downs and/or safety belt brackets may be removed as necessary where they are installed through the floor covering.

3-44. **CARGO TIE-DOWN PROVISIONS.** Four types

of cargo tie-downs may be installed as shown in figure 3-13. Different combinations of all four may also be used. Small eyebolts are provided to attach a baggage net. The rearmost seats on some aircraft have plates bolted to the cabin floor that secure the rear legs. If the seats are removed, an anchor ring may be attached to the plate for cargo tie-down.




Figure 3-13. Cargo Tie-Down Rings

3-45. CARGO PACK - MODEL 206 SERIES.

3-46. REMOVAL OF CARGO PACK. Removal is accomplished by removing the screws, fairing, and seal from around each landing gear spring, then positioning a support under the pack and removing all screws attaching it to the airplane. The four small panels which enclose the area around the nose gear shock strut and drag brace may be left installed instead of the two larger panels installed as standard. However, the control extensions and cowl flap baffles must be removed as outlined in paragraph 3-48.

3-47. INSTALLATION OF CARGO PACK. Prior to positioning the pack under the airplane, inspect all Rivnuts in the bottom of the fuselage for obstructions. Also check the small panels which enclose the area around the nose gear shock strut and drag brace. Two panels are provided in this area on standard airplanes; these are to be replaced by four smaller panels when a cargo pack is installed. If not previously removed, remove the two standard panels by unsnapping the quick-release fasteners. Install the four smaller panels furnished with the cargo pack.

NOTE

Install the two rearmost panels first, the right hand panel lapping over the left hand panel along the airplane centerline. Install the two forward panels in a similar manner.

- a. Move the pack into position under the airplane. Raise the aft end of the pack and place a support under it.
- b. Raise the forward end of the pack and align the two forward holes in the pack rim with the two front Rivnuts. Install two screws to support the forward end of the pack.

NOTE

Install lock washers and flat washers under the heads of all pack attaching screws.

c. Raise the aft end of the pack and install two attaching screws.

d. Check pack for proper alignment, then install and tighten all remaining screws, except for one screw just forward and one screw just aft of each landing gear spring. These two screws will be utilized later to help secure the fairing which covers each landing gear opening.

e. Position the rubber seal and fairing around each main landing gear spring by spreading these components, at their split side, enough to slip them over the gear spring. When installed, the split should be at the back of the gear spring. Check alignment and proper fit of fairing, then install fairing retaining screws.

NOTE

Seven screws are used to secure the fairing at each landing gear. Two screws, previously mentioned in step "d," secure the top of the fairing and the rim of the cargo pack, in this area, to the fuselage. Five additional screws secure and seal the sides and bottom of each fairing to the pack.

f. Install cowl flap baffles and control extensions in accordance with paragraph 3-49.

3-48. REMOVAL OF COWL FLAP BAFFLES AND CONTROL EXTENSIONS. (See figure 3-14.)

- a. Disconnect cowl flap control clevises from cowl flaps, and take off all four baffles (1) by removing screws (3) and nuts (2).
- b. Remove clevis (7) and link (5) from each control end and reinstall the clevises.
- c. Rig cowl flaps on turbocharged aircraft per paragraph 12A-51 and on standard aircraft per paragraph 12-48.




Figure 3-14. Cargo Pack

3-49. INSTALLATION OF COWL FLAP BAFFLES AND CONTROL EXTENSIONS. (See figure 3-14.)

- a. Disconnect cowl flap control clevises from cowl flaps, and remove clevises. Leave jamb nuts (4) on the control ends.
- b. Install links (5) on control ends, install jamb nuts (6) on links, and attach clevises (7) to the links. Do not tighten jamb nuts.
- c. Position baffles (1) along the sides of the cowl flaps so attaching holes are aligned, and install attaching screws and nuts.

NOTE

Each baffle is designed for installation on a specific cowl flap. Determine the correct baffle for each cowl flap. Turbocharged aircraft have baffles as standard equipment. Note that the flanges on the baffles are turned toward the inside of each cowl flap opening.

- d. Check to make sure that the flexible controls reach their internal stops in each direction. Mark controls so that full control travel can readily be checked and maintained during the remaining rigging procedure.
- e. Place cowl flap control lever in "OPEN" position and connect control ends to cowl flaps, but do not secure at this time.

f. On standard aircraft, measure the distance from the trailing edge of cowl flaps to cowl skin. Disconnect clevises and adjust links (5) and clevises (7) so each cowl flap opens 4 1/4 inches, then secure clevises. On turbocharged aircraft, adjust clevis at lower end of control to place cowl flaps 2 1/4 inches open (CLOSED position) to 8 1/2 inches open (OPEN position). These measurements are made in a straight line from the aft edge of a cowl flap, just outboard of cutout, to lower edge of firewall. Do not measure from aft corners of cowl flap. If either control needs to be lengthened or shortened, the lower clamp may be loosened and housing slipped in the clamp, or lower clevis may be adjusted. Maintain sufficient thread engagement of clevis.

g. Check that locknuts are tight, clamps are secure, then cycle cowl flaps several times, checking operation.

3-50. GLIDER TOW-HOOK. A glider tow-hook, which is mounted in place of the tail tie-down ring, is available for all models.

3-51. REAR VIEW MIRROR. An optional rear view mirror may be installed on the cowl deck above the instrument panel on all 200-Series aircraft. Figure 3-15 shows details of the rear view mirror installation.





Figure 3-15. Rear View Mirror Installation



1. Thumb Screw
2. Rack Assembly
3. Pad

4. Platform
5. Bracket
6. Seat Rail
7. Weld Assembly

8. Washer
9. Nut
10. Bolt

Figure 3-16. Casket Carrier Installation (Sheet 1 of 2)




Figure 3-16. Casket Carrier Installation (Sheet 2 of 2)

3-53. CASKET CARRIER INSTALLATION. (See figure 3-16.) The following instructions may be used to install the platform, rack, and tie-down belts, and to load and secure the casket:

- Remove all seats and safety belts except the pilot's and copilot's.
- Move pilot's and copilot's seats forward to their limit of travel.
- Attach belt assemblies to existing left forward and left aft seat belt attach brackets as shown in detail "G".
- Place platform in cabin and butt aft end of platform against step.
- Secure both sides of platform to outboard seat rails as shown in detail "A".
- Install rack on platform as shown in detail "B".
- Install cargo tie-down rings on inboard seat rails and attach lower belt as shown in detail "D".

The cargo tie-down ring on the left inboard seat rail is tightened down against the seat rail, since no seat adjusting hole exists in the rail at this point. The cargo tie-down ring on the right inboard seat rail will engage an existing seat adjustment hole.

- h. Attach upper belt at four points as shown in detail "H".
- i. Attach upper belt to forward belt as shown in detail "C".
- j. Attach right forward and right aft belts to existing seat belt attach points as shown in details "E" and "F".
- k. Remove pilot's seat back by removing quick-release pins.
 - l. Load the casket, adjusting end plates on rack according to casket length. Tighten forward end plate snugly.
- m. Tighten all belts securely and recheck all tie-down attachments.
- n. Reinstall pilot's seat back.

3-54. CASKET CARRIER REMOVAL. After the casket has been removed, the platform, rack, and belts may be removed by reversing the installation procedure.

SHOP NOTES:

[illegible]

SECTION 4

AIRFRAME

TABLE OF CONTENTS

	Page		
STRUT-BRACED WINGS	4-1	Installation	4-6
Removal	4-1	Adjustment	4-6
Repair	4-3	FIN	4-6
Installation	4-3	Removal	4-6
Adjustment	4-4	Repair	4-6
WING STRUTS	4-4	Installation	4-6
Removal and Installation	4-4	HORIZONTAL STABILIZER	4-6
Repair	4-4	Removal	4-6
CANTILEVER WINGS	4-4	Repair	4-6
Removal	4-4	Installation	4-6
Repair	4-6		

4-1. STRUT-BRACED WINGS. (See figure 4-1.)

4-2. Each all-metal wing panel is a semicantilever, semi-monocoque type, with two main spars and suitable ribs for the attachment of the skin. Skin panels are riveted to ribs, spars, and stringers to complete the structure. An all-metal, balanced aileron, a high-lift flap, and a detachable wing tip are mounted on each wing assembly. A single fuel tank is mounted between the wing spars at the inboard end of each wing and the leading edge of the left wing has landing and taxi lights installed. Colored wing tip lights are mounted at each contoured wing tip.

4-3. REMOVAL. Removal of a wing panel is accomplished most easily if four men are available to handle the wing. Otherwise the wing should be supported with a sling or maintenance stand when the fastenings are loosened.

- a. Remove wing gap fairings and screws securing cabin top skin to the wing top skin.
- b. Remove all wing inspection plates.
- c. Drain fuel from tank of wing being removed.
- d. Disconnect:
 1. Electrical wires at wing root disconnects.
 2. Fuel lines at wing root.
 3. Pitot line (left wing only) at wing root.
 4. Cabin ventilator hoses at wing root.
- e. Slack off tension on flap and aileron cables by loosening carry-thru cable turnbuckles; then disconnect cables at flap and aileron bellcranks.

NOTE

To ease rerouting the cables, a guide wire may be attached to each cable before it is pulled free of the wing. Then disconnect cable from wire and leave the guide wire routed through the wing; it may be attached again to the cable during reinstallation and used to pull the cable into place.

f. Support wing at outboard end and disconnect strut at wing fitting. Tie the strut up with wire to prevent it from swinging down and straining strut-fuselage fittings. If the fuselage fitting projects from the fuselage and is covered by the strut fairing, loosen the fairing and slide it up the strut; the strut may then be lowered without damage.

g. Mark position of wing attachment eccentric bushings; these bushings are used to rig out "wing-heaviness."

NOTE


It is recommended to secure flap in streamlined position with tape during wing removal to prevent damage since flap will swing freely.

h. Remove nuts, washers, bushings and bolts attaching wing spars to fuselage.

NOTE

It may be necessary to use a long drift punch to drive out wing attaching bolts, or to rock the wing slightly while pulling bolts.

i. Remove wing and lay on padded stand.



* The forward bushing is approximately half the length of the aft bushing. Care should be taken to install the short bushing in the forward side and the long bushing in the aft side. At least one washer should always be installed under the bolt head and under the nut. Torque the bolts to the value listed in the Torque Table in Section 1.

- | | | |
|--------------------------|---------------------------------|-------------|
| 1. Bolt | 5. Nut | 9. Fillet |
| 2. Washer | 6. Tip Assembly | 10. Fairing |
| 3. Long Aft Bushing | 7. Fuel Filler Cap | 11. Flap |
| 4. Short Forward Bushing | 8. Fuel Transmitter Access Door | 12. Aileron |

Figure 4-1. Strut-Braced Wing




Figure 4-2. Wing Struts

4-4. REPAIR of a damaged wing panel may be accomplished in accordance with instructions given in Section 18. Extensive repairs of wing skin or structure are best accomplished by using the wing repair jig, which may be obtained from Cessna. The jig serves not only as a holding fixture, making work on the wing easier, but also assures absolute alignment of the repaired wing.

4-5. INSTALLATION.

- a. Hold wing in position and install bolts, bushings, washers and nuts attaching wing spars to fuselage fittings.
- b. Install bolt, spacer and nut to attach upper end of wing strut to wing fittings.
- c. Route flap and aileron cables.
- d. Connect:
 1. Electrical wires at wing root disconnects.
 2. Fuel lines at wing root.

3. Pitot line (if left wing is being installed).
4. Ventilator hoses.
- e. Rig aileron system (Section 6).
- f. Rig flap system (Section 7).
- g. Refuel wing tank and check for leaks.
- h. Check operation of navigation, courtesy and landing lights.
- i. Check operation of fuel gage.
- j. Install wing gap fairings.

NOTE

Be sure to insert soundproofing panel in wing gap before replacing fairings.

- k. Install all inspection plates, interior panels and upholstery.

1. Test operate flap and aileron systems.

4-6. **ADJUSTMENT (CORRECTING "WING-HEAVY" CONDITION).** If considerable control wheel pressure is required to keep the wings level in normal flight, a wing-heavy condition exists.

- a. Remove wing fairing strip on the wing-heavy side of the airplane.
- b. (See figure 4-1.) Loosen nut (3) and rotate bushings (3 and 4) simultaneously until the bushings are positioned with the thick side of the eccentrics up. This will lower the trailing edge of the wing, and decrease wing heaviness by increasing the angle-of-incidence of the wing.

CAUTION

Be sure to rotate the eccentric bushings simultaneously. Rotating them separately will destroy the alignment between the off-center bolt holes in the bushings, thus exerting a shearing force on the bolt, with possible damage to the hole in the wing spar.

- c. Tighten nut and reinstall fairing strip.
- d. Test-fly the airplane. If the wing-heavy condition still exists, remove fairing strip on the "lighter" wing, loosen nut and rotate bushings simultaneously until the bushings are positioned with the thick side of the eccentric down. This will raise the trailing edge of the wing, thus increasing wing heaviness to balance heaviness in the opposite wing.
- e. Tighten nut, install fairing strip, and repeat test flight.

4-7. WING STRUTS. (See figure 4-2.)

4-8. Each wing has a single lift strut which transmits a part of the wing load to the lower portion of the fuselage. The strut consists of a streamlined tube riveted to two end fittings for attachment at the fuselage and wing.

4-9. REMOVAL AND INSTALLATION.

- a. Remove screws attaching strut fairings to wing and fuselage. Slide fairings away from the ends of the strut.
- b. Remove fuselage and wing inspection plates or fairings at strut junction points.
- c. Support wing securely, then remove nut and bolt

securing strut to fuselage.

- d. Remove nut, bolt, and spacer used to attach strut to wing, then remove strut from airplane.
- e. Install strut by reversing preceding steps.

4-10. **REPAIR** of wing struts is limited to replacement of strut seals, tie-downs and attaching parts. A badly dented, cracked, or deformed wing strut should be replaced.

4-11. CANTILEVER WINGS. (See figure 4-3.)

4-12. Beginning with the Models 210G and T210G, cantilever wings are used. Each wing is all-metal construction with a single main spar, two fuel spars, formed ribs and stringers. The front fuel spar also acts as an auxiliary spar and provides the forward attachment point for the wing. An inboard section of the wing forward of the main spar is sealed to form an integral fuel tank area. Stressed skin is riveted to the spars, ribs, and stringers to complete the structure. An all-metal balanced aileron, a high-lift flap, and a detachable wing tip are part of each wing assembly. A navigation light is mounted in each contoured wing tip.

4-13. **REMOVAL.** Removal of a wing is accomplished most easily if four men are available to handle the wing. Otherwise the wing should be supported with a sling or maintenance stand when the fasteners are loosened.

- a. Remove wing gap fairings and fillets.
- b. Drain fuel from wing being removed.
- c. Disconnect:
 1. Electric wires at wing root disconnects.
 2. Fuel lines at wing root.
 3. Pitot line (left wing only) at wing root.
 4. Cabin ventilator hoses at wing root.
 5. Aileron carry-thru cable and aileron direct cable of wing being removed, at turnbuckles behind headliner front shield and doorpost shield.
- d. If right wing is being removed, disconnect flap cables from right flap drive pulley, and remove cable guards and/or pulleys as required to pull flap cables into right wing root area. (Refer to paragraph 4-3 for use of guide wires.)
- e. If left wing is being removed, relieve tension on right flap cables at right flap drive pulley. Disconnect right flap cables at flap actuator in left wing and remove pulleys to pull flap cables into left wing root area.

NOTE

Rigging of flap actuator and components in left wing need not be disturbed to remove either wing.

It is recommended to secure flap in streamlined position with tape during wing removal to prevent damage since flap will swing freely.

- f. Remove nut, washer, and bolt attaching front fuel spar to fuselage.
- g. Remove bolts, washers, and retainers that hold main spar dowel pins in position.
- h. Support wing at inboard and outboard end, and remove dowel pins that attach main wing spar to




Figure 4-3. Cantilever Wing

fuselage. It is best to remove the top dowel pin first, then lower outboard end of wing before removing the bottom dowel pin.

NOTE

It may be necessary to use a long punch to drive out main wing spar attaching dowel pins, or to rock the wing slightly while removing the pins. Care must be used not to damage dowel pins, spar fittings, or spar carry-thru fittings as these are reamed holes and close tolerance dowel pins.

- i. Remove wing and lay on padded stand.

4-14. REPAIR. For repair of a damaged wing panel refer to applicable instructions in Section 18. Also refer to paragraph 4-4.

4-15. INSTALLATION.

NOTE

Refer to figure 4-3 for lubrication of dowel pins prior to installation.

- a. Hold wing in position with wing tip low.
- b. Install:
 1. Dowel pins attaching main spar to fuselage. (Install the bottom pin first then rotate wing up and install top pin.)
 2. Bolts, retainers, washers, and nuts that hold main spar attach dowel pins in position.
 3. Front fuel spar attach bolt, washer and nut.
- c. Route flap and aileron cables and make proper connections.
- d. Connect:
 1. Electrical wires at wing root disconnects.
 2. Fuel lines at wing root.
 3. Pitot line (if left wing is being installed).
 4. Cabin ventilator hoses at wing root.
- e. Rig aileron system (Section 6).
- f. Rig flap system (Section 7).
- g. Refuel wing tank and check all connections for leaks.
- h. Check operation of navigation, courtesy and landing lights.
- i. Check operation of fuel gage.
- j. Install wing gap fairings and fillets.

NOTE

Be sure to install soundproofing panel in wing gap before replacing fairings.

- k. Install all inspection plates, interior panels and upholstery.
- l. Test operate flap and aileron systems.

4-16. ADJUSTMENT (CORRECTING "WING-HEAVY" CONDITION). If considerable control wheel pressure is required to keep the wings level in normal flight, a wing-heavy condition exists. Refer to Section 6 for ground adjustment of ailerons tabs.

4-17. FIN. (See figure 4-4.)

4-18. The fin is primarily of metal construction, consisting of ribs and spars covered with skin. Fin tips are of glass fiber construction. Hinge brackets at the rear spar attach the rudder.

4-19. REMOVAL. The fin may be removed without first removing the rudder. However, for access and ease of handling, the rudder may be removed if desired, following procedures outlined in Section 10.

- a. Remove fairings on both sides of fin.
- b. Disconnect rotating or flashing beacon lead, tail navigation light lead, antennas and antenna leads, and rudder cables if rudder has not been removed.
- c. Remove screws attaching dorsal to fuselage.
- d. Remove bolts attaching fin front and rear spars to fuselage.
- e. Remove the fin.

4-20. REPAIR of the fin should be accomplished in accordance with applicable instructions in Section 18.

4-21. INSTALLATION of the fin may be accomplished by reversing the procedure in paragraph 4-19. Be sure to check and reset rudder and elevator travel if any stop bolts were removed or settings disturbed.

4-22. HORIZONTAL STABILIZER. (See figure 4-5.)

4-23. The horizontal stabilizer is primarily of metal construction, consisting of ribs and a front and rear spar which extend throughout the full span of the stabilizer. The skin is riveted to both spars and ribs. Stabilizer tips are of thermo-formed plastic construction. The elevator tab actuator screw is contained within the horizontal stabilizer assembly, and is supported by a bracket riveted to the rear spar. The underside of the stabilizer contains an opening which provides access to the elevator tab actuator screw. Hinges on the rear spar support the elevator.


4-24. REMOVAL.

- a. Remove elevators and rudder in accordance with procedures outlined in Sections 8 and 10.
- b. Remove vertical fin in accordance with procedures outlined in paragraph 4-19.
- c. Disconnect elevator trim control cables at clevis and turnbuckle inside tailcone, remove pulleys which route the aft cables into horizontal stabilizer, and pull cables out of tailcone.
- d. Remove bolts securing horizontal stabilizer to fuselage.
- e. Remove horizontal stabilizer.

4-25. REPAIR of the horizontal stabilizer should be accomplished in accordance with applicable instructions in Section 18.

4-26. INSTALLATION.

- a. Install the horizontal stabilizer by reversing the procedures outlined in paragraph 4-24, rigging the control systems as necessary. Check operation of tail navigation light and rotating or flashing beacon.




- 1. Fin Assembly
- 2. Upper Rudder Hinge
- 3. Center Rudder Hinge
- 4. Lower Rudder Hinge

* TORQUE AN5 BOLTS TO 140-225 LB IN.
 * TORQUE AN6 BOLTS TO 190-390 LB IN.

- 5. Bolt
- 6. Washer
- 7. Nut
- 8. Fairing

Figure 4-4. Fin Installation



NOTE

Stabilizer is same for cantilever wing airplanes, except it has approximately 16 inches longer span.

- | | | |
|------------|-----------------------------|---------------------------|
| 1. Nut | 7. Bushing | 14. Lower Left Fairing |
| 2. Washer | 8. Bracket | 15. Lower Right Fairing |
| 3. Bolt | 9. Bolt | 16. Forward Left Fairing |
| 4. Bracket | 10. Elevator Pylon Bracket | 17. Forward Right Fairing |
| 5. Nut | 11. Elevator Inboard Hinge | 18. Upper Right Fairing |
| 6. Washer | 12. Elevator Outboard Hinge | 19. Upper Left Fairing |
| | 13. Stabilizer Assembly | |

Figure 4-5. Horizontal Stabilizer Installation

SECTION 5

NON-RETRACTABLE LANDING GEAR (206 SERIES)

TABLE OF CONTENTS

Page

LANDING GEAR	5-1	STANDARD NOSE GEAR	5-12
Trouble Shooting	5-1	Disassembly	5-12
MAIN GEAR	5-3	Assembly	5-14
Removal	5-3	HEAVY-DUTY NOSE GEAR	5-14
Installation	5-3	Disassembly	5-14
Removal and Installation of Main		Assembly	5-16
Wheel Speed Fairing	5-3	WHEEL BALANCING	5-16
Removal of Main Wheels	5-6	TORQUE LINKS	5-16
Disassembly of Main Wheels	5-6	SHIMMY DAMPENER	5-16
Inspection and Repair of Wheels	5-6	NOSE WHEEL STEERING SYSTEM	5-18
Assembly of Main Wheels	5-6	Removal and Installation	5-18
Installation of Main Wheels	5-6	Rigging	5-18
Removal of Main Wheel and Axle	5-6	BRAKE SYSTEM	5-18
Installation of Main Wheel and Axle	5-8	Trouble Shooting	5-21
Main Wheel Alignment	5-8	Brake Master Cylinders	5-23
Wheel Balancing	5-8	Removal and Installation	5-23
Step Bracket Replacement	5-8	Disassembly and Repair	5-23
NOSE GEAR	5-9	Hydraulic Brake Lines	5-23
Replacement	5-9	Wheel Brake Assemblies	5-23
Standard Nose Wheel Speed Fairing		Removal	5-23
Replacement	5-9	Inspection and Repair	5-23
Heavy-Duty Nose Wheel Speed Fairing		Assembly	5-23
Replacement	5-9	Installation	5-23
Removal of Nose Wheel	5-9	Checking Brake Linings	5-23
Disassembly of Nose Wheel	5-12	Brake Lining Replacement	5-23
Inspection and Repair of Nose Wheel	5-12	Brake Bleeding	5-26
Assembly of Nose Wheel	5-12	PARKING BRAKE SYSTEM	5-26
Installation of Nose Wheel	5-12		

5-1. LANDING GEAR.

5-2. Conventional tricycle landing gear utilizing the familiar Cessna spring-steel main gear struts and an air-oil nose gear shock strut, is employed on the

aircraft. Wheels with disc-type brakes and tube-type tires are installed. Speed fairings are standard equipment with the standard landing gear. Oversize speed fairings are available for the optional heavy-duty nose gear and the optional oversize main wheels.

5-3. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
AIRPLANE LEANS TO ONE SIDE.		
Incorrect tire inflation.	Check tire pressure.	Inflate to correct pressure.
Landing gear attaching parts not tight.	Jack airplane and check attaching parts.	Tighten loose parts; replace defective parts.
Sprung landing gear spring.	Check visually.	Replace spring.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
AIRPLANE LEANS TO ONE SIDE (Cont).		
Bent axle.	Check visually.	Replace axle.
Different quantity of fuel in wing tanks.	Check fuel quantity in each wing tank.	Refuel airplane.
Structural damage to landing gear bulkhead components.	Check visually.	Replace damaged parts.
NOSE WHEEL SHIMMY.		
Nose strut attachment loose.	Raise nose and check strut.	Secure attaching parts.
Shimmy dampener lacks fluid.	Check fluid level per paragraphs 2-22 and 2-22A.	Service per paragraphs 2-22 and 2-22A.
Defective shimmy dampener.	Manually check dampening action.	Repair or replace dampener.
Loose or worn steering components.	Check for evidence of looseness.	Tighten loose parts; replace if defective.
Loose torque links.	Check for excessive clearance.	Add shim washers and replace parts as necessary.
Loose wheel bearings.	Raise nose, check wheel bearings and axle nut.	Replace bearings if defective; tighten axle nut properly.
Nose wheel out of balance.	See paragraph 5-16.	See paragraph 5-16.
UNEVEN OR EXCESSIVE TIRE WEAR.		
Incorrect tire inflation.	Check tire pressure.	Inflate to correct pressure.
Wheels out of alignment.	Check toe-in and camber.	Align wheels. See figure 5-2.
Wheels out of balance.	See paragraph 5-16.	See paragraph 5-16.
Sprung landing gear spring.	Check visually.	Replace spring.
Bent axle.	Check visually.	Replace axle.
Dragging brake.	Jack wheel and check brake.	See paragraph 5-44.
Wheel bearings not adjusted properly.	Jack wheel and check for bearing drag or loose bearings.	Tighten axle nut properly.
Loose torque links.	Check for excessive clearance.	Add shim washers and replace parts as necessary.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
HYDRAULIC FLUID LEAKAGE FROM NOSE STRUT.		
Defective strut seals and/or defects in lower strut.	Check lower strut for defects which would cut seals.	Replace defective seals; stone out small defects in lower strut. Replace lower strut if badly scored or damaged.
NOSE STRUT WILL NOT HOLD AIR PRESSURE.		
Defective air filler valve or valve not tight.	Check for leakage through and around valve.	Check gasket and tighten loose valve. Replace defective valve.
Defective O-ring at top of strut.	Check for leakage around inner surface of upper strut.	Replace O-ring.
Result of fluid leakage at bottom of strut.	Check for leakage at bottom of strut.	Replace defective seals; stone out small defects in lower strut. Replace lower strut if badly scored or damaged.

5-4. MAIN GEAR.

5-5. REMOVAL OF MAIN GEAR. (See figure 5-1.)

- Hoist or jack airplane as outlined in Section 2.
- Remove brake bleeder screw and drain hydraulic brake fluid from gear being removed.
- Peel back carpet and remove access plates as necessary for access to strut attaching bolts and nuts.
- Disconnect and cap or plug brake line at bulk-head fitting in fuselage.
- Remove screws attaching landing gear strut fairing and gasket to fuselage.
- Remove inboard bolt, loosen two outboard bolts and work strut out to remove. Use care when removing strut to prevent damage to hydraulic brake line. Retain any shims under inboard bolt.

5-6. INSTALLATION OF MAIN GEAR. To install the main landing gear, reverse the procedure outlined in paragraph 5-5. Pay special attention to the following:

- When installing the main landing gear strut, the outboard channel attaching bolts should be tightened to a torque value of 600-750 pound-inches.

NOTE


The convex surface of the outboard channel is installed against the lower side of the strut. When channel attaching bolts are torqued to 600-750 pound-inches, the channel should have a minimum of 80 per cent contact with the lower side of the strut.

- After installation, fill and bleed affected brake system in accordance with paragraph 5-56.

5-7. REMOVAL AND INSTALLATION OF MAIN WHEEL SPEED FAIRINGS. The main wheel speed fairings may be removed by removing the screws attaching the inboard side of the fairing to the adapter plate, and removing the bolt securing the outboard side to the axle nut. Installation of the speed fairing is the reverse of the removal. Refer to Service Kit No. SK182-12 for repair of speed fairings. Scraper-to-tire clearance on both the standard and heavy-duty main wheels on the 1966 models should be adjusted to 0.40 to 0.60 inch. Beginning with the 1967 models, the standard main wheel speed fairing scraper-to-tire clearance should be adjusted for a minimum clearance of 0.25 inch to a maximum clearance of 0.38 inch. The 1967 optional heavy-duty main wheel fairing scraper-to-tire clearance remains the same as the 1966 models. Elongated holes in the scraper are provided so that the scraper may be adjusted.

CAUTION

Always check scraper-to-tire clearance after installing speed fairing, whenever a tire has been changed, and whenever scraper adjustment has been disturbed. Wipe fuel and oil from the speed fairings to prevent stains and deterioration. If the airplane is flown from surfaces with mud, snow, or ice, the fairings should be checked to make sure there is no accumulation which could prevent normal wheel rotation.



- | | | |
|-----------------------|---------------------|----------------------|
| 1. Bolt | 11. Nut | 21. Screw |
| 2. Countersunk Washer | 12. Washer | 22. Washer |
| 3. Channel | 13. Alignment Shims | 23. Hub Cap |
| 4. Gasket | 14. Axle | 24. Nut |
| 5. Fairing | 15. Elbow | 25. Speed Fairing |
| 6. Screw | 16. Brake Assembly | 26. Bolt |
| 7. Main Gear Strut | 17. Bolt | 27. Spacer |
| 8. Step | 18. Wheel Assembly | 28. Scraper |
| 9. Clip | 19. Nut | 29. Support Assembly |
| 10. Brake Line | 20. Cotter Pin | 30. Support Assembly |

Figure 5-1. Main Landing Gear (Sheet 1 of 2)




Figure 5-1. Main Landing Gear (Sheet 2 of 2)

5-8. REMOVAL OF MAIN WHEELS. (See figure 5-10.)

NOTE

It is not necessary to remove the main wheel to reline brakes or remove brake parts, other than the brake disc or torque plate.

- a. Using the universal jack point, jack the wheel as outlined in Section 2.
- b. Remove speed fairing in accordance with paragraph 5-7.
- c. Remove cotter pin and axle nut.
- d. Remove bolts and washers attaching back plate and remove back plate.
- e. Pull wheel from axle.

5-9. DISASSEMBLY OF MAIN WHEEL.

- a. Deflate tire and break tire beads loose.

CAUTION

Avoid damaging wheel flanges when breaking tire beads loose. A scratch, gouge, or nick may cause wheel failure.

- b. Remove thru-bolts and separate wheel halves, removing tire, tube, and brake disc.
- c. Remove the grease seal rings, felts, and bearing cones from the wheel halves.

NOTE

The bearing cups are a press fit in the wheel halves and should not be removed unless replacement is necessary. To remove the bearing cups, heat the wheel half in boiling water for 15 minutes. Using an arbor press, if available, press out the bearing cup and press in the new cup while wheel is still hot.

5-10. INSPECTION AND REPAIR OF WHEELS.

- a. Clean all metal parts and the grease seal felts in solvent and dry thoroughly.
- b. Inspect wheel halves for cracks. Cracked wheel halves should be replaced. Sand out nicks, gouges, and corroded areas. When the protective coating has been removed, the area should be cleaned thoroughly, primed with zinc chromate and repainted with aluminum lacquer.
- c. Brake disc should be replaced if excessively scored or warped. Small nicks and scratches should be sanded smooth.
- d. Bearing cups and cones should be inspected carefully for damage and discoloration. After cleaning, repack cones with clean aircraft wheel bearing grease (figure 2-6) before installation in the wheel.

5-11. ASSEMBLY OF MAIN WHEEL.

- a. Insert thru-bolts through brake disc and position in the inner wheel half, using the bolts to guide disc. Assure that the disc is bottomed in wheel half.
- b. Position the tire and tube with the inflation valve through hole in outboard wheel half. Place the inner wheel half in position. Apply a light force to bring wheel halves together. Maintaining the light

force, assemble a washer and nut on one thru-bolt and tighten snugly. Assemble the remaining nuts and washers on thru-bolts and torque to value marked on wheel.

CAUTION

Uneven or improper torque of thru-bolt nuts may cause failure of bolts, with resultant wheel failure.

- c. Clean and repack bearing cones with clean aircraft wheel bearing grease (figure 2-6).
- d. Assemble the bearing cones, grease seal felts, and rings into the wheel halves.
- e. Inflate tire to seat tire beads, then adjust to correct pressure.

5-12. INSTALLATION OF MAIN WHEELS.

- a. Place wheel on axle.
- b. Install axle nut and tighten until a slight bearing drag is obvious when the wheel is rotated. Back off nut to nearest castellation and install cotter pin.
- c. Place brake back plate in position and secure with bolts and washers. Safety wire the bolts.
- d. Install speed fairing as outlined in paragraph 5-7.

CAUTION

Always check scraper-to-tire clearance after installing speed fairings, whenever a tire has been changed, and whenever scraper adjustment has been disturbed. On both the standard and oversize speed fairings for the 1966 models, set clearance between tire and scraper at 0.40 to 0.60 inch. On the standard speed fairing for the 1967 models, set clearance between tire and scraper at 0.25 inch minimum to 0.38 inch maximum clearance. On the oversize speed fairing used on the 1967 models, set clearance between tire and scraper at 0.40 to 0.60 inch. Elongated holes in the scraper are provided so that scraper may be adjusted. Wipe fuel and oil from the speed fairings to prevent stains and deterioration. If the airplane is flown from surfaces with mud, snow, or ice, the fairings should be checked to make sure there is no accumulation which could prevent normal wheel rotation.

5-13. REMOVAL OF MAIN WHEEL AND AXLE.

- a. Remove speed fairing in accordance with paragraph 5-7.
- b. Remove wheel in accordance with paragraph 5-8.
- c. Disconnect, drain, and plug the hydraulic brake line at the brake cylinder.
- d. Remove four nuts and bolts securing axle and brake components to spring strut.

NOTE

When removing axle from spring strut, note number and position of the wheel alignment shims. Mark these shims or tape them together carefully so they can be reinstalled in exactly the same position to ensure that wheel alignment is not disturbed.

						1241061-1
						0441139-6
						0441139-5
						0541157-2
						0541157-1
1241061-1	0	0	0	0	0	
0441139-6	0	0	0	1	1	
0441139-5	0	0	1	1	2	
0541157-2	0	1	1	2	2	
0541157-1	0	1	1	2	2	
SHIM NO.	Max. number of shims to be used with shims in column 1.					
COLUMN 1	COLUMN 2					

NOTE

Setting toe-in and camber in accordance with the chart while the cabin and fuel tanks are empty will give approximately zero toe-in and zero camber at gross weight. Ideal setting is zero toe-in and zero camber at normal operating weight. Therefore, if normal operation is at less than gross weight and abnormal tire wear occurs, realign the wheels to attain the ideal setting for the load condition under which the airplane normally operates.




Figure 5-2. Main Wheel Alignment (Sheet 1 of 2)

SHIM CHART FOR: ALL 200-SERIES AIRCRAFT					
SHIM PART NO.	POSITION OF THICKEST CORNER OR EDGE OF SHIM	CORRECTION IMPOSED ON WHEEL			
		TOE-IN	TOE-OUT	POS. CAMBER	NEG. CAMBER
0541157-1	AFT FWD	.06" ----	---- .06"	---- 0°3'	0°3' ----
0541157-2	UP DOWN	.006" ----	---- .006"	0°30' ----	---- 0°30'
1241061-1	UP & FWD UP & AFT DOWN & FWD DOWN & AFT	.008" .04" ---- ----	---- ---- .04" .008"	2°50' 2°49' ---- ----	---- ---- 2°49' 2°50'
0441139-5	UP & FWD UP & AFT DOWN & FWD DOWN & AFT	---- .12" ---- .11"	.11" ---- .12" ----	0°25' 0°11' ---- ----	---- ---- 0°11' 0°25'
0441139-6	UP & FWD UP & AFT DOWN & FWD DOWN & AFT	---- .24" ---- .22"	.22" ---- .24" ----	0°50' 0°22' ---- ----	---- ---- 0°22' 0°50'

Figure 5-2. Wheel Alignment (Sheet 2 of 2)

5-14. INSTALLATION OF MAIN WHEEL AND AXLE.

- Secure axle and brake components to spring strut, making sure that wheel alignment shims and speed fairing mounting plate are reinstalled in their original position.
- Install wheel assembly on axle in accordance with paragraph 5-12.
- Connect hydraulic brake line to brake cylinder.
- Fill and bleed affected brake system in accordance with paragraph 5-56.
- Install speed fairing in accordance with paragraph 5-7.

5-15. MAIN WHEEL ALIGNMENT. Correct main wheel alignment is obtained through the use of tapered shims between the gear strut and the flange of the axle. See figure 5-2 for procedure to use in checking alignment. Wheel shims, and the correction imposed on the wheel by the various shims, are listed in the illustration.

NOTE

Failure to obtain acceptable wheel alignment through the use of the shims indicates a deformed main gear strut or strut attaching bulkhead out of alignment.

5-16. WHEEL BALANCING. Since uneven tire wear is usually the cause of wheel unbalance, replacing the tire probably will correct this condition. Tire and tube manufacturing tolerances permit a specified amount of static unbalance. The lightweight point

of the tire is marked with a red dot on the tire sidewall and the heavyweight point of the tube is marked with a contrasting color line (usually near the valve stem). When installing a new tire, place these marks adjacent to each other. If a wheel becomes unbalanced during service, it may be statically rebalanced. Wheel balancing equipment is available from the Cessna Service Parts Center.

5-17. STEP BRACKET REPLACEMENT.

NOTE

The step bracket is secured to the landing gear spring strut with Conley-Weld, or a similar epoxy base adhesive.

- Mark the position of the bracket so that the replacement bracket will be installed in approximately the same position.
- Remove all traces of the original adhesive as well as any rust, paint, or scale with a wire brush and coarse sand paper.
- Leave surfaces slightly roughened or abraded, but deep scratches or nicks should be avoided.
- Clean the surfaces to be bonded thoroughly. If a solvent is used, remove all traces of the solvent with a clean, dry cloth. It is important for the surfaces to be clean and dry.
- Check the fit of the step bracket on the spring. A gap of not more than 1/32 inch is permissible.
- Mix the adhesive carefully according to manufacturer's directions.

g. Spread a coat of adhesive on the surfaces to be bonded, and place step bracket in position on the spring. Tap the bracket upward to insure a tight fit.

h. Form a small fillet of the adhesive at all edges of the bonded surfaces. Remove excess adhesive with lacquer thinner.

i. Allow the adhesive to cure thoroughly according to manufacturer's recommendations before flexing the gear spring or applying loads to the step.

j. Repaint gear spring and step bracket after curing is complete.

5-18. NOSE GEAR.

5-19. REPLACEMENT OF NOSE GEAR. (See figure 5-3.)

a. Weight tail of the airplane to raise nose wheel off the ground and remove access plates around nose gear.

b. Disconnect nose gear steering bungee from steering arm.

c. (1966 Models.) Remove bolt (9, sheet 1) to disconnect drag strut.

d. (1967 Models.) Remove bolt (4, sheet 2) and washers (6 and 7, sheet 2) to disconnect drag strut. Note position of washers (6 and 7) during removal of bolt.

e. Remove bolts (17, sheet 1) or bolts (15, sheet 2) to disconnect upper trunnion from fuselage structure. Access to either set of bolts is obtained from inside the cabin after removing carpet on each side of tunnel at firewall.

f. Install the nose gear by reversing the preceding steps. Be sure to install washers (6 and 7, sheet 2) in the position shown.

5-20. STANDARD NOSE WHEEL SPEED FAIRING REPLACEMENT. (See figure 5-3.)

a. Weight the tail of the airplane to raise the nose wheel off the ground.

b. Remove nose wheel axle stud.

c. Deflate strut completely.

WARNING

Be sure strut is deflated completely before removing bolt that attaches speed fairing to strut or disconnecting the torque link.

d. Disconnect lower torque link from lower strut and allow strut to extend.

e. Remove bolt attaching speed fairing to strut and remove cover plate. This is the bolt that attaches the fork as well as the tow-bar spacers.

f. Slide speed fairing up and remove the nose wheel. Loosen scraper if necessary. Use a rod or long punch inserted through one ferrule to tap the opposite one out of the fork. Remove both ferrules and pull the nose wheel from the fork.

g. Rotate speed fairing 90° and work it down over the nose gear fork.

h. Install speed fairing by reversing the preceding steps. Tighten axle stud until a slight bearing drag is obvious when the wheel is turned. Back off the nut to the nearest castellation and install cotter pins.

i. Service shock strut after installation has been completed.

CAUTION

Always check scraper clearance after installing speed fairings, whenever a tire has been changed, and whenever scraper adjustment has been disturbed. Set clearance between tire and scraper at 0.38 inch. Elongated holes in scraper are provided for adjustment. Wipe fuel and oil from the speed fairings to prevent stains and deterioration. If the airplane is flown from surfaces with mud, snow, or ice, the fairings should be checked to make sure there is no accumulation which could prevent normal wheel rotation.

5-21. HEAVY-DUTY NOSE WHEEL SPEED FAIRING REPLACEMENT.

a. Weight the tail of the airplane to raise nose wheel off the ground.

b. Remove nose wheel axle stud.

c. Deflate strut and disconnect lower torque link from fork hub.

WARNING

Be sure strut is deflated completely before disconnecting torque link.

d. Remove bolt securing speed fairing to fork hub. The speed fairing is attached to the lugs on the forward side of the fork hub and the tow-bar spacers are also attached with same bolt.

e. Slide speed fairing up and remove the nose wheel. Loosen scraper if necessary. Use a rod or long punch inserted through one ferrule to tap the opposite one out of the fork. Remove both ferrules and pull the nose wheel from the fork.

f. Remove bolts attaching wheel fork to fork hub and remove fork and speed fairing.

g. Install speed fairing by reversing the preceding steps. Tighten axle stud until a slight bearing drag is obvious when the wheel is turned. Back off the nut to the nearest castellation and install cotter pins.

h. Service shock strut after installation has been completed.

CAUTION

Always check scraper clearance after installing speed fairing, whenever a tire has been changed, and whenever scraper adjustment has been disturbed. Set clearance between tire and scraper at 0.38 inch. Elongated holes in the scraper are provided for adjustment. Wipe fuel and oil from the speed fairings to prevent stains and deterioration. If the airplane is flown from surfaces with mud, snow, or ice, the fairings should be checked to make sure there is no accumulation which could prevent normal wheel rotation.

5-22. REMOVAL OF NOSE WHEEL. Removal of the nose wheel may be accomplished as outlined in paragraphs 5-20 or 5-21.





Figure 5-3. Nose Landing Gear (Sheet 1 of 2)



- | | | |
|-------------------|-----------------------------------|----------------------------|
| 1. Steering Shaft | 8. Bracket | 16. Nose Wheel |
| 2. Roll Pin | 9. Bushing | 17. Hub Cap |
| 3. Steering Arm | 10. Shimmy Dampener | 18. Cover Plate |
| 4. Bolt | 11. Link | 19. Standard Speed Fairing |
| 5. Lower Trunnion | 12. Steering (Rudder Trim) Bungee | 20. Tow-Bar Spacer |
| 6. Thin Washer | 13. Drag Link | 21. Wheel Scraper |
| 7. Thick Washer | 14. Bolt | 22. Axle Ferrule |
| | 15. Bolt | |

Figure 5-3. Nose Landing Gear (Sheet 2 of 2)

5-23. DISASSEMBLY OF NOSE WHEEL.

- a. Completely deflate the tire and break tire beads loose.

WARNING

Injury can result from attempting to separate wheel halves with tire inflated. Avoid damaging wheel flanges when breaking tire beads loose.

- b. Remove thru-bolts and separate wheel halves.
- c. Remove tire and tube.
- d. Remove bearing retaining rings, grease seals and bearing cones.

NOTE

The bearing cups are a press fit in the wheel halves and should not be removed unless replacement is necessary. To remove, heat wheel half in boiling water for 15 minutes. Using an arbor press, if available, press out the bearing cup and press in the new one while the wheel is still hot.

5-24. **INSPECTION AND REPAIR.** Instructions given in paragraph 5-10 for the main wheels may be used as a guide for inspection and repair of the nose wheel.

5-25. ASSEMBLY OF NOSE WHEEL.

- a. Place tire and tube on wheel half. Insert thru-bolts, position other wheel half, and secure with nuts and washers. Torque bolts to value marked on wheel.

CAUTION

Uneven or improper torque of the thru-bolt nuts may cause bolt failure with resultant wheel failure.

- b. Clean and repack bearing cones with clean wheel bearing grease.
- c. Assemble bearing cones, seals, and retainers into the wheel halves.
- d. Inflate tire to seat tire beads, then adjust to correct pressure.

5-26. **INSTALLATION OF NOSE WHEEL.** Installation of the nose wheel may be accomplished as outlined in paragraph 5-20 or 5-21.

5-27. STANDARD NOSE GEAR.

5-28. The standard nose gear shock strut is shown in figure 5-4. The optional heavy-duty nose gear, discussed later in this Section is shown in figure 5-5. Replacement of the nose gear assembly may be accomplished as outlined in paragraph 5-19.

5-29. **STANDARD NOSE GEAR DISASSEMBLY.** (See figure 5-4.) The following procedure applies to the nose gear shock strut after it has been removed from the airplane, and the speed fairing and nose wheel have been removed. In many cases, separating the upper and lower struts will permit inspection and

parts replacement without removal or complete disassembly.

WARNING

Deflate strut completely before removing bolt (3), lock ring (30), or bolt (32). Also deflate strut before disconnecting torque links.

- a. Remove torque links. Note position of washers, shims, spacers, and bushings.
- b. Remove shimmy dampener.
- c. Remove steering shaft (16) by driving out roll pins (14) and removing steering arm (15).
- d. Remove lock ring (30) from groove inside of lower end of upper strut (11). A small hole is provided in the lock ring groove to facilitate removal.

NOTE

Hydraulic fluid will drain from strut as lower strut is pulled from the upper strut.

- e. Using a straight, sharp pull, remove lower strut from upper strut. Invert lower strut and drain hydraulic fluid from strut.
- f. Remove lock ring (24) and bearing (25) from top end of lower strut.
- g. Slide packing support ring (27), scraper ring (28), retaining ring (29), and lock ring (30) from lower strut. Note relative position and top side of each ring and bearing to aid in reassembly.
- h. Remove and discard O-rings and back-up rings from packing support ring (27).
- i. Remove bolt (32) and slide torque link fitting (31) from lower strut (26).
- j. Remove metering pin (39) and base plug (37). Remove O-rings and metering pin from base plug.

NOTE

Lower strut and fork are a press fit, drilled on assembly. Separation of these parts is not recommended except for replacement of parts.

- k. Remove bolt (18), tab washer (19), and unscrew collar (23), and remove shim(s) (22), washers (20), and steering collar (21) from upper strut.
- l. Remove clamp attaching the filler extension valve to strut and disconnect from filler valve at top of the strut.
- m. Remove bolt (3) at top of strut, and remove collar (4) and orifice support (8). Remove O-ring and valve from orifice support.
- n. Bushings and bearings in lower trunnion (9), upper trunnion (2) and collar (4) may be replaced as required. Needle bearing in steering collar (21) should not be replaced; replace the steering collar if needle bearing is defective.

NOTE

Upper and lower trunnions (2 and 9) are press-fitted to the upper strut (11), with braces (1) installed during assembly. Pin (13) is also press-fitted to the lower trunnion.




Figure 5-4. Standard Nose Gear Shock Strut

5-30. ASSEMBLY OF STANDARD NOSE GEAR STRUT.

a. Thoroughly clean all parts in solvent and inspect them carefully. Replace all worn or defective parts and all O-rings, seals, and back-up rings with new parts.

b. Assemble the strut by reversing the order of the procedure outlined in paragraph 5-29 with the exception that special attention must be paid to the following procedures.

c. Sharp metal edges should be smoothed with No. 400 emery paper, then thoroughly cleaned with solvent.

d. Used sparingly, Dow Corning DC-4 compound is recommended for O-ring lubrication. All other internal parts should be liberally coated with hydraulic fluid during assembly.

NOTE

Cleanliness and proper lubrication, along with careful workmanship are important during assembly of the shock strut.

e. Lubricate needle bearings as shown in figure 2-6 before installing.

f. When installing collar (23), screw it onto the upper strut until it is flush with the lower end of the strut, to the nearest one-third turn. Use shims (22) as required above lower washer (20), to fill gap between collars (21 and 23). Shims are available from the Cessna Service Parts Center as follows:

1243030-5.....	0.006"
-6.....	0.012"
-7.....	0.020"

Use a new tab washer (19) to safety bolt (18).

g. Install the contoured back-up ring (40), one on each side of O-ring (41) with concave surface of back-up ring next to the O-ring.

h. When installing bearing (25) at top of lower strut (26), be sure that beveled edge of bearing is installed up next to lock ring (24).

i. When installing lock ring (30), position the lock ring so that one of its ends covers the small access hole in the lock ring groove at the bottom of upper strut (11).

j. When installing shimmy dampener, do not tighten attaching bolts to a torque value in excess of 10 lb-in.

k. Tighten torque link center bolt snug. Then tighten to next castellation and install cotter pin.

l. Service the shock strut with hydraulic fluid and compressed air. Install strut filler valve extension and install strut in airplane.

NOTE

It is easier to service the shock strut just before installation, although it may be serviced after installation if desired. Refer to paragraph 2-21.

5-31. HEAVY-DUTY NOSE GEAR.

5-32. The optional heavy-duty nose gear is shown in figure 5-5, which may be used as a guide during maintenance. Replacement procedures are the same as

those given in paragraph 5-19. Refer to paragraph 5-21 for speed fairing replacement.

5-33. HEAVY-DUTY NOSE GEAR DISASSEMBLY. (See figure 5-5.) This paragraph outlines complete disassembly of the heavy-duty nose gear shock strut after it has been removed from the airplane, and the nose wheel and speed fairing have been removed from the strut. In many cases, separating the upper and lower struts will permit inspection and parts replacement without removal or complete disassembly.

WARNING

Deflate strut completely before removing bolt (3), lock ring (30), or bolt (33). Also deflate strut before disconnecting torque links.

a. Remove torque links. Note position of washers, shims, spacers, and bushings.

b. Remove shimmy dampener.

c. Remove link (17) from steering shaft (16) and collar (21).

d. Remove steering shaft (16) by driving out roll pins (14) and removing steering arm (15).

e. Remove lock ring (30) from groove inside of lower end of upper strut (11). A small hole is provided in the lock ring groove to facilitate removal.

NOTE

Hydraulic fluid will drain from strut as lower strut is pulled from the upper strut.

f. Using a straight, sharp pull, remove lower strut from upper strut. Invert lower strut and drain hydraulic fluid from strut.

g. Remove lock ring (24) and bearing (25) from top end of lower strut (26).

h. Slide packing support ring (27), scraper ring (28), retaining ring (29), and lock ring (30) from lower strut. Note relative position and top side of each bearing and ring to aid in reassembly.

i. Remove and discard O-rings (41 and 42) and back-up rings (40) from packing ring support (27).

j. Remove four bolts, washers, and nuts attaching fork (34) to fork hub (31) and remove shim (39).

k. Remove bolt (33) securing metering pin (38) and base plug (36). Remove O-rings (35 and 37) and metering pin (38) from base plug (36).

NOTE

Fork hub (31) and lower strut (26) are a press-fit, drilled on assembly. Separation of these parts is not recommended, except for replacement of parts.

l. Remove bolt (18) and tab washer (19), unscrew collar (23), and remove washers (20), shim (22), and steering collar (21).

m. Remove clamp attaching the filler valve extension valve to strut and disconnect from filler valve at top of strut.

n. Remove bolt (3) at top of upper strut, and remove collar (4) and orifice support (8). Remove O-ring (7) and filler valve (6) from orifice support (8).




Figure-5-5. Heavy-Duty Nose Gear Shock Strut

o. Bushings and bearings in lower trunnion (9), upper trunnion (2), and collar (4) may be replaced as required. Needle bearings in steering collar (21) should not be replaced; replace the steering collar if needle bearing is defective.

NOTE

Upper and lower trunnions (2 and 9) are press-fitted to upper strut (11), with braces (1) installed during assembly. Pin (13) is also press-fitted to the lower trunnion.

5-34. ASSEMBLY OF HEAVY-DUTY NOSE GEAR. (See figure 5-5.)

a. Thoroughly clean all parts in solvent and inspect them carefully. Replace all worn or defective parts and all O-rings, seals, and back-up rings with new parts.

b. Assemble the strut by reversing the order of the procedure outlined in paragraph 5-33 with the exception that special attention must be paid to the following procedures.

c. Sharp metal edges should be smoothed with No. 400 emery paper, then thoroughly cleaned with solvent.

d. Used sparingly, Dow Corning DC-4 compound is recommended for O-ring lubrication. All other internal parts should be liberally coated with hydraulic fluid during assembly.

NOTE

Cleanliness and proper lubrication, along with careful workmanship are important during assembly of the shock strut.

e. Lubricate needle bearings as shown in figure 2-6 before installing.

f. When installing collar (23), screw it onto the upper strut until it is flush with bottom end of the strut, to the nearest one-third turn. Use shim (22) as required above lower washer (20) to fill gap between collars (21 and 23). Refer to paragraph 5-30 for the available shims. Use a new tab washer (19) to safety bolt (18).

g. Install the contoured back-up rings (40), one on each side of O-ring (41) with concave surface of back-up ring next to the O-ring.

h. When installing bearing (25) at top of lower strut (26), be sure that beveled edge of bearing is installed up next to lock ring (24).

i. When installing lock ring (30), position the lock ring so that one of its ends covers the small access hole in the lock ring groove in the bottom of the upper strut (11).

j. When installing shimmy dampener, do not tighten attaching bolts to a torque value in excess of 10 lb-in.

k. Tighten torque link center bolt snug, then tighten to next castellation and install cotter pin.

l. Service the shock strut with hydraulic fluid and compressed air. Install strut filler valve extension and install strut in airplane.

NOTE

It is easier to service the shock strut just before installation, although it may be serviced after installation if desired. Refer to paragraph 2-21.

5-35. WHEEL BALANCING. Refer to paragraph 5-16 for wheel balancing.


5-36. TORQUE LINKS. The torque links are illustrated in figure 5-6, which may be used as a guide for removal, disassembly, assembly, and installation. Grease fittings and torque link bushings should not be removed except for replacement. Excessively worn parts should be replaced. Always deflate nose gear strut before disconnecting torque links.

5-37. SHIMMY DAMPENER. The shimmy dampeners for the different models are illustrated in figures 5-7 and 5-7A, which may be used as guides for removal, disassembly, and installation. Replace any parts found defective. When assembling shimmy dampener, use new O-rings and back-up rings. Lubricate parts during assembly with clean hydraulic fluid. Refer to paragraphs 2-22 and 2-22A for shimmy dampener servicing procedures. When installing shimmy dampener, do not tighten attaching bolts to a torque value in excess of 10 lb-in.

SHOP NOTES:

NOTE

Shims (14) are available to use as required between torque link and nose gear fork to remove any looseness.




1967 MODELS AND ON


NOTE

Shim (13) is used as required (maximum of three shims) under centering lug (12) to prevent over extension of the nose gear strut. Refer to figure 5-3.

*Used only with heavy-duty gear.



HEAVY-DUTY



STANDARD

PRIOR TO 1967 MODELS

- 1. Nut
- 2. Washer
- 3. Upper Torque Link
- 4. Grease Fitting

- 5. Bushing
- 6. Bolt
- 7. Spacer
- 8. Cotter Pin
- 9. Bolt

- 10. Lower Torque Link
- 11. Weld Assembly
- 12. Centering Lug
- 13. Shim
- 14. Shim

Figure 5-6. Torque Links




Figure 5-7. Shimmy Dampener

5-38. NOSE WHEEL STEERING SYSTEM.

5-39. The nose wheel steering system, shown in figure 5-8, links the rudder pedals to the nose wheel steering arm, affording steering control through the use of the rudder pedals and brakes. When moving the airplane by hand, never turn the nose wheel more than 35 degrees either side of center.

5-40. REMOVAL AND INSTALLATION. Figure 5-8 shows details of the nose wheel steering system and may be used as a guide during replacement of parts. Refer to Section 2 for lubrication.

5-41. RIGGING. Since the nose wheel steering system is connected to the rudder control system, refer to Section 10 for rigging procedures.

5-42. BRAKE SYSTEM.

5-43. The hydraulic brake system consists of two master cylinders, brake lines connecting each master cylinder to its wheel brake cylinder, and the single-disc type brake assembly, located at each main landing gear wheel.




Figure 5-7A. Shimmy Dampener

SHOP NOTES:




Figure 5-8. Nose Wheel Steering System

5-44. TROUBLE SHOOTING THE BRAKE SYSTEM.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
DRAGGING BRAKES.		
Brake pedal binding.	If brake pedals fail to return properly, check pedal for binding.	Check and adjust properly.
Parking brake linkage holding brake pedal down.	Check parking brake if pedal fails to return when released.	Check and adjust properly.
Worn or broken piston return spring. (In master cylinder.)	If brake pedal fails to return after it is released and linkage is not binding, the master cylinder is faulty.	Repair or replace master cylinder.
Insufficient clearance at Lock-O-Seal in master cylinder.	If pressure remains in brake system when pedals are released, disassemble master cylinder and check Lock-O-Seal clearance.	Adjust as shown in figure 5-9.
Restriction in hydraulic lines or restriction in compensating port in master brake cylinders.	Jack up wheel to be checked. Have someone apply and then release brakes. Wheel should rotate freely as soon as brakes are released. If wheel fails to rotate freely, loosen brake line at brake housing to relieve any pressure trapped in the line. If wheel now turns freely, the brake line is restricted or there is a restriction in the brake master cylinder.	Drain brake lines and clear the inside of the brake line with filtered compressed air. Fill and bleed brakes. If cleaning the lines fails to give satisfactory results, the master cylinder may be faulty and should be repaired.
Worn, scored or warped brake discs.	Visually check discs.	Replace brake discs and linings.
Damage or accumulated dirt restricting free movement of wheel brake parts.	Check parts for freedom of movement.	Clean and repair or replace parts as necessary.
BRAKES FAIL TO OPERATE.		
Leak in system.	Check entire system for leaks.	If brake master cylinders or wheel brake assemblies are leaking, they should be repaired or replaced.
Air in system.		Bleed system.
Lack of fluid in master cylinders.	Check fluid level.	Fill and bleed if necessary.
Master cylinder defective.		Repair or replace master cylinder.

SHOP NOTES:




Figure 5-9. Brake Master Cylinder

5-45. BRAKE MASTER CYLINDERS. The brake master cylinders, located just forward of the pilot's rudder pedals, are actuated by applying toe pressure at the top of the rudder pedals. A small reservoir is incorporated into each master cylinder to supply it with fluid. Where dual brakes are installed, mechanical linkage permits the copilot's pedals to operate the master cylinders.

5-46. REMOVAL AND INSTALLATION OF BRAKE MASTER CYLINDERS.

- a. Remove bleeder screw at wheel brake assembly and drain hydraulic fluid from brake system.
- b. Remove front seats and rudder bar shield for access to brake master cylinders.
- c. Disconnect parking brake linkage and brake master cylinders from rudder pedals.
- d. Disconnect brake master cylinders at bottom attach points.
- e. Disconnect hydraulic hoses from brake master cylinders and remove cylinders.
- f. Plug or cap hydraulic fittings, lines, and hoses to prevent entry of foreign materials.
- g. Reverse the preceding steps to install brake master cylinders, then fill and bleed brake system in accordance with paragraph 5-56.

5-47. DISASSEMBLY AND REPAIR OF BRAKE MASTER CYLINDERS. Figure 5-9 may be used as a guide during disassembly and assembly of the brake master cylinders. Repair is limited to replacement of parts, cleaning, and adjustment. Use clean hydraulic fluid as a lubricant during assembly of the cylinders.

5-48. HYDRAULIC BRAKE LINES are of rigid aluminum tubing, except for flexible hose used at the brake master cylinders. Beginning with the 1967 models, some wheel brake assemblies are moved to the forward side of the strut; therefore, a flexible hose connects the rigid tubing along the strut to the wheel brake assembly. A separate line is used to connect each brake cylinder to its corresponding wheel brake cylinder. During the 1967 model year the 1/4 inch brake lines were changed to 3/16 inch aluminum lines and the flexible hose were changed to the smaller automotive type brake hose.

5-49. WHEEL BRAKE ASSEMBLIES. The wheel brake assemblies use a disc which is attached to the main wheel with the wheel thru-bolts, and a floating brake assembly. See figure 5-10.

5-50. REMOVAL OF WHEEL BRAKES. Wheel brake assemblies are a floating type and can be removed after disconnecting the brake line and removing the back plates.

NOTE

The brake disc can be removed after wheel removal and disassembly. To remove the torque plate, remove the wheel and axle in accordance with paragraph 5-13.

5-51. INSPECTION AND REPAIR OF WHEEL BRAKES.

- a. Clean all parts except brake linings and O-rings in dry cleaning solvent and dry thoroughly.
- b. O-rings are usually replaced at each overhaul. If their re-use is necessary, they should be wiped with a clean cloth soaked in hydraulic fluid and inspected for damage.

NOTE

Thorough cleaning is important. Dirt and chips are the greatest single cause of malfunctions in the hydraulic brake system.

- c. Check brake linings for deterioration and maximum permissible wear. See paragraph 5-54.
- d. Inspect brake cylinder bore for scoring. A scored cylinder may leak or cause rapid O-ring wear. A scored brake cylinder should be replaced.
- e. If the anchor bolts on the brake assemblies are nicked or gouged, they should be sanded smooth to prevent binding with the pressure plate or torque plate. When the anchor bolts are replaced they should be pressed out. New bolts can be installed by tapping in place with a soft hammer.

5-52. ASSEMBLY OF WHEEL BRAKES. Lubricate parts with hydraulic fluid and assemble components with care to prevent damage to O-rings. Refer to figure 5-10 during assembly of wheel brakes.

5-53. INSTALLATION OF WHEEL BRAKES. Place the brake assembly in position with pressure plate in place, then install back plate and safety the attaching bolts. If the torque plate was removed, install as the wheel and axle are installed. If the brake disc was removed from the wheel, install as the wheel is assembled.


5-54. CHECKING BRAKE LININGS. The brake linings should be replaced when they are worn to a minimum thickness of 3/32 inch. Visually compare a 3/32-inch strip of material held adjacent to each lining to measure the thickness of the lining. The shank end of correct size drill bits make excellent tools for checking minimum thickness of brake linings.

5-55. BRAKE LINING REPLACEMENT. (See figure 5-10.)

- a. Remove bolts, washers, and back plate.
- b. Pull the brake cylinder out of torque plate and slide pressure plate off anchor bolts.
- c. Place back plate on a table with lining side down flat. Center a 9/64 inch (or slightly smaller) punch in the rolled rivet, and hit the punch crisply with a hammer. Punch out all rivets securing the linings to the back plate and pressure plate in the same manner.

NOTE

A rivet setting kit, Part No. R561, is available from the Cessna Service Parts Center. This kit consists of an anvil and punch.



1. Screw
2. Lockwasher
3. Grease Seal Ring
4. Felt Seal
5. Grease Seal Ring
6. Bearing Cone
7. Outer Wheel Half
8. Tire and Tube
9. Inner Wheel Half
10. Grease Seal Plate and Felt

11. Screw
12. Washer
13. Grease Seal Ring
14. Bearing Cup
15. Brake Disc
16. Torque Plate
17. Pressure Plate
18. Anchor Bolt
19. Hydraulic Fitting
20. Washer

21. Nut
22. Bolt
23. Washer
24. Bleeder Cap
25. Brake Cylinder
26. Piston
27. Brake Lining
28. Bolt
29. Brake Lining
30. Back Plate

Figure 5-10. Wheel and Brakes




Figure 5-11. Brake System

- 5-56. **BRAKE BLEEDING.** Standard bleeding, with a clean hydraulic pressure source connected to the wheel cylinder bleeder, is recommended.
- Remove brake master cylinder filler plug and screw a flexible hose with a suitable fitting into the filler hole. Immerse the free end of the hose in a container with enough hydraulic fluid to cover the end of the hose.
 - Connect a clean hydraulic pressure source, such

c. As fluid is pumped into the system, observe the immersed end of the hose at the brake master cylinder for evidence of bubbles being forced from the brake system. When bubbling has ceased, remove the bleeder source from the brake wheel cylinder and tighten the bleeder valve.

Ensure that the free end of the hose from the brake master cylinder remains immersed during the entire bleeding process.

- ### 5-57. PARKING BRAKE SYSTEM.

5-58. The parking brake system is essentially a ratchet-held handle which depresses and holds the brake master cylinders in the compressed position. No adjustment is provided in the system; replacement of worn or defective parts will restore the system to its correct operation. Figure 5-11 may be used as a guide for replacement of parts.

5-26

CESSNA AIRCRAFT COMPANY

MODEL 200 SERIES

SERVICE MANUAL

SECTION 5A

RETRACTABLE LANDING GEAR AND HYDRAULIC SYSTEM (210 AND T210 SERIES)

TABLE OF CONTENTS	Page
LANDING GEAR RETRACTION SYSTEM... 5A-2	
Operation Description..... 5A-2	
Troubleshooting..... 5A-5	
HYDRAULIC POWER SYSTEM	
COMPONENTS..... 5A-9	
ENGINE-DRIVEN HYDRAULIC PUMP..... 5A-9	
Removal and Installation..... 5A-9	
HYDRAULIC FILTER..... 5A-9	
Removal and Cleaning..... 5A-9	
POWER PACK..... 5A-9	
Removal..... 5A-11	
Disassembly and Repair..... 5A-11	
Installation..... 5A-11	
Primary and Secondary Relief Valve	
Adjustment..... 5A-11	
Priority Valve Adjustment..... 5A-11	
Handle-Release Adjustment..... 5A-11	
EMERGENCY HAND PUMP..... 5A-14	
Disassembly and Repair..... 5A-15	
LANDING GEAR ELECTRICAL CIRCUITS..... 5A-17	
Adjustment of Switches..... 5A-17	
HYDRAULIC TOOLS AND EQUIPMENT..... 5A-18	
Hydro Test Unit..... 5A-18	
Hydro Fill Unit..... 5A-19	
BLEEDING AND LEAK-TESTING..... 5A-19	
Bleeding Hydraulic System..... 5A-19	
Bleeding Emergency Hand Pump..... 5A-19	
Leak-Testing..... 5A-19	
Checking Hydraulic Fluid	
Contamination..... 5A-19	
MAIN LANDING GEAR..... 5A-20	
Removal of Main Wheels..... 5A-20	
Disassembly of Main Wheels..... 5A-20	
Inspection and Repair of Main	
Wheel..... 5A-20	
Assembly of Main Wheels..... 5A-20	
Installation of Main Wheels..... 5A-20	
Removal and Installation of Main	
Wheel and Axle..... 5A-20	
Removal of Main Gear Strut and	
Wheel..... 5A-20	
Installation of Main Gear Strut and	
Wheel..... 5A-20	
Removal of Main Gear Actuator and	
Saddle..... 5A-20	
Saddle Bearing Repair..... 5A-20	
Disassembly and Repair of	
Actuator..... 5A-22	
Installation of Actuator and Saddle..... 5A-22	
Main Gear Snubber..... 5A-22	
Adjustment of Main Gear Snubber..... 5A-22	
Removal and Installation of Main	
Gear Uplock Mechanism..... 5A-22	
Disassembly and Repair of Main	
Gear Uplock Cylinders..... 5A-22	
Main Gear Downlocks and	
Downlock Release Cylinders..... 5A-22	
Removal and Installation of	
Downlock Release Cylinders..... 5A-25	
Disassembly and Repair of	
Downlock Release Cylinders..... 5A-25	
Main Gear Rigging..... 5A-25	
Main Wheel Alignment..... 5A-25	
Wheel Balancing..... 5A-25	
Step Bracket Replacement..... 5A-25	
MAIN GEAR DOOR SYSTEM..... 5A-25	
Removal and Installation of Main	
Wheel Doors..... 5A-25	
Removal and Installation of Main	
Wheel Door Actuator..... 5A-25	
Disassembly and Repair of Door	
Actuator..... 5A-25	
Removal and Installation of Main	
Gear Strut Doors..... 5A-25	
Removal and Installation of Main	
Gear Strut Door Actuator..... 5A-25	
Disassembly and Repair of Main	
Gear Strut Door Actuator..... 5A-25	
Rigging Main Gear Door System..... 5A-25	
NOSE GEAR..... 5A-26	
Removal and Installation of Nose	
Wheel..... 5A-25	
Disassembly of Nose Wheel..... 5A-29	
Inspection and Repair of Nose	
Wheel..... 5A-29	
Assembly of Nose Wheel..... 5A-29	
Wheel Balancing..... 5A-29	
Removal and Installation of Nose	
Gear..... 5A-29	
Disassembly of Nose Gear Strut..... 5A-29	
Assembly of Nose Gear Strut..... 5A-32	
Torque Links..... 5A-32	
Shimmy Dampener..... 5A-32	
Removal and Installation..... 5A-32	
Nose Gear Actuator..... 5A-34	
Removal..... 5A-34	
Disassembly and Repair..... 5A-34	
Installation..... 5A-34	
Nose Gear Uplock Mechanism..... 5A-34	
Removal and Installation of Uplock	
and Release Actuator..... 5A-34	
Disassembly and Repair of Uplock	
Release Actuator..... 5A-34	
Nose Gear Rigging..... 5A-34	
Nose Wheel Steering System..... 5A-34	
Removal and Installation..... 5A-34	
Rigging..... 5A-34	
NOSE GEAR DOOR SYSTEM..... 5A-34	
Removal and Installation of Nose	
Wheel Doors..... 5A-34	
Removal and Installation of Nose	
Wheel Door Mechanism..... 5A-35	
Disassembly and Repair of Nose	
Wheel Door Actuator..... 5A-35	
Removal and Installation of Nose	
Gear Strut Doors..... 5A-35	
Rigging of Nose Gear Door	
System..... 5A-35	
BRAKE SYSTEM..... 5A-37	
RIGGING OF MAIN LANDING GEAR..... 5A-37	
Rigging Adjustment Support..... 5A-37	
Rigging Downlock Mechanism..... 5A-39	
Rigging Uplock Mechanism..... 5A-39	

Rigging of Doors	5A-39	Connecting Hydro Test	5A-43
Adjustment of Snubber Valves	5A-39	Disconnecting Hydro Test	5A-43
Rigging Down Indicator Switch	5A-39	Filling Airplane Reservoir.	5A-43
Rigging Up Indicator Switches	5A-39	Bleeding Time-Delay Valve	5A-43
Rigging Throttle Warning Switch	5A-39	Bleeding Airplane Hydraulic System	5A-44
RIGGING OF NOSE GEAR	5A-39	Bleeding Emergency Hand Pump	5A-44
Rigging Downlock Mechanism	5A-39	Leak-Testing	5A-44
Rigging Uplock Mechanism	5A-39	Cycling Landing Gear	5A-44
Rigging Down Indicator Switch	5A-42	Checking Time-Delay Valve	5A-44
Rigging Up Indicator Switch	5A-42	Checking Handle-Release	5A-44
Rigging Safety Switch	5A-42	Checking Priority Valve.	5A-45
Rigging of Doors	5A-42	Checking Primary Relief Valve.	5A-45
RIGGING POWER PACK SWITCH AND		Checking Secondary Relief Valve	5A-45
LOCKOUT SOLENOID.	5A-42	Checking For Suction Air Leakage	5A-45
Rigging Up-Down Switch.	5A-42	Checking Landing Gear Cycle Time.	5A-46
Rigging of Handle Lockout	5A-42	BENCH TESTING POWER PACK	5A-46
HYDRO TEST OPERATION	5A-43	Connecting Power Pack to Hydro Test	5A-46
General Operation Suggestions	5A-43	Operational Check of Power Pack	
Flow Regulation	5A-43	Valves	5A-46

It is sometimes necessary to open or close the landing gear doors while the airplane is on the ground with the engine stopped. Operate the doors with the landing gear handle in the "down" or "down-neutral" position. To open the doors, turn off the master switch and operate hand pump until doors open. To close the doors, turn the master switch on and operate the hand pump.

NOTE

Position of the master switch for gear door operation is easily remembered by the following rule: OPEN circuit = OPEN doors; CLOSED circuit = CLOSED doors.

5A-1. LANDING GEAR RETRACTION SYSTEM.

5A-2. OPERATION DESCRIPTION. Refer to the hydraulic schematic diagrams to trace the flow of hydraulic fluid as outlined in the following steps.

a. Fluid from the hydraulic pump enters the Power Pack where a passage connects to the primary relief valve. With the landing gear control lever in neutral, hydraulic fluid circulates back through the pump (unloaded).

b. When the landing gear control lever is moved out of neutral, fluid flows through a check valve to the solenoid-operated door control valve and to the gear priority valve.

c. Fluid flows through the door control valve (which is in the door-open position when the control lever is moved out of neutral) and opens the doors. The gear priority valve remains closed while the door system is being operated because the door system operates at less pressure than is required to open the priority valve.

d. After the doors are open, pressure builds up until the gear priority valve opens and permits fluid first to unlock, then to move the landing gear to either the up or down position, depending on the position selected by the landing gear control lever.

e. During the up-cycle of the landing gear, a metering pin in each main gear actuator causes a snubbing action in the actuator near the end of the gear-up travel.

f. After the landing gear is in full up or full down

position, limit switches are actuated to cause the door control valve to move to the door-closed position, and fluid then flows through the valve to close the doors.

g. After the doors are closed, pressure builds up in the system until the 3 to 9-second time-delay valve, operated by pressure from the door-close line, opens and permits fluid to flow to the handle release valve, returning the handle to neutral.

h. As the handle returns to neutral, it moves a shaft which again permits fluid to circulate back through the pump (unloaded).

NOTE

Prior to the 1968 models, a secondary relief valve, which also serves as the emergency hand pump relief valve, opens at a higher pressure than the primary relief valve.

Beginning with the 1968 models, the secondary relief valve is deleted from the hydraulic system. This also includes relocation of the primary relief valve, in the hydraulic circuit, to a position downstream of the engine-driven hydraulic pump check valve. This prevents loading of the engine-driven pump when the emergency hand pump is operated. Delete references to the secondary relief valve for the 1968 models.

i. When extending the landing gear with the hand pump, fluid flows directly to the door control valve and the priority valve, where it first opens the doors then extends the landing gear through the same passages and lines used by the regular system. A check valve prevents fluid from entering the inlet passage from the engine-driven hydraulic pump.

j. In case of an electrical failure, the door control valve will move to the door-open position and remain in this position.

k. A valve in the Power Pack relieves any pressure from thermal expansion in the door system, to keep the doors closed while the airplane is parked.




Figure 5A-1. Hydraulic System Components Location




Figure 5A-2. Hydraulic Power System

5A-3. TROUBLE SHOOTING.

NOTE

Use the Hydro Test for trouble shooting landing gear malfunction. When the Hydro Test is employed to power the hydraulic system, landing gear operation can be slowed down to a "slow motion" during which hydraulic pressures can be noted precisely and mechanical action can be observed.

WARNING

Before performing maintenance in any of the wheel or strut wells, always disconnect the doors to avoid injury from unintentional actuation of the doors. They close rapidly and with considerable force.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
ENGINE PUMP WILL NOT OPERATE GEAR BUT EMERGENCY HAND PUMP WILL OPERATE GEAR.		
Fluid level low in reservoir.	Check fluid level through sight gage on reservoir.	Refill reservoir.
Engine pump or pump line failure.	Refer to paragraph 5A-138.	Repair, replace pump or broken pump line. Refill reservoir.
Faulty primary relief valve.	Refer to paragraph 5A-136.	Remove Power Pack, repair or replace primary relief valve.
ENGINE PUMP OR EMERGENCY PUMP WILL NOT BUILD PRESSURE IN SYSTEM.		
No fluid in reservoir.	Check fluid level.	Refill reservoir.
Broken gear or door line.	Check visually.	Repair or replace hydraulic line.
Door solenoid valve jammed or sticking at mid travel.	Switch master switch on and off to free jammed valve by solenoid hammering; if this fails to dislodge valve spool, remove Power Pack for repair of jammed valve.	Repair solenoid valve.
Faulty secondary relief valve.	Refer to paragraph 5A-137.	Remove Power Pack, repair or replace secondary relief valve.
DOORS WILL NOT CLOSE, GEAR INDICATOR LIGHT NOT ILLUMINATED.		
Master switch not on.	Check visually.	Turn master switch on.
Defective limit switch circuit.	Check circuit breaker, then check circuit continuity to isolate open in circuit.	Repair defective component in circuit.
DOORS WILL NOT CLOSE, GEAR INDICATOR LIGHT ILLUMINATED.		
Defective handle up-down (pre-select) switch or wiring circuit.	Check circuit breaker, then check circuit continuity to isolate open circuit.	Repair or replace defective switch or wiring.
Defective door solenoid.	Place a steel scale against solenoid, checking for magnetic field. If magnetic field is not present solenoid is defective.	Replace solenoid.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
DOORS WILL NOT CLOSE, GEAR INDICATOR LIGHT ILLUMINATED. (Cont)		
Door solenoid valve stuck.	Place a steel scale against solenoid checking for magnetic field. If magnetic field is present, solenoid valve is stuck.	Remove Power Pack, repair or replace solenoid valve.
GEAR OPERATES BUT DOOR WILL NOT OPEN.		
Solenoid valve jammed or stuck in door-closed position.	Turn master switch on and off to free jammed valve by solenoid hammering; if this fails to dislodge valve spool, Power Pack must be removed for repair of jammed valve.	Repair or replace solenoid valve. Repair any damage to doors or door operating linkage.
GEAR UNLOCKS BEFORE DOORS ARE FULL OPEN.		
Priority valve setting low.	Check setting using the Hydro Test. See paragraph 5A-135.	Adjust Valve.
Priority valve leaking or stuck open.	Check valve using the Hydro Test.	Remove Power Pack and repair or replace valve.
LANDING GEAR HANDLE WILL NOT LOCK IN UP OR DOWN DETENT.		
Handle release valve plunger setting too low or incorrect return spring adjustment.	Check using the Hydro Test.	Adjust handle release valve and return springs. See paragraph 5A-20.
LANDING GEAR HANDLE RETURNS TO NEUTRAL BEFORE DOORS CLOSE.		
Fluid low in reservoir causing air in time-delay valve.	Check visually.	Fill reservoir and purge time-delay valve as outlined in paragraph 5A-128.
Time-delay valve stuck or will not hold fluid charge do to faulty time-delay valve ball seat.	Bleed time-delay valve per paragraph 5A-128. If not corrected, ball seat is faulty or valve is stuck open.	Remove Power Pack and repair or replace time-delay valve.
LANDING GEAR HANDLE FAILS TO RETURN TO NEUTRAL AFTER DOORS CLOSE (3 TO 9 SECONDS).		
Landing gear handle release pressure too high.	Refer to paragraph 5A-134.	Adjust handle release pressure.
Landing gear handle return springs setting too low.	Handle does not return to neutral sharply after handle has tripped.	Adjust return springs.
Landing gear handle shaft binding.	Move handle up and down, feeling for binding or jerky movement.	Remove Power Pack, repair or replace handle shaft. Also see Appendix A.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
LANDING GEAR HANDLE FAILS TO RETURN TO NEUTRAL AFTER DOORS CLOSE (3 TO 9 SECONDS) (Cont).		
Landing gear selector spool binding.	See preceding isolation procedure.	Remove Power Pack and replace manifold, selector spool and time-delay valve plunger as an assembly only.
<p style="text-align: center;">NOTE</p> <p>Extremely cold temperatures will cause a longer time delay before handle trips after the doors close. This is normal. If landing gear handle does not return to neutral properly, Power Pack overheating will result.</p>		
HAND PUMP DOES NOT BUILD UP PRESSURE, BUT ENGINE PUMP OPERATES GEAR PROPERLY.		
Faulty hand pump plunger check valve or O-ring.	Remove and inspect hand pump plunger.	Repair or replace parts as needed.
Faulty system inlet check valve or hand pump inlet check valve.	If plunger assembly is not defective, either the system inlet check valve or the hand pump inlet check valve is defective.	Remove Power Pack and repair or replace check valves.
LANDING GEAR OPERATION EXTREMELY SLOW.		
Reservoir fluid level low.	Check fluid level through sight gage.	Refill reservoir.
Engine-driven pump failure or internal leakage.	Refer to paragraph 5A-138.	Repair or replace engine pump.
Air leakage in engine pump suction line.	Refer to paragraph 5A-138.	Repair or replace suction lines or fittings.
Fluid leak in door or gear line.	Check visually for spilled fluid.	Tighten or replace lines.
Defective piston seal in door or gear cylinder.	Refer to paragraph 5A-139.	Repair or replace defective parts.
Excessive internal Power Pack leakage.	Refer to paragraph 5A-139.	Remove and repair or replace Power Pack.
POWER PACK EXTERNAL LEAKAGE.		
SLIDING SEALS. (Seals having a moving part.)		
Handle release plunger.	Check visually.	Remove release plunger and replace O-rings.
Hand pump plunger gland.	Check visually.	Remove hand pump plunger and replace O-rings.
Landing gear selector spool.	Check visually.	Remove Power Pack and replace O-ring on spool and in manifold.
Priority valve.	Check visually.	Remove Power Pack and replace priority valve seals.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
POWER PACK EXTERNAL LEAKAGE (Cont).		
STATIC SEALS. (Seals with no moving parts.)		
All fittings.	Check visually.	Remove and replace O-rings and back-up rings as required.
Hand pump gland.	Check visually.	Remove hand pump and replace O-rings.
Door solenoid.	Check visually.	Replace O-ring.
Transfer tubes between manifold and body.	Check visually.	Remove Power Pack, disassemble and replace O-rings.
Time-delay valve.	Check manually.	Remove Power Pack, disassemble and replace O-rings.
Reservoir cover.	Check visually.	Remove Power Pack and remove cover. Replace seals.
POWER PACK LOSES FLUID WITH NO EVIDENCE OF LEAKAGE.		
Air leak at engine pump shaft seal.	Refer to paragraph 5A-138.	Repair or replace engine pump.
Air leak in suction line to engine pump.	Refer to paragraph 5A-138.	Repair or replace suction line or fittings.
<p style="text-align: center;">NOTE</p> <p>In this condition, hydraulic fluid is foaming due to air being pumped into the system, and the fluid is being blown overboard through the Power Pack vent line.</p>		

HYDRAULIC SYSTEM PRESSURES

COMPONENT	OPENING PRESSURE	RESEATING PRESSURE
Handle Release Valve.	750 to 1250 psi.	-----
Priority Valve	750 to 800 psi.	-----
Primary Relief Valve.	1800 psi. (Max.)	1450 psi. (Min.)
Secondary Relief Valve.	1950 psi. (Max.)	1550 psi. (Min.)
Inlet Check Valve.	10 psi. (Max.)	2 psi. (Min.)
Hand Pump Check Valves.	10 psi. (Max.)	2 psi. (Min.)

5A-4. HYDRAULIC POWER SYSTEM COMPONENTS.

5A-5. The hydraulic power system includes equipment required to provide a flow of pressurized

hydraulic fluid to the retractable landing gear system. Main components of the hydraulic system are listed in the following chart.

ITEM	PURPOSE	LOCATION AND ACCESS
Engine-driven hydraulic pump.	To provide a flow of pressurized hydraulic fluid to the system.	Right rear accessory pad of engine. Remove upper cowling.
Hydraulic filter.	To filter fluid from the pump before entering remainder of system.	Upper right side of firewall in engine compartment. Remove the upper engine cowling.
Hydraulic Power Pack.	(1) To "load" the engine-driven pump when landing gear handle is moved out of neutral. (2) To provide a reservoir of hydraulic fluid. (3) To afford control of gear and door systems through use of valves and appropriate passages.	At top of pedestal. Partially accessible for adjustment with the decorative cover and pedestal front panels removed.
Emergency hand pump.	(4) To provide emergency hydraulic pressure through use of hand pump in the unit.	Integral with Power Pack.

5A-6. ENGINE-DRIVEN HYDRAULIC PUMP.

5A-7. The gear-type hydraulic pump is mounted on the right rear accessory pad of the engine. Driven at approximately 1-1/2 times engine crankshaft speed, the pump supplies a controlled flow of hydraulic fluid to the Power Pack and hydraulic system whenever the landing gear control handle is operated. While the control handle is in neutral, the pump bypass in the Power Pack allows the pump to cycle the hydraulic fluid. Pump flow is controlled to approximately one gallon-per-minute.

5A-8. REMOVAL AND INSTALLATION.

- Remove upper cowling. Except on the T210, remove induction airbox.
- Disconnect hydraulic lines and hoses from pump and cap or plug open fittings, lines and hoses.
- Remove four nuts securing pump to accessory case and pull pump aft to remove. Retain washers.
- To install pump, install a new mounting gasket, grease pump drive splines lightly with general purpose grease, and slide pump into position. Rotate pump shaft as necessary for smooth meshing of splines, and reverse the preceding steps.
- To prevent initial dry-running of the pump:
 - Loosen suction hose fitting at pump inlet fitting.
 - Remove Power Pack reservoir overboard vent line from fitting at top of firewall.
 - Connect suitable pressure filler unit to reservoir filler line fitting on right side of firewall.
 - Hold finger over open end of overboard vent line fitting and fill hydraulic reservoir until fluid is forced from loosened end of the suction hose.
 - Tighten suction hose, reconnect reservoir vent line, and disconnect filler unit.

- The pump may be disassembled and repaired as outlined in Appendix A.

5A-9. HYDRAULIC FILTER.

5A-10. DELETED

5A-11. A hydraulic filter is installed in the pump pressure line at the firewall to filter the hydraulic fluid before it enters the Power Pack. The filter screen disc is a 31 micron screen capable of passing hydraulic fluid at the rate of approximately 1.12 gallons-per-minute.

5A-12. REMOVAL AND CLEANING. The screen in the hydraulic filter should be removed and cleaned with solvent (Federal Specification P-S-661, or equivalent) at the first 25 hours, the first 50 hours, and at each 100-hour inspection thereafter. Also the screen should be removed and cleaned whenever improper fluid circulation is suspected. Figure 5A-2 shows details of the filter and may be used as a guide during removal, disassembly, assembly, and installation.

5A-13. POWER PACK.

5A-14. The hydraulic Power Pack, located in the pedestal, is a multi-purpose control unit in the hydraulic system. It contains a hydraulic reservoir, valves which control flow of pressurized fluid to the various actuators in the door and landing gear system, and an electrical switch connected to a gear warning horn and indicator lights. An emergency hand pump uses reservoir fluid to permit extension of the landing gear if hydraulic pressure should fail.




Figure 5A-3. Location of Power Pack Fittings

5A-15. REMOVAL.

NOTE

As hydraulic lines are disconnected or removed, plug or cap all openings to prevent entry of foreign material in the lines or fittings.

- a. Remove front seats and spread drip cloth over forward carpet.
- b. Remove landing gear control lever knob and remove decorative cover from pedestal.
- c. Position a gallon can under fill-and-drain tee fitting, then remove pressure cap on tee and drain reservoir fluid into can. A funnel with attached hose will simplify draining.
- d. Cut safety wire and disconnect electrical plug from door solenoid valve.
- e. Disconnect and cap or plug all hydraulic lines from the Power Pack.
- f. Remove upper panel assembly from pedestal.
- g. Remove the three studs and one bolt securing the Power Pack to the pedestal side members, then work Power Pack aft out of the pedestal.

NOTE

The two studs on the left side of the Power Pack serve also as pivots for the elevator trim wheel and pointer. The studs may be unscrewed from the Power Pack threads without major disturbance to the elevator trim system components by using an open end wrench to remove them. The stud on the right side of the Power Pack is the pivot for the cowl flap control arm. The cowl flap control must be removed from the pedestal side structure to remove this stud.

5A-16. DISASSEMBLY AND REPAIR. Refer to Appendix A for disassembly and repair of the hydraulic Power Pack.

5A-17. INSTALLATION.

NOTE

When installing a new Power Pack, leave the bulkhead nuts loose on the tubing fittings. This will allow proper positioning of these fittings, making it easier to align and connect the hydraulic lines.

- a. Work Power Pack into position and install the three studs and one bolt that secure it to the pedestal sides.

NOTE

The three studs serve as pivots for the elevator trim wheel, trim wheel pointer, and the cowl flap control arm. Adjust these systems and controls as necessary, according to instructions contained in appropriate sections of this manual, before installing the pedestal decorative cover.

- b. Connect all hydraulic lines to Power Pack fittings. Make sure fittings are properly installed, with jam nuts tight, after lines are tightened.

- c. Connect and safety electrical plug at door solenoid valve.

- d. Install upper panel assembly on pedestal.

- e. Connect filler unit and fill reservoir with clean hydraulic fluid.

- f. With airplane on jacks, use Hydro Test to operate landing gear through several cycles to bleed system. Check for proper operation and any signs of hydraulic fluid leakage.

- g. Check elevator trim operation and cowl flap operation, and rig as required.

- h. Install decorative cover and landing gear control lever knob.

5A-18. PRIMARY AND SECONDARY RELIEF VALVE ADJUSTMENT. If the primary or secondary relief valve should get out of adjustment, fluid contamination, wear of parts, or defective parts should be suspected. Remove the Power Pack, disassemble, repair, and adjust as outlined in Appendix A.

5A-19. PRIORITY VALVE ADJUSTMENT. The priority valve may be adjusted while the Power Pack is installed in the airplane as follows:

- a. Jack the airplane and connect Hydro Test in accordance with paragraph 5A-125.

- b. Check priority valve setting in accordance with paragraph 5A-135.

- c. If adjustment is required, turn priority valve adjusting screw (see figure 5A-5) in to increase pressure at which priority valve opens. Adjust so that the valve opens at 750 to 800 psi as noted on the Hydro Test gage.

- d. Cycle the landing gear to check for proper operation, then lower the landing gear.

- e. Fill reservoir and disconnect Hydro Test in accordance with paragraph 5A-126.

- f. Remove airplane from jacks.


5A-20. HANDLE-RELEASE ADJUSTMENT. (See figure 5A-6). Correct adjustment of the landing gear handle-release mechanism is necessary because incorrect adjustments can cause excessive pressures in the Power Pack and can prevent free circulation of fluid, resulting in damage to the Power Pack. If the mechanism releases too soon, the landing gear handle may return to neutral before the landing gear doors are closed, if the time-delay should function improperly. Pressure build-up after the doors are closed operates the time-delay valve. After the valve opens, pressure then disengages a spring-loaded plunger from a detent and a handle return spring then pushes the handle back to neutral. The spring load on the detent plunger and the spring load on each handle return spring are adjustable. To adjust the handle-release mechanism proceed as follows:

- a. Jack the airplane, then connect Hydro Test in accordance with paragraph 5A-125.

- b. Remove pedestal decorative cover to gain access to adjusting plugs at bottom of Power Pack.


- c. If Power Pack is being installed or if reservoir fluid level has been low, fill reservoir and bleed

1
INSTALL NUT




THESE THREADS MUST NOT PROTRUDE BELOW NUT. POSITION NUT EXACTLY AT TOP OF NON-THREADED AREA.

2
POSITION O-RING




COVER THREADS WITH A PLASTIC THIMBLE OR TAPE, APPLY PETROLATUM TO O-RING, THEN ROLL IT UP INTO POSITION AGAINST NUT. REMOVE THIMBLE OR TAPE AFTER O-RING IS IN POSITION.

3
INSTALL ELBOW IN THREADS UNTIL O-RING CONTACTS CHAMFER, AND NUT CONTACTS FACE OF BOSS




ROTATE NUT AND FITTING TOGETHER TO RETAIN THE ORIGINAL POSITION OF THE NUT ON THE FITTING.

4
ATTACH LINE TO ELBOW (ELBOW MAY BE TURNED TO LIMITS SHOWN TO ALIGN WITH HOSE OR LINE)



HOLD NUT STATIONARY, TURN FITTING TO DESIRED POSITION.


5
TIGHTEN NUT



INSTALL O-RINGS CAREFULLY. MOST HYDRAULIC LEAKS ARE CAUSED BY CARELESS INSTALLATION.


Figure 5A-4. Installation of Hydraulic Fittings (Sheet 1 of 2)

1
INSTALL NUT




POSITION NUT WITH RECESS DOWN.

2
POSITION BACK-UP RING & O-RING




APPLY PETROLATUM TO BACK UP RING AND O-RING, THEN WORK THEM UP INTO POSITION AGAINST NUT. TURN NUT DOWN UNTIL O-RING IS PUSHED DOWN FIRMLY AGAINST LOWER THREADS.

3
INSTALL ELBOW IN THREADS UNTIL O-RING CONTACTS FACE OF BOSS



ROTATE NUT AND FITTING TOGETHER TO RETAIN THE ORIGINAL POSITION OF THE NUT ON THE FITTING.


4
WITH NUT HELD, TURN FITTING IN 1½ TURNS



1-1/2 TURNS PLUS A MAXIMUM OF 1 ADDITIONAL TURN TO ALIGN WITH HYDRAULIC LINE.

ATTACH LINE TO FITTING.

5
TIGHTEN NUT UNTIL IT CONTACTS BOSS



INSTALL O-RINGS CAREFULLY. MOST HYDRAULIC LEAKS ARE CAUSED BY CARELESS INSTALLATION.

Figure 5A-4. Installation of Hydraulic Fittings (Sheet 2 of 2)

time-delay valve in accordance with paragraph 5A-128.

d. Using Hydro Test, cycle landing gear through at least two full cycles, unless handle will not hold or fails to release.

NOTE

If the handle will not hold, either the detent spring load adjustment is set too low, the handle-return spring load adjustments are set too high, or the handle-return springs are bottoming out and not permitting the handle-release plunger to reach the detent positions. Check that the handle can be moved manually into the detent positions. If it cannot, loosen handle-return spring adjusting plugs (2 and 3) until the handle will engage the detents. If the handle will not release, either the detent spring load adjustment is set too high (forcing the detent plunger partially into the detent and making it mechanically impossible for the plunger to move completely out of the detent) or the handle-return spring load adjustments are set too low. Tighten detent spring load adjusting plug (1) until detent plunger bottoms out in detent, then loosen plug (1) approximately two full turns, until handle will release.

e. Using the Hydro Test, check the pressure at which the handle-release plunger disengages the detents, and readjust handle-release detent spring adjusting plug (1) as necessary to obtain a release pressure of approximately 1000 psi. Tolerance is 750 psi to 1250 psi. Use a very slow flow, and be sure time is allowed for time-delay valve to open. Cycle the landing gear between each adjustment.

f. Readjust handle-return spring adjusting plugs (2 and 3) until handle trips back from up and down positions with a positive snap. Again, cycle the landing gear between each adjustment.

g. Recheck the handle-release pressure specified in step "e".

h. Operate landing gear through several cycles, lower the landing gear, and remove airplane from jacks.

i. Disconnect Hydro Test and install decorative cover on pedestal.

5A-21. EMERGENCY HAND PUMP.

5A-22. The emergency hand pump is internally mounted in the Power Pack. The pump supplies a flow of pressurized hydraulic fluid to open the doors and extend the landing gear if hydraulic pressure should fail. The hand pump receives a reserve supply of fluid from the Power Pack reservoir and pumps the fluid directly to the door control valve




Figure 5A-5. Priority Valve Adjustment

and gear priority valve, then into the passages and lines used by the regular system.

5A-23. DISASSEMBLY AND REPAIR. The emer-

gency hand pump may be repaired while in the airplane. Refer to Appendix A for dissassembly and repair of the emergency hand pump.




Figure 5A-6. Handle Release Adjustment

SHOP NOTES:




Figure 5A-7. Simplified Electric Schematic

SHOP NOTES:

5A-24. LANDING GEAR ELECTRICAL CIRCUITS.

5A-25. Landing gear electrical circuits are shown in figure 5A-7, which shows the switches in the

gear down and locked, weight-on-gear condition. The following chart describes what each electrical component in the circuit does, and what causes it to operate.

ITEM	OPERATED BY	FUNCTION
Up indicator switches.	Gear in up and locked position.	Closes circuit to gear up indicator light, handle up-down switch, and door solenoid valve.
Down indicator switches.	Gear in down and locked position.	Closes circuit to gear down indicator light, handle up-down switch, and door solenoid valve.
Handle up-down switch.	Power Pack selector spool.	"Preselects" up or down circuit. (Completes up circuit to door solenoid valve when gear reaches up position, completes down circuit to door solenoid valve when gear reaches down position.)
Door solenoid valve.	Completion of up circuit or down circuit. (Handle up-down switch and all gear indicator switches closed.)	Shifts valve to door-close position when energized. Spring-loaded to door-open position. Thus, with an electrical failure, the solenoid valve will remain in the door-open position and doors cannot be closed.

NOTE

Remember this rule: CLOSED circuit = CLOSED doors; OPEN circuit = OPEN doors. Applying this rule, the doors can be opened or closed at will by placing handle in down or down neutral, turning master switch either on or off, and supplying pressure with the hand pump.

Nose gear safety switch.	Actuating arm on lower torque link.	When airplane weight causes shock strut to compress, switch opens circuit to handle lock-out solenoid, which is spring-loaded to lock position. When airborne, strut extends and closes switch, to unlock handle from gear-down range.
Handle lock-out solenoid.	Nose gear safety switch.	Prevents handle from being moved out of gear-down range while airplane is on ground.

CAUTION

Since a fully extended strut (too much air pressure, extremely aft weight distribution, etc.) simulates an airborne condition, be especially careful not to move gear handle from gear-down range under these conditions, or nose gear will retract.

5A-26. ADJUSTMENT OF SWITCHES. Landing gear up indicator switches, down indicator switches, nose gear safety switch, and handle up-down switch may be adjusted as outlined in

the rigging procedures beginning with paragraph 5A-103. Adjustment of the throttle actuated switch is contained in paragraph 12-55.




Figure 5A-8. Simplified Schematic of Hydro Test Unit

5A-27. HYDRAULIC TOOLS AND EQUIPMENT.

5A-28. HYDRO TEST UNIT. A special portable hydraulic servicing unit is available from the Cessna Service Parts Center. The Hydro Test unit combines a motor-driven pump, pressure jack, pressure gage, reservoir, and controls into a compact unit. The Hydro Test or its equivalent is indispensable for servicing, testing, and rigging of the landing gear system.

WARNING

When using the Hydro Test, make sure personnel are in the clear before cycling the landing gear. Apply hydraulic pressure carefully; gear and door operations are rapid when hydraulic flow is set near the full capacity of the Hydro Test unit.

A hydraulic test unit may be assembled locally if desired. Specifications for a test unit are listed in the following chart.

1. Flow	1.25 -.50 gpm
2. Accumulators	None
3. Reservoir	1 gallon
4. Check Valve	Aft of Pump in pressure line.
5. Filter	3 gpm, 10 micron in pressure line after pump and before relief valve.
6. Relief Valve	Pressure line after filter and discharging to reservoir.
7. Relief Valve Setting	1700 - 00 crack to 1500 psi (min) reseal
8. Pressure Gage	2000 psi dial on pressure line and snubbed.
9. Temperature Gage	50 to 200°F at pump outlet.
10. Suction Hose and Lines	-8 (1/2 inch tube size) (min)
11. Pressure Hose and Line	-4 (1/4 inch tube size) (min)
12. Power Input	3 hp (desired) 2 hp (min)

CAUTION

Means should be provided to keep connections to aircraft system clean and free of foreign material at all times.

5A-29. HYDRO FILL UNIT. A special filler can with a manually operated pump is available from the Cessna Service Parts Center. In addition to providing a handy means of filling hydraulic reservoirs, the unit may be used to bleed the brake system.

5A-30. BLEEDING AND LEAK TESTING.

NOTE

Refer to paragraph 5A-122 for Hydro Test operation.

5A-31. BLEEDING OF THE HYDRAULIC SYSTEM. Bleeding may be accomplished by jacking the airplane and using the Hydro Test to cycle the landing gear and door system through several complete cycles. Refer to paragraph 5A-128 for bleeding of the time-delay valve inside the Power Pack. Use only clean, filtered hydraulic fluid in the hydraulic system. Hydraulic fluid preservative (MIL-H-6083) may be used for flushing and storage of hydraulic components.

NOTE

There is only one reason to have to bleed the hydraulic system. The entrance of considerable air into the hydraulic system. The most probable means of air getting into the system are: permitting reservoir fluid level to become low, air leaks in the engine-driven pump or pump suction line, and poor maintenance procedures when connecting lines and installing actuators, etc.

5A-32. BLEEDING OF THE EMERGENCY HAND PUMP may be accomplished by operating the hand pump, with the master switch OFF, until landing gear doors are fully open. Continue to operate hand pump very slowly, increasing pressure until the secondary relief valve opens and all air is bled from hand pump and valve.

CAUTION

It is very important that the hand pump be operated very slowly as pressure is being increased to bleed the secondary relief valve. If the hand pump is operated rapidly, damage to the valve can occur as air permits parts to "slam" against each other.

5A-33. LEAK-TESTING. When testing a system for leakage, the Power Pack must be bypassed. Connect Hydro Test into applicable system to be tested, apply a pressure of 2200 psi, and hold for 5 minutes. Refer to paragraph 5A-131 for Hydro Test operation during leak-testing. When checking an actuating cylinder for internal leakage, connect the Hydro Test to one port of unit and leave other port open.

CAUTION

When leak-testing any actuator, with pressure applied to one port of the cylinder, always have the opposite port open to atmospheric pressure. Otherwise, excessive pressure may be built up due to the differential area across the piston. (The rod side of the piston has less area than the head side. Thus, pressure applied to the head side of the piston may apply a far greater pressure to fluid on the rod side of the piston.)

The total of line assemblies, fittings, actuators, and any other part subject to hydrostatic (dead end) pressure shall be deemed faulty due to overstressing if hydraulic pressure in that immediate sub-system is allowed to exceed 2275 psi for any period of time.

5A-34. CHECKING HYDRAULIC FLUID CONTAMINATION. At the frequencies specified in Section 2, check contamination of hydraulic fluid as follows:

a. Disconnect a door actuator hose and drain a small quantity of fluid by actuating the hand pump. If the fluid is clear and is not appreciably darker

in color than new fluid, continue to use the present fluid.

b. If fluid coloration is doubtful, place fluid sample in a non-metallic container and insert a strip of polished copper in the fluid. Keep copper in the fluid for six hours at a temperature of 70°F. or more. A slight darkening of the copper is permissible, but there should be no pitting or etching visible up to 20X magnification.

5A-35. MAIN LANDING GEAR.

5A-36. The main landing gear struts rotate aft and inboard to stow the main wheels beneath the baggage compartment. Struts are down-locked by spring-loaded pawls at the inboard edge of the struts and by additional pawls which wedge the struts securely at the outboard supports. Uplocks are located on the main wheel stowage bay forward bulkhead. Uplocking pawls here hold the struts in the stowed position. Rotation of the gear to extend or retract the struts is achieved by saddles which are in turn bolted to the shaft flange of the hydraulic rotary actuators.

NOTE

As an additional downlock safety feature, the inboard downlocks are released by "gear up pressure" and the outboard downlocks are in the "door-open pressure" circuit.

5A-37. REMOVAL OF MAIN WHEELS. Refer to paragraph 5-8 for removal of the main wheels.

NOTE

The Model 210 and T210 Series do not use wheel speed fairings. Instead of wheel speed fairing, a hub cap is installed on the wheel over the end of the axle.

5A-38. DISASSEMBLY. Refer to paragraph 5-9 for disassembly of the main wheels.

5A-39. INSPECTION AND REPAIR. Refer to paragraph 5-10 for inspection and repair of the main wheels.

5A-40. ASSEMBLY OF MAIN WHEELS. Refer to paragraph 5-11 for assembly of the main wheels.

5A-41. INSTALLATION OF MAIN WHEELS. Refer to paragraph 5-12 for installation of the main wheels.

NOTE

Delete reference to wheel speed fairing and install hub cap.

5A-42. REMOVAL AND INSTALLATION OF MAIN WHEEL AND AXLE. Refer to paragraph 5-13 and 5-14 for removal and installation of main wheel and axle.

5A-43. REMOVAL OF MAIN GEAR STRUT AND WHEEL.

- a. Remove individual rear seats or bench type rear seat.
- b. Remove rear carpet over the raised portion of floorboard and remove access plates over landing gear bulkhead.
- c. Jack airplane in accordance with paragraph 2-4.
- d. Place landing gear handle up, with master switch off, and operate emergency hand pump until main gear downlocks release.
- e. Disconnect wheel brake line from elbow at top of saddle.
- f. Remove bolts, washers, and nuts securing clamp and strut to saddle.
- g. Carefully work strut out through door openings, leaving brake line attached to strut.

5A-44. INSTALLATION OF MAIN GEAR STRUT AND WHEEL.

- a. Reverse the steps in paragraph 5A-43 to install the main gear strut and wheel.
- b. Check rigging of main landing gear in accordance with paragraphs 5A-103 thru 5A-111.
- c. After removal from jacks, check wheel alignment in accordance with paragraph 5A-58.

5A-45. REMOVAL OF MAIN GEAR ACTUATOR AND SADDLE.

- a. Remove strut and wheel as outlined in paragraph 5A-43.
- b. Remove access plates above actuators.
- c. Disconnect and cap or plug all hydraulic lines at actuator.
- d. Remove swivel fitting from actuator.
- e. Remove bolts attaching saddle assembly to the rotary actuator flange.
- f. Remove bolts attaching the actuator mounting flange to the bulkhead casting, and holding saddle assembly in place, move the actuator inboard to separate the actuator from the saddle assembly. Work the actuator free and remove. Note position of O-ring seal between the mating flanges of the rotary actuator and saddle flange.
- g. Slide the saddle assembly inboard, free of the bearing.

NOTE

Seal or tape the exposed bearing surface of the saddle to exclude dirt.

5A-46. SADDLE BEARING REPAIR. A worn saddle bearing may necessitate reaming the bearing oversize and installing an oversize bushing to fit the bearing. The bearing should be hand-reamed after the landing gear, saddle assembly, and gear actuator have been removed to gain access to the bronze bearing.

5A-47. DELETED




Figure 5A-9. Main Gear Down Locks

5A-48. **DISASSEMBLY AND REPAIR OF MAIN GEAR ACTUATOR.** Refer to Appendix A for disassembly and repair of the main gear actuator.

5A-49. **INSTALLATION OF MAIN GEAR ACTUATOR AND SADDLE.**

a. Slide the saddle assembly in place, in the hole in the bulkhead forging.

b. Work the actuator into position, make sure O-ring seal is in groove on actuator flange, and install bolts which attach saddle and actuator flanges.

c. Install bolts which attach the actuator to the structure. Bend tangs of washers to safety the bolts.

d. Connect hydraulic lines to the actuator.

e. Install brake line swivel fitting and line at saddle fitting.

f. Install strut and wheel as outlined in paragraph 5A-42.

g. Rig main gear and check wheel alignment as outlined in paragraphs 5A-57 and 5A-58.

h. Bleed the affected brake and remove the airplane from jacks.

5A-50. **MAIN GEAR SNUBBER.** An adjustable metering pin is installed in each main landing gear actuator cylinder. This metering pin causes a snubbing action in the actuator the final .5 to 1.0 second up travel of the main landing gear.

5A-51. **ADJUSTMENT OF MAIN GEAR SNUBBER.** With the landing gear rigged and the limit switches adjusted as outlined in paragraphs 5A-103, through 5A-121, adjust main actuator snubbers so that snubbing action occurs during the final .5 to 1.0 second of main gear up travel. This may be done as follows:

a. With airplane on jacks and Hydro Test connected, retract landing gear and see that both main gears lock at the same time in the up position.

b. If the main gears are not locking at the same time, but both main gears are snubbing, adjust the slower gear as follows:

1. Loosen door line and lock nut at end of actuator.

2. Adjust metering pin in (clockwise facing the cylinder head end of actuator) until main gears lock simultaneously in the up position. Cycle landing gear after each adjustment.

NOTE

When adjusting metering pin, wait a minimum of 30 seconds between up or down cycle of the landing gear. This allows time for the time-delay valve cavity to refill.

c. If one main gear is not snubbing, adjust the faster main gear as follows:

1. Loosen door line and locknut at end of actuator.

2. Adjust metering pin out (counterclockwise facing cylinder head end of actuator) until main gears lock simultaneously in the up position. Cycle landing gear after each adjustment.

CAUTION

When adjusting metering pin out, use care to prevent damage to the snap ring on the metering pin. Adjust out only until snap ring bottoms against actuator cylinder head. **DO NOT FORCE.** Approximately two threads will be showing through locknut with snap ring against cylinder head of actuator.

d. After adjustments are completed, tighten locknut and door line on actuators and resafety metering pin locknut.

NOTE

Snubbing time is determined by observing the Hydro Test pressure gage. A sudden increase in pressure during the gear up cycle indicates the start of the snubbing action and a sudden decrease indicates that the gear is up and locked.

5A-52. **REMOVAL AND INSTALLATION OF MAIN GEAR UPLOCK MECHANISM.** Figure 5A-11 shows details of the main gear uplock mechanism and may be used as a guide during replacement of parts.

5A-53. **DISASSEMBLY AND REPAIR OF MAIN GEAR UPLOCK CYLINDER.** Refer to Appendix A for disassembly and repair of the main landing gear uplock cylinder.

5A-54. **MAIN GEAR DOWNLOCKS AND DOWNLOCK RELEASE CYLINDERS.** One cylinder releases both the right and left inboard downlocks and is operated by pressure in the gear up lines. The outboard downlocks are released by a cylinder on each side and the cylinder is operated by pressure in the door open lines.

5A-55. **REMOVAL AND INSTALLATION OF MAIN GEAR DOWNLOCK RELEASE CYLINDERS.** Removal of the main gear downlock release cylinders consists of disconnecting the hydraulic lines and push-pull rods to the downlock pawls. Then remove mounting bolts and work actuator free of airplane. Reverse procedure to install cylinder.




Figure 5A-10. Main Gear Outboard Support and Downlock




Figure 5A-11. Main Gear Uplock Details

5A-56. **DISASSEMBLY AND REPAIR OF DOWN-LOCK RELEASE CYLINDERS.** Refer to Appendix A for disassembly and repair of the main landing gear downlock release cylinders.

5A-57. **MAIN GEAR RIGGING.** Refer to paragraphs 5A-103 thru 5A-111 for rigging and adjustments to the main landing gear.

5A-58. **MAIN WHEEL ALIGNMENT.** Refer to paragraph 5-15 and figure 5-2 for alignment of the main wheels.

5A-59. **WHEEL BALANCING.** Refer to paragraph 5-16 for wheel balancing.

5A-60. **STEP BRACKET REPLACEMENT.** Refer to paragraph 5-17.

5A-61. **MAIN GEAR DOOR SYSTEM.**

5A-62. Main gear doors, shown in figure 5A-12, open for main gear retraction or extension and return to closed position at the completion of either cycle. The strut doors are opened and closed by a double-acting hydraulic actuator. The wheel doors are actuated by a double-actuating hydraulic actuator for each door. Each door actuator contains an internal locking device to hold the doors in the closed position when the actuator is retracted. This lock is released on first flow of hydraulic pressure to the door system.

5A-63. **REMOVAL AND INSTALLATION OF MAIN WHEEL DOORS.**

- a. Open landing gear doors.
- b. Disconnect door from actuator linkage by removing pin or bolt.
- c. Remove door hinge pins or bolts.
- d. Install doors by reversing the preceding steps.
- e. Rig doors in accordance with paragraph 5A-107.

5A-64. **REMOVAL AND INSTALLATION OF MAIN WHEEL DOOR ACTUATOR.**

- a. Open landing gear doors.
- b. Disconnect and cap or plug hydraulic hoses at actuator.
- c. Disconnect actuator rod by removing attaching nut and bolt at door.
- d. Remove nut and bolt attaching actuator to fuselage bracket and remove actuator.
- e. Install actuator by reversing the preceding steps.

NOTE

Fill actuator with clean hydraulic fluid before installing.

- f. After installation of actuator, rig doors and actuator in accordance with paragraph 5A-107.

5A-65. **DISASSEMBLY AND REPAIR OF DOOR ACTUATOR.** Refer to Appendix A for disassembly and repair of door actuating cylinders.

5A-66. **REMOVAL AND INSTALLATION OF MAIN**

GEAR STRUT DOORS.

- a. Open landing gear doors.
- b. Remove nut and bolt attaching push-pull rod to bracket on door.
- c. Remove small cotter pin at forward end of hinge pin and pull hinge pin from door hinge. Door will fall free.
- d. Install door by reversing the preceding steps.
- e. Rig doors in accordance with paragraph 5A-107.

5A-67. **REMOVAL AND INSTALLATION OF MAIN GEAR STRUT DOOR ACTUATOR.**

- a. Open landing gear doors.
- b. Remove carpet and access covers as required for access to actuator.
- c. Disconnect and cap or plug hydraulic hoses at actuator.
- d. Disconnect actuator rod end by removing nut and bolt attaching rod end to bellcrank.
- e. Remove bolt and nut attaching actuator to fuselage bracket and work actuator from airplane. Retain spacers and washers.
- f. Install actuator by reversing the preceding steps.

NOTE

Fill actuator with clean hydraulic fluid before installing.

- g. Rig in accordance with paragraph 5A-107.

5A-68. **DISASSEMBLY AND REPAIR OF MAIN GEAR STRUT DOOR ACTUATOR.** Refer to Appendix A for disassembly and repair of the main gear strut door actuator.


5A-69. **RIGGING MAIN GEAR DOOR SYSTEM.** Refer to paragraph 5A-107 for rigging and adjustments to the main wheel and gear strut doors.

5A-70. **NOSE GEAR.**

5A-71. The nose gear shock strut is pivoted just forward of the firewall. Retraction and extension of the nose gear is accomplished by a double-acting hydraulic cylinder, the forward end of which contains the nose gear downlock. Initial action of the cylinder disengages the downlock before retraction begins. A separate single-acting hydraulic cylinder unlocks the nose gear uplock hook.

5A-72. **REMOVAL AND INSTALLATION OF NOSE WHEEL.**

- a. Weight the tail of the airplane to raise the nose wheel off the ground.
- b. Remove nose wheel axle bolt.
- c. Use a rod or long punch inserted in ferrule to tap the opposite ferrule out of the nose wheel fork. Remove both ferrules and pull nose wheel from fork.
- d. Remove spacers, axle tube and hub caps before disassembling the nose wheel.
- e. Reverse the preceding steps to install the nose wheel. Tighten the axle bolt until a slight bearing drag is obvious when the wheel is turned. Back off the nut to the nearest castellation and install the cotter pin.




1. Bolt
2. Washer
3. Spacer
4. Strut Door Crank Assembly
5. Screw
6. Washer

7. Nut
8. Push-Pull Rod Assembly
9. Hinge Half
10. Hinge Pin
11. Cotter Pin
12. Bracket Assembly
13. Right Wheel Door

14. Left Wheel Door
15. Left Strut Door
16. Actuator Arm
17. Stub Door
18. Hinge Assembly
19. Right Strut Door

Figure 5A-12. Main Landing Gear Doors



PRIOR TO 1967 MODELS

- | | | |
|--------------------|---------------------|------------------|
| 1. Link | 8. Washer | 16. Axle Bolt |
| 2. Uplock Bushing | 9. Bolt | 17. Axle Ferrule |
| 3. Strut | 10. Nut | 18. Washer |
| 4. Steering Bungee | 11. Safety Switch | 19. Cotter Pin |
| 5. Washer | 12. Shimmy Dampener | 20. Nut |
| 6. Bolt | 13. Tire | 21. Axle Spacer |
| 7. Nut | 14. Hub Cap | 22. Axle Tube |
| | 15. Screw | |

Figure 5A-13. Nose Landing Gear (Sheet 1 of 2)




Figure 5A-13. Nose Landing Gear (Sheet 2 of 2)

5A-73. DISASSEMBLY OF NOSE WHEEL.

- a. Remove valve core, completely deflate tire, and break tire beads loose.

WARNING

Injury can result from attempting to separate the wheel halves with the tire inflated. Avoid damaging the wheel flanges when breaking the tire beads loose.

- b. Remove thru-bolts and separate wheel halves.
- c. Remove tire and tube.
- d. Remove bearing retaining rings, grease seals, and bearing cones.

NOTE

The bearing cups are a press fit in the wheel halves and should not be removed unless replacement is necessary. To remove, heat wheel half in boiling water for 15 minutes. Using an arbor press, if available, press out bearing cup and press in the new one while the wheel is still hot.

5A-74. INSPECTION AND REPAIR OF NOSE WHEEL. Instructions given in paragraph 5A-39 for the main wheels may be used as a guide for inspection and repair of the nose wheel.

5A-75. ASSEMBLY OF NOSE WHEEL.

- a. Place tube inside tire and align balance marks on tire and tube.
- b. Place tire and tube on wheel half with tube valve stem through hole in wheel half.
- c. Insert thru-bolts, position other wheel half, and secure with nuts and washers. Torque bolts to value marked on wheel.

WARNING

Uneven or improper torque of the thru-bolt nuts may cause bolt failure with resultant wheel failure.

- d. Clean and repack bearing cones with clean wheel bearing grease.
- e. Assemble bearing cones, seals, and retainers into wheel half.
- f. Inflate tire to seat tire beads, then adjust to correct pressure.

5A-76. WHEEL BALANCING. Refer to paragraph 5-16 for wheel balancing.

5A-77. REMOVAL AND INSTALLATION OF NOSE GEAR ASSEMBLY.

- a. Jack the airplane or weight the tail of the airplane to raise nose wheel off the ground.
- b. Open landing gear doors and disconnect nose wheel doors push-pull rods.
- c. Tag for identification and disconnect the electrical wires at the gear-down microswitch located on the nose gear actuator.
- d. Tag for identification and disconnect the electrical wires at nose gear safety switch on torque links

and remove clamps attaching wires to nose strut.

- e. Disconnect steering bungee from steering bell-crank.
- f. Disconnect nose gear actuator from strut by removing cotter pin, castellated nut, washers, and bolt. Retain spacer washers between downlock hooks on end of actuator.
- g. Disconnect nose gear strut door push-pull rods from nose gear.
- h. Remove trunnion bolts.

NOTE

The trunnion bolts are accessible from inside the cabin, at the very forward end of the tunnel cover. Two men will be required to remove these bolts, one working inside the cabin, the other working in the nose wheel well.

- i. Work the entire nose gear assembly free of the airplane.
- j. Install the nose gear by reversing the preceding steps.
- k. When connecting nose gear actuator to strut, lubricate and torque bolt as outlined in figure 2-6.
- l. Rig nose gear and nose gear doors as outlined in paragraphs 5A-112 thru 5A-118.

5A-78. DISASSEMBLY OF NOSE GEAR STRUT.

(See figure 5A-14.) The following procedure applies to the nose gear shock strut after it has been removed from the airplane, and the nose wheel has been removed. In many cases, separating the upper and lower struts will permit inspection and parts replacement without removal or complete strut disassembly.

WARNING

Deflate strut completely before removing bolt (33), lock ring (31), or bolt (2). Also deflate strut before disconnecting torque links.

- a. Remove torque links. Note position of washers, shims, spacers, and bushings.
- b. Remove shimmy dampener and steering bungee.
- c. Remove link (18) from steering shaft (17) and collar (21).
- d. Remove steering shaft (17) by driving out roll pins (13) and removing steering arm (14).
- e. Remove lock ring (31) from groove inside of lower end of upper strut (10). A small access hole is provided at the lock ring groove to facilitate removal of lock ring.

NOTE

Hydraulic fluid will drain from strut as lower strut is pulled from the upper strut.

- f. Using a straight, sharp pull, remove lower strut from upper strut. Invert lower strut and drain hydraulic fluid from strut.
- g. Remove lock ring (24), bearing (25), and extend stop spacer (26), (sheet 1, figure 5A-14) from lower strut. Spacer (26) is not used in the 1967 model shock strut shown in sheet 2 of figure 5A-14.
- h. Slide shims (42), if used, packing support ring




Figure 5A-14. Nose Gear Shock Strut (Sheet 1 of 2)




Figure 5A-14. Nose Gear Shock Strut (Sheet 2 of 2)

(28), scraper ring (29), retaining ring (30), and lock ring (31), from lower strut (27). Note number of shims (42), relative position, and top side of each ring and bearing to aid in reassembly.

i. Remove and discard O-rings and back-up rings from packing support ring (28).

j. Remove metering pin (38) and base plug (36) by removing bolt (33) from lower strut and fork assembly.

NOTE

Lower strut and fork are a press fit, drilled on assembly. Separation of these parts is not recommended, except for replacement of parts.

k. Remove and discard O-rings (35 and 37) from metering pin (38) and base plug (36).

l. Remove orifice support (7) by removing bolt (2). Remove and discard O-ring (6) from orifice support.

m. Remove snap ring (23, sheet 1, figure 5A-14) or collar (23, sheet 2, figure 5A-14) from upper strut (10). To remove collar (23, sheet 2, figure 5A-14), remove bolt (43) and tab washer (44). Remove washers (20), shims (22), if installed, and steering collar (21).

n. Bushings and bearings in upper trunnion (3) and lower trunnion (8) may be replaced as required. Needle bearing in collar (21) should not be replaced; replace the steering collar if needle bearing is defective.

NOTE

Upper and lower trunnions (3 and 8) are press-fitted to the upper strut (10) with braces (1) installed during assembly. Pin (12) is also press-fitted to the lower trunnion.

5A-79. ASSEMBLY OF NOSE GEAR STRUT. (See figure 5A-14.)

a. Thoroughly clean all parts in solvent and inspect them carefully. Replace all worn or defective parts and all O-rings, seals, and back-up rings with new parts.

b. Assemble the strut by reversing the order of the procedure outlined in paragraph 5A-78 with the exception that special attention must be paid to the following procedures.

c. Sharp metal edges should be smoothed with No. 400 emery paper, then thoroughly cleaned with solvent.

d. Used sparingly, Dow Corning DC-4 compound is recommended for O-ring lubrication. All other internal parts should be liberally coated with hydraulic fluid during assembly.

NOTE

Cleanliness and proper lubrication, along with careful workmanship are important during assembly of the shock strut.

e. Lubricate needle bearings as shown in figure 2-6 before installing.

f. (Sheet 1, figure 5A-14.) When installing snap ring (23), use shims (22) as required above lower

washer (20) to fill gap between snap ring and collar (21). Refer to paragraph 5-30 for the available shims.

g. (Sheet 2, figure 5A-14.) When installing collar (23), screw it onto the upper strut until it is flush with bottom end of the strut, to the nearest one-third turn. Use shims (22) as required above lower washer (20) to fill gap between collars (21 and 23). Refer to paragraph 5-30 for the available shims. Use a new tab washer (44) to safety bolt (43).

h. Install the contoured back-up rings (39), one on each side of O-ring (40) with concave surface of back-up ring next to the O-ring.

i. If new parts are being installed, place packing support ring (28), scraper ring (29), retaining ring (30), in the upper strut (10) and install lock ring (31). Measure the up-down movement of the packing support ring in the upper strut. Shims (42) are used as required above packing support ring to eliminate up-down movement of the packing support ring. Remove packing support ring from upper strut.

j. Slide lock ring (31), retaining ring (30), scraper ring (29), packing support ring (28), and required shims (42) on lower strut (27).

k. When installing bearing (25) at top of the lower strut, be sure that beveled edge of bearing is installed up next to lock ring (24).

l. When installing lock ring (31), position lock ring so that one of its ends covers the small access hole in the lock ring groove in the bottom of the upper strut (10).

m. When installing shimmy dampener, do not tighten attaching bolts to a torque value in excess of 10 lb-in.

n. Tighten torque link center bolt snug, then tighten to next castellation and install cotter pin.

o. Service the shock strut with hydraulic fluid and compressed air and install strut in airplane.

NOTE

It is easier to service the shock strut just before installation, although it may be serviced after installation if desired. Refer to paragraph 2-21.

p. When assembling and attaching the nose gear actuator and downlock mechanism, lubricate and torque attaching bolt as shown in figure 2-6.

5A-80. TORQUE LINKS. The torque links are shown in figure 5A-15, which may be used as a guide for removal, disassembly, assembly, and installation. Grease fittings and torque link bushings should not be removed except for replacement. Excessively worn parts should be replaced. Always deflate nose gear strut before disconnecting the torque links.

5A-81. SHIMMY DAMPENER. Refer to paragraph 5-37 for description of shimmy dampener used on the airplane.

5A-82. REMOVAL AND INSTALLATION. Refer to paragraph 5-37 for removal, disassembly, assembly, and installation of the shimmy dampener.

NOTE

Shims (4) are available to use as required between torque link and nose gear fork to remove any looseness. Also, shim (15) is used as required (maximum of three shims) to prevent over extension of the nose gear strut. Refer to figure 5A-13.




Figure 5A-15. Torque Links

5A-83. NOSE GEAR ACTUATOR. The double-acting nose gear actuator extends and retracts the nose gear and serves as a rigid drag strut in the gear-down position. The claw-like hook on the actuator serves as the downlock for the nose gear. An internal lock position-locks the piston within the cylinder until hydraulic pressure of approximately 125 psi is applied to the gear up port of the actuator.

5A-84. REMOVAL OF NOSE GEAR ACTUATOR.

- a. Tag for identification and disconnect the electrical wires at the gear-down switch located on the forward end of the actuator.
- b. Jack airplane or weight down the tailcone of the airplane to raise the nose wheel off the ground.
- c. Disconnect hydraulic hoses from actuator. Cap or plug hose and fitting openings to prevent entry of foreign material.
- d. Disconnect nose gear actuator from strut by removing cotter pin, castellated nut, washers, and bolt. Retain individual parts of downlock mechanism, which will be freed by bolt removal.
- e. At aft end of actuator remove nut, washer, and bolt attaching actuator to fuselage structure. Tap bolt with a fiber drift or mallet for removal. With bolt removed, actuator is freed.

5A-85. DISASSEMBLY AND REPAIR OF NOSE GEAR ACTUATOR. Refer to Appendix A for disassembly and repair of the nose gear actuator.

5A-86. INSTALLATION OF NOSE GEAR ACTUATOR.

NOTE

Before installing the nose gear actuator, check the condition and fit of attaching bolts and bushings. Replace any defective parts. Fill actuator with hydraulic fluid.

- a. Attach aft end of actuator to fuselage structure with bolt, washer and nut.
- b. Connect hydraulic hoses to actuator.
- c. Connect electrical wire to gear-down switch.
- d. Attach the actuator to the strut with bolt, washers, and nut. Safety nut with a cotter pin.

NOTE

When assembling and attaching the nose gear downlock mechanism to strut, lubricate and torque attaching bolt as shown in figure 2-6.

- e. Adjust nose gear down indicator switch as outlined in paragraph 5A-115.

5A-87. NOSE GEAR UPLOCK MECHANISM.

Figure 5A-20 shows the nose gear uplock mechanism. The uplock hook is located at the top of the nose wheel well and is released by a hydraulically operated actuator also located in the nose wheel well.

5A-88. REMOVAL AND INSTALLATION OF NOSE GEAR UPLOCK AND RELEASE ACTUATOR.

- a. Disconnect uplock spring.

- b. Disconnect and cap or plug hydraulic lines at actuator.
- c. Disconnect and tag electrical wires at up limit switch.
- d. Remove four nuts and washers attaching uplock mechanism to top of nose wheel well. Remove uplock mechanism and actuator from airplane.
- e. Remove cotter pin and clevis pin attaching actuator to uplock mechanism.
- f. Remove nuts, washers and screws attaching actuator to uplock mechanism.
- g. Install uplock mechanism and actuator by reversing the preceding steps.
- h. Rig up-limit switch as shown in figure 5A-21.

5A-89. DISASSEMBLY AND REPAIR OF UPLOCK RELEASE ACTUATOR. Refer to Appendix A for disassembly and repair of uplock release cylinder.

5A-90. RIGGING. Refer to paragraphs 5A-112 and 5A-114 for nose gear rigging and adjustments.

5A-91. NOSE WHEEL STEERING SYSTEM. The nose wheel steering system links the rudder pedals to the nose wheel fork, affording steering control through the use of the rudder pedals. The steering linkage straightens the nose wheel as the landing gear is retracted.

5A-92. REMOVAL AND INSTALLATION. Figure 5A-16 shows details of the nose wheel steering system and may be used as a guide for parts replacement.

5A-93. RIGGING. Since the nose wheel steering is connected to the rudder control system, refer to Section 10 for rigging of the system.

5A-94. NOSE GEAR DOOR SYSTEM.

5A-95. The nose gear doors are shown in figure 5A-17. The nose gear forward doors open for nose gear retraction or extension and close again when the cycle is completed. These doors are held in the closed position by an internal lock in the actuator until hydraulic pressure of approximately 125 psi is applied to the anchor port of the actuator. Actuating of the nose gear forward doors is by a double-acting hydraulic cylinder. The nose gear aft doors are mechanically linked to the nose gear trunnion. These doors open as the gear extends and close as it is retracted.

5A-96. REMOVAL AND INSTALLATION OF NOSE WHEEL DOORS.

- a. Open landing gear doors.
- b. Remove engine cowl.
- c. Disconnect push-pull rod from bracket on door by removing nut, bolt and washers.
- d. Remove nuts and bolts attaching each hinge pivot. Work from upper side of cowl opening to remove bolts. Retain bushings in hinge pivot.
- e. To replace the nose wheel doors, reverse the preceding steps.
- f. Rig as outlined in paragraph 5A-100.

5A-97. REMOVAL AND INSTALLATION OF NOSE WHEEL DOOR MECHANISM. (See figure 5A-17.)

- a. Open landing gear doors.
- b. Disconnect actuator at torque tube by removing nut, washer, and bolt.
- c. Disconnect and cap or plug hydraulic hose at actuator.
- d. Remove nut, washer, and bolt attaching actuator to its mounting bracket in nose wheel well.
- e. Disconnect door push-pull rods at door bracket.
- f. Remove torque tube by removing nuts, washer and bolts securing it to its mounting brackets.
- g. For installation, reverse the preceding steps.
- h. Rig as outlined in paragraph 5A-100.

5A-98. DISASSEMBLY AND REPAIR OF NOSE WHEEL DOOR ACTUATOR. Refer to Appendix A for disassembly and repair of nose wheel door actuator.

5A-99. REMOVAL AND INSTALLATION OF NOSE GEAR STRUT DOORS.

- a. Disconnect door rod assemblies from door.
- b. Remove screw, washer, and nut securing door hinge pin and pull hinge pin from door hinge allowing door to be removed.
- c. To remove door rod assemblies, remove nut securing tie-rod to nose gear trunnion. Do not change length of rod assembly unless necessary; changing rod assembly length will make readjustment necessary on installation.
- d. Install strut doors and linkage by reversing the preceding steps and rig doors in accordance with paragraph 5A-100.

5A-100. RIGGING. Refer to paragraphs 5A-112 through 5A-118 for nose gear door system rigging and adjustments.





Figure 5A-16. Nose Wheel Steering System



- | | | |
|-------------------------|----------------------------|----------------------|
| 1. Bolt | 7. Push-Pull Rod Assembly | 13. Screw |
| 2. Bushing | 8. Center Hinge | 14. Hinge Pin |
| 3. Front Hinge | 9. Rear Hinge | 15. Strut Door Hinge |
| 4. Washer | 10. Tee Assembly | 16. Guide Clip |
| 5. Nut | 11. Eyebolt | 17. Wheel Doors |
| 6. Torque Tube Assembly | 12. Push-Pull Rod Assembly | 18. Strut Doors |

Figure 5A-17. Nose Landing Gear Doors

5A-101. BRAKE SYSTEM.

5A-102. The hydraulic brake system consists of two master cylinders, brake lines connecting each master cylinder to its wheel brake cylinder, and the single-disc type brake assembly, located at each main landing gear wheel. Refer to paragraph 5-42 through 5-58 for maintenance of the brake system.

5A-103. RIGGING OF MAIN LANDING GEAR.

NOTE

All of the following rigging adjustments should be accomplished with the airplane on jacks. To rig the main gear downlock pawls, it is necessary that the airplane be level. Since the engine-driven pump cannot be used to supply pressure for these rigging procedures, a Hydro Test or other ground hydraulic power source should be used.

5A-104. RIGGING OF ADJUSTING SUPPORT. (See figure 5A-10.) The adjusting support is bolted to

the outboard forging and forms the down stop for the main gear.

NOTE

The spring strut must be installed and secured before rigging the adjusting support. Also, check that gear is level laterally over the saddle, using C-bar (Special Tool No. SE-587-1) and the spirit level, with 1500 psi hydraulic pressure applied to gear down port of the main gear actuator. Shim as required between support pin bolt and structure to obtain this level condition. Refer to the following step "a" for the varying thickness of the shims.

- a. Check for contact between flat surface of strut and lower surface of adjusting support. Minor gaps may exist as long as 50% of strut is in contact with support. Shim as required between outboard forging and adjusting support to obtain correct contact. The following shims are available from the Cessna Service Parts Center.




Figure 5A-18. Main Gear Downlock Clearances

AFT

1241418-1.....	*
-2.....	.012"
-3.....	.020"
-4.....	.032"
-9.....	.006"

FWD

1241418-5.....	*
-6.....	.012"
-7.....	.020"
-8.....	.032"
-10.....	.006"

*Sheet of .025" laminated with ten .002" additional removable laminations.
b. Check that the aft edge of strut contacts ad-

justing support (.005 inch maximum clearance) as shown in figure 5A-10, when gear is down. To shift adjusting support fore and aft, first loosen bolts securing support (elongated holes are provided in the support), then adjust two jam nuts as required and retighten the mounting bolts. Torque aft mounting bolts to 310-340 pound-inches and torque forward mounting bolts to 170-200 pound-inches.

c. Check that the forward edge of the strut contacts wedge (.001 to .010 inch clearance) as shown in figure 5A-10, when gear is down. If adjustment is necessary, locate, drill, and countersink a new wedge, and install with one MS20427M rivet. The following wedges (measured at thickest part) are available from the Cessna Service Parts Center.

1241404-1.....	.175"
-2.....	.220"
-3.....	.200"




Figure 5A-19. Main Gear Uplock and Uplock Limit Switch Clearance

5A-105. RIGGING OF DOWNLOCK MECHANISM.

The inboard and outboard downlocks are hydraulically operated pawls containing adjustable downlock pins which wedge against the strut to lock the gear in the down position. Jack the airplane and rig as follows:

NOTE

Before rigging the downlock pawls, refer to paragraph 5A-44 to ascertain that the main landing gear strut is correctly installed.

- a. Check that clearance between the inboard downlock pawl and gear strut is $.003 + .004 - .000$ inches when 1500 psi hydraulic pressure is applied to the gear down port of the main gear actuator (to ensure that the gear is in the full down position). Inboard pawl clearance during the retraction cycle is shown in figure 5A-18. The pawl is adjusted up or down with relation to the gear strut by inserting or removing washers on the fork-bolt that attaches the pawl to the fuselage structure.
- b. Check that outboard downlock pin reaches the overcenter position shown in figure 5A-18 (.03 to .10 inch). Adjust upper stop bolt as required to obtain this position.
- c. Check over-all length of outboard downlock pin as shown in figure 5A-18 (snugly against strut to .003 inch maximum clearance), with hydraulic pressure on gear. Downlock pin assembly must be removed to change over-all length.
- d. With outboard downlock pin fully retracted, check that pin clears any part of strut at least .008 inches during manual retraction as shown in figure 5A-18.
- e. Check that inboard downlock pawls release the struts simultaneously.

5A-106. RIGGING OF UPLOCK MECHANISM.

(See figure 5A-19.) The main gear uplocks are located on the main wheel stowage bay forward bulkhead. The uplock pawls are spring-loaded to lock position and are hydraulically operated to the unlocked position. Jack airplane and rig uplock mechanism as follows:

- a. While retracting landing gear, check that landing gear strut edge contacts uplock bracket at the last .375 inch of strut up travel before strut contacts upstop bumper.

NOTE

If uplock bracket shows excessive damage from gear strut, loosen attaching bolts and re-position prior to adjusting uplock pawls and switches.

- b. With main gear strut firmly against the upstop bumper, the uplock pawl should extend easily into the locked position. Adjust upstop bumper so that locking face of uplock pawl clears strut by .002 to .005 inch.
- c. With uplock release actuator retracted, adjust push-pull rod so that uplock pawls release landing gear struts simultaneously.

NOTE

When gear strut is extending, the strut should clear the uplock pawls at least .09 inch at the closest point.

5A-107. RIGGING OF MAIN LANDING WHEEL AND STRUT DOORS. After jacking the airplane, main landing gear door adjustments are accomplished by adjusting push-pull rod ends and actuator rod ends as required to cause the doors to close snugly. Doors must not close so tight that internal locks in actuating cylinders are not reached. When installing new doors, some trimming and forming at edges may be necessary to achieve a good fit and permit actuators to lock. The doors must clear the gear during retraction and extension at least 1/2 inch.

5A-108. ADJUSTMENT OF SNUBBER VALVES. Refer to paragraph 5A-51 for adjustment of the main landing gear snubbers.

5A-109. RIGGING MAIN GEAR DOWN INDICATOR SWITCHES. Main landing gear down indicator switches are mounted on brackets attached to the strut and actuated by the inboard downlock pawl. Adjust switches as shown in figure 5A-18.

5A-110. RIGGING MAIN GEAR UP INDICATOR SWITCHES. Main landing gear up indicator switches are mounted on brackets attached to the uplock pawls. After jacking the airplane and retracting the landing gear, adjust the switches as shown in figure 5A-19.

5A-111. RIGGING THROTTLE-OPERATED GEAR WARNING SWITCH. Refer to Section 12 for rigging of the throttle-operated gear warning switch.

5A-112. RIGGING OF NOSE GEAR.

NOTE

The nose gear shock strut must be correctly inflated prior to rigging of the nose gear.

5A-113. RIGGING OF DOWNLOCK MECHANISM. (See figure 5A-20.) The nose gear downlock mechanism is basically a claw hook at the piston rod end of the nose gear actuator. The actuator contains an internal lock to hold the claw hook mechanism overcenter. Jack the airplane and rig the downlock mechanism as follows:



- a. Check that the hooks and crossbar are free from drag. Adjust rod end of actuator piston rod as required.

CAUTION

The piston rod is flattened near the threads to provide a wrench pad. Do not grip the rod with pliers, as tool marks will cut seal in the actuator.

5A-114. RIGGING OF UPLOCK MECHANISM. (See figure 5A-20.)

- a. Check uplock hook adjustment. With uplock



NOTE: Locking of internal lock is indicated by inability to lift and disengage external claw locks manually. Locks shall release only when hydraulic pressure is applied at anchor end port of actuator.

Figure 5A-20. Nose Gear Up and Downlock Clearances





Figure 5A-21. Rigging Nose Gear Limit Switches

fully retracted, the nose gear uplock bushing should clear the uplock hook .06 to .09 inch and strike the flat surface of up stop side of hook.

5A-115. RIGGING OF DOWN INDICATOR SWITCH. (See figure 5A-21.) The nose gear down indicator switch is operated by an arm on the downlock mechanism. After jacking the airplane, adjust the switch to actuate with .04 to .06 travel of the downlock hooks remaining.

5A-116. RIGGING OF UP INDICATOR SWITCH. (See figure 5A-21.) The nose gear up indicator switch is attached to the uplock hook in the top of the nose wheel well. After jacking the airplane, adjust the switch to actuate with .06 to .09 travel of the uplock hook remaining.

5A-117. RIGGING OF SAFETY SWITCH. The safety switch, which is electrically connected to the landing gear handle lockout solenoid, is operated by an actuator attached to the lower torque link. Adjust the switch to actuate when the strut is between .12 to .25 inch from full extended position.

5A-118. RIGGING OF NOSE GEAR DOORS. After jacking the airplane, nose landing gear door adjustments are accomplished by adjusting push-pull rod ends and actuator rod ends as required to cause the

doors to close snugly. Doors must not close so tight that internal lock in the actuating cylinder is not reached. When installing new doors, some trimming and forming at edges may be necessary to achieve a good fit and permit actuators to lock. The doors must clear the gear during retraction and extension at least 1/2 inch.

5A-119. RIGGING OF POWER PACK SWITCH AND LOCKOUT SOLENOID.

5A-120. RIGGING OF UP-DOWN SWITCH. The handle up-down switch is located on the Power Pack and is normally rigged during assembly of the Power Pack, outlined in Appendix A. With landing gear handle at centerline of barrier, adjust up-down switch so that switch clicks at an equal distance up and down from centerline of barrier as landing gear handle is moved up and down.

5A-121. RIGGING OF GEAR HANDLE LOCKOUT. The handle lockout solenoid contains a plunger which prevents the handle from being moved upward from the gear-down range. Adjust the small nut on the solenoid plunger so the plunger fully locks the handle, but clears the handle when actuated, even with slight side-pressure exerted manually on the handle.




Figure 5A-22. Hydro Test Unit

5A-122. HYDRO TEST OPERATION.

5A-123. GENERAL OPERATION.

- a. Always open bypass valve before starting Hydro Test motor. This procedure permits the motor to start under a no-load condition and, if practiced, will contribute to the service life of the Hydro Test unit.
- b. Operation of the Hydro Test with bypass and lockout valves closed simultaneously should not be continued for more than one minute.
- c. Avoid unnecessary, continuous operation of the Hydro Test under high pressure-low flow conditions. Such operation causes rapid heating of the fluid supply and will be indicated on the Hydro Test temperature gage. When pressure is no longer needed, open the bypass valve. This will relieve pressure and allow the fluid to recirculate freely.
- d. Normal position of the pressure jack will expose approximately 1-1/2 inches of the threaded area of the pressure jack. Rotating the pressure jack out any further is unnecessary and serves no useful purpose.
- e. Do not operate the Hydro Test with the pressure jack removed.
- f. All hoses should be capped or plugged and stowed on rack provided when they are not in use.
- g. Avoid contamination of the Hydro Test unit by checking condition of the fluid in the airplane before making connections.
- h. Before disconnecting the Hydro Test from the airplane make certain that the airplane reservoir is full of fluid. If the Hydro Test remains idle for any length of time while connected to the airplane, fluid may siphon from the airplane reservoir to the Hydro Test reservoir.

NOTE

The Hydro Test unit is a precision test instrument as well as a hydraulic power source. The retention of its accuracy and the length of its service life depend on good care and proper operation.

5A-124. FLOW REGULATION. The following procedure is used to adjust the Hydro Test flow to any value desired for a specific operation, with the Hydro Test connected to the airplane hydraulic system and the airplane on jacks.

- a. Open bypass valve and lockout valve.
- b. Start Hydro Test pump motor.
- c. Close bypass valve.
- d. Open flow valve, then slowly close it until indicator in flow gage sight glass aligns with mark indicating desired flow. To read flow indicator, match line on widest part of indicator with fixed line on external part of gage.

5A-125. CONNECTING HYDRO TEST.

- a. Remove engine cowling from right side of engine.
- b. Disconnect hydraulic pump suction (larger) hose from firewall fitting and connect Hydro Test suction (larger) hose to firewall fitting. Cap or plug disconnected pump hose.
- c. Disconnect hydraulic pump pressure (smaller) hose from fitting in filter at firewall and connect

Hydro Test pressure (smaller) hose to the fitting. Cap or plug disconnected hose.

- d. Connect Hydro Test vent hose to airplane reservoir vent line protruding below lower edge of firewall.

NOTE

Before making this connection, be certain the line is wiped clean and free of any dirt or foreign material which might have worked into the line. If the line is dirty internally, remove and flush with solvent, then dry with compressed air and reinstall.

- e. Connect Hydro Test electric cable to appropriate electrical power source.

5A-126. DISCONNECTING HYDRO TEST.

- a. Be sure landing gear is down and locked, and doors are closed.
- b. With bypass closed, and lockout valve open, operate Hydro Test until airplane reservoir is full, then open bypass valve and stop Hydro Test pump motor.
- c. Disconnect all Hydro Test hoses from airplane immediately, beginning with the suction hose. If the suction hose remains connected for any length of time after Hydro Test is shut down, fluid will transfer from airplane reservoir into Hydro Test reservoir.
- d. Connect all airplane hoses and install cowling.

5A-127. FILLING AIRPLANE RESERVOIR.

Normally, the airplane reservoir is filled by using a manually operated pressure brake bleeder and Hydro Fill unit (available from Cessna Service Parts Center). The Hydro Test is used to fill the reservoir before disconnecting it from the airplane hydraulic system, as outlined in paragraph 5A-126.

5A-128. BLEEDING TIME-DELAY VALVE. The time-delay valve in the Power Pack may be purged of air by operating the engine-driven pump, or the Hydro Test may be used.

- a. Make sure reservoir is full.
- b. Start engine and let run at 1000 rpm, or connect Hydro Test in accordance with paragraph 5A-125.
- c. Place landing gear handle in down position and hold for approximately one minute, while turning the master switch OFF until doors open, then ON until doors close.
- d. Repeat step "c" four times, waiting one minute between each repeat. This allows time-delay valve to refill.
- e. Check that time-delay valve operates properly by moving landing gear handle sharply to the down position and recording time as handle returns to neutral.

NOTE

The time delay between closing of the landing gear doors and releasing the landing gear handle to neutral should be between 3 and 9 seconds at room temperature. Colder temperatures will cause a longer delay.

f. Shut down engine, or disconnect Hydro Test in accordance with paragraph 5A-126.

5A-129. BLEEDING AIRPLANE HYDRAULIC SYSTEM. Refer to paragraph 5A-31.

5A-130. BLEEDING OF THE EMERGENCY HAND PUMP. Refer to paragraph 5A-32.

5A-131. LEAK-TESTING. When testing a system for leakage, the Power Pack must be bypassed. When checking an actuating cylinder for internal leakage, connect the Hydro Test to one port of the unit and leave other port open. Perform test as follows:

- a. Jack the airplane (see paragraph 2-4).
- b. Connect Hydro Test pressure hose to system or unit to be leak-tested, using suitable fittings.
- c. Set flow valve for minimum flow.
- d. Set lockout valve cracked open.
- e. Set bypass valve open.
- f. Set pressure jack out approximately 1-1/2 inches.
- g. Start Hydro Test pump motor.
- h. Slowly close bypass valve until pressure reaches 1950 psi (maximum obtainable with Hydro Test pump motor).
- i. Close lockout valve to trap fluid, then stop Hydro Test pump motor immediately.
- j. Screw pressure jack in, increasing pressure to 2200 psi, and hold 5 minutes. Check for leaks while system or unit is under pressure. The pressure jack has a pressure capability to the limit of the Hydro Test pressure gage.

CAUTION

When leak-testing any actuator, with pressure applied to one port of the cylinder, always have the opposite port open to atmospheric pressure. Otherwise, excessive pressure may be built up due to the differential area across the piston. (The rod side of the piston has less area than the head side. Thus, pressure applied to the head side of the piston may apply a far greater pressure to fluid on the rod side of the piston.)

The total of line assemblies, fittings, actuators, and any other part subjected to hydrostatic (dead end) pressure shall be deemed faulty due to overstressing if hydraulic pressure in that immediate sub-system is allowed to exceed 2275 psi for any period of time.

- k. After completion of test, open Hydro Test lockout valve to relieve pressure, then disconnect Hydro Test and reconnect hydraulic system lines.

- l. Remove airplane from jacks.

5A-132. CYCLING LANDING GEAR.

- a. Connect Hydro Test in accordance with paragraph 5A-125 and jack the airplane as outlined in paragraph 2-4.

- b. Observe color of hydraulic fluid through sight gage in airplane reservoir. If fluid appears dis-

colored, or any other reason exists to suspect fluid contamination, draw off a fluid sample as outlined in paragraph 5A-34.

NOTE

Fluid sampling is necessary only when good reason exists to suspect contamination. If examination of fluid reveals contamination, flush complete hydraulic system with clean hydraulic fluid and examine several seals and cylinder bores for damage.

- c. Set Hydro Test flow valve closed, lockout valve open, and bypass valve open.
 - d. Start Hydro Test pump motor.
 - e. Slowly close bypass valve completely.
 - f. Observe fluid flowing through Hydro Test sight gage. When all air bubbles have dissipated, operations may be continued.
 - g. Using landing gear control handle in airplane, operate gear as desired.

NOTE

Gear cycling time can be prolonged by slowly opening the Hydro Test bypass valve part way. This will bleed off part of the pump flow.

- h. After completion of cycling, open Hydro Test bypass valve and stop pump motor.
 - i. Disconnect Hydro Test in accordance with paragraph 5A-126.
 - j. Make sure landing gear is down and locked, and remove airplane from jacks.

5A-133. CHECKING TIME-DELAY VALVE.

NOTE

The time delay between closing of the landing gear doors and releasing of the landing gear handle to neutral should be between 3 to 9 seconds at room temperature. Colder temperatures will cause a longer delay.

- a. Connect Hydro Test in accordance with paragraph 5A-125.
 - b. Set Hydro Test at approximately 1500 psi, with a one gallon-per-minute flow rate.
 - c. With airplane master switch OFF to open the doors, move landing gear handle to down position and turn master switch to ON position. Note the time delay between closing of the doors and releasing of the handle to neutral. See the preceding "NOTE."
 - d. There is no adjustment of the time-delay valve. If it is defective, refer to Appendix A for disassembly and repair of the Power Pack.
 - e. Disconnect Hydro Test in accordance with paragraph 5A-126.

5A-134. CHECKING HANDLE-RELEASE TO NEUTRAL.

- a. Cycle the landing gear through two complete cycles in accordance with paragraph 5A-132, ending with the gear down and locked, and the doors closed.

- b. Set Hydro Test bypass valve full open.
- c. Place landing gear handle to full down.
- d. Very slowly close bypass valve until handle trips back to neutral. Read gage at point of handle trip. This pressure should be 750 to 1250 psi. Be sure to allow time for time-delay valve to open.

NOTE

One release valve serves to release the handle from both the gear down and the gear up positions. If the handle-return springs are adjusted correctly, the release valve should release the handle from both positions at the same pressure. The foregoing procedure checks the release pressure from the gear down position, and the following procedure checks the release pressure from the gear up position. This is performed only to assure satisfactory operation of other equipment relative to handle release operations.

- e. Set Hydro Test bypass valve full open.
- f. Place landing gear handle full up.
- g. Very slowly close bypass valve until handle trips back to neutral. Read gage at point of handle trip. This pressure should be 750 to 1250 psi. Be sure to allow time for time-delay valve to open.
- h. Refer to paragraph 5A-20 for handle-release adjustment.
- i. Make sure landing gear is down and locked and disconnect Hydro Test unit in accordance with paragraph 5A-126.
- j. Remove airplane from jacks.

5A-135. CHECKING PRIORITY VALVE.

- a. Cycle landing gear through two complete cycles in accordance with paragraph 5A-132.
- b. With landing gear down, turn master switch OFF to open gear doors. Leave the switch OFF to permit doors to remain open, thereby making it easier and faster to complete this check.
- c. Open Hydro Test bypass valve.
- d. Place landing gear handle full up. Very slowly close bypass valve, observing Hydro Test pressure gage and Hydro Test flow gage, until priority valve opens. Priority valve should open at a pressure of 750 to 800 psi.

NOTE

As the priority valve opens, the nose gear downlock starts to release. Read Hydro Test pressure gage at this point. The Hydro Test flow gage will also aid in positively establishing opening of the priority valve. As pressure slowly builds up in the door system, there is practically no flow of fluid and the flow indicator will be resting on the bottom of the sight glass. As the priority valve opens, the sudden increase in flow will cause the indicator to rise in the sight glass.

- e. Refer to paragraph 5A-19 for priority valve adjustment.

- f. Make sure landing gear is down and locked, and disconnect Hydro Test in accordance with paragraph 5A-126.

- g. Remove airplane from jacks.

5A-136. CHECKING PRIMARY (SYSTEM) RELIEF VALVE.

- a. Connect Hydro Test in accordance with paragraph 5A-125.
- b. Open Hydro Test bypass valve.
- c. Place landing gear handle full down.
- d. Slowly close bypass valve, observing pressure build-up and point at which pressure stabilizes on Hydro Test gage. Stabilization indicates relief valve setting. The relief valve pressure should be 1750 to 1800 psi, at a flow rate of approximately one gallon-per-minute on the Hydro Test.
- e. The Power Pack must be removed and partially disassembled to adjust the primary relief setting. Refer to Appendix A.
- f. Disconnect Hydro Test in accordance with paragraph 5A-126.

5A-137. CHECKING SECONDARY (HAND PUMP) RELIEF VALVE. PRIOR TO 1968 MODELS.

- a. Place landing gear handle full down. With master switch OFF, operate emergency hand pump to open landing gear doors.
- b. Disconnect door open line from nose gear door cylinder and connect Hydro Test pressure hose to door open line.
- c. Close lockout valve on Hydro Test.
- d. Operate emergency hand pump in airplane, observing Hydro Test pressure gage for pressure at which secondary relief valve opens. This pressure should be 1900 to 1950 psi.
- e. The Power Pack must be removed and partially disassembled to adjust secondary relief valve setting. Refer to Appendix A.
- f. Open lockout valve on Hydro Test to release the pressure, disconnect Hydro Test pressure hose from door open line, and reconnect door open line to nose gear door actuator.
- g. Replenish hydraulic reservoir fluid as required.

5A-138. CHECKING FOR SUCTION AIR LEAKAGE.

- a. Remove engine cowl as necessary for access.
- b. Disconnect hydraulic pump suction (larger) hose from pump and connect Hydro Test suction (larger) hose to the airplane suction hose, using a suitable fitting.
- c. Disconnect hydraulic pump pressure (smaller) hose from pump and connect Hydro Test pressure (smaller) hose to airplane pressure hose, using a suitable fitting.
- d. Connect Hydro Test vent hose to airplane reservoir vent line, protruding below lower edge of firewall.

NOTE

Before making this connection, be certain the line is wiped clean and is free of any dirt or foreign material which might have worked into the line. If the line is dirty internally, remove and flush with solvent, then dry with compressed air and reinstall.

e. Connect Hydro Test electrical cable to appropriate electrical power source.

f. Jack the airplane and cycle the landing gear through five complete cycles. No air should be visible in Hydro Test sight gage.

g. Air visible in sight glass indicates leakage in suction line, hose, or fittings. Replace defective parts.

NOTE

If replacement of parts stops any visible air in Hydro Test sight glass but air still enters hydraulic system, engine-driven pump may have a suction leak.

h. Make sure landing gear is down and locked, and remove airplane from jacks.

i. Disconnect Hydro Test in accordance with paragraph 5A-126.

5A-139. CHECKING LANDING GEAR CYCLE TIME. When the hydraulic system or aircraft pump is suspected of malfunction because gear cycle time is slow, it could be caused by low fluid in aircraft reservoir, causing system to be full of air. The following procedure will purge air from system and fill the reservoir.

a. Cycle the landing gear through two complete cycles in accordance with paragraph 5A-132.

b. With landing gear extended, place gear handle in full up position and record time required for gear to retract and doors to close. Time should not exceed 10.5 seconds (+5 seconds, -0 seconds), plus the time required for the time-delay valve to operate (see paragraph 5A-133.)

c. With landing gear retracted, place gear handle in full down position and record time required for gear to extend and doors to close. Time should not exceed 7.5 seconds (+8 seconds, -2 seconds), plus the time required for the time-delay valve to operate (see paragraph 5A-133).

NOTE

If time is within limit when operated by Hydro Test, but exceeds limit when operated by engine-driven pump, there is internal leakage in pump. Repair or replace pump. If time exceeds limit when operated either by Hydro Test or engine-driven pump, internal leakage is in hydraulic system. Check actuators for internal leakage. Refer to paragraph 5A-131. Repair or replace actuators as required. If actuators are not defective, Power Pack internal leakage is indicated. Repair or replace Power Pack. Refer to Appendix A for repair of hydraulic components.

5A-140. BENCH TESTING HYDRAULIC POWER PACK WITH HYDRO TEST.

5A-141. A new or newly overhauled hydraulic Power Pack may be tested, using the Hydro Test, prior to installing the unit in the airplane. When bench testing the hydraulic Power Pack it will be necessary to use a serviceable hydraulic actuator cylinder. A main landing gear rotary actuator cylinder may be used in place of a nose landing gear actuator. For control of the door valve solenoid it will be necessary to fabricate an electrical harness as shown in figure 5A-23. This harness, when connected to a 12-volt battery, will allow control of the electrical current to the door valve solenoid, permitting complete operation of the door hydraulic circuits.

5A-142. CONNECTING POWER PACK TO HYDRO TEST.

a. Connect Hydro Test to Power Pack as follows:

1. Connect Hydro Test suction hose to suction port on Power Pack.

2. Connect Hydro Test pressure hose to pressure port on Power Pack.

3. Connect Hydro Test vent hose to vent port at top of Power Pack reservoir.

b. Using hydraulic hose of adequate length, connect serviceable nose landing gear actuator cylinder or main landing gear rotary actuator cylinder to Power Pack, at gear or door system fittings.

NOTE

Check to be sure that door open and door close ports on the Power Pack are connected to the correct port of the actuator cylinder. Also that gear up and gear down ports of the Power Pack are connected to the correct ports of the actuator cylinder.

c. Install caps on all other open ports on Power Pack.

d. Connect electrical test harness to Power Pack electrical connector and to a 12-volt battery as shown in figure 5A-23.

5A-143. OPERATIONAL CHECK OF POWER PACK VALVES. Bench checking the priority valve, time-delay valve, and system relief valve with the Hydro Test may be performed in accordance with the foregoing paragraphs except that Power Pack is on the bench instead of in the airplane. When checking priority valve, read pressure just as the actuator starts to move.

NOTE

At completion of gear up or gear down cycle, return manual switch in test harness to neutral or power off position before placing the landing gear control handle in the opposite position.

HYDRAULIC SYSTEM SCHEMATICS

The 10 following fold-out pages contain color-coded schematic diagrams of the hydraulic system prior to the 1968 models. The 10 following coded pages contain the schematic diagrams of the hydraulic Power Pack with the removed secondary relief valve. Balance of the hydraulic system is the same as that shown in the color-coded fold-out pages.

Sheet 1 shows the system "at rest" with the landing gear up. Sheets 2 through 5 show various stages of the gear-down cycle, after which the system is again "at rest" with the landing gear down. Sheets 6 through 9 show various stages of the gear-up cycle, after which the system returns to the condition shown on sheet 1. Sheet 10 shows the landing gear being extended with the emergency hand pump without electrical power.

NOTE

The door vent valve shown in these schematics is not used in early 1966 model Power Packs. However, replacement Power Packs (new or remanufactured) have this valve installed. The valve relieves any pressure from thermal expansion in the door system, to keep the doors closed while the airplane is parked.





Figure 5A-24. (Sheet 1 of 10)






Figure 5A-24. (Sheet 2 of 10)




Figure 5A-24. Hydraulic System Schematic (Sheet 2 of 10)




Figure 5A-24. (Sheet 3 of 10)




Figure 5A-24. Hydraulic System Schematic (Sheet 3 of 10)





Figure 5A-24. (Sheet 4 of 10)



GEAR DOWN AND LOCKED, DOORS CLOSING

Figure 5A-24. Hydraulic System Schematic (Sheet 4 of 10)




Figure 5A-24. (Sheet 5 of 10)




Figure 5A-24. Hydraulic System Schematic (Sheet 5 of 10)




Figure 5A-24. (Sheet 6 of 10)




Figure 5A-24. Hydraulic System Schematic (Sheet 6 of 10)




Figure 5A-24. (Sheet 7 of 10)




Figure 5A-24. Hydraulic System Schematic (Sheet 7 of 10)





Figure 5A-24. (Sheet 8 of 10)



GEAR UP AND LOCKED, DOORS CLOSING

Figure 5A-24. Hydraulic System Schematic (Sheet 8 of 10)




Figure 5A-24. (Sheet 9 of 10)






Figure 5A-24. Hydraulic System Schematic (Sheet 9 of 10)



CODE

FLOW UNDER PRESSURE	RETURN FLOW
STATIC PRESSURE	RETURN-STATIC
SUPPLY	VENT

Figure 5A-24. (Sheet 10 of 10)



EMERGENCY CONDITION. ENGINE PUMP FAILURE, NO ELECTRICAL POWER.
DOORS OPENED, GEAR UNLOCKED AND BEING EXTENDED BY HAND PUMP PRESSURE

Figure 5A-24. Hydraulic System Schematic (Sheet 10 of 10)

SECTION 6

AILERON CONTROL SYSTEM

TABLE OF CONTENTS	Page		
AILERON CONTROL SYSTEM	6-1	Removal of Aileron Drive Pulley or Bellcrank	6-3
Control Column	6-1	Repair of Aileron Drive Pulley or Bellcrank	6-3
Control Cables	6-1	Installation of Aileron Drive Pulley or Bellcrank	6-3
Ailerons	6-1	Removal and Installation of Aileron Cables and Pulleys	6-3
Trouble Shooting	6-2	Removal of Aileron	6-3
Removal of Control Column - Except 210G and T210G and on	6-3	Repair of Aileron	6-10
Removal of Control Column - 210G and T210G and on	6-3	Installation of Aileron	6-10
Installation of Control Column	6-3	Rigging - Except Model 210 Series (1967 and on) and 1968 Model 206 Series	6-10
Repair of Control Column	6-3	Rigging - Model 210 Series (1967 and on) and 1968 Model 206 Series	6-10

6-1. AILERON CONTROL SYSTEM.

6-2. CONTROL COLUMN. Details of the control column used on all 200-Series airplanes are shown in figure 6-1. Rotation of the control wheel rotates four needle bearing rollers on the end of the control wheel tube which, in turn, rotate a square tube inside and extending from the control wheel tube. Attached to this square tube is a sprocket which operates the aileron system. The same arrangement is provided for both control wheels and synchronization is obtained by the interconnecting roller chains and sprockets. Model 210 Series aircraft (1967 and on) and 1968 Model 206 Series aircraft have a cable drum attached to the control tube and synchronization of the control wheels is provided by cables and adjustable turnbuckles. The forward end of the square tube is mounted in a bearing block on the firewall and does not move fore and aft, but rotates with the control wheel. The four needle bearing rollers on the end of the control wheel tube reduce friction as the control wheel is moved fore and aft for elevator

system operation. A sleeve weld assembly, containing bearings which permit the control wheel tube to rotate within it, is secured to the control wheel tube by a sleeve and retaining ring in such a manner that it moves fore and aft with the control wheel tube. This movement allows the push-pull tube attached to the weld assembly to operate an elevator arm assembly, to which one elevator cable is attached. A torque tube connects this arm assembly to the opposite one, to which the other elevator cable is attached. When dual controls are installed, the copilot's control wheel is linked to the aileron and elevator control systems in the same manner as the pilot's control wheel.

6-3. CONTROL CABLES. The aileron control cable routing and pulleys are shown in figure 6-2.

6-4. AILERONS. All 200-Series aircraft are equipped with Frise type ailerons which pivot on two hinges located on brackets extending from each wing. The aileron is shown in figure 6-3.

6-5. TROUBLE SHOOTING THE AILERON SYSTEM.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
LOST MOTION IN CONTROL WHEEL.		
Loose control cables.	Check cable tension.	Adjust cables to proper tension.
Broken pulley or bracket, cable off pulley, or worn rod end bearings.	Check visually.	Replace worn or broken parts, install cables correctly.
RESISTANCE TO CONTROL WHEEL MOVEMENT.		
Cables too tight.	Check cable tension.	Adjust cables to proper tension.
Pulleys binding or cable off.	Observe motion of the pulleys. Check cables visually.	Replace defective pulleys. Install cables correctly.
Drive pulley distorted or damaged.	Check visually.	Replace drive pulley.
Defective chain or sprocket assembly.	Check visually.	Replace.
Clevis bolts in system too tight.	Check connections where used.	Loosen, then tighten properly and safety.
CONTROL WHEEL NOT LEVEL WITH AILERONS NEUTRAL.		
Improper adjustment of cables.	Check rigging.	Readjust cable turnbuckles.
Improper adjustment of aileron push-pull rods.	Check rigging.	Adjust push-pull rods to obtain proper alignment.
DUAL CONTROL WHEELS NOT COORDINATED.		
Chain or cables improperly adjusted.		Adjust in accordance with rigging procedure.
INCORRECT AILERON TRAVEL.		
Push-pull rods not adjusted properly.	Check rigging.	Adjust in accordance with rigging procedure.
Incorrect adjustment of travel stop bolts.	Check rigging.	Adjust in accordance with rigging procedure.

SHOP NOTES:

6-6. REMOVAL OF CONTROL COLUMN - EXCEPT MODEL 210 SERIES (1967 and on) AND 1968 MODEL 206 SERIES (See figure 6-1, sheet 1).

- a. Remove screws attaching control wheel to control tube and remove the control wheel.
- b. Remove shock-mounted instrument panel in accordance with paragraph 16-5.
- c. Remove screws securing plate (24).
- d. Remove push-pull rod (47).
- e. Loosen turnbuckle barrel (63) and disengage chain from sprocket (6).
- f. Remove nut and washer from shaft protruding through bearing on forward side of firewall.
- g. Pull control wheel tube assembly aft to remove. Remove the copilot's control wheel tube in a similar manner.
- h. Remove four screws securing arms (55) to torque tube (60), and remove phenolic sleeve (48).

NOTE

The Model 210 and T210 Series (prior to 1967) are equipped with elevator bob weights that are connected to elevator arms (55). Refer to Section 8 for bob weight removal.

- i. Disconnect elevator cables from elevator arms.
- j. Remove torque tube (60) by telescoping tube into arm (55), then pivot arm on bearing (56) until tube clears opposite arm, and remove torque tube.
- k. Remove screws (49) and nuts (38), then remove arms (55).
- l. After removal, detail parts may be removed or replaced as necessary.

6-6A. REMOVAL OF CONTROL COLUMN - MODEL 210 SERIES (1967 and on) AND 1968 MODEL 206 SERIES (See figure 6-1, sheet 3.)

- a. Remove screws attaching control wheel to control wheel tube and remove the control wheel.
- b. Remove shock-mounted instrument panel in accordance with paragraph 16-5.
- c. Remove screws securing plate (25).
- d. Remove push-pull rod (29).
- e. Loosen turnbuckle (31) and remove cables from drums (3).
- f. Remove nut and washer from shaft protruding through bearing on forward side of firewall.
- g. Pull control wheel tube assembly aft to remove. Remove the copilot's control wheel tube in a similar manner.
- h. Remove four screws securing arms (7) to torque tube (10) and remove phenolic sleeve (9).
- i. Disconnect elevator cables from elevator arms.
- j. Remove torque tube (10) by telescoping tube into arm (7), then pivot arm on bearing until tube clears opposite arm, and remove torque tube.
- k. Remove screws and nuts securing arms (7), then remove arms.
- l. After removal, detail parts may be removed or replaced as necessary.

6-7. INSTALLATION OF CONTROL COLUMN may be accomplished by reversing the removal procedure. Be sure to resafety all parts that were safetied. Check elevator and aileron system for correct rigging. The nut securing the control column to the

firewall should be tightened snugly, then loosened the least amount required to eliminate binding, but not more than .020 inch maximum clearance. If a sprocket was removed, torque sprocket mounting bolt to 15 lb-inches upon installation.

6-8. REPAIR OF CONTROL COLUMN. Worn, damaged, or defective shaft, bearings, bushings, sprockets, roller chains, and other components should be replaced. Refer to the lubrication diagram in Section 2 for lubrication recommendations.

6-9. REMOVAL OF AILERON DRIVE PULLEY OR BELLCRANK.

- a. Remove cover on wing for access.
- b. Disconnect control cables. It may be necessary to disconnect cables after the component has been detached from the wing.
- c. Detach aileron push-pull rod from component.
- d. Remove bolts, washers, and nuts securing the component to the wing.
- e. Remove component through the access opening, using care that the bushing is not dropped. One or more brass washers may be used as shims between wing structure and drive pulley.

NOTE

Protect needle bearings from dust or dirt by covering open ends with tape.

6-10. REPAIR OF AILERON DRIVE PULLEY OR BELLCRANK. Repair of aileron drive pulleys or bellcranks consists of the replacement of defective parts. If needle bearings are dirty or need grease, clean thoroughly and lubricate as specified in Section 2.

6-11. INSTALLATION OF AILERON DRIVE PULLEY OR BELLCRANK.

- a. Attach the control cables to component before positioning it in the wing.
- b. Install brass washers as required to shim out excessive clearance between component and wing, then install pivot bolt.
- c. Connect aileron cables, aileron push-pull rod, and rig the aileron system.

6-12. REMOVAL AND INSTALLATION OF AILERON CABLES AND PULLEYS. Aileron cables may be removed after disconnecting both ends of the cables and removing cable guards and pulleys as necessary to work the cables free of the airplane. When installing a cable, be sure cable is in pulley groove and cable guards are properly installed. Rig the aileron system after installation.


NOTE

To ease rerouting of cables, a length of wire may be attached to the end of the cable before it is withdrawn from the airplane. Leave the wire in place, routed through the structure; then attach it to the cable being installed and use it to pull the cable into position.

6-13. REMOVAL OF AILERON. (See figure 6-3.) Removal is accomplished by disconnecting push-pull rod, then removing aileron hinge bolts.

NOTE


The Model 210 and T210 Series (Prior to 1967) are equipped with elevator bob weights that are connected to elevator arms (55). Refer to Section 8 for bob weight removal.



*USED ONLY ON AIRPLANES WITHOUT DUAL CONTROL WHEEL INSTALLATION.

Figure 6-1. Control Column (Sheet 1 of 3)

CONTROL WHEEL -
EARLY 1966 AND ON



NOTE

The microphone switch is installed in the control handle when aircraft is equipped with oxygen system. The control wheel may be removed using procedure outlined in paragraph 6-6 after separating quick-disconnect.

1. Control Handle
2. Microphone Switch
3. Quick-Disconnect
4. Bracket
5. Microphone Cable

Figure 6-1. Control Column (Sheet 2 of 3)

References for Figure 6-1

- | | | |
|---------------------------|----------------------------|-----------------------------|
| 1. Cotter Pin | 25. Spacer | 49. Screw |
| 2. Nut | 26. Collar | 50. Bolt |
| 3. Washer | 27. Wheel Adapter | 51. Screw |
| 4. Nut | 28. Rivet | 52. Screw |
| 5. Screw | 29. Rivet | 53. Nut |
| 6. Sprocket | 30. Control Wheel | 54. Cotter Pin |
| 7. Idler Shaft | 31. Screw | 55. Arm |
| 8. Roll Pin | 32. Screw | 56. Bearing (Self-Aligning) |
| 9. Support | 33. Screw | 57. Roller Chain |
| 10. Bearing Block | 34. Nut | 58. Bolt |
| 11. Bearing | 35. Bearing | 59. Washer |
| 12. Bracket | 36. Tapered Plug and Screw | 60. Elevator Torque Tube |
| 13. Panel Plate | 37. (Nylon) Control Glide | 61. Support |
| 14. Grommet | 38. Nut | 62. Turnbuckle Terminal |
| 15. Screw | 39. Washer | 63. Turnbuckle Barrel |
| 16. (Roller) Bearing | 40. Screw | 64. Turnbuckle Terminal |
| 17. Retainer | 41. Nut | 65. Bolt |
| 18. Screw | 42. Tube-Inner | 66. Roller Chain |
| 19. Tube and Bearing Assy | 43. Rod End | 67. Sprocket |
| 20. Sleeve Assembly | 44. Guide Assembly | 68. Bearing |
| 21. Bearing | 45. Rub Strip | 69. Bolt |
| 22. Bearing Race | 46. Washer | 70. Spacer |
| 23. Snap Ring | 47. Push-Pull Rod | 71. Chain |
| 24. Support Plate | 48. Phenolic Sleeve | 72. Chain Guard |

MODEL 210 AND T210 - 1967 AND ON

MODEL 206 SERIES - 1968




Figure 6-1. Aileron Control System (Sheet 3 of 3)




Figure 6-2. Aileron Control System (Sheet 1 of 2)

MODEL 210 AND T210 - 1967 AND ON




Figure 6-2. Aileron Control System (Sheet 2 of 2)




Figure 6-3. Aileron Installation

6-14. REPAIR OF AILERON. Repair may be accomplished in accordance with instructions contained in Section 18. After an aileron has been repaired, check static balance and rebalance if necessary. Before installation, check balance weights for security.

6-15. INSTALLATION OF AILERON. After aileron hinge bolts have been installed, connect push-pull rod. If push-pull rod adjustment was not disturbed, it should not be necessary to rig the system. Check aileron travel and alignment, and rerig if necessary.

6-16. RIGGING OF AILERON CONTROL SYSTEM - EXCEPT MODEL 210 SERIES (1967 and on) AND 1968 MODEL 206 SERIES. (SEE figure 6-1, sheet 1.)

a. Check that upper left chain (57) is engaged with left aileron sprocket (6) in accordance with figure 6-4. With pilot's control wheel in neutral, adjust turnbuckles (63) so that both control wheels are synchronized in neutral.

NOTE

Adjust turnbuckles so that tension is only enough to remove slack without binding.

b. Engage control lock or tape a bar across both control wheels to hold them in neutral.
c. Set the aileron push-pull rods at 8.57" between centerlines of rod-end bolt holes, and install. Adjust the turnbuckles at the drive pulleys to obtain correct cable tension on aileron carry-thru cable, while maintaining the ailerons in neutral with reference to the trailing edge of the wing flaps, while flaps are up.
d. Remove control lock or bar taped across control wheels, and check aileron travel.

NOTE

An inclinometer for measuring control surface travel is available from the Cessna Service Parts Center.

e. Adjust stop bolts at both drive pulleys to obtain correct aileron travel.

f. Be sure all turnbuckles are safetied, all cables and cable guards are properly installed, and all jam nuts are tightened, then replace all parts removed for access.

WARNING

Be sure ailerons move in the correct direction when operated by the control wheel.

6-16A. RIGGING OF AILERON CONTROL SYSTEM - MODEL 210 SERIES (1967 and on) AND 1968 MODEL 206 SERIES. (See figures 6-1 and 6-2.)

a. Relieve all tension on aileron control system by loosening turnbuckles.
b. Disconnect aileron push-pull tubes.
c. Adjust turnbuckle on lower interconnect cable, and pins and swaged balls on upper interconnect cable to remove slack from the interconnect cables and position control wheels level (synchronized).

NOTE

On early 1967 Model 210 serials, the upper interconnect cable did not have adjustable cable ends and the pins tighten against the cable. Torque the pins to 30 to 35 pound-inches torque. The swaged balls may not seat, but the total clearance must not exceed .25 inches. The pins are replaced with adjustable cable ends for leveling the control wheels on later serial aircraft.




Figure 6-4. Neutral Position for Rigging

- d. Block control wheels in neutral.
- e. Adjust direct and carry-thru cable turnbuckles to position bellcranks approximately in neutral while maintaining proper cable tension.
- f. Streamline aileron with reference to flap (flaps full UP and disregarding aileron trim tabs), then adjust push-pull tube to fit and install.
- g. With aileron streamlined, mount inclinometer on trailing edge of aileron and set pointer to 0°.
- h. Unblock control wheels, then adjust travel stops to obtain correct aileron travel.
- i. Be sure all turnbuckles are safetied, all cables and cable guards are properly installed, and all jam


nuts are tightened, then replace all parts removed for access.

WARNING

Be sure ailerons move in the correct direction when operated by the control wheel.

6-17. ADJUSTMENT OF AILERON TRIM TABS. (1967 MODELS AND ON) (Refer to figure 6-3)

- a. Loosen screws on lower surface of trim tab (11) and adjust tab as required for wing heaviness.



AVAILABLE FROM CESSNA SERVICE PARTS CENTER
(TOOL NO. SE-716)

Figure 6-5. Inclinometer for Measuring Control Surface Travels

SECTION 7

FLAP CONTROL SYSTEMS

TABLE OF CONTENTS

	Page
FLAP CONTROL SYSTEMS	7-1
Operational Checkout	7-1
Removal, Installation and Adjustment of Flap Position Transmitter - Except Model 210 Series (1967 and on) and 1968 Model 206 Series	7-1
Removal, Installation, and Adjustment of Flap Position Transmitter - 210G and T210G	7-1
Trouble Shooting	7-2
Removal, Repair, and Installation of Motor and Transmission Assembly - Except 210G and T210G and on	7-3
Removal, Repair, and Installation of Motor and Transmission Assembly - 210G and T210G and on	7-3
Removal, Repair, and Installation of Drive Pulleys - Except 210G and T210G and on	7-3
Removal, Repair, and Installation of Drive Pulleys - 210G and T210G and on	7-3
Removal, Repair, and Installation of Outboard Bellcranks	7-3
Replacement of Flap Cables and Pulleys.	7-12
Removal, Repair, and Installation of Flaps	7-12
Rigging - Except Model 210 Series (1967 and on) and 1968 Model 206 Series	7-12
Rigging - 1967 Model 210 Series	7-13
Rigging - 1968 Model 210 Series	7-15
Rigging - 1968 Model 206 Series	7-15
Flap Motor Brake Adjustment	7-16

7-1. FLAP CONTROL SYSTEMS.

7-2. Electrically operated wing flaps are used on all 200-Series aircraft. Power from the motor and transmission assembly is transmitted to the flaps by a system of cables, and interconnect tubes. The systems are shown in figure 7-1.

CAUTION

A flap interrupt switch is mounted above the baggage door on the 210G and T210G and on to prevent flap operation when the baggage door is open. Likewise all aircraft with cargo doors have a similar switch on the front cargo door frame. If the aircraft is to be operated with the cargo doors removed, a spoiler kit must be installed. The kit includes a switch depressor to retain use of the flaps.

7-3. OPERATIONAL CHECKOUT OF FLAP CONTROL SYSTEM.

- Operate flaps through full range of travel, observing for uneven or jumpy motion, binding and lost motion in system. Make sure flaps are moving together through full range of travel.
- Deliberately overrun motor at each end of stroke to make sure transmission is free wheeling.
- Check to see that flaps are not sluggish in operation. In flight at 100 mph, indicated airspeed, the flaps should take approximately 8.7 seconds to extend and 7.6 seconds to retract. On the ground with engine running, the flaps take approximately 6.5 seconds to extend or retract.

- Raise flaps and check to see that they are completely up. Check flap position indicator to see that it reads 0°. Mount an inclinometer on one flap and set to 0°.

NOTE

An inclinometer for measuring control surface travel is available from the Cessna Service Parts Center. (See figure 6-5.)

- Lower flaps to extreme down position and check flap down angle with inclinometer.
- Open the flap drive pulley and bellcrank access openings and attempt to rock pulley or bellcrank to disclose internal bearing play.
- Examine rollers and tracks for defective parts.

7-4. REMOVAL, INSTALLATION AND ADJUSTMENT OF FLAP POSITION TRANSMITTER - EXCEPT MODEL 210 SERIES (1967 and on) AND 1968 MODEL 206 SERIES (See figure 7-1).

- Remove access covers from bottom of right wing below right drive pulley (6).
- Remove two bolts (10) which secure flap position transmitter (11).
- Remove cotter pin (13) and pin (14) which secure wire rod (12) to arm (15).
- Disconnect two wires at the quick-disconnects and remove the transmitter from the wing.
- Installation of flap position transmitter may be accomplished by reversing the preceding steps, after which it should be adjusted as described in paragraph 7-11. Reinstall all parts removed for access.

7-4A. REMOVAL, INSTALLATION, AND ADJUSTMENT OF FLAP POSITION TRANSMITTER - 210G AND T210G. (See figure 7-1, sheet 3.)

a. Remove access cover from bottom of left wing below flap motor (4).

b. Remove bolts securing transmitter (13).

c. Remove cotter pin securing transmitter arm to actuator (11).

d. Disconnect electrical wires, then remove transmitter from wing.

e. Installation of flap transmitter may be accomplished by reversing the preceding steps, after which it should be adjusted as described in paragraph 7-12. Reinstall all parts removed for access.

7-5. TROUBLE SHOOTING THE FLAP CONTROL SYSTEM.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
BOTH FLAPS FAIL TO MOVE.		
Popped circuit breaker.	Check circuit breaker.	Reset circuit breaker.
Defective switch.	Place jumper across switch.	Replace switch.
Defective motor.	Remove and bench test motor.	Replace motor.
Broken or disconnected wires.	Run continuity check of wiring.	Connect or repair wiring.
Defective or disconnected transmission.	Check to see transmission is connected to flap system. If connected, remove for bench test.	Connect or replace transmission.
Defective flap interrupt switch.	Check continuity.	Replace switch.
LEFT FLAP FAILS TO MOVE.		
Disconnected or broken cable.	Check cable tensions.	Connect or replace cable.
Disconnected push-pull rod.	Check push-pull rod attachment.	Attach push-pull rod.
BINDING IN SYSTEM AS FLAPS ARE RAISED AND LOWERED.		
Cables not riding on pulleys.	Open access covers and observe pulleys.	Route cables correctly over pulleys.
Broken or binding pulleys.	Check pulleys for free rotation or breaks.	Replace defective pulleys.
Frayed cable.	Check condition of cables.	Replace defective cable.
Bind in drive pulleys.	Check drive pulleys in motion.	Replace drive pulley.
Flaps binding on tracks.	Observe flap tracks and rollers.	Replace defective parts.
INCORRECT FLAP TRAVEL.		
Incorrect rigging.		Rig flaps correctly.

7-6. REMOVAL, REPAIR, AND INSTALLATION OF MOTOR AND TRANSMISSION ASSEMBLY - EXCEPT 210G AND T210G AND ON. (See figure 7-1, sheet 1.)

- a. Transmission (4), motor (1), tube (5), and hinge (3) are removed as one assembly if standard fuel tanks are installed. With long range tanks installed, it is necessary to detach the assembly from hinge (3) before removing motor and transmission from wing and to attach them to the hinge after positioning them in wing.
- b. Remove access covers from bottom of right wing under drive pulley and motor assembly.
- c. Remove bolt securing tube (5) to drive pulley (6).
- d. Remove bolt securing hinge (3) to the wing, or, if long range fuel tanks are installed, remove bolt securing transmission to the hinge.
- e. Disconnect electrical wires at quick-disconnects and remove screw securing ground wire. Remove assembly from wing.
- f. Repair of the transmission and motor assembly consists of replacement of the motor (1), transmission (4) or tube (5). Bearings in hinge (3) may be replaced.
- g. Installation may be accomplished by reversing the preceding steps and rigging the flap control system.

7-6A. REMOVAL, REPAIR, AND INSTALLATION OF MOTOR AND TRANSMISSION ASSEMBLY - 210G AND T210G AND ON. (See figure 7-1, sheet 3.)

- a. Transmission and motor (4), actuator (11) and lower support (14) are removed as a unit.
- b. Remove access cover beneath transmission and motor (4) from the left wing.
- c. Remove access covers beneath drive pulleys (15) on each wing, then relieve cable tension at drive pulleys.
- d. Disconnect cables from actuator (11).
- e. Disconnect lower support (14) at forward end. Disconnect aft end of lower support and transmission and motor, then remove assembly from wing.
- f. Repair consists of replacement of motor, transmission or coupling.
- g. Installation may be accomplished by reversing the preceding steps, then rigging the flap control system.

7-7. REMOVAL, REPAIR, AND INSTALLATION OF DRIVE PULLEYS - EXCEPT 210G AND T210G AND ON. (See figure 7-1, sheet 1.)

NOTE

The right drive pulley (6) must be removed to detach flap position transmitter arm (15) from the drive pulley assembly.

- a. Remove access covers under right drive pulley.
- b. Disconnect the inboard push-pull rod from drive pulley (6), and the outboard push-pull rod from the outboard bellcrank, then lower the flap gently.
- c. Remove bolt securing tube (5) to drive pulley (6).
- d. Remove pin (14) to disconnect flap position transmitter rod (12) from arm (15).
- e. Loosen turnbuckles (18 and 19) and detach cables (8 and 9) from drive pulley by removing bolts and pins.
- f. Remove bolt securing drive pulley (6) to wing and

remove drive pulley. Remove bolt attaching synchronizing push-pull tube (2) to the drive pulley.

g. To remove a left drive pulley, use this same procedure, omitting steps "c" and "d," for the left side.

h. Repair of drive pulleys is limited to replacement of needle bearings.

i. Installation may be accomplished by reversing the preceding steps and rigging per paragraph 7-11. Cables may be attached to drive pulleys before installing them in the wings.

NOTE

Transmitter arm (15) must be attached to right drive pulley (6) before installing the drive pulley.

7-7A. REMOVAL, REPAIR, AND INSTALLATION OF DRIVE PULLEYS - 210G AND T210G AND ON. (See figure 7-1, sheet 3.)

- a. Remove access cover under drive pulleys, then relieve the cable tension on system.
- b. Disconnect cables from drive pulleys and lower flaps gently.
- c. Remove bolt securing push-pull rod (7) to drive pulley.
- d. Remove bolt securing synchronizing tube (8) to drive pulley.
- e. Remove bolt securing drive pulley to wing, then remove drive pulley using care bushing is not dropped.

NOTE

Protect needle bearings by covering open ends with tape. One or more brass washers may be used as shims under drive pulleys and bellcranks.

f. Repair of drive pulleys is limited to replacement of needle bearings.

g. Installation may be accomplished by reversing the preceding steps and rigging the flap system.

7-8. REMOVAL, REPAIR, AND INSTALLATION OF OUTBOARD BELLCRANKS. (See figure 7-1.)


- a. Remove access covers under outboard bellcranks.
- b. Remove bolt securing outboard push-pull rod to bellcrank. Also remove bolt attaching inboard push-pull rod to drive pulley. Lower flap gently.
- c. Remove bellcrank pivot bolt, then position bellcrank as necessary to expose synchronizing tube at attach point.
- d. Remove bolt attaching synchronizing push-pull tube to bellcrank, then remove bellcrank through access hole.

NOTE

To remove synchronizing push-pull tube, disconnect it at both ends and position it through lightening holes until it can be removed through the access hole.

e. Repair of bellcranks is limited to replacement of needle bearings.

f. Installation may be accomplished by reversing the preceding steps and then rigging system.



CABLE TENSION:
 70±10 LBS (AT THE
 AVERAGE TEMPERATURE
 FOR THE AREA).

ALL MODELS EXCEPT 210G AND T210G AND ON
AND AS SHOWN ON SHEET 2

- | | | |
|---------------------------------|-------------------------------|-----------------------------|
| 1. Flap Motor | 8. Direct Cable | 16. Set Screw |
| 2. Synchronizing Push-Pull Tube | 9. Retract Cable | 17. Nut and Ball Assembly |
| 3. Flap Motor Hinge | 10. Bolt | 18. Turnbuckle |
| 4. Transmission | 11. Flap Position Transmitter | 19. Turnbuckle |
| 5. Flap Motor Actuating Tube | 12. Wire Rod | 20. Flap Switch |
| 6. Drive Pulley Assembly | 13. Cotter Pin | 21. Flap Position Indicator |
| 7. Push-Pull Rod | 14. Pin | 22. Bellcrank |
| | 15. Flap Transmitter Arm | |

Figure 7-1. Flap Control System (Sheet 1 of 5)




Figure 7-1. Flap Control System (Sheet 2 of 5)




Figure 7-1. Flap Control System (Sheet 3 of 5)




Figure 7-1. Flap Control System (Sheet 4 of 5)

NOTE

Drive pulleys and outboard bellcranks are identical to those shown on Sheet 3.

SEE SHEET 4

CABLE TENSION:

50±10 LBS (AT THE AVERAGE TEMPERATURE FOR THE AREA).


**MODELS 210 AND T210-
MID-1968 AND ON**

NOTE

Apply Grade 'C' Loctite to Setscrew (11) upon installation.

- | | |
|----------------------|----------------------------|
| 1. Synchronizer Tube | 9. Up-Limit Switch |
| 2. Follow-Up Control | 10. Nylon Grommet |
| 3. Pulley Bracket | 11. Set Screw |
| 4. Guard | 12. Striker Plate |
| 5. Support | 13. Down-Limit Switch |
| 6. Direct Cable | 14. Motor and Transmission |
| 7. Noise Filter | 15. Lower Support |
| 8. Bellcrank | 16. Retract Cable |

Figure 7-1. Flap Control System (Sheet 5 of 5)



NOTE


Bushings (10), rollers (11), and spacers (15) are first positioned through slots in flap tracks, then are secured to the flap roller supports with attaching bolts, washers, and nuts. Nylon plug buttons (16) prevent wing flap from chafing wing trailing edge.

1. Wing Flap
2. Wing Structure
3. Outboard Flap Track
4. Outboard Actuating Bracket
5. Access Cover

6. Center Flap Track
7. Inboard Actuating Bracket
8. Inboard Flap Track
9. Bolt
10. Bushing
11. Roller

12. Washer
13. Nut
14. Stiffener
15. Spacer
16. Nylon Plug Buttons

Figure 7-2. Flap Installation (Sheet 1 of 2)



- 1. Access Cover
- 2. Flap Assembly
- 3. Actuating Bracket

- 4. Nylon Rub Buttons
- 5. Roller
- 6. Bushing

- 7. Spacer
- 8. Flap Track
- 9. Wing Structure

Figure 7-2. Flap Installation (Sheet 2 of 2)




Figure 7-3. Flap System Schematics (Sheet 1 of 2)




Figure 7-3. Flap System Schematics (Sheet 2 of 2)

7-9. REPLACEMENT OF FLAP CABLES AND PULLEYS may be accomplished while using figure 7-1 as a guide. Refer to applicable rigging paragraph for proper cable attachment.

NOTE

To ease rerouting of cables, a length of wire may be attached to the end of the cable before it is withdrawn from the aircraft. Leave the wire in place, routed through the structure; then attach it to the new cable and use it to pull cable into place.

7-10. REMOVAL, REPAIR, AND INSTALLATION OF FLAPS. Figure 7-2 shows details of the flap installation and may be used as a guide during removal and installation of the flaps. If flap push-pull rod adjustment is not disturbed, it should not be necessary to rerig the flap system. Check flap travel and rerig if necessary. Repair of a damaged flap may be accomplished in accordance with instructions contained in Section 18.

7-11. RIGGING FLAP CONTROL SYSTEM - EXCEPT MODEL 210 SERIES (1967 and on) AND 1968 MODEL 206 SERIES (See figure 7-1, sheet 1.)

NOTE

Before using this procedure, disconnect flap cables at turnbuckles above cabin headliner, and disconnect flap push-pull rods at drive pulleys and bellcranks in both wings.

a. If cables are not connected to drive pulleys, it is necessary to disconnect parts attached to each drive pulley so it may be rotated beyond its normal range of travel to permit cable attachment. If drive pulleys are not installed, attach cables before installing the drive pulleys in the wings.

b. The 3/32" retract cable connects to the forward side of the right hand drive pulley and to the aft side of the left hand drive pulley.

c. The 1/8" direct cable connects to the aft side of the right hand drive pulley and to the forward side of the left hand drive pulley.

d. Adjust synchronizing push-pull tube in right wing to 48.69" between centers of rod end holes, tighten jam nuts, and install. If outboard bellcrank is not installed, the tube and bellcrank must be positioned in the wing and the tube attached to the bellcrank before the bellcrank is installed.

e. Using care not to cause damage, run flap motor to fully retract actuating tube (5) on motor (full up position). Loosen set screw (16) and rotate nut and ball assembly (17) in or out as required to position right flap drive pulley so that centerline of bolt hole for flap inboard push-pull rod attachment is 4.20 inches aft of the fuel well bulkhead. Tighten set screw (16).

NOTE

Apply Loctite Sealant Grade C (American Sealant Co., Hartford 11, Conn.) to threads of set screw (16) after final adjustments have been made.

f. Manually holding right flap full up, adjust right inboard push-pull rod to align with attaching holes, and install the push-pull rod. Tighten push-pull rod end locknut.

g. Repeat step "f" for the right outboard push-pull rod.

NOTE

The right wing flap and motor must be correctly rigged before the flap cables and left wing flap can be rigged.

h. Adjust synchronizing push-pull tube in the left wing to 48.69 inches between centers of rod end holes, tighten lock nut, and install tube. If outboard bellcrank is not installed, the tube and bellcrank must be positioned in the wing and the tube attached to the bellcrank before the bellcrank is installed.

i. Connect flap cables at turnbuckles above cabin headliner. Adjust turnbuckles to position left wing flap drive pulley so the centerline of the bolt hole for flap inboard push-pull rod attachment is 4.20 inches aft of the fuel well bulkhead, maintaining 70± 10 pounds cable tension.

NOTE

When tightening cable turnbuckles, be sure the cables are in the pulley grooves and cable ends are correctly positioned at the drive pulleys. Rig cable tension to the average temperature for the area.

j. Manually holding left wing flap up, adjust left inboard push-pull rod to align with attaching holes and install the push-pull rod. Tighten push-pull rod end lock nut.

k. Repeat step "j" for the left outboard push-pull rod.

l. Check cable tension at intermediate flap positions to see that cable tension is within limits. Retract cable tension may increase to 90 pounds when flaps are fully retracted. Check that drive pulleys are in the positions specified in steps "e" and "i."

Check that all locknuts are tight and all turnbuckles are safetied.

NOTE

Since flap rollers may not bottom in flap tracks with flaps fully extended, some free play may be noticed in this position.

m. With flaps up, mount an inclinometer on the right wing flap and set to 0°. Operate flaps to full down position and check flap down angle. See Section 1 for wing flap travel. Repeat check on left flap.

n. Connect wing flap position transmitter rod (12) to arm (15) on right wing drive pulley (6).

o. Raise wing flaps to full up position and adjust flap position transmitter to make position indicator read 0°. Slotted holes in the transmitter bracket are provided for adjustment. If necessary, transmitter rod may be formed slightly for additional adjustment.

p. Perform an operational checkout of the wing flap control system, check all locknuts for tightness, check that all turnbuckles are safetied, and reinstall all parts removed for access.

7-12. RIGGING FLAP CONTROL SYSTEM - 1967 MODEL 210 SERIES. (See figure 7-1, sheet 3.)

a. Run system to full down position.

b. Disconnect push-pull rods at flaps.

c. If cables are being replaced, attach 1/8" direct cable to forward side of each drive pulley and the 3/32" retract cables to the aft side of the drive pulleys. If drive pulleys are not installed, it may be easier to attach the cables before installing the drive pulleys.

d. Adjust the synchronizing push-pull tubes to 41.94 inches between rod end holes, tighten jam nuts then install.

e. Check that cables are in pulley grooves, then adjust cable tension as specified in applicable figure.

f. Manually hold flap full up, then mount an inclinometer on flap and set to 0°.

NOTE

An inclinometer for measuring control surface travel is available from the Cessna Service Parts Center. (See figure 6-5.)

g. Lower flap to down angle degree specified in Section 1 and adjust push-pull rods to fit, then connect rods to flap.

h. Repeat steps "f" and "g" to connect opposite flap.

i. Carefully run flap system to full up position, periodically checking cable tension to avoid damage.

j. Readjust push-pull rods if necessary to ensure that flaps are snug in full up position then check that down angle and tension remain within tolerance.

NOTE


Since flap rollers may not bottom in flap tracks at full down position, some free play may be present.

NOTE

Apply LOCTITE sealant, grade C, to threads of set screw (4) at final installation of set screw.

NOTE

Adjust brake assembly, with solenoid actuated, so minimum clearance between brake lining and any part of the coupling is .001" and maximum is .010". Do not bend spring (9).



NOTE

Alignment of flap motor shaft and transmission shaft is important. After reassembly, brake drum and coupling assembly must turn freely with brake released. It is permissible to enlarge the holes illustrated to a maximum of .250" to obtain proper alignment.

During the 1966 model-year an improved flap motor replaced the existing motor, eliminating the need for the external brake. Alignment procedure still applies to those aircraft equipped with the external brake.

1. Motor
2. Motor Shaft
3. Brake Drum
4. Set Screw

5. Coupling
6. Hinge
7. Transmission
8. Transmission Shaft

9. Spring Assembly
10. Brake Lining
11. Solenoid
12. Bracket

Figure 7-4. Flap Motor Brake

k. Connect wing flap position transmitter rod to actuator (11).

l. Raise wing flaps to full up position and adjust flap position transmitter to make position indicator read 0°. Slotted holes in the transmitter bracket are provided for adjustment. If necessary, transmitter rod may be formed slightly for additional adjustment.

m. Perform an operational checkout of the wing flap control system, check all locknuts for tightness, check that all turnbuckles are safetied, and reinstall all parts removed for access.

7-13. RIGGING FLAP CONTROL SYSTEM - 1968 MODEL 210 SERIES (See figure 7-1, sheets 3 & 4.)

a. Run flaps to full up position.

b. Disconnect push-pull rods at flaps.

c. If cables are being replaced, attach 1/8" direct cable to forward side of each drive pulley and the 3/32" retract cables to the aft side of the drive pulleys. If drive pulleys are not installed, it may be easier to attach the cables before installing the drive pulleys.

d. Adjust synchronizing push-pull rod to 41.94 inches (Early 1968 Models) or 41.87 inches (Mid-1968 and on) between rod-end holes, then tighten jam nuts and install.

e. Adjust inboard push-pull rods to 12.12 inches (Early 1968 Models) or 10.81 inches (Mid-1968 and on); adjust outboard push-pull rods to 11.57 inches (Early 1968 Models) or 10.39 inches (Mid-1968 and on), then tighten jam nuts and install.

f. Check that cables are in pulley grooves, then adjust turnbuckles to obtain correct cable tension and place flaps in full up position (flap actuator in full up position). Adjust up limit switch to operate and shut off motor at this position.

g. Mount an inclinometer on one flap and set to 0°.

NOTE

An inclinometer for measuring control surface travel is available from the Cessna Service Parts Center. (See figure 6-5 of the Service Manual.)

h. Lower flaps to specified down angle, then adjust down limit switch to operate and shut off motor at this position.

i. Repeat steps "g" and "h" for opposite flap.

j. Run flaps to full up position, then disconnect follow-up control at switch mounting arm.

k. Move control lever (14) to full UP position, then without moving control lever, move arm (16) until control lever cam (13) is centered between mid-range switches. Adjust follow-up control to fit and secure at this position.

l. Adjust mid-range switches in slotted holes until rollers just clear cam, then secure switches.

m. Turn on master switch and run flaps through several cycles, stopping at various mid-range settings and checking that cable tension is within limits. Retract cable tension may increase to 90 pounds when flaps are fully retracted.

n. Flight test aircraft and check that follow-up control does not cause automatic cycling, which indicates the operating switches do not have sufficient clear-

ance at the cam. If cycling occurs, readjust operating switches as necessary per step "l", then complete rigging.

o. Check that all rod ends and clevis ends have sufficient thread engagement, all jam nuts are tight, then replace all parts removed for access.

7-14. RIGGING FLAP CONTROL SYSTEM - 1968 MODEL 206 SERIES (See figure 7-1, sheets 1 & 2.)

NOTE

Before using this procedure, disconnect flap cables at turnbuckles above cabin headliner, and disconnect flap push-pull rods at drive pulleys and bellcranks in both wings.

a. If cables are not connected to drive pulleys, it is necessary to disconnect parts attached to each drive pulley so it may be rotated beyond its normal range of travel to permit cable attachment. If drive pulleys are not installed, attach cables before installing the drive pulleys in the wings.

b. The 3/32" retract cable connects to the forward side of the right hand drive pulley and to the aft side of the left hand drive pulley.

c. The 1/8" direct cable connects to the aft side of the right hand drive pulley and to the forward side of the left hand drive pulley.

d. Adjust synchronizing push-pull tube in right wing to 48.69" between centers of rod end holes, tighten jam nuts, and install. If outboard bellcrank is not installed, the tube and bellcrank must be positioned in the wing and the tube attached to the bellcrank before the bellcrank is installed.

e. Using care not to cause damage, run flap motor to fully retract actuating tube on motor (full up position). Loosen set screw and rotate nut and ball assembly in or out as required to position right flap drive pulley so that centerline of bolt hole for flap inboard push-pull rod attachment is 3.95 inches aft of the fuel well bulkhead. Tighten set screw then adjust up-limit switch to deactuate the system at this position.

NOTE

Apply Grade 'C' Loctite (American Sealant Co., Hartford 11, Conn.) to threads of actuating tube set screw after final adjustments have been made.

f. Manually holding right flap full up, adjust right inboard push-pull rod to align with attaching holes, and install the push-pull rod. Tighten push-pull rod end locknut.

g. Repeat step "f" for the right outboard push-pull rod.

NOTE

The right wing flap and motor must be correctly rigged before the flap cables and left wing flap can be rigged.

h. Adjust synchronizing push-pull tube in the left wing to 48.69 inches between centers of rod end holes, tighten lock nut, and install tube. If outboard bellcrank is not installed, the tube and bellcrank must be positioned in the wing and the tube attached to the bellcrank before the bellcrank is installed.

i. Connect flap cables at turnbuckles above cabin headliner. Adjust turnbuckles to position left wing flap drive pulley so the centerline of the bolt hole for flap inboard push-pull rod attachment is 4.20 inches aft of the fuel well bulkhead, maintaining 70 ± 10 pounds cable tension.

NOTE

When tightening cable turnbuckles, be sure the cables are in the pulley grooves and cable ends are correctly positioned at the drive pulleys. Rig cable tension to the average temperature for the area.

j. Manually holding left wing flap up, adjust left inboard push-pull rod to align with attaching holes and install the push-pull rod. Tighten push-pull rod end lock nut.

k. Repeat step "j" for the left outboard push-pull rod.

l. Loosen follow-up control at switch mounting arm (21).

m. Move control lever (7) to full UP position, then without moving control lever, move arm (9) until control lever cam (6) is centered between switches (8) and (10). Secure follow-up control at this position.

n. Adjust switches (8) and (10) in slotted holes until rollers just clear cam, then secure switches.

o. Turn on master switch and run flaps through several cycles, stopping at various mid-range settings and checking that cable tension is within limits. Retract cable tension may increase to 90 pounds when flaps are fully retracted.

p. Run flaps to full UP position and mount an inclinometer on trailing edge of one flap, then set to 0° .

NOTE

An inclinometer for measuring control surface travel is available from the Cessna Service Parts Center. Refer to figure 6-5 of the 200-Series Service Manual.

q. Run flaps to full down position and set down-limit switch to deactuate the system at this position.

NOTE

Since flap rollers may not bottom in flap tracks with flaps fully extended, some free play may be noticed in this position.

r. Flight test aircraft and check that follow-up control does not cause automatic cycling, which indicates the operating switches do not have sufficient clearance at the cam. If cycling occurs, readjust operating switches as necessary per step "n", then complete rigging.

s. Check that all rod ends and clevis ends have sufficient thread engagement, all jam nuts are tight, then replace all parts removed for access.

7-15. FLAP MOTOR BRAKE ADJUSTMENT. Refer to figure 7-4 for adjustment of the flap motor solenoid-released brake assembly.

SECTION 8

ELEVATOR CONTROL SYSTEM

TABLE OF CONTENTS	Page		
ELEVATOR CONTROL SYSTEM	8-1	Elevator Removal	8-2
Trouble Shooting	8-1	Elevator Repair	8-2
REPLACEMENT OF COMPONENTS	8-2	Elevator Installation	8-2
Control Column	8-2	RIGGING ELEVATOR CONTROL	
Cables, Pulleys, and Bellcranks	8-2	SYSTEM	8-4

8-1. ELEVATOR CONTROL SYSTEM.

the torque tube at the control column on the Model 210 and T210 (prior to 1967) to improve longitudinal stability. The control column is shown in figure 6-1.

8-2. The elevator control systems are illustrated in figures 8-1 and 8-3. Counterweights are secured to

8-3. TROUBLE SHOOTING THE ELEVATOR CONTROL SYSTEM.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
NO RESPONSE TO CONTROL WHEEL FORE-AND-AFT MOVEMENT.		
Forward or aft push-pull tube disconnected.	Check visually.	Attach push-pull tube and rig per paragraph 8-10.
Cables disconnected.	Check visually.	Attach cables and rig per paragraph 8-10.
BINDING OR JUMPY MOTION FELT IN MOVEMENT OF ELEVATOR SYSTEM.		
Defective bellcrank pivot bearing.	Check bellcrank; move to check for play or binding.	Replace bellcrank.
Defective elevator bellcrank pivot bearing.	Check bellcrank; move to check for play or binding.	Replace bellcrank.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
BINDING OR JUMPY MOTION FELT IN MOVEMENT OF ELEVATOR SYSTEM. (Cont)		
Cables slack.	Check for correct tension.	Adjust to correct tensions.
Cables not riding correctly on pulleys.	Check cable routing.	Route cables correctly on pulleys.
Defective elevator hinges.	Disconnect rear push pull tube and move elevator by hand, checking hinges.	Replace defective hinges.
Defective push-pull tube bearings.	Disconnect push-pull tube and check that bearings rotate freely.	Replace defective rod end.
Defective control column needle bearing rollers.	Check visually.	Replace rollers.
Defective control column torque tube bearings.	Disconnect parts and check that torque tube rotates freely.	Replace bearings.
Bob weight shields misaligned.	Check visually.	Adjust shields for proper clearance.
ELEVATOR FAILS TO ATTAIN PRESCRIBED TRAVEL.		
Stops incorrectly set.		Rig per paragraph 8-10.
Cables unevenly tightened.		Rig per paragraph 8-10.
Interference at firewall or instruments.	Check visually.	Rig per paragraph 8-10.

8-4. REPLACEMENT OF COMPONENTS.

NOTE

8-5. THE CONTROL COLUMN may be removed, repaired, and installed as outlined in Section 6.

8-6. CABLES, PULLEYS, AND BELLCRANKS. Cables, pulleys, and bellcranks, as well as other components of the elevator control systems, may be removed and installed while using the illustrations in this section as a guide. Repair consists of replacement of defective parts. If rigging has been affected by replacement of components, rerig in accordance with paragraph 8-10.

NOTE

To ease rerouting of cables, a length of wire may be attached to the end of the cable before it is withdrawn from the airplane. Leave the wire in place, routed through the structure; then attach it to the cable being installed and use it to pull the cable into position.

8-7. ELEVATOR REMOVAL. (See figure 8-4.)

- Remove stinger.
- Disconnect elevator trim tab push-pull tube from trim tab.
- Remove three bolts (12) securing right and left elevators to elevator bellcrank (10).

If precautions are taken to see that the elevator trim system is not moved and actuator screw is not turned, it will not be necessary to rerig the elevator trim control system.

- Remove elevator hinge bolts to remove elevator.
- Elevator bellcrank (10) may be removed after disconnecting push-pull tube (9) and removing pivot bolt (11). Bolts (12) must be removed, but it is not necessary to remove elevators to remove the bellcrank.

8-8. ELEVATOR REPAIR may be accomplished as outlined in Section 18. Hinge bearings may be replaced as necessary. If repair has affected static balance, check static balance and rebalance as required.

8-9. ELEVATOR INSTALLATION. Reverse the procedure outlined in paragraph 8-7 to install the elevators. When tightening bolts (12), be sure elevators are aligned with each other. Do not attempt to align the elevator trailing edges on Model 210 series (1967 and on) and 1968 Model 206 series as there is a 0° 54' twist designed into the connecting torque tube. This twist causes the right elevator to be higher than the left. Check elevator and trim tab travel, and rig if necessary. Trim system rigging is given in Section 9.




Figure 8-1. Elevator Control System (210 Series)




Figure 8-2. Elevator Bob Weights

8-10. RIGGING THE ELEVATOR CONTROL SYSTEM. (See figures 8-1, 8-3, and 8-6.) The elevator control system can be rigged using the following procedure:

- a. Lock control wheel tube in neutral by installing control lock.

NOTE

On 1968 models the control lock hole is re-located to prevent take-off with control lock installed. Refer to figure 8-7 for control tube rigging tool.

- b. Adjust elevator cable turnbuckles to streamline elevators with horizontal stabilizer and to obtain 30 pounds cable tension, then safety the turnbuckles.

NOTE

Disregard the counterweight areas of the elevators when streamlining. These areas are contoured so that they will be streamlined at cruising speed (elevators approximately 3° down).

- c. Mount an inclinometer on one elevator and set to zero degrees.

NOTE

An inclinometer for measuring control surface travels is available from the Cessna Service Parts Center. Refer to figure 6-5.

- d. Remove control lock, then adjust elevator travel stops to attain correct elevator travel as listed in Section 1.
- e. Adjust elevator downspring turnbuckle (with elevators full down) as shown in figure 8-5. Safety the turnbuckle.
- f. Move control wheel through full range of travel and check cable tension in various positions. Tension should not be less than 20 pounds or more than 40 pounds in any position.
- g. Check that all turnbuckles are safetied and all parts are secured, then reinstall all parts removed for access.

WARNING

Be sure elevators move in the correct direction when operated by the control wheel.





Figure 8-3. Elevator Control System (206 Series)



NOTE

Trailing edge elevator sections are foam filled on Model 210-Series aircraft. Elevator skins are corrugated on Model 206-Series aircraft.

Beginning in 1968, the Model 206 Series uses the Model 210 elevator configuration. This change standardizes 200-Series elevator-stabilizer installations.


1. Outboard Hinge (P206 and U206 Series)
2. Elevator Trim Tab
3. Right Elevator
4. Left Elevator
5. Inboard Hinge (P206 and U206 Series)
6. Static Balance Weight
7. Outboard Hinge (210 and T210 Series)

8. Needle Bearing
9. Push-Pull Tube
10. Elevator Bellcrank
11. Bolt
12. Bolt
13. Inboard Hinge (210 and T210 Series)

Figure 8-4. Elevator Installation

NOTE


As the elevator bellcrank pivots, the assist spring link moves over-center and exerts pressure in the direction the bellcrank is pivoting. The spring pressure is not adjustable.



MODEL 210G AND T210G AND ON

NOTE

A turnbuckle in the downspring cable is provided for adjustment. With elevator in full down position adjust to obtain overall downspring length of 7.88 inches on the Model 206 Series, and 7.05 inches on the Model 210 Series (prior to 1967).



ALL MODELS EXCEPT 210G AND T210G AND ON

Figure 8-5. Elevator Bellcrank Installation

NOTE

The holes are drilled off center in the bellcrank stops to provide elevator travel adjustments. Every 90° of rotation of the bellcrank stop provides approximately 1° of control surface travel.




Figure 8-6. Travel Stops on Elevator Rear Bellcrank




Figure 8-7. Control Column Neutral Rigging Tool - All Models (1968 and on)

SECTION 9

ELEVATOR TRIM CONTROL SYSTEM

TABLE OF CONTENTS	Page	
ELEVATOR TRIM CONTROL SYSTEM	9-1	
Trouble Shooting	9-1	Removal and Installation of
Removal	9-5	Elevator Trim Tab Actuator
Repair	9-5	Rigging
Installation.	9-5	ELECTRIC TRIM SYSTEM.
Removal and Installation of		Trouble Shooting
Elevator Trim Tab	9-5	Removal and Installation.
		9-8

9-1. ELEVATOR TRIM CONTROL SYSTEM.

The elevator trim tab is located on the right elevator and is controlled by a trim wheel, roller chains, screwjack actuator, and cable system arrangement. A position indicator in the trim wheel mechanism indicates nose attitude of the aircraft. Forward rotation of the wheel trims the nose down, and aft rotation of the wheel trim the nose up. Beginning in 1968, the standard elevator trim control system

may be equipped with an electric trim assist as optional equipment. (See figure 9-6.) The System is operated by a control wheel-mounted switch. The servo unit includes a motor and a chain driven, solenoid operated adjustable clutch. The trim tab up cable enters the servo housing and double wraps around a drive drum. While the clutch is not energized, the drive drum freewheels so manual operation is not affected.

9-2. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
EXCESSIVE RESISTANCE IN TRIM CONTROL WHEEL.		
Cable tension too high.	Check cable tension.	Adjust tension.
Pulleys binding or rubbing.	Check pulleys.	Repair or replace as necessary.
Cables not in place on pulleys.	Check visually.	Install cables correctly.
Trim tab hinge binding.	Disconnect actuator and move tab up and down to check hinge resistance.	Lubricate or replace hinge as necessary.
Defective trim tab actuator.	Remove chain from actuator sprocket and operate actuator manually.	Replace actuator.
Rusty chain.	Visually check chain.	Remove and replace rusty chain.
Damaged sprocket.	Visually check sprockets.	Remove and replace damaged sprockets.
Bent sprocket shaft.	Observe motion of sprockets.	Remove and replace bent sprocket shafts.




Figure 9-1.. Elevator Trim Control System (210 Series)




Figure 9-2. Elevator Trim Control System (206 Series)

9-3. REMOVAL OF ELEVATOR TRIM CONTROL SYSTEM may be accomplished while using the illustrations in this Section as a guide.

9-4. REPAIR OF ELEVATOR TRIM CONTROL SYSTEM. Any worn, damaged, or defective components of the elevator trim control system should be replaced.

9-5. INSTALLATION OF ELEVATOR TRIM CONTROL SYSTEM may be accomplished while using the illustrations in this Section as a guide.

9-6. REMOVAL AND INSTALLATION OF ELEVATOR TRIM TAB.

- a. Disconnect push-pull link from arm on trim tab.

NOTE

Tape or otherwise secure link from actuator screw so it cannot turn to retain proper rigging.

- b. On the Model 210 Series and 1968 206 series airplanes, remove screw from end of hinge pin and remove hinge pin. Trim tab and/or hinges may then be replaced as required.

- c. On the Model 206 Series (Prior to 1968) airplanes, the ends of the hinges are crimped to retain the hinge pin. It is usually easier to drill out hinge attaching rivets, then spread crimped ends and remove hinge pin if necessary.

- d. After installation, connect push-pull link. If the link was not rotated, it is not necessary to rerig the elevator trim control system.

9-7. REMOVAL AND INSTALLATION OF ELEVATOR TRIM TAB ACTUATOR.

- a. Release trim tab cable tension at turnbuckle.
- b. Disconnect push-pull link from actuator.
- c. Remove access cover on lower skin of stabilizer beneath trim tab actuator.
- d. Loosen chain guard at forward end of actuator and disengage chain from actuator sprocket.
- e. Remove screws and clamps attaching actuator to bracket and remove actuator.
- f. To install the elevator trim tab actuator, reverse the preceding steps. Rig elevator trim system in accordance with paragraph 9-8.

9-8. RIGGING THE ELEVATOR TRIM CONTROL SYSTEM. (See figures 9-1 and 9-2.)

- a. Loosen travel stop blocks on trim tab cables and disconnect actuator screw from link to trim tab.

- b. Check cable tension and readjust turnbuckle if necessary. Resafety turnbuckle. If chains and/or cables are being installed, permit actuator screw to rotate freely as chains and cables are connected, set cable tension with turnbuckle, and safety the turnbuckle.

- c. Rotate trim control wheel full forward (nose down), making sure pointer does not restrict trim wheel movement. If necessary to re-position pointer where it will not restrict trim wheel movement, proceed as follows:

1. Remove control pedestal cover. Refer to paragraph 11-5.
2. Loosen nut at trim wheel pivot shaft.
3. Loosen screws securing chain guard (see figure 9-4) far enough that trim wheel can be moved





Figure 9-3. Elevator Trim Tab Installation



1. Elevator Trim Wheel
2. Position Pointer
3. Pointer Pivot Stud
4. Pedestal
5. Pedestal Cover
6. Trim Wheel Pivot Stud
7. Chain Guard

NOTE

The Model 210 Series pedestal and cover are illustrated. The Model 206 Series pedestal and cover are similar, except that provisions for installing the hydraulic Power Pack are omitted.




Figure 9-4. Elevator Trim Wheel Installation

1/8 inch, then use a thin screwdriver to pry trailing leg of pointer out of groove in trim wheel.

4. Reinstall screws and nuts, but do not install pedestal cover until rigging has been completed.

NOTE

Full forward (nose down) position of trim wheel is the position where further movement is prevented by chain or cable ends contacting sprockets or pulleys.

d. With elevator and trim tab both in neutral (streamlined), place inclinometer on tab and set to zero. Disregard the counterweight areas of the elevators when streamlining. These areas are contoured so that they will be approximately 3° down at cruising speed.

NOTE

An inclinometer for measuring control surface travels is available from the Cessna Service Parts Center. Refer to figure 6-5.

e. Rotate actuator screw in or out as required to place trim tab up with a maximum of 2° overtravel, when actuator screw is connected to link from trim tab.

f. Rotate trim control wheel to place trim tab up and down, readjusting actuator screw as required to obtain overtravel in both directions.


g. Position stop blocks and adjust as shown in figure 9-5 to limit travel as noted in Section 1.

h. Install control pedestal cover and check that trim wheel pointer travels the same distance from ends of slot in cover. Re-position trailing leg of pointer if necessary (refer to step "c").

i. Check that all safeties are installed and all parts are secure, then reinstall all parts removed for access.

WARNING

Be sure trim tab moves in correct direction when operated by trim control wheel. Nose down trim corresponds to tab up position.



1. With elevators in neutral, set trim tab to neutral (streamlined).
2. Position stop block (1) against clevis on cable B and secure to cable B.
3. Place inclinometer on trim tab and lower tab to degree specified in Section 1.
4. Position stop block (2) against stop block (1) and secure to cable A.
5. Raise trim tab to specified degree, place stop block (3) against stop block (2) and secure to cable B.

Figure 9-5. Elevator Trim Tab Travel Adjustment

9-9. ELECTRIC TRIM SYSTEM (See figure 9-6.)

9-10. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
SYSTEM INOPERATIVE.		
Circuit breaker out.	Check visually.	Reset circuit breaker.
Defective circuit breaker.	Check continuity.	Replace circuit breaker.
Defective wiring.	Check continuity.	Repair wiring.
Defective trim switch.	Check continuity.	Replace switch.
Defective trim motor.	Remove and bench test.	Replace motor.
TRIM MOTOR OPERATING - TRIM TAB FAILS TO MOVE.		
Defective clutch solenoid.	Check continuity.	Replace clutch solenoid.
Improperly adjusted clutch tension.	Check tension.	Adjust friction washer.
Disconnected or broken cable.	Operate manual trim wheel.	Connect or replace cable.
Defective actuator.	Check actuator operation.	Replace actuator.

9-11. REMOVAL AND INSTALLATION.

- Remove aft cabin wall for access.
- Disconnect trim cable at actuator.
- Remove cable from drive drum, then disconnect electrical wires to servo unit.
- Remove mounting bolts, then remove unit from aircraft.

NOTE

Before installing the servo, adjust the clutch to slip at 25 +2 -0 in. lbs (Model 206 series), and 42 ±2 in. lbs (Model 210 series) by means of the friction washers and spanner nuts. The spanner nuts jam against each other as a lock.

- Install unit by reversing preceding steps.
- Install trim tab cable and adjust turnbuckle to obtain correct cable tension, then check trim tab travel and rig if necessary.

NOTE

Rigging for the electric trim system is the same as the manual system. After rigging is complete, adjust the potentiometer (located adjacent to the electric trim housing) to obtain a 24-second travel time from full nose down (tab up) trim to full nose up (tab down) trim. This test and adjustment procedure must be made with engine running to obtain normal operating voltage.

NOTE

Remainder of elevator trim system is identical to Model 210 series shown in figure 9-1.




Figure 9-6. Electric Elevator Trim (Sheet 1 of 2)

NOTE

Remainder of elevator trim system is identical to Model 206 series shown in figure 9-2.

CABLE TENSION:
25 +5 -0 LBS (AT THE AVERAGE TEMPERATURE FOR THE AREA.)

1. Clutch Cover
2. Spanner Nut
3. Washer
4. Friction Washer
5. Drive Drum
6. Solenoid Clutch
7. Support Structure
8. Motor Cover
9. Motor
10. Cover
11. Motor Support
12. Housing
13. Cover

MODEL 206 SERIES

Figure 9-6. Electric Elevator Trim (Sheet 2 of 2)

SECTION 10

RUDDER CONTROL SYSTEM

TABLE OF CONTENTS

Page

RUDDER CONTROL SYSTEM 10-1 Trouble Shooting 10-1 Removal of Rudder Pedal Assembly. 10-2 Installation of Rudder Pedal Assembly 10-2 Removal of Rudder Cables 10-7	Installation of Rudder Cables 10-7 Removal of Rudder 10-7 Repair of Rudder 10-7 Installation of Rudder 10-7 Rigging 10-7
---	--

10-1. **RUDDER CONTROL SYSTEM.** Rudder control is maintained through use of conventional rudder pedals which also control nose wheel steering. When

dual controls are installed, stowable rudder pedals are provided at the copilot's position.

10-2. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
RUDDER DOES NOT RESPOND TO PEDAL MOVEMENT.		
Broken or disconnected cables.	Visually check cables.	Connect or replace cables.
UNDUE EFFORT REQUIRED TO ACTUATE RUDDER.		
Cables too tight.	Check cable tension.	Adjust cable tension.
Cables not riding properly on pulleys.	Check visually.	Route cables correctly on pulleys.
Binding, broken, or defective pulleys.	Check visually, rotate pulleys by hand to check for binding.	Replace defective pulleys.
Pedal bars need lubrication.		Lubricate with general purpose oil.
Defective rudder bar bearings.	Lubrication fails to eliminate binding.	Replace bearing blocks.
Defective rudder hinge bearings.		Replace defective bearings.
LOST MOTION BETWEEN RUDDER PEDALS AND RUDDER.		
Rudder cables loose.	Check cable tension.	Adjust cable tension.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
STOWABLE PEDALS DO NOT DISENGAGE.		
Broken or defective control.	Disconnect control and check manually.	Replace control.
STOWABLE PEDALS DO NOT STOW.		
Defective cover, catch, or latch pin.	Check visually.	Replace defective parts.
STOWABLE PEDALS DO NOT RE-ENGAGE.		
Binding control.	Check control operation.	Repair or replace control.
Misaligned or bent mechanism.	Check visually.	Repair or replace defective parts.

10-3. REMOVAL OF RUDDER PEDAL ASSEMBLY.

- Remove carpeting, shields, and soundproofing from the rudder pedal and tunnel areas as necessary for access.
- Disconnect the brake master cylinders and the parking brake cables at the pilot's rudder pedals, then remove the pilot's rudder pedals and copilot's rudder pedals and brake links if installed.
- Slack off rudder system tension by loosening turnbuckles.
- Disconnect the rudder cables and the nosewheel steering system push-pull rods from the rudder bars.
- Disconnect the rudder trim bungee from the rudder bar. Note that on the Model 206 Series, this is a dual-purpose bungee, serving as both rudder trim and nose gear steering.
- On airplanes equipped with stowable rudder pedals, disconnect controls at the pedals.
- Remove the bolts securing the rudder bar bearing blocks and work the rudder bars out of the tunnel area to remove.

NOTE

Since the two inboard bearing blocks contain clearance holes for the rudder bars at one end and a bearing hole at the other end, they should be tagged so they can be reinstalled in the same positions.

10-4. INSTALLATION OF RUDDER PEDAL ASSEMBLY.

NOTE


Rudder bar assemblies should be checked for lubrication before installation. Internal bearings are oilite bearings which should be saturated with engine oil. The bearing blocks bear against the steel shafts and require no lubrication unless binding occurs. A few drops of general purpose oil will eliminate such binding.

- Position the rudder bar assemblies and install bearing blocks in the same position from which they were removed.
- Connect the rudder bungee to the rudder bar.
- Connect the rudder cables and the nose wheel steering system push-pull rods to the rudder bars.
- Install the copilot's rudder pedals and brake links if used, install the pilot's rudder pedals, then attach the brake master cylinders and parking brake cables to the pilot's rudder pedals.
- Connect stowable rudder pedal controls, if installed.
- Rig the system as outlined in paragraph 10-10.
- Replace soundproofing, carpeting, and shields removed for access.

SINGLE CONTROLS HUB


NOTE

Brake links (13), bellcranks (14), and attaching parts are replaced with hubs (1), when dual controls are not installed.



- | | |
|------------------------|-----------------------------|
| 1. Single Controls Hub | 11. Forward Rudder Bar |
| 2. Spacer | 12. Brake Torque Tube |
| 3. Clevis Bolt | 13. Brake Link |
| 4. Anti-Rattle Spring | 14. Bellcrank |
| 5. Pivot Shaft | 15. Bracket |
| 6. Pin | 16. Stowable Pedal Controls |
| 7. Rudder Pedal | 17. Scuff Plate |
| 8. Aft Rudder Bar | 18. Cover Assembly |
| 9. Bearing Block | 19. Catch |
| 10. Master Cylinder | |

Figure 10-1. Rudder Pedals Installation



CABLE TENSION:
 30 LBS \pm 10 LBS (AT THE
 AVERAGE TEMPERATURE
 FOR THE AREA)

Rudder travel measured perpendicular
 to hinge line.

- | | |
|-------------------------------|-----------------|
| 1. Turnbuckle | 7. Roller |
| 2. Right Rear Rudder Cable | 8. Spacer |
| 3. Left Rear Rudder Cable | 9. Cable Guard |
| 4. Stop Bolt | 10. Rudder Bars |
| 5. Right Forward Rudder Cable | 11. Fairlead |
| 6. Left Forward Rudder Cable | 12. Clip |

Figure 10-2. Rudder Control System (210 Series)





Figure 10-3. Rudder Control System (206 Series)

1. Steering Arm
2. Steering Bungee
3. Rod End
4. Nut
5. Washer
6. Whiffletree (Steering Bellcrank)
7. Bolt
8. Link Rod
9. Boot
10. Rudder Bar Arm
11. Retainer
12. Screw



1. Steering Arm
2. Bolt
3. Rudder Trim Sprocket
4. Rod End
5. Rudder Bar
6. Sleeve
7. Clamp
8. Bungee




Figure 10-4. Nosewheel Steering Linkage

10-5. REMOVAL OF RUDDER CABLES. (See figures 10-2 and 10-3.)

- a. Disconnect cables at rudder bars and at the short cables near the rudder.
- b. Connect guide wires to the aft end of each rudder cable.

NOTE

The guide wires are used as an aid in reinstallation of the rudder cables. As the rudder cables are pulled forward, out of the aircraft, the guide wires are drawn into place and are left in the position formerly occupied by the cables.

- c. Remove cable guards, pulleys and fairleads as necessary to withdraw each cable.

10-6. INSTALLATION OF RUDDER CABLES. (See figures 10-2 and 10-3.)

- a. Connect aft end of each rudder cable to forward end of guide wires. Pull the cables through the fuselage with the wires and detach guide wires.
- b. Check cable routing and install pulleys, cable guards, and fairleads.
- c. Connect the rudder cables to the rudder bars and to the short cables near the rudder.
- d. Rig the system as outlined in paragraph 10-10.

10-7. REMOVAL OF RUDDER. (See figure 10-5.)

- a. Remove the stinger and upper stabilizer fairings and disconnect the tail navigation light wire.
- b. Loosen the aft rudder cable turnbuckles and disconnect the rudder cables from the rudder.
- c. With rudder supported, remove all rudder hinge bolts and lift the rudder free of the vertical fin.

10-8. REPAIR OF RUDDER may be accomplished in accordance with structural repair instructions contained in Section 18.

10-9. INSTALLATION OF RUDDER. (See figure 10-5.) To install the rudder, reverse the procedure outlined in paragraph 10-7. Rig rudder control system.


10-10. RIGGING RUDDER CONTROL SYSTEM.

- a. Loosen rudder cable aft turnbuckles to relieve tension on rudder system.
- b. Weight the tail down to raise the nose wheel off the ground.
- c. On all models, disconnect nose gear steering bungee.
- d. On the Model 210 Series, disconnect rudder trim bungee from rudder bar arm.
- e. On the Model 210 Series, set free length of nose gear steering bungee at $6.415 \pm .010$ inches between centers of mounting holes at each end, as shown in figure 10-4, and reconnect steering bungee.
- f. Clamp rudder pedals in neutral with a board.
- g. Adjust rudder cable aft turnbuckles to streamline rudder with 30 pounds tension on rudder cables.
- h. Remove board used to clamp rudder pedals in neutral.
- i. Set rudder stop bolts to obtain correct rudder travel.
- j. On the Model 210 Series, reconnect the rudder trim bungee to the rudder bar arm and rig as outlined in Section 11.
- k. On the Model 206 Series, reconnect and rig rudder trim and nose gear steering bungee as outlined in Section 11.
- l. Operate rudder system, checking for ease of movement and full travel. Check cable tension with rudder in various positions. Cable tension should not be less than 20 pounds or more than 40 pounds in any position.
- m. Check that all turnbuckles are safetied, all jam nuts are tight, and all parts removed for access are reinstalled, then lower nose wheel to the ground.

WARNING

Be sure rudder moves in correct direction when operated by the rudder pedals.

SHOP NOTES:




- 1. Rudder
- 2. Bolt
- 3. Washer


- 4. Upper Hinge
- 5. Bolt
- 6. Washer
- 7. Center Hinge

- 8. Bolt
- 9. Washer
- 10. Lower Hinge

Figure 10-5. Rudder Installation



ESTABLISHING NEUTRAL
POSITION OF RUDDER



MEASURING
RUDDER
TRAVEL

1. Establish neutral position of rudder by clamping straightedge (such as wooden 2 x 4) on each side of fin and rudder and blocking trailing edge of rudder half the distance between straightedges as shown.
2. Tape a length of soft wire to the stinger in such a manner that it can be bent to index at the lower corner of the rudder trailing edge.
3. Using soft lead pencil, mark rudder at point corresponding to soft wire indexing point (neutral).
4. Remove straightedges and blocks.
5. Hold rudder against right, then left, rudder stop. Measure distance from pointer to pencil mark on rudder in each direction of travel. Distance should be between 8.12" and 8.72".

Figure 10-6. Checking Rudder Travel

SECTION 11

RUDDER TRIM CONTROL SYSTEMS

TABLE OF CONTENTS

Page

RUDDER TRIM CONTROL SYSTEMS	11-1	Repair	11-4
Trouble Shooting	11-1	Rigging (Model 210 Series)	11-4
Replacement	11-4	Rigging (Model 206 Series)	11-4
Removal and Installation of Control Pedestal Cover	11-4		

11-1. RUDDER TRIM CONTROL SYSTEMS.

11-2. In the Model 210 Series, a spring-loaded bungee is attached directly to the left rudder bar arm, and a trim wheel is linked to the bungee.

In the Model 206 Series, the nose wheel steering bungee is utilized as a rudder trim bungee in flight. A trim wheel adjusts the overall length of the bungee through a sprocket and chain arrangement.

11-3. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
FALSE READING ON POSITION INDICATOR.		
Improper rigging.		Rig in accordance with paragraph 11-7 or 11-8.
Worn, bent, or disconnected linkage.	Observe visually.	Repair or replace as necessary.
HARD OR SLUGGISH OPERATION.		
Worn, bent, or binding linkage.	Observe visually.	Repair or replace as necessary.
Incorrect rudder cable tension.	Check rudder cable tension.	Adjust rudder cable tension as outlined in Section 10.
FULL TRAVEL NOT OBTAINED.		
Rudder trim system improperly rigged.		Rig in accordance with paragraph 11-7 or 11-8.





Figure 11-1. Rudder Trim Control System (210 Series)



1. Bolt
2. Washer
3. Bushing
4. Idler Sprocket
5. Sprocket
6. Shaft
7. Bushing

8. Indicator
9. Trim Wheel
10. Sprocket
11. Spacer
12. Grommet
13. Washer
14. Bolt

15. Bushing
16. Chain
17. Rudder Bar
18. Chain Guard
19. Sleeve
20. Clamp
21. Bungee

Figure 11-2. Rudder Trim Control System (206 Series)

11-4. REPLACEMENT OF RUDDER TRIM SYSTEMS. The two basic types of trim systems are shown in figures 11-1 and 11-2, which may be used as a guide during removal and installation.

NOTE

On the Model 206 Series, the nose gear must be removed before removing bungee. Refer to Section 5 for nose gear removal procedure.

11-5. REMOVAL AND INSTALLATION OF CONTROL PEDESTAL COVER.

- a. Turn fuel selector valve to OFF, drain fuel strainer, then remove knurled nut from optional engine primer and pull plunger from primer. Protect primer from dirt.
- b. Remove fuel selector handle by removing roll pin, and remove fuel selector plate or cup.
- c. Remove cowl flap knob.
- d. Remove nut from microphone jack when attached to cover.
- e. Remove screws securing pedestal cover and remove the cover.
- f. Reverse the preceding steps to install the cover.

11-6. REPAIR OF RUDDER TRIM SYSTEMS. Any worn, damaged, or defective components of the rudder trim system should be replaced.

11-7. RIGGING THE RUDDER TRIM SYSTEM - MODEL 210 SERIES. (See figure 11-1.)

NOTE

The only rigging adjustment possible, or necessary, on this rudder trim system is adjustment of the trim pointer to correspond with the spring-load being brought to bear on the rudder control system. The rigging method employed here involves merely "centering" the rudder and then "centering" the trim wheel indicator. Unless trim mechanism parts are deformed, this results in a correctly rigged system. The rudder control system and nose wheel steering bungee must be properly rigged before rigging the rudder trim system.

- a. Remove pedestal decorative cover and sheet metal covers to gain access to rudder trim components in pedestal.
- b. Weight the tail to raise nosewheel off ground.
- c. Turn rudder trim wheel until rudder is streamlined.

d. If necessary, readjust pointer by lifting "tracking" leg of pointer out of spiral groove in trim wheel. Set pointer to neutral.

e. Using trim wheel, run pointer through its full travel, checking to see that there is corresponding response of rudder.

f. Lower nosewheel to ground and reinstall all parts removed for access.

11-8. RIGGING THE RUDDER TRIM SYSTEM - MODEL 206 SERIES. (See figure 11-2.)

- a. Remove pedestal cover and pilot's rudder bar shield.
- b. Disconnect nosewheel steering bungee from right rudder bar arm by removing nut, washer and bolt.
- c. Raise nosewheel off ground and lock nose gear in neutral.
- d. Loosen idler sprocket on roller chain connecting rudder trim wheel mechanism to steering bungee.
- e. Block rudder in neutral position.

NOTE

The rudder control system must be correctly rigged prior to rigging of the trim system.

f. Screw bungee sprocket all the way into bungee shaft, then screw rod end all the way into sprocket threads.

NOTE

This sets the bungee at its shortest free length.

g. Holding rod end to prevent it from turning, rotate sprocket until the hole in rod end aligns exactly with attaching hole on right rudder bar arm. Install bolt, washer and nut.

h. With chain disengaged from bungee sprocket, set trim wheel to neutral position.

i. Without disturbing bungee or trim wheel sprocket, set chain on sprockets and tighten idler sprocket.

j. Unblock rudder, then run trim wheel through its full range of travel, observing that full pointer travel is reached before full bungee extension or contraction is attained.

k. Lower nosewheel to ground and reinstall all parts removed for access.

WARNING

Be sure rudder moves in proper direction when moved by trim control wheel.

SHOP NOTES:

SECTION 12

POWERPLANT

(NORMALLY ASPIRATED)

REFER TO SECTION 12A FOR TURBOCHARGED POWERPLANT

TABLE OF CONTENTS

	Page		Page
ENGINE COWLING	12-1	Fuel Injection Pump	12-13
Cleaning, Inspection, and Repair	12-1	Removal of Fuel Injection Pump	12-13
ENGINE	12-1	Installation of Fuel Injection Pump	12-14
Engine Data	12-2	Fuel Injection Pump Adjustments	12-14
Trouble Shooting	12-3	ENGINE COWL FLAPS	12-14
Engine Removal	12-6	Rigging Engine Cowl Flaps	12-14
Inspection and Repair	12-6	ENGINE CONTROLS	12-14
Powerplant Build-Up	12-6	RIGGING PROCEDURES - ENGINE	
Engine Installation	12-6	CONTROLS	12-17
AIR INDUCTION SYSTEM	12-8	Rigging Induction Air Control	12-17
Removal of Air Intake Box	12-8	Rigging Propeller Governor Control	12-17
Cleaning and Inspection of Air Intake Box	12-8	Rigging Mixture Control	12-17
Installation of Air Intake Box	12-8	Rigging Throttle Control	12-17
Engine Air Filter	12-9	Rigging Throttle Microswitches	12-17
Removal of Engine Air Filter	12-9	STARTING SYSTEM	12-18
Cleaning of Engine Air Filter	12-9	Replacement of Starter	12-18
Installation of Engine Air Filter	12-9	Standard Maintenance	12-18
ENGINE EXHAUST SYSTEM	12-9	Trouble Shooting Starter	12-19
Removal	12-9	SLICK MAGNETOS	12-20
Inspection	12-9	Removal	12-20
Installation	12-9	Internal Timing	12-20
ENGINE BAFFLES	12-9	Installation and Timing to the Engine	12-20
Cleaning and Inspection	12-9	Maintenance	12-22
FUEL INJECTION SYSTEM	12-10	OIL SYSTEM	12-22
Fuel-Air Control Unit	12-10	Trouble Shooting	12-24
Removal of Fuel-Air Control Unit	12-10	Full-Flow Oil Filter	12-25
Cleaning and Inspection of Fuel-Air		Filter Element Replacement	12-25
Control Unit	12-10	Filter Adapter Removal	12-26
Installation of Fuel-Air Control Unit	12-10	Disassembly, Repair, and Assembly of	
Fuel-Air Control Unit Adjustments	12-10	Filter Adapter	12-26
Fuel Manifold Valve	12-10	Filter Adapter Installation	12-28
Removal of Fuel Manifold	12-12	Oil Cooler	12-28
Cleaning Fuel Manifold Valve	12-12	EXTREME WEATHER MAINTENANCE	12-28
Installation of Fuel Manifold	12-13	Cold Weather	12-28
Fuel Discharge Nozzles	12-13	Low Battery Starting	12-29
Removal of Fuel Discharge Nozzles	12-13	Hand-Cranking	12-29
Cleaning and Inspection of Fuel		Hot Weather	12-29
Discharge Nozzles	12-13	Dusty Conditions	12-30
Installation of Fuel Discharge Nozzles	12-13	Seacoast Areas, Humid Areas	12-30

12-1. ENGINE COWLING.

12-2. The upper cowling is divided into four removable sections. The right and left nose caps are fastened to the lower section and to each other with screws. The right and left upper cowl sections are secured with quick release fasteners and either section may be removed individually. The left cowl section has two access doors. One at the upper front provides easy access to the engine oil filler neck, and one at the lower left provides easy access to the oil dipstick. The lower engine nacelle is an extension of the fuselage and provides fairing for the 210-Series nose wheel in its retracted position.

12-3. CLEANING, INSPECTION, AND REPAIR OF ENGINE COWLING. The cowling should be cleaned by spraying with solvent (Federal Specification PS-661 or equivalent) and wiping clean with a cloth. After cleaning, inspect cowling for dents, cracks, and loose rivets. Repair all defects to prevent spread of damage.

12-4. ENGINE

12-5. The non-turbocharged powerplant is an air-cooled, six-cylinder, horizontally opposed, wet sump, fuel-injected Continental engine. Refer to paragraph 12-6 for engine data.

12-6. ENGINE DATA.

Aircraft Series	210 Series, P206 Series, and Thru U206A	U206B
Model (Continental)	IO-520-A	IO-520-F
BHP at RPM	285 at 2700	—
BHP Maximum for Take-Off (5 Minutes) at RPM	—	300
BHP Maximum Except Take-Off RPM (Max. Continuous)	—	2850
	—	285
	—	2700
Number of Cylinders	6-Horizontally Opposed	Same
Displacement	520 Cubic Inches	Same
Bore	5.25 Inches	Same
Stroke	4.00 Inches	Same
Compression Ratio	8.5:1	Same
Magnetos	Slick #662	Same
Right Magneto	Fires 22° BTC Upper Right and Lower Left	Same
Left Magneto	Fires 22° BTC Upper Left and Lower Right	Same
Firing Order	1-6-3-2-5-4	Same
Spark Plugs	SL-350	Same
Gap	.015 to .018 Inch	Same
Torque Value	330 ± 30 Lb-In	Same
Fuel Metering System	Continental Fuel Injection	Same
Unmetered Fuel Pressure	9.0 to 11.0 PSI at 600 RPM 29.2 to 30.8 PSI at 2700 RPM	Same 31.0 to 32.5 PSI at 2850 RPM
Fuel	Aviation Gasoline	Same
Grade-Minimum	100/130	Same
Oil Sump Capacity	12 U.S. Quarts	Same
Tachometer	Type AS-54 Mechanical Drive	Same
Alternator	14-Volt, 60-Ampere	Same
Dry Weight with Accessories (Approx)	471	Same
Oil Pressure		
Minimum Idling	10 PSI	Same
Normal	30 to 60 PSI	Same
Oil Temperature		
Normal Operating	Within Green Arc	Same
Maximum Temperature	Red Line (240°F)	Same
Cylinder Head Temperature	460°F Maximum	Same

ENGINE DATA. (Cont)

INSTRUMENT CONNECTION LOCATIONS:

Oil Temperature	Below Oil Cooler	Same
Oil Pressure	Between No. 2 and No. 4 Cylinders	Same
Cylinder Head Temp.	Lower Side of No. 1 Cylinder; P206, No. 2 Cylinder	Lower Side of No. 1 Cylinder
Manifold Pressure	Right Rear Intake Elbow	Same
Fuel Flow	Fuel Manifold Valve	Same

12-7. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
ENGINE FAILS TO START.		
Improper use of starting procedure.		Review starting procedure.
Defective aircraft fuel system.	See paragraph 13-3.	See paragraph 13-3.
Engine flooded.	See paragraph 12-83.	See paragraph 12-83.
Spark plugs fouled or improperly gapped.	Remove and check.	Clean and regap. Replace if defective.
Failure of magneto impulse couplings.	With ignition switch off, rotate propeller by hand and listen for loud clicks as impulse couplings operate.	Repair or replace magnetos.
Defective magneto switch or grounded magneto leads.	Check continuity.	Repair or replace switch or leads.
Defective ignition system.	See paragraph 12-68.	See paragraph 12-68.
Excessive induction air leaks.	Check visually.	Correct the cause of air leaks.
Dirty screen in fuel control unit, or defective fuel control unit.	Remove screen and check visually. Check fuel flow through fuel control unit.	Clean dirty screen. Replace fuel control unit if defective.
Defective electric fuel pump.	See paragraph 13-3.	See paragraph 13-3.
Defective fuel manifold valve, or dirty screen inside valve.	Check fuel flow through valve.	Remove and clean per paragraph 12-37. Replace if defective.
Clogged fuel injection lines or discharge nozzles.	Check fuel flow through lines and nozzles.	Clean lines and nozzles. Replace if defective. Refer to paragraph 12-41.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
ENGINE FAILS TO START (Cont).		
Fuel pump not permitting fuel from electric pump to bypass.	Check fuel flow through engine-driven fuel pump.	Replace fuel pump.
Vaporized fuel.	Vaporized fuel is most likely to occur in hot weather with a hot engine.	See paragraph 12-83.
ENGINE STARTS BUT DIES, OR WILL NOT IDLE.		
Propeller control in low rpm position.	Check visually.	Use high rpm for all ground operations.
Defective aircraft fuel system.	See paragraph 13-3.	See paragraph 13-3.
Improper idle speed or idle mixture adjustment.	See paragraph 12-34.	See paragraph 12-34.
Spark plugs fouled or improperly gapped.	Remove and check.	Clean and regap. Replace if defective.
Water in fuel system.	Open fuel strainer drain valve and check for water.	Drain fuel tank sumps, fuel lines, and fuel strainer.
Defective ignition system.	See paragraph 12-68.	See paragraph 12-68.
Excessive induction air leaks.	Check visually.	Correct the cause of air leaks.
Dirty screen in fuel control unit, or defective fuel control unit.	Remove screen and check visually. Check fuel flow through fuel control unit.	Clean dirty screen. Replace fuel control unit if defective.
Defective fuel manifold valve, or dirty screen inside valve.	Check fuel flow through valve.	Remove and clean per paragraph 12-37. Replace if defective.
Restricted fuel injection lines or discharge nozzles.	Check fuel flow through lines and nozzles.	Clean lines and nozzles. Replace if defective. Refer to paragraph 12-41.
Defective engine-driven fuel pump.	If engine continues to run with electric pump turned on, but stops when it is turned off, the engine-driven pump is defective.	Replace engine-driven fuel pump.
Vaporized fuel.	Vaporized fuel is most likely to occur in hot weather with a hot engine.	See paragraph 12-83.
Manual primer leaking.	Disconnect primer outlet line. If fuel leaks through primer, it is defective.	Repair or replace primer.
Defective engine.	Check compression. Listen for unusual engine noises.	Engine repair is required.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
ENGINE RUNS ROUGHLY, WILL NOT ACCELERATE PROPERLY, OR LACKS POWER.		
Propeller control in low rpm position.	Check visually.	Use high rpm for all ground operations.
Restriction in aircraft fuel system.	See paragraph 13-3.	See paragraph 13-3.
Restriction in fuel injection system.	Check fuel flow through discharge nozzles, fuel lines, manifold valve, fuel control unit, and fuel pump until restriction is located.	Clean out restriction. Replace any item found defective.
Fuel pump pressure improperly adjusted.	See paragraph 12-46.	See paragraph 12-46.
Worn or improperly rigged throttle or mixture control.	Check visually.	Rig properly. Replace worn linkage.
Spark plugs fouled or improperly gapped.	Remove and check.	Clean and regap. Replace if defective.
Defective ignition system.	See paragraph 12-68.	See paragraph 12-68.
Defective engine.	Check compression. Listen for unusual engine noises.	Engine repair is required.
POOR IDLE CUT-OFF.		
Worn or improperly rigged mixture control.	Check that idle cut-off stop on fuel control unit is contacted.	Rig properly. Replace worn linkage.
Dirty or defective fuel manifold valve.	Operate electric fuel pump and check that no fuel flows through manifold valve with mixture control in idle cut-off.	Remove and clean per paragraph 12-37. Replace if defective.
Fuel contamination.	Check all screens in fuel and fuel injection system.	Drain all fuel and flush out fuel system. Clean all screens, fuel lines, discharge nozzles, fuel strainer, fuel manifold valve, and fuel pump.
Defective mixture control valve in fuel control unit.	If none of the preceding causes are found, fuel control unit is probably at fault.	Replace defective fuel control unit.

SHOP NOTES:

12-8. ENGINE REMOVAL. Identify each item as it is disconnected to aid in replacement.

NOTE

Plug or cap all disconnected lines, hoses and fittings.

- a. Turn all cabin switches and fuel selector valve OFF.
- b. Remove the engine cowling.
- c. Open the battery circuit by disconnecting the ground cable.

WARNING

Residual fuel draining from lines and hoses is a fire hazard. Use care to prevent the accumulation of such fuel when lines and/or hoses are disconnected.

- d. Disconnect magneto ground wires at the magnetos and pull them aft clear of the engine baffle.

WARNING

These magnetos DO NOT have internal grounding springs. Ground the magneto points to prevent accidental firing.

- e. Drain the engine oil.
- f. Remove propeller. (See paragraph 14-7.)
- g. Disconnect the induction air control, the throttle control, the mixture control, and the propeller governor control.
- h. Disconnect wires and cables as follows:
 1. Disconnect oil temperature connector located directly below oil cooler.
 2. Disconnect tachometer drive from adapter.
 3. Disconnect starter cable.
 4. Disconnect cylinder head temperature bulb lead. (See paragraph 12-6 for location on the different models.)
 5. Disconnect alternator cable and cable shielding ground.
 6. Disconnect the throttle microswitch(es).
 7. Remove all clamps attaching wires or cables to the engine. Pull all wires and cables aft to clear the engine assembly.
- i. Disconnect lines and hoses as follows:
 1. Disconnect hydraulic lines at the hydraulic pump. (Model 210 Series).
 2. Disconnect vacuum line at the vacuum pump.
 3. Disconnect the manifold pressure line.
 4. Disconnect the fuel supply line and the vapor return line at the fuel pump.
 5. Disconnect the fuel pressure line at the fuel manifold valve.
 6. Disconnect oil pressure line at the engine.
 7. Disconnect and remove the left and right manifold drain lines and the balance tube drain.

- j. Remove clamps securing the induction air control, the throttle control, the mixture control, and the propeller governor control. Pull these controls free of the engine, using care not to damage them by bending too sharply.

- k. Disconnect the flexible ducting.

- l. Disassemble and remove the right and left exhaust stack assemblies.

- m. Attach a hoist to the lifting eye at the top center of the engine crankcase. Lift the engine just enough to relieve the weight from the engine mounts.

CAUTION

Place a stand under the tail tie-down ring before removing the engine. The loss of engine weight will allow the tail to drop.

- n. Remove the engine as follows:
 1. Remove bolts and ground strap.
 2. Hoist engine out of nacelle and clear of aircraft.

CAUTION

Hoist engine slowly and make sure all wires, lines, and hoses have been disconnected.

3. Remove mount pads, spacers, ground strap and pins. Before removing shock mounts, refer to figure 12-1.

12-9. INSPECTION AND REPAIR. For specific items to be inspected refer to engine manufacturer's manual.

- a. Inspect all hoses for internal swelling, chafing through protective plys, cuts and breaks. Replace any damaged or doubtful hoses.
- b. Inspect all fittings for thread damage.
- c. Visually inspect the engine for loose nuts, bolts, cracks, and fin damage.
- d. For major repairs refer to the manufacturer's overhaul and repair manual.

12-10. POWERPLANT BUILD-UP consists of the installation of parts, accessories and components to the basic engine to build up a powerplant unit ready for installation on the airplane. All safety wire, lockwashers, palnuts, elastic stop nuts, gaskets and rubber connections should be new parts.

12-11. ENGINE INSTALLATION.

- a. Hoist engine to a point just above the nacelle.
- b. Install engine on mount pads as follows:
 1. Install mount pads, spacers, pins, and ground strap on engine mount, positioning the shock mounts as noted in figure 12-1.
 2. Lower the engine slowly into place on the engine mounts.
 3. Torque the engine shock mount bolts to the value shown in figure 12-1. Bend tab washers.
 - c. Install the flexible ducting.
 - d. Route the propeller governor control cable along the inside of the left intake manifold and secure.

NOTE

ON ALL MODELS:

It is important that the correct engine mounts be installed in the correct positions. Install upper mounts with beveled edge at the top, except as noted below for turbocharged engines. Install lower mounts with beveled edge at the front, except as noted below for turbocharged engines. In addition, be sure that the two reinforced mounts are used at the upper, forward positions.

To determine which two of the eight mounts are the reinforced ones, use fingernail to feel whether moulded-in washer is present.

Torque bolts (1) to 300, +50, -00 lb-in.

ON TURBOCHARGED ENGINES:


Barrel nuts (9) are replaced with turbine support shafts at the right mounts of turbocharged engines.

Heat shields (10) replace heat deflectors (4) on turbocharged engines.

Install left, forward, lower mount with beveled edges at the front and at the top on turbocharged engines.

Approximately 45 early turbocharged engines were originally equipped with reinforced upper rear mounts with two bevels. These bevels are at the front and at the top. However, replacement upper rear mounts will not be reinforced and will have only one bevel, at the top.

If shock mounts will be re-used, mark each one so it will be reinstalled in exactly the same position. If new shock mounts will be installed, position them as noted above.



1. Bolt
2. Ground Strap
3. Tab Lockwasher
4. Heat Deflector
5. Lower Mount
6. Engine Mount Support
7. Spacer
8. Upper Mount
9. Barrel Nut
10. Heat Shield




Figure 12-1. Engine Mounts

- e. Connect lines and hoses as follows:
 1. Install and connect the hydraulic pump vent line. (Model 210 Series.)
 2. Install and connect the left and right manifold drain lines and the balance tube drain.
 3. Connect the oil pressure line at its fitting between No. 2 and 4 cylinders.

NOTE

Throughout the airplane fuel system, from the tanks to the engine-driven fuel pump, use Parker Sealube (or equivalent) as a thread lubricant or to seal a leaking connection. Apply sparingly to male fittings only, omitting the first two threads. Always be sure that a compound, the residue from a previously used compound, or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel soluble lubricant, such as engine lubricating oil, on the fitting threads. Do not use any other form of thread compound on the injection system fittings.

4. Connect the fuel flow gage line at the fuel manifold valve.
5. Connect the fuel supply line and the vapor return line at the fuel pump.
6. Connect the manifold pressure line.
7. Connect vacuum line at the vacuum pump.
8. Connect hydraulic lines at the hydraulic pump. See paragraph 5A-8. (Model 210 Series.)
- f. Connect wires and cables as follows:

WARNING

The magnetos DO NOT have internal grounding springs. If the magneto ground wires are not installed and the switch turned off, ground the magneto points to prevent accidental firing.

1. Connect the oil temperature connector located directly below the oil cooler.
2. Connect tachometer drive to adapter and torque to 100 lb-in.
3. Connect starter cable.
4. Connect cylinder head temperature bulb lead. (See paragraph 12-6 for location on the different models.)
5. Connect alternator wires and wire shielding ground.
6. Connect the throttle microswitch(es).
7. Install all clamps attaching wires or cables to engine.
- g. Install the right and left exhaust stack assemblies. Use all new gaskets regardless of apparent condition of old gaskets.
- h. Install the engine controls.
- i. Rig the engine controls in accordance with paragraph 12-50.
- j. Connect the battery ground cable.
- k. Make a magneto switch ground-out and continuity check. Connect the magneto primary wires to the magnetos.

WARNING

Be sure the magneto switch is OFF.

- l. Install propeller. (See Section 14.)
- m. Service the engine in accordance with the applicable instructions in Section 2.
- n. Inspect the engine installation.
- o. Perform engine run-up.

12-12. AIR INDUCTION SYSTEM.

12-13. Ram air enters the induction airbox at the upper left engine baffle and is ducted to the fuel-air control unit. An air filter is mounted between the airbox and the upper left engine baffle. On the Model 210 Series, a dual ram air source is provided through the addition of an air filter and an airbox at the upper right rear engine baffle. This additional airbox is attached to the left airbox assembly. An induction air door, located between the airbox intake and the fuel air-control unit, may be operated manually from the cabin to permit the selection of either cold or heated air. When the induction air door is closed, engine suction opens a spring-loaded door through which heated air is drawn from within the engine compartment. Also, on the Model 210 Series, the manually operated induction air door closes only the left induction air inlet. The spring-loaded door closes automatically, in the event of engine backfire, to prevent the backfire from discharging into the engine compartment, which would create a fire hazard. From the fuel air control unit, air is supplied to the cylinders through the manifold intake piping. Drains are provided in the left and right intake manifolds and balance tube. The balance tube connects the right and left intake manifold at the front of the engine.

12-14. REMOVAL OF AIR INTAKE BOX.

- a. Disconnect induction air control at control arm.
- b. Disconnect throttle switch(es).
- c. Remove induction air filter (right and left filter on Model 210 Series).
- d. Remove clamps attaching lines and wires to airbox.
- e. Remove bolts securing airbox to fuel-air control unit and remove airbox and gasket.

12-15. CLEANING AND INSPECTION OF AIR INTAKE BOX. Clean all metal parts with a suitable solvent. Inspect for cracks, dents, loose rivets, etc. Minor cracks may be stop-drilled. In case of continued or severe cracking, replace airbox.

12-16. INSTALLATION OF AIR INTAKE BOX.

- a. Place airbox and gasket in place on engine and fuel-air control unit.
- b. Install attaching bolts.
- c. Install clamps attaching lines and wires to airbox.
- d. Install air filter. (Right and left on 210 Series.)
- e. Rig induction air control in accordance with paragraph 12-51.
- f. Connect and adjust throttle switch(es).

12-17. ENGINE AIR FILTER. An induction air filter, mounted at the airbox intake, removes dust particles from the ram air by collecting them on oil-coated filtering units.

12-18. REMOVAL OF ENGINE AIR FILTER. The engine air filter is secured by four bolts at the upper left rear engine baffle. To remove the engine air filter, remove these four bolts. On the Model 210 Series a second air filter is mounted in the right induction airbox intake.

12-19. CLEANING OF ENGINE AIR FILTER. The filter should be serviced in accordance with instructions outlined in Section 2.

12-20. INSTALLATION OF ENGINE AIR FILTER. Place the engine air filter in position between the upper left rear engine baffle and the induction airbox intake. Make certain the gasket is in place between the filter and the airbox intake. Install the four bolts which secure the assembly. On the Model 210 Series an air filter is installed in the right induction airbox in the same manner as the left air filter.

12-21. ENGINE EXHAUST SYSTEM. The exhaust system consists of two exhaust stack assemblies, one for the left and one for the right bank of cylinders. Each cylinder has a riser pipe attached to the exhaust port. The three risers at each bank of cylinders are joined together into a collector pipe which connects to a muffler and tailpipe, forming an exhaust stack assembly. The center riser on each bank is detachable, but the front and aft risers are welded to the collector pipe. The left muffler is enclosed in a shroud which captures exhaust heat used to heat the airplane cabin.

12-22. REMOVAL OF ENGINE EXHAUST SYSTEM.

- a. Remove engine cowling for access.
- b. Disconnect ducts from heater shroud on left stack assembly.
- c. Disconnect tailpipe braces from shock mounts at firewall brackets.
- d. Remove nuts, springs, and bolts attaching tailpipe and muffler to collector pipe and remove muffler and tailpipe assembly.
- e. Remove nuts attaching exhaust stacks to the cylinders and remove exhaust stacks and gaskets.

12-23. INSPECTION of the exhaust system should be thorough because the cabin heating system uses air heated by the heat exchangers of the exhaust system. Since exhaust systems of this type are subject to burning, cracking, and general deterioration from alternate thermal stresses and vibration (comparable to those affecting automotive mufflers), inspection is important and should be accomplished every 100 hours of operation. In addition, an inspection

should be performed any time exhaust fumes are detected in the cabin.

a. Remove engine cowling, and loosen or remove heater shrouds so that ALL surfaces of the exhaust stack assembly can be visually inspected. Especially check the areas adjacent to welds. Look for exhaust deposits in surrounding areas, indicating that exhaust gas is escaping through a crack or hole.

b. Where part of the exhaust stack assembly is not accessible for a thorough visual inspection or is hidden by parts of non-removable shrouds, the following method is recommended.

1. Remove the exhaust stack assembly and heater shrouds.

2. Use rubber expansion plugs to seal openings.

3. Using a manometer or gage, apply approximately 1-1/2 psi (3 inches of mercury) air pressure while the stack assembly is submerged in water. Any leaks will appear as bubbles and can be readily detected.

4. It is recommended that any exhaust stacks found defective be replaced before the next flight.

5. If no defects are found, remove plugs and dry thoroughly with compressed air.

12-24. INSTALLATION OF ENGINE EXHAUST SYSTEM. When installing exhaust stacks, be sure there is one copper-asbestos gasket between each riser and its mounting pad on the cylinder. The tailpipes are secured at the lower end with a clamp, which is attached to shock mounts on the firewall brackets. Make certain that the clamp is tight around tailpipe and the shock mounts are in serviceable condition.

12-25. ENGINE BAFFLES.

12-26. The sheet metal baffles installed on the engine direct the flow of air around the cylinders and other engine components. These baffles incorporate rubber-asbestos composition seals at points of contact with the engine nacelle to help confine and direct the airflow to the desired area. It is very important to engine cooling that the baffles are installed correctly.

12-27. CLEANING AND INSPECTION OF ENGINE BAFFLES. The engine baffles should be cleaned with a suitable solvent to remove oil and dirt.

NOTE

The rubber-asbestos seals are oil and grease resistant but should not be soaked in solvents for long periods.

Inspect for cracks in the metal and for loose and/or torn seals. Replace defective parts.

12-28. FUEL INJECTION SYSTEM.

NOTE

Throughout the airplane fuel system, from the tanks to the engine-driven fuel pump, use Parker Sealube (or equivalent) as a thread lubricant or to seal a leaking connection. Apply sparingly to male fittings only, omitting the first two threads. Always be sure that a compound, the residue from a previously used compound, or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel soluble lubricant, such as engine lubricating oil, on the fitting threads. Do not use any other form of thread compound on the injection system fittings.

12-29. Fuel injection is standard equipment on all 200-Series aircraft. This fuel injection system is a simple, low pressure system of injecting fuel into the intake valve port in the cylinder head. It is a multi-nozzle, continuous-flow type which controls fuel flow to match engine airflow. Any change in throttle position, engine speed, or a combination of both, causes changes in fuel flow in the correct relation to engine airflow. A manual mixture control and a fuel flow indicator are provided for leaning at any combination of altitude and power setting. The fuel flow meter is calibrated in gallons per hour and indicates approximately the gallons of fuel consumed each hour. The continuous flow system uses a typical rotary vane fuel pump. There are no running parts in this system except for the engine-driven fuel pump.

12-30. FUEL-AIR CONTROL UNIT. This unit occupies the position ordinarily used for a carburetor, at the intake manifold inlet. The function of this unit is to control engine air intake and to set the metered fuel pressure for proper fuel-air ratio. There are three control elements in this unit, one for air and two for fuel. One of the fuel control elements is for fuel mixture and the other is for fuel metering. Fuel enters the control unit through a strainer and passes to the metering valve. The position of the metering valve controls this fuel passed to the manifold valve and nozzles. A linkage connecting the metering valve to the air throttle proportions airflow to fuel flow. The position of the mixture valve determines the amount of fuel returned to the fuel pump. The fuel control portion of the fuel-air control unit is enclosed in a shroud and is blast-air cooled to help prevent vapor lock.

12-31. REMOVAL OF FUEL-AIR CONTROL UNIT.

- a. Remove the air intake box and air filter(s) and disconnect mixture and throttle control rod ends at fuel-air control unit.

NOTE

Cap all disconnected hoses, lines, and fittings.

- b. The three fuel lines which attach to the fuel control unit are routed inside flexible tubing to help cool the fuel. Loosen the tubing clamps at the fuel control unit and slide the tubing back to gain access to the fuel line fittings.

- c. Disconnect the fuel lines at the fuel control unit.
- d. Loosen the hose clamps which secure the fuel-air control unit to the right and left intake manifolds.
- e. Remove the fuel-air control unit.
- f. Cover the open ends of the intake manifold piping to prevent the entry of foreign matter.

12-32. CLEANING AND INSPECTION OF FUEL-AIR CONTROL UNIT.

- a. Check control connections, levers, and linkages for security, safetying, and for lost motion due to wear.
- b. Remove the fuel screen assembly and clean in fresh cleaning solvent. Reinstall and safety.
- c. Check the air control body for cracks and the fuel-air control unit for overall condition.

12-33. INSTALLATION OF FUEL-AIR CONTROL UNIT.

- a. Place the fuel-air control unit in position on the engine.
- b. Before tightening the hose clamps which secure the fuel-air control unit to the intake manifold, temporarily bolt the fuel-air control unit to the fuel-air control unit support to obtain the correct position.
- c. Connect the fuel lines at the fuel-air unit.
- d. Install the air tubes on the fuel control shroud and secure with clamps.
- e. Install the induction airbox and clean filter.
- f. Rig the engine controls in accordance with paragraph 12-50 thru 12-55.

12-34. FUEL-AIR CONTROL UNIT ADJUSTMENTS.

The idle speed adjustment is a conventional spring-loaded screw located in the air throttle lever. The idle mixture adjustment is the locknut at the metering valve end of the linkage. Tightening the nut to shorten the linkage provides a richer mixture. A leaner mixture is obtained by backing off the nut to lengthen the linkage. Adjust mixture control to obtain a slight and momentary gain of 25 rpm maximum at 1000 rpm engine speed as mixture control is moved slowly from full "RICH" toward idle cut-off. If mixture is set too "LEAN," engine speed will drop immediately, thus requiring enrichment. If mixture is set too "RICH," engine speed will increase above 25 rpm, thus requiring leaning. Idle speed is approximately 600 rpm.

12-35. FUEL MANIFOLD VALVE (FUEL DISTRIBUTOR). Metered fuel flows to the fuel manifold valve, which provides a central point for distributing fuel to individual cylinders. An internal diaphragm, operated by fuel pressure, raises or lowers a plunger to open and close the individual cylinder supply ports simultaneously. A needle valve in the plunger insures that the plunger fully opens the outlet ports before fuel flow starts, and closes the ports simultaneously for positive engine shut-down. A fine-mesh screen is included in the fuel manifold valve.




Figure 12-2. Fuel Injection Schematic

12-36. REMOVAL OF FUEL MANIFOLD.

NOTE

Cap all disconnected lines, hoses, and fittings.

- a. Disconnect the fuel lines and the six fuel injection lines at the fuel manifold.
- b. Remove the two crankcase bolts which secure the fuel manifold and remove the fuel manifold.

12-37. CLEANING FUEL MANIFOLD VALVE.

- a. Remove fuel manifold valve from engine and remove safety wire from cover attaching screws.
- b. Hold the top cover down against internal spring until all four cover attaching screws have been removed, then gently lift off the cover. Use care not to damage the spring-loaded diaphragm below cover.
- c. Remove the upper spring and lift the diaphragm assembly straight up.

NOTE

If the valve attached to the diaphragm is stuck in the bore of the body, grasp the center nut and rotate and lift at the same time to work gently out of the body.

CAUTION

Do not attempt to remove needle or spring from inside plunger valve. Removal of these items from the valve will disturb the calibration of the valve.

- d. Using clean gasoline, flush out the chamber below the screen.
- e. Flush above the screen and inside the center bore making sure that outlet passages are open. Use only a gentle stream of compressed air to remove dust and dirt and to dry.

CAUTION

The filter screen is a tight fit in the body and may be damaged if removal is attempted. It should be removed only if a new screen is to be installed.

- f. Clean diaphragm and valve and top cover in the same manner. Be sure the vent hole in the top cover is open and clean.
- g. Carefully replace diaphragm and valve. Check that valve works freely in body bore.
- h. Position diaphragm so that horizontal hole in




Figure 12-3. Idle Adjustments

plunger valve is 90 degrees from the fuel inlet port in the valve body.

- i. Place upper spring in position on diaphragm.
- j. Place cover in position so that vent hole in cover is 90 degrees from inlet port in valve body. Install cover attaching screws and tighten to 20±1 lb-in. Install safety wire on cover screws.
- k. Install fuel manifold valve assembly on engine and reconnect all lines and hoses to valve.
- l. Inspect installation and install cowling.

12-38. INSTALLATION OF FUEL MANIFOLD.

- a. Secure the fuel manifold to the crankcase with two crankcase bolts.
- b. Connect the fuel lines and the six fuel injection lines. Inspect completed installation.

12-39. **FUEL DISCHARGE NOZZLES.** From the fuel manifold valve, individual, identical size and length fuel lines carry metered fuel to the fuel discharge nozzles located in the cylinder heads. The outlet of each nozzle is directed into the intake port of each cylinder. An air bleed, incorporated into each nozzle, aids in vaporizing the fuel by breaking the high vacuum in the intake manifold at idle rpm and keeps the fuel lines filled. The nozzles are calibrated in several ranges. All nozzles furnished for one engine are the same range and are identified by a number and a suffix letter stamped on the flat portion of the nozzle body. When replacing a fuel discharge nozzle be sure that it is of the same calibrated range as the rest of the nozzles in the engine. When a complete set of nozzles is being replaced, the number must be the same as the one removed, but the suffix letters may be different, as long as they are the same for all nozzles being installed on a particular engine.

12-40. REMOVAL OF FUEL DISCHARGE NOZZLES.

NOTE

Plug or cap all disconnected lines and fittings.

- a. Disconnect the fuel injection lines at the fuel discharge nozzles. Remove the nozzles with a 1/2 inch deep socket.

12-41. **CLEANING AND INSPECTION OF FUEL DISCHARGE NOZZLES.** To clean nozzles, immerse in clean solvent and use compressed air to dry them. When cleaning the nozzle with compressed air, direct air through the nozzle in the direction opposite of normal fuel flow. Do not remove the nozzle shield or distort it in any way. Do not use a wire or other metal object to clean the orifice or metering jet. After cleaning, check the shield height from the hex portion of the nozzle. The bottom of the shield should be approximately 1/16 inch above the wrench pads on the nozzle.

12-42. INSTALLATION OF FUEL DISCHARGE NOZZLES.

- a. Install the fuel discharge nozzles in the cylinders using a 1/2 inch deep socket, and tighten nozzle to a torque value of 60-80 lb-in.

- b. Connect the fuel injection lines at the fuel discharge nozzles.
- c. Check installation for crimped lines, loose fittings, etc.

12-43. **FUEL INJECTION PUMP.** The fuel pump is a positive-displacement, rotating vane type. The pump is connected to the accessory drive section of the engine. Fuel enters the pump at the swirl well of the vapor separator. Here, vapor is separated by a swirling motion so that only liquid fuel is fed to the pump. The vapor is drawn from the top center of the swirl well by a small pressure jet of fuel and is fed into the vapor return line and returned to the fuel tank. Since the pump is engine-driven, changes in engine speed affect total pump flow proportionally. The pump supplies more fuel than is required by the engine; therefore, a relief valve is provided to maintain a constant fuel pump pressure. A check valve allows auxiliary fuel pump pressure to bypass the engine-driven fuel pump for starting, or in the event of engine-driven pump failure. The fuel pump is ram-air cooled to help prevent high fuel temperatures. The ram air is picked up at the upper left engine baffle and directed through a flexible tube to the fuel pump shroud. The fuel supply and return lines from the fuel pump to the control unit are routed inside flexible tubes to help prevent vaporized fuel at these points.

12-44. REMOVAL OF FUEL INJECTION PUMP.

Place the fuel tank selector valve OFF. Place the mixture control in idle cut-off. The fuel pump is enclosed in a shroud and is ram-air cooled to help prevent high fuel temperatures. The ram air is picked up at the upper left engine baffle and directed through a flexible tube to the fuel pump shroud. The fuel supply and return lines from the fuel pump to the fuel control unit are routed inside flexible tubes. Loosen the clamps and slide the flexible tubes free of the horns on the fuel pump shroud to gain access to the fuel lines.

- a. Remove the alternator drive belt.
- b. Tag and disconnect all lines and fittings attached to the fuel pump.

NOTE

Plug or cap all disconnected lines, hoses, and fittings.

- c. Remove the shroud surrounding the fuel pump.
- d. Remove the nuts and washers attaching the fuel pump to the engine.
- e. Remove fuel pump and gasket.

WARNING

Residual fuel draining from lines and hoses is a fire hazard. Use care to prevent accumulation of such fuel when lines and/or hoses are disconnected.

- f. If a replacement pump is not being installed immediately, a temporary cover should be installed on the fuel pump mount pad.

12-45. INSTALLATION OF FUEL INJECTION PUMP.

- a. Position a new gasket and fuel pump on the mounting studs with fuel pump inlet to the left. Be sure pump drive aligns with drive in the engine.
- b. Secure pump to engine with plain washers, internal tooth lock washers, and nuts. Tighten nuts evenly.
- c. Install cooling shroud on fuel pump.
- d. Install all fittings and connect all lines.
- e. Install the flexible ram air tube on the air horn of the fuel pump shroud and install clamp.
- f. Replace the alternator drive belt and tighten the nut on the adjusting arm so that the drive belt has proper tension.
- g. Inspect complete installation.

12-46. ADJUSTMENTS. During the 1967 model year an adjustable orifice is added to the engine-driven fuel pump so that the pressures for the full throttle position may be obtained. This adjustable orifice allows the exact desired pressure setting and will eliminate changing of fixed orifice to get the pressure required. The adjustable orifice applies only to the full throttle setting. Adjustment of the idle position is still obtained through the relief valve. This new pump is used as spare parts and is furnished if a new pump is ordered. Adjustment of pump not incorporating the adjustable orifice is still performed as outlined in Cessna Service Kit No. 320-2, using the pressures outlined in paragraph 12-6 of this Manual. To adjust the pump incorporating the adjustable orifice to the pressures shown in paragraph 12-6, proceed as follows:

- a. Adjust engine idle speed to 600 ± 25 rpm using idle speed adjustment on the air throttle with mixture control in full rich position.
- b. Set the fuel pump relief valve adjustment, on the centerline of the fuel pump, to within the specified limits by adjusting the screw clockwise to raise the pressure and counterclockwise to lower the pressure.
- c. After adjusting the idle unmetered pressure within the specified limits, check the idle mixture by advancing the throttle to approximately 800 rpm. Engine speed should increase approximately 25-50 rpm when mixture control is moved toward the lean position.
- d. Advance the throttle to maximum engine speed with the mixture control in full rich position. The unmetered fuel pressure should be within the specified limits.
- e. To increase the unmetered fuel pressure, loosen locknut and turn the slotheaded needle valve, located just below the fuel pump inlet fitting, in clockwise direction, and to reduce the pressure turn in a counterclockwise direction.

NOTE

Cessna Service Kit No. 320-2 provides a special indicator, lines, and instructions for connecting indicator to perform accurate calibration of the engine-driven fuel pump.

12-47. ENGINE COWL FLAPS. Cowl flaps are provided as a means of controlling engine temperature. Two cowl flaps, operated by a single control in the

cabin, are located at the lower aft end of the engine nacelle. Engine exhaust stacks extend through cut-outs in the aft portion of the cowl flaps.

12-48. RIGGING ENGINE COWL FLAPS.

- a. Disconnect cowl flap control clevises from cowl flaps.
- b. Check to make sure that the flexible controls reach their internal stops in each direction. Mark controls so that full control travel can be readily checked and maintained during the remaining rigging procedure.
- c. Place cowl flap control lever in the CLOSED position, which is the bottom hole in the bracket (figure 12-4). If control lever cannot be placed in correct hole in bracket, loosen clamp at upper end of controls and slip housings in clamp or adjust controls at upper clevis to position control lever in correct hole in bracket.
- d. Hold one cowl flap closed snugly and adjust clevis at cowl flap until bolt can be installed. Repeat for other cowl flap. If either control needs to be lengthened or shortened, the lower clamp may be loosened and housing slipped in the clamp, or lower clevis may be adjusted. Maintain sufficient thread engagement of clevis.
- e. Check that locknuts are tight, clamps are secure, and all bolts and nuts are installed.

NOTE

Some airplanes are equipped with small rubber bumpers on the fuselage. Also, some cowl flaps are formed so only the aft corners contact the fuselage and some cowl flaps contact all the way across the trailing edge, except for cut-outs. In all cases, cowl flaps should close snugly and the flexible controls must reach their internal stops in each direction to assure full travel of the controls.

12-49. ENGINE CONTROLS. The propeller and mixture controls lock in any position desired. To move these controls, the spring-loaded buttons, one in the end of each control knob, must be depressed. When the button is released, the control is locked. These controls also have a vernier adjustment. Turning the control knob in either direction will change the control setting. The vernier is primarily for precision control setting. The throttle has neither a locking button nor a vernier adjustment, but contains a knurled friction knob which is rotated for more or less friction as desired. During the 1966 model-year, an additional "Palnut" type locknut was installed in back of the existing locknut at the engine end of the throttle, mixture, and propeller controls. The induction air control also has a locking button, but it does not have a vernier adjustment. Do not pull induction air control out of its housing while it is disconnected. To do so would permit intricate parts of the locking mechanism to fall out and possibly be lost.

Beginning with the 1968 models, the manual induction heat control is deleted from the instrument panel. The manual control is replaced by an automatic device. If the air filter should become clogged, suction







Figure 12-4. Cowl Flaps



MODEL 206 SERIES



MODEL 210 SERIES



NOTE

Use LOCTITE sealant Grade C (American Sealant Co., Hartford, Conn.) to bond screws (13) to attaching nuts and heads of the screws to actuator (8) after final adjustments have been made.

NOTE

Slotted and oversize holes are provided in microswitches and attaching brackets for adjustment. Extension tab (14) may be bent for additional adjustment, if necessary to obtain proper adjustment of switches (9 and 10), since they are attached with the same mounting screws. Identity of the gear warning and fuel pump switches (9 and 10) may be established by noting that the ground wire is always attached to the gear warning switch.

1. Throttle Shaft Lever Cam
2. Airbox Bracket
3. Microswitch Actuator
4. Electric Fuel Pump Microswitch
5. Mounting Screw
6. Throttle Shaft Lever Cam
7. Airbox Bracket

8. Microswitch Actuator
9. Landing Gear Warning Microswitch
10. Electric Fuel Pump Microswitch
11. Switch Mounting Bracket
12. Mounting Bracket Screw
13. Switch Mounting Screw
14. Microswitch Actuator Extension Tab

Figure 12-5. Rigging Throttle Microswitches

from the engine intake will open a spring-loaded door in the induction airbox. This permits the induction air to be drawn from within the engine compartment. This induction air is unfiltered air. Inspect alternate air spring-loaded door for freedom of operation and complete closing.

12-50. RIGGING PROCEDURES — ENGINE CONTROLS.

CAUTION

Some engine controls have a small retaining ring brazed (or attached with epoxy resin) in a groove .97 inch from the threaded end of the control. The purpose of these retaining rings is to prevent inadvertent withdrawal and possible damage to the knob end of the controls while jam nuts and rod ends are removed.

12-51. RIGGING INDUCTION AIR CONTROL.

- a. Push control full in. Pull it out approximately 1/8 inch for cushion on the Model 210 only.
- b. On the Model 210 only, shift the control housing in its clamp as necessary to place the air valve in the full closed position, with valve closing off alternate air source. Tighten clamp in this position.
- c. On the Model 206 Series, shift the control housing in its clamp as necessary to place the air valve inside the airbox in a horizontal position with the control lever against the stop. Tighten clamp in this position.
- d. Pull the control out and check that the air valve inside the airbox seats, opening the alternate air source or closing off the normal air source.
- e. Check that the bolt and nut at the air valve lever secure the control wire and that the bolt will swivel in the lever.
- f. Bend the wire tip 90° to prevent it from being withdrawn if the attaching nut should become loose.
- g. When installing a new control, it may be necessary to shorten the wire and/or control housing.

12-52. RIGGING PROPELLER GOVERNOR CONTROL. See Section 14.

12-53. RIGGING MIXTURE CONTROL.

- a. Push control full in, then pull it out approximately 1/8 inch for cushion.
- b. Check that mixture control arm is in full rich position. If necessary, loosen locknut and screw the rod end in or out until attaching bolt slides in easily.
- c. Pull mixture control full out (idle cut-off), remove bolt at rod end, and check that mixture arm is in full idle cut-off. Reinstall bolt.
- d. The mixture arm must reach mechanical stops in both positions and control should have approximately 1/8 inch cushion at the instrument panel.

12-54. RIGGING THROTTLE CONTROL.

- a. Push control full in, then pull it out approximately 1/8 inch for cushion.
- b. Check that throttle control arm is against the mechanical stop. If necessary, loosen locknut and screw rod end in or out until attaching bolt slides in easily.

c. Pull throttle control full out, remove bolt at rod end, and check that throttle arm contacts idle stop. Reinstall bolt.

d. Throttle arm must reach mechanical stops in both positions and control should have approximately 1/8 inch cushion at the instrument panel.

12-55. RIGGING THROTTLE MICROSWITCHES.

All Model 210-Series airplanes are equipped with one throttle microswitch which operates the landing gear warning system whenever the throttle is retarded while the gear is not down and locked. In addition, another throttle microswitch slows down the electric fuel pump whenever the throttle is retarded while the electric pump is being used. This fuel pump microswitch is also used on Model U206 and P206 Series airplanes. The landing gear warning microswitch should cause the horn to blow as the throttle is retarded to approximately 12 inches of mercury manifold pressure and the electric fuel pump microswitch should slow down the pump as the throttle is retarded to approximately 16 inches of mercury.

a. Start engine and set throttle to obtain 16 inches of mercury manifold pressure. Mark position of throttle control at instrument panel. On the Model 210 Series, continue to retard throttle to 12 inches of mercury manifold pressure and also mark this position. Shut down engine.

b. (Refer to figure 12-5.) On Model 206 Series aircraft, adjust microswitch at the engine throttle shaft lever as required to cause the electric fuel pump to slow down as the throttle is retarded to the marked position. With mixture control in IDLE CUT-OFF, electric fuel pump switch in HI, and master switch turned on, listen for change in sound of electric fuel pump as it slows down (16 ± 1 inches of mercury).

c. (Refer to figure 12-5.) On Model 210 Series aircraft, two microswitches are located at the engine throttle shaft lever. Both are actuated by a single actuator and both are attached with the same screws. Adjust the fuel pump microswitch to cause the electric fuel pump to slow down as the throttle is retarded to the first marked position (16 ± 1 inches of mercury). Adjust the landing gear warning horn microswitch to sound the warning horn as the throttle is retarded to the second marked position (12 ± .5 inches of mercury).

NOTE

Actuation of the fuel pump microswitch may be determined as outlined in step "b." Because the landing gear is down and locked, it will be necessary to keep the gear-down (green) indicator light depressed approximately half its travel distance, with master switch turned on, in order to determine when the gear warning microswitch actuates the warning horn system.

d. Perform flight test to check gear warning system on Model 210 Series at 2500 feet pressure altitude as follows:

1. Set propeller control at 2300 rpm.
2. Slowly reduce throttle until warning horn

blows, and note manifold pressure at which horn blows. Horn should blow between 11.5 and 12.5 inches of mercury manifold pressure.

3. If horn actuation does not fall within this tolerance, mark throttle at 12 inches of mercury manifold pressure for ground reference.

NOTE

After flight testing, if required results were not obtained, set throttle at the marked position and readjust microswitch to actuate horn at this setting. Recheck electric fuel pump microswitch setting. Repeat flight test until desired results are obtained.

12-56. STARTING SYSTEM.

12-57. The automatically engaged starting system employs an electric starter motor mounted to a 90-degree adapter. A starter solenoid is activated by the ignition key on the instrument panel. When the solenoid is activated, its contacts close and electrical current energizes the starter motor. Initial rotation of the starter motor engages the starter through an overrunning clutch in the starter adapter, which incorporates worm reduction gears. The starter is located just aft of the right rear cylinder.

12-58. REPLACEMENT OF STARTER.

- a. Disconnect electrical power lead from the starter. Insulate the disconnected terminal as a safety precaution.
- b. Remove the nuts securing the starter and remove the starter.
- c. To install the starter, reverse this procedure. Install a new O-ring on the starter, then install the starter. Be sure that starter drive engages with the drive in the starter adapter.

12-59. DELETED

12-60. STANDARD MAINTENANCE of starters includes replacing brushes and brush springs, cleaning dirty commutators and turning down burned or out-of-round commutators.

CAUTION

Never lubricate the commutator. Starter bearings are sealed and require no lubrication.

Starter brushes should be replaced when worn down to one-half their original length (compare with new ones). Brush spring tension should be sufficient to give brushes a good firm contact with the commutator. Brush leads should be unbroken, with their terminal screws tight. A glazed or dirty commutator can be cleaned by holding a strip of No. 00 sandpaper or brush seating stone against it. Move sandpaper or stone back and forth across the commutator to avoid wearing a groove. Do not use emery paper or carborundum because of their possible shorting action.

CAUTION

Never operate the cranking motor for more than 30 seconds at a time without allowing it to cool. Blow out all dust after the commutator is cleaned.

Roughness, out-of-roundness, or high mica may necessitate turning down the commutator. After the turning operation, the mica should be undercut.

12-61. DELETED

SHOP NOTES:

12-62. TROUBLE SHOOTING THE STARTER.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
STARTER WILL NOT OPERATE.		
Defective master switch or circuit.	Check master circuit.	Repair circuit.
Defective starter switch or switch circuit.	Check switch circuit continuity.	Replace switch or wires.
Defective starter.	Check through items above. If another cause is not apparent starter is defective.	Remove and repair or replace starter.
STARTER MOTOR RUNS, BUT DOES NOT TURN CRANKSHAFT.		
Defective overrunning clutch or drive.	Remove starter and check starter drive and overrunning clutch.	Replace defective parts.
Damaged starter pinion gear or crankshaft gear.	Remove starter and check pinion gear and crankshaft gear.	Replace defective parts.
STARTER DRAGS.		
Low battery.	Check battery.	Charge or replace battery.
Starter switch or re-lay contacts burned or dirty.		Replace with serviceable unit.
Defective starter power cable.	Check cable.	Replace cable.
Defective starter.	Check starter brushes, brush spring tension, thrown solder on brush cover.	Repair or replace starter.
Dirty, worn commutator.	Clean, check visually.	Turn down commutator.
STARTER EXCESSIVELY NOISY.		
Worn starter pinion.	Remove and examine pinion.	Replace starter drive.
Worn or broken teeth on crankshaft gears.	Remove starter and turn over engine by hand to examine crankshaft gear.	Replace crankshaft gear.

12-63. SLICK MAGNETOS.

NOTE

A spark plug that is kept clean and properly gapped will give better and longer service than one that is allowed to collect lead deposits and is improperly gapped. The proper gap setting is given in paragraph 12-6. At each 100-hour inspection, remove, clean, inspect, and re-gap all spark plugs. Install lower plugs in upper portion of cylinder and vice-versa. Since deterioration of lower spark plugs is usually more rapid than that of the upper spark plugs, rotating them helps prolong spark plug life.

12-64. Slick magnetos contain a conventional two-pole rotating magnet (rotor), mounted in ball bearings. Driven by the engine through an impulse coupling at one end, the rotor shaft operates the breaker points at the other end. The nylon rotor gear drives a nylon distributor gear which transfers high tension current from the wedge-mounted coil to the proper outlet in the distributor block. A coaxial capacitor is mounted in the distributor block housing to serve as the condenser as well as a radio noise suppressor. Both nylon gears are provided with timing marks for clockwise or counterclockwise rotation, and the distributor gear and distributor block have timing marks, visible through the air vent holes, for timing to the engine. A timing hole is provided in the bottom of the magneto adjacent to the magneto flange. A timing pin or 6-penny nail can be inserted through this timing hole into the mating hole in the rotor shaft to lock the magneto approximately in the proper firing position. The breaker assembly is accessible after removing the screws fastening the magneto halves together and disconnecting capacitor slip terminal.

12-65. REMOVAL. When removal of the complete magneto is desired, remove the spark plug leads from the magneto and tag them for identification, disconnect the capacitor lead, and remove the nuts securing the magneto to the engine. For replacement of the breaker assembly or where removal of only the aft (engine) half of the magneto is desired, remove the screws fastening the halves together, pull the front half forward only far enough to disconnect the capacitor slip terminal, and remove the nuts securing the magneto to the engine. As the halves are separated, be sure that the large distributor gear is not dropped.

CAUTION

When removing the distributor block housing from the aft case, do not pull it away far enough to break or damage the capacitor lead or slip terminal.

12-66. INTERNAL TIMING.

a. Whenever the nylon gear on the rotor shaft or the plastic cam (which also serves as the key for the gear) has been removed, be sure that the gear and cam are installed so the timing mark on the gear

aligns with the "O" stamped on the rotor shaft.

b. When replacing breaker assembly or adjusting contact points, place a timing pin (or .093" 6-penny nail) through the timing hole in the bottom of the magneto next to the flange and into the mating hole in the rotor shaft. Adjust contact points so they just break in this position, with a maximum point opening of 0.008 to 0.012 inch when the timing pin is removed. Temporarily assemble the magneto halves and capacitor slip terminal, and use a timing light to check that the timing mark, visible through the ventilating plug holes, are aligned at the instant the contact points break. Readjust the points if necessary.

NOTE

The side of the magneto with the manufacturer's insignia has a red timing mark and the side opposite the insignia has a black timing mark. The distributor gear also has a red timing mark and a black timing mark. The contact points should break when the two red lines are aligned at the insignia side of the magneto, or, when the two black lines are aligned at the opposite side of the magneto. Do not time with red and black lines together on the same side.

c. Whenever the large distributor gear and the rotor gear have been disengaged, they must be re-engaged with their timing marks aligned for the correct rotation. Align the timing mark on the rotor gear with "RH" on the distributor gear. Care must be taken to keep these two gears meshed in this position until the magneto halves are assembled.

12-67. INSTALLATION AND TIMING TO THE ENGINE. To install and time the magneto to the engine proceed as follows:

a. Turn the propeller in normal direction of rotation until No. 1 cylinder is in correct firing position on compression stroke.

NOTE

IO-520 Series engines have degrees marked on a bracket attached to the starter adapter, with a timing mark on the alternator drive pulley as the reference point.

b. Turn the magneto shaft until the timing marks visible through the ventilation plug holes are aligned (red-to-red or black-to-black) and insert a timing pin (or .093" 6-penny nail) through the timing hole in the bottom of the magneto next to the flange and into the mating hole in the rotor shaft. This locks the magneto approximately in firing position while installing on the engine.

c. After magneto gasket is in place, position the magneto on the engine and secure, then remove the timing pin from the magneto. Be sure to remove this pin before turning the propeller.

d. Connect a timing light to the capacitor terminal at the front of the magneto and to a good ground.

e. Turn propeller back a few degrees to close the contact points.




Figure 12-6. Ignition Schematic

NOTE

Do not turn the propeller back far enough to engage the impulse coupling or the propeller will have to be turned in normal direction of rotation until the impulse coupling releases, then backed up to slightly before the firing position.

f. Slowly advance the propeller in normal direction of rotation until timing light indicates the position of contact point breaking. Magneto mounting clamps may be loosened so that the magneto may be shifted to break the points at the correct firing position.

g. Tighten magneto mounting nuts, recheck timing, then remove timing light.

h. Connect spark plug leads to their correct magneto outlets.

NOTE

The No. 1 magneto outlet is the one closest to the ventilation plug on the side of the magneto having the manufacturer's insignia. The magneto fires at each successive outlet in clockwise direction. Connect No. 1 magneto outlet to No. 1 cylinder spark plug lead, No. 2 outlet to the next cylinder to fire, etc. Engine firing order is listed in paragraph 12-6.

i. Connect ignition switch primary lead to the capacitor terminal on the magneto.

12-68. MAINTENANCE. Magneto-to-engine timing should be checked with a timing light every 200 hours. If timing is off more than 1° in either direction, the magneto should be retimed to the engine. The magneto mounting clamps may be loosened for this purpose. If the internal timing marks visible through the ventilation plug holes on the sides of the magneto are misaligned more than $1/16''$ when the magneto fires, the magneto should be retimed internally. Whenever the magneto halves are separated, the breaker assembly should always be checked. As long as internal timing and magneto-to-engine timing are within the preceding tolerances, it is recommended that the magneto be checked internally only at 500-hour intervals.

NOTE

If ignition trouble should develop, spark plugs and ignition wiring should be checked first. If the trouble appears definitely to be associated with a magneto, the following may be used to help disclose the source of trouble without overhauling the magneto.

a. Moisture Check.

(1) Remove screws securing magneto halves together, disconnect capacitor slip terminal, remove

distributor cap, and inspect for moisture.

(2) Check distributor gear finger and carbon brush for moisture.

(3) Check breaker assembly for moisture, especially on contact points.

(4) If any moisture is evident, lightly wipe with a soft, dry, clean, lint-free cloth.

b. Breaker Compartment Check.

(1) Check all parts of the breaker assembly for security.

(2) Check contact points for absence of excessive wear, burning, deep pits, and carbon deposits.

Points may be cleaned with a hard-finish paper.

Replace defective breaker assemblies. Make no attempt to stone or dress contact points. Clean new points with oleum spirits before installing.

(3) Check cam oiler pad. If dry, apply 2 or 3 drops of SAE 70 oil to the pad. Remove any excessive oil from breaker assembly. Too much oil may result in fouling and excessive burning of points. The corner of the cam oiler pad should touch the cam lobe lightly.

(4) Check the capacitor.

(5) Check the carbon brush on the distributor gear for excessive wear. The brush must extend a minimum of $1/32''$ beyond the end of the gear shaft. The spring which the brush contacts should be bent out approximately 20° from vertical, since spring pressure on the brush holds the distributor gear shaft against the thrust bearing in the distributor cap.

(6) Oil the bearings at each end of the distributor gear shaft with a drop of SAE 20 oil. Wipe off excess.

(7) Make sure internal timing is correct and reassemble the magneto. If removed from the engine, install and time properly.

12-69. OIL SYSTEM.

12-70. Wet sump, pressure-lubricating oil systems are employed in the engines used on the 200 Series. In these engines, oil under pressure from the oil pump is fed through drilled crankcase passages which supply oil to the crankshaft main bearings and camshaft bearings. Connecting rod bearings are pressure lubricated through internal passages in the crankshaft. Valve mechanisms are lubricated through the hollow push-rods, which are supplied with oil from the crankcase oil passages. Oil is returned by gravity to the engine oil sump. Cylinder walls and piston pins are spray-lubricated by oil escaping from connecting rod bearings. The engines are equipped with an oil cooler and conventional vernatherm-controlled oil temperature regulation. A pressure relief valve is installed to maintain proper oil pressure at higher engine speeds. Removable oil filter screens are provided within oil systems. External, replaceable element oil filters and non-congealing oil coolers are optional equipment.




Figure 12-7. Oil System Schematic

12-71. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
NO OIL PRESSURE.		
No oil in sump.	Check with dipstick.	Fill sump with proper grade and amount of oil.
Oil pressure line broken, disconnected, or pinched.	Inspect oil pressure line.	Replace or connect.
Oil pump defective.	Remove and inspect.	Examine engine. Metal particles from damaged pump may have entered engine oil passages.
Defective oil pressure gage.	Check with another gage. If second reading is normal, air-plane gage is defective.	Replace gage.
Oil congealed in gage line.	Disconnect line at engine and gage. Flush with kerosene.	Pre-fill with kerosene and install.
Relief valve defective.	Remove and check for dirty or defective parts.	Clean and reinstall. Replace if defective.
HIGH OIL TEMPERATURE.		
Oil cooler thermo bypass valve defective.	Feel front of cooler core with hand. If core is cold, oil is bypassing cooler.	Replace thermo bypass valve.
Oil cooler air passages clogged.	Inspect cooler core.	Clean air passages.
Oil cooler oil passages clogged.	Attempt to drain cooler. Inspect any drainings for sediment.	Clean oil passages.
Oil congealed in oil cooler.	This condition can only occur in extremely cold temperatures.	If congealing is suspected, use external heater or a heated hangar to thaw the congealed oil.
Secondary effect of low oil pressure.	Observe oil pressure gage for low indication.	Determine and correct reason for low oil pressure.
Defective oil temperature gage.	Check with another gage. If second reading is normal, air-plane gage is defective.	Replace gage.
Defective oil temperature bulb.	Check for correct oil pressure, oil level and cylinder head temperature. If they are not correct, check oil temperature gage for being defective; if a similar reading is observed, bulb is defective.	Replace temperature bulb.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
LOW OIL TEMPERATURE.		
Defective oil temperature bulb or gage.	Check with another gage. If reading is normal, airplane gage is defective. If reading is similar, temperature bulb is defective.	Replace defective part.
Oil cooler thermo bypass valve defective or stuck closed.	Remove valve and check for proper operation.	Replace thermo bypass valve.
LOW OIL PRESSURE.		
Low viscosity oil.		Drain oil and refill sump with proper grade of oil.
Low oil level.	Check with dipstick.	Fill sump to proper level with proper grade of oil.
Oil pressure relief valve spring weak or broken.	Remove and check spring.	Replace weak or broken spring.
Defective oil pump.	Check oil temperature and oil level. If temperature is higher than normal and oil level is correct, internal failure is evident.	Examine engine. Metal particles from damaged oil pump may have entered engine oil passages.
Secondary result of high oil temperature.	Observe oil temperature gage for high indication.	Determine and correct reason for high oil temperature.
HIGH OIL PRESSURE.		
High viscosity oil.		Drain oil and refill sump with proper grade and amount of oil.
Relief valve defective.	Remove and check for dirty or defective parts.	Clean and reinstall. Replace if defective.
Defective oil pressure gage.	Check oil pressure with another gage. If second gage gives a normal reading, airplane gage is defective.	Replace oil pressure gage.

12-72. **FULL-FLOW OIL FILTER.** An optional external oil filter may be installed on these airplanes. The filter and filter adapter replace the regular engine oil filter screen. In some filter installations, the filter adapter incorporates a bypass valve, outlet valve, and isolation valve. Normally, oil from the oil pump flows through the isolation valve, through the filter element, through the outlet valve, to the engine oil passages. If the filter element should become blocked, the bypass valve will open, allowing oil to flow to the engine oil passages. The isolation valve blocks off the filter assembly, and oil then flows through the bypass valve, if excessive oil pressure should occur. In some filter installations the filter adapter incorporates only a bypass valve. This

type adapter is the latest and is also available for all earlier aircraft. Refer to note on figure 12-8.

12-73. **FILTER ELEMENT REPLACEMENT.** (See figure 12-8.)

NOTE

Filter element replacement kits are available from the Cessna Service Parts Center.

- Remove engine cowling as necessary for access.
- Remove both safety wires from filter can and unscrew hollow stud (23) to detach filter assembly from adapter (5) as a unit. Remove from the airplane, discarding gasket (13).

- c. Press downward on stud (23) to remove.
- d. Lift lid (16) off filter can, discarding gasket (17).
- e. Pull filter element out of can and discard.
- f. Wipe parts clean with a soft cloth.

NOTE

When installing a new filter element, it is important that all gaskets are clean, lubricated, and positioned properly, and that the correct amount of torque is applied to filter attaching stud. If the stud is under-torqued, oil leakage will occur. If the stud is over-torqued, filter can may be deformed, again causing oil leakage.

Lubricate rubber grommets in new filter element, rubber gaskets (13) and (17) and metal gasket (22) with clean engine oil or general purpose grease before installation. Dry gaskets may cause false torque readings, again resulting in oil leakage.

Before assembly, place a straightedge across bottom of filter can. Check for a distortion or out-of-flat condition greater than .010 inch. Replace if either of these conditions exist.

Before assembly, cut adapter nut safety wire and try to rotate adapter by hand. If adapter can be moved, check for thread deformation in engine and adapter.

After installing a new gasket on lid (16), turn it upside down. If gasket falls, replace gasket and repeat test. If this gasket falls off, replace lid.

g. Inspect adapter gasket seat for gouges, deep scratches, wrench marks, and mutilation. If any of these are found, replace adapter.

h. Place new element in can, and insert stud (23) with new metal gasket (22) in place, through the can and element.

i. Position new gasket (17) inside lower flange of lid (16). Position new gasket (13) around upper flange of lid (16). Place the lid in position.

j. Install filter assembly on adapter. Holding can to prevent it from turning, tighten stud (23) and torque to 20-25 lb-ft, using a torque wrench.

k. Reinstall parts removed for access, and service the engine with proper grade and quantity of oil. One

additional quart of oil is required each time the element is replaced.

l. Start engine and check for proper oil pressure. Check for leaks after warming up engine.

m. Again check for leaks after engine has been run at a high power setting (preferably a flight around the field).

n. Check to make sure filter has not been making contact with adjacent parts due to engine torque.

o. While engine is still warm, recheck torque on stud (23), then safety stud to lower bracket (21) on filter can, and safety adapter to upper bracket (20) on filter can.

12-74. FILTER ADAPTER REMOVAL. (See figure 12-8.)

a. Remove filter assembly as outlined during element replacement.

b. Note angular position of adapter, then remove safety wire and loosen adapter nut (2).

NOTE

A special wrench adapter for adapter nut (2) (Part No. SE-709) is available from the Cessna Service Parts Center, or one may be made as shown in figure 12-9. Remove any engine accessory that interferes with removal of the adapter.

c. Unscrew adapter and remove from engine.

12-75. DISASSEMBLY, REPAIR, AND ASSEMBLY OF FILTER ADAPTER. Figure 12-8 shows the relative position of internal parts of the filter adapter and may be used as a guide during replacement of parts. The bypass and outlet valves are to be replaced as units, with the bypass valve being staked three places at installation. The detail parts which form the isolation valve may be replaced individually. Also use new seals, lubricate parts with engine oil, and replace any part that shows signs of excessive wear. Note that washer (6) is installed with its countersunk side toward outlet valve (3). Tighten plug (12) to a maximum of .40 inch as shown in figure 12-8. The heli-coil type insert (14) in the adapter may be replaced, although special tools are required. Follow instructions of the tool manufacturer for their use. If the isolation valve should become defective, remove plug (12) and parts (6 through 11). Weld shut vent hole in plug (12). Reinstall washer (6), sleeve (7), O-ring (8), and plug (12) in the adapter.

SHOP NOTES:




Figure 12-8. Full-Flow Oil Filter

12-76. FILTER ADAPTER INSTALLATION.

a. Assemble adapter nut and new O-ring on adapter in sequence illustrated. Lubricate O-ring with engine oil. Tighten adapter nut until O-ring is centered in groove.

b. Apply anti-seize compound sparingly to adapter threads, then simultaneously screw adapter and nut into engine until O-ring seats against engine without turning adapter nut. Rotate adapter to the approximate angular position noted during removal. Do not tighten nut at this time.

c. Temporarily install filter assembly on adapter, and position so adequate clearance with adjacent parts is attained. Maintaining this position of the adapter, tighten adapter nut to 50-60 lb-ft and safety. Use a torque wrench, extension and adapter as necessary.

d. Using new gaskets, install the filter assembly

as outlined during element replacement.

e. Be sure to service the engine oil system, perform the checks and inspections outlined, and re-safety all parts requiring safetying, as noted in paragraph 12-73.

f. Reinstall any component removed for access.

12-77. OIL COOLER. An optional non-congealing oil cooler may be installed. As noted in Section 12A, the non-congealing oil cooler is standard equipment on the turbocharged engines. Oil circulating through the engine is allowed to circulate continuously through warm-up passages to prevent the oil from congealing when operating in low temperatures. On the standard and non-congealing oil coolers, as the oil increases to a certain temperature, the thermostat valve closes, causing the oil to be routed to all of the cooler passages for cooling.




Figure 12-9. Wrench Adapter Fabrication

12-78. EXTREME WEATHER MAINTENANCE.

12-79. COLD WEATHER starting will be made easier by the installation of an optional oil dilution system and a ground service receptacle which permits quick connection of an external power source. After the last flight of the day, drain the engine oil into a clean retainer so the oil can be preheated. Cover the engine to prevent ice or snow from collecting inside the cowling. When preparing the aircraft for flight or engine run-up after these conditions have been followed, preheat the drained oil. After preheating the oil, gasoline may be mixed with the oil in a ratio of 1 part gasoline to 12 parts oil before pouring into the engine oil sump. If the free

air temperature is below -29°C (-20°F), the engine compartment should be preheated by a ground heater. After the engine compartment has been preheated, inspect all engine compartment drain and vent lines for presence of ice. After this procedure has been followed, pull the propeller through several revolutions by hand before starting the engine.

WARNING

Do not heat oil above 121°C (250°F). A flash fire may result. Before pulling propeller through, insure that magneto switch is in the OFF position to prevent engine from firing.

CAUTION

Due to the desludging effect of the diluted oil, engine operation should be observed closely during the initial warm-up of the engine. Engines that have a considerable amount of operational hours accumulated since their last dilution period may be seriously affected by the dilution process. This will be caused by the diluted oil dislodging sludge and carbon deposits within the engine. This residue will collect in the oil sump and possibly clog the screened inlet to the oil pump. Small deposits may actually enter the oil pump and be trapped by the main oil filter screen. Partial or, in some cases, complete loss of engine lubrication may result from either condition. If these conditions are anticipated after oil dilution, the engine should be run for several minutes at normal operating temperatures and then stopped and inspected for evidence of sludge and carbon deposits in the oil sump, oil cooler, and oil filter screen. Future occurrence of this condition can be prevented by diluting the oil prior to each oil change. This will prevent the build-up accumulation of the sludge and carbon deposits within the engine.

Winterization Kits are available for non-turbocharged engines only. The kits are essentially devices to restrict the entry of air through the front opening of the cowl, or to restrict the outlet of air at the rear opening of the cowl. All kits are designed for easy installation on the aircraft and should be used in accordance with instructions accompanying the kits.

An optional, manually operated priming system may be installed on 200-Series airplanes. The primer is located on the pedestal. Fuel to the primer pump is taken from the fuel strainer and is delivered to the aft end of each intake manifold, thus priming the entire length of the intake manifold for each bank of cylinders.

12-80. LOW BATTERY STARTING.

12-81. (Prior to 1967 Models.) If a ground service receptacle is installed, the use of an external power source is recommended for low battery starting. Before connecting a generator type external power source, it is important that the master switch be turned on. This will enable the battery to absorb transient voltages which otherwise might damage the semiconductors in the electronic equipment. When using a battery type external power source, the master switch should be turned off to prevent an unnecessary power drain from the power source batteries to the airplane's battery. Starting may also be accomplished by hand-cranking.

CAUTION

Be certain that the polarity of any external power source or batteries is correct (positive to positive and negative to negative). A polarity reversal will result in immediate damage to semiconductors in the airplane's electronic equipment.

12-81A. (1967 Models and on.) If a ground service receptacle is installed, the use of an external power source is recommended for cold weather starting and lengthy maintenance work on the airplane's electrical system with the exception of electronic equipment.

NOTE

Electrical power for the airplane's electrical circuits is provided through a split bus bar having all electronic circuits on one side of the bus and other electrical circuits on the other side of the bus. When an external power source is connected, a contactor automatically opens the circuit to the electronic portion of the bus bar as a protection against damage to the semiconductors in the electronic equipment by transient voltages from the power source. Therefore, the external power source cannot be used as a source of power when checking electronic components. Just before connecting an external power source (generator type or battery cart), the master switch should be turned ON.

The ground service plug receptacle circuit incorporates a polarity reversal protection. Power from the external power source will flow only if the ground service plug is correctly connected to the airplane. If the plug is accidentally connected backwards, no power will flow to the airplane's electrical system, thereby preventing any damage to electrical equipment.

The battery and external power circuits have been designed to completely eliminate the need to "jumper" across the battery contactors to close it for charging a completely "dead" battery. A special fused circuit in the external power system supplies the needed "jumper" across the contacts so that with a "dead" battery and an external power source applied, turning the master switch ON will close the battery contactor.

12-82. HAND-CRANKING. A normal hand-cranking procedure may be used to start the engine.

12-83. HOT WEATHER. Engine starting in hot weather or with a hot engine is sometimes hampered by vapor formation in the fuel lines. To purge the vapor, move the mixture control to full rich, open

If prolonged cranking is necessary, allow the starter motor to cool at frequent intervals, since excessive heat may damage the armature.

12-85. SEACOAST AREAS, HUMID AREAS. In salt water areas, special care should be given to keep the engine and engine accessories clean to prevent oxidation. Fuel and oil should be checked frequently and drained of condensed moisture in humid areas.

[illegible]

SECTION 12A

TURBOCHARGED POWERPLANT

TABLE OF CONTENTS	Page	
ENGINE COWLING	12A-1	Fuel Manifold (Fuel Distributor) 12A-25
Cleaning, Inspection and Repair	12A-1	Removal 12A-25
ENGINE	12A-1	Cleaning 12A-25
Engine Data	12A-2	Installation 12A-25
Trouble Shooting	12A-3	Fuel Discharge Nozzles 12A-25
Removal	12A-6	Removal 12A-25
Inspection and Repair	12A-6	Cleaning 12A-25
Powerplant Build-Up	12A-7	Installation 12A-25
Installation	12A-7	Fuel Injection Pump 12A-25
TURBOCHARGER	12A-7	Removal 12A-26
Removal and Installation	12A-10	Installation 12A-26
CONTROLLER AND WASTE-GATE		Adjustment 12A-26
ACTUATOR	12A-10	ENGINE COWL FLAPS 12A-26
Functions	12A-10	Rigging Cowl Flaps 12A-26
Operation	12A-10	ENGINE CONTROLS 12A-27
Trouble Shooting	12A-11	RIGGING PROCEDURES 12A-27
Controller and Turbocharger		Propeller Control 12A-27
Flight Check	12A-14	Mixture Control 12A-27
Removal and Installation of		Throttle Control 12A-27
Turbocharger Controller	12A-15	Throttle Control Microswitches 12A-27
Controller Adjustments	12A-15	STARTING SYSTEM 12A-27
Removal and Installation of Waste Gate		Replacement of Starter 12A-27
and Actuator	12A-16	Standard Maintenance 12A-27
Adjustment of Waste-Gate Actuator	12A-18	Trouble Shooting 12A-27
INDUCTION AIR SYSTEM	12A-18	MAGNETOS 12A-27
Removal and Installation of Ducting		OIL SYSTEM 12A-27
and Airbox	12A-19	Trouble Shooting 12A-29
Removal and Installation of Filter	12A-19	Full-Flow Oil Filter 12A-29
EXHAUST SYSTEM	12A-19	Filter Element Replacement 12A-29
Removal	12A-19	Filter Adapter Removal 12A-29
Inspection	12A-22	Disassembly, Repair, and Assembly of
Installation	12A-22	Filter Adapter 12A-29
ENGINE BAFFLES	12A-23	Filter Adapter Installation 12A-29
Cleaning and Inspection	12A-23	Oil Cooler 12A-29
FUEL INJECTION SYSTEM	12A-23	EXTREME WEATHER MAINTENANCE 12A-29
Fuel-Air Control Unit	12A-23	Cold Weather 12A-29
Removal	12A-23	Low Battery Starting 12A-29
Cleaning and Inspection	12A-25	Hand-Cranking 12A-29
Installation	12A-25	Hot Weather 12A-29
Fuel-Air Control Unit Adjustments	12A-25	Dusty Conditions 12A-29
		Sea Coast, Humid Areas 12A-29

12A-1. ENGINE COWLING.

12A-2. The engine cowling is similar to that described in Section 12, except it is wider at the front, with additional ram air openings in the right and left nose caps. The opening in the right side supplies ram air to the turbocharger. The opening in the left side supplies ram air to the cabin heating system. When removing the nose caps, remove clamps and disconnect the flexible ducts from the induction air and heater air inlet ducts. Be sure to connect the heater and induction air inlet ducts to the flexible duct when installing the nose caps.

12A-3. CLEANING, INSPECTION, AND REPAIR OF ENGINE COWLING may be accomplished as outlined in paragraph 12-3.

12A-4. ENGINE.

12A-5. The turbocharged powerplant is an air-cooled, six-cylinder, horizontally opposed, wet-sump, fuel-injected, turbocharged Continental engine. Refer to paragraph 12A-6 for engine data.

12A-6. ENGINE DATA.

MODEL (Continental)

TSIO-520-C

BHP at RPM

285 at 2700

Limiting Manifold Pressure (Sea Level)

32.5 Inches Hg

Number of Cylinders

6-Horizontally Opposed

Displacement

520 Cubic Inches

Bore

5.25 Inches

Stroke

4.00 Inches

Compression Ratio

7.5:1

Magnetos

Slick #662

Right Magneto

Fires 20° BTC Upper Right
and Lower Left

Left Magneto

Fires 20° BTC Upper Left
and Lower Right

Firing Order

1-6-3-2-5-4

Spark Plugs

SL-350

Gap

.015 to .018 Inch

Torque Value

330 ± 30 Lb-In

Fuel Metering System

Continental Fuel Injection

Unmetered Fuel Pressure

5.5 to 6.5 PSI at 600 RPM

30.8 to 32.2 PSI at 2700 RPM

Fuel

Aviation-100/130 Grade (Min.)

Oil Sump Capacity

12 U.S. Quarts

Tachometer

Type AS-54 Mechanical Drive

Alternator

14 Volt, 60 Ampere

Approximate Dry Weight

483 Pounds

with Accessories (Excluding Turbocharger
System)

Oil Pressure

10 PSI

Minimum Idling

30 to 60 PSI

Normal

Oil Temperature

Within Green Arc

Normal Operation

Red Line (240°F)

Maximum Permissible

Cylinder Head Temperature

460°F Maximum

INSTRUMENT CONNECTION LOCATIONS:

Oil Temperature

Below Oil Cooler

Oil Pressure

Between No. 2 and No. 4 Cylinders

Cylinder Head Temperature

Lower Side of No. 5 Cylinder

Manifold Pressure

Right Rear Intake Elbow

Fuel Flow

Fuel Manifold Valve

12A-7. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
ENGINE FAILS TO START.		
Improper use of starting procedure.		Review starting procedure.
Defective aircraft fuel system.	See paragraph 13-3.	See paragraph 13-3.
Engine flooded.	See paragraph 12A-78.	See paragraph 12A-78.
Spark plugs fouled or improperly gapped.	Remove and check.	Clean and regap. Replace if defective.
Failure of magneto impulse couplings.	With ignition switch off, rotate propeller by hand and listen for loud clicks as impulse couplings operate.	Repair or replace magnetos.
Defective magneto switch or grounded magneto leads.	Check continuity.	Repair or replace switch or leads.
Defective ignition system.	See paragraph 12-68.	See paragraph 12-68.
Excessive induction air leaks.	Check visually.	Correct the cause of air leaks.
Dirty screen in fuel control unit, or defective fuel control unit.	Remove screen and check visually. Check fuel flow through fuel control unit.	Clean dirty screen. Replace fuel control unit if defective.
Defective electric fuel pump.	See paragraph 13-3.	See paragraph 13-3.
Defective fuel manifold valve, or dirty screen inside valve.	Check fuel flow through valve.	Remove and clean per paragraph 12-37. Replace if defective.
Clogged fuel injection lines or discharge nozzles.	Check fuel flow through lines and nozzles.	Clean lines and nozzles. Replace if defective. Refer to paragraph 12A-44.
Fuel pump not permitting fuel from electric pump to bypass.	Check fuel flow through engine-driven fuel pump.	Replace fuel pump.
Vaporized fuel.	Vaporized fuel is most likely to occur in hot weather with a hot engine.	See paragraph 12A-78.
ENGINE STARTS BUT DIES, OR WILL NOT IDLE.		
Propeller control in low rpm position.	Check visually.	Use high rpm for all ground operations.
Defective aircraft fuel system.	See paragraph 13-3.	See paragraph 13-3.
Improper idle speed or idle mixture adjustment.	See paragraph 12-34.	See paragraph 12-34.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
ENGINE STARTS BUT DIES, OR WILL NOT IDLE (Cont).		
Spark plugs fouled or improperly gapped.	Remove and check.	Clean and regap. Replace if defective.
Water in fuel system.	Open fuel strainer drain valve and check for water.	Drain fuel tank sumps, fuel lines, and fuel strainer.
Defective ignition system.	See paragraph 12-68.	See paragraph 12-68.
Excessive induction air leaks.	Check visually.	Correct the cause of air leaks.
Dirty screen in fuel control unit, or defective fuel control unit.	Remove screen and check visually. Check fuel flow through fuel control unit.	Clean dirty screen. Replace fuel control unit if defective.
Defective fuel manifold valve, or dirty screen inside valve.	Check fuel flow through valve.	Remove and clean per paragraph 12-37. Replace if defective.
Restricted fuel injection lines or discharge nozzles.	Check fuel flow through lines and nozzles.	Clean lines and nozzles. Replace if defective. Refer to paragraph 12A-44.
Defective engine-driven fuel pump.	If engine continues to run with electric pump turned on, but stops when it is turned off, the engine-driven pump is defective.	Replace engine-driven fuel pump.
Vaporized fuel.	Vaporized fuel is most likely to occur in hot weather with a hot engine.	See paragraph 12A-78.
Manual primer leaking.	Disconnect primer outlet line. If fuel leaks through primer, it is defective.	Repair or replace primer.
Discharge nozzle air vent manifold restricted or defective.	Check visually.	Check for bent or loose connections. Tighten loose connections. Check for restriction and replace defective components.
Defective engine.	Check compression. Listen for unusual engine noises.	Engine repair is required.
ENGINE RUNS ROUGHLY, WILL NOT ACCELERATE PROPERLY, OR LACKS POWER.		
Propeller control in low rpm position.	Check visually.	Use high rpm for all ground operations.
Restriction in aircraft fuel system.	See paragraph 13-3.	See paragraph 13-3.
Restriction in fuel injection system.	Check fuel flow through discharge nozzles, fuel lines, manifold valve, fuel control unit, and fuel pump until restriction is located.	Clean out restriction. Replace any item found defective.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
ENGINE RUNS ROUGHLY, WILL NOT ACCELERATE PROPERLY, OR LACKS POWER (Cont).		
Fuel pump pressure improperly adjusted.	See paragraph 12A-49.	See paragraph 12A-49.
Worn or improperly rigged throttle or mixture control.	Check visually.	Rig properly. Replace worn linkage.
Spark plugs fouled or improperly gapped.	Remove and check.	Clean and regap. Replace if defective.
Defective ignition system.	See paragraph 12-68.	See paragraph 12-68.
Exhaust system leakage.	Check visually.	Tighten or repair exhaust system.
Turbocharger wheels rubbing.	Check manually.	Replace turbocharger.
Improperly adjusted or defective waste-gate controller.	See paragraph 12A-16.	See paragraph 12A-16. Replace if defective.
Leak in turbocharger discharger pressure system.	Inspect turbocharger installation.	Replace or repair damaged parts.
Manifold pressure overshoot.	Normal, when engine is accelerated too rapidly.	Move throttle about two-thirds open. Let engine accelerate to 30 inches Hg. and peak. Move throttle to full open position.
Defective engine.	Check compression. Listen for unusual engine noises.	Engine repair is required.
POOR IDLE CUT-OFF.		
Worn or improperly rigged mixture control.	Check that idle cut-off stop on fuel control unit is contacted.	Rig properly. Replace worn linkage.
Dirty or defective fuel manifold valve.	Operate electric fuel pump and check that no fuel flows through manifold valve with mixture control in idle cut-off.	Remove and clean per paragraph 12-37. Replace if defective.
Fuel contamination.	Check all screens in fuel and fuel injection system.	Drain all fuel and flush out fuel system. Clean all screens, fuel lines, discharge nozzles, fuel strainer, fuel manifold valve, and fuel pump.
Defective mixture control valve in fuel control unit.	If none of the preceding causes are found, fuel control unit is probably at fault.	Replace defective fuel control unit.

NOTE

Refer to paragraph 12A-14D for trouble shooting of the controller and waste-gate actuator.

12A-8. ENGINE REMOVAL. Remove the engine as a complete unit with all accessories installed.

NOTE

Tag each item disconnected to aid in identifying wires, hoses, and control linkage when engine is replaced. Protect openings, exposed as a result of removing or disconnecting units, against entry of foreign material by installing suitable covers or sealing with tape.

- a. Turn off all cabin switches and fuel selector valve.
- b. Remove engine cowling and nose cap.
- c. Open battery circuit by disconnecting the ground cable.

WARNING

Residual fuel draining from lines and hoses is a fire hazard. Use care to prevent the accumulation of such fuel when lines and/or hoses are disconnected.

- d. Disconnect magneto primary lead wires at magneto capacitor and pull them aft clear of the engine baffles.

WARNING

The magneto is NOT internally grounded when the primary lead is disconnected. The magneto primary circuit must be grounded or all spark plug leads must be disconnected to prevent the engine from firing when the propeller is rotated.

- e. Drain the engine oil.
- f. Remove propeller. (See Section 14.)
- g. Disconnect throttle, mixture, and propeller control. Remove clamps attaching controls to engine and pull controls aft to clear engine assembly. Use care to avoid bending controls too sharply.

NOTE

During the following procedures, remove any clamps which secure controls, wires, hoses or lines to the engine, engine mount, or attached brackets, so they will not interfere with engine removal. Some of the items listed can be disconnected at more than one place. It may be desirable to disconnect some of these items at other than the places indicated. The reason for engine removal should be the governing factor in deciding at which point to disconnect them. Omit any of the items which are not present on a particular engine.

- h. Disconnect wires and cables as follows:
 1. Disconnect oil temperature connector located directly below oil cooler.
 2. Disconnect tachometer drive from adapter.
 3. Disconnect starter electrical cable.
 4. Disconnect cylinder head temperature bulb

lead at the bulb.

5. Disconnect electrical wires and wire shielding ground from alternator.

6. Disconnect electrical wires at throttle switches.

7. Disconnect exhaust gas temperature wires, if installed.

8. Remove all clamps attaching wires or cables to the engine. Pull all wires and cables aft to clear the engine assembly.

i. Disconnect lines and hoses as follows:

1. Disconnect the hydraulic supply and pressure lines at hydraulic pump. Disconnect and remove hydraulic pump vent line. (210 Series.)

2. Disconnect vacuum line at the vacuum pump, and remove oil separator vent line.

3. Disconnect manifold pressure line at intake manifold.

4. Disconnect the fuel supply and the vapor return lines at the fuel pump. Disconnect and remove fuel pump drain line.

5. Disconnect the fuel-flow gage line at firewall.

6. Disconnect oil pressure line at the engine.

7. Disconnect and remove the right and left manifold drain lines and the balance tube drain line.

8. Disconnect air and oil lines at waste-gate controller, located on the firewall.

9. Disconnect air vent line to fuel-flow gage, at firewall.

10. Disconnect engine primer lines at right and left intake manifold, if installed.

11. Disconnect oil drain line from oil deflector under external oil filter, if installed.

12. Remove all clamps attaching disconnected lines and hoses to engine or structure.

j. Disconnect flexible ducting at cabin heater.

k. Attach a hoist to the lifting eye at the top center of the engine crankcase. Lift engine just enough to relieve the weight from the engine mount.

CAUTION

Place a stand under the tail tie-down ring before removing the engine. The loss of engine weight will allow the tail to drop.

1. Remove the engine as follows:

1. Remove heat shields, engine mount bolts, and ground strap.

2. Hoist engine out of nacelle and clear of aircraft.

CAUTION

Hoist engine slowly and make sure all wires, lines, and hoses have been disconnected. Also, use care to prevent damage to left intake manifold by the battery box.

3. Remove mount pads, spacers, ground strap, and pins.

12A-9. INSPECTION AND REPAIR. For specific items to be inspected refer to the manufacturer's manual.

- a. Inspect all hose for internal swelling, chafing through protective plys, cuts and breaks, hardening and loose connections. Excessive heat on hose will cause them to become brittle and easily broken. Hose and lines are most likely to crack or break near the end fittings and support points. At engine overhaul, install all new hose.
- b. Inspect all fittings for damaged threads.
- c. Visually inspect the engine for loose nuts, bolts, cracks, and fin damage.
- d. Inspect baffles, baffle seals, and brackets for cracks, deterioration, and breakage.
- e. For major repairs refer to the manufacturer's overhaul and repair manual.

12A-10. POWERPLANT BUILD-UP. Refer to paragraph 12-10 for powerplant build-up.

12A-11. ENGINE INSTALLATION.

- a. Hoist engine to a point just above the nacelle.
- b. Install engine mount pads as shown in figure 12-1.
- c. Install engine on mount pads as follows:
 1. Lower engine slowly into place on the engine mount pads.
 2. Attach ground strap under engine sump bolt and install engine mount bolts. Torque engine mount bolts to 300 + 50 - 00 lb-in. Bend tab washers to form lock for mount bolts. Install heat shields.

NOTE

If exhaust system was loosened or removed, refer to paragraph 12A-27.

- d. Connect flexible ducting on heater shroud and cabin valve.
- e. Route propeller governor control along left side of engine and secure with clamps.
- f. Connect lines and hoses as follows:
 1. Install and connect the hydraulic pump vent line (210 Series).
 2. Install and connect the left and right manifold drain lines and the balance tube drain line.
 3. Connect the oil pressure line at its fitting between No. 2 and 4 cylinders.

NOTE

Throughout the airplane fuel system, from the tanks to the engine-driven fuel pump, use Parker Sealube (or equivalent) as a thread lubricant or to seal a leaking connection. Apply sparingly to male fittings only, omitting the first two threads. Always be sure that a compound, the residue from a previously used compound, or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel soluble lubricant, such as engine lubricating oil, on the fitting threads. Do not use any other form of thread compound on the injection system fittings.

4. Connect the fuel-flow gage line at firewall.
5. Connect the fuel supply and the vapor return

lines at the fuel pump. Connect and install fuel pump drain line.

6. Connect manifold pressure line at intake manifold.
7. Connect vacuum line at the vacuum pump, and install oil separator vent line.
8. Connect hydraulic supply and pressure lines at hydraulic pump (210 Series). See paragraph 5A-8.
9. Connect air and oil lines at waste-gate controller on firewall.
10. Connect air vent line to fuel-flow gage line at firewall.
11. Connect engine primer lines at right and left intake manifold, if used.
12. Connect oil drain line to oil deflector under external oil filter, if installed.
13. Install all clamps securing lines and hoses to engine or structure.
- g. Connect wires and cables as follows:
 1. Connect oil temperature connector located directly below oil cooler.
 2. Connect tachometer drive to adapter and torque to 100 lb-in.
 3. Connect starter electrical lead.
 4. Connect cylinder head temperature bulb lead.
 5. Connect electrical wires and wire shielding ground to alternator.
 6. Connect electrical wires to throttle switches.
 7. Connect exhaust gas temperature wires, if installed.
 8. Install clamps that attach wires or cables, to engine or structure.

- h. Connect engine controls and install block clamps.
 - i. Rig engine controls in accordance with paragraph 12A-53.
 - j. Make a magneto switch ground-out and continuity check, then connect the magneto primary lead wires to the magnetos. Remove temporary ground or connect spark plug leads, whichever procedure was used at removal.

WARNING

Be sure the magneto switch is OFF when connecting primary leads to magnetos.

- k. Install propeller. (See Section 14.)
1. Service the engine in accordance with the applicable instructions in Section 2.

NOTE

When installing a new or newly overhauled engine, and prior to starting the engine, disconnect the oil inlet line at the controller and the oil outlet line at the controller. Connect these oil lines to a full-flow oil filter, allowing oil to bypass the controller. With filter connected, operate engine approximately 15 minutes to filter out any foreign particles from the oil. This is done to prevent foreign material from entering the controller.

- m. Inspect entire engine installation and install cowling.
- n. Perform engine run-up.





Figure 12A-1. Turbocharger System (Sheet 1 of 2)



NOTE

The turbocharger discharge duct (17) replaces the turbocharger discharge hose, used on the 1966 Models and a few early 1967 Models. Couplers (16A) and clamps are used to attach the duct to the throttle body adapter and the turbocharger. These parts are used as service parts on earlier airplanes.

- | | | |
|--------------------------------|---------------------------------|------------------------------|
| 1. Throttle Body Adapter | 13. Check Valve | 22. Doubler |
| 2. Absolute Controller | 14. Turbine Housing | 23. Magnet |
| 3. Rate Controller | 15. Compressor Housing | 24. Door |
| 4. Vacuum System Oil Separator | 16. Oil Inlet Adapter | 25. Induction Air Filter |
| 5. Tube | 16A. Coupler | 26. Baffle Assembly |
| 6. Turbocharger Support | 17. Turbocharger Discharge Duct | 27. Center Duct |
| 7. Shaft | 18. Turbocharger Inlet Hose | 28. Forward Duct |
| 8. Exhaust System | 19. Washer | 29. Seal |
| 9. Waste-Gate Actuator | 20. Cotter Pin | 30. Wear Guard |
| 10. Waste Gate | 21. Check Valve | 31. Nose Cap Flexible Duct |
| 11. Tailpipe | | 32. Turbocharger Inlet Elbow |
| 12. Oil Outlet Adapter | | 33. Aft Duct |

Figure 12A-1. Turbocharger System (Sheet 2 of 2)

12A-12. TURBOCHARGER.

12A-13. The turbocharger is an exhaust gas-driven compressor, or air pump, which provides high velocity air to the engine intake manifold. The turbocharger is composed of a turbine wheel, compressor wheel, turbine housing, and compressor housing. The turbine, compressor wheel, and interconnecting drive shaft comprise one complete assembly and are the only moving parts in the turbocharger. Turbocharger bearings are lubricated with filtered oil supplied from the engine oil system. Engine exhaust gas enters the turbine housing to drive the turbine wheel. The turbine wheel, in turn, drives the compressor wheel, producing a high velocity of air entering the engine induction intake manifold. Exhaust gas is then dumped overboard through the exhaust outlet of the turbine housing and exhaust tailpipe. Air is drawn into the compressor through the induction air filter, and is forced out of the compressor housing through a tangential outlet to the intake manifold. The degree of turbocharging is varied by means of a waste-gate valve, which varies the amount of exhaust gas allowed to bypass the turbine.

12A-14. REMOVAL AND INSTALLATION OF TURBOCHARGER.

- a. Remove engine cowl as required.
- b. Remove waste-gate to tailpipe clamp.
- c. Loosen clamp at turbine exhaust outlet and work tailpipe from turbine outlet.
- d. Loosen clamps and remove air inlet and outlet ducts from turbocharger compressor.
- e. Disconnect oil pressure and scavenger lines from turbocharger. Plug or cap open oil lines and fittings. Remove clamp on oil supply line to the turbocharger.
- f. Loosen clamp and remove induction air inlet elbow at turbocharger compressor.
- g. Remove right cowl flap by disconnecting control at cowl flap and removing hinge pin.
- h. Cut safety wire and remove two bolts attaching turbine to forward mounting bracket.
- i. Remove three bolts attaching turbine to turbine rear mounting bracket.
- j. Remove three remaining bolts, washers, and nuts attaching turbine to exhaust manifold.
- k. Work turbocharger from aircraft through cowl flap opening in lower cowl.
- l. To install the turbocharger, reverse the preceding steps. When installing the turbocharger, install a new gasket between exhaust manifold and turbine exhaust inlet. Reinstall safety wire.

12A-14A. CONTROLLER AND WASTE-GATE ACTUATOR.

12A-14B. FUNCTIONS. The waste-gate actuator and controllers use engine oil for power supply. The turbocharger is controlled by the waste gate and waste-gate actuator, and the absolute pressure and rate-of-change controller. The waste gate bypasses the engine exhaust gases around the turbocharger turbine inlet. The waste-gate actuator, which is physically connected to the waste gate by mechanical linkage, controls the position of the waste-gate butterfly valve. The absolute pressure

and rate-of-change controller has a two-fold function; the absolute pressure controller controls the maximum turbocharger compressor discharge pressure, while the rate-of-change controller controls the rate at which the turbocharger compressor discharge pressure will increase.

12A-14C. OPERATION. The waste-gate actuator is spring-loaded to position the waste gate to the normally open position when there is not adequate oil pressure in the waste-gate actuator power cylinder during engine shut down. When the engine is started, oil pressure is fed into the waste-gate actuator power cylinder through the capillary tube. This automatically fills the waste-gate actuator power cylinder and lines leading to the controllers, blocking the flow of oil by normally closed metering and/or poppet valves. As the oil pressure builds up in the waste-gate actuator power cylinder, it overcomes the force of the waste-gate open spring, closing the waste gate. When the waste gate begins to close, the exhaust gases are routed through the turbocharger turbine. As the engine increases its power and speed, the increase of temperature and pressure of the exhaust gases causes the turbocharger to rotate faster, raising the turbocharger compressor outlet pressure. As the compressor outlet pressure rises, the aneroid bellows in the absolute pressure controller sense the increase in pressure. When at high engine speed and load, and the proper absolute pressure is reached, the force on the aneroid bellows opens the normally closed metering valve. When the oil pressure in the waste-gate actuator power cylinder is lowered sufficiently, the waste-gate actuator open spring forces the mechanical linkage to open the waste gate. A portion of the exhaust gases then bypasses the turbocharger turbine, thus preventing further increase of turbocharger speed and holding the compressor discharge absolute pressure to the desired value. Conversely at engine idle, the turbocharger runs slowly with low compressor pressure output; therefore, the low pressure applied to aneroid bellows is not sufficient to affect the unseating of the normally closed metering valve. Consequently, engine oil pressure keeps the waste gate closed. The rate-of-change controller senses the compressor outlet pressure in the upper chamber and through an internal capillary restrictor tube in the lower chamber. When the compressor discharge pressure increases more rapidly than approximately 6.5 inches of mercury per second, a pressure differential exists between the upper and lower chambers of the diaphragm. As the pressure in the upper chamber becomes greater than that of the lower chamber, the diaphragm between the upper and lower chamber is forced downward causing the poppet valve to open and lower the oil pressure in the waste-gate actuator power cylinder, causing the waste gate to open. This prevents the turbocharger from increasing at too fast a rate and prevents overboosting the engine. Above 19,000 feet, the absolute pressure controller will continue to maintain 32.5±.5 inches of mercury manifold pressure at full throttle. It is necessary to reduce manifold pressure with the throttle to follow the maximum manifold pressure versus altitude schedule shown on the instrument panel placard.

CAUTION

All turbocharged engine installations on Cessna aircraft are equipped with controller systems which automatically control the engine power within prescribed manifold pressure limits. Although these automatic controller systems are very reliable and eliminate the need for manual control through constant throttle manipulation, they are not infallible. For instance, such things as rapid throttle manipulation (especially with cold oil), momentary waste gate sticking, air in the oil system of the controller, etc., can cause overboosting.

Consequently, it is still necessary that the pilot observe and be prepared to control the manifold pressure, particularly during take-off and power changes in flight.

The slight overboosting of manifold pressure beyond established maximums, which is occasionally experienced during initial take-off roll or during a change to full throttle operation in flight, is not considered detrimental to the engines as long as it is momentary. Momentary overboost is generally in the area of 2 to 3 inches and can usually be controlled by slower throttle movement. No corrective action is required where momentary overboosting corrects itself and is followed by normal engine operation. However, if overboosting of this nature persists, or if the amount of overboost goes as high as 6 inches, the controller system should be checked for necessary adjustment or replacement of the malfunctioning component.

OVERBOOST EXCEEDING 6 INCHES beyond established maximums is excessive and can result in engine damage. It is recommended that overboosting of this nature be reported to your Cessna Dealer, who will be glad to determine what, if any, corrective action needs to be taken.

12A-14D. TROUBLE SHOOTING THE CONTROLLER AND WASTE-GATE ACTUATOR.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
UNABLE TO GET RATED POWER BECAUSE MANIFOLD PRESSURE IS LOW.		
Controller not getting enough oil pressure to close the waste gate.	Check pump outlet pressure, oil filter, and external lines for obstructions.	Determine cause of low pressure and correct. Replace oil filter. Clean lines and replace if defective.
Controller out of adjustment or defective.	See paragraph 12A-16.	Replace if defective.
Defective actuator.	See paragraph 12A-18.	Replace actuator.
Leak in exhaust system.	Check that exhaust clamps fit properly and are tight. Check visually for cracks and other obvious defects.	Replace defective components.
Leak in intake system.	Tighten all hose clamps and fittings, since an intake leak is very difficult to locate. Check visually for cracks and other obvious defects.	Replace defective components.
ENGINE SURGES OR SMOKES.		
Defective controller.	See paragraph 12A-16.	Replace controller.
Actuator linkage binding.	See paragraph 12A-18.	Correct the cause of binding.
Actuator leaking oil.	Check visually.	Replace actuator.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
TURBOCHARGER NOISY WITH PLENTY OF POWER.		
Turbocharger overspeeding from defective or improperly adjusted controller.	See paragraph 12A-16.	Replace if defective.
Waste gate sticking closed.	See paragraph 12A-18.	Correct cause of sticking. Replace defective parts.
Controller drain line (oil return to sump) obstructed.	Disconnect and check.	Clean line. Replace if defective.
ENGINE POWER INCREASES SLOWLY OR SEVERE FLUCTUATIONS OF MANIFOLD PRESSURE WHEN THROTTLE ADVANCED RAPIDLY.		
Controller rate-of-change out of calibration or defective.	See paragraph 12A-16.	Replace if defective.
Waste-gate operation is sluggish.	See paragraph 12A-18.	Correct cause of sluggish operation. Replace defective parts.
ENGINE POWER INCREASES RAPIDLY AND MANIFOLD PRESSURE OVERBOOSTS WHEN THROTTLE ADVANCED RAPIDLY.		
Controller rate-of-change out of calibration or defective.	See paragraph 12A-16.	Replace if defective.
Waste-gate operation is sluggish.	See paragraph 12A-18.	Correct cause of sluggish operation. Replace defective parts.
FUEL PRESSURE DECREASES DURING CLIMB, WHILE MANIFOLD PRESSURE REMAINS CONSTANT.		
Compressor discharge pressure to fuel pump aneroid blocked.	Check lines for obstructions.	Clean out lines.
Leaking or otherwise defective fuel pump aneroid.		Replace fuel pump.
MANIFOLD PRESSURE DECREASES DURING CLIMB AT ALTITUDES BELOW THE NORMAL PART-THROTTLE CRITICAL ALTITUDE, OR POOR TURBOCHARGER PERFORMANCE INDICATED BY CRUISE RPM FOR CLOSED WASTE GATE. (Refer to paragraph 12A-14E.)		
Leak in intake system.	Tighten all hose clamps and fittings, since an intake leak is very difficult to locate. Check visually for cracks and other obvious defects.	Replace defective components.
Leak in exhaust system.	Check that exhaust clamps fit properly and are tight. Check visually for cracks and other obvious defects.	Replace defective components.
Leak in compressor discharge pressure line to controller.	Tighten fittings. Check for cracks and other obvious defects.	Replace defective components.
Controller seal leaking.	Check visually.	Replace controller.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
MANIFOLD PRESSURE DECREASES DURING CLIMB AT ALTITUDES BELOW THE NORMAL PART-THROTTLE CRITICAL ALTITUDE, OR POOR TURBOCHARGER PERFORMANCE INDICATED BY CRUISE RPM FOR CLOSED WASTE GATE. (Refer to paragraph 12A-14E.) (Cont)		
Waste-gate actuator leaking oil.	Check visually.	Replace actuator.
Waste gate butterfly-closed gap is excessive.	Refer to paragraph 12A-18.	Adjust per paragraph 12A-18.
Intake air filter obstructed.	Check visually.	Remove and clean. Refer to Section 2 for servicing instructions.
FUEL FLOW DOES NOT DECREASE AS MANIFOLD PRESSURE DECREASES AT PART-THROTTLE CRITICAL ALTITUDE.		
Defective fuel pump aneroid mechanism.		Replace fuel pump.
Obstruction or leak in compressor discharge pressure line to fuel pump.	Check for leaks or obstruction in lines and fittings.	Clean out lines and tighten fittings.
FUEL FLOW INDICATOR DOES NOT REGISTER CHANGE IN POWER SETTINGS AT HIGH ALTITUDES.		
Water freezing in indicator lines.	Disconnect lines and check.	Clean out lines.
SUDDEN POWER DECREASE ACCOMPANIED BY LOUD NOISE OF RUSHING AIR.		
Intake system air leak from hose becoming detached.	Check visually.	Check hose condition. Install hose and hose clamps securely.
MANIFOLD PRESSURE GAGE INDICATION WILL NOT REMAIN STEADY AT CONSTANT POWER SETTINGS.		
Defective controller.		Replace controller.
Waste-gate operation is sluggish.	See paragraph 12A-18.	Correct cause of sluggish operation. Replace if defective.

SHOP NOTES:

12A-14E. CONTROLLER AND TURBOCHARGER OPERATION FLIGHT CHECK. The following procedure details the method of checking the operation of the absolute and rate-of-change controller, and a performance check of the turbocharger.

① TAKEOFF — ABSOLUTE CONTROLLER CHECK.

- a. Cowl Flaps — Open.
- b. Airspeed — 110 MPH IAS.
- c. Oil Temperature — Middle of green arc.
- d. Engine Speed — 2700 ± 25 RPM.
- e. Fuel Flow — 28.0 to 29.5 GPH (Full Rich Mixture).
- f. Full Throttle M. P. — Absolute controller should maintain $32.5 \pm .5$ in. Hg (stabilized).

Climb 2000 feet after takeoff to be sure manifold pressure has stabilized. It is normal on the first takeoff of the day for full throttle manifold pressure to decrease 1/2 to 1.0 inch of mercury within one minute after the initial application of full power. Refer to paragraph 12A-16 for absolute controller adjustment.

② CLIMB — ABSOLUTE CONTROLLER AND TURBOCHARGER PERFORMANCE CHECK.

- a. Cowl Flaps — Open.
- b. Airspeed — 120 MPH IAS.
- c. Engine Speed — 2500 RPM.
- d. Fuel Flow — Adjust mixture for 20 GPH.
- e. Part-Throttle M. P. — 27.5 in. Hg.
- f. Climb to 20,000 feet — Check part-throttle critical altitude during climb.

This part-throttle critical altitude is where manifold pressure starts decreasing during the climb at a rate of approximately 1.0 inch of mercury per 1000 feet. After noting this altitude and the outside air temperature, the desired manifold pressure should be maintained by advancing the throttle during the remainder of the climb.

Once the climb power setting is established after takeoff, the controller should maintain a steady manifold pressure up to the part-throttle critical altitude indicated in the following chart. If part-throttle critical altitude has not been reached by 20,000 feet, discontinue check and proceed to cruise check.

<u>Outside Air Temperature</u>	<u>Part-Throttle Critical Altitude (75% Power)</u>
Standard or Colder	Above 24,000 feet
20°F Above Standard	16,000 to 22,000 feet
40°F Above Standard	10,000 to 16,000 feet

Part-throttle critical altitudes lower than those listed indicate the turbocharger system is not operating properly (refer to the trouble shooting chart in paragraph 12A-14D). Critical altitudes above those listed indicate turbocharger performance better than normal. Also check that fuel flow decreases as manifold pressure decreases at critical altitude. Refer to the trouble shooting chart if fuel flow does not decrease.

③ CRUISE — TURBOCHARGER PERFORMANCE CHECK.

- a. Cowl Flaps — Closed.
- b. Airspeed — Level flight.
- c. Pressure Altitude — 20,000 feet.
- d. Engine Speed — 2700 RPM.
- e. Part-Throttle M. P. — 27.5 in. Hg.
- f. Fuel Flow — Lean to 18 GPH.
- g. Propeller Control —
 - (1) Slowly decrease RPM until manifold pressure starts to drop, indicating waste gate is closed.
 - (2) Note outside air temperature and RPM as manifold pressure starts to drop, which should be in accordance with the following chart.
 - (3) After noting temperature and RPM, increase engine speed 50 RPM to stabilize manifold pressure, with the waste gate modulating exhaust flow to control compressor output.


<u>Outside Air Temperature</u>	<u>RPM where M. P. Starts to Decrease</u>
40°F Above Standard	2700 to 2550
20°F Above Standard	2600 to 2450
Standard Temperature	2500 to 2350
20°F Below Standard	2400 to 2250
40°F Below Standard	2300 to 2150

If the waste gate is closed at engine speeds higher than those listed, refer to the trouble shooting chart in paragraph 12A-14D. Closing of the waste gate at engine speeds lower than those listed indicates turbocharger performance better than normal.

④ DESCENT — RATE-OF-CHANGE CONTROLLER.

- a. Cowl Flaps — Closed.
- b. Airspeed — 100 MPH IAS.
- c. Pressure Altitude — 19,000 to 15,000 feet.
- d. Propeller — High RPM.
- e. Mixture — Full Rich.
- f. Throttle — Idle, until M. P. stabilizes.
 - (1) Rapidly advance throttle to full power.
 - (2) Note time required for M. P. to increase from 20 to 30 in. Hg.

Time required should be 1.25 to 2.0 seconds (5 to 8 in. Hg per second). Refer to paragraph 12A-16 for rate-of-change controller adjustment.



NOTE

Circled numbers refer to corresponding flight checks required in preceding text.

12A-15. REMOVAL AND INSTALLATION OF TURBOCHARGER CONTROLLER.

- a. Disconnect and tag oil lines from controller and plug or cap open lines and fittings.
- b. Disconnect compressor outlet pressure sensing line from controller and plug or cap open line and fitting.
- c. Remove two bolts attaching controller to mounting bracket on firewall.
- d. Remove controller from aircraft, being careful not to drop controller unit.
- e. Installation of the controller may be accomplished by reversing the preceding steps. Resafety bolts attaching controller to bracket.

12A-16. ABSOLUTE AND RATE-OF-CHANGE CONTROLLER ADJUSTMENTS. (See figure 12A-1A.)

The controller is mounted on the left side of the firewall, with the vertical unit being the absolute controller and the horizontal unit the rate-of-change controller.

ABSOLUTE ADJUSTMENT:

- a. With engine oil temperature at middle of green arc, slowly open throttle and note maximum manifold pressure obtainable. Do not exceed $32.5 \pm .5$ in. Hg.
- b. Cut safety wire and remove plug from bottom of absolute controller (the vertical unit).
- c. Using a flat-bladed screwdriver, rotate metering valve seat clockwise to increase manifold pressure and counterclockwise to decrease manifold pressure. Lightly tap the unit after each adjustment to seat internal parts.

NOTE

When adjusting, rotate in VERY small increments as this is an extremely sensitive adjustment. Approximately 13 degrees rotation will change the manifold pressure reading about one inch Hg.

- d. Install and safety plug in absolute unit, then op-

erate engine as in step "a" to ascertain that adjustment has not caused radical change in manifold pressure.

NOTE

When making adjustment on the ground, the hotter the engine gets, the lower the manifold pressure will be.

- e. After each adjustment, the airplane must be flight tested to check results.
- f. Repeat this procedure until desired results are obtained.

RATE-OF-CHANGE ADJUSTMENT:

- a. Remove controller per paragraph 12A-15.
- b. Remove fitting from controller drain port, which routes oil to the engine oil sump.
- c. Remove Allen-head plug just forward of inlet port.
- d. Insert tool (Part No. 5090002-1) into drain port. Insert small flat-bladed screwdriver into hole vacated by Allen-head plug. Rotate poppet assembly until screwdriver blade engages slot provided in bellows assembly boot.
- e. Holding bellows assembly boot, rotate poppet assembly with the special tool clockwise to increase rate-of-change and counterclockwise to decrease rate-of-change. Lightly tap the unit after each ad-

justment to seat internal parts.

NOTE

As with the absolute adjustment, rotate in VERY small increments as this adjustment is extremely sensitive.

- f. Reinstall Allen-head plug and fittings, and install the controller per paragraph 12A-15.
- g. After each adjustment, the airplane must be flight tested to check results.
- h. Repeat this procedure until desired results are obtained.

12A-17. REMOVAL AND INSTALLATION OF WASTE GATE AND ACTUATOR.

- a. Disconnect and tag oil lines from actuator, and plug or cap open lines and fittings.
- b. Remove bolts, washers, and nuts attaching waste gate and actuator assembly to tailpipe.
- c. Loosen clamp attaching tailpipe to turbine exhaust outlet and work tailpipe from turbine.
- d. Remove bolts, washers, and nuts attaching the assembly to the exhaust manifold.
- e. Remove the assembly from aircraft, being careful not to drop the unit.
- f. Installation may be accomplished by reversing the preceding steps.




Figure 12A-1A. Controller Adjustments




Figure 12A-3. Waste Gate Adjustment

NOTE

When installing the assembly, be sure the gaskets at inlet and outlet of valve are installed and are in good condition. Replace gaskets if damaged.

12A-18. ADJUSTMENT OF WASTE-GATE ACTUATOR. (See figure 12A-3.)

- Remove waste-gate actuator in accordance with paragraph 12A-17.
- Plug actuator outlet port and apply a 50 to 60 psig air pressure to the inlet port of the actuator.
- Check for 0.010, -0.005 inch gap between butterfly and waste-gate body as shown in figure 12A-3.
- If adjustment is required, remove pin from actuator shaft.
- Hold clevis end and turn shaft clockwise to increase gap or counterclockwise to decrease gap of butterfly. Install pin through clevis and shaft, securing pin with washer and cotter pin.
- After adjusting closed position, and with zero pressure in cylinder, check butterfly for a clearance of 1.100 + .000, -.125 inch in the full-open position as shown in figure 12A-3.
- If adjustment is required, loosen locknut and turn stop screw clockwise to decrease or counterclockwise to increase clearance of butterfly.
- Recheck butterfly in the closed position to ascertain that gap tolerance has been maintained.

NOTE

To assure correct spring loads, actuate butterfly with air pressure. Actuator shaft and butterfly should move freely. Actuator shaft should start to move at 15 ± 2 psig and fully extend at 35 ± 2 psig. Two to four psi hysteresis is normal, due to friction of O-ring against cylinder wall.

- Remove air pressure line and plug from actuator.
- Install waste gate and actuator as outlined in paragraph 12A-17.

12A-19. INDUCTION AIR SYSTEM.

12A-20. Ram air to the engine enters an induction air duct at the right side of the nose cap. The air is filtered through a dry filter, located in the induction airbox. From the induction air filter, the air passes through a flexible duct to the inlet of the turbocharger compressor. The compressor compresses the induction air. The pressurized induction air is then routed through a duct to the fuel-air control unit mounted behind the engine, and is then supplied to the cylinders through the intake manifold piping. The fuel-air control unit is connected to the cylinder intake manifold by elbows, hoses, and clamps. The intake manifold is attached to each cylinder by four bolts through a welded flange, which is sealed by a gasket. A balance tube

passes around the front side of the engine to complete the manifold assembly. An alternate air door, mounted in the duct between the filter and the turbocharger compressor, is held closed by a small magnet. If the induction air filter should become clogged, suction from the turbocharger compressor will open the door. This permits the compressor to draw heated induction air from within the engine compartment. This induction air is unfiltered air. The alternate air door should be checked periodically for freedom of operation and complete closing. The induction air filter should be removed and cleaned at each 50-hour inspection, more often when operating under dusty conditions. Refer to Section 2.

12A-21. REMOVAL AND INSTALLATION OF DUCTING AND AIRBOX.

- a. Remove engine cowling as required for access to the induction air ducts.
- b. Loosen clamp at lower end of airbox and remove flexible duct from airbox.
- c. Remove two screws, washers and nuts attaching airbox to upper rear engine baffle.
- d. Remove four screws attaching airbox to induction air duct and work airbox and filter from induction air duct.
- e. Remove screws attaching clips on duct to clips on rocker box covers.
- f. Remove screws attaching lower side of induction air duct to the two front cylinder rocker box covers.
- g. Loosen clamp and remove air duct from flexible inlet air duct, and remove induction air duct.
- h. Installation of the induction air duct is the reversal of the removal procedure.

NOTE

Clean filter and ascertain that induction air ducts and airbox are clean when installing.

12A-22. REMOVAL AND INSTALLATION OF FILTER.

- a. Remove right half of engine cowling.
- b. Remove screws attaching airbox to upper rear baffle.
- c. Loosen clamp and disconnect flexible air duct to airbox.
- d. Remove four screws attaching airbox to forward air duct and work airbox and filter from airplane.
- e. Remove four bolts, washers, and nuts attaching filter between airbox halves.
- f. Clean filter as outlined in Section 2.
- g. Installation of filter and airbox is the reversal of the removal procedure.

NOTE

When installing filter, note direction of air flow on the filter. Inspect and install gasket at aft face of filter assembly. Also, when tightening bolts fastening air filter, push inward on lower end of the upper duct (where turbocharger inlet connects to the upper duct). This is done so that inlet hose doesn't chafe against the cowling.

12A-23. EXHAUST SYSTEM.

12A-24. The exhaust system consists of two exhaust stack assemblies; one for the left and one for the right bank of cylinders. These exhaust stack assemblies are joined together to route the exhaust from all cylinders through the waste gate or turbine. The three risers on the left bank of cylinders are joined together into a common pipe to form the left stack assembly. The right rear cylinder exhaust is routed down and aft to the rear of the engine where it connects to the left stack assembly. The risers on the two right front cylinders are connected to a common pipe to form the right stack assembly. The right stack assembly connects to the left stack assembly at the front of the engine. Mounting pads for the waste gate and turbine are provided on the right stack assembly. From the exhaust port of the turbine, a tailpipe routes the exhaust overboard through the lower cowl. The exhaust port of the waste gate is routed into the tailpipe so the exhaust gas can be expelled from the system when not needed at the turbine. The waste gate is actuated by the waste-gate actuator which, in turn, is controlled by the waste-gate controller. During the 1967 Model year the engine exhaust system was redesigned to eliminate the wrap around insulation blankets. Heat shrouds replace the wrap around insulation blankets. Figure 12A-4 illustrates the engine exhaust system and heat shields. Also, sleeving is installed on the fuel hose from the engine-driven pump to the fuel metering body, and on the hose from the auxiliary fuel pump to the engine-driven pump on the Model T210. This is to prevent excessive heat on these fuel hoses as they route close to the exhaust stack.

12A-25. REMOVAL OF EXHAUST SYSTEM.

- a. Remove engine cowling and right and left nose caps.
- b. Remove intake manifold balance tube from front of engine.
- c. Remove heat shield at front of engine.
- d. Loosen clamp and disconnect flexible duct at aft end of cabin heater shroud on left exhaust stack assembly.
- e. Remove clamps and bolts securing rear heat shield to engine and remove heat shield.
- f. Remove clamps attaching left exhaust stack assembly to riser pipes and to rear crossover pipe on left side of engine.
- g. Work left exhaust stack assembly down from risers and out of crossover pipes at front and rear of engine.
- h. Remove four nuts and washers attaching exhaust riser pipe to each cylinder on left bank of cylinders, and remove riser pipes and gaskets.
- i. Remove clamp attaching exhaust tail pipe to exhaust port of turbine.
- j. Remove bolts attaching waste gate to right exhaust stack assembly. Work tail pipe from turbine and lower waste gate and tail pipe into cowling.
- k. Remove bolts attaching turbocharger to mounting brackets.
- l. Remove bolts and nuts attaching turbocharger to right exhaust stack assembly. Lower turbocharger into cowling.

m. Remove bolts, nuts, and clamps attaching right exhaust stack assembly to riser pipes on right side of engine.

n. Work right exhaust stack assembly down from risers and remove.

o. Remove nuts and washers attaching riser pipes to front two cylinders on right side of engine, and remove riser pipes and gaskets.

p. Remove nuts and washers attaching exhaust pipe to rear cylinder on right side of engine and remove pipe and gasket.





Figure 12A-4. Exhaust System (Sheet 1 of 2)



HEAT DEFLECTORS AND INSULATORS

1. Clamp
2. Crankcase
3. Intake Manifold Balance Tube
4. Heat Deflector
5. Rivet

6. Heat Shield
7. Bolt
8. Lockwasher
9. Washer

10. Right Nosecap
11. Insulation
12. Retaining Skin
13. Left Nosecap
14. Screw

Figure 12A-4. Exhaust System (Sheet 2 of 2)

12A-26. INSPECTION OF EXHAUST SYSTEM.

Inspection of the exhaust system should be thorough, because the cabin heating system uses air heated by the heat exchanger of the exhaust system. Since exhaust systems of this type are subject to burning, cracking, and general deterioration from alternate thermal stresses and vibration, inspection is important and should be accomplished every 100 hours of operation. In addition, an inspection should be performed any time exhaust fumes are detected in the cabin. Also, a thorough inspection of the engine exhaust system should be made to detect any cracks causing leaks which might result in loss of optimum turbocharger efficiency and engine power. To inspect the engine exhaust system, proceed as follows:

a. Remove engine cowl, heater shroud, and heat shields so that ALL surfaces of the exhaust assemblies can be visually inspected.

NOTE

Especially check the areas adjacent to welds. Look for exhaust gas deposits in surrounding areas, indicating that exhaust gases are escaping through a crack or hole.

b. After visual inspection, an air leak check should be made on the exhaust system, as follows:

1. Attach the pressure side of an industrial vacuum cleaner to the tailpipe opening, using a rubber plug to effect a seal as required.

NOTE

The inside of the vacuum cleaner hose should be free of any contamination that might be blown into the engine exhaust system.

2. With the vacuum cleaner operating, all joints in the exhaust system may be checked manually by feel, or by using a soap and water solution and watching for bubbles. All joints should be free of air leaks with the exception of the waste gate bearings which will show some bubbling. Also, some small bubbles will appear at the joint of the turbocharger turbine and compressor bearing housing.

c. For a more thorough inspection, or if fumes have been detected in the cabin, the following procedure is recommended.

1. Remove exhaust stack assemblies.
2. Use rubber expansion plugs to seal openings.
3. Using a manometer or gage, apply approximately 1-1/2 psi (3 inches of mercury) air pressure while each stack assembly is submerged in water. Any leaks will appear as bubbles and can be readily detected.

4. It is recommended that exhaust stacks found defective be replaced before the next flight.

d. After installation of exhaust system components, perform the inspection in step "b" of this paragraph to ascertain there are no leaks at the joints of the system.

12A-27. INSTALLATION OF EXHAUST SYSTEM.

NOTE

It is important that the complete exhaust system, including the turbocharger and waste gate, be installed without pre-loading any section of the exhaust stack assembly.

a. Use new gaskets between exhaust stacks and engine cylinders, at each end of waste gate, and between turbocharger and exhaust stack.

b. Place all sections of exhaust stacks in position and torque nuts attaching them to the cylinders evenly to 60±10 lb-in, while riser clamps are loose.

c. Manually check that front and rear crossover pipe slip-joints do not bind. Tighten clamps attaching left risers to left stack assembly. Tighten the clamp attaching right stack to right front riser.

d. Raise turbocharger into position and install bolts and nuts attaching turbocharger to right exhaust stack and those attaching turbocharger to front and rear turbocharger supports (6, figure 12A-1). Tighten bolts securely.

e. Install bolts and nuts attaching waste gate to right hand exhaust stack and tighten securely.

f. While applying an upward force of one G to counteract weight of turbocharger and waste gate assembly, tighten clamp attaching exhaust stack to riser.

g. Tighten clamp securing tailpipe to turbocharger.

h. Be sure all parts are secure and safetied as required, then perform step "b" of paragraph 12A-26 to check for air leaks.

i. Install heater shroud duct and heat shields.

j. Install intake manifold balance tube at front of engine and install heat shields at front of engine, then install nose caps and cowl.

NOTE

The lower sections of turbocharger supports (6, figure 12A-1) are supplied as service parts with their upper holes omitted. These undrilled parts are also supplied when a new turbocharger inlet stack, right front stack, or either of the two right front risers is ordered. The following steps outline the proper procedure for drilling and installing the supports.

k. Install all parts but do not tighten attaching clamps or bolts.

l. Torque nuts attaching risers to cylinders evenly to 60±10 lb-in.

m. Tighten bolts and clamps per steps "d" thru "g."

NOTE

It is important that weight of turbocharger and waste gate assembly be counteracted, as listed in step "f," when tightening clamps attaching stacks to risers.

n. Mark hole locations in undrilled supports to match existing holes in upper supports.

- o. Remove lower supports, leaving all other parts tight.
- p. Drill the marked holes with a size F (.257) drill.
- q. Reinstall supports, install bolts fastening upper and lower supports together, then tighten all bolts securely. If any exhaust system bolts or clamps were loosened while lower supports were not installed, loosen all clamps and bolts and repeat the installation procedure to be sure no pre-loading is present.
- r. Be sure all parts are secure and safetied as required, reinstall any parts removed for access, then install nose caps and cowlings.

12A-28. ENGINE BAFFLES. The sheet metal baffles installed on the engine direct the cooling airflow around the cylinders and other engine components. The baffles incorporate rubber-asbestos composition seals at points of contact with the engine cowl to help confine and direct the airflow to the desired area. Baffles and seals must be maintained in good condition and replaced whenever they become worn or damaged. It is very important to engine cooling that the baffles and seals are installed correctly.

12A-29. CLEANING AND INSPECTION OF BAFFLES. The engine baffles should be cleaned with a suitable solvent to remove oil and dirt.

NOTE

The rubber-asbestos seals are oil and grease resistant but should not be soaked in solvent for long periods.

Inspect baffles for cracks in the metal and for loose and/or torn seals. Replace defective parts.

12A-30. FUEL INJECTION SYSTEM.

NOTE

Throughout the airplane fuel system, from the tanks to the engine-driven fuel pump, use Parker Sealube (or equivalent) as a thread lubricant or to seal a leaking connection. Apply sparingly to male fittings only, omitting the first two threads. Always be sure that a compound, the residue from a previously used compound, or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel soluble lubricant, such as engine lubricating oil, on the fitting threads. Do not use any other form of thread compound on the injection system fittings.

12A-31. The fuel injection system is a simple, low-pressure system of injecting fuel into the intake valve port in each cylinder head. It is a multi-nozzle, continuous-flow type which controls fuel flow to match engine airflow. Any change in air throttle position, engine speed, or a combination of both, causes changes in fuel flow in the correct relation to engine air flow. A manual mixture control and a fuel flow gage, indicating metered fuel flow in gallons per hour, are provided for leaning at any combination

of altitude and power setting. The four major components of the system are: the fuel injection pump, fuel-air control unit, fuel manifold valve, and the fuel discharge nozzles. The fuel injection pump incorporates an adjustable aneroid sensing unit which is pressurized from the discharge side of the turbocharger compressor. Turbocharger discharge air pressure is also used to vent the fuel discharge nozzles and the vent port of the fuel flow gage.

WARNING

Residual fuel draining from lines and hoses is a fire hazard. Use care to prevent the accumulation of such fuel when lines and/or hoses are disconnected throughout the fuel injection system.

12A-32. FUEL-AIR CONTROL UNIT. The fuel-air control unit occupies the position ordinarily used by the carburetor at the intake manifold inlet. The function of this unit is to control engine air intake and to set the metered fuel pressure for proper fuel-air ratio. There are three control elements in this unit, one for air and two for fuel. One of the fuel control elements is for fuel mixture and the other is for fuel metering. Fuel under pressure from the fuel pump enters the control unit through a strainer and passes to the metering valve. The position of the metering valve controls the fuel passed to the manifold valve and discharge nozzles. An adjustable linkage connecting the metering valve to the air throttle proportions air flow to fuel flow. The position of the mixture valve determines the amount of fuel returned to the fuel pump. The fuel control portion of the fuel-air control unit is enclosed in a shroud and is blast-air cooled to help prevent vapor lock.

12A-33. REMOVAL OF FUEL-AIR CONTROL UNIT.

- a. Place fuel selector valve handle in OFF position.
- b. Remove upper engine cowlings.
- c. Loosen clamp and disconnect flexible duct from elbow at top of air throttle.
- d. Tag and disconnect electrical wires from landing gear warning and electric fuel pump microswitches.
- e. Disconnect throttle and mixture control rod ends at fuel-air control unit.

NOTE

Cap or plug all disconnected hoses, lines and fittings.

- f. Disconnect cooling air blast tube from fuel control valve shroud.
- g. Disconnect and tag all fuel lines at the fuel control valve.
- h. Remove nuts and washers securing triangular brace to fuel-air control unit and engine, at lower end of control unit. Remove brace.
- i. Remove bolt attaching fuel-air control unit to brace at top of control unit.
- j. Loosen hose clamps which secure fuel-air control unit to right and left intake manifold assemblies and slip hoses from fuel-air control unit.




Figure 12A-5. Fuel Injection Schematic

k. Remove fuel-air control unit.

12A-34. CLEANING AND INSPECTION OF FUEL-AIR CONTROL UNIT. Refer to paragraph 12-32 for cleaning and inspection of fuel-air control unit.

12A-35. INSTALLATION OF FUEL-AIR CONTROL UNIT.

- a. Place fuel-air control unit in position at rear of engine.
- b. Install bolt attaching fuel-air control unit to brace at top of the control unit. Ascertain that shock mount is in place and in good condition.
- c. Install triangular brace at lower end of control unit.
- d. Install hoses and clamps which secure fuel-air control unit to right and left intake manifold assemblies. Tighten hose clamps.
- e. Connect fuel lines to control unit and connect air blast tube at fuel control shroud.
- f. Connect throttle and mixture control rod ends to fuel-air control unit.
- g. Connect electrical wires to landing gear warning and electric fuel pump microswitches. Check switch rigging in accordance with paragraph 12-55.
- h. Install induction air duct to elbow at top of fuel air control unit.
- i. Inspect entire installation.
- j. Install engine cowling.

12A-36. FUEL-AIR CONTROL UNIT ADJUSTMENTS. Refer to paragraph 12-34 for fuel-air control unit adjustments.

12A-37. FUEL MANIFOLD (FUEL DISTRIBUTOR). Refer to paragraph 12-35.

12A-38. REMOVAL OF FUEL MANIFOLD. Refer to paragraph 12-36 for removal of the fuel manifold.

12A-39. CLEANING OF FUEL MANIFOLD. Refer to paragraph 12-37 for cleaning of fuel manifold.

12A-40. INSTALLATION OF FUEL MANIFOLD. Refer to paragraph 12-38 for installation of the fuel manifold.

12A-41. FUEL DISCHARGE NOZZLES.

12A-42. From the fuel manifold valve, individual, identical size and length fuel lines carry metered fuel to the fuel discharge nozzles located in the cylinder heads. The outlet of each nozzle is directed into the intake port of each cylinder. An air bleed and nozzle pressurization arrangement is incorporated in each nozzle to aid in vaporization of the fuel. The nozzles are calibrated in several ranges. All nozzles furnished for one engine are of the same calibrated range and are identified by a number and suffix letter stamped on the flat portion of the nozzle body. When replacing a fuel discharge nozzle, be sure that it is of the same calibrated range as the rest of the nozzles in that engine. When a complete set of nozzles is being replaced the number must be

the same as the one removed, but the suffix letter may be different, as long as they are the same for all nozzles being installed in a particular engine.

12A-43. REMOVAL OF FUEL DISCHARGE NOZZLES.

- a. Remove engine cowling as required.

NOTE

Plug or cap all disconnected lines and fittings.

- b. Disconnect nozzle pressurization line at nozzles and disconnect pressurization line at "tee" fitting so that pressurization line may be moved away from discharge nozzles.
- c. Disconnect fuel injection line at fuel discharge nozzle.
- d. Using care to prevent damage or loss of washers and O-rings, lift sleeve assembly from fuel discharge nozzle.
- e. Using a standard 1/2-inch deep socket, remove fuel discharge nozzle from cylinder.

12A-44. CLEANING OF FUEL DISCHARGE NOZZLES. To clean the fuel discharge nozzles, immerse nozzle assembly in fresh cleaning fluid. Do not use any metal removing chemicals for this cleaning. Do not use wire or any other metal objects to remove foreign material from orifice or metering jet in nozzle. Dry nozzle assembly with compressed air. When drying internal part of nozzle with compressed air, direct air through nozzle in the direction opposite to normal fuel flow.

12A-45. INSTALLATION OF FUEL DISCHARGE NOZZLES.

- a. Using a standard 1/2-inch deep socket, install nozzle body in cylinder and tighten to a torque value of 60-80 lb-in.
- b. Install O-rings, sleeve assembly, and washers.
- c. Align sleeve assembly and connect pressurization line to nozzles. Connect pressurization line to "tee" fitting.
- d. Install O-ring and washer at top of discharge nozzle, and connect fuel injection line to nozzle.
- e. Inspect installation for crimped lines and loose fittings.
- f. Inspect nozzle pressurization vent system for leakage. A tight system is required, since turbo-charger discharge pressure is applied to various other components of the injection system.
- g. Install cowling.

12A-46. FUEL INJECTION PUMP. The fuel pump is a positive-displacement, rotating vane type. It has a splined shaft for connection to the accessory drive section of the engine. Fuel enters the pump at the swirl well of the pump vapor separator. Here, vapor is separated by a swirling motion so that only liquid fuel is fed to the pump. The vapor is drawn from the top center of the swirl well by a small pressure jet of fuel and is fed into the vapor return line, where it is returned to the fuel tank. Since the pump is engine-driven, changes in engine speed

affect total pump flow proportionally. A check valve allows the auxiliary fuel pump pressure to bypass the engine-driven pump for starting, or in the event of engine-driven fuel pump failure in flight. The pump supplies more fuel than is required by the engine; therefore, a relief valve is provided to maintain a constant fuel pump pressure. The engine-driven fuel pump is equipped with an aneroid. The aneroid and relief valve are pressurized from the discharge side of the turbocharger compressor to maintain a proper fuel/air ratio at altitude. The aneroid is adjustable for fuel pump outlet pressure at full throttle and the relief valve is adjustable for fuel pump outlet pressure at idle. Refer to paragraph 12A-49.

12A-47. REMOVAL OF FUEL INJECTION PUMP.

- Place fuel selector valve handle in OFF.
- Remove upper engine cowl.
- Remove alternator and left rear intake elbow.
- Hoist engine far enough to remove weight from engine mount and remove left rear engine mount leg, shock mount, and alternator bracket.
- Remove flexible duct and shroud, removing fuel lines and fittings as necessary. Tag each fitting and line for identification, and cap or seal to prevent entry of foreign material. Flanges of shroud may be straightened to facilitate removal and installation, but must be re-formed after installation. Note angular position of fittings before removal.
- Remove nuts and washers attaching fuel pump to engine, and pull pump aft to remove. Remove thin gasket.
- Place temporary cover on pump mounting pad.

12A-48. INSTALLATION OF FUEL INJECTION PUMP.

- Install and align any fittings removed after pump removal.
- Using new thin gasket, install pump with aneroid chamber down.
- Install cooling shroud and remainder of fittings, bending flanges of shroud to their original position and aligning fittings as noted during removal.
- Connect all fuel lines and shroud flexible duct.
- Install alternator bracket, shock mount, and engine mount leg. Remove hoist, then adjust alternator drive belt tension. Refer to Section 17.
- Install intake elbow.
- Start engine and perform operational check, adjusting fuel pump if required. See paragraph 12A-49.
- Install engine cowling.

12A-49. ADJUSTMENT OF FUEL INJECTION PUMP.

The fuel injection pump adjustments require special equipment and procedures. Cessna Service Kit No. SK320-2 (available from the Cessna Service Parts Center) supplies a special indicator, lines, and instructions for performing accurate calibration of the engine-driven fuel pump pressure. With engine at normal operating temperature and mixture control set at full rich, set the unmetered fuel pressure to the values listed in paragraph 12A-6.




Figure 12A-6. Cowl Flap Control

NOTE

After adjusting the unmetered fuel pressure, idle rpm and idle mixture must be readjusted as outlined in paragraph 12-34.

12A-50. ENGINE COWL FLAPS. Cowl flaps are provided as a means of controlling engine temperature. Two cowl flaps, operated by a single control in the cabin, are located at the lower aft end of the engine nacelle. The overboard exhaust tube for the cabin heater extends through the cutout in the aft portion of the left cowl flap. The right hand flap, except for the hinge loops, is painted with heat-resistant paint (Part No. CES1054-743), which is available from the Cessna Service Parts Center. Whenever the cowl flap is repainted, this type paint should be used. The cowl flap controls have been rerouted for improved control action.

12A-51. RIGGING ENGINE COWL FLAPS.

NOTE

The cowl flap control extensions, shown in figure 12A-6, were deleted during the 1966 model-year because of rerouting of the cowl flap controls and changes in their length.

- Disconnect cowl flap control clevises from cowl flaps.
- Check to make sure that the flexible controls reach their internal stops in each direction. Mark controls so that full control travel can readily be checked and maintained during the remaining rigging procedure.
- Place cowl flap control lever in the OPEN position, which is the top hole in the bracket. Be sure that correct hole in bracket is used. If control lever cannot be placed in correct hole in bracket, loosen clamp at upper end of controls and slip housings in clamp or adjust controls at upper clevis to position control lever in correct hole in bracket.

d. (Model T210) Adjust clevis at lower end of control to open one cowl flap 5.50 inches. This measurement is made in a straight line from the aft edge of the cowl flap, just outboard of cutout (if present), to lower edge of firewall. Do not measure from aft corners of cowl flap. Repeat for other cowl flap. If either control needs to be lengthened or shortened, the lower clamp may be loosened and housing slipped in the clamp, or lower clevis may be adjusted. Maintain sufficient thread engagement of clevis.

e. (Model TU206 and TP206) Adjust clevis at lower end of control to open one cowl flap $7.00 + .25, -.00$ inches. This measurement is made in a straight line from the aft edge of the cowl flap, just outboard of cutout (if present), to lower edge of firewall. Do not measure from aft corners of cowl flap. Repeat for other cowl flap. If either control needs to be lengthened or shortened, the lower clamp may be loosened and housing slipped in the clamp, or the lower clevis may be adjusted. Maintain sufficient thread engagement of clevis. Note that the cowl flaps are partially open in the CLOSED position.

f. Check that locknuts are tight, clamps are secure, and all bolts and nuts are installed.

NOTE

In all cases, the flexible controls must reach their internal stops in each direction to assure full travel of the controls.

12A-52. ENGINE CONTROLS. The engine controls are similar to those described in paragraph 12-49, except for minor routing of the controls. There is no induction alternate air control as the induction alternate air door opens automatically in the event the induction air filter should become clogged. During the 1966 model-year, an additional "Palnut" type locknut was installed in back of the existing locknut at the engine end of the throttle, mixture and propeller controls.

12A-53. RIGGING PROCEDURES - ENGINE CONTROLS.

CAUTION

Some engine controls have a small retaining ring brazed (or attached with epoxy resin) in a groove 0.97 inch from the threaded end of the control. The purpose of these retaining rings is to prevent inadvertent withdrawal and possible damage to the knob end of the controls while jam nuts and rod ends are removed.

12A-54. RIGGING PROPELLER CONTROL. Refer to Section 14 for propeller control rigging.

12A-55. RIGGING MIXTURE CONTROL. Refer to paragraph 12-53 for mixture control rigging.

12A-56. RIGGING THROTTLE CONTROL. Refer to paragraph 12-54 for throttle control rigging.

12A-57. RIGGING THROTTLE MICROSWITCHES. Refer to paragraph 12-55 for rigging of throttle microswitches.

12A-58. STARTING SYSTEM.

12A-59. The automatically engaged starting system employs an electric starter motor mounted to a 90-degree adapter. A starter solenoid is activated by the ignition key on the instrument panel. When the solenoid is activated, its contacts close and electrical current energizes the starter motor. Initial rotation of the starter motor engages the starter through an overrunning clutch in the starter adapter, which incorporates worm reduction gears. The starter is located just aft of the right rear cylinder.

12A-60. REPLACEMENT OF STARTER.

a. Remove induction airbox and filter to gain access to starter.

b. Disconnect electrical power lead from the starter. Insulate the disconnected terminal as a safety precaution.

c. Remove nuts securing the starter and remove the starter.

d. To install the starter, reverse this procedure. Install a new O-ring on the starter, then install the starter. Be sure that starter drive engages with the drive in the starter adapter.

12A-61. DELETED.

12A-62. STANDARD MAINTENANCE. Refer to paragraph 12-60.

12A-63. DELETED.

12A-64. TROUBLE SHOOTING STARTER. Refer to paragraph 12-62 for trouble shooting the starter.

12A-65. MAGNETOS. The engine is equipped with Slick magnetos. Refer to paragraphs 12-63 through 12-68 for maintenance of magnetos.

12A-66. OIL SYSTEM. (See figure 12A-7.) The engine lubrication system is a full-pressure, wet-sump type. Lubricating oil is drawn from the engine sump to the oil pump through a suction screen and tube. From the oil pump, engine oil under pressure is passed to the full-flow oil filter, where it is filtered before entering the passages of the engine. Bypass valves are provided. Engine oil from the filter is routed through drilled and cored passages to all moving parts requiring lubrication. Oil furnished to the propeller governor for propeller operation is also routed through internal passages. Oil pressure is maintained by an adjustable, spring-loaded relief valve mounted in the lower portion of the pump body. Oil temperature is automatically regulated by an oil cooler and a thermostat control valve. When the oil temperature reaches a predetermined temperature the thermostat valve closes, causing the engine oil to be routed through the externally mounted cooler. Engine oil is also used to control the waste gate and




Figure 12A-7. Oil System Schematic

lubricate the turbocharger bearings. Engine oil is returned to the engine sump from the turbocharger sump by a scavenger pump, which is integral with the engine oil pump. The engine oil filler neck is located on top of the engine and is reached through an access door in the top of the left cowl. The oil level in the sump is checked on a dipstick at the rear of number two cylinder and is reached through an access door in the side of the left cowl.

12A-67. TROUBLE SHOOTING OIL SYSTEM. Refer to paragraph 12-71 for trouble shooting of the oil system.

12A-68. FULL-FLOW OIL FILTER. An external oil filter is installed on these airplanes. The filter and filter adapter replace the regular engine oil filter screen. In some filter installations, the filter adapter incorporates a bypass valve, outlet valve, and isolation valve. Normally, oil from the oil pump flows through the isolation valve, through the filter element, through the outlet valve, to the engine oil passages. If the filter element should become blocked, the bypass valve will open, allowing oil to flow to the engine oil passages. The isolation valve blocks off the filter assembly, and oil then flows through the bypass valve, if excessive oil pressure should occur. In some filter installations the filter adapter incorporates only a bypass valve. This type adapter is the latest and is also available for all earlier aircraft. Refer to note on figure 12-8.

12A-69. FILTER ELEMENT REPLACEMENT. Refer to paragraph 12-73 for replacement of either filter element. Beginning with the 1967 Models, an oil deflector and drain line have been added beneath the external filter to prevent engine oil from dripping on the exhaust stack assembly.

12A-70. FILTER ADAPTER REMOVAL. Refer to paragraph 12-74 for removal of either filter adapter.

12A-71. DISASSEMBLY, REPAIR, AND ASSEMBLY OF FILTER ADAPTER. Refer to paragraph 12-75 for filter adapter disassembly, repair, and assembly.

12A-72. FILTER ADAPTER INSTALLATION. Refer to paragraph 12-76 for installation of filter adapter.

12A-73. OIL COOLER. The engine is equipped with a non-congealing oil cooler as standard equipment. Refer to paragraph 12-77.

12A-74. EXTREME WEATHER MAINTENANCE.

12A-75. COLD WEATHER. The turbocharged engine installation is designed so that a winterization kit is

not required. Refer to paragraph 12-79 for other cold weather operating recommendations.

12A-76. LOW BATTERY STARTING. Refer to paragraph 12-80.

12A-77. HAND-CRANKING. Refer to paragraph 12-82.

12A-78. HOT WEATHER. When the engine is hot or the outside air temperature is high, the engine may die after running several seconds because the mixture became either too lean due to fuel vapor or too rich due to excessive prime fuel. The following procedure will prevent over-priming and take care of fuel vapor in the system:

- a. Set the throttle $1/3$ to $1/2$ open.
- b. When the ignition key is on BOTH and you are ready to engage the starter, turn the fuel pump on HI until the fuel flow comes up to 4-6 gal/hr and then turn the pump off.

NOTE

During a restart after a brief shut-down in extremely hot weather the presence of fuel vapor may require the pump to run on HI for up to 1 minute or more before the vapor is cleared sufficiently to obtain 4-6 gal/hr for starting.

c. Without hesitation, engage the starter and the engine should start in 3 to 5 revolutions. Adjust the throttle for 1200-1400 RPM.

d. If there is fuel vapor in the lines, it will pass into the injector nozzles in 2 to 3 seconds and the engine will gradually slow down and stop. When engine speed starts to decrease, turn the fuel pump on HI for approximately one second to clear out the vapor. Intermittent use of HI boost is needed since prolonged use of HI pump after the vapor is cleared will flood out the engine.

e. Let the engine run at 1200 to 1400 RPM until the vapor is eliminated and the engine idles normally.

If prolonged cranking is necessary, allow the starter motor to cool at frequent intervals, since excessive heat may damage the armature.

12A-79. DUSTY CONDITIONS. Refer to paragraph 12-84.

12A-80. SEACOAST AREAS, HUMID AREAS. Refer to paragraph 12-85.

SECTION 13

FUEL SYSTEM (EXCEPT CANTILEVER WING)

TABLE OF CONTENTS

Page

FUEL SYSTEM	13-1
Trouble Shooting	13-2
Checking Fuel Vents	13-9
FUEL CELLS	13-9
General Precautions	13-9
Removal and Installation	13-9
Preservation	13-11
FUEL CELL REPAIRS	13-11
U.S. RUBBER - 907N and 943 Cells	13-11
U.S. RUBBER - 932 Cells	13-12
U.S. RUBBER - Testing	13-13
GOODYEAR - BTC 37 or BTC 39 Cells	13-14
GOODYEAR - TESTING	13-16
REMOVAL AND INSTALLATION OF FUEL TRANSMITTER	13-16
REMOVAL AND INSTALLATION OF RESERVOIR TANKS	13-16
REMOVAL AND INSTALLATION OF SELECTOR VALVE	13-16
SELECTOR VALVE REPAIR	13-16

ELECTRIC FUEL PUMP	13-18
Disassembly	13-18
Disassembly of Motor	13-18
Inspection of Motor	13-18
Reassembly of Motor	13-18
Disassembly of Pump	13-18
Inspection of Pump	13-18
Reassembly of Pump	13-18
Disassembly of Bypass and Pressure Relief	13-18
Inspection of Bypass and Pressure Relief	13-18
Reassembly of Bypass and Pressure Relief	13-20
Adjusting Pressure Relief	13-20
Functional Test Procedure	13-20
Electric Fuel Pump Circuits	13-22
FUEL STRAINER	13-22
Disassembly	13-22

13-1. FUEL SYSTEM.

NOTE

The fuel system as described in this section does not include the fuel injection system. Refer to Section 12 or 12A for that part of the fuel system.

13-2. Fuel from the cells in the wings is gravity-fed through fuel reservoir tanks installed forward of the front doorpost bulkheads, beneath the cabin floor, to the engine-driven fuel pump. The fuel line from the lower forward corner of each fuel cell to the reservoir tank serves as a combination fuel feed and vapor return line. The fuel bypasses the electric auxiliary fuel pump when it is not in operation. The fuel cells are individually vented overboard through check valves located in each cell.

WARNING

Fuel draining from fuel tanks and discon-

nected lines or hoses constitutes a fire hazard. Adequate safety precautions should be taken whenever it is necessary to drain fuel or to disconnect lines or hoses.

NOTE

Throughout the airplane fuel system, from the tanks to the engine-driven fuel pump, use Parker Sealube (or equivalent) as a thread lubricant or to seal a leaking connection. Apply sparingly to male fittings only, omitting the first two threads. Always be sure that a compound, the residue from a previously used compound, or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel soluble lubricant, such as engine lubricating oil, on the fitting threads. Do not use any other form of thread compound on the injection system fittings.

13-3. TROUBLE SHOOTING.

NOTE

Use this trouble shooting chart in conjunction with the engine trouble shooting chart in Section 12 or 12A.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
NO FUEL FLOW TO ENGINE-DRIVEN FUEL PUMP.		
Fuel selector valve not turned on.	Check position of selector valve.	Turn fuel selector valve on.
Fuel tank empty.	Check fuel quantity.	Service with proper grade and amount of fuel.
Fuel line disconnected or broken.	Inspect fuel lines.	Connect or repair fuel lines.
Fuel cell screen plugged.	Disconnect fuel line from cell outlet. No flow indicates plugged screen.	Remove and clean screen. Flush out fuel cell.
Defective fuel selector valve.	Disconnect inlet and outlet lines from valve. If fuel flows from inlet line but not through valve, it is defective.	Remove and repair or replace selector valve.
Plugged fuel strainer.	Inspect strainer.	Remove and clean strainer and screen.
Defective check valve in electric fuel pump.	Disconnect inlet and outlet lines from fuel pump. If fuel flows from inlet line but not through pump, it is defective.	Repair or replace electric pump.
Fuel line plugged.	Disconnect at fuel pump inlet. No flow indicates plugged line.	Disconnect lines as necessary to locate obstructions, then clean.
FUEL STRAVATION AFTER STARTING.		
Partial fuel flow from the preceding causes.	Use the preceding isolation procedures, checking for sufficient rate of flow.	Use the preceding remedies.
Malfunction of engine-driven fuel pump or fuel injection system.	Refer to Section 12 or 12A.	Refer to Section 12 or 12A.
Fuel vents plugged.	Check per paragraph 13-4.	See paragraph 13-4.
Water in fuel.	Open fuel strainer drain valve and check for water.	Drain fuel tank sumps, fuel lines, and fuel strainer.
NO FUEL FLOW WHEN ELECTRIC PUMP OPERATED.		
Defective fuel pump switch.	Check continuity of switch.	Replace defective switch.
Open or defective circuit breaker.	Check visually; if not open, check continuity.	Reset. Replace if defective.
Loose connections or open circuit.	Check connections and wiring.	Tighten connections; repair or replace wiring.
Defective electric fuel pump.	Disconnect outlet line. With proper fuel supply to pump, fuel under pressure should flow from pump.	Replace defective pump.

SHOP NOTES:

This image shows a single sheet of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page. There is no handwriting or other markings on the paper.





Figure 13-1. Fuel System Schematic




NOTE

There are minor differences in fuel line routing aft of reservoir tanks for the various models.

- | | |
|---|-----------------------------------|
| 1. Fuel Vent Line | 12. Selector-to-Strainer Line |
| 2. Fuel Vent Valve | 13. Vapor Return-to-Selector Line |
| 3. Forward Line Screen | 14. Electric Pump Drain Line |
| 4. Aft Line Screen | 15. Electric Fuel Pump |
| 5. Aft Fuel Line | 16. Fuel Strainer |
| 6. Forward Fuel Line | 17. Fuel Strainer Drain Line |
| 7. Aft Fuel Line | 18. Vapor Return Check Valve |
| 8. Left Reservoir | 19. Right Reservoir |
| 9. Reservoir-to-Selector Valve Line | 20. Selector Valve Handle |
| 10. Vapor Return Selector-to-Reservoir Line | 21. Forward Fuel Line |
| 11. Selector Valve | |

Figure 13-2. Fuel System




NOTE

This installation is applicable
to Model 210 Series.

- | | | |
|----------------------|----------------------|-------------------------|
| 1. O-Ring | 6. Fuel Line | 12. Strainer Drain Line |
| 2. Reducer | 7. Fuel Line | 13. Pump Drain Line |
| 3. Fuel Line | 8. Fuel Strainer | 14. Elbow |
| 4. Elbow | 9. L. H. Tunnel Wall | 15. Auxiliary Fuel Pump |
| 5. R. H. Tunnel Wall | 10. Pump Bracket | 16. Fuel Line |
| | 11. Clamp | |

Figure 13-3. Electric Fuel Pump and Strainer (Sheet 1 of 3)




1. Screw
2. Clamp
3. Duct
4. Aft Half Shroud
5. Forward Half Shroud
6. Auxiliary Fuel Pump
7. Gasket
8. Reducer

9. Pump Bracket
10. Bolt
11. Clamp
12. Elbow
13. Drain Line
14. Clamp
15. Screw
16. Grommet

17. Fuel Strainer
18. Fuel Hose
19. Elbow
20. Fuel Hose
21. Bolt
22. Clamp
23. Reducer
24. Gasket

Figure 13-3. Electric Fuel Pump and Strainer (Sheet 2 of 3)



1. Hose
2. Reducer
3. O-Ring
4. Auxiliary Fuel Pump
5. Grommet
6. Elbow
7. Fuel Strainer
8. Pump Bracket
9. Pump Drain Line
10. Clamp

NOTE

This installation is applicable to turbocharged 206 Series.

Figure 13-3. Electric Fuel Pump and Strainer (Sheet 3 of 3)

13-4. CHECKING FUEL VENTS. Field experience has demonstrated that the fuel vents can become plugged, causing possible fuel starvation of the engine or collapse of the fuel cell. Also the bleed hole in the vent valve assembly could possibly become plugged, allowing pressure from expanding fuel to pressurize the tanks. To check the vent and bleed hole in the vent valve assembly, proceed as follows:

- a. Attach a rubber tube to the end of the vent line beneath one wing.
- b. Turn off fuel selector valve.
- c. Blow into tube to slightly pressurize the tank. If air can be blown into tank, the vent line is open.
- d. After tank is slightly pressurized, insert end of rubber tube into a container full of water and watch for a continuous stream of bubbles, which indicate the bleed hole in valve assembly is open and relieving pressure.
- e. Repeat steps "a" through "d" for fuel vent beneath opposite wing.

NOTE

Remember that a plugged vent line or bleed hole can cause either fuel starvation and collapsing of fuel cell or the pressurizing of the cell by fuel expansion

- f. Any fuel vent found plugged or restricted must be corrected prior to returning airplane to service.

NOTE

The fuel vent line protruding beneath the wing near the wing strut must be correctly aligned to avoid possible icing of the vent tube. Dimensions are shown in figure 13-5.

13-5. FUEL CELLS.

13-6. These airplanes are equipped with rubberized bladder-type fuel cells, one of which is located in the inboard bay of each wing panel. The cells are secured by snap fasteners to prevent collapse of the flexible cells. The airplane may be equipped with either Goodyear or U.S. Rubber Company fuel cells. Goodyear and U. S. Rubber Company fuel cells are interchangeable; therefore, either type cell may be used. Goodyear fuel cells are BTC-37, or BTC-39 type construction and U.S. Rubber Company fuel cells may either be US-907N, US-943, or US-932 type construction. Repair procedures for the fuel cells differ for the typed used. Therefore, determine which fuel cell is used before repairs are attempted. To determine this, inspect the top outer surface of the fuel cell. Each fuel cell is marked as to manufacturer and type of construction.

13-7. GENERAL PRECAUTIONS. When storing, inspecting, or handling U.S. Rubber fuel cells the following precautions should be adhered to:

- a. Fuel cells should be stored in their original shipping containers at room temperature and with no more than normal humidity.
- b. Remove cells from shipping container only at time of installation.

- c. Inspect shipping container and cell for evidence of damage which may have occurred during shipping.
- d. When handling fuel cells, do not pick up cell by the fittings or drag cell over any surface.
- e. Do not handle cells with any sharp pointed tools or lay cell on any sharp edge or point.
- f. Use care when handling fuel cells to protect all projections, such as fittings.

When storing, inspecting or handling Goodyear fuel cells the following should be adhered to:

- a. Store cell in a cool dry room away from any electrical motors or direct heat.
- b. If for any reason a cell has been in use and is to be stored, clean cell with warm water and soap. Dry and wrap in as small a package as possible and place in a cardboard container.
- c. Handle cell carefully to protect all fittings and prevent damage to cell.

13-8. FUEL CELL REMOVAL AND INSTALLATION. When removing a fuel cell, the following procedure is suggested as a guide:

- a. Drain applicable fuel cell by removing drain plugs.

NOTE

When removing U.S. Rubber fuel cells, drain fuel and flush the cell with light weight (SAE 10) engine oil 24 hours before cell is removed or deformed in any way.

- b. Remove wing root fairings and disconnect fuel lines at wing root.
- c. Remove clamps from forward and aft fuel cell boss at wing root, and carefully work fuel strainer and line from cell boss.
- d. Disconnect electrical lead and ground strap from fuel quantity transmitter. Remove transmitter by removing attaching screws and carefully work it from fuel cell and wing rib.
- e. Remove screws attaching drain adapter to lower surface of wing.
- f. Remove clamps and work overboard vent line from cell. Remove vent valve from inside of fuel cell.
- g. Remove fuel filler adapter and gaskets by removing screws attaching adapter to wing and fuel cell. On airplanes equipped with long range tanks, remove cover plate and gaskets.
- h. Working through filler neck opening, loosen snap fasteners. Tilt snap fasteners slightly when pulling cell free, to prevent tearing the rubber.
- i. Collapse and carefully fold cell for removal, then work cell out of fuel cell bay through filler opening. Use care when removing and prevent damage to cell.
- j. Unfold cell and remove fittings, snap fasteners and fuel sump drain adapter.

To install a new or repaired fuel cell, proceed as follows:

- a. Cell compartment must be thoroughly cleaned of all fittings, trimmings, loose washers, bolts, nuts, etc.
- b. All sharp edges of cell compartments must be




Figure 13-4. Fuel Cell Installation

rounded off and protective tape applied over all sharp edges and protruding rivets.

c. Inspect cell compartment just prior to installation of a cell for the above mentioned conditions.

d. Install fuel drain adapter and snap fasteners.

e. Check to be sure cell is warm enough to be flexible and fold as necessary to fit through fuel cell access opening.

f. Place fuel cell in compartment, develop it out to its full size and attach snap fasteners, then reverse the removal procedures for installation. When fastening snap fasteners, tilt the fastener to one side slightly to prevent placing a strain on the rubber.

g. Install all new gaskets when installing fuel cell.

h. When tightening screw-type clamps, apply a maximum of 20 pound-inches of torque to clamp screws. No oil is to be applied to fittings prior to installing.

i. When installing filler adapter, cover plate, and fuel quantity transmitter to the wing and fuel cell, tighten attaching screws evenly. The sealing or compression surfaces must be assembled when absolutely dry (NO SEALING PASTE TO BE USED).

j. After installation has been completed, cell should be inspected for final fit within compartment, making certain that cell is extended out to the structure and no corners are folded in.

k. The final inspection prior to closing the cell should be a close check to be sure cell is free of foreign matter such as lint, dust, oil, or any installation equipment. If cell is not thoroughly clean, it should be cleaned with a lint-free cloth soaked in water, alcohol, or kerosene. NO OTHER SOLVENT SHALL BE USED.

NOTE

Throughout the airplane fuel system, from the tanks to the engine-driven fuel pump, use Parker Sealube (or equivalent) as a thread lubricant or to seal a leaking connection. Apply sparingly to male fittings only, omitting the first two threads. Always be sure that a compound, the residue from a previously used compound, or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel soluble lubricant, such as engine lubricating oil, on the fitting threads. Do not use any other form of thread compound on the injection system fittings.

13-9. FUEL CELL PRESERVATION. The following is a reprint of U.S. Rubber Company directive:

"When synthetic rubber fuel cells are placed in service, the gasoline has a tendency to extract the plasticizer from the inner liner of the cell. This extraction of plasticizer is not detrimental as long as gasoline remains in the fuel cells, as the gasoline itself will act as a suitable plasticizer. When the gasoline is drained from the fuel cell, the plasticizing effect of the gasoline is lost and the inner liner of the cell begins to dry out and subsequent cracking or check-

ing will occur. This cracking or checking may penetrate through the inner liner permitting gasoline to diffuse through walls of the cell after the cell has been re-fueled. To prevent this failure, a thin coating of light engine oil should be applied to the inner liner of all serviceable fuel cells, which have contained gasoline, when it is evident that the cells will remain without fuel for more than ten days, whether installed in airplanes or in storage. The oil will act as a temporary plasticizer and will prevent the inner liner from drying and cracking. If it becomes necessary to return the cell to the contractor or the vendor for testing or repair, do not allow quantities of oil to be puddled in the cell as it will make handling and repair much more difficult. Cells should be repacked as similar to the original factory pack as possible."

13-10. FUEL CELL REPAIRS.

13-11. U.S. RUBBER - US-907N AND US-943 CELLS.

WARNING

No repairs are to be made on the radius of a cell or in the fitting area of a cell. No damaged areas such as cuts and tears larger than one inch are to be repaired in the field. Cells with such damage should be replaced, or repaired by the manufacturer. Arrangements for manufacturer to repair a fuel cell should be made through Cessna.

OUTSIDE OF CELL:

a. Use a piece of synthetic rubber coated fabric (U. S. Rubber 5200 outside repair material) large enough to cover damage at least 2" from cut in any direction. Buff this material lightly and thoroughly with garnet paper and wash with Methyl Ethyl Ketone (U.S. Rubber Co. 3339 solution) to remove buffing dust.

b. Cement buffed side of patch with two coats of U.S. Rubber Co. 3230 cement or Minnesota Mining Co. EC-678. Allow each coat to dry 10-15 minutes.

c. Buff cell area to be patched lightly and thoroughly with garnet paper and wash with 3339 solution to remove buffing dust.

d. Cement buffed area with two coats of U.S. Rubber 3230 or Minnesota Mining Co. EC-678 cement. Allow each coat to dry 10-15 minutes.

e. Freshen cemented area of patch and cemented area of cell with 3339 solution.

f. While still tacky, apply edge of patch to edge of cemented area on the cell. With a roller or blunt instrument, roll or press the patch to the cemented area and roll or press it down a half-inch to an inch across at a time so as not to trap air between patch and cell. Lay 50 lb shot bag over patch which is protected by piece of Holland Cloth to prevent sticking. Weight should not be removed for 6 hours.

g. Seal coat edge of patch 1/2" with one coat of U.S. Rubber 3230 or Minnesota Mining Co. EC-678 cement and allow the cement to dry thoroughly.

INSIDE OF CELL:

a. After the damaged area has been patched on the outside of the cell and the repair allowed to stand a minimum of 6 hours, the cell is then ready to have




Figure 13-5. Fuel Vent Location

the patch applied on the inside of the cell.

b. Lightly and thoroughly buff a piece of cured U.S. Rubber 5200/5187 nylon sandwich material large enough to cover damage at least 2" from cut in any direction. Wash buffing dust off patch with Methyl Ethyl Ketone solution (U.S. Rubber 3339).

c. Cement buffed side of patch with two coats of black rubber cement, U.S. Rubber 3230 or Minnesota Mining Co. EC-678, and allow each coat to dry 10-15 minutes.

d. Buff cell area to be patched lightly and thoroughly with fine sandpaper (#"0") and then wash off buffing dust with Methyl Ethyl Ketone solution (U.S. Rubber 3339).

e. Coat buffed area with two coats of black rubber cement, U.S. Rubber 3230 or Minnesota Mining Co. EC-678, and allow each coat to dry 10-15 minutes.

f. Freshen cemented area of patch and cemented area of cell with Methyl Ethyl Ketone (U.S. Rubber 3339) solution.

g. While still tacky, apply edge of patch to edge of cemented area, centering patch over cut in cell. With a roller or blunt instrument, roll or press the patch to the cemented area on the cell. Hold part of patch off the cemented area and roll or press it down a half-inch to an inch across at a time so as not to trap air between patch and cell. Apply 50 lb shot bag to repaired area and do not disturb for 6 hours.

h. Seal coat patch and 1/2" from edge of patch with two coats of U.S. Rubber 3230 or Minnesota Mining Co. EC-678 cement. Allow the first coat to dry one hour or more. Wipe patch and cemented area lightly with #10 oil, so that when the cell is in its original position the patch area will not stick to other areas of the cell.

SCUFFED FABRIC:

- Buff area surrounding scuffed fabric.

b. Wash buffing dust from area with 3339 solution.

c. Apply two coats of U.S. Rubber 3230 or Minnesota Mining Co. EC-678 cement to the buffed area, allowing 10 minutes drying time between coats.

NOTE

A fuel cell repair kit, U.S. Rubber Kit No. RK-30S, contains all the necessary materials to repair a US-907N or a US-943 fuel cell. This kit is available from the Cessna Service Parts Center.

13-12. U.S. RUBBER - US-932 CELLS.

REPAIRS. All field repairs are to be made by FAA certificated repair stations using the Repair Kit RK-932 which is available from the Cessna Service Parts Center. Fuel cells should be pressure tested before repair and 24 hours after repair using the procedure outlined in paragraph 13-13.

WARNING

No repairs are to be made on the radius of a cell or in the fitting area of a cell. No damaged areas such as cuts and tears larger than one inch are to be repaired in the field. Cells with such damage should be replaced, or repaired by the manufacturer. Arrangements for manufacturer to repair a fuel cell should be made through Cessna.

KIT CONTENTS. Following is a list of materials contained in the kit:

DESCRIPTION

QUANTITY

3413 Patching Material	(one)	Piece Urethane Film 8" x 8"
5356 Patching Material	(one)	Piece Urethane Nylon Fabric 8" x 8"
Paint Brushes	(five)	1/2" Commercial
3339 Solvent	(one)	1/2 Pint Can
Emery Cloth	(five)	Pieces 4 1/2" x 5 1/2" # 180 Grit
Cheese Cloth	(one)	Piece 18" x 36"
3420-A Adhesive	(five)	1/2 Pint Cans, 32 Grams Each
3420-B Adhesive	(five)	Plastic Containers 2 Grams Each
Spatula	(five)	Wooden

TYPES OF REPAIRS:

- Use patches of Urethane film for small pin hole type leaks.
- Use fabric patches for tears or cuts up to 1" long.
- Patches may be applied to either the inside or the outside surface of the fuel container, whichever is more convenient.
- Use a patch that will extend a minimum of 1" in every direction beyond the area to be repaired.

MIXING INSTRUCTIONS FOR ADHESIVES.

- Cut a small hole in the plastic container and pour contents (3420-B) into the can containing the 3420-A.
- Mix well with wood spatula (tongue depressor).
- Allow mixture to stand for 10 minutes.
- Mix again.
- The mixed adhesive (3420) must be kept in a closed container until used. Once this adhesive has been mixed, it must be used within 12 hours.

PREPARATION FOR REPAIR.

- Wash damaged area on fuel container with 3339 solvent. Surface must be clean and dry.
- Buff area to be repaired with emery cloth and wipe clean with a cheesecloth swab dampened in 3339 solvent. Buffed area should be larger than repair patch.
- Buff and clean one side of repair patch as outlined in step b above.
- Cement buffed surfaces of patch and article to be repaired with two coats of mixed adhesive, allowing each coat to dry 10 minutes. Between adhesive coat applications, brush may be kept in 3339 solvent.

PATCH APPLICATION.

- Allow cemented surfaces to dry until tacky.
- Center patch over damaged area and apply slowly, 1/2" to 1" at a time, making sure no air is trapped under the patch.
- Apply pressure by rubbing a well rounded screw-driver handle (or similar tool) across the patch.
- Weight or clamp repaired area between two pieces of wood (or metal) for a minimum of 8 hours with waxed paper (or similar material) between the repair and clamping blocks to prevent sticking. Avoid sharp edges on clamping blocks or plates.

CAUTION

Do not disturb repair for 24 hours and repaired container should be aged for 5 days at temperatures of 60°F to 80°F before returning to service.

13-13. FUEL CELL TESTING - U.S. RUBBER.

PROCEDURE FOR PHENOLPHTHALEIN - AMMONIA TESTING. When cells are removed from the airplane for suspected leakage, the following method for locating leaks may be used. This method may also be employed after local repairs have been made to check both the efficiency of the repair and presence of other leaks not originally found.

MATERIALS NEEDED:

- Commercial or household ammonia (28-29% concentration).
- Indicator solution -- contents per gallon as follows:
 - 1/2 gallon of distilled water.
 - 1/2 gallon of denatured alcohol.
 - 15 grams of phenolphthalein crystals or powder.
- Approximately three yards of balloon cloth or airplane cloth.

PROCEDURE:

- Pour ammonia on an absorbent cloth at the rate of 3cc per cubic foot of cell capacity with a minimum of 10cc. Place saturated cloth inside cell.
- Close all openings and apply positive test air pressure of 1/4 psi (4 ounces).

CAUTION

Never inflate an unsupported cell above a pressure of 1/4 psi (4 ounces). Pressures in excess of four ounces may damage the cell.

- Soak cloth in phenolphthalein indicator solution.
- Wring out cloth and spread evenly and smoothly over area of cell being checked.
- Check all surfaces of cell. Leaks will be indicated by the appearance of pink spots on the cloth.

PRECAUTIONS:

- Extreme caution must be maintained to prevent cover plates from damaging or cutting the cell during installation, phenol test, deflation and removal.
- Unsupported test must be conducted on a flat, dirt free surface having no sharp projections or anything which could damage the inflated cell. An unsupported bladder cell can be inflated only to a pressure of 1/4 psi (4 ounces) maximum. Any pressure in excess of this will cause damage or rupture of cell.
- If phenolphthalein-ammonia solution is used more than 8 hours a new solution should be prepared.

13-14. GOODYEAR BTC-37 OR BTC-39 CELLS.

GENERAL PRECAUTIONS. When storing, inspecting or handling Goodyear fuel cells, the following should be adhered to:

- a. Fold cells smoothly and lightly as possible with a minimum number of folds. Place protective wadding between folds.
- b. Wrap cells in moisture-proof paper and place it in a suitable container. Do not crowd cell in container, use wadding to prevent movement.
- c. Stacked boxed cells to allow access to oldest cells first. Do not allow stacks to crush bottom boxes. Leave cells in boxes until used.
- d. Storage area must be cool +30°F to +85°F, and free of exposure to sunlight, dirt, and damage.
- e. Used cells must be cleaned with soap and warm water prior to storage. Dry and package as outlined in the preceding steps.
- f. Do not carry cells by fittings. Maintain original cell contours or folds when refolding for boxing.

NOTE

Prior to removal of Goodyear fuel cells, drain fuel, purge with fresh air, and swab out to remove all traces of fuel.

REPAIRS. All field repairs should be made on a suitable size, well-lighted table, having a flat, smooth, clean surface. Prevent contact with sharp edges, corners, dirty floors or other surfaces. Repair area must be well ventilated.

WARNING

DO NOT PERMIT SMOKING OR OPEN FLAME NEAR REPAIR AREA OR FUEL CELLS.

Use Repair Kit No. 2F1-3-35342, which is available from the Cessna Service Parts Center. Fuel cells should be tested before and after repair using the procedure outlined in paragraph 13-15.

WARNING

No repairs are to be made on the radius of a cell or in the fitting area of a cell. No damaged areas such as cuts and tears larger than three inches are to be repaired in the field. Cells with such damage should be replaced, or repaired by the manufacturer. Arrangements for manufacturer to repair a fuel cell should be made through Cessna.

KIT CONTENTS. The following is a list of materials contained in the repair kit:

DESCRIPTION	QUANTITY
*2331C Repair Cement	(8) (1/2 pint cans, 173 cc in each can)
*2328C Cross-Linker	(8) (1 oz bottles, 28cc in each bottle)
Methyl Ethyl Ketone	(2) (1 pint cans)
FT-160 Repair Fabric	(2) (12" x 12" sheets)
Cellophane	(4) (12" x 24" sheets)
Foam Rubber Cloth Back	(2) (12" x 12" sheets)

*At room temperature, the shelf life of 2331C Repair Cement and 2328C Cross-Linker is six months from date of packaging.

Additional equipment necessary to perform repairs on Goodyear fuel cells are as follows:

DESCRIPTION	QUANTITY
Paint Brush	(1) (1")
Roller	(1) (1" diameter x 34" flat or equivalent)
Aluminum Plates	(2) (1/4" x 6" x 6")
Cure Iron	(1) (Goodyear Part No. 2F1-3-25721)

REPAIR LIMITATIONS.

- a. Outside patches are to lap defect at least two and one quarter inches in any direction from cut.
- b. Inside patches are to lap defect at least two inches in any direction from cut.
- c. Outside patches are to be applied and cured prior to applying an inside patch.

d. Blisters between innerliner and fabric larger than one inch in diameter require an outside and an inside patch.

e. Separations between outer plies larger than one inch require an outside and inside patch. All holes and punctures require an outside and inside patch.

f. Slits or tears up to three inches maximum length

require an outside and inside patch.

g. External abraided or scuffed areas without fabric damage require an outside patch only.

h. A loose lap may be trimmed provided that one inch effective bond remains.

i. Air cure repair patches are to remain clamped and undisturbed for 72 hours at room temperature of approximately 75 degrees F.

PREPARATION FOR REPAIR.

a. Wash damaged area on fuel cell with Method Ethyl Ketone.

NOTE

When cleaning fuel cell, use a lint free cloth dampened with Methol Ethyl Ketone and clean an area of approximately one square foot surrounding the damaged area. A total of three separate washings are recommended to assure cleanliness.

b. Cut a patch from repair material large enough to cover damaged area by at least two and one quarter inches in any direction from damage.

c. Taper edges and round corners of patch so as to present a feather edge to the cell when patch is applied.

d. Abraid cell wall surface about injury and contact side of patch with fine emery cloth to remove shine.

e. Repeat Methol Ethyl Ketone washing two more times. A total of three washings each surface.

f. Tape a piece of cellophane inside cell over injury. This is done to prevent cell walls from becoming stuck together when applying cement and patch.

g. When all of the preceding preparatory work has been done and cell has been positioned on repair table, mix cement as follows:

MIXING ADHESIVES. Mix repair cement 2331C (1/2 pint can with 173cc) with cross-linker 2328C (1 ounce bottle with 28cc) and stir thoroughly.

NOTE

Mixing cement is done immediately prior to use. The mixed cement has a pot life of 25 minutes after mixing. 2331C repair cement requires thorough mixing to obtain full adhesive values.

Brush one even coat of mixed repair cement on the cell wall around injury and on the contact side of repair patch. Allow this coat of cement to dry for twenty minutes.

PATCH APPLICATION.

a. Repeat a second mixing of repair cement and brush a second coat on the cell wall around injury and on the contact side of repair patch.

CAUTION

Do not use first can of mixed cement for second coat. Pot life of mixed cement is 25 minutes.

b. After the second coat of cement has been applied, and ten minutes of drying time allowed, center re-patch over injury.

c. With a roller, roll or press patch to cemented area of cell, starting at center of patch and working to outside edge to prevent air from being trapped between patch and cell. Hold the unrolled portion of repair patch off the cemented surface until roller contact insures an air free union. At this time, re-patch may be moved on wet surface to improve lay. Do not lift repair patch, slide it.

NOTE

Make sure cellophane inside cell over injury remains in place as it will prevent the inside surfaces of the cell being cemented together when clamp is placed on patch.

d. Cover one surface of each of the aluminum plates (plates must be larger than patch) with fabric-backed airfoam, fabric side out. Tape airfoam in place. Foam must cover edges of plate for protection.

e. Fold cell adjacent to patch and place prepared plates, one over repair patch, and one on opposite side.

f. Secure the assembly with a "C" clamp. Tighten by hand. Check cement flow to determine pressure.

NOTE

Make sure that cell fold is not clamped between plates. This would cause a hard permanent crease. Also, make sure that patch does not move as clamp is tightened.

g. Leave cell clamped to air cure for 72 hours.

NOTE

Air cure repairs are to be made at room temperature of approximately 75°F. For each 10 degrees drop in temperature, add 25 per cent cure time. Example: room temperature is 64 degrees, air cure for 90 hours instead of 72 hours.

h. After cure time has expired, remove clamp, metal plate, foam rubber, and cellophane. To remove cellophane, use a wet cloth or sponge to dampen cellophane and remove by peeling off.

i. Inspect repair for any loose edges or unsatisfactory conditions. If a loose edge is found and it is no more than 1/4 inch, it is permissible to trim and buff loose edge.

j. Inside patch is applied in the same manner as the outside patch except for size of repair patch after the outside patch has been cured.

NOTE

Success of applying an outside and inside repair patch simultaneously is doubtful and not recommended.

REPAIR PATCH-HEAT.CURE METHOD. Follow procedures for air cure method, except attach cure

iron to assembly during step "f", and plug electric cord into electrical outlet.

NOTE

After two hours cure time with cure iron, unplug electric and allow repair iron to cool for 15 minutes. Then remove "C" clamp, plates and cellophane. All heat cured patches are ready for use when thoroughly cooled.

13-15. FUEL CELL TESTING – GOODYEAR. Fuel cells should be tested after repair and before installation. Either of the following test procedures may be used; however, the chemical test is the more sensitive and preferred test.

SOAP SUDS TEST.

- a. Install test plates on all fitting openings.
- b. Inflate the cell with air to a pressure of 1/4 psi (4 ounces) maximum.

CAUTION

Never inflate an unsupported cell above a pressure of 1/4 psi (4 ounces). Pressures in excess of four ounces may damage the cell.

- c. Apply a soap and water solution to all repaired areas and all areas which are suspected of leakage. Bubbles indicate leakage in the cell.
- d. After completion of test, clean exterior of cell and remove test plates.

CHEMICAL TEST.

- a. Install test plate on all but one fitting opening.
- b. Pour ammonia on an absorbent cloth in the ratio of 3cc per cubic foot of cell capacity.
- c. Place the ammonia saturated cloth inside cell and install test plate on opening.
- d. Make a phenolphthalein solution as follows: Mix 40 grams of phenolphthalein crystals in 1/2 gallon of ethyl alcohol. To this solution add 1/2 gallon of water.
- e. Inflate the cell with air to a pressure of 1/4 psi (4 ounces) maximum.
- f. Soak a large white cloth in the phenolphthalein solution.
- g. Wring cloth out thoroughly and spread evenly and smoothly over outer surface of cell.
- h. Check all surfaces of cell. Leaks will be indicated by the appearance of red spots on the cloth. If red spots appear on the cloth, they may be removed by soaking the cloth in the phenolphthalein solution.

NOTE

The phenolphthalein solution and test cloth are satisfactory only as long as they remain clean. Indicator solution that is not in immediate use should be stored in a closed container to prevent evaporation and deterioration.

- i. After completion of test, remove all test plates and test equipment. Allow cell to air out.

13-16. REMOVAL AND INSTALLATION OF FUEL GAGE TRANSMITTER.

- a. Drain fuel from cell.
- b. Remove wing root fairing to gain access to transmitter.
- c. Disconnect electrical leads at transmitter.
- d. Remove screws through unit and root rib.
- e. Replace the unit by reversing the steps listed above. Use no gasket paste on rubberized cells.
- f. Fill cell with fuel to check for leaks and correct gage indication (see paragraph 16-44).

13-17. REMOVAL AND INSTALLATION OF FUEL RESERVOIR TANKS.

- a. Remove front seats, carpeting, and access plates as necessary for access to tank to be removed.
- b. Disconnect fuel lines at the tank to be removed.
- c. Remove four screws securing tank mounting legs to fuselage structure.
- d. Lift out the tank.
- e. Reverse the preceding steps to install a reservoir tank.

13-18. REMOVAL AND INSTALLATION OF FUEL SELECTOR VALVE.

- a. Drain all fuel from wing tanks at fuel tank sump drain plugs. With valve turned to LEFT TANK, drain left fuel lines at selector valve; with valve turned to RIGHT TANK, drain right fuel lines.
- b. Remove control pedestal cover. (Refer to paragraph 11-5 for procedure.)
- c. Remove access hole covers in floorboard and fuselage skin in area of fuel selector valve.
- d. Disconnect all fuel lines from selector valve.
- e. Disconnect square shaft from valve by removing attached roll pin.
- f. Remove bolts or screws attaching valve to support bracket and remove valve.
- g. Install valve by reversing this procedure.

13-19. FUEL SELECTOR VALVE REPAIR. (See figure 13-6.) The fuel selector valve may be repaired by disassembly, replacement of defective parts, and reassembly as follows:

- a. Mark sump plate (23) and body (1) to ensure correct reassembly, then remove sump plate (23) and O-ring (22) after removing four screws.
- b. Drive out roll pin (5) securing yoke (6) to shaft. As yoke is lifted off, balls (8) and springs (7) are free. Retain them.
- c. Lift off washer (9).
- d. Mark cover (4) and body to assure later alignment of parts and remove screws (3).
- e. With fine emery paper, sand off any burrs or sharp edges on shaft (21). Apply petrolatum to shaft as a lubricant, then work cover off shaft.
- f. Drive back roll pin (13) and remove rotor (12). Teflon seal (14), O-rings (15), washers (16), and springs (17) are now free to be removed. Check all parts carefully to locate any defects.
- g. Remove burrs or sharp edges on shaft, lubricate and slide it down, out of body (1). Remove teflon seals (20) and O-rings (19).
- h. Remove O-ring (18) within body and O-ring (10) within cover.
- i. Replace all O-rings, lap or replace teflon

seals, and lubricate O-rings before installation.

CAUTION

Install all parts in the relative position depicted in figure 13-6, otherwise the valve will not operate correctly.


j. Install O-ring (18) in body shaft hole. Install O-rings (19) and teflon seals (20), then slide shaft and rotor into place. Position rotor in exact relative position shown in figure 13-6, then install O-ring (22) and sump plate (23).

k. Install .169" diameter pins in body ports, then slide springs (17), washers (16), O-rings (15) and teflon seals over pins. Slide rotor (12) over shaft. Remove .169" dia. pins and, readjusting rotor vs. shaft position as necessary, tap roll pin (13) into place, letting it protrude on the side depicted.

NOTE

This roll pin serves also as a stop, limiting valve shaft travel.

1. Install O-ring (10) in cover, lubricate shaft (21)



1. Valve Body
2. Lockwasher
3. Screw
4. Cover
5. Roll Pin
6. Yoke
7. Spring
8. Ball
9. Brass Washer

10. O-Ring
11. O-Ring
12. Rotor
13. Roll Pin
14. Seal
15. O-Ring
16. Washer
17. Spring

18. O-Ring
19. O-Ring
20. Seal
21. Rotor
22. O-Ring
23. Sump Plate
24. Screw
25. Washer
26. Spring

Figure 13-6. Fuel Selector Valve

with petrolatum, install large O-ring (11), and slide cover down into place.

CAUTION

Make sure cover is installed in relative position illustrated. A lug on the cover protrudes to serve as a stop detent and if the cover is not installed correctly, the valve will not operate correctly.

m. Install brass washer (9) and yoke (6). Note the position of the small hole in the squared, upper portion of the yoke. If this is reversed, the valve linkage will not attach properly.

13-20. **ELECTRIC FUEL PUMP.** The electric fuel pump on the Model 206 Series is located on the fire-wall. On the Model 210 Series, the pump is mounted in the nose gear wheel well. An integral bypass and check valve permits fuel flow through the pump even when the pump is inoperative but prevents reverse flow. A separate overboard drain line from the pump prevents entry of fuel into the electric motor, in the event of pump internal leakage.

13-21. **DISASSEMBLY.** (See figure 13-7.)

a. Remove screws (29) and washers (13), and separate motor from pump.

CAUTION

Use care when removing screws (29) as spring (20) is under compression.

13-22. **DISASSEMBLY OF MOTOR.**

- a. Loosen screws (19) but do not remove.
- b. Remove cover (3) by removing screws (1) and washers (2).
- c. Remove brush holders (6) and brush assemblies (7) by removing screws (5).
- d. Loosen screws (19) and remove end bell (8), but do not remove screws (19) from shaft end bell (18).
- e. Remove bearing (9) from end bell (8).
- f. Remove armature (11).
- g. Remove springs (12), washers (13), field (14), shell (15), spacers (17), screws (19), and washers (2) from shaft bell end (18).
- h. Remove bearing (9) from shaft bell end (18).
- i. Do not remove spacer (22), truarc rings (10), or motor shaft pin (21) unless replacement is necessary.

13-23. **INSPECTION OF MOTOR COMPONENTS.**

- a. Thoroughly wash all parts of motor, except brushes (7), bearings (9), armature (11), and field (14), in cleaning solvent (Federal Specification P-S-661, or equivalent) and dry with filtered compressed air.
- b. Wipe parts not washed in solvent with a clean cloth.
- c. Inspect all parts for damage and evidence of excessive wear.
- d. Inspect all parts for breakage or distortion.
- e. Replace any worn or damaged parts.

13-24. **REASSEMBLY OF MOTOR.** The assembly procedure for the motor is the reverse of the dis-

assembly procedure. When reassembling, pay special attention to the following items:

- a. Spacers (17), springs (12), and washers (13) must be held in place by screws (19) when assembling end bell (8).
- b. Compress end bell (8) until screws (19) are engaged, then tighten screws (19) evenly to a torque value of 10 pound-inches.
- c. Brushes (7) are contoured, therefore the contour of the brush must match the armature commutator when being installed.

13-25. **DISASSEMBLY OF PUMP.**

- a. Remove pin (23) and remove slinger ring (41)
- b. Remove bearing and seal assembly (40) and rotor and shaft assembly (39) from pump body (30).

NOTE

Vanes (25) and pins (26) are attached to rotor (39) and are removed with rotor and shaft assembly.

- c. Remove spacer (38), bearing plate (37), O-ring (27), and body bearing (28) from pump body (30).

13-26. **INSPECTION OF PUMP COMPONENTS.**

- a. Thoroughly wash all parts in cleaning solvent (Federal Specification P-S-661, or equivalent) and dry with filtered compressed air.
- b. Inspect all parts for damage and evidence of excessive wear.
- c. Replace all O-rings, and bearing and seal assembly.
- d. Replace any damaged or worn parts.

13-27. **REASSEMBLY OF PUMP.** The assembly procedure for the pump is the reverse of the disassembly procedure. When reassembling, pay special attention to the following items:


- a. Pin (36) must be correctly located in pump body (30) in order to properly position bearing plate (37) and spacer (38). Location holes in bearing plate and spacer must align with pin.
- b. Vanes (25) and pins (26) must be assembled to the rotor and shaft assembly (39), and held in place while installing in pump body (30).
- c. Use a suitable lubricant on O-rings to prevent damage when installing. A recommended lubricant for O-rings is Dow Corning Silicone No. 4.

13-28. **DISASSEMBLY OF BYPASS AND PRESSURE RELIEF.**

- a. Remove nameplate (34), plug assembly (33), spring (32), and swing check assembly (31) from pump body (30).

13-29. **INSPECTION OF BYPASS AND PRESSURE RELIEF.**

- a. Thoroughly wash all parts in cleaning solvent (Federal Specification P-S-661, or equivalent) and dry with filtered compressed air.
- b. Inspect all parts for damage and evidence of excessive wear.
- c. Inspect swing check assembly seat for damage.
- d. Replace O-rings and all other damaged parts.



- | | | |
|--------------------|----------------------|-------------------------------|
| 1. Screw | 15. Shell | 28. Body Bearing |
| 2. Lockwasher | 16. Nameplate | 29. Screw |
| 3. Cover | 17. Spacer | 30. Pump Body |
| 4. Grommet | 18. Shaft End Bell | 31. Swing Check Assembly |
| 5. Screw | 19. Screw | 32. Spring |
| 6. Brush Retainer | 20. Retention Spring | 33. Adjusting Plug |
| 7. Brush Assembly | 21. Motor Shaft Pin | 34. Nameplate |
| 8. End Bell | 22. Spacer | 35. O-Ring |
| 9. Bearing | 23. Slinger Pin | 36. Housing Pin |
| 10. Truarc Ring | 24. Bearing O-Ring | 37. Bearing Plate |
| 11. Armature | 25. Vane | 38. Spacer |
| 12. Spring | 26. Vane Pin | 39. Rotor and Shaft Assembly |
| 13. Lockwasher | 27. Bearing O-Ring | 40. Bearing and Seal Assembly |
| 14. Field Assembly | | 41. Slinger Ring |

Figure 13-7. Electric Fuel Pump

13-30. REASSEMBLY OF BYPASS AND PRESSURE RELIEF. The assembly procedure for the bypass and pressure relief is the reverse of the disassembly procedure. When reassembling, pay special attention to the following:

a. Install swing check assembly (31) so it is seated on seat in pump body (30). The valve must open inwardly.

13-31. ADJUSTING PRESSURE RELIEF.

a. Install pump assembly in appropriate test stand. (See figure 13-8.)

b. While maintaining a no flow condition, adjust plug (33) until a relief pressure of 23 to 24 psi is obtained.

c. After correct pressure is obtained, seal plug (33) at threads with Epocast Epoxy No. 212-10 mixed with hardener No. 9816 (Reference: Furane Plastics.)

d. Allow Epoxy to dry and install nameplate (34).

13-32. FUNCTIONAL TEST PROCEDURE. Each unit shall be set up in test stand as shown in figure 13-8 and functionally tested as follows:

a. Flow Tests.

1. Apply 14 vdc to test unit.


2. With valves "A" and "B" closed, adjust valve "C" to outlet pressures of 5.0 psi increments until maximum relief is reached at no flow.

NOTE

No flow pressure shall be 27.5 psig maximum.

b. Bypass Pressure Drop.


1. With test unit shut off, open valves "A" and "B".



NOTE

ALL PLUMBING TO BE 1/2-INCH TUBING.

Figure 13-8. Test Stand Schematic



1. Spring
2. Washer
3. Plunger
4. Top
5. Drain Control

6. Plate
7. O-Ring
8. Gasket
9. Filter
10. Retainer Ring

11. Standpipe
12. O-Ring
13. Bowl
14. O-Ring
15. Drain Line

Figure 13-9. Fuel Strainer

2. Close valve "C" and energize bypass pump.
3. Adjust valve "B" until flowmeter reads 40 gph and record inches of mercury as read on Hg manometer.

NOTE

Pressure drop shall not exceed 0.60 inches of mercury. Bypass pressure drop is 0.35 psi maximum at 40 gph.

c. Insulation Resistance Test.

1. Apply 50 volts dc across both leads and pump case. Insulation resistance shall be 50 megohms minimum.

13-33. ELECTRIC FUEL PUMP CIRCUITS. The electric fuel pump circuit is operated by a split rocker-type switch. The low side of the switch is connected through the "START" position of the ignition switch so that the fuel pump will operate only while the ignition switch is in the "START" position and the low side of the fuel pump switch is turned on. When the ignition key is released, the pump will stop. The high side of the fuel pump switch will operate the pump regardless of ignition switch position. A throttle shaft operated microswitch adds a resistance to the high circuit to slow down the pump when the throttle is retarded to prevent an excessively rich mixture as throttle is retarded while the electric pump is operating in the high position. Refer to Section 12 for rigging of the microswitch.

NOTE

On the Model 210 Series, a landing gear warning system microswitch is also operated by the throttle shaft.

13-34. FUEL STRAINER. The fuel strainer is located in the nose wheel well in the Model 210 Series, and is readily accessible with the nose gear doors open. In the Model 206 Series, the fuel strainer is located in the forward tunnel area and the tunnel panel doors must be removed for access to the fuel strainer. The strainer is equipped with a drain valve control operated from the cabin on models prior to 1968. Beginning with the 1968 models, the fuel strainer drain control has been re-located adjacent to the oil dipstick. Access to the strainer drain control is made through the oil dipstick cowl door.

13-35. FUEL STRAINER DISASSEMBLY. (See figure 13-9.) To disassemble and assemble the strainer, proceed as follows:

- a. Turn off fuel selector valve.
- b. Disconnect strainer drain tube and remove safety wire, nut, and washer at bottom of filter bowl and remove bowl.
- c. Carefully unscrew standpipe and remove.
- d. Remove filter screen and gasket. Wash filter screen and bowl in solvent (Federal Specification P-S-661, or equivalent) and dry with compressed air.
- e. Using a new gasket between filter screen and top assembly, install screen and standpipe. Tighten standpipe only finger tight.
- f. Using all new O-rings, install bowl. Note that step-washer at bottom of bowl is installed so that step seats against O-ring. Connect strainer drain tube.
- g. Turn on fuel selector valve, close strainer drain, and check for leaks. Check for proper operation.
- h. Safety wire bottom nut to top assembly. Wire must have right hand wrap, at least 45 degrees.

SHOP NOTES:

SECTION 13A

FUEL SYSTEM (CANTILEVER WING)

TABLE OF CONTENTS

	Page		Page
FUEL SYSTEM	13A-1	Sealing During and After Structural	
Trouble Shooting	13A-1	Repair.	13A-5
FUEL VENTS	13A-1	Sealing Fuel Leaks	13A-8
Removal	13A-1	CURING TIME	13A-8
Installation	13A-2	Testing	13A-8
Checking	13A-2	FUEL QUANTITY TRANSMITTERS	13A-9
FUEL TANKS	13A-4	Removal	13A-9
FUEL TANK LEAKS	13A-4	Installation	13A-9
Classification	13A-4	FUEL TANK PURGING	13A-9
Sealants	13A-4	REMAINDER OF FUEL SYSTEM	13A-9

13A-1. FUEL SYSTEM.

NOTE

The fuel system as described in this section does not include the fuel injection system. Refer to Section 12 or 12A for that part of the fuel system.

13A-2. Fuel from the tanks in the wings is gravity-fed through fuel reservoir tanks installed forward of the front doorpost bulkheads, beneath the cabin floor, to the engine-driven fuel pump. The fuel line from the lower forward corner of each fuel tank to the reservoir tank serves as a combination fuel feed and vapor return line. The fuel bypasses the electric auxiliary fuel pump when it is not in operation. The fuel tanks are individually vented overboard through vent lines with a check valve located at each wing tip.

WARNING

Fuel draining from fuel tanks and disconnected lines or hoses constitutes a fire hazard. Adequate safety precautions should be taken whenever it is necessary to drain fuel or to disconnect lines or hoses.

NOTE

Throughout the airplane fuel system, from the tanks to the engine-driven fuel pump, use Parker Sealube (or equivalent) as a thread lubricant or to seal a leaking connection. Apply sparingly to male fittings only, omitting the first two threads. Always

be sure that a compound, the residue from a previously used compound, or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel soluble lubricant, such as engine lubricating oil, on fitting threads. Do not use any other form of thread compound on the injection system fittings.


13A-3. TROUBLE SHOOTING. For trouble shooting, refer to paragraph 13-3.

13A-4. FUEL VENTS.

13A-5. The fuel tank vent line extends from the upper aft outboard corner of each fuel tank to the wing tip. This vent line contains a check valve to prevent fuel drainage through the vent line, but still allows the positive pressure from expanding fuel to escape from the tanks. Check all fittings and clamps for tightness and vent line for clearance to prevent chafing against inner wing structure. The fuel vent line at the trailing edge of the wing tip should be checked daily for evidence of foreign matter.

13A-6. REMOVAL OF FUEL VENT.

- Remove wing tip and access covers located on underside of wing as necessary for access.
- Disconnect fuel vent line at fuel tank and disconnect clamps attaching vent line to wing structure.
- Disconnect vent line from the check valve at wing tip.
- Remove vent line by carefully pulling it from the outboard end of the wing.



NOTE

Remainder of the fuel system schematic is the same as that used with the strut-braced wing, shown in figure 13-1.

Figure 13A-1. Fuel System Schematic

13A-7. INSTALLATION OF FUEL VENT. Installation of fuel vent is accomplished by reversing the procedure outlined in paragraph 13A-6.

CAUTION

Make sure the vent line check valve is installed as shown in figure 13A-3.

13A-8. CHECKING FUEL VENTS. Field experience has demonstrated that the fuel vents can become plugged, causing possible fuel starvation of the engine. Also the bleed hole in the vent valve assembly could possibly become plugged, allowing pressure from expanding fuel to pressurize the tanks. To check the vent and bleed hole in the vent valve assembly, proceed as follows:

- Attach a rubber tube to the end of the vent line at the trailing edge of one wing tip.
- Turn off fuel selector valve and check that both

fuel filler caps are securely installed.

c. Blow into tube to slightly pressurize the tank. If air can be blown into tank, the vent line is open.

d. After tank is slightly pressurized, insert end of rubber tube into a container full of water and watch for a continuous stream of bubbles, which indicate the bleed hole in valve assembly is open and relieving pressure.

e. Repeat this procedure for fuel vent at opposite wing tip.

NOTE

Remember that a plugged vent line or bleed hole can cause either fuel starvation or the pressurizing of the tank by fuel expansion.

f. Any fuel vent found plugged or restricted must be corrected before returning airplane to service.

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
 SERVICE MANUAL




Figure 13A-2. Fuel System




Figure 13A-3. Fuel Tank Vents

WARNING

REFER TO PARAGRAPH 13A-22 FOR FUEL TANK PURGING WHICH SHOULD BE ACCOMPLISHED BEFORE REPAIRING FUEL TANKS.

13A-9. FUEL TANKS.

13A-10. Airplanes with the cantilever wings have an inboard section of each wing forward of the main spar sealed to form an integral fuel tank area. The fuel tank consists of a front and rear fuel spar, inboard, outboard and intermediate ribs, and stringers. A standpipe at the fuel tank filler acts as a visual aid, when loading fuel, to indicate the quantity of fuel in the tank.

13A-11. FUEL TANK LEAKS.

13A-12. CLASSIFICATION OF FUEL LEAKS. Fuel leaks which do not constitute a flight hazard are stains, seeps, and heavy seeps NOT in an enclosed area. However, they should be repaired when the airplane is grounded for other maintenance. Fuel leaks which constitute a flight hazard are running leaks in any area, and seeps, heavy seeps, or stains in an enclosed area, such as the wing leading edge, the sections of wing inboard and outboard of the fuel tank, and the area between the rear fuel spar and the main spar. These leaks must be repaired before that tank is used for another flight. The wet or stained spot on the wing in the area of the tank is an indication of the intensity of the leak. Fuel leak classifications are shown in figure 13A-4.

NOTE

Stains and seeps that are not considered a flight hazard must be inspected after each flight to insure that they have not grown in intensity to the point of causing a flight hazard.

If a leak causing a flight hazard should occur at a place where there are no facilities available to make an acceptable repair, it is recommended that the leaking tank be drained and some suitable material placed over the leak, if it is within an enclosed area of the wing, to eliminate escaping of fumes. By switching the fuel selector valve to the other tank, the airplane can then be flown to a base where the fuel leak can be repaired.

13A-13. INTEGRAL FUEL TANK SEALANT. Two kinds of sealants are used, one to seal the fuel tank and the other to seal the access doors and fuel quantity transmitter adapter. The access door sealant is more pliable and will not adhere to metal as firmly as the tank sealant does. This permits the access doors and fuel quantity transmitter adapter to be removed without damage to them. Service Kit SK210-56, available from the Cessna Service Parts Center, contains these sealants with the proper quantity of




Figure 13A-4. Classification of Fuel Leaks

accelerator for each sealant. The sealants can be identified by color. The tank sealant is white and its accelerator is a black paste. The access door sealant is gray and its accelerator is a clear liquid. When mixing the accelerator with the sealant, use all the material in the container to insure the proper ratio of accelerator to sealant. Stir the accelerator to absorb all floating liquid before it is mixed with the sealant. The accelerator can then be poured into the container of sealant for mixing; otherwise, a wax-free container must be used. Stir accelerator and sealant until it becomes a uniform mixture. Do not allow air bubbles to mix in. If this occurs, work air bubbles out.

13A-14. SEALING DURING AND AFTER STRUCTURAL REPAIR.


CAUTION

Protect drain holes and fuel outlet screens when applying sealants.

Any repair that breaks the fuel tank seal will necessitate resealing of that area of the tank. Repair parts that need sealing must be installed and riveted during the sealing operation. All joints within the boundary


of the tank, but which do not provide a direct fuel path out of the tank, such as stringers and rib flanges within the tank, must be fay surface sealed only. Joints which provide a direct fuel path out of the tank area, such as fuel spar flanges and inboard and outboard rib flanges, must be fay surface sealed and fillet sealed on the fuel side. Fay surface sealing is applying sealant to one mating part before assembly. Enough sealant must be applied so it will squeeze out completely around the joint when the parts are riveted or fastened together. The fillet seal is applied after the joint is fay surface sealed and riveted or fastened together. Fillet sealing is applying sealant to the edge of all riveted joints, any joggles, bend reliefs, voids, all rivets and/or fasteners through the boundary of the tank, and any place that could produce a fuel leak. The fay sealant need not be cured before the fillet seal is applied, but the squeezed out sealant, to which the fillet sealant is applied, must be free of dirt and contamination. Fillets laid on intersecting joints shall be joined together to produce a continuous fillet. Filler sealant must be pressed into the joint, working out all entrapped air. The best method of applying sealant is with an extrusion gun. Then work the sealant into the joint with a small paddle, being careful to eliminate all air bubbles.

SEALANT MUST SQUEEZE OUT CONTINUOUSLY





FAY SURFACE SEALING

SEALANT MUST SQUEEZE OUT CONTINUOUSLY



FILLET SEALING (With fay surfaces sealed)



FASTENER SEALING

Figure 13A-5. Fuel Tank Sealing (Sheet 2 of 2)

NOTE

During structural repair, parts must be pre-drilled, countersunk and/or dimpled if required, and cleaned before being sealed and positioned for final installation.

- a. Remove all existing sealant from area to be sealed, leaving a taper on the remaining sealant. The taper will allow a scarf bond and a continuous seal when the new sealant is applied.

NOTE

The best method of removing sealant is with a chisel-like tool made of hard fiber. Remaining sealant may then be removed with aluminum wool. Steel wool or sandpaper must not be used.

- b. Vacuum thoroughly to remove all chips, filings, dirt, etc., from the tank area.
- c. All surfaces and areas to be sealed shall be thoroughly cleaned by wiping with a clean cloth dampened with Methyl Ethyl Ketone (MEK), acetone or similar solvent, and dried with a clean cloth before the solvent evaporates. Always pour the solvent on the cloth. Never use contaminated solvent. The cloth shall not be so saturated that dripping occurs.

NOTE

Allowable work life of either sealant is four hours from the starting time of mixing. This applies to standard conditions of 77° Fahrenheit and 50% relative humidity. An increase in temperature or a decrease in humidity will shorten the work life of the sealant.

- d. Apply fay surface sealant to one mating part and install rivets or fasteners while sealant is still within its allowable work life.

NOTE

During the sealing operation, sealant must be checked at various times to determine that it has not exceeded its allowable work life. Use a small wood paddle, such as a tongue depressor, to gather some sealant. Touch the sealant to a piece of clean sheet metal. If the sealant adheres to the sheet metal, it is still within its allowable work life. If the sealant does not adhere to the sheet metal, it is beyond its allowable work life and must not be used.

- e. Apply a fillet seal to the repaired area on the inside of the tank.
- f. Apply fay surface door sealant to access doors and fuel quantity transmitter adapter, if removed, and install the doors and adapter.
- g. Allow the sealant to cure. Refer to paragraph 13A-16 for curing time.
- h. Clean stains from outside of tank area.
- i. Test fuel tank for leaks as described in paragraph 13A-17.

13A-15. **SEALING FUEL LEAKS.** First determine the source of the fuel leaks. Fuel can flow along a seam or the structure of the wing for several inches, making the leak source difficult to find. A stained area is an indication of the leak source. Fuel leaks can be found by testing the complete tank as described in paragraph 13A-17. Another method of detecting the source of a fuel leak is to remove access doors and blow with an air nozzle from the inside of the tank in the area of the leak while a soap bubble solution is applied to the outside of the tank. After the leak source has been found, proceed as follows:

- a. Remove existing sealant in the area of the leak as described in paragraph 13A-14, step "a."
- b. Clean the area and apply a fillet seal. Press sealant into leaking area with a small paddle, being sure to work out all entrapped air.
- c. If a leak occurs around a rivet or bolt, restrike the rivet or torque the bolt to the maximum allowable torque, and repair any damaged sealant.
- d. Apply fay surface door sealant to access doors or fuel quantity transmitter adapter, if removed, and install the doors and adapter.
- e. Test fuel tank for leaks as described in paragraph 13A-17.

13A-16. **CURING TIME.** Normal curing time for fillet sealant is 90 hours based on a standard condition of 77° Fahrenheit and 50% relative humidity. This time may be accelerated as shown in the following chart.

Temperature of Sealant °F.	Time in Hours
160	3
140	4
120	7

NOTE

Temperature shall not exceed 160°F. Tank must be vented to relieve pressure during accelerated curing.

Normal curing time for access door sealant is 24 hours based on a standard condition of 77° Fahrenheit and 50% relative humidity.

WARNING

Access door sealant must not be heated above 90° until sealant is cured for 24 hours based on a standard condition of 77° Fahrenheit and 50% relative humidity. Harmful vapors are released if sealant is heated above 90°F.

13A-17. **TESTING INTEGRAL FUEL TANK.**

- a. Remove vent line from vent fitting and cap the fitting.
- b. Remove forward and aft fuel lines from tank.
- c. To one of the tank fittings, attach a water manometer capable of measuring 20 inches of water.
- d. To the other tank fitting, connect a well regulated supply of air (1/2 PSI MAXIMUM or 13.8 INCHES OF WATER). Nitrogen may be used where the tank might be exposed to temperature changes while testing.

- e. Make sure filler cap is installed and sealed.

CAUTION

Do not attempt to apply pressure to the tank without a good regulator and a positive shut-off in the supply line. Do not inflate the fuel tank to more than 1/2 psi or damage may occur.

- f. Apply pressure slowly until 1/2 PSI is obtained.
- g. Apply soap solution as required.
- h. Allow 15 to 30 minutes for pressure to stabilize.
- i. If tank holds for 15 minutes, without pressure loss, tank is acceptable.
- j. Reseal and retest if any leaks are found.

13A-18. FUEL QUANTITY TRANSMITTERS.

13A-19. A fuel quantity transmitter is located on each aft fuel spar. It is the float arm actuated, variable resistor type and is powered by the airplane electrical system.

13A-20. REMOVAL OF FUEL QUANTITY TRANSMITTER. Removal of the fuel quantity transmitter can be accomplished through the access door on the underside of the wing forward of the flap bellcrank.

- a. Remove access door.
- b. Drain enough fuel from tank to lower fuel level below fuel transmitter.
- c. Disconnect electrical leads at transmitter.
- d. Remove bolts attaching transmitter to fuel spar.
- e. Remove gasket and fuel transmitter.

13A-21. INSTALLATION OF FUEL QUANTITY TRANSMITTER. The fuel quantity transmitter can be installed by reversing the procedure outlined in paragraph 13A-20. Use new gasket around opening in fuel tank and new sealing washers. Do not damage float or bend float arm when placing transmitter into tank as incorrect fuel readings can result. After installation is complete, turn on master switch and check fuel gage reading against known quantities in tank. Minor adjustments can be made by bending float arm on fuel quantity transmitter unit (see paragraph 16-44).

13A-22. FUEL TANK PURGING.

WARNING

To reduce the possibility of an explosion while repairing integral fuel cavities which have been fueled, the cavities may be purged with an inert gas.

The following procedure may be used to purge the cell with Argon or carbon dioxide.

- a. Ground the aircraft to a suitable ground stake.
- b. Set fuel selector valve handle in "OFF" position.
- c. Drain all fuel from cavity being repaired.

WARNING

Fuel draining from fuel tanks and disconnected lines or hoses constitutes a fire hazard. Adequate safety precautions should be taken whenever it is necessary to drain fuel or to disconnect lines or hoses.

- d. Remove access door and insert hoses to each end of tank simultaneously.
- e. Allow inert gas to flow into tank for several minutes (time dependent upon hose size, rate of flow, etc.) to remove all gasoline vapors.

Since Argon or carbon dioxide are heavier than air, these gasses will remain in the tank during the repair. The repair shall be made using non-sparking tools (air motors, plastic scrapers, etc.)

NOTE

Portable vapor detectors are available to determine presence of explosive mixtures, and are calibrated for leaded gasoline and could be used to determine that it is safe to make repairs.

13A-23. REMAINDER OF FUEL SYSTEM.

13A-24. Beginning with paragraph 13-17, the remainder of Section 13 also applies to airplanes with the cantilever wing.

SHOP NOTES:

SECTION 14

PROPELLERS

TABLE OF CONTENTS

	Page		Page
PROPELLERS	14-1	Trouble Shooting	14-9
Repair	14-1	Removal	14-9
PROPELLER	14-5	Removal and Installation of Governor	
Trouble Shooting	14-5	Control Arm and Bearing Assembly. . .	14-9
Removal	14-6	Installation	14-10
Cleaning of Propeller Hub	14-9	High RPM Stop Adjustment	14-10
Installation	14-9	Rigging Propeller Governor Control . .	14-10
PROPELLER GOVERNOR	14-9		

NOTE

Federal Aviation Regulations, Part 43, (FAR 43) define major and minor repairs and alterations and who may accomplish them. This section may be used as a guide, but the Federal Aviation Regulations and the propeller manufacturer's instructions must be observed.

PROPELLERS.

14-2. All 200-Series aircraft are equipped with all-metal, constant-speed, governor-regulated propellers. Two-bladed propellers are standard equipment, with three-bladed propellers being optional on these models. Propeller blades have a built-in tilt of approximately 5/8 degree beginning about the 16-inch station. This tilt provides the blades with a greater centrifugal restoring moment. On all except the Super Skywagon Series, the propeller hub is extended approximately three inches.

14-3. REPAIR of metal propellers first involves evaluating the damage and determining whether the repair will be a major or minor one and, in accordance with Federal Aviation Regulations, who is permitted to accomplish the repair.

a. General Repair Considerations:

Under no circumstances are the raised edges of defects to be corrected by peening. No welding, soldering or compounds of any nature are to be used to fill or correct defects. All repair is to be in accordance with standard approved and accepted practice.

More than one defect on blade is not cause for considering blade not airworthy if repair is within indicated limits. A reasonable number of repairs per blade is permissible if their location with respect to each other is not such as to form a continuous line that may materially weaken blade. Any transverse crack shall be cause for considering blade not airworthy.

Repair necessitating the removal of an appreciable amount of metal shall be reason to check horizontal and vertical balance.

The repair of defects is permissible providing the treatment does not materially weaken the blade, reduce its weight, or impair its performance.

b. Defects on Thrust Face or Camber Side:

Repair by removal of metal to form shallow, large radius, round bottomed depressions. Periodic inspection during repair should be made to avoid removal of excessive amounts of metal. All raised edges should be carefully smoothed out to reduce the area of the defect and the amount of metal to be removed. Repair with suitable fine cut files and coarse grain emery cloth and smooth all edges and surfaces with fine grain emery cloth. Any blade repair on these surfaces which necessitates a depression that exceeds the manufacturer's tolerances or those listed in FAR 43 shall be cause for considering blade not airworthy.

c. Defects on Leading and Trailing Edge:

Repair defects as outlined in step "b" with suitable half round file and emery cloth. Carefully smooth all edges of repaired defect. Any blade repair on leading and trailing edges which necessitates metal removal that exceeds the manufacturer's tolerances or those listed in FAR 43 shall be cause for considering blade not airworthy.

Blades that have leading or trailing edges pitted from normal wear may be reworked by removing sufficient metal to eliminate the pitting. Start well back from the edge and work over the edge in such a manner that the contour of the blade remains substantially the same. Avoid abrupt section changes and blunt edges. Permissible reductions in blade thickness and width, listed in the manufacturer's publications or FAR 43, must be observed.

d. Tip Damage:

Damage on blade tips may be removed in accordance with "b" and "c," as long as metal removed is within the tolerances specified. Damage which cannot be repaired by local removing of metal may be repaired by removing metal so as to shorten blades, although shortening blades is a propeller major repair. Any shortening of one blade requires an identical shortening of the other one(s), and any change in tip plan form or contour of one blade requires an identical change on the other one(s). Limitations concerning shortening of blades are specified in the manufacturer's publications or FAR 43.

SHOP NOTES:

e. Refinishing:

Prior to corrosion protection treatments, all repair areas should be smoothly polished out and blended in to finish repair and improve appearance. Wherever possible, all repaired blades should be anodized in a sulfuric acid anodize bath. The blades must be anodized with loose blade retention hardware on shank end; therefore, the blade must be supported vertically with steel hardware out of the solution and suitably protected to be unaffected by fumes. The same holds true for caustic baths.

Where anodizing is not readily available, local repaired or inspected areas may be treated by other approved methods for corrosion protection; so-called chromodizing, alodine solution, painting, etc. It is doubtful that the finish of these treatments, other than sulfuric acid anodize, will blend in with regard to appearance. If desired, both camber and thrust face sides may be painted with zinc chromate primer and black lacquer to improve appearance. The thrust face side should always be painted.

STANDARD ON:

SUPER SKYWAGON AND TURBO-SYSTEM SUPER SKYWAGON SERIES





Figure 14-1. Two-Bladed Propeller

STANDARD ON :

CENTURION AND TURBO-SYSTEM CENTURION SERIES

SUPER SKYLANE AND TURBO-SYSTEM SUPER SKYLANE SERIES



NOTE

Use spacers (4) as required to cause a snug fit between the spinner and the spinner support.

- 1. Propeller Spinner
- 2. Screw
- 3. Spinner Support
- 4. Spacer
- 5. Cylinder

- 6. Screw
- 7. Stud
- 8. Washer
- 9. Nut

- 10. Spinner Bulkhead
- 11. O-Ring
- 12. Dowel Pin
- 13. Bolt
- 14. Propeller

Figure 14-2. Two-Bladed, Extended Hub Propeller

14-4. PROPELLER.

14-5. The constant-speed propeller used on the 200-Series airplanes is a single-acting propeller in which oil pressure from the engine, boosted and

regulated by a governor, is used to increase blade pitch, and the natural, centrifugal twisting moment of the rotating blades and the force of a spring are used to decrease blade pitch. The propeller is illustrated in figures 14-1 thru 14-4.

14-6. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
FAILURE TO CHANGE PITCH.		
Control disconnected or broken.	Check visually.	Connect or replace control.
Governor not correct for propeller. "Sensing wrong."	See paragraph 14-11.	Install correct governor.
Defective governor.	See paragraph 14-12.	See paragraph 14-12.
Defective pitch changing mechanism inside propeller or excessive blade friction.	Check manually.	Propeller repair or replacement is required.
FAILURE TO CHANGE PITCH FULLY.		
Improper rigging of governor control.	Check that arm on governor has full travel.	Rig correctly.
Defective governor.	See paragraph 14-12.	See paragraph 14-12.
SLUGGISH RESPONSE TO PROPELLER CONTROL.		
Excessive friction in pitch changing mechanism inside propeller or excessive blade friction.	Check manually.	Propeller repair or replacement is required.
STATIC RPM TOO HIGH.		
Governor high rpm stop set too high.	See "Note" at end of this chart.	Rig correctly.
Defective governor.	See paragraph 14-12.	See paragraph 14-12.
Incorrect propeller or incorrect low pitch blade angle.	Check aircraft specifications.	Install correct propeller, with correct blade angle.
STATIC RPM TOO LOW.		
Governor high rpm stop set too low.	See "Note" at end of this chart.	Rig correctly.
Defective governor.	See paragraph 14-12.	See paragraph 14-12.
Incorrect propeller or incorrect low pitch blade angle.	Check aircraft specifications.	Install correct propeller, with correct blade angle.
ENGINE SPEED WILL NOT STABILIZE.		
Sludge in governor.	See paragraph 14-12.	See paragraph 14-12.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
ENGINE SPEED WILL NOT STABILIZE (Cont).		
Air trapped in propeller actuating cylinder.	This condition may occur after the propeller has been reinstalled, or has been idle for an extended period.	Trapped air should be purged by exercising the propeller several times prior to take-off after the propeller has been reinstalled or has been idle for an extended period.
Excessive friction in pitch changing mechanism inside propeller or excessive blade friction.	Check manually.	Propeller repair or replacement is required.
Defective governor.	See paragraph 14-12.	See paragraph 14-12.
OIL LEAKAGE AT MOUNTING FLANGE.		
Damaged O-ring seal between engine and propeller.	Check visually for oil leakage.	Replace O-ring seal.
Foreign material between engine and propeller mating surfaces or nuts not tight.	Check visually for oil leakage.	Clean propeller and engine mating surfaces and tighten nuts properly.
OIL LEAKAGE BETWEEN HUB AND CYLINDER.		
Defective gasket or screws not tight.	Check visually for oil leakage.	Replace gasket and tighten screws properly.
OIL LEAKAGE AT ANY OTHER PLACE.		
Defective seals, gaskets, threads, etc, or incorrect assembly.	Check visually for oil leakage.	Propeller repair or replacement is required.
<p style="text-align: center;">NOTE</p> <p>It is possible for either the propeller low pitch (high rpm) stop or the governor high rpm stop to be the high rpm limiting factor. It is desirable for the governor stop to limit the high rpm at the maximum rated rpm for a particular airplane. Due to climatic conditions, field elevation, low pitch blade angle, and other considerations, an engine may not reach rated rpm on the ground. It may be necessary to readjust the governor stop after test flying to obtain maximum rated rpm when airborne.</p>		

14-7. REMOVAL. (See figures 14-1 thru 14-4.) On Models with the type propeller shown in figures 14-1 and 14-3, the propeller spinner must be removed for propeller removal. On models with the type shown in figures 14-2 and 14-4, the propeller and propeller spinner may be removed as a complete unit. To remove propeller, proceed as follows:

- If spinner is to be removed, remove attaching screws and remove spinner, spinner support, and spacers. Retain any spacers behind spinner support.
- On models with the type propeller shown in fig-

ures 14-2 and 14-4, remove cowlings to gain access to propeller attaching nuts.


- Loosen nuts attaching propeller about 1/4" and pull propeller forward until halted by nuts.

NOTE

As the propeller is separated from the engine, oil will drain from the propeller and engine cavities.

OPTIONAL ON :

SUPER SKYWAGON AND TURBO-SYSTEM SUPER SKYWAGON SERIES



NOTE

Use spacers (4) as required to cause a snug fit between the spinner and the spinner support.

- 1. Propeller Spinner
- 2. Screw
- 3. Spinner Support
- 4. Spacer

- 5. Cylinder
- 6. Screw
- 7. Stud
- 8. Lug
- 9. Nut


- 10. Spinner Bulkhead
- 11. O-Ring
- 12. Dowel Pin
- 13. Propeller

Figure 14-3. Three-Bladed Propeller

OPTIONAL ON:

CENTURION AND TURBO-SYSTEM CENTURION SERIES

SUPER SKYLANE AND TURBO-SYSTEM SUPER SKYLANE SERIES



NOTE

Use spacers (4) as required to cause a snug fit between the spinner and the spinner support.

- 1. Propeller Spinner
- 2. Screw
- 3. Spinner Support
- 4. Spacer
- 5. Cylinder

- 6. Screw
- 7. Stud
- 8. Washer
- 9. Nut

- 10. Spinner Bulkhead
- 11. O-Ring
- 12. Dowel Pin
- 13. Bolt
- 14. Propeller

Figure 14-4. Three-Bladed, Extended Hub Propeller

- d. Remove attaching nuts and pull propeller forward to remove from engine.
- e. If desired, the spinner bulkhead can be removed by removing attaching lugs (figures 14-1 and 14-3) or bolts (figures 14-2 and 14-4).

14-8. CLEANING OF PROPELLER HUB.

- a. Remove propeller spinner. Remove spinner support from front of propeller. Remove any spacers used behind the spinner support.
- b. Remove screws securing cylinder to hub and remove cylinder.
- c. Use a solution of one part light engine oil and two parts solvent to clean exposed parts and interior of cylinders. Dry gently with compressed air, then use clean engine oil to lubricate parts lightly before assembly.
- d. Install new O-rings and gaskets at each cleaning of propeller hub.
- e. Reassemble cylinder to hub.
- f. Install any spacers used between the spinner support and cylinder, then install the spinner support and spinner. Spacers are used as required to cause a snug fit between the spinner and the spinner support.

14-9. INSTALLATION.

- a. If spinner bulkhead was removed, position it so the propeller blades will emerge from the spinner with ample clearance and install spinner bulkhead attaching lugs (figures 14-1 and 14-3) or bolts (figures 14-2 and 14-4).

CAUTION

Avoid scraping metal from bore of spinner bulkhead and wedging scrapings between engine flange and propeller. Trim the inside diameter of the bulkhead as necessary when installing a new spinner bulkhead.

- b. Clean propeller hub cavity, mating surfaces, and crankshaft.
- c. Lightly lubricate a new O-ring and the crankshaft pilot with clean engine oil, and install the O-ring in the propeller hub.
- d. Align propeller mounting studs and dowel pins with proper holes in engine crankshaft flange and slide propeller carefully over crankshaft pilot until mating surface is approximately 1/4 inch from crankshaft flange.
- e. Install propeller attaching washers and nuts and work propeller aft as far as possible, then tighten nuts evenly and torque to 55-65 pound-feet.
- f. Install any spacers used between spinner support bulkhead and propeller cylinder, then install spinner support and spinner. The spacers are used as required to cause a snug fit between the spinner and the spinner support.

14-10. PROPELLER GOVERNOR.

14-11. The propeller governor is a single-acting, centrifugal type, which boosts oil pressure from the engine and directs it to the propeller where the oil is used to increase blade pitch. A single-acting governor uses oil pressure to effect a pitch change in

one direction only; a pitch change in the opposite direction results from a combination of centrifugal twisting moment of rotating blades and compressed springs. Oil pressure is boosted in the governor by a gear type oil pump. A pilot valve, flyweights, and a speeder spring act together to open and close governor oil passages as required to maintain a constant engine speed.

NOTE

Outward physical appearance of specific governors is the same, but internal parts determine whether it uses oil pressure to increase or decrease blade pitch. Always be sure the correct governor is used.

CAUTION

The propellers used on the 200-Series airplanes require governors which "sense" in a certain manner. "Sensing" is determined by the type pilot valve installed inside the governor. Since the same basic governor may be set to "sense" oppositely, it is important to ascertain that the governor is correct for the propeller being used.

14-12. TROUBLE SHOOTING. When trouble shooting the propeller-governor combination, it is recommended that a governor known to be in good condition be installed to check whether the propeller or the governor is at fault. Removal and replacement, rigging, high-speed stop adjustment, desludging, and replacement of the governor mounting gasket are not major repairs and may be accomplished in the field. Repairs to propeller governors are classed as propeller major repairs in Federal Aviation Regulations, which also define who may accomplish such repairs.

14-13. REMOVAL.

- a. Remove cowling, engine baffles, and nose cap as required for access.
- b. Disconnect governor control from governor.
- c. Disconnect intake manifold balance tube at front of engine and move as required for clearance during governor removal, if necessary.
- d. Remove nuts and washers securing governor to engine and work governor from mounting studs.
- e. Remove gasket between governor and engine mounting pad.

14-14. REMOVAL AND INSTALLATION OF GOVERNOR CONTROL ARM AND BEARING ASSEMBLY. (See figure 14-5.)

- a. Using a scribe, make aligning index marks on governor arm and end of governor serrated shaft.

NOTE

The governor arm must be reinstalled on the governor shaft in the same serration or the governor speed will be changed approximately 200 rpm.

- b. Remove safety wire from governor arm screw and from screws attaching governor head to governor.

- c. Remove two screws that pass through the non-notched holes in the retainer.
- d. Loosen, but do not remove, four remaining screws so that retainer may be rotated.
- e. Loosen screw in governor arm so that arm may be slipped toward end of serrated shaft.
- f. Slip governor arm toward end of serrated shaft and work retainer and control arm from governor.

NOTE

If governor arm becomes disengaged from serrated shaft, align index marks and install arm on serrated shaft. The control arm spring has approximately 1-1/2 turn preload.

- g. Rotate and remove bearing race from governor.
- h. Installation of the control arm and bearing assembly is the reversal of the removal procedure.

14-15. INSTALLATION.

- a. Wipe governor and engine mounting pad clean.
- b. Install a new gasket on the mounting studs. Install gasket with raised surface of the gasket screen toward the governor.
- c. Position governor on mounting studs, aligning governor splines with splines in engine, and install mounting nuts and washers. Do not force spline engagement. Rotate engine crankshaft slightly and splines will engage smoothly when properly aligned.
- d. Connect governor control to governor and rig.
- e. Connect intake manifold balance tube, if removed. Ascertain that intake manifold clamps are tight.
- f. Reinstall all parts removed for access.

14-16. HIGH RPM STOP ADJUSTMENT.

- a. (Figure 14-6, Type B.) Remove engine cowling. Disconnect cabin heater inlet air duct as required for access to governor.

NOTE

On aircraft using type A, of figure 14-6, a plug button is provided in the left front baffle for governor adjustment.

- b. Loosen the high-speed stop screw jam nut.
- c. Turn the stop screw in to decrease maximum rpm and out to increase maximum rpm. One full revolution of the stop screw causes a change of approximately 25 rpm.
- d. Tighten stop screw jam nut and make propeller control linkage adjustment as necessary to maintain full travel.
- e. Reinstall cabin heater inlet air duct, cowling, or plug button removed for access.
- f. Test operate propeller and governor.

NOTE

It is possible for either the propeller low pitch (high rpm) stop or the governor high rpm stop to be the high rpm limiting factor. It is desirable for the governor stop to limit the high rpm at the maximum rated rpm for a particular airplane. Due to climatic conditions, field elevation, low pitch blade angle, and other considerations, an engine may not reach rated rpm on the ground. It may be necessary to readjust the governor stop after test flying to obtain maximum rated rpm when airborne.

14-17. RIGGING PROPELLER GOVERNOR CONTROL.

- a. Disconnect control end from governor.
- b. Place propeller control in cabin full forward, then pull back approximately 1/8" and lock in this position. This will allow "cushion" to assure full




Figure 14-5. Governor Control Arm and Bearing Assembly

contact with governor high rpm stop screw.

c. Place governor arm against high rpm stop screw.

d. Loosen jam nut and adjust control rod until attaching holes align while governor arm is against high rpm stop screw. Be sure to maintain sufficient thread engagement of the control and the rod end. If necessary, shift the control in its clamps to achieve this.

e. Attach control rod end to the governor, tighten jam nut, and install all safeties.

f. Operate the propeller control to see that the governor arm attains full travel in both directions.


NOTE

Some models are equipped with an offset extension to the governor arm. The offset extension has an elongated slot to permit further adjustment. The preceding steps may still be used as an outline in the rigging procedure. The result of rigging, in all cases, is full travel of the governor arm (bottom out against both high and low pitch stops) with some "cushion" at both ends of control travel.

TYPE A

NON-TURBOCHARGED ENGINES EXCEPT MODEL U206B


1. Propeller Governor
2. High-RPM Stop Screw
3. Governor Arm Extension
4. Nut
5. Control Rod End
6. Governor Control



TYPE B

TURBOCHARGED ENGINES AND MODEL U206B

1. Propeller Governor
2. High-RPM Stop Screw
3. Arm and Bearing Assembly
4. Nut
5. Control Rod End
6. Governor Control



SEE FIGURE 14-5

Figure 14-6. Governor and Control Adjustments

SECTION 15

UTILITY SYSTEMS

TABLE OF CONTENTS	Page	
HEATING AND DEFROSTING SYSTEM	15-1	REPLACEMENT AND REPAIR 15-3
Heater Operation	15-1	OXYGEN SYSTEM 15-6
Defroster Operation	15-3	Maintenance Precautions 15-6
VENTILATING SYSTEM	15-3	Replacement of Components 15-7
Overhead Cabin Ventilation	15-3	Inspection Requirements 15-7
Forward Cabin Ventilation	15-3	Functional Test 15-10
TROUBLE SHOOTING	15-3	Charging 15-10
		Cleaning Oxygen Masks 15-10

15-1. HEATING AND DEFROSTING SYSTEM.

15-2. Cabin heating and defrosting are provided by an exhaust manifold heat exchanger, air ducts and valves, controls, and outlets. The only moving parts of the system are the valves and their controls, hence there is little mechanical wear involved. Normally, the only maintenance check required on the heating and defrosting system is careful examination to make sure that the exhaust manifold and heat exchanger have no burned spots or cracks which could allow exhaust fumes to enter the system, and a check of hoses and ducting to make sure that air passage is unobstructed. Heater and defroster controls and valves should be checked periodically to insure proper operation.

15-3. HEATER OPERATION. On airplanes with turbocharged engines, ram air is ducted through an opening in the left side of the nose cap, through the exhaust shroud, to a firewall shut-off valve. On airplanes with non-turbocharged engines, ram air is ducted through an engine baffle and heat exchange section of the left exhaust muffler, to a firewall shut-off valve. On all models, heated air flows from the firewall shut-off valve into a duct across the aft side of the firewall where it is distributed into the cabin. The shut-off valve, operated by a control marked "CABIN HEAT," regulates the volume of heated air entering the cabin. Pulling the heater control full out supplies maximum flow and pushing it in gradually decreases flow, shutting off flow completely when pushed full in. Refer to paragraph




Figure 15-1. Heating and Defrosting System

15-7 for operation of fresh air scoop doors, which permit unheated air also to enter the firewall duct for distribution into the cabin.

15-4. DEFROSTER OPERATION. Air from the duct across the aft side of the firewall flows through a flexible duct to the defroster outlet. The defroster control operates a damper in the outlet to regulate the amount of air deflected across the inside surface of the windshield. The temperature and volume of this air are controlled by the settings of the cabin heating system controls.

15-5. VENTILATING SYSTEM.

15-6. OVERHEAD CABIN VENTILATION on all Model 206-Series aircraft and prior to Models 210G and T210G, is provided by manually adjustable ventilators installed on each side of the cabin near the upper corners of the windshield. Air is received from scoops mounted in the inboard leading edges of the wings. Formed elbows and ducts deliver ram air to the ventilators, which are adjustable to regulate the amount and direction of air emitted into the cabin. Beginning with the Models 210G and T210G, air received from scoops mounted in the inboard leading edges of the wings is ducted to two plenum chambers mounted in the ceiling immediately forward of the pilot and copilot. Beginning with the 1967 models, rear seat ventilation is provided by plenum chambers which receive ram air from scoops mounted in the inboard leading edges of the wings. Each plenum chamber is equipped with a valve which meters the incoming cabin ventilation air. This provides a chamber for the expansion of cabin air which greatly reduces inlet air noise.

NOTE

The filters at the air inlets are primarily noise reduction filters. They may be removed and cleaned or replaced. Since air passing through the filters is emitted into the cabin, do not use a cleaning solution which would contaminate cabin air. The filters may be removed to increase air flow. However, their removal will cause a slight increase in noise level. Some models do not use these filters.

15-7. FORWARD CABIN VENTILATION is provided by two fresh air scoop doors, one on each side of the fuselage, just forward of the front seats. The left scoop door is operated by a control in the instrument panel marked "CABIN AIR," and the right scoop

door is operated by a control in the instrument panel marked "AUX. CABIN AIR." Fresh air from the scoop doors is routed to the duct across the aft side of the firewall, where it is distributed into the cabin. As long as the "CABIN HEAT" control is pushed full in, no heated air can enter the firewall duct; therefore, when the "CABIN AIR" or "AUX. CABIN AIR" controls are pulled out, only fresh air from the scoops will flow through the duct into the cabin. As the "CABIN HEAT" control is gradually pulled out, more and more heated air will blend with the fresh air from the scoops and be distributed into the cabin. All of the controls may be set at any position from full open to full closed.

15-8. TROUBLE SHOOTING.

15-9. Most of the operational troubles in the heating, defrosting, and ventilating systems are caused by sticking or binding air valves and their controls, damaged air ducting, or defects in the exhaust muffler. In most cases, air valves or controls can be freed by proper lubrication. Damaged or broken parts should be repaired or replaced. When checking rigging of controls, be sure valves respond freely to control movement, that they move in the correct direction, and that they move through their full range of travel and seal properly. Check that heater hoses are properly secured and replace hoses that are burned, frayed, or crushed. If fumes are detected in the cabin, a very thorough inspection of the exhaust muffler should be accomplished. Refer to paragraph 12A-26 for the turbocharged engine exhaust system inspection or to paragraph 12-23 for the non-turbocharged engine exhaust system inspection. Since any holes or cracks may permit exhaust fumes to enter the cabin, replacement of defective parts is imperative because fumes constitute an extreme danger. Seal any gaps in heater ducts across the firewall with 700P, or equivalent compound.

15-10. REPLACEMENT AND REPAIR.

15-11. Figures 15-1 thru 15-3 show heating, defrosting and ventilating systems, and may be used as guides during replacement of components. Burned, frayed, or crushed hose should be replaced with new hose. Cut to length and install in the original routing. Trim the hose winding shorter than the hose to allow hose clamps to be fitted. Air valves that are defective should be repaired or replaced. Check for proper operation and correct rigging of the valves after repair or replacement.

SHOP NOTES:




Figure 15-2. Overhead Ventilating System (Sheet 1 of 2)

SEE SHEET 1

MODEL 206 SERIES
1967 & ON





Figure 15-2. Overhead Ventilating System (Sheet 2 of 2)



1. Auxiliary Cabin Air Control
2. Cabin Air Control
3. Hose
4. Clamp
5. Screen
6. Air Valve Assembly
7. Scoop Door
8. Fuselage Skin

Figure 15-3. Forward Ventilating System

15-12. OXYGEN SYSTEM.

15-13. A six-port oxygen system is available as optional equipment on aircraft with non-turbocharged engines. It is standard equipment on aircraft with turbocharged engines. The system has one oxygen cylinder, an automatic constant-flow regulator, and pressure lines and outlets. Six oxygen masks are furnished with the system. The pilot's supply line is designed to provide a greater flow of oxygen than the passengers' lines. The pilot's mask is equipped with a microphone that is keyed by a switch button on the pilot's control wheel. A pressure gage is mounted on the aft baggage compartment wall. Filler valve locations for the various models are shown in figure 15-4.

WARNING

Oil, grease, or other lubricants in contact with high-pressure oxygen create a serious fire hazard, and such contact must be avoided. Do not permit smoking or open flame in or near airplane while work is performed on oxygen system.

15-14. MAINTENANCE PRECAUTIONS.

- a. Working area, tools, and hands must be clean.
- b. Keep oil, grease, water, dirt, dust, and all other foreign matter from system.
- c. Keep all lines dry and capped until installed.
- d. All compounds used on fittings must conform to MIL-C-5542. No compound shall be used on aluminum alloy flared fittings. Compounds are used only

on the first three threads of the male threads. No compound is used on coupling sleeves, or outside of tube flares.

e. Fabrication of pressure lines is not recommended. Lines should be replaced by part number.

f. Lines and fittings must be clean and dry. One of the following methods may be used:

1. Clean with a vapor degreasing solution of stabilized trichlorethylene conforming to MIL-T-7003. Follow by blowing lines clean and dry with clean, dry, filtered air.

CAUTION

Most air compressors are oil lubricated, and a minute amount of oil may be carried by the air stream. A water lubricated compressor should be used to blow tubing clean.

2. Flush with naphtha conforming with Specification TT-N-95, then blow clean and dry with clean, dry, filtered air. Flush with anti-icing fluid conforming to MIL-F-5566 or anhydrous ethyl alcohol. Rinse thoroughly with fresh water and dry with clean, dry, filtered air.

3. Flush with hot inhibited alkaline cleaner until free from oil and grease. Rinse with fresh water and dry with clean, dry, filtered air.

NOTE

Cap lines at both ends immediately after drying to prevent contamination.

15-15. REPLACEMENT OF COMPONENTS. Removal, disassembly, assembly, and installation of components may be accomplished while using figure 15-4 as a guide.

CAUTION

The pressure regulator, pressure gage and line, and filler valve and line should be removed and replaced only by persons familiar with high-pressure fittings. Observe the maintenance precautions listed in the preceding paragraph.

NOTE

Oxygen cylinder and regulator assemblies may not always be installed in the field exactly as illustrated in figure 15-4, which shows factory installations. Important points to remember are these:

The vent hole in the regulator body must not be covered by the control clamp installed around the regulator body.

The low pressure relief valve should not be removed from the regulator except for replacement; it is installed in a specific port only. Although the other three low pressure ports are common to each other, the low pressure relief valve port is not.

The high pressure relief valve should not be removed from the regulator except for replacement. Although all high pressure ports are common to each other, the thread size is different for the high pressure relief valve.

a. Before removing cylinder, release oxygen pressure, then disconnect push-pull control cable, filler line, pressure gage line, and outlet line from the regulator. Cap all openings immediately.

b. To replace filler valve O-rings, release oxygen pressure, then disconnect chain but do not remove cap from valve (17). Remove screws securing valve and carefully pull valve out far enough to expose wrench pads on valve seat (20). Disconnect pressure line, and cap line and seat. Disassemble, replace O-rings, reassemble, and install.

NOTE

On the Model 210, the baggage compartment vertical shelf must be removed for access to the filler valve. On the Models 206 and U206, the baggage compartment rear wall must be removed for access.

c. To replace valve core (11) in outlets, unscrew core with a suitable tool that will engage lugs protruding at each side of core. When installing the core, be sure that poppet (10) is in place in spring and that other end of poppet enters center of core. If these parts are not positioned properly, the outlet will not operate properly.

d. To remove the entire oxygen system, the headliner must be lowered and soundproofing removed to expose lines. Refer to Section 3 for headliner removal.

15-16. INSPECTION REQUIREMENTS.

a. ICC 3AA 1800 Oxygen Cylinder. This cylinder, used on non-turbocharged aircraft, shall be hydrostatically tested to 5/3 working pressure every five years by an FAA approved facility. The month and year of the latest test is stamped near the neck of the cylinder. This date should also be recorded in the aircraft log book.

b. ICC 3HT 1850 Oxygen Cylinder. This cylinder, used on turbocharged aircraft, shall be hydrostatically tested to 5/3 working pressure every three years by an FAA approved facility, and shall be retired from service 12 years or 4380 filling cycles after date of manufacture, whichever occurs first. The month and year of the latest test is stamped near the neck of the cylinder. This date should also be recorded in the aircraft log book.

c. The regulator shall be removed and overhauled by an FAA approved facility whenever the oxygen cylinder is pressure tested or retired from service in accordance with step "a" or "b".

d. Pressure Gage. The pressure gage shall be checked for accuracy and cleaned by an FAA approved facility every five years.

e. Individual Outlets. Each outlet shall be disassembled and inspected, and the sealing core replaced regardless of condition, every five years.

f. Filler Valve. The filler valve shall be disassembled and inspected, and the O-rings replaced







Figure 15-4. Oxygen System (Sheet 1 of 4)



MODEL 206 SERIES - PRIOR TO 1968




1968 MODEL 206 SERIES

1. Cylinder
2. Pressure Gage
3. Filler Valve
4. ON-OFF Control
5. High-Pressure Relief Valve


6. Bracket
7. Regulator
8. Plug
9. Low-Pressure Relief Valve
10. Atmospheric Vent Hole
11. Quick-Disconnect Valve

MODEL 206 SERIES

Figure 15-4. Oxygen System (Sheet 2 of 4)



**MODEL 206 SERIES - PRIOR TO 1968
AND MODEL T210F**




MODEL TP206

NOTE

The models T210G and H oxygen systems are identical to the Model 210G and H installations shown on sheet 1 of this series.

- | | |
|----------------------|-------------------------------|
| 1. ON-OFF Control | 7. Regulator |
| 2. Low-Pressure Line | 8. Quick-Disconnect Valve |
| 3. Pressure Gage | 9. High-Pressure Relief Valve |
| 4. Clamps | 10. Clamp |
| 5. Cylinder | 11. Plug |
| 6. Filler Valve | 12. Low-Pressure Relief Valve |
| | 13. Atmospheric Vent Hole |





TURBOCHARGED AIRCRAFT


Figure 15-4. Oxygen System (Sheet 3 of 4)

NOTE

Items (3) thru (7) constitute a standard filler valve. Filler valves are mounted in different locations on various models. When replacing O-rings, replace by part number listed in applicable Parts Catalog.




MODEL 210 SERIES - 1968



MODEL 206 SERIES - 1968

TYPICAL OUTLET



1. Adapter
2. Spacer
3. Seat
4. Piston
5. O-Ring
6. Valve
7. Cap
8. Cover

9. Outlet
10. Pressure Gage
11. Pressure Gage Line
12. ON-OFF Control
13. Access Door
14. Arm
15. Knob
16. Bracket

17. Cover
18. Base
19. Jam Nut
20. Spring
21. Poppet
22. Core
23. Escutcheon
24. Cover
25. Lock Ring

OUTLET & FILLER VALVE DETAILS

Figure 15-4. Oxygen System (Sheet 4 of 4)

regardless of condition, every five years.

g. System Leak Test. With 200 to 500 psi on gage, check entire system for leaks, using leak detector compounded for use with oxygen systems. With system under full pressure, repeat leak test on high-pressure lines and fittings. Perform a complete leak test at least every five years. When components are removed and replaced, leak test applicable connections. After the test has been completed, wash away all traces of the leak detector.

h. System Purging. Whenever components have been removed and replaced, plug masks into all outlets and purge the system for 10 minutes. Smell oxygen flowing from outlets and continue to purge until odorless. Refill cylinder as required during and after purging.

5-16A. FUNCTIONAL TEST. Whenever the oxygen system regulator (or regulator and cylinder assembly) has been replaced or overhauled, perform the following flow and internal leakage tests to check that the system functions properly.

a. Fully charge the oxygen system per paragraph 15-17.

b. Install an oxygen outlet adapter (Cessna Part Number C166005-0506) into a pressure gage (gage should be calibrated in one-pound increments from 0 to 100 PSI), and insert adapter into an oxygen outlet. Place control lever in the "ON" position. The gage pressure should be 75 ± 10 PSI.

c. Insert adapters (or mask and line assemblies if they are operating properly) into all remaining outlets. With oxygen flowing from all outlets, the pressure should still be 75 ± 10 PSI.

d. Place oxygen control lever in the "OFF" position and allow pressure to fall to 0 PSI. Remove all adapter assemblies except the one with the pressure gage. The pressure must not rise above 0 PSI when observed for one minute. Remove pressure gage and adapter from oxygen outlet.

NOTE

If pressures specified in the foregoing procedures are not obtained, the oxygen regulator is not operating properly. Remove and replace cylinder and regulator assembly with another unit and repeat test procedure.

e. Connect oxygen masks to each outlet and check each mask for proper operation.

f. Check proper function of pilot's mask microphone and control wheel switch. After checking, return all masks to mask case.

g. Recharge oxygen system as required.

15-17. CHARGING. Do not charge oxygen systems if fittings on servicing equipment or filler valve are corroded or contaminated. If in doubt, clean with stabilized trichlorethylene and let air dry. Do not permit solution to enter internal parts. Before charging, check the hydrostatic test date as noted in paragraph 15-16, step "a" or "b."

CAUTION

Do not charge an oxygen cylinder if it has become contaminated. The regulator and cylinder assembly must then be disassembled, inspected, and cleaned by an FAA approved facility before filling. Contamination, as used here, means dirt, dust, or other foreign matter, as well as ordinary air in large quantities. If a gage line or filler line is disconnected and fittings capped immediately, the cylinder will not become contaminated unless temperature variation has created a suction within the cylinder. Likewise, a regulator may be replaced without contaminating the cylinder, if the same conditions are observed. Ordinary air contains water vapor which could condense and freeze. Since there are very small orifices in the system, it is important that this not be permitted to occur.

a. Connect cascade connection to filler valve.

b. Slowly open valve on cascade cylinder with lowest pressure, as noted on cascade pressure gage, allow pressure to equalize, then close cascade cylinder valve.

c. Repeat this procedure, using a progressively higher pressure cascade cylinder, until system has been charged to the pressure indicated in the following chart.

d. This chart automatically compensates for temperature rise as a result of compression. Ambient temperature listed in the chart is the air temperature in the area where the system is to be charged. Approach the chart filling pressures slowly and do not overcharge.

NOTE

This chart is for systems used on non-turbocharged aircraft. Since the cylinder used on turbocharged aircraft is rated at 1850 instead of 1800 psi at 70°F, add 50 psi to the filling pressures listed when filling oxygen systems on turbocharged aircraft.

TABLE OF FILLING PRESSURES

Ambient Temp. °F	Filling Press. psig	Ambient Temp. °F	Filling Press. psig
0	1600	50	1825
10	1650	60	1875
20	1700	70	1925
30	1725	80	1975
40	1775	90	2000

15-18. CLEANING OXYGEN MASKS. Oxygen masks may be washed and cleaned in household detergent-type solutions. However, the radio microphone in the pilot's mask must either be removed or protected from moisture. Masks may be disinfected with a hospital-type antiseptic spray (Zep Aero SBT-12, or equivalent).

NOTE

Each interconnected series of oxygen cylinders is equipped with a single gage. The trailer type cascade may also be equipped with a nitrogen cylinder (shown reversed) for filling landing gear struts, accumulators, etc. Cylinders are not available for direct purchase, but are usually leased and refilled by a local compressed gas supplier.

Service Kit SK310-32 (available from the Cessna Service Parts Center) contains an adapter, a pressure gage, hose, lines, and fittings for equipping two oxygen cylinders to service oxygen systems. As noted in the Service Kit, a tee (Part No. 11844) and a pigtail (Part No. 1243-2) should be ordered for each additional cylinder to be used in the cascade of cylinders. Be sure to ground the airplane and ground servicing equipment before use.




Figure 15-5. Typical Portable Oxygen Cascades

CESSNA AIRCRAFT COMPANY

MODEL 200 SERIES

SERVICE MANUAL

SECTION 16

INSTRUMENTS AND INSTRUMENT SYSTEMS

TABLE OF CONTENTS	Page
GENERAL.....	16-1
INSTRUMENT PANELS.....	16-1
Removal.....	16-4
Adding Extra Shock Mounts.....	16-4
Installation.....	16-4
Instrument Removal.....	16-4
Instrument Installation.....	16-4
PITOT AND STATIC SYSTEMS.....	16-4
True Airspeed Indicator.....	16-4
Troubleshooting.....	16-5
Troubleshooting - Airspeed Indicator.....	16-5
Troubleshooting - Altimeter.....	16-6
Troubleshooting - Vertical Speed Indicator.....	16-6
Troubleshooting - Pitot Tube Heater.....	16-7
Maintenance.....	16-7
Checking for Leaks.....	16-7
Static Pressure System Inspection and Leakage Test.....	16-7
Blowing Out Pitot and Static Lines.....	16-10
Removal.....	16-10
Replacement.....	16-10
VACUUM SYSTEM.....	16-10
Troubleshooting.....	16-12
Troubleshooting - Gyros.....	16-12
Troubleshooting - Vacuum Pump.....	16-14
Removal.....	16-15
Replacement.....	16-15
Cleaning.....	16-15
Relief Valve Adjustment.....	16-15
ENGINE INDICATORS.....	16-15
Tachometer.....	16-15
Manifold Pressure/Fuel Flow Indicator.....	16-15
Troubleshooting - Manifold Pressure Gage.....	16-16
Troubleshooting - Fuel Flow Indicator.....	16-17
Cylinder Head Temperature Gage.....	16-18
Troubleshooting.....	16-18
Oil Pressure Gage.....	16-19
Troubleshooting.....	16-19
Oil Temperature Gage.....	16-19
Fuel Quantity Indicators.....	16-19
Troubleshooting.....	16-20
Fuel Quantity Transmitter Calibration.....	16-20
WING FLAP POSITION INDICATING SYSTEM.....	16-20C
Indicator.....	16-20C
Transmitter.....	16-21
MAGNETIC COMPASS.....	16-21
STALL WARNING HORN AND TRANS-MITTER.....	16-21
ELECTRIC CLOCK.....	16-21
TURN-AND-BANK INDICATOR.....	16-22
Troubleshooting.....	16-22
TURN COORDINATOR.....	16-22A
Troubleshooting.....	16-22A
CESSNA ECONOMY MIXTURE INDICATOR.....	16-23
Troubleshooting.....	16-23
Calibration.....	16-23
Removal and Installation.....	16-24
HOURLY METER.....	16-24
WING LEVELER.....	16-24
Rigging.....	16-24

16-1. GENERAL


16-2. This section describes typical instrument installation and the systems operating them, with emphasis on troubleshooting and corrective measures for the systems themselves. It does not deal with specific instrument repairs since this usually requires special equipment and data and should be handled by instrument specialists. Federal Aviation Regulations require that malfunctioning instruments be sent to an approved instrument overhaul and repair station or returned to the manufacturer for servicing. Our concern here is with preventive maintenance on the various instrument systems and correction of system faults, which result in instrument malfunctions.

The descriptive material, maintenance and troubleshooting information in this section is intended to help the mechanic determine malfunctions, and correct them, up to the defective instrument itself, at which point, the instrument technician should be called in.

Some instruments, such as fuel quantity and oil pressure gages, are so simple and inexpensive that repairs usually will be more costly than a new instrument; on the other hand, aneroid and gyro instruments usually are well worth repairing. The words "replace instrument" in the text, therefore, should be taken only in the sense of physical replacement in the airplane. Whether the replacement is to be with a new instrument, an exchanged one, or the original instrument is to be repaired, must be decided on the basis of individual circumstances.

16-3. INSTRUMENT PANELS

16-4. Instrument panels in 200-series aircraft are made in two main sections. The stationary panel carries switches and controls and contains instruments, such as the tachometer, manifold pressure gage, and fuel and oil gages, which are not sensitive to vibration. The shock-mounted panel carries the major flight instruments. Most of the instruments are screw-mounted on the backs of the stationary



NOTE

Type "A" shock mount has unequal threads. Install shorter threads through the floating panel.

NOTE

Beginning in 1968 the shock panel is smaller and carries only the gyro instruments. The two upper shock mounts on the panel have grounding straps.

Figure 16-1. Typical Instrument Panel

and shock-mounted panels, which in turn are covered with decorative panels.

16-5. REMOVAL. The stationary instrument panel is secured to engine mount stringers and a forward fuselage bulkhead and ordinarily is not considered removable. The shock-mounted panel is secured to the stationary panel by rubber shock mount assemblies.

a. To remove the shock-mounted panel, release the clips securing the decorative panel by carefully prying under the buttons on the clips. Remove any control knobs or switches on the panel which would interfere, and pull off the cover. Remove the nuts from the shock mount screws, tag and disconnect the instrument plumbing and wiring, and pull the panel straight back. The control wheel can be removed from the control shaft by removing securing screws, thereby permitting the shock panel to be taken off with the control shaft installed.

b. Where type "B" shock mount assemblies are used, bolts securing the panel to the shock mounts must be removed. Note the combination of bolts, washers, ground straps and spacers used on each mount for correct replacement when the panel is reinstalled.

16-6. ADDING EXTRA SHOCK MOUNTS. Service life of instruments is directly related to adequate shock-mounting of the panel. In some cases, particularly when additional instruments have been added in the field, the original shock-mounts are inadequate to support the increased weight of the panel. Installing additional shock mounts, when the instrument complement is increased, is a practical fix to prevent rapid deterioration of the mounts at the original locations.

16-7. INSTALLATION.

a. To install the shock-mounted panel, set it in place in the stationary panel, aligning the shock mounts with the holes in the panel, and install the nuts on the shock mount screws.

b. When installing type "B" shock mount assembly, place spacers, washers, and ground straps (if used) in proper sequence, then insert bolt through panel into mount and install nut.

c. Replace the instruments and connect the wiring and plumbing. Position the decorative cover and press the retainer clips through the holes in the panel. A light coat of paraffin, beeswax or soap on the prongs of the retainer clips will make their insertion easier.

d. Install any previously removed control knobs and switches. If the control wheel was previously removed for complete removal of the shock panel and decorative cover, reinstall the control wheel.

16-8. INSTRUMENT REMOVAL. The instruments in the stationary and shock-mounted panels are secured with screws inserted through the panel face under the decorative cover. To remove an instrument, remove the decorative cover, disconnect the plumbing or wiring to the instrument concerned, remove the retainer screws and take the instrument out from behind. The instrument cluster, containing fuel and oil gages, is installed as a unit and secured by screws on each corner of the cluster. The cluster must be removed from the rear of the stationary panel to replace an individual gage.

NOTE

All 200-Series aircraft are equipped with a zipper across the cowl deck pad to provide access to the back of the instrument panel.

In all cases when an instrument is removed, the lines or wires disconnected from it should be protected. Cap open lines and cover pressure connections on the instrument, to prevent thread damage and the entrance of foreign matter. Wire terminals should be insulated or tied up so they will not ground accidentally, or short-circuit on another terminal.

16-9. INSTRUMENT INSTALLATION. Generally, installation procedure is the reverse of the removal procedure. Make sure mounting screw nuts are tightened firmly, but do not overtighten them, particularly on instruments having plastic cases. The same rule generally applies to connecting plumbing and wiring. If thread lubricant or sealer is used on plumbing, it should be applied sparingly and only on the male threads. When replacing an electrical gage in an instrument cluster assembly avoid bending the pointer or dial plate. Distortion of the dial or back plate could change calibration of the gages.

16-10. PITOT AND STATIC SYSTEMS. (See figure 16-3.)

16-11. The pitot system conveys ram air pressure to the airspeed indicator. The static system vents the vertical speed indicator and altimeter to atmospheric pressure through plastic tubing connected to static ports. The airspeed indicator is also connected to the static system. An alternate static source is installed as standard equipment on turbocharged aircraft, and optional equipment on standard aircraft. This source is to be used only in emergencies. When used as a static source, cabin pressure is substituted for atmospheric pressure, causing instrument readings to vary from normal. Refer to Owner's Manual for flight operation using alternate static source pressure. A pitot tube heater and stall warning heater may be installed as optional equipment. The heating element is controlled by a switch at the instrument panel and powered by the electrical system.

16-12. TRUE AIRSPEED INDICATOR. A true airspeed indicator may be installed as optional equipment on all 200-Series aircraft. The indicator is equipped with a true airspeed conversion ring. The ring may be rotated until pressure altitude is aligned with outside air temperature, then indicated airspeed on the gage is read as true airspeed on the adjustable ring. The instrument may be removed using figure

16-2 as a guide. Upon installation, and before tightening mounting screws (2), the instrument must be calibrated. This is accomplished as follows: Rotate ring (4) until 120 mph on the adjustable ring aligns with 120 mph on the indicator. Holding this setting, move retainer (3) until 60°F. aligns with zero pressure altitude, then tighten mounting screws (2) and replace decorative cover.




Figure 16-2. True Airspeed Indicator

SHOP NOTES:

16-13. TROUBLE SHOOTING -- PITOT-STATIC SYSTEM.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
LOW OR SLUGGISH AIRSPEED INDICATION.		
Normal altimeter and vertical speed - Pitot tube obstructed, leak or obstruction in pitot line.	Test pitot tube and line for leaks or obstructions.	Blow out tube and line, repair or replace damaged line.
INCORRECT OR SLUGGISH RESPONSE.		
All three instruments - leaks or obstruction in static line.	Test line for leaks and obstructions.	Repair or replace line, blow out obstructed line.
Alternate static source valve open.	Check visually.	Close for normal operation.

16-14. TROUBLE SHOOTING -- AIRSPEED INDICATOR.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
HAND FAILS TO RESPOND.		
Pitot pressure line not properly connected to airspeed indicator connection.	Test line and connection for leaks.	Repair or replace damaged line, tighten connections.
Pitot or static lines clogged.	Check lines for obstructions.	Blow out lines.
INCORRECT INDICATION OR HAND OSCILLATES.		
Leak in pitot or static lines.	Test lines and connections for leaks.	Repair or replace damaged lines, tighten connections.
Defective mechanism.	Substitute known-good indicator and check reading.	Replace instrument.
Leaking diaphragm.	Substitute known-good indicator and check reading.	Replace instrument.
Alternate static source valve open.	Check visually.	Close for normal operation.
HAND VIBRATES.		
Excessive vibration.	Check panel shock mounts.	Replace defective shock mounts.
Excessive tubing vibration.	Check clamps and line connections for security.	Tighten clamps and connections, replace tubing with flexible hose.

16-15. TROUBLE SHOOTING -- ALTIMETER.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
INSTRUMENT FAILS TO OPERATE.		
Static line plugged.	Check line for obstructions.	Blow out line.
Defective mechanism.	Substitute known-good altimeter and check reading.	Replace instrument.
INCORRECT INDICATION.		
Hands not carefully set.	Reset hands with knob.	
Leaking diaphragm.	Substitute known-good altimeter and check reading.	Replace instrument.
Pointers out of calibration.	Compare reading with known-good altimeter.	Replace instrument.
HAND OSCILLATES.		
Static pressure irregular.	Check line for obstructions or leaks.	Blow out line, tighten connections.
Leak in airspeed or vertical speed indicator installations.	Check other instruments and system plumbing for leaks and obstructions.	Blow out lines, tighten connections.

16-16. TROUBLE SHOOTING -- VERTICAL SPEED INDICATOR.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
INSTRUMENT FAILS TO OPERATE.		
Static line plugged.	Check line for obstructions.	Blow out line.
Static line broken.	Check line for damage, connections for security.	Repair or replace damaged line, tighten connections.
INCORRECT INDICATION.		
Partially plugged static line.	Check line for obstructions.	Blow out line.
Ruptured diaphragm.	Substitute known-good indicator and check reading.	Replace instrument.
Pointer off zero.		Reset pointer to zero.
HAND VIBRATES.		
Excessive vibration.	Check panel shock mounts.	Replace defective shock mounts.
Defective diaphragm.	Substitute known-good indicator and check for vibration.	Replace instrument.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
POINTER OSCILLATES.		
Partially plugged static line.	Check line for obstructions.	Blow out line.
Leak in static line.	Test line and connections for leaks.	Repair or replace damaged line, tighten connections.
Leak in instrument case.	Substitute known-good indicator and check reading.	Replace instrument.

16-17. TROUBLE SHOOTING -- PITOT TUBE HEATER.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
TUBE DOES NOT HEAT OR CLEAR ICE.		
Switch turned "OFF."		Turn switch "ON."
Circuit breaker out.	Check circuit breaker.	Reset circuit breaker.
Break in wiring.	Test for open circuit.	Repair wiring.
Heating element burned out.	Check resistance of heating element.	Replace element.

16-18. PITOT AND STATIC SYSTEM MAINTENANCE.

Proper maintenance of the pitot and static system is essential for the proper operation of the altimeter, and vertical speed and airspeed indicators. Leaks, moisture and obstructions in the pitot system will result in false airspeed indications, while static system malfunctions will affect the readings of all three instruments. Under instrument flight conditions, these instrument errors could be hazardous. Cleanliness and security are the principal rules for pitot and static pressure system maintenance. Both the pitot tube and the static ports must be kept clean and unobstructed.

16-19. CHECKING PITOT SYSTEM FOR LEAKS.

To check the pitot system for leaks, fasten a piece of rubber or plastic tubing over the pitot tube, close the opposite end of the tubing and slowly roll up the tube until the airspeed indicator registers in the cruise range. Secure the tube and after a few minutes re-check the airspeed indicator. Any leakage will have reduced the pressure in the system, resulting in a lower airspeed indication. Slowly unroll the tubing before removing it, so the pressure is reduced gradually. Otherwise the instrument may be damaged. If the test reveals a leak in the system, check all connections for tightness.

16-19A. STATIC PRESSURE SYSTEM INSPECTION AND LEAKAGE TEST. The following procedure outlines inspection and testing of the static pressure system, assuming that the altimeter has been tested and

inspected in accordance with current Federal Aviation Regulations.

- a. Ensure that the static system is free from entrapped moisture and restrictions.
- b. Ensure that no alterations or deformations of the airframe surface have been made that would affect the relationship between air pressure in the static pressure system and true ambient static air pressure for any flight configuration.
- c. Seal off one static pressure source with plastic tape. This must be an air-tight seal.
- d. Close the static pressure alternate source valve, if installed.
- e. Attach a source of suction to the remaining static pressure source opening. Figure 16-3A shows one method of obtaining suction.
- f. Slowly apply suction until altimeter indicates a 1000-foot increase in altitude.

CAUTION

When applying or releasing suction, do not exceed the range of the vertical speed indicator or airspeed indicator.

g. Cut off the suction source to maintain a "closed" system for one minute. Leakage shall not exceed 100 feet of altitude loss as indicated on altimeter.

h. If leakage rate is within tolerance, slowly release suction source, then remove tape used to seal static source.





Figure 16-3. Pitot Static Systems



TO APPLY SUCTION:

1. Squeeze air bulb to expel as much air as possible.
2. Hold suction hose firmly against static pressure source opening.
3. Slowly release air bulb to obtain desired suction, then pinch hose shut tightly to trap suction in system.
4. After leak test, release suction slowly by intermittently allowing a small amount of air to enter static system. To do this, tilt end of suction hose away from opening, then immediately tilt it back against opening. Wait until vertical speed indicator approaches zero, then repeat. Continue to admit this small amount of air intermittently until all suction is released, then remove test equipment.

TO APPLY PRESSURE:

CAUTION

Do not apply positive pressure with airspeed indicator or vertical speed indicator connected into static system.

1. Hold pressure hose firmly against static pressure source opening.
2. Slowly squeeze air bulb to apply desired pressure to static system. Desired pressure may be maintained by repeatedly squeezing bulb to replace any air escaping through leaks.
3. Release pressure by slowly opening pressure bleed-off screw, then remove test equipment.

Figure 16-3A. Static System Test Equipment

NOTE

If leakage rate exceeds the maximum allowable, first tighten all connections then repeat the leakage test. If leakage rate still exceeds the maximum allowable, use the following procedure.

- i. Disconnect static pressure lines from airspeed indicator and vertical speed indicator, and use suitable fittings to connect the lines together so that the altimeter is the only instrument still connected into the static pressure system.
- j. Repeat the leakage test to check whether the static pressure system or the removed instruments are the cause of leakage. If instruments are at fault, they must be repaired by an "appropriately rated repair station" or replaced. If the static pressure system is at fault, use the following procedure to locate the leakage.
- k. Attach a source of positive pressure to the static source opening. Figure 16-3A shows one method of obtaining positive pressure.

CAUTION

Do not apply positive pressure with the airspeed indicator or vertical speed indicator connected to the static pressure system.

- l. Slowly apply positive pressure until altimeter indicates a 500-foot decrease in altitude, and maintain this altimeter indication while checking for leaks. Coat line connections, static pressure alternate source valve, and static source flange with solution of mild soap and water, watching for bubbles to locate leaks.
- m. Tighten leaking connections. Repair or replace any parts found defective.
- n. Reconnect airspeed indicator and vertical speed indicator into the static pressure system and repeat leakage test per steps "c" thru "h."

16-20. BLOWING OUT PITOT AND STATIC LINES. Although the pitot system is designed to drain down to the pitot tube opening, condensation may collect at other points in the system and produce a partial obstruction. To clear the line, disconnect it at the airspeed indicator and, using low pressure air, blow from the indicator end of the line toward the pitot tube.

CAUTION

Never blow through pitot or static lines toward the instruments. Doing so may damage them.

Like the pitot lines, the static pressure lines must be kept clear and the connections tight. When necessary, disconnect the static line at the first instrument to which it is connected, then blow the line clear with low pressure air.

NOTE

On aircraft equipped with alternate static source, use the same procedure, opening alternate static source valve momentarily to clear its line, then close valve and clear remainder of the system.

16-21. REMOVAL OF PITOT AND STATIC PRESSURE SYSTEM. To remove the pitot mast, remove the four mounting screws on the side of the attaching connector and pull the mast out of the connector far enough to disconnect the pitot line. Electrical connections to the heater assembly (if installed) may be disconnected through the wing access opening just inboard of the mast. The pitot and static lines are removed in the usual manner, after removing the wing access openings, decorative cover over the left doorpost and left forward upholstery panel. If it is necessary to remove all static system plumbing, the cabin left sidewall upholstery and left side of headliner must be loosened for access to the static line in these areas. The static pressure port connections are accessible through the main gear wheel wells (Model 210-Series only). Reinstallation of the pitot line in the wing will be simpler if a guide wire is drawn in as the line is removed from the wing.

16-22. REPLACEMENT OF PITOT AND STATIC PRESSURE SYSTEM. When replacing components of the pitot and static pressure systems, use anti-seize compound sparingly on the male threads on both metal and plastic connections. Avoid excess compound which might enter the lines. Tighten connections firmly, but avoid overtightening and distorting the fittings. If twisting of plastic tubing is encountered when tightening the fittings, VV-P-236 or USP Petrolatum may be applied sparingly between the tubing and fittings.

16-23. VACUUM SYSTEM.

16-24. Suction to operate the directional gyro and gyro horizon instruments is provided by an engine-driven vacuum pump mounted on the engine accessory section. The pump is gear-driven through a spline-type coupling. The vacuum pump discharge is through an oil separator, where the oil, which passes through the pump and lubricates it, is returned to the engine sump and the air is expelled overboard. A suction relief valve, to control system pressure, is connected between the pump inlet and the firewall fitting. In the cabin, the vacuum line runs from gyro instruments to the relief valve at the firewall. A suction gage indicates suction at the gyro instruments. A central air filtering system is utilized in all vacuum systems. The reading of the suction gage in the central filter system indicates net difference in suction before and after air passes through a gyro. This differential pressure will gradually decrease as the central filter becomes dirty, causing a lower reading on the suction gage. During the 1966 model-year all 200-Series aircraft began using different gyros. These gyros have no instrument filters, but must be used with a central filtering system.




Figure 16-4. Typical Vacuum System




Figure 16-4A. Typical Vacuum System

SHOP NOTES:

16-25. TROUBLE SHOOTING -- VACUUM SYSTEM.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
HIGH SUCTION GAGE READINGS.		
Gyros function normally, relief valve screen clogged, relief valve malfunction.	Check screen, then valve. Compare gage readings with new gage.	Clean screen, reset valve. Replace gage.
LOW SUCTION GAGE READINGS.		
Leaks or restriction between instruments and relief valve, relief valve out of adjustment, defective pump, restriction in oil separator or pump discharge line.	Check lines for leaks, check pump discharge volume, disconnect and test pump.	Repair or replace lines, adjust or replace relief valve, repair or replace pump, clean oil separator.
Central air filter dirty.	Check operation with filter removed.	Clean or replace filter.
SUCTION GAGE FLUCTUATES.		
Defective gage or sticking relief valve.	Check suction with test gage.	Replace gage. Clean sticking valve with Stoddard solvent. Blow dry and test. If valve sticks after cleaning, replace it.
OIL COMES OVER IN PUMP DISCHARGE LINE.		
Oil separator clogged, oil return line obstructed, excessive oil flow through pump.	Check oil separator, return line. Check that pump oil return rate does not exceed 120 cc/hour (approx. 8 drops/minute), at 50 psi oil pressure.	Clean oil separator in Stoddard solvent, blow dry. Blow out lines. If pump oil consumption is excessive, replace oil metering collar and pin in pump.

16-26. TROUBLE SHOOTING -- GYROS.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
HORIZON BAR FAILS TO RESPOND.		
Central or instrument air filters dirty.	Check filters.	Clean or replace filters.
Suction relief valve improperly adjusted.		Adjust or replace relief valve.
Faulty suction gage.	Substitute known-good suction gage and check gyro response.	Replace suction gage.
Vacuum pump failure.	Check pump.	Replace pump.
Vacuum line kinked or leaking.	Check lines for damage and leaks.	Repair or replace damaged lines, tighten connections.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
HORIZON BAR DOES NOT SETTLE.		
Defective mechanism.	Substitute known-good gyro and check indication.	Replace instrument.
Insufficient vacuum.		Adjust or replace relief valve.
Excessive vibration.	Check panel shock mounts.	Replace defective shock mounts.
HORIZON BAR OSCILLATES OR VIBRATES EXCESSIVELY.		
Central or instrument air filter dirty.	Check filters.	Clean or replace filters.
Suction relief valve improperly adjusted.		Adjust or replace relief valve.
Faulty suction gage.	Substitute known-good suction gage and check gyro indication.	Replace suction gage.
Defective mechanism.	Substitute known-good gyro and check indication.	Replace instrument.
Excessive vibration.	Check panel shock mounts.	Replace defective shock mount.
EXCESSIVE DRIFT IN EITHER DIRECTION.		
Central or instrument air filter dirty.	Check filters.	Clean or replace filters.
Low vacuum, relief valve improperly adjusted.		Adjust or replace relief valve.
Faulty suction gage.	Substitute known-good suction gage and check gyro indication.	Replace suction gage.
Vacuum pump failure.	Check pump.	Replace pump.
Vacuum line kinked or leaking.	Check lines for damage and leaks.	Repair or replace damaged lines, tighten connections.
DIAL SPINS IN ONE DIRECTION CONTINUOUSLY.		
Operating limits have been exceeded.		Cage and reset when airplane is level.
Defective mechanism.	Substitute known-good gyro and check indication.	Replace instrument.

16-27. TROUBLE SHOOTING -- VACUUM PUMP.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
EXCESSIVE OIL IN DISCHARGE.		
Excessive flow to pump.	Check pump vent plugs.	Clean vent plugs.
Clogged oil separator.	Check separator for obstructions.	Clean separator.
Damaged engine drive seal.		Replace gasket.
HIGH SUCTION.		
Suction relief valve screen clogged.	Check screen for obstructions.	Clean or replace screen.
LOW SUCTION.		
Relief valve leaking.		Replace relief valve.
Vacuum pump failure.	Substitute known-good pump and check pump suction.	Replace vacuum pump.
LOW PRESSURE.		
Safety valve leaking.		Replace safety valve.
Vacuum pump failure.	Substitute known-good pump and check pump pressure.	Replace vacuum pump.

16-28. REMOVAL OF VACUUM SYSTEM. The various components of the vacuum system are secured by conventional clamps, mounting screws and nuts. To remove a component, remove the mounting screws, nuts, or clamps and disconnect lines.

16-29. REPLACEMENT OF VACUUM SYSTEM. When replacing a vacuum system component, make sure connections are made correctly. Use thread lubricant sparingly and only on male threads. Avoid overtightening connections. Before reinstalling a vacuum pump, probe the oil passages in the pump and engine, to make sure they are open. Place the mounting pad gasket in position over the studs and make sure it does not block the oil passages. Coat the pump drive splines lightly with a high-temperature grease such as Dow Silicone #30 (Dow-Corning Co., Midland, Mich.). After installing the pump, before connecting the plumbing, start the engine and hold a piece of paper over the pump discharge to check for proper lubrication. Proper oil flow thru the pump is one to four fluid ounces per hour.

16-30. CLEANING OF VACUUM SYSTEM. In general, low-pressure, dry compressed air should be used in cleaning vacuum system components removed from the airplane.

CAUTION

Never apply compressed air to lines or components installed in the airplane. The excessive pressures will damage the gyro instruments. If an obstructed line is to be blown out, disconnect it at both ends and blow from the instrument panel out.

Components such as the oil separator and suction relief valve which are exposed to engine oil and dirt should be washed with Stoddard solvent, then dried with a low-pressure air blast. Check hoses for collapsed inner liners as well as external damage.

16-31. VACUUM RELIEF VALVE ADJUSTMENT. A suction gage reading of 5.3 inches of mercury is desirable for gyro instruments. However, a range of 4.6 to 5.4 inches of mercury is acceptable. To adjust the relief valve, remove central air filter, run engine to 1900 rpm on the ground, and adjust relief valve to 5.3±.1 inches of mercury. Reinstall filter. Whenever suction gage reading drops to 4.6 inches of mercury, remove central air filter and check relief valve adjustment, then install a new filter if drop in reading was caused by clogged filter.

16-33. TACHOMETER. The tachometers used on 200-Series aircraft are mechanical indicators driven at half crankshaft speed by flexible shafts. Most tachometer difficulties will be found in the driveshaft. To function properly, the shaft housing must be free of kinks, dents and sharp bends. There should be no bend on a radius shorter than six inches, and no bend within three inches of either terminal. If a tachometer is noisy or the pointer oscillates, check the cable housing for kinks, sharp bends and damage. Disconnect the cable at the tachometer and pull it out of the housing. Check the cable for worn spots, breaks and kinks.

A kink may be detected by holding the cable vertically by one end and slowly rotating it between the fingers to feel for binding and jumpy motion.

Speedometer cable grease or Lubriplate No. 110. Insert the cable in the housing as far as possible, then slowly rotate it to make sure it is seated in the engine fitting. Insert the cable in the tachometer, making sure it is seated in the drive shaft, then reconnect the housing and torque to 50 pound-inches (at instrument).

16-34. MANIFOLD PRESSURE/FUEL FLOW INDICATOR. All 200-Series aircraft have the manifold pressure and fuel flow indicator in one instrument case. However, each instrument operates independently. The manifold pressure gage is a barometric instrument which indicates absolute pressure in the intake manifold in inches of mercury. The fuel flow indicator is a pressure instrument that is calibrated in gallons per hour. It indicates the approximate number of gallons of fuel being metered per hour to the engine. Pressure for operating the indicator is obtained through a hose from the fuel manifold valve. The fuel-flow indicator is vented to atmospheric pressure with standard engine installations, and to turbocharger outlet pressure with turbocharger engine installation.

SHOP NOTES:

[illegible]

16-35. TROUBLE SHOOTING -- MANIFOLD PRESSURE GAGE.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
EXCESSIVE ERROR AT EXISTING BAROMETRIC PRESSURE.		
Pointer shifted.		Replace instrument.
Leak in vacuum bellows.		Replace instrument.
Loose pointer.		Replace instrument.
Leak in pressure line.	Test line and connections for leaks.	Repair or replace damaged line, tighten connections.
Condensate or fuel in line.	Check line for obstructions.	Blow out line.
JERKY MOVEMENT OF POINTER.		
Excessive internal friction.		Replace instrument.
Rocker shaft screws tight.		Replace instrument.
Link springs too tight.		Replace instrument.
Dirty pivot bearings.		Replace instrument.
Defective mechanism.		Replace instrument.
Leak in pressure line.	Test line and connections for leaks.	Repair or replace damaged line, tighten connections.
SLUGGISH OPERATION OF POINTER.		
Foreign matter in line.	Check line for obstructions.	Blow out line.
Damping needle dirty.		Replace instrument.
Leak in pressure line.	Test line and connections for leaks.	Repair or replace damaged line, tighten connections.
EXCESSIVE POINTER VIBRATION.		
Tight rocker pivot bearings.		Replace instrument.
Excessive panel vibration.	Check panel shock mounts.	Replace defective shock mounts.
IMPROPER CALIBRATION.		
Faulty mechanism.		Replace instrument.
NO POINTER MOVEMENT.		
Faulty mechanism.		Replace instrument.
Broken pressure line.	Check line and connections for breaks.	Repair or replace damaged line.

16-36. TROUBLE SHOOTING -- FUEL FLOW INDICATOR.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
DOES NOT REGISTER.		
Pressure line clogged.	Check line for obstructions.	Blow out line.
Pressure line broken.	Check line for leaks and damage.	Repair or replace damaged line.
Fractured bellows or damaged mechanism.		Replace instrument.
Clogged snubber orifice.		Replace instrument.
Pointer loose on staff.		Replace instrument.
POINTER FAILS TO RETURN TO ZERO.		
Foreign matter in line.	Check line for obstructions.	Blow out line.
Clogged snubber orifice.		Replace instrument.
Damaged bellows or mechanism.		Replace instrument.
INCORRECT OR ERRATIC READING.		
Damaged or dirty mechanism.		Replace instrument.
Pointer bent, rubbing on dial or glass.		Replace instrument.
Leak or partial obstruction in pressure or vent line.	Check line for obstructions or leaks.	Blow out dirty line, repair or tighten loose connections.

SHOP NOTES:

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
SERVICE MANUAL

16-38. **CYLINDER HEAD TEMPERATURE GAGE.** On the 200-series, a temperature bulb regulates power to the electrical system powered cylinder head temperature gage. The gage and bulb require little or no maintenance other than cleaning, making sure that the lead is properly supported and all connections are clean, tight and properly insulated. The Rochester and Stewart Warner gages are connected the same, but the Rochester gage does not have a calibration pot and cannot be adjusted. Refer to Table 1, page 16-20A, when troubleshooting the cylinder head temperature gage.

16-39. **TROUBLESHOOTING—CYLINDER HEAD TEMPERATURE GAGE.**

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
GAGE INOPERATIVE.		
No current to circuit.	Check circuit breaker, electrical circuit to gage.	Repair electrical circuit.
Defective gage, bulb or circuit.	Isolate with ohmmeter check of circuits.	Repair or replace defective item.
GAGE FLUCTUATES RAPIDLY.		
Loose or broken wire permitting alternate make and break of gage current.	Inspect circuit wiring.	Repair or replace defective wire.
GAGE READS TOO HIGH ON SCALE.		
High voltage.		Check "A" terminal.
Gage off calibration.		Replace instrument.
GAGE READS TOO LOW ON SCALE.		
Low voltage.		Check voltage supply and "D" terminal.
Gage off calibration.		Replace instrument.
GAGE READS OFF SCALE AT HIGH END.		
Break in bulb.		Replace instrument.
Break in bulb leads.		Replace instrument.
Internal break in gage.		Replace instrument.
OBVIOUSLY INCORRECT READING.		
Defective gage mechanism.		Replace instrument.
Incorrect calibration.		Replace instrument.

SHOP NOTES:

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
SERVICE MANUAL

16-40. OIL PRESSURE GAGE. The Bourdon-type oil pressure gage on the 200-Series is a direct-reading gage, operated by a pressure pickup line connected to the engine main oil gallery.

16-41. TROUBLESHOOTING-OIL PRESSURE GAGE.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
GAGE DOES NOT REGISTER.		
Pressure line clogged.	Check line for obstructions.	Clean line.
Pressure line broken.	Check line for leaks and damage.	Repair or replace damaged line.
Fractured Bourdon tube.		Replace instrument.
Gage pointer loose on staff.		Replace instrument.
Damaged gage movement.		Replace instrument.
GAGE POINTER FAILS TO RETURN TO ZERO.		
Foreign matter in line.	Check line for obstructions.	Clean line.
Foreign matter in Bourdon tube.		Replace instrument.
Bourdon tube stretched.		Replace instrument.
GAGE DOES NOT REGISTER PROPERLY.		
Faulty mechanism.		Replace instrument.
GAGE HAS ERRATIC OPERATION.		
Worn or bent movement.		Replace instrument.
Foreign matter in Bourdon tube.		Replace instrument.
Dirty or corroded movement.		Replace instrument.
Pointer bent and rubbing on dial, dial screw or glass.		Replace instrument.
Leak in pressure line.	Check line for leaks and damage.	Repair or replace damaged line.

16-42. OIL TEMPERATURE GAGE. On some airplanes, the oil temperature gage is a Bourdon tube-type pressure instrument connected by armored capillary tubing to a temperature bulb in the engine. The temperature bulb, capillary tube and gage are filled with fluid and sealed. Expansion and contraction of fluid in the bulb with temperature changes operates the gage. Checking capillary tube for damage and fittings for security is the only maintenance required. Since the tube's inside diameter is small, small dents and kinks, which would be acceptable in larger tubing, may partially or completely close off the capillary, making the gage inoperative. Some airplanes are equipped with gages that are electrically actuated and are not adjustable. Refer to Table 1, page 16-20B when troubleshooting the oil temperature gage.

16-43. FUEL QUANTITY INDICATORS. The fuel quantity indicators are magnetic types that are used in conjunction with float-operated variable-resistance transmitters in the fuel tanks. The tank-full position of the transmitter float produces a minimum resistance through the transmitter, permitting maximum current flow through the fuel quantity indicator and maximum pointer deflection. As the fuel level of the tank is lowered, resistance in the transmitter is increased, producing a decreased current flow through the fuel quantity indicator and a smaller pointer deflection.

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
 SERVICE MANUAL

16-44. TROUBLESHOOTING--FUEL QUANTITY INDICATORS.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
FAILURE TO INDICATE.		
No power to indicator or transmitter. (Pointer stays below E.)	Check circuit breaker, inspect for open circuit.	Reset breaker, repair or replace defective wire.
Grounded wire. (Pointer stays above F.)	Check for partial ground between transmitter and gage	Repair or replace defective wire.
Low voltage.	Check voltage at indicator.	Correct voltage.
Defective indicator.	Substitute known-good indicator.	Replace indicator.
OBVIOUSLY INCORRECT INDICATION.		
Defective indicator.	Substitute known-good indicator.	Replace indicator.
Defective transmitter.	Check internal resistance of transmitter.	Recalibrate or replace.
Low or high voltage.	Check voltage at indicator.	Correct voltage.
STICKY OR SLUGGISH INDICATOR OPERATION.		
Defective indicator.	Substitute known-good indicator.	Replace indicator.
Low voltage.	Check voltage at indicator.	Correct voltage.
ERRATIC READINGS.		
Loose or broken wiring on indicator or transmitter.	Inspect circuit wiring.	Repair or replace defective wire.
Defective indicator or transmitter.	Substitute known-good indicator or transmitter.	Replace indicator or transmitter.
Defective master switch.		Replace switch.

16-45. TRANSMITTER ADJUSTMENT.

WARNING: using the following fuel transmitter calibration procedures on components other than the originally installed (Stewart Warner) components will result in a faulty fuel quantity reading.

16-45A. STEWART WARNER GAGE TRANSMITTER CALIBRATION.

Chances of transmitter calibration changing in normal service is remote; however, it is possible that the float arm or the float arm stops may become bent if the transmitter is removed from the fuel cell/tank. Transmitter calibration is obtained by adjusting float travel. Float travel is limited by the float arm stops.

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
SERVICE MANUAL

WARNING: Use extreme caution while working with electrical components of the fuel system. The possibility of electrical sparks around an "empty" fuel cell creates a hazardous situation.

Before installing transmitter, attach electrical wires and place master switch in the "ON" position. Allow float arm to rest against lower float arm stop and read indicator. The pointer should be on E (empty) position. Adjust the float arm against lower stop so indicator pointer is on E. Raise float until arm is against upper stop and adjust upper stop to permit indicator pointer to be on F (full). Install transmitter in accordance with paragraph 13-16.

16-45B. ROCHESTER GAGE TRANSMITTER.

Do not attempt to adjust float arm or stop. No adjustment is allowed.

16-44C. FUEL QUANTITY INDICATING SYSTEM OPERATIONAL TEST

WARNING: Remove all ignition sources from the airplane and vapor hazard area. Some typical examples of ignition sources are static electricity, electrically powered equipment (tools or electronic test equipment – both installed on the airplane and ground support equipment), smoking and sparks from metal tools.

WARNING: Observe all standard fuel system fire and safety practices.

1. Disconnect all electrical power from the airplane. Attach maintenance warning tags to the battery connector and external power receptacle stating:

DO NOT CONNECT ELECTRICAL POWER, MAINTENANCE IN PROGRESS.

2. Electrically ground the airplane.
3. Level the airplane and drain all fuel from wing fuel tanks.
4. Gain access to each fuel transmitter float arm and actuate the arm through the transmitter's full range of travel.
 - A. Ensure the transmitter float arm moves freely and consistently through this range of travel. Replace any transmitter that does not move freely or consistently.

WARNING: Use extreme caution while working with electrical components of the fuel system. The possibility of electrical sparks around an "empty" fuel cell creates a hazardous situation.

- B. While the transmitter float arm is being actuated, apply airplane battery electrical power as required to ensure that the fuel quantity indicator follows the movement of the transmitter float arm. If this does not occur, troubleshoot, repair and/or replace components as required until the results are achieved as stated.

NOTE: Stewart Warner fuel quantity indicating systems can be adjusted. Refer to paragraph 16-44A for instructions for adjusting Stewart Warner fuel indicating systems. Rochester fuel quantity indicating system components are not adjustable. Only component replacement or standard electrical wiring system maintenance practices are permitted.

5. With the fuel selector valve in the "OFF" position, add unusable fuel to each fuel tank.

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
SERVICE MANUAL

6. Apply electrical power as required to verify the fuel quantity indicator indicates "EMPTY".

A. If "EMPTY" is not indicated, adjust, troubleshoot, repair and/or replace fuel indicating components as required until the "EMPTY" indication is achieved.

NOTE: Stewart Warner fuel quantity indicating systems can be adjusted. Refer to paragraph 16-44A for instructions for adjusting Stewart Warner fuel indicating systems. Rochester fuel quantity indicating system components are not adjustable, only component replacement or standard electrical wiring system maintenance practices are permitted.

7. Fill tanks to capacity, apply electrical power as required and verify fuel quantity indicator indicates "FULL".

A. If "FULL" is not indicated, adjust, troubleshoot, repair and/or replace fuel indicating components as required until the "FULL" indication is achieved.

NOTE: Stewart Warner fuel quantity indicating systems can be adjusted. Refer to paragraph 16-44A for instructions for adjusting Stewart Warner fuel indicating systems. Rochester fuel quantity indicating system components are not adjustable. Only component replacement or standard electrical wiring system maintenance practices are permitted.

8. Install any items and/or equipment removed to accomplish this procedure. Remove maintenance warning tags and connect the airplane battery.

16-44D. OIL TEMPERATURE INDICATING SYSTEM RESISTANCE TABLE 1

The following table is provided to assist in troubleshooting the oil temperature indicating system components.

NOTE: Select the oil temperature sending unit part number that is used in your aircraft from the left column and the temperature from the column headings. Read the ohms value under the appropriate temperature column.

Part Number	Type	72°F	120°F	165°F	220°F	250°F
S1630-1	Oil Temp				46.4 Ω	
S1630-3	Oil Temp		620.0 Ω			52.4 Ω
S1630-4	Oil Temp		620.0 Ω			52.4 Ω
S1630-5	Oil Temp			192.0 Ω		
S2335-1	Oil Temp	990.0 Ω				34.0 Ω

16-44E. CYLINDER HEAD TEMPERATURE INDICATING SYSTEM RESISTANCE TABLE 2

The following table is provided to assist in troubleshooting the cylinder head temperature indicating system components.

Select the cylinder head temperature sending unit part number that is used in your aircraft from the left column and the temperature from the column headings. Read the ohms value under the appropriate temperature column.

Part Number	Type	200°F	220°F	450°F	475°F
S1372-1	CHT		310.0 Ω	34.8 Ω	46.4 Ω
S1372-2	CHT		310.0 Ω	34.8 Ω	
S1372-3	CHT			113.0 Ω	
S1372-4	CHT			113.0 Ω	
S2334-3	CHT	745.0 Ω			38.0 Ω
S2334-4	CHT	745.0 Ω			38.0 Ω

CESSNA AIRCRAFT COMPANY
MODEL 200 SERIES
SERVICE MANUAL

16-45. WING FLAP POSITION INDICATING SYSTEM.

16-46 INDICATOR used on 200-Series aircraft (prior to 1968) is an electrical instrument that indicates flap position in 10-degree increments from 0 to 40 degrees. Beginning in 1968, a mechanical pointer replaces the electrical type. Refer to Section 7 for description and adjustment details.

16-47. TRANSMITTER used prior to 1968 is located adjacent to the transmission and motor. An electrical signal is sent to the position indicator as the transmitter senses flap movement by means of mechanical linkage.

16-48. MAGNETIC COMPASS. (See figure 16-5.)

16-49. The magnetic compass used in 200-Series aircraft is liquid-filled, with expansion provisions to compensate for temperature changes. It is equipped with compensating magnets adjustable from the front of the case. The compass is individually lighted by a GE No. 330 lamp inside the compass case, controlled by the instrument lights rheostat switch. No maintenance is required on the compass except an occasional check on a compass rose with adjustment of the compensation, if necessary, and replacement of the lamp. The compass mount is attached by three screws to a base plate. The base plate is bonded to the windshield with Methylene Chloride. A tube containing the compass light wires is attached to the metal strip at the top of the windshield. Removal of the compass is accomplished by removing the screw at the forward end of the compass mount, unfastening the metal strip at the top

of the windshield, and cutting the two wire splices. Removal of the compass mount is accomplished by removing the three screws attaching the mount to the base plate. Access to the inner screw is gained through a hole in the bottom of the mount, through which a thin screwdriver can be inserted. When installing the compass, it will be necessary to resplice the compass light wires.

16-50. STALL WARNING HORN AND TRANSMITTER.

16-51. The stall warning horn is mounted on the map compartment. It is electrically operated, and is controlled by a stall warning transmitter mounted on the leading edge of the left wing. For further discussion of the warning horn and transmitter, refer to Section 17.

16-52. ELECTRIC CLOCK.

16-53. All 200-Series aircraft are equipped with an electric clock which operates on 12 volts and requires a one-amp fuse. The fuse holder is located adjacent to the battery box. The clock's electrical circuit is separate from the aircraft's electrical system, and will operate when the master switch is "OFF."




Figure 16-5. Magnetic Compass

16-54. TURN-AND-BANK INDICATOR.

16-55. The turn-and-bank indicator used in 200-Ser-

ies aircraft is an electrically operated instrument. It is powered by the aircraft electrical system and therefore operates only when the master switch is on.

16-56. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
INDICATOR POINTER FAILS TO RESPOND.		
Automatic resetting circuit breaker defective.	Check circuit breaker.	Replace circuit breaker.
Master switch "OFF" or switch defective.	Check switch "ON"	Replace defective switch.
Broken or grounded lead to indicator.	Check circuit wiring.	Repair or replace defective wiring.
Indicator not grounded.	Check ground wire.	Repair or replace defective wire.
Defective mechanism.		Replace instrument.
HAND SLUGGISH IN RETURNING TO ZERO.		
Defective mechanism.		Replace instrument.
Low voltage.	Check voltage at indicator.	Correct voltage.
POINTER DOES NOT INDICATE PROPER TURN.		
Defective mechanism.		Replace instrument.
HAND DOES NOT SIT ON ZERO.		
Gimbal and rotor out of balance.		Replace instrument.
Hand incorrectly sits on rod.		Replace instrument.
Sensitivity spring adjustment pulls hand off zero.		Replace instrument.
IN COLD TEMPERATURES, HAND FAILS TO RESPOND OR IS SLUGGISH.		
Oil in indicator becomes too thick.		Replace instrument.
Insufficient bearing end play.		Replace instrument.
Low voltage.	Check voltage at indicator.	Correct voltage.
NOISY GYRO.		
High voltage.	Check voltage at indicator.	Correct voltage.
Loose or defective rotor bearings.		Replace instrument.

16-56A. TURN COORDINATOR is an electrically operated, gyroscopic, roll-turn rate indicator. Its gyro simultaneously senses rate of motion roll and yaw axes which is projected on a single indicator. The

gyro is a non-tumbling type requiring no caging mechanism, and incorporates an ac brushless spin motor with a solid state inverter.

16-56B. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
INDICATOR DOES NOT RETURN TO CENTER.		
Friction caused by contamination in the indicator damping.		Replace instrument.
Friction in gimbal assembly.		Replace instrument.
DOES NOT INDICATE A STANDARD RATE TURN (TOO SLOW).		
Low voltage.	Measure voltage at instrument.	Correct voltage.
Inverter frequency changed.		Replace instrument.
NOISY MOTOR.		
Faulty bearings.		Replace instrument.
ROTOR DOES NOT START.		
Faulty electrical connection.	Check continuity and voltage.	Correct voltage or replace faulty wire.
Inverter malfunctioning.		Replace instrument.
Motor shorted.		Replace instrument.
Bearings frozen.		Replace instrument.
IN COLD TEMPERATURES, HAND FAILS TO RESPOND OR IS SLUGGISH.		
Oil in indicator becomes too thick.		Replace instrument.
Insufficient bearing end play.		Replace instrument.
Low Voltage.	Check voltage at instrument.	Correct voltage.
NOISY GYRO.		
High voltage.	Check voltage to instrument.	Correct voltage.
Loose or defective rotor bearings.		Replace instrument.

16-57. CESSNA ECONOMY MIXTURE INDICATOR (optional) is an exhaust gas temperature (EGT) sensing device which is used to aid the pilot in selecting the most desirable fuel-air mixture for cruising

flight at less than 75% power. Exhaust gas temperature (EGT) varies with the ratio of fuel-to-air mixture entering the engine cylinders. See appropriate airplane Owner's Manual for operating procedures of system.

16-58. TROUBLE SHOOTING.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
INDICATOR INOPERATIVE		
Defective indicator, probe or circuit.	Isolate with ohmmeter check of circuit.	Repair or replace defective part.
INCORRECT READING.		
Indicator needs calibrating.	See paragraph 16-59.	See paragraph 16-59.
FLUCTUATING READING.		
Loose, frayed, or broken lead, permitting alternate make and break of current.	Check for defective circuit.	Tighten connections, and repair or replace defective leads.

16-59. CALIBRATION. Three different types of indicators have been used. The earliest type (type "A") was equipped with a calibration adjustment knob on the face of the instrument and a small calibration adjustment screw on the back of the case. A later type (type "B") was equipped with a calibration adjustment knob on the face of the instrument only. The latest type (type "C") is equipped with a calibration adjustment potentiometer on the back of the case, with a reference pointer adjustment screw on the face of the instrument.

NOTE

The meter reading will change slightly after initial calibration because of lead deposit build-up on the probe. These deposits, however, will reach an equilibrium level and will result in a small drop in EGT indication, so that a small recalibration will be desirable. These lead deposits do not in any way affect the use of the indicator for mixture control or trouble detection. Leads and/or probes can be interchanged between types "A" and "B," but neither of these can be interchanged with type "C."

TYPE "A" CALIBRATION:

The calibration adjustment knob located on the face of the instrument is used to position the pointer over the reference increment line (4/5 of scale) at peak EGT with 65% cruise power.

NOTE

This setting will provide relative temperature indications for normal cruise power settings within the range of the instrument.

Rotation of the knob will adjust the pointer three small divisions up or down ($\pm 75^{\circ}\text{F}$). The knob operates a cam and may be rotated either direction through 360° , without damage to the instrument. If further calibration is required to place the pointer over the reference line at peak EGT with 65% power, remove the instrument and use the small calibration adjustment screw located in the hole at the one o'clock position on the back of the case. Turning the screw one complete turn counterclockwise increases the meter reading one small increment (25°F). Clockwise rotation of the screw decreases the meter reading. Rarely will adjustment of this nature be required after initial installation.

TYPE "B" CALIBRATION:

The calibration adjustment knob located on the face of the instrument is used to position the pointer over the reference increment line (4/5 of scale) at peak EGT with 65% cruise power.

NOTE

This setting will provide relative temperature indications for normal cruise power settings within the range of the instrument.

Rotation of the knob will adjust the pointer seven small divisions up or down ($\pm 175^{\circ}\text{F}$). The knob operates a cam and may be rotated either direction without damage to the instrument.

TYPE "C" CALIBRATION:

Since there is no calibration adjustment knob on the face of the instrument, all calibration is done at the potentiometer adjustment screw at the back of the case. Turning the screw clockwise increases the meter reading, and turning it counterclockwise decreases the meter reading. There is a stop in each direction and damage can occur if too much torque is applied against the stops. Approximately 600°F total adjustment is provided. The adjustable yellow pointer on the face of the instrument is a reference pointer only.

16-60. REMOVAL AND INSTALLATION. Removal of the indicator is accomplished by removing the mounting screws and disconnecting leads. Tag the leads to facilitate installation. The thermocouple probe is secured to the exhaust stack with a clamp. The clamp should be tightened to 45 lb-in., and safetied as required.

16-61. HOURMETER.

16-62. An hourmeter may be installed as optional equipment. The meter operates electrically, and is actuated by a pressure switch in the oil system. The meter is powered by the clock's electrical system, and therefore will operate independent of the master switch. A small indicator on the dial face rotates when the meter is actuated. If the meter is inoper-

ative, and the clock is operating, the meter or its wiring is faulty and must be replaced.

16-63. WING LEVELER.

16-64. A wing leveler system, consisting of a turn coordinator, pneumatic servos and connecting cables and hoses may be installed as optional equipment. The turn coordinator gyro senses changes in roll attitude, then electrically meters vacuum power from the engine-driven vacuum pump to the cylinder-piston servos, operating the ailerons for longitudinal stability. Manual control of the system is afforded by the roll trim knob. The roll trim should not be used to correct faulty rigging or "wing heaviness". Manual override of the system may be accomplished without damage to the aircraft or system. The ON-OFF valve controls the vacuum supply to the distributor valve, but does not affect the electrically operated turn coordinator gyro.

The system may be removed and installed while using figure 16-6 as a guide and observing general precautions outlined in this section. Installation of the wing leveler system does not change the vacuum relief valve settings specified in paragraph 16-31. Refer to appropriate publication issued by manufacturer for trouble shooting.

16-65. RIGGING. The aileron servos are rigged by positioning the left aileron up, then pulling the servo cable until the piston is extended and the seal is taut but not stretched. Holding this position, attach the servo cable to the aileron cable as shown in applicable figure. Repeat procedure for right wing.

SHOP NOTES:




Figure 16-6. Wing Leveler Control System (Sheet 1 of 2)




Figure 16-6. Wing Leveler Control System (Sheet 2 of 2)

SECTION 17

ELECTRICAL SYSTEMS

NOTE

The electrical systems on 206 and 210 series aircraft are identical except where specifically noted otherwise.

TABLE OF CONTENTS	Page	Page
ELECTRICAL POWER SUPPLY SYSTEM . . .	17-2	
BATTERY AND EXTERNAL POWER SYSTEM . . .	17-2	
Ammeter	17-2	
Split Bus Bar	17-2	
Battery	17-2	
Removal and Replacement	17-2	
Cleaning	17-2	
Adding Electrolyte or Water.	17-2	
Testing.	17-2	
Charging	17-3	
Battery Box.	17-3	
Removal and Replacement	17-3	
Maintenance	17-3	
Battery Contactor.	17-3	
Removal and Replacement	17-3	
Master Switch	17-3	
Ground Service Receptacle.	17-5	
Removal and Replacement	17-5	
Battery Contactor Closing Circuit	17-5	
Trouble Shooting the Battery and External Power System	17-7	
ALTERNATOR POWER SYSTEM	17-8	
Alternator	17-8	
Alternator Reverse Voltage Damage	17-8	
Removal and Replacement	17-8	
Alternator Voltage Regulator	17-10	
Removal and Replacement	17-11	
Trouble Shooting the Alternator Power System	17-11	
AIRCRAFT LIGHTING SYSTEM	17-13	
Trouble Shooting the Aircraft Lighting System	17-13	
Landing and Taxi Lights	17-14	
Removal and Replacement	17-14	
Navigation Lights	17-14	
Removal and Replacement	17-14	
Courtesy Lights	17-14	
Removal and Replacement	17-14	
Rotating Beacon	17-14	
Removal and Replacement	17-14	
Flashing Beacon Light	17-18	
Removal and Replacement	17-18	
Overhead Console Lights	17-18	
Removal and Replacement	17-18	
Adjustment	17-18	
Map Lights	17-19	
Removal and Replacement:		
Door Post Map Lights	17-19	
Control Wheel Map Light	17-20	
Post Lights	17-20	
Removal and Replacement	17-20	
Dome Lights	17-20	
Compass and Radio Dial Lights	17-21	
STALL WARNING UNIT	17-21	
Removal and Replacement	17-21	
STALL WARNING UNIT	17-21	
Removal and Replacement	17-21	
STALL WARNING SWITCH	17-21	
Adjustment	17-21	
Removal and Replacement	17-21	
PITOT AND STALL WARNING HEATER CIRCUITS	17-21	
Removal and Replacement	17-21	
LANDING GEAR INDICATOR LIGHTS	17-21	
Removal and Replacement	17-21	
CIGAR LIGHTER	17-23	
ELECTRICAL LOAD ANALYSIS CHARTS		
1966 MODELS	17-24	
1967 MODELS	17-25	
1968 MODELS	17-26	

17-1. ELECTRICAL POWER SUPPLY SYSTEM.

17-2. Electrical energy for the aircraft is supplied by a 14-volt, direct-current, single-wire, negative ground electrical system. A single 12-volt battery supplies power for starting and furnishes a reserve source of power in the event of alternator failure. An engine-driven alternator is the normal source of power during flight and maintains a battery charge controlled by a voltage regulator. An external power source receptacle is offered as optional equipment to supplement the battery alternator system for starting and ground operation.

17-3. BATTERY AND EXTERNAL POWER SYSTEM.

17-4. AMMETER. The ammeter is connected between the battery and the aircraft bus. The meter indicates the amount of current flowing either to or from the battery. With a low battery and the engine operating at cruise speed the ammeter will show the full alternator output when all electrical equipment is off. When the battery is fully charged and cruise RPM is maintained with all electrical equipment off, the ammeter will show a minimum charging rate.

17-5. SPLIT BUS BAR. A split bus bar has been installed on all 1967 model aircraft utilizing an electrically engaged starter. One side of the bus bar supplies power to the electrical equipment while the other side supplies the electronic installations. When the master switch is closed the battery contactor engages and battery power is supplied to the electrical side of the split bus bar. The electrical bus feeds battery power to the electronics bus through a normally-closed relay; this relay opens when the starter switch is engaged or when an external power source is used, preventing transient voltages from damaging the semiconductor circuitry in the electronic installations.

17-6. BATTERY. The battery is 12 volts and is approximately 33 ampere-hour in capacity. The battery is mounted on the forward left side of the firewall and is equipped with non-spill type filler caps.

17-7. REMOVAL AND REPLACEMENT OF BATTERY. (See figure 17-1.)

- a. To gain access to the battery, remove the upper left half of cowling.
- b. Remove the battery box lid and disconnect the battery ground cable.

CAUTION

Always remove the ground cable first and connect it last to prevent accidentally shorting the battery to the airframe with tools.

- c. Disconnect the positive cable from the battery and remove the battery from the aircraft.
- d. To install a battery, reverse this procedure.

17-8. CLEANING THE BATTERY. For maximum efficiency, the battery and connections should be kept clean at all times.

- a. Remove the battery in accordance with preceding paragraph.

- b. Tighten battery cell filler caps to prevent the cleaning solution from entering the cells.

- c. Wipe battery cable ends, battery terminals and entire surface of the battery with a clean cloth moistened with a solution of bicarbonate of soda (baking soda) and water.

- d. Rinse with clear water, wipe off excess water and allow battery to dry.

- e. Brighten up cable ends and battery terminals with emery cloth or a wire brush.

- f. Install the battery according to the preceding paragraph.

- g. Coat the battery terminals and the cable ends with petroleum jelly.

17-9. ADDING ELECTROLYTE OR WATER TO THE BATTERY. A battery being charged and discharged with use will decompose the water from the electrolyte by electrolysis. When the water is decomposed, hydrogen and oxygen gases are formed which escape into the atmosphere through the battery vent system. The acid in the solution chemically combined with the plates of the battery during discharge or is suspended in the electrolyte solution during charge. Unless the electrolyte has been spilled from a battery, acid should not be added to the solution. The water will decompose into gases and should be replaced regularly. Add distilled water as necessary to maintain the electrolyte level even with the horizontal baffle plate inside the battery. When "dry charged" batteries are put into service, fill as directed with electrolyte. However, as the electrolyte level falls below normal with use add only distilled water to maintain the proper level. The battery electrolyte contains approximately 25% sulphuric acid by volume. Any change in this volume will hamper the proper operation of the battery.

CAUTION

Do not add any type of "battery rejuvenator" to the electrolyte. When acid has been spilled from a battery, the acid balance may be adjusted by following instructions published by the Association of American Battery Manufacturers.

17-10. TESTING THE BATTERY. The specific gravity check method of testing the battery is preferred when the condition of the battery is in a questionable state-of-charge. However, when the aircraft has been operated for a period of time with an alternator output voltage which is known to be correct, the question of battery capability may be answered more correctly with a load type tester. If testing the battery is deemed necessary, the specific gravity should be checked first and compared with the following chart.

BATTERY HYDROMETER READINGS

1.280 Specific Gravity	100% Charged
1.250 Specific Gravity	75% Charged
1.220 Specific Gravity	50% Charged
1.190 Specific Gravity	25% Charged
1.160 Specific Gravity	Practically Dead

NOTE

All readings shown are for an electrolyte temperature of 80° Fahrenheit. For higher temperatures the readings will be slightly lower. For cooler temperatures the readings will be slightly higher. Some hydrometers have a built-in temperature compensation chart and a thermometer. If this type tester is used, disregard this chart.

If a specific gravity reading indicates that the battery is not fully charged, the battery should be charged at approximately 20 amperes for 30 minutes, or until the battery voltage rises to 15 volts. After charging, a load type tester will give more meaningful results. A specific gravity check can be used after charging but the check cannot spot cells which short under load, broken connectors between plates of a cell, etc.

17-11. CHARGING THE BATTERY. When the battery is to be charged, the level of electrolyte should be checked and adjusted by adding distilled water to cover the tops of the internal battery plates. The battery cables and connections should be clean.

WARNING

When a battery is charging, hydrogen and oxygen gases are generated. Accumulation of these gases can create a hazardous explosive condition. Always keep sparks and open flame away from the battery. Allow unrestricted ventilation of the battery area during charging.

The main points of consideration during a battery charge are excessive battery temperature and violent gassing. Under a reasonable rate of charge (20 amperes or less) the battery temperature should not rise over 125°F nor should gassing be so violent that acid is blown from the vents.

17-12. BATTERY BOX. The battery is completely enclosed in a box which is painted with acid proof paint. The box has a vent tube which protrudes through the bottom of the aircraft allowing battery gases and spilled electrolyte to escape. The battery box is riveted to the left forward side of the firewall.

17-13. REMOVAL AND REPLACEMENT OF BATTERY BOX. (See figure 17-1.) The battery box is riveted to the firewall. The rivets must be drilled out to remove the box. When a battery box is installed and riveted into place, all rivets and scratches inside the box should be painted with acid-proof lac-

quer, Part No. CES 1054-381, available from the Cessna Service Parts Center.

17-14. MAINTENANCE OF BATTERY BOX. The battery box should be inspected and cleaned periodically. The box and cover should be cleaned with a strong solution of bicarbonate of soda (baking soda) and water. Hard deposits may be removed with a wire brush. When all corrosive deposits have been removed from the box, flush it thoroughly with clean water.

WARNING

Do not allow acid deposits to come in contact with skin or clothing. Serious acid burns may result unless the affected area is washed immediately with soap and water. Clothing will be ruined upon contact with battery acid.


Inspect the cleaned box and cover for physical damage and for areas lacking proper acid proofing. A badly damaged or corroded box should be replaced. If the box or lid require acid proofing, paint the area with acid-proof black lacquer, Part No. CES 1054-381, available from the Cessna Service Parts Center.

17-15. BATTERY CONTACTOR. The battery contactor is bolted to the firewall below the battery box. The contactor is a solenoid plunger type, which is actuated by turning the master switch on. When the master switch is off, the battery is disconnected from the electrical system. A silicon diode is used to eliminate spiking of the transistorized radio equipment. The cathode (+) terminal of the diode connects to the battery terminal of the battery contactor. The anode (-) terminal of the diode connects to the same terminal on the contactor as the master switch wire. This places the diode directly across the contactor solenoid coil so that inductive spikes originating in the coil are clipped when the master switch is opened. See figure 17-1 for pictorial installation of the battery contactor and diode.

17-16. REMOVAL AND REPLACEMENT OF BATTERY CONTACTOR. (See figure 17-1.)

- a. Open battery box and disconnect ground cable from negative battery terminal. Pull cable clear of battery box.
- b. Remove the nut, lockwasher and the two plain washers securing the battery cables to the battery contactor.
- c. Remove the nut, lockwasher and the two plain washers securing the wire which is routed to the master switch.
- d. Remove the bolt, washer and nut securing each side of the battery contactor to the firewall. The contactor will now be free for removal.
- e. To replace the contactor, reverse the procedure.

17-17. MASTER SWITCH. The operation of the battery and alternator systems is controlled by a master switch. The switch is a rocker type with double-pole, double-throw contacts. The switch, when operated, connects the battery contactor coil to ground and the alternator field circuit to the battery, activating the power systems. The master switch is



1. Nut
2. Lockwasher
3. Gnd Ser Recpt Cable
4. Starter Contactor Cable
5. Washer

6. Bolt
7. Ground Cable
8. Fuse
9. Cap-Fuse
10. Battery Box
11. Fasteners

12. Power Cable
13. Clock Wire
14. Diode Wire
15. Battery Solenoid
16. Master Switch Wire

Figure 17-1. Battery Installation

located on the stationary instrument panel.

NOTE

17-18. GROUND SERVICE RECEPTACLE. A ground service receptacle is installed to permit the use of external power for cold weather starting or when performing lengthy electrical maintenance. A reverse polarity protection system is utilized whereby ground power must pass through an external power contactor to be connected to the bus. A silicon junction diode is connected in series with the coil on the external power contactor so that if the ground power source is inadvertently connected with a reversed polarity, the external power contactor will not close. This feature protects the diodes in the alternator, and other semiconductor devices used in the airplane, from possible reverse polarity damage.


NOTE

Maintenance of the electronic installations cannot be performed when using external power. Application of external power opens the relay supplying voltage to the electronics bus. For lengthy ground testing of electronics systems, connect a well regulated and filtered power supply directly to the battery side of the battery contactor. Adjust the supply for 14 volts and close the master switch.

When using ground power to start the airplane, close the master switch before removing the ground power plug. This will insure closure of the battery contactor and excitation of the alternator field in the event that the battery is completely dead.

- 17-19. REMOVAL AND REPLACEMENT OF THE GROUND SERVICE RECEPTACLE.** (See figure 17-2.)
- Open the battery box and disconnect the ground cable from the negative terminal of the battery and pull the cable free of the box.
 - Remove the nuts, washers, ground strap, bus bar and diode board from the studs of the receptacle and remove battery cable.
 - Remove the screws and nuts holding the receptacle; ground strap will then be free from the bracket.
 - To install a ground service receptacle, reverse this procedure.


17-20. BATTERY CONTACTOR CLOSING CIRCUIT
On 1967 Model aircraft and On, a diode, resistor and fuse circuit was added to the ground service receptacle bracket to shunt a small charge around the battery contactor so that ground power may be used to close the contactor when the battery is too dead to energized the contactor by itself.



GROUND SERVICE RECEPTACLE INSTALLATION THRU 1966

- | | | |
|-----------------|---------------|----------------|
| 1. Ground Strap | 5. Receptacle | 8. Washer |
| 2. Cover Plate | 6. Bracket | 9. Power Cable |
| 3. Doubler | 7. Lockwasher | 10. Nut |
| 4. Screw | | 11. Nipple |

Figure 17-2. Ground Service Receptacle Installation (Sheet 1 of 2)



1967 & 1968 GROUND SERVICE RECEPTACLE INSTALLATION

- | | | |
|------------------------------|---|------------------------------|
| 1. Nut | 10. Wire to Ext. Pwr. Recept. | 17. Cover Plate |
| 2. Lockwasher | 11. Solder Terminal | 18. Screw |
| 3. Washer | 12. Spacer | 19. Receptacle |
| 4. Insulating Washer | 13. Diode Board | 20. Ground Strap |
| 5. Fuse | 14. Bus Bar | 21. Ext. Power Contactor |
| 6. Bracket | 15. Nipple - Used before resistor was added | 22. Nipple - Early Airplanes |
| 7. Wire to Battery Contactor | 16. Doubler | 23. Cover - Late Airplanes |
| 8. Resistor -.75 ohm | | 24. Power Cable |
| 9. Diode | | 25. Contactor Control Wire |

Figure 17-2. Ground Service Receptacle Installation (Sheet 2 of 2)

17-21. TROUBLE SHOOTING THE BATTERY AND EXTERNAL POWER SYSTEM.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
BATTERY WILL NOT SUPPLY POWER TO BUS OR IS INCAPABLE OF CRANKING ENGINE.		
Battery discharged.	1. Measure voltage at "BAT" terminal of battery contactor with master switch and a suitable load such as a taxi light turned on. Normal battery will indicate 11.5 volts or more.	If voltage is low, proceed to step 2. If voltage is normal, proceed to step 3.
Battery faulty.	2. Check fluid level in cells and charge battery at 20 amps for approximately 30 minutes or until the battery voltage rises to 15 volts. Check battery with a load type tester.	If tester indicates a good battery, the malfunction may be assumed to be a discharged battery. If the tester indicates a faulty battery, replace the battery.
Faulty contactor or wiring between contactor or master switch.	3. Measure voltage at master switch terminal (smallest) on contactor with master switch closed. Normal indication is zero volts.	If voltage reads zero, proceed to step 4. If a voltage reading is obtained, check wiring between contactor and master switch. Also check master switch.
Open coil on contactor.	4. Check continuity between "BAT" terminal and master switch terminal of contactor. Normal indication is 16 to 24 ohms (Master switch open).	If ohmmeter indicates an open coil, replace contactor. If ohmmeter indicates a good coil, proceed to step 5.
Faulty contactor contacts.	5. Check voltage on "BUS" side of contactor with master switch closed. Meter normally indicates battery voltage.	If voltage is zero or intermittent, replace contactor. If voltage is normal, proceed to step 6.
Faulty wiring between contactor and bus.	6. Inspect wiring between contactor and bus.	Repair or replace wiring.
STARTER ENGAGES WHEN GROUND POWER IS CONNECTED.		
Shorted or reversed diode in split bus-bar system.	Check wiring to, and condition of diode mounted on the split bus relay bracket adjacent to the magneto switch.	Correct wiring. Replace diode board assembly.
GROUND POWER WILL NOT CRANK ENGINE.		
Ground service connector wired incorrectly.	1. Check for voltage at all three terminals of external power contactor with ground power connected and master switch off. 2. Check for voltage at small terminal of ground service receptacle.	If voltage is present on input and coil terminals but not on the output terminal, proceed to step 4. If voltage is present on the input terminal but not on the coil terminal, proceed to step 2. If voltage is present on all three terminals, check wiring between contactor and bus. If voltage is not present, check ground service plug wiring. If voltage is present, proceed to step 3.

17-21. TROUBLE SHOOTING THE BATTERY AND EXTERNAL POWER SYSTEM. (Continued)

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
GROUND POWER WILL NOT CRANK ENGINE (Continued)		
Open or mis-wired diode on ground service diode board assembly.	3. Check polarity and continuity of diode on diode board at rear of ground service receptacle.	If diode is open or improperly wired, replace diode board assembly.
Faulty external power contactor.	4. Check resistance from coil terminal of external power contactor to ground (master switch off and ground power unplugged). Normal indication is 16-24 ohms.	If resistance indicates an open coil, replace contactor. If resistance is normal, proceed to step 5.
Faulty contacts in external power contactor.	5. With master switch off and ground power applied, check for voltage drop between two large terminals of external power (turn on taxi light for a load). Normal indication is zero volts.	If voltage is intermittantly present or present all the time, replace contactor.

17-22. ALTERNATOR POWER SYSTEM. The introduction of the high current silicon diode resulted in a reduction of mass required for an alternator rectifier system. This innovation made the alternator practical for use in light aircraft power systems. The alternator, like the generator, produces an ac current by electromagnetic induction. Rectification of the ac is accomplished by silicon diodes rather than by a commutator as in the generator. The alternators higher efficiency arises from the fact that the ac is produced in a three phase system which means that all of the windings carrying ac are working to produce power most of the time. In the generator, only a small portion of the ac windings are in use at any given time.

The alternator, unlike the generator, is self-limiting in its output current capability. Therefore, no current limiting device is required in the alternator regulator. Also, because of the use of silicon diodes in the output network of an alternator the flow of current back into the alternator is impossible and no reverse current protection device is required either. The alternator field is designed to retain no residual magnetic flux and, therefore, the alternator requires excitation to be applied from an external source (the battery) before the alternator will function.

17-23. ALTERNATOR. The 60 ampere alternators used on Cessna single engine aircraft are three phase, delta connected with integral silicon diode rectifiers. The alternator is rated at 14 volts at 60 amperes continuous output. The moving center part of the alternator (rotor) consists of an axial winding with radial interlocking poles which surround the winding. With excitation applied to the winding through slip rings the pole pieces assume magnetic polarity. The rotor is mounted in bearings and rotates inside the stator which contains the windings in which the ac current is generated. The stator windings are three-phase, delta connected and are attached to two diode plates, each of which contains three silicon diodes.

The diode plates are connected to accomplish full-wave,

rectification of the ac current. The resulting dc output is applied to the aircraft bus and sensed by the voltage regulator. The regulator controls the excitation applied to the alternator field thus controlling the output voltage of the alternator.

17-24. ALTERNATOR REVERSE VOLTAGE DAMAGE. The alternator is very susceptible to reverse polarity damage due to the very low resistance of the output windings and the low resistance of the silicon diodes in the output. If a high current source, such as a battery or heavy duty ground power cart is attached to the aircraft with the polarity inadvertently reversed, the current through the alternator will flow almost without limit and the alternator will be immediately damaged.

17-25. REMOVAL AND REPLACEMENT OF THE ALTERNATOR. (See figure 17-3.)

- Make sure that the master switch remains in the off position or disconnect the negative lead from the battery.
- Disconnect the wiring from the alternator.
- Remove the safety wire from the upper adjusting bolt and remove the bolt from the alternator.
- Remove the nut and washer from the lower mounting bolt.
- Remove the alternator drive belt and lower mounting bolt to remove the alternator.
- To replace the alternator, reverse this procedure.
- Adjust belt tension to obtain 3/8" deflection at the center of the belt when applying 12 pounds of pressure to the belt. After the belt is adjusted and the bolt is safety wired, tighten the bottom bolt to 50-70 ft.-lbs. torque to remove any play between the alternator mounting foot and the U-shaped support assembly.

CAUTION

Whenever a new belt is installed, belt tension should be checked within 10 to 25 hours of operation.




Figure 17-3. Alternator Installation

NOTE

When tightening the alternator belt, apply pry bar pressure only to the end of the alternator nearest to the belt pulley.


17-26. ALTERNATOR VOLTAGE REGULATOR.

The alternator voltage regulator contains two relays. One relay is actuated by the aircraft master switch and connects the regulator to the battery. The second relay is a two-stage, voltage sensitive device which is used to control the current applied to the field winding of the alternator. When the upper set of contacts on the voltage regulator relay are closed, full bus voltage is applied to the field. This condition will exist when the battery is being heavily charged or when a very heavy load is applied to the system. When the upper contacts open, as the voltage begins to rise toward normal bus voltage, the voltage to the alternator field is reduced through a resistor network in the base of the regulator thus reducing the output from the alternator. As the voltage con-

tinues to rise, assuming a very light load on the system, the lower contacts will close and ground the alternator field and shut the alternator completely off. Under lightly loaded conditions the voltage relay will vibrate between the intermediate charge rate and the lower (completely off) contacts. Under a moderate load, the relay will vibrate between the intermediate charge rate and the upper (full output) contacts.

The voltage relay is temperature compensated so that the battery is supplied with the proper charging voltage for all operating temperatures. With the battery fully charged (ship's ammeter indicating at or near zero) and a moderate load applied to the system (a taxi light turned on) the voltage at the bus bar should be within the range shown according to the air temperature on the following chart:

TEMPERATURE	BUS VOLTAGE
60-74°F	13.8-14.1
75-90°F	13.7-14.0
91-100°F	13.6-13.9



1. Filter - Radio Noise
2. Wire to Master Switch
3. Shield - Ground

4. Screw
5. Voltage Regulator
6. Wire Shields to Ground

7. Wire to Alternator "F"
8. Wire to Alternator "A+"
9. Wire to Alternator Ground

Figure 17-4. Voltage Regulator Installation

The voltage regulator is adjustable but adjustment on the airplane is not recommended. A bench adjustment procedure is outlined in the Cessna Alternator Charging Systems Servis/Parts Manual.

17-27. REMOVAL AND REPLACEMENT OF REGULATOR. (See figure 17-4.)

a. Make sure that the master switch is off or disconnect the negative lead from the battery.

b. Remove the connector plug from the regulator.
c. Remove two screws holding the regulator on the firewall.
d. To replace the regulator, reverse the procedure. Be sure that the connections for grounding the alternator, wiring shields and the base of the regulator are clean and bright before assembly. Otherwise, poor voltage regulation and/or excessive radio noise may result.

17-28. TROUBLE SHOOTING THE ALTERNATOR SYSTEM.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
AMMETER INDICATES HEAVY DISCHARGE WITH ENGINE NOT RUNNING OR ALTERNATOR CIRCUIT BREAKER OPENS WHEN MASTER SWITCH IS TURNED ON.		
Shorted field in alternator.	1. Remove plug from regulator with master switch on and observe if heavy drain persists.	If heavy drain is reduced, go to step 2. If heavy drain is not reduced, go to step 3.
	2. Check resistance from terminal "F" on alternator to the alternator case. Normal indication is 6-7 ohms.	If resistance is too low, repair or replace alternator.
Shorted radio noise filter or shorted wire.	3. Remove cable from output terminal of alternator. Check resistance from end of cable to ground (MASTER SWITCH MUST BE OFF).	If resistance does not indicate a direct short, go to step 6. If resistance indicates a direct short, go to step 4.
	4. Remove cable connections from radio noise filter. Check resistance from the filter input terminal to ground. Normal indication is infinite resistance.	If reading indicates a direct short, replace filter. If no short is evident, go to step 5.
	5. Check resistance from ground to the free ends of the wires which connected to the radio noise filter (or alternator if no noise filter is installed). Normal indication does not show a direct short.	If a short exists in wires, repair or replace wiring.
Shorted diodes in alternator.	6. Check resistance from output terminal of alternator to alternator case. Reverse leads and check again. Resistance reading may show continuity in one direction but should show an infinite reading in the other direction.	If an infinite reading is not obtained in at least one direction, repair or replace alternator.

17-28. TROUBLE SHOOTING THE ALTERNATOR SYSTEM. (Continued)

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
ALTERNATOR SYSTEM WILL NOT KEEP BATTERY CHARGED.		
Regulator faulty or improperly adjusted.	1. Start engine and adjust for 1500 RPM. Ammeter should indicate a heavy charge rate with all electrical equipment turned off. Rate should taper off in 1-3 minutes. A voltage check at the bus should indicate a reading consistent with the voltage vs temperature chart on page 17-10.	If charge rate tapers off very quickly and voltage is normal, check battery for malfunction. If ammeter shows a low charge rate or any discharge rate, and voltage is low, proceed to step 2.
	2. Stop engine, remove cowl, and remove cover from voltage regulator. Turn master switch ON/OFF several times and observe field relay in regulator. Relay should open and close with master switch and small arc should be seen as contacts open.	If relay is inoperative, proceed to step 3. If relay operates, proceed to step 4.
	3. Check voltage at A+ terminal of regulator with master switch closed. Meter should indicate bus voltage.	If voltage is present, replace regulator. If voltage is not present, check wiring between regulator and bus.
	4. Remove plug from regulator and start engine. Momentarily jumper the "A+" and "F" terminals together on the plug. Ship's ammeter should show heavy rate of charge.	If heavy charge rate is observed, replace regulator. If heavy charge rate is not observed, proceed to step 5.
	5. Check resistance from "F" terminal of alternator. Normal indication is a very low resistance.	If reading indicates no, or poor continuity, repair or replace wiring from regulator to alternator.
	6. Check resistance from "F" terminal of alternator to alternator case. Normal indication is 6-7 ohms.	If resistance is high or low, repair or replace alternator.
	7. Check resistance from case of alternator to airframe ground. Normal indication is very low resistance.	If reading indicates no, or poor continuity, repair or replace alternator ground wiring.
Faulty wiring between alternator and regulator, or faulty alternator.		
ALTERNATOR OVERCHARGES BATTERY - BATTERY USES EXCESSIVE WATER.		
Regulator faulty or improperly adjusted.	Check bus voltage with engine running. Normal indication agrees with voltage vs temperature chart on page 17-10. Observe ship's ammeter, ammeter should indicate near zero after a few minutes of engine operation.	Replace regulator.

17-29. AIRCRAFT LIGHTING SYSTEM.

panel lights, courtesy lights, a rotating beacon thru 1966 models and a flashing beacon for 1967 models and on.

17-30. Lighting equipment consists of landing and taxi lights, navigation lights, interior and instrument

17-31. TROUBLE SHOOTING AIRCRAFT LIGHTING SYSTEM.

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
LANDING OR TAXI LIGHT OUT.		
Lamp burned out.	Inspect.	Replace lamp.
Defective wiring.	Check continually.	Repair wiring.
BOTH LANDING AND TAXI LIGHT OUT.		
Circuit breaker open.	Inspect.	Reset breaker.
Defective wiring.	Check continuity.	Repair wiring.
Defective switch.	Check continuity through switch.	Replace switch.
ONE NAVIGATION LIGHT OUT.		
Lamp burned out.	Inspect.	Replace lamp.
Defective wiring.	Check continuity.	Replace wiring.
Defective flasher unit.		Replace flasher unit.
NAVIGATION LIGHTS WILL NOT TURN ON.		
Circuit breaker open.	Inspect.	Reset breaker.
Defective wiring.	Check continuity between switch and aircraft bus.	Repair wiring.
Defective switch.	Check continuity through switch.	Replace switch.
ROTATING BEACON WILL NOT LIGHT.		
Circuit breaker open.	Inspect.	Reset breaker.
Defective wiring.	Check continuity of wiring from aircraft bus to rotating beacon plug.	Repair wiring.
Defective beacon.		Repair or replace beacon.
FLASHING BEACON DOES NOT LIGHT.		
Lamp burned out.	Test with new lamp.	Replace lamp.
Circuit breaker open.	Inspect.	Reset.
Faulty flasher assembly.	Remove and test.	Repair or replace.
Faulty switch or wiring.	Test for continuity.	Repair or replace.

17-31. TROUBLE SHOOTING AIRCRAFT LIGHTING SYSTEM. (Continued)

PROBABLE CAUSE	ISOLATION PROCEDURE	REMEDY
MAP LIGHT, DOME LIGHT OR COURTESY LIGHT TROUBLE.		
Circuit breaker open.	Inspect.	Reset breaker.
Burned out lamp.	Inspect.	Replace.
Defective switch.	Check continuity.	Replace.
Defective wiring.	Check continuity from light to aircraft bus.	Repair wiring.
INSTRUMENT LIGHTS WILL NOT LIGHT.		
Rheostat turned down.		Adjust.
Circuit breaker open.	Inspect.	Reset breaker.
Burned out lamp.	Inspect.	Replace.
Defective rheostat.	Check continuity.	Replace.
Defective wiring.	Check continuity of wiring from light to bus.	Repair wiring.

17-32. **LANDING AND TAXI LIGHTS.** The landing and taxi lights are mounted in the leading edge of the left wing. A clear plastic cover provides weather protection for the lamps and is shaped to maintain the leading edge curvature of the wing. The landing lamp is mounted on the inboard side and adjusted to throw its beam further forward than the taxi light. Both lights are controlled by a single switch.

17-33. **REMOVAL AND REPLACEMENT OF LANDING AND TAXI LIGHTS.** (See figure 17-5.)

- a. Remove the screws securing the landing light window assembly and the assembly will then be free for removal.
- b. Remove the four attaching screws from the bracket assembly and remove the bracket.

NOTE

Do not reposition the landing and taxi light adjustment screws. If readjustment is required refer to figure 17-6.

- c. Remove the two screws securing the wiring to the lamp contacts and remove the lamp.
- d. Install new lamp and reassemble.

17-34. **NAVIGATION LIGHTS.** The navigation lights are located on each wing tip and the stinger. Operation of the lights is controlled by a single two position switch. A plastic light detector on each wing tip allows the pilot to determine if the lamps are working properly during flight.

17-35. **REMOVAL AND REPLACEMENT OF NAVI-**

GATION LIGHTS. Figure 17-7 shows in detail all components of the navigation lights. Use this figure as a guide for removal and replacement.

17-36. **COURTESY LIGHTS.** The lights consist of one light located on the underside of each wing to provide ground lighting around the cabin area. The courtesy lights have clear lens and are controlled by a single slide switch labeled, "Utility Lights," located on the left rear door post. The switch also operates the dome lights.

17-37. **REMOVAL AND REPLACEMENT OF COURTESY LIGHTS.** Figure 17-8 shows in detail all components of the courtesy lights installation. Use this figure as a guide for removal and replacement.

17-38. **ROTATING BEACON.** The 1966 models have a rotating beacon containing a small motor that rotates a shutter with three lens openings around a single bulb to give a flashing warning of the aircraft's position. The beacon is installed in a fiberglass mounting atop the vertical fin.

17-39. **REMOVAL AND REPLACEMENT OF ROTATING BEACON.** (See figure 17-9.)

- a. Remove the three screws holding the beacon to the fiberglass mounting.
- b. Withdraw the beacon from the mounting and remove the screw attaching the ground wire to the fin structure.
- c. Disconnect the other electrical lead and remove beacon.
- d. To replace the beacon, reverse this procedure. Mount the beacon with the light baffle forward.




Figure 17-5. Landing and Taxi Light Installation




Figure 17-6. Landing and Taxi Light Adjustment Chart




Figure 17-7. Navigation Light Installation




Figure 17-8. Courtesy Light Installation




Figure 17-9. Rotating and Flashing Beacon Light Installation

17-40. **FLASHING BEACON LIGHT.** The 1967 models, and on, have a flashing beacon light mounted on the vertical fin tip. The flashing beacon is an iodine-vapor lamp, electrically switched by a solid state flasher assembly that is located within the vertical fin tip. The switching frequency of the flasher assembly operates the beacon at approximately 45 flashes per minute. A second flashing beacon may also be installed on the bottom of the fuselage as optional equipment.

17-41. **REMOVAL AND REPLACEMENT OF THE FLASHING BEACON LIGHT.** For removal and replacement of the flashing beacon light, refer to figure 17-9.

17-42. **OVERHEAD CONSOLE LIGHTS.** The overhead console contains a map light and an instrument panel flood light. The instrument light portion of the console has a red lens which provides non-glare in-

strument flood lighting. The intensity of the instrument lighting is controlled by a rheostat mounted on the instrument panel. The console incorporates two map light openings with slide covers to provide map lighting. The map light can be exposed by sliding the cover. 1968 models have ventilation outlets added to the overhead console as shown in figure 17-10.

17-43. **REMOVAL AND REPLACEMENT OF OVERHEAD CONSOLE LIGHT.** For removal and replacement of the overhead console refer to figure 17-10.

17-44. **ADJUSTMENT OF OVERHEAD LIGHT CONSOLE.** The overhead light console may be adjusted to allow the light to illuminate the instrument panel without striking the windshield and causing glare. Adjust the angle of light by turning the rear outboard adjusting screws (See figure 17-10.), until the light beams are properly directed.




Figure 17-10. Overhead Light Console Installation (Sheet 1 of 2)

17-45. MAP LIGHTS. White map lighting and red, non-glare instrument lighting are provided by an adjustable light mounted on the forward part of the left door post. The lights are controlled by a three-position type switch, with red, white and off positions. The map light contains a white bulb for general purpose lighting and a red bulb for adjustable instrument lighting. The intensity of the the red bulb is controlled by the console light rheostat on the instrument panel. When optional post lights are installed, a second, two-color map light is installed on the right door post. With post lights installed, a switch on the instrument panel selects whether console lights or post lights are in use. When using the console lights, the red lamps in the map lights will be inoperative. When using the post lights, the red lamps in the map lights will be operative and will be dimmed with the post lights by the console light rheostat.

As optional equipment, a white, dimmable map light may be installed on the underside of the pilots control wheel. A solid-state dimming circuit has been utilized so that a miniature dimming control may be used. The dimming control extends just below the edge of the control wheel for convenient thumb operation.

17-46. REMOVAL AND REPLACEMENT OF DOOR POST MAP LIGHTS (See figure 17-11.)

- For replacement of defective lamp, slide the hood and lens from the map light assembly and remove the defective lamp. Replace the lamp with an equivalent type.
- For removal of the map light assembly, remove the screws from the front doorpost shield.
- Remove the nut and washer attaching the map light to the shield.
- Remove the ground wire from the map light screw.




Figure 17-10. Overhead Light Console Installation (Sheet 2 of 2)

e. Detach the wires at the quick disconnect fasteners and remove the map light assembly.

17-47. REMOVAL AND REPLACEMENT OF THE CONTROL WHEEL MAP LIGHT. (See figure 17-12.)

- a. Rotate the control wheel 90° to the left to gain access to the under side of the wheel.
- b. Remove four screws at the corners of the etched circuit board assembly.
- c. Detach the wires from the terminal strip along the edge of the circuit board. Note the connection for reference when replacing the board.
- d. To install the control wheel map light, reverse this procedure.

NOTE

It is recommended that the board be replaced as an assembly if the lamps should become defective. If personell familiar with etched circuit board repair work are available, emergency repairs of the map light assembly may be made by soldering

leads to #330 lamps and then soldering the lamps to the board in place of those provided. The lamps should be secured in place with a spot of epoxy cement after soldering.

17-48. POST LIGHTS. As optional equipment, individual post lights are available for not-glare instrument lighting. The post light consists of a cap and clear lamp assembly with a tinted lens. 1966 models have red tinted lens and 1967 & on models have blue tinted lens. The intensity of the post lighting is controlled by the console light rheostat when the pilot selects post lighting with the post light/console light switch on the instrument panel.

17-49. REMOVAL AND REPLACEMENT OF POST LIGHTS. For removal of the post lamp, slide the cap and lens assembly from the base. Slide the lamp from the socket and replace.

17-50. DOME LIGHTS. The dome lights are located on each side of the aft cabin and are controlled by a




Figure 17-11. Map Light Installation, Door Post




Figure 17-12. Control Wheel Map Light Installation

single slide-switch labeled "Utility Lights", located on the left door post. This switch also operates the courtesy lights.

17-51. COMPASS AND RADIO DIAL LIGHTS. The compass and radio dial lights are contained within the individual units. The light intensity is controlled by the radio dial light dimming rheostat mounted on the lower left side of the instrument panel.

17-52. STALL WARNING UNIT. The stall warning unit is mounted on the bottom of the map compartment. The 210 series aircraft have a dual purpose warning unit which contains the horn for the stall warning and a second horn for the gear warning. The stall warning horn emits a high-pitched, steady sound when actuated by the stall warning switch on the wing.

17-53. REMOVAL AND REPLACEMENT OF STALL WARNING UNIT. Figure 17-13 shows installation details of the stall warning unit.

17-54. STALL WARNING SWITCH. The stall warning switch is installed in the leading edge of the left wing and is actuated by airflow over the surface of the wing. The switch will close as a stall condition is approached, actuating the stall warning horn. The horn should sound at approximately five to ten miles per hour above the actual stall speed. Initial installation of the switch should be with the lip of the warning switch approximately one sixteenth of an inch below the center line of the wing skin cutout. Test fly the aircraft to determine if the horn sounds at the desired speed. If the horn sounds too soon, move the unit down slightly; if too late, move the unit up slightly.

17-55. REMOVAL AND REPLACEMENT OF THE STALL WARNING SWITCH. Figure 17-14 shows the installation details of the stall warning switch.

17-56. PITOT AND STALL WARNING HEATER CIRCUITS. Electrical heater units are incorporated in some pitot tubes and stall warning switch units. The heaters offset the possibility of ice formation on the pitot tube and stall warning actuator switch. The heaters are integrally mounted in the pitot tube and stall warning actuator switch. Both heaters are controlled by the pitot heat switch.


17-57. REMOVAL AND REPLACEMENT OF PITOT HEATER. Figure 17-15 shows the installation details of the pitot heater.

17-58. LANDING GEAR INDICATOR LIGHTS. The position of the landing gear on the model 210 series is indicated by two press-to-test lamp assemblies mounted on the right side of the switch panel. The green light is on when all the wheels are down and locked; the red is on when all the wheels are up and locked. If any wheel assumes an intermediate position of neither up and locked nor down and locked, both lights will be dark. The hood of each light is removable for bulb replacement, and has a dimming shutter.

17-59. REMOVAL AND REPLACEMENT OF LANDING GEAR INDICATOR LIGHTS.

a. Remove the hood on either light by unscrewing counter-clockwise. The lamp bulb is in the hood and may be replaced by pulling it out and inserting a new lamp.

MODEL 210 SERIES



MODEL 206 SERIES




Figure 17-13. Stall Warning Units Installation

- b. To remove the lamp socket assembly, remove the nut around the assembly on the front side of the panel.
- c. Tag and unsolder the wires from the socket assembly.
- d. To replace a lamp socket assembly, reverse the above procedure.

17-60. CIGAR LIGHTER. A special circuit breaker

is contained in a small cylinder screwed directly on the back of the cigar lighter socket. The circuit breaker is a bi-metallic type and is resettable. To reset a breaker, make sure that the master switch is off, then insert a small diameter pin (end of a paper clip works) into the hole in the phenolic back plate of the breaker and apply pressure. A small click will be heard when the breaker resets.




Figure 17-14. Stall Warning Switch Installation




Figure 17-15. Pitot Heater Installation

ELECTRICAL LOAD ANALYSIS CHART

FOR ALL 1966 MODELS

ELECTRICAL EQUIPMENT	AMPS. REQD	
	P206 & U206	210 & T210
Battery Contactor	0.8	0.8
Carburetor Air Temperature Indicator	0.03	0.03
Cigarette Lighter	10.0	10.0
Clock	Negligible	
Courtesy Lights and Cabin Lights	3.3	3.3
Cylinder Head Temperature Indicator	0.18	0.18
Flap Motor	15.00	15.00
Flap Position Indicator	0.26	0.26
Fuel Quantity Indicators	0.36	0.36
Fuel Pump - Auxiliary	3.0	3.0
Gear Warning Horn	---	0.25
Heaters, Stall Warning & Pitot	8.6	8.6
H. F. Antenna Reel Motor	14.0	14.0
Instrument Lights:		
Cluster	0.3	0.3
*Console	2.0	2.0
Compass	0.08	0.08
Lamp - Gear Up or Gear Down	---	0.08
Landing Lights	15.6	15.6
Map Light	0.33	0.33
Navigation Light	5.6	5.6
Oil Dilution System	1.0	1.0
*Post Lighted Panel Installation	1.6	1.6
Rotating Beacon	4.8	4.8
Solenoid Valve - Door Opening	---	2.7
†Solenoid Valve - Gear Handle Lock	---	0.6
Stall Warning Horn25	.25
Turn & Bank Indicator	0.18	0.18
Vertical Adjusting Seats	20.0	20.0
Bendix ADF-T12C	0.8	0.8
Cessna ADF 300 (Type R-521)	1.6	1.6
Cessna ADF 500 (Type R-318)	4.3	4.3
Cessna Marker Beacon 300 (Type R-521)	0.17	0.17
Cessna 1 1/2 Nav/Com 300 & 300R (Types RT-514A & RT-514R)	4.5	4.5
Cessna Nav/Com 500 (Type RT-317)	5.2	5.2
Cessna Nav/Omni 500 (Type R-319)	7.0	7.0
Cessna Nav-O-Matic 200 Autopilot	2.0	2.0
Cessna Nav-O-Matic 300 Autopilot	2.0	2.0
Cessna Nav-O-Matic 400 Autopilot	3.0	3.0
Cessna Transceiver 500 (Type RT-302)	6.5	6.5
King KA-10 Isolation Amplifier	0.5	0.5
King KN-60 DME	5.0	5.0
King KX-120 With KI-200 Indicator	6.4	6.4
King KX-150 BE	6.0	6.0
King KX-160E	3.0	3.0
King KY-95E	4.0	4.0
Narco Mark IV Superhomer	4.0	4.0
Narco UGR-1A Glideslope Receiver	2.5	2.5
Pantronics DX10-DA	6.5	6.5

*A switching arrangement prevents the console lights from being operated at the same time the post lights are operated.

†Applicable to the flight running load only.

ELECTRICAL LOAD ANALYSIS CHART

FOR ALL 1967 MODELS

ELECTRICAL EQUIPMENT	AMPS. REQD	
	206 SERIES	210 SERIES
Battery Contactor	0.6	0.6
Cigarette Lighter	10.0	10.0
Clock	Negligible	Negligible
Courtesy Lights and Cabin Lights	3.3	3.3
Cylinder Head Temperature Indicator	0.2	0.2
Flap Motor	15.00	15.00
Flap Position Indicator	0.1	0.1
Flashing Beacon	7.0	7.0
Fuel Quantity Indicators	0.4	0.4
Fuel Pump - Auxiliary	3.0	3.0
Gear Warning Horn		0.25
Heaters, Stall Warning & Pitot	10.00	10.00
H. F. Antenna Reel Motor	14.0	14.0
Instrument Lights:		
Cluster	0.3	0.3
*Console	2.0	2.0
Compass	0.1	0.1
Lamp - Gear Up or Gear Down		0.1
Landing Lights	15.6	15.6
Map Light	0.33	0.33
Navigation Light	5.6	5.6
Oil Dilution System	1.0	1.0
*Post Lighted Panel Installation	2.0	2.0
Solenoid Valve - Door Opening		2.7
Solenoid Valve - Gear Handle Lock		0.6
Stall Warning Horn	0.25	0.25
Turn & Bank Indicator	0.2	0.2
Bendix ADF-T12C	0.8	0.8
Cessna ADF 300 (Type R-521)	1.6	1.6
Cessna ADF 500 (Type R-318)	4.2	4.2
Cessna DME 300 (Type KN-60)	5.0	5.0
Cessna Marker Beacon 300 (Type R-502B)	0.17	0.17
Cessna Nav/Com 300R (Types RT-515R, RT-515R-1 & RT-517R)	5.5	5.5
Cessna Nav/Com 500 (Type RT-317)	5.2	5.2
Cessna Nav/Omni 300 (Type RT-525)	6.0	6.0
Cessna Nav/Omni 500 (Type R-319)	7.0	7.0
Cessna Nav-O-Matic 300 Autopilot	2.0	2.0
Cessna Nav-O-Matic 400 Autopilot	3.0	3.0
Cessna Transceiver 300 (Type RT-524A)	3.2	3.2
Cessna Transceiver 500 (Type RT-302G)	6.5	6.5
Cessna Transponder 800	4.0	4.0
King KA-25 Isolation Amplifier	0.5	0.5
King KX-150BE	4.7	4.7
King KX-160E, AE or AF	2.5	2.5
King KY-95E	4.0	4.0
Narco Mark 12A with VOA-4 or -5 Indicator	4.8	4.8
Pantronics DX10-DA	6.5	6.5

*A switching arrangement prevents the console lights from being operated at the same time the post lights are operated.

ELECTRICAL LOAD ANALYSIS CHART

FOR ALL 1968 MODELS

ELECTRICAL EQUIPMENT	AMPS. REQD	
	206 SERIES	210 SERIES
Battery Contactor	0.6	0.6
Cigarette Lighter	10.0	10.0
Clock	Negligible	Negligible
Courtesy Lights and Cabin Lights	3.3	3.3
Cylinder Head Temperature Indicator	0.2	0.2
Flap Motor	15.0	15.0
Flashing Beacon	7.0	7.0
Fuel Quantity Indicators	0.4	0.4
Fuel Pump - Auxiliary	3.0	3.0
Gear Warning Horn		0.25
Heaters, Stall Warning & Pitot	10.0	10.0
Instrument Lights:		
Cluster	0.3	0.3
*Console	0.3	0.3
Compass	2.0	2.0
Switch Panel	0.7	0.7
Lamp - Gear Up or Gear Down		0.1
Landing Lights	15.6	15.6
Map Light	0.33	0.33
Map Light - Control Wheel Mounted	0.16	0.16
Navigation Lights	5.6	5.6
Oil Dilution System	1.0	1.0
*Post Lighted Panel Installation	2.0	2.0
Solenoid Valve - Door Opening		2.7
Solenoid Valve - Gear Handle Lock		0.6
Stall Warning Horn	0.25	0.25
Turn & Bank Indicator	0.2	0.2
Turn Coordinator	0.8	0.8
 Brittain Wing Leveler	 0.8	 0.8
Cessna 300 ADF (Type R-521)	1.6	1.6
Cessna 300 DME (Type KN-60B)	5.0	5.0
Cessna 300 Marker Beacon (Type R-502B)	0.02	0.02
Cessna 300 Nav/Com (Types RT-517R & RT-540A)	5.5	5.5
Cessna 300 Transceiver (Type RT-524A)	3.2	3.2
Cessna 400 ADF (Type R-318G-2)	4.2	4.2
Cessna 400 Glideslope (Type R-502B)	0.02	0.02
Cessna 400 Nav/Com (Type RT-522A)	2.0	2.0
Cessna 400 Transceiver (Type RT-532A)	1.0	1.0
Cessna 400 Transponder (Type R-506A)	3.0	3.0
Cessna 300 Nav-O-Matic Autopilot	2.0	2.0
Cessna 400 Nav-O-Matic Autopilot	3.0	3.0
King KA-25C Isolation Amplifier	0.5	0.5
King KX-150BE	4.7	4.7
King KX-160E, AE or AF	2.5	2.5
King KY-95E	4.0	4.0
Narco Mark 12A with VOA-8 or -9 Indicator	4.8	4.8
Narco Glideslope UGR-2	0.3	0.3
Pantronics DX10-DA	6.5	6.5
H. F. Antenna Reel Motor	14.0	14.0

*A switching arrangement prevents the console lights from being operated at the same time the post lights are operated.

SECTION 18

STRUCTURAL REPAIR

TABLE OF CONTENTS

	Page		Page
REPAIR CRITERIA	18-1	WING (CANTILEVER)	18-3
EQUIPMENT AND TOOLS	18-1	Wing Skin	18-3
Control Balancing	18-1	Wing Stringers	18-4
Support Stands	18-1	Wing Fuel Spars	18-4
Fuselage Repair Jig	18-1	Wing Ribs	18-4
Wing Jig	18-1	Wing Spars	18-4
WING AND STABILIZER ANGLE-OF- INCIDENCE (EXCEPT CANTILEVER WING) .	18-2	Wing Leading Edge	18-4
WING AND STABILIZER ANGLE-OF- INCIDENCE (CANTILEVER WING)	18-2	Ailerons	18-4
REPAIR MATERIALS	18-2	Wing Flaps	18-4
WING (EXCEPT CANTILEVER)	18-2	ELEVATORS AND RUDDERS	18-4
Wing Skin	18-2	Foam-Filled Trailing Edges and Tabs . .	18-4
Wing Stringers	18-2	FIN AND STABILIZER	18-4
Wing Ribs	18-3	FUSELAGE	18-5
Wing Spars	18-3	Bulkheads	18-5
Wing Leading Edge	18-3	BAFFLES	18-6
Ailerons	18-3	ENGINE COWLING	18-6
Wing Flaps	18-3	REPAIR OF THERMO-FORMED PLASTIC COMPONENTS	18-6
		REPAIR OF GLASS FIBER CONSTRUCTED COMPONENTS	18-6

18-1. REPAIR CRITERIA.

18-2. Although this section outlines repair permissible on structure of the aircraft, the decision of whether to repair or replace a major unit of structure will be influenced by such factors as time and labor available, and by a comparison of labor costs with the price of replacement assemblies. Past experience indicates that replacement, in many cases, is less costly than major repair. Certainly, when the aircraft must be restored to its airworthy condition in a limited length of time, replacement is preferable.

18-3. Restoration of a damaged aircraft to its original design strength, shape and alignment involves careful evaluation of the damage, followed by exacting workmanship in performing the repairs. This section suggests the extent of structural repair practical on the aircraft and supplements Federal Aviation Regulations, Part 43. Consult the factory when in doubt about a repair not specifically mentioned here.

18-4. EQUIPMENT AND TOOLS.

18-5. Equipment and tools for repair of structure may be fabricated locally for all but major repair

jobs. For major repair of wings and fuselage, special jigs, available from the factory, are recommended. These jigs are precision equipment designed to ensure accurate alignment of these airframe components.

18-6. CONTROL BALANCING requires the use of a fixture to determine the static balance moment of the control surface assembly. Plans for, and the use of, such a fixture are shown in figure 18-9.

18-7. SUPPORT STANDS shown in figure 18-1 are used to hold a fuselage or wing when it is removed. The stands may be manufactured locally of any suitable wood.

18-8. FUSELAGE REPAIR JIG. The fuselage jig, which may be obtained from the factory, is a sturdy, versatile fixture used to hold an entire fuselage and to locate the firewall, wing and landing gear attachment points. The jig is ideal for assembling new parts in repair of a badly damaged fuselage.

18-9. WING JIG. The wing jig, which may also be obtained from the factory, serves as a holding fixture during extensive repair of a damaged wing. The jig locates the root rib, leading edge, and tip rib of the wing.

18-10. WING AND STABILIZER ANGLE-OF-INCIDENCE (EXCEPT CANTILEVER WING). Angle-of-incidence and wing twist are listed in the following chart. Stabilizers do not have twist. Wings have a constant angle from the wing root to the strut fitting station. All twist in the panel is between this station and the tip rib. The amount of twist between these points is the difference between the angle-of-incidence at the root and the angle-of-incidence at the tip. See figure 18-2.

WING

Angle-of-incidence, Root	+1°30'
Angle-of-incidence, Tip	-1°30'
Twist (Washout)	3°

STABILIZER

Angle-of-incidence	-3°±15'
------------------------------	---------

18-11. WING AND STABILIZER ANGLE-OF-INCIDENCE (CANTILEVER WING). Angle-of-incidence and wing twist are listed in the following chart. Stabilizers do not have twist. The cantilever wing has a uniform twist from the root rib to the tip rib. The amount of twist between these two ribs is the difference between the angle-of-incidence at the root and the angle-of-incidence at the tip. See figure 18-2.

WING

Angle-of-incidence, Root	+1°30'
Angle-of-incidence, Tip	-1°30'
Twist (Washout)	3°

STABILIZER

Angle-of-incidence	-3°±15'
------------------------------	---------

18-12. REPAIR MATERIALS.

18-13. Thickness of material on which a repair is to be made can easily be determined by measuring with a micrometer. In general, material used in Cessna aircraft covered in this manual is made from 2024 aluminum alloy, heat treated to a -T3, -T4, or -T42 condition. If the type of material cannot be readily determined, 2024-T3 may be used in making repairs, since the strength of -T3 is greater than -T4 or -T42 (-T4 and -T42 may be used interchangeably, but they may not be substituted for -T3). When necessary to form a part with a smaller bend radius than the standard cold bending radius for 2024-T4, use 2024-0 and heat treat to 2024-T42 after forming. The repair material used in making a repair must equal the gage of the material being repaired unless otherwise noted. It is often practical to cut repair pieces from service parts listed in the Parts Catalogs.

A few components (empennage tips, for example) are fabricated from thermo-formed plastic or glass fiber constructed materials.

18-14. WING (EXCEPT CANTILEVER WING).

18-15. The wing assemblies are of the semi-cantilever type employing semi-monocoque type of structure. Basically, the internal structure consists of built-up front and rear spar assemblies, formed sheet metal nose, intermediate, and trailing edge

ribs. Stressed skin, riveted to the rib and spar structures, completes the wing structure.

18-16. ACCESS openings (hand holes with removable cover plates) are located in the underside of the wing between the wing root and tip section. These openings afford access to the aileron bellcranks, flap bellcranks, electrical wiring, strut attaching fittings, aileron control cable pulley and control cable disconnect points.

18-17. WING SKIN.

18-18. NEGLIGIBLE DAMAGE. Any smooth dents in the wing skin that are free from cracks, abrasions and sharp corners, which are not stress wrinkles and do not interfere with any internal structure or mechanism, may be considered as negligible damage. In areas of low stress intensity, cracks, deep scratches or deep, sharp dents, which after trimming or stop drilling can be enclosed by a two-inch circle, can be considered negligible if the damaged area is at least one diameter of the enclosing circle away from all existing rivet lines and material edges. Stop drilling is considered a temporary repair and a permanent repair should be made as soon as practicable.

18-19. REPAIRABLE DAMAGE. Figure 18-3 outlines typical repairs to be employed in patching skin. Before installing a patch, trim the damaged area to form a rectangular pattern, leaving at least a one-half inch radius at each corner, and de-burr. The sides of the hole should lie span-wise or chord-wise. A circular patch may also be used. If the patch is in an area where flush rivets are used, make a flush patch type of repair; if in an area where flush rivets are not used, make an overlapping type of repair. Where optimum appearance and airflow are desired, the flush patch may be used. Careful workmanship will eliminate gaps at butt-joints; however, an epoxy type filler may be used at such joints.

18-20. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If a skin is badly damaged, repair should be made by replacing an entire skin panel, from one structural member to the next. Repair seams should be made to lie along existing structural members and each seam should be made exactly the same in regard to rivet size, spacing, and pattern as the manufactured seams at the edges of the original sheet. If the manufactured seams are different, the stronger should be copied. If the repair ends at a structural member where no seam is used, enough repair panel should be used to allow an extra row of staggered rivets, with sufficient edge margin, to be installed.

18-21. WING STRINGERS.

18-22. NEGLIGIBLE DAMAGE. Refer to paragraph 18-18.

18-23. REPAIRABLE DAMAGE. Figure 18-4 outlines a typical wing stringer repair. Two such repairs may be used to splice a new section of stringer material in position, without the filler material.

18-24. **DAMAGE NECESSITATING REPLACEMENT OF PARTS.** If a stringer is so badly damaged that more than one section must be spliced into it, replace the entire stringer.

18-25. **WING RIBS.**

18-26. **NEGLIGIBLE DAMAGE.** Refer to paragraph 18-18.

18-27. **REPAIRABLE DAMAGE.** Figure 18-5 outlines typical wing rib repairs.

18-28. **DAMAGE NECESSITATING REPLACEMENT OF PARTS.** Leading edge and trailing edge ribs that are extensively damaged should be replaced. However, due to the necessity of unfastening so much skin in order to replace ribs, they should be repaired if practicable. Center ribs, between the front and rear spars, should always be repaired if practicable.

18-29. **WING SPARS.**

18-30. **NEGLIGIBLE DAMAGE.** Due to the stresses which wing spars encounter, very little damage can be considered negligible. All cracks, stress wrinkles, deep scratches, and sharp dents must be repaired. Smooth dents, light scratches, and abrasions may be considered negligible.

18-31. **REPAIRABLE DAMAGE.** Figure 18-6 outlines typical spar repairs. It is often practical to cut repair pieces from spare parts listed in Parts Catalogs. Service Kits are available for certain types of spar repairs.

18-32. **DAMAGE NECESSITATING REPLACEMENT OF PARTS.** Damage so extensive that repair is not feasible requires replacement of a complete wing spar. Also refer to paragraph 18-2.

18-33. **WING LEADING EDGE.**

18-34. **NEGLIGIBLE DAMAGE.** Refer to paragraph 18-18.

18-35. **REPAIRABLE DAMAGE.** A typical leading edge skin repair is shown in figure 18-8. An epoxy type filler may be used to fill gaps at butt joints. To facilitate repair, extra access holes may be installed in the locations noted in figure 18-7. If the damage would require a repair which could not be made between adjacent ribs, refer to the following paragraph.

18-36. **DAMAGE NECESSITATING REPLACEMENT OF PARTS.** For extensive damage, complete leading edge skin panels should be replaced. To facilitate replacement, extra access holes may be installed in the locations noted in figure 18-7.

18-37. **AILERONS.**

18-38. **NEGLIGIBLE DAMAGE.** Refer to paragraph 18-18.

18-39. **REPAIRABLE DAMAGE.** The leading edge skin repair shown in figure 18-8 should be used to repair damage to aileron leading edge skins. The flush-type skin patches shown in figure 18-3 should be used to repair damage to the remaining skins. Filler material must match existing corrugations. Doubler material may be flat. If damage would require a repair which could not be made between adjacent ribs, see the following paragraph.

18-40. **DAMAGE NECESSITATING REPLACEMENT OF PARTS.** If the damage would require a repair which could not be made between adjacent ribs, complete skin panels should be replaced. Ribs and spars may be repaired, but replacement is generally preferable. Where extensive damage has occurred, replacement of the aileron assembly is recommended. After repair and/or repainting, balance in accordance with figure 18-9.

18-41. **WING FLAPS.**

18-42. **NEGLIGIBLE DAMAGE.** Refer to paragraph 18-18.

18-43. **REPAIRABLE DAMAGE.** Flap repairs should be similar to aileron repairs discussed in paragraph 18-39. A flap leading edge repair is shown in figure 18-8.

18-44. **DAMAGE NECESSITATING REPLACEMENT OF PARTS.** Flap repairs which require replacement of parts should be similar to aileron repairs discussed in paragraph 18-40.

18-45. **WING (CANTILEVER).**

18-46. Beginning with the Models 210G and T210G, a cantilever type wing is used. It is sheet metal constructed, with a single main spar, two fuel spars, formed ribs and stringers. The front fuel spar also serves as an auxiliary spar and is the forward wing attaching point. An inboard section forward of the main spar is sealed to form an integral fuel tank area. The main spar consists of milled spar caps and attaching fittings joined by a web section. The aft fuel spar is a formed channel. The front fuel spar is a built-up assembly consisting of a formed channel, doubler, attach strap and support angle. Stressed skin, riveted to the ribs, spars and stringers, completes the wing structure.

18-47. **ACCESS** openings (hand holes with removable cover plates) are located in the underside of the wing between the wing root and tip section. These openings afford access to the flap and aileron bellcranks, flap drive pulleys, flap actuator in left wing, flap and aileron control cable disconnect points, fuel transmitter, air scoop connectors and electrical wiring.

18-48. **WING SKIN.**

18-49. **NEGLIGIBLE DAMAGE.** Refer to paragraph 18-18.

18-50. REPAIRABLE DAMAGE. Refer to paragraph 18-19.

18-51. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Paragraph 18-20 also applies to the cantilever wing except that repairs must not be made to upper or lower wing skin inboard of wing station 40.00 without factory approval. However, an entire skin may be replaced without factory approval. Refer to Section 1 for wing station locations.

18-52. WING STRINGERS. Paragraph 18-21 also applies to the cantilever wing.

18-53. WING FUEL SPARS.

18-54. NEGLIGIBLE DAMAGE. Refer to paragraph 18-18.

18-55. REPAIRABLE DAMAGE. The type of repairs outlined in figure 18-5 for rib repairs also applies to fuel spars. For area where repairs are restricted, refer to the following paragraph.

18-56. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Repairs must not be made to the front fuel spar inboard of wing station 54.00 without factory approval. However, an entire fuel spar may be replaced without factory approval. Refer to Section 1 for wing station locations.

18-57. WING RIBS.

18-58. NEGLIGIBLE DAMAGE. Refer to paragraph 18-18.

18-59. REPAIRABLE DAMAGE. Figure 18-5 outlines typical wing rib repairs.

18-60. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Any wing rib damaged extensively should be replaced. However, due to the necessity of disassembling so much of the wing in order to replace a rib, especially in the fuel tank area which involves sealing, ribs should be repaired if practicable.

18-61. WING SPARS.

18-62. NEGLIGIBLE DAMAGE. Refer to paragraph 18-30.

18-63. REPAIRABLE DAMAGE. Figure 18-6 (sheet 5) outlines a typical main spar repair. For area where repairs are restricted, refer to the following paragraph.

18-64. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Repairs must not be made to the main spar inboard of wing station 155.00 without factory approval. However, an entire main spar may be replaced without factory approval. Refer to Section 1 for wing station locations.

18-65. WING LEADING EDGE.

18-66. NEGLIGIBLE DAMAGE. Refer to paragraph 18-18.

18-67. REPAIRABLE DAMAGE. A typical leading edge skin repair is shown in figure 18-8. Extra access holes, outlined in figure 18-7, must not be installed on the cantilever wing without factory approval. For area where repairs are restricted, refer to the following paragraph.

18-68. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Repairs must not be made to the leading edge skin inboard of wing station 40.00 without factory approval. However, an entire leading edge skin may be replaced without factory approval. Refer to Section 1 for wing station locations.

18-69. AILERONS. Paragraph 18-37 also applies to ailerons on the cantilever wing.

18-70. WING FLAPS. Paragraph 18-41 also applies to flaps on the cantilever wing.

18-71. ELEVATORS AND RUDDERS.

18-72. NEGLIGIBLE DAMAGE. Refer to paragraph 18-18. The exception to negligible damage on the elevator surfaces is the front spar, where a crack appearing in the web at the hinge fittings or in the tip rib which supports the overhanging balance weight is not considered negligible. Cracks in the overhanging tip rib, in the area at the front spar intersection with the web of the rib, also cannot be considered negligible.

18-73. REPAIRABLE DAMAGE. Skin patches shown in figure 18-3 may be used to repair skin damage. If the damaged area would require a repair which could not be made between adjacent ribs, see the following paragraph.

18-74. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If the damaged area would require a repair which could not be made between adjacent ribs, complete skin panels should be replaced. Ribs and spars may be repaired, but replacement is generally preferable. Where extensive damage has occurred, replacement of the entire assembly is recommended. After repair and/or repainting, balance in accordance with figure 18-9.

18-75. FOAM-FILLED ELEVATOR TRAILING EDGES AND ELEVATOR TRIM TABS. Skin replacement and/or rebonding the filler material may be accomplished on the foam-filled elevator trailing edges and elevator trim tabs, used on 210 Series aircraft. Rebonding may be accomplished by use of an epoxy resin adhesive. Any damage to the filler materials, such as crushing or broken pieces, should be repaired by replacing the trailing edge or trim tab as a bonded unit. Standard repairs may be accomplished on the elevator.

18-76. FIN AND STABILIZER.

18-77. NEGLIGIBLE DAMAGE. Refer to paragraph 18-18.

18-78. REPAIRABLE DAMAGE. Skin patches shown in figure 18-3 may be used to repair skin damage. Access to the dorsal area of the fin may be gained by removing the horizontal closing rib at the bottom of the fin. Access to the internal fin structure is best gained by removing skin attaching rivets on one side of the rear spar and ribs, and springing back the skin. Access to the stabilizer structure may be gained by removing skin attaching rivets on one side of the rear spar and ribs, and springing back the skin. If the damaged area would require a repair which could not be made between adjacent ribs, or a repair would be located in an area with compound curves, see the following paragraph.

18-79. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If the damaged area would require a repair which could not be made between adjacent ribs or the repair would be located in an area with compound curves, complete skin panels should be replaced. Ribs and spars may be repaired, but replacement is generally preferable. Where damage is extensive, replacement of the entire assembly is recommended.

18-80. FUSELAGE.

CAUTION

Repairs must not be made to the main wing spar carry-thru section of cantilever wing airplanes without factory approval.

18-81. The fuselage is of semi-monocoque construction consisting of formed bulkheads, longitudinal stringers, reinforcing channels and skin platings.

18-82. NEGLIGIBLE DAMAGE. Refer to paragraph 18-18. Mild corrosion appearing upon alclad surfaces does not necessarily indicate incipient failure of the base metal. However, corrosion of all types should be carefully considered, and approved remedial action taken. Small cans appear in the skin structure of all metal airplanes. It is strongly recommended, however, that wrinkles which appear to have originated from other sources, or which do not follow the general appearance of the remainder of the skin panels, be thoroughly investigated. Except in the landing gear bulkhead area, wrinkles occurring over stringers which disappear when the rivet pattern is removed may be considered negligible. However, the stringer rivet holes may not align perfectly with the skin holes because of a permanent "set" in the stringer. If this is apparent, replacement of the stringer will usually restore the original strength characteristics of the area.

NOTE

Wrinkles occurring in the skin of the main landing gear bulkhead areas should not be considered negligible. The skin panel should be opened sufficiently to permit a thorough examination of the lower portion of the landing gear bulkhead and its tie-in structure.

Wrinkles occurring on open areas which disappear when the rivets at the edge of the sheet are removed, or a wrinkle which is hand removable, may often be repaired by the addition of a 1/2 x 1/2 x .060 inch 2024-T4 extruded angle, riveted over the wrinkle and extended to within 1/16 to 1/8 inch of the nearest structural members. Rivet pattern should be identical to the existing manufactured seam at the edge of the sheet.

18-83. REPAIRABLE DAMAGE. Fuselage skin repairs may be accomplished in the same manner as wing skin repairs outlined in paragraph 18-19. Stringers, formed skin flanges, bulkhead channels, and similar parts may be repaired as shown in figure 18-4.

18-84. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Fuselage skin major repairs may be accomplished in the same manner as wing skin repairs outlined in paragraph 18-20. Damaged fittings should be replaced. Seat rails serve as structural parts of the fuselage and should be replaced if damaged.

18-85. BULKHEADS.

18-86. LANDING GEAR BULKHEADS. Since these bulkheads are highly stressed members irregularly formed to provide clearance for control lines, actuators, fuel lines, etc., patch type repairs will be, for the most part, impractical. Minor damage consisting of small nicks or scratches may be repaired by dressing out the damaged area, or by replacement of rivets. Any other such damage should be repaired by replacing the landing gear support assembly as an aligned unit.

18-87. REPAIR AFTER HARD LANDING. Buckled skin or floorboards and loose or sheared rivets in the area of the main gear support will give evidence of damage to the structure from an extremely hard landing. When such evidence is present, the entire support structure should be carefully examined and all support forgings should be checked for cracks, using a dye penetrant and proper magnification. Bulkheads in the area of possible damage should be checked for alignment and a straightedge should be used to determine deformation of the bulkhead webs. Damaged support structure, buckled floorboards and skins, and damaged or questionable forgings should be replaced. Landing gear components should be replaced and rigged properly.

18-88. REPLACEMENT OF HI-SHEAR RIVETS with close tolerance bolts or other commercial fasteners of equivalent strength properties is permissible. Holes should not be elongated and the Hi-shear substitute should be a smooth push fit. Forgings may be spot-faced the least amount necessary for proper seating of the fasteners.

18-89. NOSE GEAR WHEEL WELL AND FIREWALL. The nose gear wheel well is made of stainless steel, as is the firewall bulkhead. Refer to paragraph 18-18 for negligible damage, and paragraph 18-19 for repairable damage. Stainless steel patches should be used in nose wheel well and firewall repairs. Any repairs in these areas will require resealing with 700P, or equivalent compound.

18-90. LANDING GEAR DOORS. Landing gear doors may be repaired by any method consistent with good sheet metal practice. However, any repairs to these doors should be made only after careful consideration of the door function and clearance is made. Close tolerances are required here for correct landing gear operation.

18-91. BAFFLES.

18-92. CONSIDERATIONS. Baffles ordinarily should be replaced if damaged or cracked. However, small plate reinforcements riveted to the baffle will often prove satisfactory both to the strength and cylinder cooling requirements of the unit.

18-93. ENGINE COWLING.

18-94. REPAIR OF COWLING SKINS. If extensively damaged, complete sections of cowlings should be replaced. Standard flush-type skin patches, however, may be used if repair parts are formed to fit. Small cracks may be stop-drilled and dents straightened, if they are reinforced on the inner side with a doubler of the same material.

18-95. REPAIR OF REINFORCEMENT ANGLES. Cowl reinforcement angles, if damaged, should be replaced. Due to their small size they are easier to replace than to repair.

18-96. REPAIR OF THERMO-FORMED PLASTIC COMPONENTS.

18-97. Repair of puncture or holes in thermo-formed plastics can be made by trimming out the damaged area, removing any paint in the area, and installing an overlapping, beveled, or flush patch of identical material. Doublers may be installed behind the patch where additional strength is desired. MEK, or any commercially available solvent that will soften and dissolve the plastic, may be used as the bonding agent. Dissolving some of the plastic shavings in the solvent will furnish additional working time. Moderate pressure is recommended for best results. Curing time will vary with the agent used, but repairs should not be strained until fully cured. Cracks can be repaired by saturating the crack itself with the solvent, then filling with an epoxy filler or a paste made of the plastic shavings and the solvent. Again, the crack may be reinforced with a doubler on the back side for additional strength. After the repair has been made, the area may be sanded smooth and painted. Parts that are extensively damaged should be replaced instead of repaired.

18-98. REPAIR OF GLASS FIBER CONSTRUCTED COMPONENTS.

18-99. Glass fiber constructed components on the aircraft may be repaired as stipulated in instructions furnished in SK182-12. Observe the resin manufacturer's recommendations concerning mixing and application of the resin. Epoxy resins are preferable for making repairs, since epoxy compounds are usually more stable and predictable than polyester and, in addition, give better adhesion.






Figure 18-1. Wing and Fuselage Support Stands



A	B	C	WING STATION
2.00	1.00	29.50	39.00
.79	1.00	20.00	207.00

(REFER TO PARAGRAPH 18-10)


MEASURING WING TWIST

If damage has occurred to a wing, it is advisable to check the twist. The following method can be used with a minimum of equipment, which includes a straightedge (32" minimum length of angle, or equivalent), three modified bolts for a specific wing, and a protractor head with level.

1. Check chart for applicable dimension for bolt length (A or B).
2. Grind bolt shanks to a rounded point as illustrated, checking length periodically.
3. Tape two bolts to straightedge according to dimension C.
4. Locate inboard wing station to be checked and make a pencil mark approximately one-half inch aft of leading edge skin.
5. Holding straightedge parallel to wing station, (staying as clear as possible from "cans"), place bolt on pencil mark and set protractor head against lower edge of straightedge.
6. Set bubble in level to center and lock protractor to hold this reading.
7. Omitting step 6, repeat procedure for outboard wing station, using dimensions specified in chart. Check to see that protractor bubble is still centered.
8. Proper twist is present in wing if protractor readings are the same (parallel). Forward or aft bolt may be lowered from wing .10 inch maximum to attain parallelism.

Figure 18-2. Checking Wing Twist (Sheet 1 of 2)

CANTILEVER WING



A	B	C	WING STATION
2.00	2.00	40.50	26.50
.75	2.00	25.50	205.00


(REFER TO PARAGRAPH 18-11)

MEASURING WING TWIST


If damage has occurred to a wing, it is advisable to check the twist. The following method can be used with a minimum of equipment, which includes a straightedge (42" minimum length of angle, or equivalent), three modified bolts for a specific wing, and a protractor head with level.

1. Check chart for applicable dimension for bolt length (A or B).
2. Grind bolt shanks to a rounded point as illustrated, checking length periodically.
3. Tape two bolts to straightedge according to dimension C.
4. Locate inboard wing station to be checked and make a pencil mark approximately one-half inch aft of first lateral row of rivets aft of wing leading edge. Extend pencil line through landing light as required.
5. Holding straightedge parallel to wing station, (staying as clear as possible from "cans"), place bolt on pencil mark and set protractor head against lower edge of straightedge.
6. Set bubble in level to center and lock protractor to hold this reading.
7. Omitting step 6, repeat procedure for outboard wing station, using dimensions specified in chart. Check to see that protractor bubble is still centered.
8. Proper twist is present in wing if protractor readings are the same (parallel). Forward or aft bolt may be lowered from wing .10 inch maximum to attain parallelism.


Figure 18-2. Checking Wing Twist (Sheet 2 of 2)



PATCH REPAIR FOR 3 INCH DIAMETER HOLE



PATCH REPAIR FOR 2 INCH DIAMETER HOLE



PATCH REPAIR FOR 1 INCH DIAMETER HOLE









Figure 18-3. Skin Repair (Sheet 1 of 6)



SECTION THRU ASSEMBLED PATCH

A-A




-  ORIGINAL PARTS
-  REPAIR PARTS
-  REPAIR PARTS IN CROSS SECTION

OVERLAPPING REC-TANGULAR PATCH


RIVET TABLE	
SKIN GAGE	RIVET DIA.
.020	1/8
.025	1/8
.032	1/8
.040	1/8
.051	5/32




Figure 18-3. Skin Repair (Sheet 2 of 6)



NOTE

For optimum appearance and airflow, use flush rivets, dimpled skin and patch, and counter-sunk doubler.



-  ORIGINAL PARTS
-  REPAIR PARTS
-  REPAIR PARTS IN CROSS SECTION

FLUSH RECTANGULAR PATCH
(CIRCULAR FLUSH PATCH IS
SIMILAR)

RIVET TABLE	
SKIN GAGE	RIVET DIA.
.020	1/8
.025	1/8
.032	1/8
.040	1/8
.051	5/32

Figure 18-3. Skin Repair (Sheet 3 of 6)




Figure 18-3. Skin Repair (Sheet 4 of 6)




Figure 18-3. Skin Repair (Sheet 5 of 6)







Figure 18-4. Stringer and Channel Repair (Sheet 1 of 4)







Figure 18-4. Stringer and Channel Repair (Sheet 2 of 4)

-  ORIGINAL PARTS
-  REPAIR PARTS
-  REPAIR PARTS IN CROSS SECTION




Figure 18-4. Stringer and Channel Repair (Sheet 3 of 4)




Figure 18-4. Stringer and Channel Repair (Sheet 4 of 4)




Figure 18-5. Rib Repair (Sheet 1 of 2)




Figure 18-5. Rib Repair (Sheet 2 of 2)




Figure 18-6. Wing Spar Repair (Sheet 1 of 5)




Figure 18-6. Wing Spar Repair (Sheet 2 of 5)




Figure 18-6. Wing Spar Repair (Sheet 3 of 5)






Figure 18-6. Wing Spar Repair (Sheet 4 of 5)






NOTE

This repair applies from station 155 outboard. Factory approval is required inboard of station 155.

APPLICABLE TO CANTILEVER WING



TWO ROWS OF RIVETS IN FILLER (MINIMUM). MAKE RIVET SPACING IDENTICAL TO REPAIR SPACING FOR LARGER FILLERS.

-  ORIGINAL PARTS
-  REPAIR PARTS
-  REPAIR PARTS IN CROSS SECTION





Figure 18-6. Wing Spar Repair (Sheet 5 of 5)

CAUTION

Do not install on cantilever wing without factory approval.

**PRECAUTIONS:**

1. Add the minimum number of access holes necessary.
2. Any circular or rectangular access hole which is used with approved optional equipment installations may be added in lieu of the access hole illustrated.
3. Use landing light installations instead of adding access holes where possible. Do not add access holes at outboard end of wing; remove wing tip instead.
4. Do not add an access hole in the same bay where one is already located.
5. Locate new access holes near the center of a bay (spanwise).
6. Locate new access holes forward of the front spar as close to the front spar as practicable.
7. Locate new access holes aft of the front spar between the first and second stringers aft of the spar. When installing the doubler, rotate it so the two straight edges are closest to the stringers.
8. Alternate bays, with new access holes staggered forward and aft of the front spar, are preferable.
9. A maximum of five new access holes in each wing is permissible; if more are required, contact the Cessna Service Department.
10. When a complete leading edge skin is being replaced, the wing should be supported in such a manner that wing alignment is maintained.

- a. Establish exact location for inspection cover and inscribe centerlines.
- b. Determine position of doubler on wing skin and center over centerlines. Mark the ten rivet hole locations and drill to size shown.
- c. Cut out access hole using dimension shown.
- d. Flex doubler and insert through access hole, and rivet in place.
- e. Position cover and secure using screws as shown.

Figure 18-7. Access Hole Installation

1. Dimple leading edge skin and filler material; countersink the doubler.
2. Use MS20426AD4 rivets to install doubler.
3. Use MS20426AD4 rivets to install filler, except where bucking is impossible. Use CR162-4 Cherry (blind) rivets where regular rivets cannot be bucked.
4. Contour must be maintained; after repair has been completed, use epoxy filler as necessary and sand smooth before painting.
5. On cantilever wing, vertical size is limited by ability to install doubler clear of front fuel spar or stringers outboard of spar. On other wings, flaps and ailerons, vertical size is limited by ability to install doubler clear of front spar.
6. Lateral size is limited to seven inches across trimmed out area.
7. Number of repairs is limited to one in each bay. On cantilever wings, consider a bay in the area forward of front fuel spar as if ribs extended to leading edge.



GENERAL NOTES

1. Balance control surfaces in a draft-free area.
2. Place hinge bolts through control surface hinges, and position on knife edge balancing mandrels.
3. Make sure all control surfaces are in their final flight configuration: painted (if applicable), trim tabs installed, all foreign matter removed from inside of control surface, elevator trim tab push-pull rod installed, and all tips installed.
4. Place balancing mandrels on a table or other suitable flat surface.
5. Adjust trailing edge support to fit control surface being balanced while center of balancing beam is directly over hinge line. Remove balancing beam and balance the beam itself by adding washers or nuts as required at end opposite the trailing edge support.
6. When positioning balancing beam on control surface, avoid rivets to provide a smooth surface for the beam, and keep the beam 90° to the hinge line of the control surface.
7. Paint is a considerable weight factor. In order to keep balance weight to a minimum, it is recommended that existing paint be removed before adding paint to a control surface. Increase in balance weight will also be limited by the amount of space available and clearance with adjacent parts. Good workmanship and standard repair practices should not result in unreasonable balance weight.
8. The approximate amount of weight needed may be determined by taping loose weight at the balance weight area.
9. Lighten balance weight by drilling off part of weight.
10. Make balance weight heavier by fusing bar stock solder to weight after removal from control surface. The ailerons should have balance weight increased by ordering additional weight and gang channel, listed in applicable Parts Catalogs, and installing next to existing inboard weight the minimum length necessary for correct balance, except that a length which contains at least two attaching screws must be used. If necessary, lighten new weight and/or existing weights for correct balance.

BALANCING BEAM





Figure 18-9. Control Surface Balancing (Sheet 1 of 4,

BALANCING MANDREL



RUDDERS AND ELEVATORS






Figure 18-9. Control Surface Balancing (Sheet 2 of 4)

AILERONS



DETAIL A-A



Balance aileron inverted, with trailing edge at point opposite cut-out for push-pull rod .85" below hinge line horizontal plane.
(EXCEPT CANTILEVER WING AILERON)

Balance aileron inverted, with trailing edge at point opposite cut-out for middle hinge .66" below hinge line horizontal plane.
(CANTILEVER WING AILERON)

Refer to chart for correct range of underbalance.

Figure 18-9. Control Surface Balancing (Sheet 3 of 4)

MODEL	AILERONS Balance Range	RUDDER Balance Range	RIGHT ELEVATOR Balance Range	LEFT ELEVATOR Balance Range
1966 210 SERIES	0.0 to +3.0 in-lbs (Underbalance)	0.0 to +1.5 in-lbs (Underbalance)	0.0 to +5.4 in-lbs (Underbalance)	0.0 to +5.4 in-lbs (Underbalance)
1967 210 SERIES	+7.00 to +11.16 in-lbs (Underbalance)	-0.97 to -1.87 in-lbs (Overbalance)	0.0 to +12.1 in-lbs (Underbalance)	0.0 to +11.9 in-lbs (Underbalance)
1968 210 SERIES	Same as above	Same as above	Same as above	Same as above
1966 206 SERIES	0.0 to +3.0 in-lbs (Underbalance)	0.0 to +1.5 in-lbs (Underbalance)	0.0 to +18.35 in-lbs (Underbalance)	0.0 to +18.70 in-lbs (Underbalance)
1967 206 SERIES	Same as above.	-0.97 to -1.87 in-lbs (Overbalance)	Same as above.	Same as above.
1968 206 SERIES	Same as above	Same as above	0.0 to +12.1 in-lbs (Underbalance)	0.0 to +11.9 in-lbs (Underbalance)

NOTE

The "Balance Range" columns list the moment tolerances within which the control surface must balance. These tolerances must never be exceeded in the final flight configuration.

Figure 18-9. Control Surface Balancing (Sheet 4 of 4)

SECTION 19

PAINTING

NOTE

This section is divided into two parts. Part 1 covers the procedures used, at the factory, for over-all painting of the aircraft. Part 2 covers the procedures for touch-up painting on the aircraft. Before attempting any painting on the aircraft, determine the type and color of the paint that is on the aircraft. The color and type of paint, on the aircraft when it left the factory, is stamped in code of the Finish and Trim Plate located on the left front door post. Applying this code to the applicable Parts Catalog the type and color can be determined. In all cases determine the type of paint that is on the aircraft before adding touch-paint as some types of paint are not compatible.

PART 1

OVER-ALL PAINTING

19-1. PAINTING.

19-2. Painting an aircraft requires little special equipment. The average shop will have the compressor, spray gun, and clean place to work required for a good paint job. Ordinarily, painting involves four basic steps. They are:

1. Stripping - Removing of paint to the bare metal.
2. Cleaning - Washing down the aircraft thoroughly to remove all oil, grease, and dirt.
3. Priming - Applying one priming coat before painting with acrylic paint.
4. Painting - Applying coat of final paint, then adding decorative strips and identification markings.

19-3. MATERAILS. The following list of materials is for use in both Part 1 and Part 2. These materials can be obtained from the Cessna Service Parts Center.

- a. Thinner T-6094A
- b. Thinner T-8402A
- c. Thinner T-7945
- d. Thinner T-9275
- e. Thinner T-7987
- f. Thinner T-9186
- g. Solvent No. 2
- h. Class A Solvent Proof Paper
- i. Wash Primer EX2016G
- j. Activator EX2016A
- k. Primer Surfacer EX8229B
- l. Sealer EX8229A
- m. Acrylic Paint PX114A-Series
- n. Filler White Streak
- o. Filler Green Stuff No. 74
- p. Wiping Cloth
- q. Polishing Compound No. 606
- r. Wax and Grease Remover DX440
- s. Klad Polish
- t. Imperial Cleaner
- u. Tape, Permacel No. 781
- v. Thinner T-1411

19-4. CLEANING.

- a. Inspect aircraft for any surface defects, such as small dents or unsatisfactory previous repairs. Refer to Part 2 for repairs.
- b. Wipe excess sealer from around windows and skin laps.
- c. Mask windows and any other areas not to be primed, with Class A Solvent Proof Paper and Permacel tape no. 781.
- d. Use Klad Polish to remove stains, oxides, etc., from bare aluminum.
- e. Use T-6095A for final cleaning of the aircraft prior to applying primer. Saturate a contaminant-free, lint free cloth in T-6094A thinner and wring out so no thinner is dripping from the cloth. Wipe the aircraft surface using the thinner saturated cloth and immediately following wipe surface with a dry, lint free cloth.

NOTE

It is important that the thinner is wiped before it evaporates. Change cloths often, so that aircraft surface is thoroughly cleaned and the surface is not contaminated from the use of a dirty cloth. Always use clean thinner in the final cleaning. Be sure that thinner is disposed of when contaminated.

19-5. PRIMER PREPARATION.

NOTE

Mix EX2016G primer only in quantities required for use within six hours and then only in a stainless steel container. Mixed primer shall be discarded if not used within six hours.

- a. Mix EX2016G primer and EX2016A activator in a 1:1 ratio and stir thoroughly.

NOTE

The mixed primer shall stand a minimum of 30 minutes prior to being applied to the aircraft.

b. Check all tapes to make sure that they are adhered to paper and masked surface. Cover flap tracks, nose gear strut tube, wheels, and shimmy dampener rod ends.

c. Blow all contaminants from surface of aircraft with a jet of dry compressed air.

19-6. PRIMER APPLICATION.

NOTE

Air pressure at gun shall be between 40 to 50 psig. At all times, keep gun six to eight inches from the work and perpendicular to surface being primed. DO NOT PAINT WITH ARCING MOTION. Keep paint room at 75 to 85 degrees Fahrenheit.

a. Apply EX2016G primer in one well broken up wet, even coat to 0.0003 to 0.0005 inch dry film thickness.

b. Allow primer to dry until a firm pressure with the finger nail will not penetrate the coating.

NOTE

Primer shall be top coated within four hours of application.

19-7. PAINT PREPARATION (ACRYLIC WHITE).

a. Thoroughly stir and mix in original container to make sure all pigments are in solution.

b. Mix required amount of acrylic white with T-8204A thinner. Recommended thinning ratio is 100 parts paint to 100-120 parts thinner by volume. This variation in thinning may be required to facilitate application during hot weather and is permitted.

c. Scuff sand the primer only where runs or large dirt particles are in evidence. (Over-all sanding operation will be performed after application of the first coat of paint.)

19-8. PAINT APPLICATION (ACRYLIC WHITE).

NOTE

Air pressure at the gun should be 40 to 50 psig and 12±1 psig at the pot during application. At all times, keep gun six to eight inches from the work and perpendicular to surfaces being painted. DO NOT PAINT WITH ARCING MOTION.

a. Apply one light wet even coat of paint to the aircraft.

b. Let dry until not tacky and lightly sand with No. 400 paper and wipe with a tack cloth.

c. Apply second coat even and wet. The minimum thickness necessary to provide good hiding is recommended. Heavy coats, applied in an attempt to improve gloss, should definitely not be applied or the acrylic may craze.

d. Burn down with T-8402A where necessary as soon after application of paint as practicable. Burn down should be held to a minimum.

e. Allow the finish to flash off for 10 minutes and move airplane to force dry oven and dry for 1-1/2 hours at 120 to 140 degrees Fahrenheit.

f. Remove airplane from oven and allow airplane to cool to room temperature.

19-9. PREPARATION FOR STRIPES. (ACRYLIC COLORS.)

a. Mask stripe area using Permacel No. 781 tape and class A solvent proof paper. Double tape all skin laps to prevent blow by.

NOTE

If an unpainted airplane is to receive stripes only, clean and prime as outlined in paragraphs 19-4 through 19-6.

b. Scuff sand stripe area with No. 400 or No. 600 sandpaper. The use of power sanders should be held to a minimum with care exercised to preclude sanding through the white base coat.

c. Wipe sanded surface with a tack cloth and check all tapes to be sure they are adhered to surface.

19-10. PAINT PREPARATION (ACRYLIC COLOR).

a. Thoroughly stir and mix in original container to make sure all pigments are in solution.

b. Mix required amount of stripe color with T-7945 thinner. Recommended thinning ratio is 100 parts paint to 100-125 parts thinner by volume. This will allow for the slight thinner variation required with different colors.

19-11. APPLICATION OF STRIPES.

NOTE

Air pressure at the gun shall be 40 to 50 psig. At all times keep gun six to eight inches from the work and perpendicular to the surface being painted. DO NOT PAINT WITH ARCING MOTION.

a. Keep first coat even and light. The first coat should be somewhat lighter than the second to avoid sags, but should be wet enough to achieve a smooth surface.

b. Apply second coat in wet passes to achieve full coverage. Heavy coats applied in an attempt to improve gloss, should definitely not be applied or the acrylic may craze.

c. Inspect for overspray and apply burn down agent, T-7945 thinner, to any area showing overspray. Care in application will minimize overspray.

NOTE

Burn down of non-metallic colors shall be accomplished with T-7945 thinner. Burn down of metallic colors shall be accomplished with T-7987 thinner.

d. The masking tape and paper shall not be removed until the paint has dried a minimum of 15 minutes. Care shall be used in removal of masking to prevent damage to the finish.

19-12. PROCEDURE FOR PAINTING WITH CESSNA LACQUER - 27H SERIES.

19-13. PREPARATION. Thoroughly clean all surfaces and beyond area to be painted, with T-6094 thinner. Extreme care should be taken to remove all letters, grease, bugs, etc. Carefully mask off stripe areas to be painted and see that all tapes are firmly adhered to metal to prevent ragged edges. Class "A" wrapping paper and thinner-proof tape should be used to cover windows and windshield. This will prevent damage from solvent and thinner vapors. Newspapers will not provide adequate protection.

19-14. PRIMER - MIXTURE AND APPLICATION.

NOTE

Mix EX-2016 primer only in quantities required for use within six hours and then only in stainless steel bucket.

a. Mix EX-2016 primer and T-6070 activator in a 1:1 ratio and stir thoroughly.

NOTE

The primer shall stand after mixing a minimum of 30 minutes prior to being applied to the airplane.

b. Apply EX-2016 in a well broken up, wet, even coat.

c. Mix one part EX-2414 yellow lacquer primer with two parts T-6094 thinner.

d. Apply one well broken up, wet, even coat of the EX-2414 primer over the EX-2016 primer.

19-15. PREPARATION OF LACQUER COLORS - 27H SERIES.

a. Thoroughly stir and mix in original container to make sure all pigments are in solution.

b. Thin required amount of lacquer color with T-6094 thinner in a 1:1 ratio. Mix thoroughly and strain into cups before using.

19-16. APPLICATION OF LACQUER COLORS - 27H SERIES.

NOTE

Air pressure at gun should not exceed 40 psig. At all times, keep gun six to eight inches from the work and perpendicular to surface being painted. DO NOT PAINT WITH ARCING MOTION. Keep paint room at 75 to 85 degrees Fahrenheit.

a. Apply first coat even and wet; second and third coats in the same manner.

b. Check carefully before second and third coats for defects and correct before final coats.

c. Using T-6094 thinner as a "burn-down" agent, "burn-down" to give smooth, even surfaces free from overspray.

19-17. PROCEDURE FOR PAINTING WITH CESSNA ENAMEL VINYL - 82 SERIES.

NOTE

82A, 82B, and 82 are interchangeable, although 82A and 82B have better flow characteristics.

19-18. PREPARATION. Thoroughly clean all surfaces and seams with T-6094 thinner. Extreme care should be taken to assure that no oil seepage occurs from seams, splices, or rivet heads. All bugs and foreign matter should be removed from the airplane before painting. Thoroughly inspect after cleaning to be sure all surfaces are ready for priming. Class "A" wrapping paper and thinner-proof masking tape should be used to cover windows and windshield. This will prevent damage from solvent and thinner vapors. Newspapers will not provide adequate protection.

19-19. PRIMER - MIXTURE AND APPLICATION.

NOTE

Mix EX-2016 primer only in quantities required for use within six hours and then only in stainless steel bucket.

a. Mix EX-2016 primer and T-6070 activator in a 1:1 ratio and stir thoroughly.

NOTE

The primer shall stand after mixing a minimum of 30 minutes prior to being applied to the airplane.

b. Apply EX-2016 primer in a well broken up, wet, even coat. If primer has to be sanded, dry scuff sand with #600 paper and reprime. Sanding breaks film, result in poor adhesion.

NOTE

On all leading edge surfaces, apply a cross coat, wet and even, of EX-2016 primer.

c. Clean equipment immediately after use and under no consideration use EX-2016 primer that has been mixed longer than six hours.

19-20. PREPARATION OF ENAMEL VINYL COLORS - 82 SERIES.

a. Thoroughly mix and stir in original container to make sure all pigments are in solution.

b. Thin required amount of vinyl color with T-1866 vinyl thinner in a 1:1 ratio. Mix thoroughly and strain into either a cup or pressure pot.

19-21. APPLICATION OF VINYL COLORS - 82 SERIES.

NOTE

If vinyl is to be applied from a pressure pot, do so under the following conditions: Pressure of 10 psig. Regulate gun pressure at gun with test gauge to 25 psig, using gun with FX needle and fluid tip, with fan set wide open and yield two turns open. If cups are used, set fan at 30 psig with EX needle and fluid tips, fan set one turn open and yield wide open.

- a. Apply first coat even and wet; second and third coats in same manner.
- b. Check second and third coats, mask off and lightly wet sand with #400 paper the painted surfaces of previous color that is in area to be painted.

NOTE

On all leading edges apply a fourth coat. After finishing each color coat, "burn-down" with T-1411 thinner as the "burn-down" agent. Remove all masking from painted surfaces after each color application. If you have a Heat Room, turn up the heat and dry paint at temperatures of 125 to 145 degrees Fahrenheit, for at least three hours. Heat will give a very good reflow on vinyl paint.

19-22. PROCEDURE FOR APPLICATION OF HI-VISIBILITY PAINT.

19-23. MATERIALS REQUIRED are:

- 3 qts Switzer Orange Day-Glo
- 2 qts Toluene Thinner
- 2 qts Switzer Filteray, Type B Top Coat
- 2 qts White Base Coat
- 2 qts Thinner

19-24. MIXING PROCEDURE: All paint shall be thinned to spraying consistency as follows:

- a. Hi-Visibility paint shall be thinned with two parts Toluene thinner to three parts paint.
- b. Clear top coat shall be thinned with one part Xylene thinner to one part paint.
- c. White base coat shall be thinned with one part thinner to one part paint. This formula applies to either lacquer or vinyl.

NOTE

Either Toluene or Xylene may be used as the thinner for Hi-Visibility paint and the top coat. Toluene is recommended for the Hi-Visibility paint and Xylene for the top coat.

19-25. SURFACE PREPARATION. Hi-visibility paint must be applied over a good white undercoat. The preferred white undercoat is white lacquer. If, however, the airplane is already painted with vinyl base paint, the white undercoat may consist of white vinyl. A white primer may also be used as the undercoat.

19-26. APPLICATION.

- a. Apply three well broken up, even coats of white undercoat. Allow sufficient drying time. Wipe with tack rag.
- b. Apply one heavy wet coat of Hi-Visibility paint. This coat should consist of three wet passes over the entire area. Allow two or three minutes drying time between passes. Dry coat should be 2.5 to 3.5 mils thick. Allow one to two hours drying time.
- c. Wipe surface with tack rag to remove overspray.
- d. Apply two wet coats of clear top coat, consisting of two passes per coat. Dry coat should be 1.5 to 2.5 mils thick.

NOTE

Hi-Visibility paint is not offered at the factory.

PART 2

TOUCH-UP PAINTING

19-27. TOUCH-UP-GENERAL.

19-28. Where necessary to touch-up or refinish an area, the edge of the finish adjacent to the defect shall be feathered by sanding with No. 320 paper and followed with No. 400 paper. Avoid, if possible, sanding through the primer. If the primer is penetrated over an area 1/2 inch or larger, repriming is necessary. Avoid spraying metal primer on the adjacent paint as much as possible.

- a. When touching up acrylic, vinyl, or lacquer, use EX2016G primer mixed one part primer to one part EX2016A activator. Stir thoroughly and allow to set 30 minutes before spraying.
- b. When touching up epoxy, use Dupont 818-012

primer mixed two parts primer to one part 8539 activator. Stir thoroughly and allow to set 30 minutes before spraying.

CAUTION

Before attempting touch-up, determine the type of paint that is on the aircraft. Some types of paints are not compatible. Acrylic paint does not adhere to vinyl paint satisfactorily. Therefore, when acrylic paint is to be applied over vinyl paint, a barrier coat of lacquer paint is required between the vinyl and acrylic paint.

19-29. TOUCH-UP-ACRYLIC.

a. Fill the feathered areas by spraying on several light coats of EX8229A Surfacer. Only sufficient Surfacer should be used to assure filling. Allow 5 to 8 minutes drying time between coats of Surfacer used. Sand the Surfacer smooth with No. 400 paper. Apply a light coat of EX8229A Sealer over the sanded Surfacer. After drying for 5 to 8 minutes, spray the Acrylic top coat.

NOTE

Dry overspray may be removed by burndown with T-8402A (White), T-7945 (non-metallic color), T-7987 (metallic color), or by compounding with Dupont No. 808 Rubbing Compound.

19-30. TOUCH-UP-VINYL.

a. If priming with EX2016G primer is required, a light coat of MIL-P-8585 Zinc Chromate primer thinned four parts Toluol to one part primer shall be applied over the EX2016G primer.

b. Fill the feathered areas by spraying on several light coats of ACME 538 Dark Grey Surfacer. Allow 5 to 8 minutes drying time for each coat of Surfacer. Sand the area smooth with No. 400 paper and apply the top coat of vinyl.

NOTE

Dry overspray may be removed by burndown with T-1411, or by compounding with Dupont 808 Rubbing Compound.

19-31. TOUCH-UP-LACQUER.

a. When priming with EX2016G is required, a light coat of EX2414 primer shall be sprayed over the EX2016G primer. Mix one part EX2414 Yellow lacquer primer with two parts T-6094 thinner. Fill the

feathered areas by spraying on several light coats of ACME 538 Dark Grey Surfacer. Allow 5 to 8 minutes dry time for each coat of Surfacer applied. Sand the area smooth with No. 400 paper and apply top coat of lacquer.

NOTE

Dry overspray may be removed by burndown with T-6094 thinner, or by compounding with Dupont No. 808 Rubbing Compound.

19-32. TOUCH-UP-EPOXY.

a. If bare metal is not exposed, or after the metal is primed, spray a light coat of Dupont Epoxy Primer over the rework area. Mix two parts 825-8500 Primer with one part VG5943 activator. If a thinner is required, use T-3871 thinner. Stir primer and allow to set 45 minutes before spraying.

NOTE

Top coat must be applied over primer within 72 hours of priming.

b. When the primer is DRY, apply top coat, Cessna Part Number CES1054-826. The Dupont Chemical Resistance Enamel white epoxy base coat shall be mixed one part enamel to one part VG8339 activator. If thinning is required, use T-3871 thinner.

c. The Enmar 5400 series color epoxy is used to paint the stripes. All colors, except the Valor Red, shall be mixed one part by volume paint to one part by volume T-5400 Adduct Thinner. Mix the Valor Red in the same ratios, except use T-6487 Adduct Activator. If a thinner is required, use T-5402 Thinner. Stir thoroughly and allow the mixed paint to set for 30 minutes prior to spraying.

SECTION 20

ELECTRICAL WIRING DIAGRAMS

Table of Contents

Model Number	Drawing Number
210 SERIES	1270405
206 SERIES	1270625

NOTE

The page numbering method in this Section differs from that of the rest of the book. However, each model series drawing number begins with an index of diagrams contained therein, which will facilitate locating any particular diagram.

Cessna.

WIRING DIAGRAM

MODEL 210

DWG. NO. 1270405

TABLE OF CONTENTS

PAGE NO.	TITLE	DATE ISSUED	REV
1.0	<u>Title Page</u>		
2.0	<u>Table of Contents</u>	3-15-68	
2.1	<u>Table of Contents</u>	3-15-68	
2.2	<u>Table of Contents</u>	3-15-68	
3.0	<u>Notes</u>	5-1-64	B
4.0	<u>D.C. Power</u>	10-18-62	
4.1	Battery & External Power Systems	3-3-65	B-Inac.
4.1.1	Battery & External Power Systems	1-31-67	D
4.2	Generator System	5-1-64	Inac.
4.3	Alternator System, 52 AMP	3-3-65	B-Inac.
4.4	Alternator System, 60 AMP	7-8-66	B-Inac.
4.5	Split Bus Bar	7-18-67	A
4.6	Wiring Diagram - Alternator System, 60 AMP	7-11-67	A
5.0	<u>Ignition</u>	10-18-62	
5.1	<u>Ignition System</u>	11-16-65	B
6.0	<u>Engine Control</u>	10-18-62	
6.1	<u>Starter System</u>	2-9-66	B
7.0	<u>Fuel & Oil</u>	10-18-62	
7.1	Fuel Pump System	4-1-63	Inac.
7.1.1	Fuel Pump System	10-4-66	C
7.2	Oil Dilution System (Opt.)	5-28-65	C
8.0	<u>Engine Instruments</u>		
8.1	Cylinder Head Temperature	8-20-64	B
8.2	Fuel Quantity	2-25-66	A-Inac.
8.2.1	Fuel Quantity Indicator	7-18-66	A
8.3	Hourmeter (Opt.)	9-29-66	NC
9.0	<u>Flight Instruments</u>	11-5-62	
9.1	Turn & Bank & Gyro Horizon Indicator	7-18-66	B
9.2	W.D. Brittain Wing Leveler (Opt.)	6-7-67	NC
9.3	Wiring Diagram - Turn Coordinator	9-25-67	NC

Cessna.

**TITLE: WIRING DIAGRAM---
MODEL 210**

DRAWING NO.

1270405

DATE: 3-15-68

PAGE: 2.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

TABLE OF CONTENTS

PAGE NO.	TITLE	DATE ISSUED	REV
10.0	<u>Other Instruments</u>	10-18-62	
10.1	Clock	5-28-65	C
10.2	Wiring Diagram - Flap Position Indicator	2-25-66	NC-Inac
10.2.1	Wiring Diagram - Flap Position Indicator	9-14-67	A-Inac.
11.0	<u>Lighting</u>	11-5-62	
11.1	Dome & Courtesy Lights	2-25-66	B-Inac.
11.1.1	Dome & Courtesy Lights	7-18-66	A
11.2	Instruments Lights	7-11-67	E
11.3	Landing Lights	2-25-66	C-Inac.
11.3.1	Landing Lights	2-25-66	NC
11.4	Navigation Lights	2-25-66	B-Inac.
11.4.1	Navigation Lights	1-16-68	A
11.5	Rotating Beacon (Opt.)	1-29-66	A-Inac.
11.5.1	Flashing Beacon Light (Opt.)	1-29-66	NC
11.6	Map Light (Opt.)	9-3-64	A-Inac.
11.6.1	Map Light	7-11-67	B
11.7	Post Lighting & Back Lighting (Opt.)	7-26-66	B-Inac.
11.7.1	Post Lighting (Opt.)	11-27-67	B
11.8	Nav-O-Matic 300 Post Light (Opt.)	11-17-64	NC-Inac
11.9	Back Lighting	7-11-67	A
11.10	Map Light, Control Wheel (12 Volt)	9-25-67	NC
12.0	<u>Landing Gear</u>	11-5-62	
12.1	Landing Gear Door Control System	7-18-66	B
13.0	<u>Heating, Ventilating, & De-Icing Section</u>	11-5-62	
13.1	Cigar Lighter	7-18-66	C
13.2	Heated Pitot Tube & Heated Stall Warning System	2-25-66	B-Inac.
13.2.1	Heated Pitot Tube & Heated Stall Warning System (Opt.)	10-4-66	A
14.0	<u>Control Surface</u>	11-5-62	
14.1	Wing Flaps Position Indicator	9-10-64	A-Inac.
14.2	Wing Flaps - Electric, & Flap Position Indicator	10-26-65	C-Inac.
14.3	Wiring Diagram - Wing Flaps - Electric	2-25-66	A-Inac.
14.3.1	Wiring Diagram - Wing Flaps - Electric	9-14-67	A-Inac.
14.5	Wiring Diagram - Wing Flaps	9-14-67	NC
14.6	Electric Elevator Trim (Opt.)	1-2-68	B

Cessna.

TITLE: WIRING DIAGRAM---
MODEL 210

DRAWING NO.

1270405

DATE: 3-15-68

PAGE: 2.1

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

TABLE OF CONTENTS

PAGE NO.	TITLE	DATE ISSUED	REV
15.0	<u>Warning & Emergency</u>	11-5-62	
15.1	<u>Stall Warning System (Non-Heated)</u>	9-10-64	A-Inad.
15.1.1	Stall Warning System (Non-Heated)	2-25-66	A-Inad.
15.1.2	Stall Warning System (Non-Heated)	2-25-66	NC
15.2	<u>Gear Warning System</u>	7-18-66	B-Inad.
15.2.1	Gear Warning System	10-4-66	D
16.0	<u>Miscellaneous Section</u>	9-27-63	
16.1	Vertically Adjusting Seat (Opt.)	9-10-64	A



TITLE: WIRING DIAGRAM---
MODEL 210

DRAWING NO.

1270405

DATE: 3-15-68

PAGE: 2.2

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

NOTES

1. WIRE CODE DESIGNATIONS PER CES 1100.
2. WIRE CODE APPLICATION AND WIRE LENGTH TOLERANCES PER CES 1015.
- (A) 3. "S" SUFFIX ON WIRE GAUGE IN WIRE TABLE DENOTES SHIELDED WIRE.
"DS" Suffix on wire gauge in wire table denotes a double-shielded wire per S-1462.
4. NON-SHIELDED WIRES TO BE PER S-1460 white. Wires 10-gauge and larger to be Type II construction.
- (B) 5. SHIELDED WIRES TO BE PER S-1461 white, unless designated otherwise by note on the field of the wiring diagram.
6. Part numbers shown in the "equipment table" of the various pages are for reference only and do not constitute a material requirement unless specifically noted on the individual page. Refer to the various equipment installation drawings for verification of part numbers.
7. Equipment part numbers shown on the various pages that are for reference only, (see Note 6,) will not be changed unless it affects wire terminals and fabrication.
8. Vendor codes per S-1400. Vendor codes are shown in parentheses.
9. Wires noted herein as "(opt)" are optional to the standard airplane.
10. All wires not specified as "(opt)" are to be installed as standard equipment. The airplane assembly will specify the additional equipment required for deluxe versions.
11. When "(opt)" is used in the title block of a diagram, all wires shown therein are optional except where noted as "(std)".

Cessna.

DRAWING NO.

DRAWN	WJR	TITLE: WIRING DIAGRAM--- MODEL 210
DATE	4-23-64	

1270405

APP'D	HRS 2-13 Hmc	REV: B
-------	--------------	--------

PAGE: 3.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

FORM NO. 80-160

D. C. POWER SECTION

Cessna.

DRAWING NO.

1270405

DRAWN RIDDER TITLE: WIRING DIAGRAM---
DATE 9-10-62 MODEL 210


APP'D RRS HMC

REV:

PAGE: 4.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

CHG LET	REVISION	BY DATE	CHK APPD
A	ADD 5-550B KLIPVOLT SUPPRESSOR S-1360-50 WAS 5-1232-50 12-10-61-1 WAS 12-10-61-1 12-13505-2 WAS 0712605-1 SER 21058511 & ON	GLW 12-30-61	RRS JH
B	ADDED LIMITING SERIALS TO FIELD; REMOVED 12-10-61-1 BUS BAR FROM E/T; ADD WIRE LENGTHS TO W/T; 0669502-0104 WAS 12-13505-2 SER 21058511 & ON	WJR 6/16/62	RRS JH



EFFECTIVE THRU SER 21058511 & ON

ITEM NO	PART NO.	DESCRIPTION	INSTALLED ON
10	CA-2	CKT BKR (MTCC)	
9	5-550B	KLIPVOLT SUPPRESSOR (BATA)	
8	0750027-1	START SOLENOID	
7	AN2552-3A	RECEPTACLE	
6			
5	5-1360-50	CKT BKR	
4	0669502-0104	INST CLUSTER KIT	
3	5-1159-1-1	SWITCH-MASTER	
2	0712605-2	CONTACTOR BAT	
1	0712605-1	BATTERY	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
F-DA2	8	55	5-1367-1-10	5-1367-1-14		
F-DA1	8	42	5-1367-1-10	5-1367-1-14		
F-PC1	2	55	5-1367-1-14	5-1367-1-14	1270403 (OPT)	
F-PB5	1A	6	5-1367-1-6	5-1367-1-8		
F-PA11	1B	141	5-1367-1-6	5-1367-1-6		
F-PA10	2	21	5-1367-1-14	5-1367-1-12		
F-PA9	2	21	5-1367-1-12	5-1367-1-13		
F-PB5	1B	3	5-1367-1-6	5-1367-1-8		
F-PA1	2	16	5-1367-1-12	5-1367-1-13		


WIRE TABLE

DRAWN: R. DORR GROUP: 10-15-61 CHECK: 10-15-61 PROJ: 10-15-61	NAME: R. DORR DATE: 10-15-61 TITLE: WIRING DIAGRAM — BATTERY & EXTERNAL POWER SYSTEMS	Cessna 1270403 REV: B PAGE: 1
--	---	--

NOTES:

- 1 S-1367-2-6 TERMINAL ON SHIELDS.
- 2 S-1367-2-12 TERMINAL ON SHIELDS.
- 3 PART OF 1250400 ENGINE INSTL.


CHG	REVISION	BY	CHK
LET		DATE	APPD



*Inactive SER 21058511 & ON
W. J. R. 3-26-62
T.M. HMC*

WIRE	GA	MATERIAL	LG	TERMINALS	SERIALS
F-PB7	8			5-1367-4-10 5-1367-4-10 1200418 (OPT)	
F-PB6	8			5-1367-4-12 5-1367-4-10 200418 (OPT)	
F-PB4	185			5-1367-1-6 5-1367-1-10	
F-PB3	185			5-1367-1-6 5-1367-1-12	
F-PB2	8			5-1367-4-12 5-1367-4-10	
F-PB1	8			5-1367-4-8 5-1367-4-10	

WIRE TABLE			
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS			
NAME	DATE	TITLE	
DRAWN RIDDER	7-10-62	WIRING DIAGRAM —	
GROUP	1/1/62	GENERATOR	
CHECK	1/1/62	SYSTEM	
PROJ	1/1/62		
SUPERSEDED BY 1270403			
PAGE 4.3	SUPERSEDES	MODEL 210	REV 4.2




WHEN RADIO NOISE FILTER (OPT) IS REQD, REPLACE F-PB2 AS SHOWN

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
7	145329	NOISE FILTER (SPR)	
6	F-PB5	WIRE	
5	3	GENERATOR	
4	0413205-11	REGULATOR	
3	S-1159-1-1	SWITCH-MASTER	
2	S-1360-50	CIRCUIT BREAKER	
1	1270401-1	BUS BAR	

EQUIPMENT TABLE

(SR4455)

CHG LET	REVISION	BY	CHK
A	BY REV: CHANGED WIRE CODE D-PB WAS D-OP (SR4455)	DATE 5.7.69	APPRO
B	BY REV: C5 FF-10A-368A WAS C4 FF-10A-362A, 1250209-1 WAS 0770033-2 DWG INACTIVE (SR4661)	DATE 5.7.69	APPRO



STANDARD

OPTIONAL
(USED WITH ADF INSTL)

NOTES:

1. TERMINALS C3XB-14462A & B-14463 ARE (FOR) PART NUMBERS.
2. "D" PREFIX USED ON THIS DRAWING INSTEAD OF "F" BECAUSE WIRES ARE SAME AS THOSE USED IN MODEL 182. THIS DIAGRAM IS SCHEMATICALLY IDENTICAL TO 0770610 PAGE 4.4 AND IS FOR REF ONLY.
3. 8 GAUGE SHIELDED WIRE MATERIAL PER S-1534.
4. OBSERVE POLARITY SYMBOL ON DIODE ASSY WHEN INSTALLING ON SWITCH TERMINALS OR DIODE WILL FAIL WHEN SYSTEM IS ENERGIZED

9	1250209-1	FILTER ASSY
8	C5-FF-10A-368A	PLUG ASSY (FOR)
7	145329	NOISE FILTER SPR
6	0770719-1	DIODE ASSY
5	S-1159-1-1	SWITCH - MASTER
4	075C216-1	REGULATOR ASSY
3	S-136C-50	CIRCUIT BREAKER
2	075C217-1	ALTERNATOR ASSY
1	0770033-2	FILTER

EQUIPMENT TABLE

JUMPER 18	6	S-1367-1-6	S-1367-1-2	1250206
D-PB 6 BS	39	S-1367-2-10	S-1367-4-B	(OPT)
D-PB 15 BS	22	S-1367-3-8	S-1367-4-B	(OPT)
D-PB 14 10	22	S-1367-1-10	S-1367-3-8	
D-PB 13 18S	24	S-1367-1-4	S-1367-3-8	
D-PB 12 18	20	S-1367-1-6	S-1367-1-6	
D-PB 11 BS	56	S-1367-1-6	S-1367-4-B	

WIRE TABLE

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

NAME	DATE	WIRING DIAGRAM - ALTERNATOR SYSTEM, 52 AMP	Cessna
DRAWN	1/1/69		
CHECKED	1/1/69		
PROJ	1/1/69		
WIRE	1/1/69		
1270405	1270405	210	B 4.3

PAGE 4.4

PAGE 4.2

210



B

4.3

INACTIVE
SER 21058716 & ON
1-6-65 LRB
1-6-65 HFW
1-6-65 JPS

SER 21058716 & ON

CHG LET	REVISION	BY DATE	CHK APPD
A	FH-PB20 WAS DFH-PB20; FH-PB22 WAS DFH-PB22; FH-PB24 WAS DFH-PB24; FH-PB25 WAS DFH-PB25; S-1629-1 WAS 145329; IN 41796 WAS 42281-2; IN 0770038-2 WAS 0770038-1 ADDED T210 TO MODEL BLOCK; ALL (OPT) TO FH-PB24 & FH-PB25 SER T210-000101, SER 21058716 & ON	WJR 15-65	ALA N/A
B	ADDED CG11001-0101, DETAIL 'A' SER T210-0169 & ON, SER 21058716 & ON	978 12-65	N/A



NOTES:

1. D PREFIX IS USED ON THESE WIRES INSTEAD OF "F" BECAUSE WIRES ARE THE SAME AS THOSE USED IN MODEL 182. THIS DRAWING IS SCHEMATICALLY IDENTICAL TO 0770610 PAGE 4.5.
2. 8 GAUGE SHIELDED WIRE MATERIAL PER S-1534-8-9.
3. OBSERVE POLARITY SYMBOL ON DIODE ASSY WHEN INSTALLING ON SWITCH TERMINALS OR DIODE WILL FAIL WHEN SYSTEM IS ENERGIZED.
4. AMP TERMINAL 41796 (ARP).

ITEM NO.	PART NO.	DESCRIPTION	INSTALLED ON
9	CG11001-0101	REGULATOR	
8	1250211-1	PLUG ASSY	
7	S-1629-1	NOISE FILTER	
6	0770719-1	DIODE ASSY	
5	S-1159-1-1	SWITCH-MASTER	
4	0750216-1	REGULATOR ASSY	
3	S-1596-60	CIRCUIT BREAKER	
2	CG11501-0101	ALTERNATOR ASSY	
1	0770038-2	FILTER	

EQUIPMENT TABLE

																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					</
--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	----

WIRE TABLE

NAME	DATE	TITLE
DRAWN: BREEAD	12/8/64	WIRING DIAGRAM—
GROUP: 12145		ALTERNATOR
CHECK: 12145		SYSTEM, 60 AMP
PROJ: 12145		
REV: 12145		

Cessna.


1270405

SUPPLEMENT	PG	REV	MODEL	REV	PAGE
1270405	PG 4.6	1250405	4.3	210 & T210	REV: B PAGE: 4.4

FORM NO 00-1014

SER 21058819 & ON
SER T210-0198 & ON

CHG LET	REVISION	BY DATE	CHK APPRO
A	BY REV: 0713854-2 WAS 0713854-1 F-1072 WIKI WAS 1, WIKI 20 AMP BREAKER WAS 10 AMP BKR SER 21058819 & ON, SER T210-0198 & ON	GLW 5-6-66	JAK HLM



WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
F-PA21	18			51493-1 51367-1-8	
F-PA20	18			51493-1 51493-1	
F-PA19	14			51493-2 51367-2-6	
F-PA22	14			51493-2 51367-2-6	

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

DRAWN	NAME	DATE	TITLE
J. W. DILL		1/1/66	WIRING DIAGRAM—
GROUP			SPLIT BUS BAR
CHECK			
PROJ			

Cessna.

1270405


SUPERSEDED BY:	SUPERSEDES:	MODEL: 210 & T210	REV: A	PAGE: 4.5
----------------	-------------	-------------------	--------	-----------

ITEM NO.	PART NO.	DESCRIPTION	INSTALLED ON
4	1570043-1	DIODE ASSY	
3	51668-1	RELAY - POWER	
2	0713854-2	BUS BAR - PRIMARY	
1	0713854-1	BUS BAR - ELECT	

EQUIPMENT TABLE

(SR 5200)

CHG	REVISION	BY	CHK
LET		DATE	APP
A	ADDED DETAIL ADF-PB30 D-PB31, CA-2 (ITEM 9) (OBS) DFM-PB21 (SR 5160) (SR 5161) (ON)	Y.B.S. 4/8/67	V.H.C. 4/8/67



INACTIVE (SR 5160) (SR 5161) (ON)

DETAIL A
(EFFECTIVE TO (SR 5160) (SR 5161) (ON))

NOTES:

1. AMP TERMINAL 42281-2 ON CONDUCTOR.
2. AMP TERMINAL 2-3239-1-2 ON SHIELD & GROUNDING WIRE.
3. 8 GAUGE SHIELDED WIRE MATERIAL PER S-1534-8-9.
4. OBSERVE POLARITY SYMBOL ON DIODE WHEN INSTALLING ON SWITCH TERMINALS OR DIODE WILL FAIL WHEN SYSTEM IS ENERGIZED.
5. "D" PREFIX IS USED ON THESE WIRES INSTEAD OF "F". THESE WIRES ARE SAME AS THOSE USED IN 182. THIS DWG IS SCHEMATICALLY IDENTICAL TO 0770610 Pg. 4.7.

PART NO.	DESCRIPTION	INSTALLED ON
9	CA-2	CKT BKR (80602)
8	C6A8-10A730A	HOUSING (ECW5)
7	S-1629-1	NOISE FILTER
6	0770719-1	DIODE ASSY
5	S-1159-1-1	SWITCH-MASTER
4	S-1896-60	CIRCUIT BREAKER
3	0770038-2	FILTER
2	C811001-0101	REGULATOR
1	C811501-0101	ALTERNATOR ASSY

D-PB31				S-1367-1-6	S-1367-1-6		(SR 5160) (SR 5161) (ON)
DFH-PB30				S-1367-1-6	S-1367-1-6		(SR 5160) (SR 5161) (ON)
D-PB29	18			S-1367-1-12			
D-PB28	18S			S-1367-1-12			
D-PB27	18S			S-1367-1-12			
D-PB26	18S			S-1367-1-12			
DH-PB25	8S			S-1367-1-10	S-1367-1-10		
DH-PB24	8S			S-1367-1-10	S-1367-1-10		
DFH-PB23	10			S-1367-3-10	S-1367-3-10		
DH-PB22	18S			S-1367-1-6	S-1367-1-6		
DFH-PB21	18S			S-1367-1-6	S-1367-1-6		
DH-PB20	8S			S-1367-1-10	S-1367-1-10		

WIRE TABLE

GROUP	NAME	DATE	TITLE
DRAWN	ALC	5-3-66	WIRING DIAGRAM—
CHECK	YAKSHAW	6-30-66	ALTERNATOR
PROJ	W.B.	7-7-66	SYSTEM,
			60 AMP
SUPERSEDED BY	1270405	P.G.	MODEL
			2101T210
REV.	A	PAGE	4-6

Cessna.

1270405

1084 NO 50-1016

IGNITION SECTION

Cessna.

DRAWING NO.

1270405


DRAWN *RIDDER* TITLE: WIRING DIAGRAM---
DATE *9-10-62* MODEL 210

APP'D *R.R.S. jlm*

REV:

PAGE: 5.0


CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.



NOTES:

1. SHORTING BAR BETWEEN "R" AND UNMARKED TERMINAL ADJACENT TO IT IS NOT USED FOR THIS CIRCUIT.
2. TERMINATE SHIELDS ON F-JA5 & F-JAT WIRES AT THE SWITCH WITH S-1367-2-6 TERMINALS & CONNECT TO "GND" TERMINAL ON SWITCH.
3. S-1367-1-10 TERMINAL ON HOT LEAD, S-1367-3-10 ON SHIELD.

CHG LET	REVISION	BY	CHK
A	REROUTE F-JA9 TO COIL TERMINAL; S-1360-10 WAS S-1232-10; REMOVED 1270429-1 BUS BAR, F-JA3 & F-JA9 FROM E/T; ADDED WIRE LENGTHS TO W/T	WJR	RES
B	ON WIRES F-JA5 & F-JAT 18-5 WAS 18-05	GLW	RES



DIAGRAMS SHOW NOT ACTUAL SWITCH BUT CIRCUIT CONTINUITY AT EACH POSITION.
 O EXTERNALLY ACCESSIBLE TERMINAL.

PART NO.	DESCRIPTION	INSTALLED ON
8	S-1360-10 CIRCUIT BREAKER	
7		
6		
5		
4	0750027-1 START. SOLENOID	
3	SLICK #662 RIGHT MAGNETO	
2	SLICK #662 LEFT MAGNETO	
1	0713129-1 SWITCH, MAG	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
F-JA7	18-5	65	S-1367-1-6	2	
F-JA5	18-5	65	S-1367-1-6	2	
F-JA4	18	9	S-1367-1-6	S-1367-1-6	

NAME	DATE	TITLE
RIDDER	9-11-62	WIRING DIAGRAM — IGNITION SYSTEM
GROUP	10-12-62	
CHECK	10-5-62	
PROJ	10-12-62	

FORM NO. 80-101	1270405	REV: B	PAGE: 6.1
-----------------	---------	--------	-----------

ENGINE CONTROL SECTION

Cessna.

DRAWING NO.


DRAWN	RIDDER	TITLE: WIRING DIAGRAM--- MODEL 210	1270405
DATE	9-11-62		
APP'D	RES Jm ^c	REV:	PAGE: Change 1 6.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

NOTES:

1 PART OF 1250400 ENGINE INSTALLATION.

REV	REVISION	BY	DATE
A	INST WAS INSTRUMENT LIGHTS REMOVED 1270429-1 BUS BAR FROM E/T. S-1360-10 WAS S-1362-10 REMOVED F-PA10 FROM E/T; ADDED WIRE LENGTHS TO W/T	WJR	7/75
B	ADD F-JA10 (1870043-1 F-PA12) WAS F-PA10 (REF) (SR+886/ SR+887)	JWHL	1/6/66
C	BY REV: ADD S-1673-1, DETAIL A & SR & S-1991-1, DETAIL B & SR ED & RR 10470 (SR6222)	DLB	1/6/66



DETAIL 13
SER 21058716
THRU SER(SR6222)

DETAIL A
THRU SER 21058715

QTY	PART NO	DESCRIPTION	INSTALLED ON
8	S-1991-1	CONTACTOR	
7	1870043-1	DIODE ASSY	
6	S-1360-10	CIRCUIT BREAKER	
5	0713129-1	SWITCH	
4	1	STARTER	
3	0750027-1	START SOLENOID	
2	S-1673-1	CONTACTOR	
1	0712603-2	CONTACTOR BAT.	

EQUIPMENT TABLE

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-JA10	18		S-1493-1	S-1367-1-6	SER2058894200-0984 ON
F-PA12	2		S-1367-7-4	S-1367-7-4	
F-JA1	18		S-1367-1-6	S-1367-1-6	
F-JA3	18		S-1367-1-6	S-1367-1-6	

WIRE TABLE

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-JA10	18		S-1493-1	S-1367-1-6	SER2058894200-0984 ON
F-PA12	2		S-1367-7-4	S-1367-7-4	
F-JA1	18		S-1367-1-6	S-1367-1-6	
F-JA3	18		S-1367-1-6	S-1367-1-6	

WIRING DIAGRAM —
STARTER SYSTEM

Cessna.

1270405

SUPPLEMENTED BY	SUPPLEMENTED	MODEL	REV	PAGE
		210	C	6.1

FUEL AND OIL SECTION

Cessna.

DRAWING NO.

1270405

DRAWN

RIDDER

TITLE: WIRING DIAGRAM---

DATE

9-11-62

MODEL 210

APP'D

KRS HMC

REV:


PAGE:

7.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

NOTES:
 1 DENOTES PART OF 1216012 FUEL PUMP.

CHG LET	REVISION	BY DATE	CHK APPD



Inactive
 SERIAL 21058221; ON
 3-25-63
for inspec
HMC

ITEM NO	PART NO.	DESCRIPTION	INSTALLED ON
8	MS 3106-105-16	PLUG	
7	1270429-1	BUS BAR	
6	S-1232-10	CIRCUIT BREAKER	
5	S-1160-1-1	SWITCH	
4	A76	VALVE (HFP)	
3	1216012-1	FUEL PUMP	
2	300192A1	CAPACITOR	
1	AN3436-2-6	TERMINAL BLOCK	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
F-QE2	18			S-1367-1-6	SOLDER
F-QE1	18			S-1367-1-6	SOLDER
F-QD4	18			S-1367-1-6	S-1367-1-6
F-QD3	18			S-1367-1-6	S-1367-1-6
F-QD1	18			S-1367-1-6	S-1367-1-6

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS

NAME	DATE	TITLE
RIDDER	9-12-62	WIRING DIAGRAM - FUEL PUMP SYSTEM
GROUP	10-10-62	
CHECK	10-10-62	
PROJ	10-10-62	



DWG NO. 1270405

SUPERSEDED BY 1270405 PAGE 7.1

SUPersedes MODEL 210 REV PAGE 7.1

(SR 4038-9)

CHG LET	REVISION	BY	CHK
A	S-1160-1-2 WAS S-1160-1-1; INST WAS INST LIGHTS; REMOVED 1270405-1 BUS BAR & 1270405-JA3 FROM EIT; ADDED WIRE LENGTHS TO W/T	WJR	RES
B	ADD DETAIL A. USM5-B WAS USMW76-B. ADD ITEM 10. C292501-0101 SWITCH WAS 0713129-1 (SR4886)(SR4887)	GLW	YAK
C	DELETE DETAIL A. DELETE WIRES F-QD15 F-QD16 & F-QD14. USM5-B WAS E33-10K. REMOVED SERIALS FROM F-QD7, F-QD9, F-QD10 (SR4886)(SR4887)-9	GLW	YAK



ITEM NO	PART NO.	DESCRIPTION	INSTALLED ON
11			
10			
9	4140-00-1	FUEL PUMP (DUKA)	
8	C292501-0101	SWITCH, MAG	
7			
6	AN3436-2-6	TERMINAL BLOCK	
5	MOR-20-2	RESISTOR (TRTA)	
4	USM5-B	SWITCH, FUEL PUMP (UMX)	
3	USM5-B	SWITCH, T-SWY (UMX)	
2	S-1160-1-2	SWITCH	
1	S-1360-1-0	CIRCUIT BREAKER	

EQUIPMENT TABLE

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-QD3	18		100	S-1367-1-6	S-1367-1-6
F-QD13	18		6	S-1367-1-6	SOLDER
F-QD2	18		5	S-1367-1-6	SOLDER
F-QD11	18		8	S-1367-1-6	S-1367-1-8
F-QD10	18		120	S-1367-1-6	SOLDER
F-QD9	18		120	S-1367-1-6	SOLDER
F-QD8	18		100	S-1367-1-6	S-1370-1
F-QD7	18		100	SOLDER	S-1367-1-6

WIRE TABLE


CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

DRAWN	NAME	DATE	TITLE
G WOOD		1-17-63	WIRING DIAGRAM —
CHECK		2-26-63	FUEL PUMP
PROJ		3-28-63	SYSTEM
SUPERSEDED BY			
SUPERSEDES	1270405	PAGE 7.1	MODEL: 210 & T210
REV	G		PAGE: 7.1

Cessna.


1270405

1. WIRES MADE FOR THIS DRAWING
ARE USED ON MODELS 205 & P206
U206. CHANGES MADE TO THIS
DRAWING SHOULD ALSO BE MADE
TO WIRING DIAGRAM ON 1270625
PAGE 7.2.




CHG LET	REVISION	BY	CHK
		DATE	APP
A	S-1360-10 CKT BKR WAS S-1232-10 1209461-1 BUS BAR WAS 1209429-1 ADDED NOTE. 2.; 1200687 N/A WAS 1200937	WJR 11-1-63	RES ALL
B	REMOVED 12709461-1 BUS BAR FROM E/T; ADDED WIRE LENGTHS TO W/T	WJR 7-1-64	RES ALL
C	ADDED F-Q83 WIRE; INACTIVATED F-Q82 WIRE; N/A ON F-Q81 WAS 1200687; ADDED T210 TO MODEL BLOCK (SR46637). (SR46637)	WJR 5-4-65	RES ALL

4			
3	5-1340-10	CIRCUIT BREAKER	
2	5-1158-1-1	SWITCH	
1	AN4078-1	OIL DIL VALVE	
	PART NO	DESCRIPTION	INSTALLED ON



EQUIPMENT TABLE

F-QB3	18		5-1367-1-6	5-1367-1-10	1200711	SER 7310-000 / 21058716	8/0N
F-QB2	18	60	5-1367-1-6	5-1367-1-10	1200867	INACTIVE SER 21058716	8/0N
F-QB1	18	7	5-1367-1-6	5-1367-1-8	1200711		
WIRE CODE NO	CA	MATERIAL	LG	TERMINALS	N/A	SERIALS	

WIRE TABLE							
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS							
	NAME	DATE	TITLE				
DRAWN	RIDDER	9-12-62	WIRING DIAGRAM — OIL DILUTION SYSTEM (OPT)				
GROUP							
CHECK	R. HICK	10-9-62					
PROJ	N. H. Galt	11-12-61					
SUPERSEDED BY			SUPERSEDES	MODEL	REV	C	PAGE
				2106T210			7.2

DWS NO.
1270405

ENGINE INSTRUMENTS SECTION

Cessna.

DRAWING NO.

1270405

DRAWN

H WISE

TITLE: WIRING DIAGRAM---

DATE

8-27-62

MODEL 210

APP'D

RPS Hmc


REV:

PAGE:

8.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

CHG LET	REVISION	BY	CHK
		DATE	APPD
A	ADDED WIRE LENGTHS TO WIT; HF-EB1 WIRE WAS F-EB1; S-1367-1-10 WAS S-1232-10; C669502-0104 WAS S-713602-1; REMOVED 270929-1 BUS BAR FROM C/T; INST WAS INST LIGHTS	WJR 7-6-66	110



Inactive SER 21058819 & ON
2110-0198 & ON
2-3-66
2-17-66
RCS OKM

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
HF-EB1	18	50 S-1367-1-8	S-1367-1-8		
F-EB3	18	88 S-1367-1-10	S-341-2		
F-EB2	18	120 S-1367-1-10	S-341-2		

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
5			
4			
3	0726110-1	XMTR, FUEL LEVEL	
2	C669502-0104	INST CLUSTER KIT	
1	S-1367-1-10	CIRCUIT BREAKER	

EQUIPMENT TABLE


NAME	DATE	TITLE
RIDDER	9-13-62	WIRING DIAGRAM - FUEL QUANTITY INDICATOR
GROUP		
CHECK		
PROJ		
SUPERSEDED BY	PAGE	SUPPLIES
1270405	8.2.1	
MODEL	REV	PAGE
7210, 210	A	8.2

Cessna.

DWG NO
1270405

(SR 4886)
(SR 4887)

CHG LET	REVISION	BY	CHK
A	BY REVISION: ITEMS 4 & 5 WERE REVERSED. 5-1635 E 5-1635 CHGD TO AGREE WITH ITEMS 4 & 5. (SR 4886) (SR 4887)-	GLW 5-7-66	HLW




ITEM NO.	PART NO.	DESCRIPTION	INSTALLED ON
5	5-1641-9	HOUSING-SOCKET	
4	5-1640-9	HOUSING-PIN	
3	0726110-1	XMTR, FUEL LEVEL	
2	C669502-0104	INST CLUSTER KIT	
1	5-1360-10	CIRCUIT BREAKER	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
YEL	18	5-1460-18-4	5-1636-2	5-1367-10	
YEL	18	5-1460-18-4	5-1636-2	5-1367-10	
HF-EB1	18		50	5-1367-10	5-1367-10
F-EB3	18		5-1367-10	5-1635-2	
C-EB4	18		5-1367-10	5-1635-2	

NAME	DATE	TITLE
DRAWN J. MUSTON	2-1-66	WIRING DIAGRAM—
CHECK R. Wick	2-17-66	FUEL QUANTITY
PROJ H. M. Galt	2-14-66	INDICATOR

SUPPLEMENTED BY	1270405	PAGE 8.2	MODEL 210 & T210	REV: A	PAGE 8.2.1
-----------------	---------	----------	------------------	--------	------------



NOTE:

1 WIRING DIAGRAM SHOWN IS FOR USE WHEN AN OPTIONAL ELECTRIC CLOCK IS INSTALLED. WHEN ELECTRIC CLOCK IS NOT INSTALLED WIRE F-DF1 CONNECTS PRESSURE SWITCH TO FUSEHOLDER. INSTALL S-1091-1 FUSE AND S-1690 22 FUSEHOLDER.

5	S-1317N1	CLOCK	
4	S-66450-0101	HOURLMETER	
3	S-1711-1	OIL PRESSURE SW	
2	S-1091-1	FUSE	
1	S-1579-1	BAT. CONTACTOR	
ITEM NO	PART NO.	DESCRIPTION	INSTALLED ON
EQUIPMENT TABLE			

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
F-DF4	18			S-1493-1 S-1367-1-E	
F-DF3	18			S-1493-1 S-1367-1-E	
F-DF2	18			S-1367-1-E S-1367-1-E	
F-DF1	18			S-1367-1-E SOLDER	
WIRE TABLE					
CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS					
DRAWN	NAME	DATE	TITLE		
3	WEDL	9-23-66	WIRING DIAGRAM—		
GROUP	H. H. H.	9-27-66	HOURLMETER		
CHECK	R. H. H.	9-28-66	(OPT)		
PROJ	Wichita	9-29-66			
SUPERSEDED BY:			SUPERSEDER	MODEL:	REV:
				210, T210	8.3

Cessna.

DWG NO. 1270405

FLIGHT INSTRUMENTS SECTION

Cessna.

DRAWING NO.

1270405

DRAWN *RIDDER*

DATE *9-14-62*


APP'D *RRS Nhc*

TITLE: WIRING DIAGRAM---
MODEL 210

REV:

PAGE: 9.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.




F-FE4	20	6	S-341-2	SOLDER	0713705	(OPT) inactive	2105554 EA SER
F-FE3	20	8	S-341-2	S-1367-1-B	0713705	(OPT) inactive	2105554 EA SER
F-FE2	20	6	S-341-2	SOLDER	0713705	(OPT) inactive	2105554 EA SER
F-FE1	20	6	S-341-2	SOLDER	0713705	(OPT) inactive	2105554 EA SER
F-FA2	18	16	S-1367-1-B	S-1367-1-B			
F-FA1	18	12	S-1367-1-B	S-1367-1-10			
WIRE CODE NO	GA	MATERIAL	LG	TERMINALS			SERIALS

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

NAME	DATE	TITLE
DRAWN: RIDDER	9-14-62	WIRING DIAGRAM — TURN & BANK AND GYRO HORIZON INDICATOR
GROUP: 12-4-62		
CHECK: 12-4-62		
PROJ: 11-2-62		




Cessna.

DWG NO. **1270405**

SUPERSEDED BY	SUPERSEDES	MODEL 210 E T210	REV A	PAGE 9.1
---------------	------------	---------------------	----------	-------------

1. TURN COORDINATOR INDICATOR INCLUDES ALL WIRES AND CABLES BETWEEN INVERTER, INDICATOR AND CIRCUIT BREAKER.




REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED

[illegible]

WIRE TABLE


CONTRACT NO:		Cessna AIRCRAFT CO.		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE		
GROUP	H. Will	5-25-67	WIRING DIAGRAM -		
DRAWN	HARRIS	5/22/67	BRITTAINE WING LEVELER		
CHECK	YAKSHAW	5-23-67	(OPT)		
STRESS	am	5-25-67			
PROJECT	Nimble	5-24-67			
APPD	RF	5-24-67			
			SIZE	CODE IDENT. NO.	DWG NO.
			C	71379	1270405
			SCALE: NONE	(583600) DC	PAGE: 9.2

2	C661003-0401	TURN COORDINATOR
1	CA-2	CKT BKR (73803)
ITEM NO.	PART NO.	DESCRIPTION
	EQUIPMENT TABLE	



CUT NO. 1			WIRE TABLE		
CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
	NAME	DATE	Cessna AIRCRAFT CO.		
DESIGN	COOK	9-13-67	TITLE		
GROUP	H Wine	9-13-67	WIRING DIAGRAM -		
DRAWN	Hanna	9-8-67	TURN COORDINATOR		
CHECK	LAURIE	9-8-67			
STRESS	auto	9-11-67			
PROJECT	H. M. Carter	9-14-67	SIZE	CODE IDENT. NO.	DWG NO.
APPD	RE. HARRIS	9-9-67	C	71379	1270405
			SCALE: NONE		21047210
					PAGE: 93

	NAME	DATE
DESIGN	COOK	9-13-67
GROUP	H. Wines	9-13-67
DRAWN	Marine	9-8-67
CHECK	LAURIE	9-9-67
STRESS	ant	9-11-67
PROJECT	H. M. Cate	9-14-67
APPO	25. M. 0. 0. 0.	9-14-67

 CESSNA AIRCRAFT CO.		COMMERCIAL AIRCRAFT DIV. 5900 E. PAWNEE WICHITA, KANSAS	
TITLE WIRING DIAGRAM — TURN COORDINATOR			
SIZE C	CODE IDENT. NO. 71379	DWG NO. 1270405	
SCALE: NONE		21047210	PAGE: 93

OTHER INSTRUMENTS SECTION

Cessna.

DRAWING NO.

1270405

DRAWN

RIDDER

TITLE: WIRING DIAGRAM---

DATE

10-8-62

MODEL 210

APP'D

CRS *llms R*

REV:

PAGE:


10.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

CHG LET	REVISION	BY	CHK
		DATE	APPD

SER 21058819 & ON,
SER T210-0198 & ON

CHG LET	REVISION	BY	CHK
A	BY REVISION: S-1638-2 WAS S-1641-4; S-1638-3 WAS S-1640-8. S-1636-2 & S-1635-2 HAVE BEEN INTERCHANGED IN W/T SER 21058819 & ON, SER T210-0198 & ON	GLW 5-9-65	JAK AKM HME



INACTIVE
EFF THRU SER 21058937 & ON, SER T210-0308 & ON
JAK
AKM
HME

PART NO.	DESCRIPTION	INSTALLED ON
5	S-1638-2 HOUSING-CAP	
4	S-1638-3 HOUSING-PLUG	
3	C590801-010 TRANSMITTER	
2	C668001-010Z INDICATOR	
1	S41360-10 CIRCUIT BREAKER	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
GRAY	18	S-1640-18-B		S-1636-2 S-341-2	
F-DB7	18			S-1367-10 S-1635-2	
F-DB6	18		G	S-1367-1-8 SOLDER	
F-DB1	18		37	S-1367-1-8 S-1367-1-10	

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

DRAWN	NAME	DATE	TITLE
J. HUSTON		2-2-64	WIRING DIAGRAM—
GROUP	H. WIND	2-17-64	FLAP POSITION
CHECK	R. BUCK	2-18-64	INDICATOR
PROJ	H. WIND	2-14-64	

1270405

REV: A


PAGE: 10.2.1


LIGHTING SECTION


Cessna.

DRAWN		RIDDER	TITLE: WIRING DIAGRAM--- MODEL 210		DRAWING NO.	
DATE		9-18-62			1270405	
APP'D		P.R.S. Nm			REV:	PAGE: 11.0
CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.						

Inactive SER 21058819 EON
2110-0198 EON
2-17-66
2-18-66
RHS axm NINE

[illegible]






NOTES:

1. WHEN (OPT) POST & BACK LIGHTING IS INSTALLED, WIRE F-LB5 IS CONNECTED TO CONSOLE SIDE OF S-1238-Z-1 SWITCH REF 1270405 PAGE 11.7.
2. JUMPERS ARE 20 GA WIRE.

CHG LET	REVISION	BY	DATE	CHK
A	CABIN LIGHTS WAS INST LIGHTS; REMOVED 1270429-1 FROM E/T; S-1360-10 WAS S-1232-10; C660501-0101 WAS 0713068-1; ADDED WIRE LENGTHS TO W/T; ADDED F-LB6, F-LB7 & C661502-0104 (SR4455)-9	WJR	8-6-64	RES
B	ADDED S-341-2 TO F-LB6 & ADDED JUMPER TO INST CLUSTER; ADDED DETAIL 'A'; ADDED HF-LB8 & HF-LB9; ADDED T210 TO MODEL BLOCK (SR4637)(SR4661)L	WJR	5-17-65	RES
C	ADD DETAIL B & NOTE 2 (SR4886)(SR4887)-9	GLW	5-14-65	VAL
D	S-341-2 ON F-LB7 WAS SOLDER (SR4886)(SR4887) & ON	GLW	5-27-65	RES
E	ITEM 2 XR6637 WAS RS1212-B-R934 (SR4637)(SR4661) & ON	VRS	4-14-67	VAL



WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
HF-LB9	18			S-341-2 S-1367-1-8	(SR4637)(SR4661) & ON
HF-LB8	18			S-341-2 SOLDER	(SR4637)(SR4661) & ON
F-LB7	20			SOLDER S-1367-1-8	21058511 THRU (SR4886)(SR4887)
F-LB6	20			SOLDER S-341-2	21058511 & ON
F-LB4	18			41 S-341-2 S-1367-1-6	INACTIVE (SR4661) & ON
F-LB5	18			90 S-341-2 SOLDER	
F-LB3	18			50 S-341-2 SOLDER	INACTIVE (SR4661) & ON
F-LB1	18			4 S-1367-1-8 SOLDER	

WIRE TABLE

NAME	DATE	TITLE
DRAWN RIDDER	7-19-62	WIRING DIAGRAM—
GROUNDED	10-30-62	INSTRUMENT LIGHTS
CHECK	10-30-62	
PROJ	11-2-62	


PART NO.	DESCRIPTION	INSTALLED ON
8 336R	LAMP (GE)	
7 25-240XP16	LAMPHOLDER (LECR)	
6 C669502-0204	INST CLUSTER KIT	
5 0700621-1	MAP LIGHT INSTL	
4 C660501-0101	COMPASS	
3 XR6637	RHEOSTAT (83777)	
2 S-1360-10	CIRCUIT BREAKER	
1		

EQUIPMENT TABLE

Cessna.

DWG NO. 1270405

REV E PAGE 11.2



NOTES:

- 1 SWITCH IS MECHANICALLY INTERCONNECTED SO THAT DEPRESSING "LAND" PORTION OF SWITCH TO "ON" POSITION ALSO CARRIES "TAXI" PORTION OF SWITCH TO "ON" POSITION.

CHG LET	REVISION	BY	DATE	CHK	APPD
A	S-1360-20 CKT BKR WAS S-1232-19 1270441-1 BUS BAR WAS 1270429-1 WIRES F-LC3 & F-LC6 WERE 15 GA (SR4588)	HLW	9-17-63	RES	7M
B	ADDED WIRE LENGTHS TO W/T; REMOVED 1270441-1 FROM E/T; HF-LC8 WAS F-LC8; OBSOLETE F-LC4, F-LC5 & F-LC7; HF-LC9 WAS F-LC7; HF-LC10 WAS F-LC6; HF-LC11 WAS F-LC4 (SR4455)	WJR	8-10-64	RES	7M
C	INBD WAS OUTBD; OUTBD WAS INBD; ADDED T210 TO MODEL BLOCK; INACTIVATED DWG BLOCK (SR4886) (SR4887)	WJR	1-26-66	RES	7M

Inactive SER 21058819 & ON
T210-0198 & ON
W.F.R. 1-27-66
W.F.W. 2-17-66
CPS
OKM
NMC

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
HF-LC11	14		20	5-1367-2-8	5-341-1	1220090 SER 21058811 & ON
HF-LC10	14		2	5-1367-2-8	5-1367-2-8	1220090 SER 21058811 & ON
HF-LC9	14		174	5-1367-2-8	5-341-1	1220090 SER 21058811 & ON
HF-LC8	14		6	5-1367-2-8	5-1367-2-8	1220025
F-LC7	14		162	5-1367-2-8	5-341-1	1220003 OBSOLETE
F-LC6	14		26	5-1367-2-6	5-341-1	
F-LC5	14		6	5-1367-2-8	5-1367-2-8	1220025 OBSOLETE
F-LC4	14		168	5-1367-2-8	5-341-1	1220003 OBSOLETE
F-LC3	14		26	5-1367-2-6	5-341-1	
F-LC1	14		4	5-1367-2-6	5-1367-2-6	

WIRE TABLE

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

DRAWN	NAME	DATE	TITLE
RIDDER	7-20-62		WIRING DIAGRAM - LANDING LIGHTS
CHECK	R. D. R.	10-26-62	
PROJ	H. D. R.	11-2-62	
SUPERSEDED BY	PAGE	SUPERSEDES	MODEL
1270405	11-3-1		210, T210
REV	C	PAGE	11.3

Cessna.


DWG NO. 1270405

PART NO.	DESCRIPTION	INSTALLED ON
4 0523118-1	LANDING LIGHT	
3 5-1160-1-1	SWITCH	
2 5-1360-20	CIRCUIT BREAKER	
1		

EQUIPMENT TABLE

(SR4886)
(SR4887)

CHG LET	REVISION	BY DATE	CHK APPD



NOTES:
1 SWITCH IS MECHANICALLY INTERCONNECTED SO THAT DEPRESSING "LAND" PORTION OF SWITCH TO "ON" POSITION ALSO CARRIES "TAXI" PORTION OF SWITCH TO "ON" POSITION.

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
5	0523118-1	LANDING LIGHT	
4	5-1640-9	HOUSING - PIN	
3	5-1641-9	HOUSING - SOCKET	
2	5-1160-1-1	SWITCH	
1	5-1360-20	CIRCUIT BREAKER	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
BLACK	16	5-1460-16-0		5-1367-2-8	5-1367-2-8
TAN	14	5-1460-14-10		5-1635-2	5-1367-2-8
BLACK	16	5-1460-16-0		5-1367-2-8	5-1367-2-8
GRAY	14	5-1460-14-8		5-1635-2	5-1367-2-8
F-LC14	14			5-1367-2-6	5-1636-2
F-LC13	14			5-1367-2-6	5-1636-2
F-LC12	14			5-1367-2-6	5-1367-2-6


WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

NAME	DATE	TITLE
RIDDER	1-4-66	WIRING DIAGRAM - LANDING LIGHTS
GROUP	H. Ward	2-17-66
CHECK	P. Ward	2-18-66
PROJ	H. Ward	2-19-66

1270405

REV: 11.3.1



NOTES:

1. SWITCH IS MECHANICALLY INTERCONNECTED SO THAT DEPRESSING "STEADY" PORTION OF SWITCH TO "ON" POSITION ALSO CARRIES "FLASH" PORTION OF SWITCH TO "ON" POSITION.

CHG LET	REVISION	BY	DATE	CHK
A	ADD OPTIONAL & STANDARD CONFIGURATIONS. ADD WIRES F-LD14 F-LD15 & F-LD16. ADD S-1158-2-1 SWITCH WIRES F-LD3 THRU F-LD9. F-LD9 & F-LD11 BECOME OPTIONAL 1270461-1 BUS BAR WAS 1270423-1 BUS BAR (SR 4039-9)	GLW	2-26-63	RRS
B	ADDED WIRE LENGTHS TO W/T; ADDED LIMITING SERIES TO FIELD; INACTIVATED F-LD3, F-LD4, F-LD5 F-LD6, F-LD9 & F-LD11; REMOVED 1270461-1 FROM E/T; OBSOLETE F-LD8, F-LD7, F-LD12, F-LD13 & F-LD10; HF-LD17 WAS F-LD10; HF-LD18 WAS F-LD7; HF-LD20 WAS F-LD13; HF-LD21 WAS F-LD8 HF-LD19 WAS F-LD12 (SR 4455)-9	WJR	8-11-64	RRS

*Inactive SER 21058819 & ON
w/o 1-27-66
RRS OKM 2-17-66
HMC*

HF-LD21	18	14	S-1367-1-B	SOLDER	SER 21058511 & ON
HF-LD20	18	14	S-1367-1-B	SOLDER	SER 21058511 & ON
HF-LD19	18	250	S-341-2	SOLDER	SER 21058511 & ON
HF-LD18	18	250	S-341-2	SOLDER	SER 21058511 & ON
HF-LD17	18	20	S-341-2	SOLDER	SER 21058511 & ON
F-LD16	18	27	S-341-2	S-1367-1-B	SER 21058221 & ON
F-LD15	18	352	S-341-2	S-1367-1-B	SER 21058221 & ON
F-LD14	18	50	S-341-2	S-1367-1-B	SER 21058221 & ON
F-LD13	18	14	S-1367-1-B	SOLDER	OBSOLETE
F-LD12	18	250	S-341-2	SOLDER	OBSOLETE
F-LD11	18	46	S-1367-1-B	S-341-2	1270462 (OPT) inactive 21058511 & ON
F-LD10	18	23	S-341-2	SOLDER	OBSOLETE
F-LD9	18	335	S-1367-1-B	S-341-2	1270462 (OPT) inactive 21058511 & ON
F-LD8	18	14	SOLDER	S-1367-1-B	OBSOLETE
F-LD7	18	250	S-341-2	SOLDER	1220004 OBSOLETE
F-LD6	18	66	S-1367-1-B	S-341-2	1270462 (OPT) inactive 21058511 & ON
F-LD5	18	46	S-1367-1-B	S-1367-1-B	1270462 (OPT) inactive 21058511 & ON
F-LD4	18	19	S-1367-1-B	S-1367-1-B	1270462 (OPT) inactive 21058511 & ON
F-LD3	18	45	S-1367-1-B	S-1367-1-B	1270462 (OPT) inactive 21058511 & ON
F-LD1	18	4	S-1367-1-B	S-1367-1-B	


WIRE TABLE			
WIRE CODE NO	MATERIAL	LG	TERMINALS
GA			N/A
SERIALS			
CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS			
NAME	DATE	TITLE	
RIDDER	9-21-62	WIRING DIAGRAM - NAVIGATION LIGHTS	
DRAWN	10-24-62		
CHECK	10-26-62		
PROJ	11-2-62		
SUPERSEDED BY		PAGE	SUPPLIES
1270405		11.4.1	
MODEL		210 & T210	REV B
PAGE		11.4	

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
8	S-1158-2-1	SWITCH	
7	9423006-13	POSITION LIGHT	
6	0433006-7	POSITION LIGHT	
5	0423006-12	POSITION LIGHT	
4	0713511-1	FLASHER, NAV LT	
3	S-1460-1-1	SWITCH	
2	S-1360-10	CIRCUIT BREAKER	
1			

EQUIPMENT TABLE

SER 21058819 & ON,
SER T210-0198 & ON

CHG LET	REVISION	BY	CHK
		DATE	APPD
A	BY REV: C622001-0202 WAS 1221112-1E-2, C622001-0102 WAS 0433006-7, ITEM 3 WAS ITEM 4 & F-LD29 WAS F-LD24; ADD F-LD27, F-LD28	RCC	R.L.L.
	5-1637-1, 5-1637-2; DELETE 3 RED & 3 BLACK WIRES	1-6-67	do.
	ED:RR 01163 ED:RR 01335		



NOTES:

1. S-1636-2 SOCKET & S-1637-2 HOUSING - PLUG.
2. S-1635-2 PIN & S-1637-1 HOUSING - CAP.

PART NO	DESCRIPTION	INSTALLED ON
8	S-1637-2 HOUSING-SOCKET	
7	S-1641-9 HOUSING-SOCKET	
6	S-1640-9 HOUSING-PIN	
5	C622001-0102 POSITION LIGHT	
4	S-1637-1 HOUSING-PIN	
3	C622001-0202 WING LIGHT ASSY	
2	S-1158-2-1 SWITCH	
1	S-1360-10 CIRCUIT BREAKER	


EQUIPMENT TABLE


F-LD29	18			S-1635-1	S-1635-1		
F-LD28	18			S-1635-2	S-1635-1		
F-LD27	18			S-1635-2	S-1635-1		
F-LD26	18			S-1367-1-6	S-1636-2		
F-LD25	18			S-1367-1-6	S-1636-2		
F-LD24	18	THRU SER(SAG63)	2	SOLDER			
F-LD23	18			S-1367-1-6	1		
F-LD22	18			S-1367-1-6	S-1367-1-6		

WIRE TABLE							
WIRE CODE NO	GA	MATERIAL	LG	TERMINALS			SERIALS
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS							
DRAWN	RIDDER	DATE	1-5-66	WIRING DIAGRAM—			
GROUP	N. Wier	DATE	2-17-66	NAVIGATION LIGHTS			
CHECK	R. Black	DATE	2-18-66				
PROJ	H. M. Galt	DATE	2-24-66				
SUPERSEDED BY:		REPLACES	1270405 11.4	MODEL	210 & T210	REV:	A
						PAGE:	11.4.1

Cessna.

1270405

[illegible]


NAME		DATE		TITLE		 Cessna.	
DRAWN	RIDDER	10-5-62	WIRING DIAGRAM —				
GROUP	211464	10 (4-2)	ROTATING BEACON				
CHECK	C. Luck	10-26-62	(OPT)				
PROJ.	M. H. A.	1-2-63				DWG NO. 1270405	
SUPERSEDED BY 1270405		PAGE	SUPERSEDES		MODEL: 210 E T210	REV: A	PAGE: 11-5

NOTES:

- 1 S-1636-2 SOCKET & S-1637-2 HOUSING - PLUG.
2 S-1635-2 PIN & S-1637-1 HOUSING - CAP.

(SR4886)
(SR4887)

CHG LET	REVISION	BY DATE	CHK APP



WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
DFH-LF7	16			2	S-1636-2	(STD)
F-LF6	16			S-1367-2-8	1	(STD)
F-LF5	16			S-1367-2-8	S-1367-2-8	0700169

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS

PART NO	DESCRIPTION	INSTALLED ON
4	C59450-0101 FLASHER UNIT	
3	C621001-0101 LIGHT ASSY	
2	S-1158-2-1 SWITCH	
1	S-1360-10 CIRCUIT BREAKER	

EQUIPMENT TABLE

DRAWN	NAME	DATE	TITLE
RIDDER		12-21-65	WIRING DIAGRAM -
GROUP	H. H. H.	1-24-66	FLASHING BEACON
CHECK			LIGHT
PROJ	H. H. H.	1-27-66	(OPT)
SUPERSEDED BY:			
1270405	PAGE 11.5	MODEL: 210 & T210	REV: PAGE: 11.5.1


Cessna.

1270405

NOTE:

1. WIRES MADE PER THIS DRAWING ARE USED ON MODELS OTHER THAN 210. CHANGES MADE ON THESE WIRES SHOULD ALSO BE MADE ON OTHER WIRING DIAGRAMS.

CHG LET	REVISION	BY DATE	CHK APPD
A	REMOVED 1270461-1 FROM E/T ADDED WIRE LENGTHS TO WIT: INACTIVATED DRAWING	WJR 8-1-64	265 T/W



Inactive
 WJQ
 223

SER 21058511 EON
 8-12-64
 m


[illegible]

WIRE TABLE

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

4	1470089-10	MAP LIGHT ASSY	
3	0713029	SWITCH	
2	5-1360-10	CIRCUIT BREAKER	
1			
	PART NO	DESCRIPTION	INSTALLED ON

EQUIPMENT TABLE

NAME		LATE	TITLE			
DRAWN	G WOOD	3-29-63	WIRING DIAGRAM — MAP LIGHT (OPTIONAL)			
CROPE	W. McLean	3-30-63				
CHECK	R. Buck	4-22-63				
PROJ	W. McLean	3-30-63				
DTPG NO			1270405			
SUPERSIDED BY PAGE		SUPERSIDES		MODEL	REV	PAGE
1270405		11.6.1		210	A	11.6


Cessna.


DWG NO. 1270405



SUPERSEDED BY 1270405	PAGE 11.6.1	SUPERSEDES	MODEL 210	REV A	PAGE 11.6
--------------------------	----------------	------------	--------------	----------	--------------

NOTES:

CHG LET	REVISION	BY	CHK
		DATE	APPRO
A	ADD T210 TO MODEL REMOVED OPT FROM TITLE. ADD OPT TO F-LA19 & F-LA18 WIRES IN NOTE 1, REMOVE 1B-1 INSULATOR (GRAY) (SR1586) (SR1587)-F	G.I.W 5-14-66	VAR K.M
B	ITEM 2 XRG637 WAS R124-B-R534 (SR5160) & R5161 & ON	VMS 6/27/66	WAL K.M



WIRE TABLE			
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS			
DRAWN	NAME	DATE	TITLE
	RIDDER	8-13-64	WIRING DIAGRAM — MAP LIGHT
GROUP	R. M. M. M.	8-13-64	
CHECK	R. M. M. M.	8-13-64	
PROJ.	H. W. W.	9-1-64	
SUPERSEDED BY			 DWG. NO. 1270405
SUPERSEDED BY		PAGE	REV. 8
MODEL		210 T210	PAGE 11.6.1



- NOTES:
1. VENDOR FURNISHED LEADS TERMINATE AT SWITCH WITH S-1367-1-6 TERMINAL.
 2. WHEN MAP LIGHT & CONSOLE LIGHTS ARE INSTALLED WITH POST & BACK LIGHTING, WIRE F-LBS IS CONNECTED TO CONSOLE SIDE OF S-1238-2-1 SWITCH INSTEAD OF R-124-8-RS34 RHOSTAT.


9	1B - 1	STAND-OFF INSUL	(GRAY)
8	3-123B-2-1	SWITCH	
7	41163-C-14	LIGHT ASSY (GBN)	
6	5602M-3H-R-14	LIGHT ASSY (GBN)	
5	5952-3H-R-14	LIGHT ASSY (GBN)	
4	5602M-3H-R-14	LIGHT ASSY (GBN)	
3	5952-3H-R-14	LIGHT ASSY (GBN)	
2	R-12-6-BRS34	RHEOSTAT (TRTA)	
1	S-136-010	CIRCUIT BREAKER	

(SR4607)

CHG LET	REVISION	BY	CHKD
		DATE	APP
A	BY REV: RED/WHIT / BLACK WIRES BETWEEN POST LIGHTS WERE 20 GA. (JA:BEALED WIRE NEVER USED)	L.P.B. - 7-64	175 TH 122
B	REMOVED JUMPER & (1) 18-1 STAND OFF INSUL (GRAY) DWG BECOMES INACTIVE. (SR4886)(SR4887) - 9	GLW 5-14-66	184 84


Inactive SERD1058819 & T210-078 & CUN
 62W 5-14-66
 72W 7-15-66
 1A K51HAW 7-16-66

DHF-LB81	18			S-1367-1-B	S-341-2	1200686	
DHF-LB80	18			S-341-2	S-1367-1-B		
BLACK	22	S-1460-22-0		SOLDER	S-341-2		
BLACK	22			SOLDER	SOLDER		
BLACK	22			SOLDER	SOLDER		
BLACK	22			SOLDER	SOLDER		
BLACK	22			SOLDER	SOLDER		
BLACK	22			SOLDER	SOLDER		
BLACK	22	S-1460-22-0		SOLDER	SOLDER		
RED/WHT	22	S-1460-22-2-9		SOLDER	SOLDER		
RED/WHT	22			SOLDER	SOLDER		
RED/WHT	22			SOLDER	SOLDER		
RED/WHT	22			SOLDER	SOLDER		
RED/WHT	22			SOLDER	SOLDER		
RED/WHT	22			SOLDER	SOLDER		
RED/WHT	22			SOLDER	SOLDER		
RED/WHT	22	S-1460-22-2-9		S-341-2	SOLDER		
DHF-LB62	18			S-1367-1-6	S-341-2		
DHF-LB61	18			S-341-2	S-1367-1-B		
BLACK	22	S-1460-22-0		SOLDER	S-341-2		
BLACK	22	-22-0		SOLDER	SOLDER		
RED/WHT	22	-22-2-9		SOLDER	SOLDER		
RED/WHT	22	-22-2-9		SOLDER	SOLDER		
RED/WHT	22	S-1460-22-2-9		S-341-2	SOLDER		
F-LB55	18			S-341-2	S-1367-1-6		
BLACK	22	S-1460-22-0		S-341-2	SOLDER		
RED/WHT	22	S-1460-22-2-9		SOLDER	SOLDER		
RED/WHT	22	S-1460-22-2-9		SOLDER	S-341-2		
F-LB51	18			S-1367-1-4	S-341-2	1200686	
WIRE	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS	

WIRE TABLE			
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS			
DRAWN	NAME	DATE	TITLE
	W. L. H. R.	1-2-60	WIRING DIAGRAM— POST LIGHTING & BACK LIGHTING (OPT)
CHECKED		6-8	
CHECKED			
APPROVED		1-2-60	
	W. L. H. R.	1-2-60	
REV. 11.7 1270405			 DASH NO.: 1270405
REV. 11.7 1270405			MODEL: 210 REV. B PAGE 11.7

SER 21058937 ON,
SER T210-0308 ON

CHG LET	REVISION	BY	CHK
A	ITEM 2 XRG637 WAS RS12 1/2-B-RS34 SER 21058937 ON, SER T210-0308 ON	VRS	YAK
B	NOTE 3. RED/YEL WIRES WERE RED/WHT	6/27/64	YAK



DETAIL A
SER 21058937 ON,
SER T210-0308 ON


STANDARD EQUIPMENT SER 21058937 ON, SER T210-0308 ON
JUMPERS ARE 20 GA WIRE.
WHEN MAP LIGHT & CONSOLE LIGHTS ARE INSTALLED
WITH POST & BACK LIGHTING, WIRE
F-LB5 IS CONNECTED TO CONSOLE SIDE OF
S-1238-2-1 SWITCH INSTEAD OF XRG637
RHEOSTAT. PART OF F-LB5 IS USED AS A JUMPER

PART NO.	DESCRIPTION	INSTALLED ON
10	FRL-5-2 2 OHM RESISTOR (TRTA)	
9	1B13/2 LWI CAPS (APMH)	
8	S-1238-2-1 SWITCH	
7	C669502-0204 INST CLUSTER	
6	336 LAMP (GE)	
5	5952-3RM-CW-14 LIGHT ASSY (GBN)	
4	25-240XPIG LAMPHOLDER (LECR)	
3	5952-3LM-CW-14 LIGHT ASSY (GBN)	
2	XRG637 RHEOSTAT (6377)	
1	S-1360-10 CIRCUIT BREAKER	

RED/YEL 22	5-1460-22-29	SOLDER	SOLDER	1200727
BLACK 22	5-1460-22-29	SOLDER	SOLDER	
DHF-LB85 20		SOLDER	SOLDER	
DHF-LB84 20		S-341-1	S-1370-1	
DHF-LB83 20		SOLDER	S-1541-8	
DHF-LB82 20		SOLDER	SOLDER	
DHF-LB81 20		S-341-2	S-1541-8	
DHF-LB80 20		S-341-2	S-1541-8	
BLACK 22		SOLDER	SOLDER	
BLACK 22		SOLDER	SOLDER	
BLACK 22		SOLDER	SOLDER	
BLACK 22		SOLDER	SOLDER	
BLACK 22		SOLDER	SOLDER	
BLACK 22		SOLDER	SOLDER	
BLACK 22		SOLDER	SOLDER	
BLACK 22		SOLDER	SOLDER	
BLACK 22		S-341-2	SOLDER	
BLACK 22		SOLDER	SOLDER	
BLACK 22		S-341-2	SOLDER	
BLACK 22		SOLDER	SOLDER	
RED/WHT 22		SOLDER	SOLDER	
RED/WHT 22		SOLDER	SOLDER	
RED/WHT 22		S-341-2	SOLDER	
RED/WHT 22		SOLDER	SOLDER	
RED/WHT 22		SOLDER	SOLDER	
RED/WHT 22		SOLDER	SOLDER	
RED/WHT 22		SOLDER	SOLDER	
RED/WHT 22		SOLDER	SOLDER	
RED/WHT 22		SOLDER	SOLDER	
RED/WHT 22		SOLDER	SOLDER	
RED/WHT 22		SOLDER	SOLDER	
RED/WHT 22		SOLDER	S-341-2	
RED/WHT 22	5-1460-22-29	SOLDER	S-341-2	1200727

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
WIRE TABLE						
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KAN. 67301						
DRAWN	G WOOD	5-14-66	TITLE			
CHECKED	A WILCOX	7-15-66	WIRING DIAGRAM - POST LIGHTING			
PROJ.	A WILCOX	7-16-66	(OPT)			
SUPERSEDED BY:			SUPERSEDES:		PAGE 11.7.1	
1270405			210, T210		11.7.1	

CHG LET	REVISION	BY	CHK
		DATE	APPD



Inactive SER 2105838 & ON
10-30-64
W. J. G.
J
P.S.


[illegible]

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS.

NAME RIDDER		DATE 8-18-69		TITLE WIRING DIAGRAM— NAV-O-MATIC 300 POST LIGHT (OPT)		Cessna.	
DRAWN GROUP		BY CHECKED		BY CHECKED		PWS NO. 1270405	
PROJ 44-166		7-26-69		7-26-69			
SUPERSEDED BY		SUPERSEDES		MODEL 210		REV. PAGE: 11.8	

3	A5299-12	LIGHT ASSY (GMC)	
2	R-12-8-R534	RECOSTAT (TRTA)	
1	S-1360-10	CIRCUIT BREAKER	
ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
	EQUIPMENT TABLE		

CHG LET	REVISION	BY	CHK
		DATE	APPRO
A	ITEM 2 XR6638 WAS XR6085 ITEM 3 XR6637 WAS R12 1/2" 8- RS 34 (SR5160, SR5161 (ON)	YRS 6/24/66	WBS OK Hm NLS



1 TERMINATE WITH S-1370-1 SPLICE.
2 TERMINATE WITH S-1370-2 SPLICE.
3 JUMPER TO BE 20 GA WIRE


4			
3	XR6637	RHEOSTAT	(B3777)
2	XR6638	RHEOSTAT	(B3777)
1	336	BULB (GE)	
	PART NO.	DESCRIPTION	INSTALLED ON

EQUIPMENT TABLE

[illegible]

1. ALL MATERIALS DEFINED ON THIS
DRAWING ARE FOR REFERENCE AND
TECHNICAL USE ONLY

REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED

[illegible]

CONTRACT NO.			WIRE LABEL		
			COMMERCIAL AIRCRAFT DIV. 5800 E PAWNEE WICHITA, KANSAS		
NAME DATE			Cessna AIRCRAFT CO.		
DESIGN -	J. WEDDL	7-28-67	TITLE		
GROUP	H. WILD	7-27-67	WIRING DIAGRAM -		
DRAWN	C. GARCIA	9-19-67	MAP LIGHT, CONTROL WHEEL		
CHECK	R. STUCK	9-19-67	(12 VOLT)		
STRESS	ans	9-19-67			
PROJECT	1000	9-19-67	SIZE	CODE IDENT NO.	DWG NO.
APPD	R. B. MORGAN	9-19-67	C	71379	1270405
SUPERSEDES: 12337-794			SCALE: NONE (SR 5160) X PAGE: 11, 10		

ITEM NO	PART NO.	DESCRIPTION
EQUIPMENT TABLE		

LANDING GEAR SECTION

Cessna.

DRAWING NO.

DRAWN *RIDDER* TITLE: WIRING DIAGRAM---
DATE *10-8-62* MODEL 210


1270405

APP'D *RRS Nm*

REV:

PAGE: 12.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.



NOTES:

- FOR GEAR DOWN SWITCHES REFER TO 1270405 PAGE 15.2
- NOSE GEAR SQUAT SWITCH CLOSED WHEN STRUT IS EXTENDED.
- CONTROL HANDLE CANNOT BE PLACED IN GEAR - UP POSITION EXCEPT WHEN SOLENOID IS ENERGIZED I.E. WHEN NOSE GEAR STRUT IS EXTENDED.
- HYD VALVE SOLENOID IS ENERGIZED WHEN GEARS ARE EITHER LOCKED UP OR LOCKED DOWN AND POWER PACK CONTROL HANDLE IS IN ITS UP-NEUTRAL OR DN-NEUTRAL POSITION.
- GEAR UP SWITCHES ARE CLOSED WHEN GEARS ARE LOCKED.

CHG LET	REVISION	BY	CHK
A	ADDED WIRE LENGTHS TO W/T; REMOVED 1270429-1 FROM E/T; 5-1360-10 WAS 5-1232-10; 2940-1 WAS 1280500-1; S-1377-1 WAS 65-43000-1; REMOVED F-GD1 FROM E/T; INST WAS INST LIGHTS; ADDED COLOR CODED WIRES TO (OAC) POWER PACK DIAGRAM, VM911M-9A WAS VM911-2A (SR44-533)	WJR	RES
B	BY REVISION: REVISED SYMBOL FOR ITEMS 3 & 4. ADD T210 TO MODEL BLOCK (SR4886) (SR4887)-F	GLW	NEW

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
11	M53106A-145-25	PLUG	
10	1270039-1	SWITCH	
9	AN3436-2-3	TERMINAL	
8			
7	AN3436-2-6	TERMINAL	
6	S-1377-1	SWITCH	
5	2940-1	POWER PACK (OAC)	
4	VM920M-3	LIGHT ASSY(MAR)	
3	VM911M-4A	LIGHT ASSY(MAR)	
2	S-1360-10	CIRCUIT BREAKER	
1			

EQUIPMENT TABLE

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-GD9	18	35	S-1367-1-8	SOLDER	
F-GD8	18	26	SOLDER	SOLDER	
F-GD7	18	58	S-1367-1-6	SOLDER	
F-GD3	18	170	S-1367-1-6	SOLDER	
F-GD2	18	210	S-1367-1-6	S-1367-1-6	
F-GE2	18	3	SOLDER	SOLDER	
F-GE1	18	13	S-1367-1-8	SOLDER	

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS


DRAWN	NAME	DATE	TITLE
RIDDER		10-10-62	WIRING DIAGRAM —
CHECKED	NAME	DATE	
W. H. H. A.		10-26-62	LANDING GEAR DOOR
PROJ	NAME	DATE	
W. H. H. A.		11-2-62	CONTROL SYSTEM

DWG NO	REV	PAGE
1270405	B	12.1


HEATING, VENTILATING, AND DE-ICING SECTION

Cessna.

DRAWN <i>RIDDER</i>		TITLE: WIRING DIAGRAM---		DRAWING NO.	
DATE <i>10-5-62</i>		MODEL <i>210</i>		1270405	
APP'D <i>RES Nm</i>		REV:		PAGE: 13.0	
CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.					



THRU SER 21058161



SER 21058162 & ON

NOTE:

1. CIRCUIT BREAKER IS RESET BY INSERTING A PROBE INTO THE $\frac{5}{16}$ DIA HOLE IN BREAKER FACE AND PUSHING LIGHTLY UNTIL A CLICK IS HEARD.

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
7	5-1596-60	CIRCUIT BREAKER	
6	60232-1	CKT BKR (CUE)	
5			
4	6669502-0104	INST CLUSTER KIT	
3			
2	0513052-3	CIGAR LIGHTER	
1	5-1232-10	CIRCUIT BREAKER	

EQUIPMENT TABLE

CHG LET	REVISION	BY	CHK
DATE	DATE	APPRO	
A	ADD 60232-1 CKT BKR TO CIGAR LIGHTER F-HC4 WIRE. NOTE: 5-1232-50 & 0713602-1 OBSOLETE F-HC3 H-HC3 WIRE WAS 18 GA 5-1367-2-B TERM WAS 5-1367-1-B (SR 4081)	GLW	RLW
B	ADDED WIRE LENGTH TO W/T 1 2669502-0104 WAS 0713602-1; 5-1360-50 WAS 5-1232-50; REMOVED 1270429-1 & 1270405 -DA1 FROM E/T	WJR	RLW
C	F-DA3 (REF) WAS F-DA1 (REF) 5-1396-60 WAS 5-1360-60 ADD MODEL T210 (SR4086)(SR4087)-9	GLW	RLW

F-HC4	16	15	5-1367-2-10	5-1367-2-8	SER 21058162 & ON
F-HC3	16	14	5-1367-2-8	5-1367-2-8	OBSOLETE 21058162 & ON
WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS

DRAWN	NAME	DATE	TITLE
21/11/62	RIDDER	10-5-62	WIRING DIAGRAM - CIGAR LIGHTER
CHECK	NAME	DATE	
10-3-62	R. H. H.	10-3-62	
PROJ	NAME	DATE	
11-2-62	H. M. L.	11-2-62	

Cessna.


DWG NO. 1270405

SUPERSEDED BY	SUPERSEDES	MODEL	REV	PAGE
		210, T210	C	13.1

NOTES:

ONLY HEATER CIRCUITS SHOWN.
FOR STALL WARNING CIRCUIT
SEE PAGE 15.1.

CHG LET	REVISION	BY	DATE	CHK
A	ADDED WIRE LENGTHS TO W/T; S-1360-10 WAS S-1232-10; REMOVED 1270429-1 FROM E/T; OBSOLETE F-HA3, F-HA4 & F-HA5; HF-FB3 WAS F-HA3; HF-FB4 WAS F-HA3; HF-FB5 WAS F-HA4 SER 21058811 & ON	WJR	8-15-66	225 NAC
B	0721105-13 WAS 0721106-2 INACTIVATE DRAWING SER 21058813 & ON, SER T210-0198 & ON	JW	2-17-66	225 NAC



Inactive SER 21058819 & ON; SER T210-0198 & ON
WJR 1-28-66
R.P.W. 2-17-66
RBS
AKM
HMC


ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
5			
4	0511062-5	XMTR, STALL WARN, HTD	
3	0721105-13	PITOT TUBE, HEATED	
2	S-1158-Z-1	SWITCH	
1	S-1360-10	CIRCUIT BREAKER	
EQUIPMENT TABLE			

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
HF-FB5	18		50	SEE HF-FB3	5-341-2 1220090 (STD) 21058811 & ON
HF-FB4	18			5-1367-1	5-1367-1 1220090 (STD) 21058811 & ON
HF-FB3	16		92	5-341-1	5-1367-2 1220090 (STD) 21058811 & ON
F-HA5	18		6	5-1367-1	5-1367-1 1220090 (STD) OBSOLETE
F-HA4	18		38	SEE F-HA3	5-341-2 1220090 (STD) OBSOLETE
F-HA3	16		80	5-341-1	5-1367-2 1220090 (STD) OBSOLETE
F-HA2	16		23	5-1367-2-6	5-341-1 1220090
F-HA1	16		4	5-1367-2-6	5-1367-2 1220090
WIRE TABLE					

NAME	DATE	TITLE
RIDDER	10-5-62	WIRING DIAGRAM —
		HEATED PITOT TUBE &
		HEATED STALL WARNING
		SYSTEM (OPT)
Cessna.		
1270405		
SUPERSEDED BY	PAGE	SUPERSEDED
1270405	13.2.1	
MODEL:	210	REV: A
PAGE:	13.2	

(SR4886)
(SR4887)

CHG	REVISION	BY	CHK
LET		DATE	APPD
A	S-1360-15 WAS S-1360-10 (SR5144)	G L W	7-22-66



NOTES:

- 1 ONLY HEATER CIRCUIT SHOWN, FOR
STALL WARNING CIRCUIT, SEE
PAGE 15.1.2.

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
6	0721105-15	PITOT TUBE HEATED	
5	S-1672-2	XMTR STALL WARN HTD	
4	S-1640-9	HOUSING - PIN	
3	S-1641-9	HOUSING - SOCKET	
2	S-1158-2-1	SWITCH	
1	S-1360-15	CIRCUIT BREAKER	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
BLUE	16	S-1460-16-6	SEE BLUE	S-341-2	(STD)	
BLACK	18	S-1460-18-0	S-1367-1	S-1367-1-8	(STD)	
BLUE	16	S-1460-16-6	S-1635-2	S-1369-2	(STD)	
F-HA7	16		S-1367-2-6	S-1636-2	1200440	
F-HA6	16		S-1367-2-6	S-1367-2-6	1200440	

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

NAME	DATE	TITLE
RIDDER	1-6-66	WIRING DIAGRAM—
H. W.	2-17-66	HEATED PITOT TUBE &
CHECK	2-18-66	HEATED STALL WARNING
PROJ	2-24-66	SYSTEM (OPT)

1270405

13.2

CONTROL SURFACE SECTION

Cessna.

DRAWING NO.

1270405

DRAWN

RIDDER

DATE

10-23-62

TITLE: WIRING DIAGRAM---
MODEL 210

APP'D

RRS *Nme*


REV:

PAGE:

14.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

FORM NO. 80-172



NOTE:

1. FLAP SWITCH SHOWN IN FLAP "DOWN" POSITION.
2. GND. BLACK WIRE ON TRANSMITTER MTG. BOLT.

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
10	C590501-0101	TRANSMITTER	
9	C668001-0102	INDICATOR	
8	28INT-12D	SOLENOID (GN)	
7			
6	1260068-2	XMTR, FLAP POS	
5	S-1318-1	INDICATOR, FLAP POS	
4	S-1360-10	CIRCUIT BREAKER	
3	0760657-1	FLAP ACTUATOR	
2	0760632-1	SWITCH, ELECT. FLAP	
1	S-1360-15	CIRCUIT BREAKER	

EQUIPMENT TABLE

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-DB6	18		6	S-1367-1-8	SOLDER
F-DB5	18		48	S-1367-1-10	S-341-2
HF-DB4	18		177	S-341-2	S-341-2
HF-DB3	18		177	S-341-2	S-341-2
F-DB2	18		49	S-1367-1-10	S-341-2
F-DB1	18		37	S-1367-1-8	S-1367-1-10
F-CC9	16		8	S-341-1	S-1367-1-8
F-CC8	16		5	S-1367-2-6	S-1367-2-6
HF-CC7	16		129	S-341-1	S-341-1
HF-CC6	16		129	S-341-1	S-341-1
HF-CC5	16		129	S-341-1	S-341-1
F-CC4	16		25	S-1367-2-6	S-341-1
F-CC3	16		25	S-1367-2-6	S-341-1
F-CC2	16		25	S-1367-2-6	S-341-1
F-CC1	16		32	S-1367-2-6	S-1367-2-6

WIRE TABLE

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

GROUP	NAME	DATE	TITLE
DRAWN	G WOOD	2-5-63	WIRING DIAGRAM -
CHECK	M. J. H. H.	4-5-63	WING FLAPS -
PROJ	M. J. H. H.	4-5-63	ELECTRIC, & FLAP
			POSITION INDICATOR


Cessna.

1270405

SUPERSEDED BY PAGE 14.3	SUPERSEDES PAGE 14.1	MODEL 2104TZ10	REV C	PAGE 14.2
-------------------------	----------------------	----------------	-------	-----------

(SR 4946)

CHG	REVISION	BY	CHK
LET		DATE	APPD
A	0740657-B WAS C301001-0101 INACTIVE DRAWING (SR 4946) (SR 4946)	GLW	APC
		10-26-65	NEW



NOTES

- 1 SWITCH SHOWN IS A MOMENTARY ON-ON-MOMENTARY ON-ON CONFIGURATION. THE MOTOR IS SHORTED WHEN THE SWITCH IS IN THE CENTER ON-ON POSITION. THE SWITCH IS SHOWN IN CENTER ON-ON POSITION.
- 2 SWITCH TERMINALS SHOWN AS VIEWED FROM TOGGLE SIDE OF SWITCH.

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
5	S-1638-2	HOUSING-CAP	
4	0740657-B	FLAP MOTOR ASSY	
3	S-1638-1	HOUSING-PLUG	
2	S-1661-1	SWITCH ASSY	
1	S-1360-15	CIRCUIT BREAKER	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
FH-CC16	16		127	S-1636-2	S-341-1
FH-CC15	16		127	S-1636-2	S-341-1
F-CC8	16		5	S-1367-2-6	S-1367-2-8
F-CC3	16		25	S-1367-2-6	S-341-1
F-CC2	16		25	S-1367-2-6	S-341-1
F-CC1	16		32	S-1367-2-6	S-1367-2-6

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

DRAWN	NAME	DATE	TITLE
3	WOOD	10-19-65	WIRING DIAGRAM—
GROUP	W. WOOD	10-19-65	WING FLAPS—
CHECK	A. J. J.	2-65	ELECTRIC
PROJ	A. J. J.	10-13-65	

Cessna.


DWG NO
1270405

SUPERSEDED BY	PAGE	SUPERSEDES	MODEL	REV	PAGE
1270405	14-3-1	1270405	PAGE 142	210 & T210	A 143

1074-ND 10-16-64

SER 21058819 & ON,
SER T210-0198 & ON

CHG LET	REVISION	BY	CHK
A	AUD E13-00M SWITCH, F-CC19 WIRE 0760657-B WAS C301001-0101. S 1493-2 1EKMAL ON F-CC11 WIRE WAS S-1367-2-G SER 21058819 & ON, SER T210-0198 & ON	GLW 5-10-66	YAK HAW HAW



NOTES:

- SWITCH SHOWN IS A "MOMENTARY ON"-ON- "MOMENTARY ON" CONFIGURATION. THE MOTOR IS SHORTED WHEN THE SWITCH IS IN THE CENTER 'ON' POSITION. THE SWITCH IS SHOWN IN THE CENTER ON POSITION.
- SWITCH TERMINALS SHOWN AS VIEWED FROM TOGGLE SIDE OF SWITCH.

8	E13-00M	SWITCH (CRYE)
7		
6	S-1638-3	HOUSING-PLUG
5	S-1638-2	HOUSING-CAP
4	0760657-B	FLAP MOTOR ASSY
3	S-1638-1	HOUSING-PLUG
2	S-1661-1	SWITCH ASSY
1	S-1360-15	CIRCUIT BREAKER
PART NO.	DESCRIPTION	INSTALLED ON

EQUIPMENT TABLE

INACTIVE
EFF THRU SER 21058819 & ON, SER T210-0308 & ON
HAW B-22-67
HAW

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
F-CC19	16			S-1493-2 S-1367-2-G	
BLK	16	S-1460-16-0		S-1635-2 S-1635-2	
ORN	16	S-1460-16-3		S-1636-2 S-1635-2	
F-CC18	16			S-1367-2-G S-1635-2	
F-CC17	16			S-1493-2 S-1635-2	
F-CC8	16		5	S-1367-2-G S-1367-2-G	
F-CC1	16		32	S-1367-2-G S-1367-2-G	

WIRE TABLE

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

NAME	DATE	TITLE
DRAWN J. HUSTON	2-2-66	
GROUP H. W. HAW	2-17-66	
CHECK R. L. LUK	2-18-66	
PROJ H. W. HAW	2-24-66	


WIRING DIAGRAM—
WING FLAPS
ELECTRIC

Cessna.


1270405

SUPERSEDED BY:	SUPERSEDES:	PAGE:	MODEL:	REV:	PAGE:
1270405, PG 14, 5	1270405	14, 3	210 & T210	A	14, 3.1

REVISION			
LET	DESCRIPTION	DATE	APPD



ORN(2)	16	-16-3	S-1493-2	S-1636-2			
BLK(2)	16	-16-0	S-1493-2	S-1636-2			
ORN(1)	16	-16-3	S-1635-2	S-1636-2			
BLK(1)	16	-16-0	S-1635-2	S-1636-2			
F-CC33	16		S-1367-1-4	S-1636-2			
F-CC32	16		S-1367-1-4	S-1636-2			
F-CC31	16		S-1367-1-4	S-1636-2			
F-CC30	16		S-1635-2	S-1367-1-4			
F-CC29	16		S-1635-2	S-1367-1-4			
F-CC28	16		S-1493-2	S-1636-2			
F-CC27	16		S-1367-1-4	S-1636-2			
F-CC26	16		S-1367-1-4	S-1636-2			
F-CC25	16		S-1367-1-4	S-1636-2			
F-CC24	16		S-1367-1-4	S-1636-2			
F-CC23	16		S-1367-1-4	S-1636-2			
F-CC22	16		S-1636-2	S-1367-1-4			
F-CC21	16		S-1635-2	S-1367-1-4			
F-CC20	16		S-1367-2-8	S-1367-1-4			
F-CC17	16		S-1493-2	S-1367-1-4			
WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS		



OPTIONAL WIRING USED WHEN RADIO IS INSTALLED

DETAIL A

9	C301001-0204	ACTUATOR ASSY	
8	C301001-0205	ACTUATOR ASSY	
7	S-1638-2	HOUSING-CAP	
6	S-1638-1	HOUSING-PLUG	
5	S-1641-6	HOUSING-SOCKET	
4	S-1640-6	HOUSING-PIN	
3	E13-00M	SWITCH	(01963)
2	E33-10K	SWITCH	(01963)
1	S-1360-15	CIRCUIT BREAKER	
ITEM NO.	PART NO.	DESCRIPTION	VENDOR
EQUIPMENT TABLE			

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX=CESSNA SPEC. NO.
S-XXX OR CMXXXX=CESSNA
STD. NO.

SUPERSEDES:
1270405 PAGE 14.3, 1
10.2, 1


SUPERSEDED BY:

CONTRACT NO.	
DESIGN	G. WOOD
GROUP	H. WOOD
DRAWN	J. HUSTON
CHECK	YAKS-HAW
STRESS	and
PROJECT	7-19-67
APPD	8-24-67

WIRE TABLE			
NAME	DATE	TITLE	
G. WOOD	7-19-67	WIRING DIAGRAM - WING FLAPS	
H. WOOD	8-21-67		
J. HUSTON	7-19-67		
YAKS-HAW	8-24-67		
and	8-24-67		
SIZE	CODE IDENT. NO.	DWG NO.	
C	71379	1270405	
SCALE: NONE	SER 21058337 ON	PAGE: 14.5	

COMMERCIAL AIRCRAFT DIV.
5800 E. PAWNEE
WICHITA, KANSAS

Cessna AIRCRAFT CO.



CHG LET	REVISION	BY	CHK
A	BY REV: ADD NOTE 3 & 5. SER 21058937 ON, SER T210-0308 ON	JWH	YAC
B	BY REV: ADD 1270057-1, F-CD8, NOTE 4 & 5-1635-1 & 5-1637-1 TERMINALS TO F-CD4 WIRE; 1560332-25 WAS 1560332-26 EDRR 01362 SER 210-5916 ON, SER T210-0338 ON	CG	RES
C	BY REV: ADD 1409, SER OUT 1270057-1 & DELETE NOTE 4; ADD DETAIL A & NOTE 5 EDRR 01958 (SR5747)	JEL	RES

NOTES:

- WITH RED MOTOR LEAD NEGATIVE & BLACK LEAD POSITIVE, MOTOR WILL ROTATE IN A CLOCKWISE DIRECTION (LOOKING INTO SHaft) THIS GIVES A "NOSE".
- BLK GND WIRE IS DESCRIBED ON 1270475, PG 2.47.0
- PART NO. IS 328636, VENDOR CODE IS 00779.
- VENDOR FOR 1409 VOLTAGE REGULATOR IS ADVANCED AVIONICS P.O. BOX 188 AUGUSTA, KANSAS

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
7	1409	VOLTAGE REG.	5
6	1270057-1	RES & DIODE ASSY	4
5	7271-8-3	CKT BKR	(B26A7)
4	150141-2	FUSE ASSY	
3	8-171	TERM BLOCK	(11785)
2	1560321-12	CLUTCH	
1	1560322-25	MOTOR ASSY	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
F-CD8	18			5-1635-1	5-1636-3
F-CD7	18			5-1637-1	5-1637-2
F-CD5	20			5-1637-1	5-1637-2
F-CD4	20			5-1637-1	5-1637-2
F-CD3	20			5-1637-1	5-1637-2
F-CD2	20			5-1637-1	5-1637-2
F-CD1	20			5-1637-1	5-1637-2
F-CD7	18			5-1637-1	5-1637-2

WIRE TABLE

NAME	DATE	TITLE
WIRE	7-28-67	WIRING DIAGRAM—
GROUP	7-29-67	ELECTRIC ELEVATOR
CHECK	7-29-67	TRIM (OPTIONAL)
PROJ	7-29-67	
SUPERSEDED BY		
SUPERSEDES		
MODEL	210-T210	REV: C
PAGE	14.6	

Cessna.

1270405


SER 21058937 ON, SER T210-0308 ON

WARNING AND EMERGENCY SECTION

Cessna.

DRAWN <i>RIDDER</i>		TITLE: WIRING DIAGRAM--- MODEL 210	DRAWING NO.
DATE 10-23-62			1270405
APP'D <i>KES jmc</i>	REV:		PAGE: 15.0
CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.			

CHG LET	REVISION	BY	CHK
A	ADDED WIRE LENGTHS TO W/T, REMOVED 1270429-1 & F-DB1 FROM E/T	WJB 8-15-64	RKS 7M



*Inactive
SER 21058236: ON
3-22-63
GWR
RKS
HME*

F-GCB	18	14	5-1367-1-6	5-1367-1-8	
F-GCI	18	16	5-1367-1-8	5-1367-1-6	INACTIVE SER 21058236: ON
F-RP2	18		5-1367-1-6	5-341-2	INACTIVE SER 21058236: ON
F-FC2	18	115	5-1367-1-6	5-341-2	
F-FC1	18	57	5-1367-1-6	5-341-2	
WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
7	S-131B-1	INDICATOR, FLAP POS	
6			
5	CA-2	CKT BKR (MTCC)	
4			
3	0511062-4	XMTR, STALL WARN	
2	1270035-1	WARNING SPKR	
1	1213239-1	WARNING UNIT	

EQUIPMENT TABLE


WIRE TABLE			
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS			
DRAWN	NAME	DATE	TITLE
RIDDER		7-17-62	WIRING DIAGRAM —
CHECK		10-14-62	STALL WARNING
		10-25-62	SYSTEM (NON-
		11-2-62	HEATED)
SUPERSEDED BY	DAGE	SUPERSEDES	MODEL
1270405	15-1-61		210
REV	A	PAGE	151

Cessna.

DWG NO. 1270405

(SR 4203)

CHG LET	REVISION	BY	CHK
		DATE	APPRO
A	ADDED WIRE LENGTHS TO W/T; REMOVED 1270461-1 & F-GC9 FROM EIT; OBSOLETE F-FC2; HF-FC3 WAS F-FC2 (SR4455)	WJR 8-15-64	PPS NM NAC



Inactive SER 21058819 & ON
T210-0198 & ON

1-28-66
4 PW 2-17-66
PPS 1/1/11

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
8			
7			
6			
5	CA-2	CIRCUIT BREAKER (MTCC)	
4			
3	0511062-4	XMTR, STALL WARN	
2			
1	1213242-1	WARNING UNIT	

EQUIPMENT TABLE

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
HF-FC3	18		100	5-1367-1-6	5-341-2
F-GCB	18		14	5-1367-1-6	5-1367-1-8
F-FC2	18		115	5-1367-1-6	5-341-2
F-FC1	18		57	5-1367-1-6	5-342-1

WIRE TABLE


CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS


NAME	DATE	TITLE
DRAWN: G WOOD	3-22-63	WIRING DIAGRAM —
GROUP: J. L. 1/1/11	4-1-63	STALL WARNING
CHECK: P. L. 1/1/11	4-1-63	SYSTEM (NON-
PROJ: H. L. 1/1/11	4-1-63	HEATED)


Cessna.

DWG NO.
1270405SUPERSEDED BY: 1270405 15-1.2 PAGE 15.1
MODEL 210
REV A PAGE 15.1.1

CHG LET	REVISION	BY	CHK
		DATE	APPRO



WIRE TABLE					
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS					
NAME	DATE	TITLE	 DWS NO: 1270405		
DRAWN: RIDDER	1-6-66	WIRING DIAGRAM— STALL WARNING SYSTEM (NON- HEATED)			
GROUP: H. H. W.	2-17-66				
CHECK: H. H. W.	2-17-66				
PROJ: H. H. W.	2-17-66				
SUPERSEDED BY	SUPERSIDE	PLATE	MODEL	REV.	PAGE
	1270405	15	210 & T210		15.1, 2



NOTES:

- GEAR DOWN SWITCHES ARE CLOSED WHEN GEARS ARE LOCKED DOWN.
- SWITCH IS CLOSED WHEN THROTTLE IS CLOSED I.E. ENGINE POWER IS REDUCED.
- SEE PAGE 12.1 FOR GEAR UP LIMIT SWITCHES.

CHG LET	REVISION	BY	CHK
A	ADDED WIRE LENGTHS TO W/T; REMOVED 1270429-1, F-DB1, F-GC1 & F-GC8;	WJR	APD
B	BY REVISION: REVISED SYMBOLS FOR ITEMS 10 & 11	GLW	YAK

Inactive
SER 21058221 & ON
2-22-63
JW
HMC

ITEM NO	PART NO.	DESCRIPTION	INSTALLED ON
15	10-3222	SWITCH (LITW)	
14	AN 3436-2-6	TERMINAL	
13	65-430001	SWITCH (LITW)	
12	AN 3234-2	SWITCH	
11	VM911M-2A	LIGHT ASSY(MARI)	
10	VM920M-3	LIGHT ASSY(MARI)	
9	MS3106A-145-23	PLUG	
8	S-1232-10	CIRCUIT BREAKER	
7			
6	CA-2	CKT BKR (MTCC)	
5			
4	S-1318-1	INDICATOR, FLAP POS	
3			
2			
1	1213239-1	WARNING UNIT	

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-GEG	20		6	S-1367-1-6	SOLDER
F-GE5	20		26	SOLDER	SOLDER
F-GE4	18		3	SOLDER	SOLDER
F-GD6	18		164	S-1367-1-4	SOLDER
F-GD5	18		80	S-1367-1-4	S-1367-1-4
F-GD4	18		205	S-1367-1-4	S-1367-1-4
F-GD1	18		65	S-1367-1-8	S-1367-1-6
F-GC4	18		38	S-1367-1-6	SOLDER
F-GC3	18		10	S-1367-1-4	S-1367-1-6
F-GC2	18		58	S-1367-1-4	S-1367-1-6


WIRE TABLE

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

DRAWN	NAME	DATE	TITLE
RIDDER		7-18-62	WIRING DIAGRAM - GEAR WARNING SYSTEM
CHECK	NAME	DATE	
W. H. H.		10-25-62	
PROJ	NAME	DATE	
W. H. H.		11-2-62	
SUPERSEDED BY	SUPERSEDES	MODEL	210
1270405 PAGE 15.2.1		REV	B
		PAGE	15.2

Cessna.

DWG NO: 1270405



MISCELLANEOUS SECTION


Cessna.

DRAWING NO.

1270405

DRAWN GLW TITLE: WIRING DIAGRAM---

DATE 9-5-63 MODEL 210


APP'D *RRS* REV:

PAGE: 16.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

(SR 4204)

CHG LET	REVISION	BY	CHK
		DATE	APPD
A	ADDED WIRE LENGTHS TO W/T REMOVED 1270461-1 FROM E/T	WJR 8-18-64	WJR 1/2



NOTES:

- COLOR CODED WIRES ARE VENDOR FURNISHED.
- WIRES ESTABLISHED ON THIS PAGE ARE USED ALSO ON MODELS 205-206 & 182. REF 1270625 PAGE 16.1 & 0770610 PAGE 16.1 FOR RESPECTIVE WIRING DIAGRAMS.

ITEM NO	PART NO.	DESCRIPTION	INSTALLED ON
5			
4	S-1360-15	CIRCUIT BREAKER	
3	1414249-2	MOTOR ASSY	
2	S-1491-1	BUSHING-TERMINAL	
1	1414268-1	SWITCH ASSY	

EQUIPMENT TABLE

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
F-MB4	16		131	S-1493-2	S-13672-6	0700718
F-MB3	16		12	S-1493-2	S-13672-6	0700718
F-MB2	16		26	S-1493-2	S-1493-2	0700718
F-MB1	16		113	S-13672-6	S-1493-2	0700718

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

DRAWN	NAME	DATE	TITLE
G. WOOD		8-28-63	WIRING DIAGRAM —
CHECK			VERTICALLY
PROJ			ADJUSTING SEAT
			(OPT)

Cessna.

1270405

SUPERSEDED BY	SUPERSEDES	MODEL	REV	PAGE
		210	A	16.1

FORM NO. 80-161



WIRING DIAGRAM

MODEL 206 Series

DWG. NO. 1270625

TABLE OF CONTENTS

PAGE NO.	TITLE	DATE ISSUED	REV
1.0	<u>Title Page</u>		
2.0	<u>Table of Contents</u>	3-15-68	
2.1	<u>Table of Contents</u>	3-15-68	
2.2	<u>Table of Contents</u>	3-15-68	
3.0	<u>Notes</u>	5-1-64	C
4.0	<u>D.C. Power</u>		
4.1	Battery & External Power System	3-3-65	D-Inac.
4.1.1	Battery & External Power System	1-31-67	D
4.2	Generator System	5-1-64	Inac.
4.3	Alternator System, 52 AMP	3-3-65	B-Inac.
4.4	Wiring Diagram - Alternator System, 60 AMP	7-8-66	B-Inac.
4.5	Split Bus Bar	2-9-66	NC
4.6	Wiring Diagram - Alternator System, 60 AMP	7-10-67	A
5.0	<u>Ignition</u>		
5.1	Ignition System	11-16-65	E
6.0	<u>Engine Control</u>		
6.1	Starter System	8-20-64	C
7.0	<u>Fuel & Oil</u>		
7.1	Fuel Pump System	8-20-64	E
7.2	Oil Dilution System (Opt.)	5-28-65	E



TITLE: WIRING DIAGRAM---
MODEL 205, P206, U206

DRAWING NO.

1270625

DATE: 3-15-68

PAGE: 2.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

TABLE OF CONTENTS

PAGE NO.	TITLE	DATE ISSUED	REV
8.0	<u>Engine Instruments</u>		
8.1	Cyl. Head Temp	8-20-64	E
8.2	Fuel Quantity Indicator	8-20-64	C
8.3	Hourmeter (Opt.)	9-29-66	NC
9.0	<u>Flight Instruments</u>		
9.1	Turn & Bank & Gyro Horizon Indicator	8-20-64	C
9.2	Stall Warning System (Non-heated)	6-29-66	F
9.3	W.D. - Brittain Wing Leveler (Opt.)	6-7-67	NC
9.4	Wiring Diagram - Turn Coordinator	9-25-67	NC
10.0	<u>Other Instruments</u>		
10.1	Clock	5-28-65	F
10.2	Wiring Diagram - Flap Position Indicator	2-24-66	A
11.0	<u>Lighting</u>		
11.1	Dome & Courtesy Lights	2-24-66	D
11.2	Instrument Lights	7-10-67	F
11.3	Landing Lights	2-24-66	E
11.4	Navigation Lights	1-16-68	F
11.5	Rotating Beacon	1-29-66	C-Inac
11.5.1	Flashing Beacon Lights	3-30-67	A
11.5.2	Flashing Beacon Light (Floatplane)	3-30-67	NC
11.6	Map Light (Opt.)	9-8-64	A-Inac
11.6.1	Map Light	7-10-67	B
11.7	Post Lighting & Back Lighting (Opt.)	9-29-66	B-Inac
11.8	Nav-O-Matic 300 Post Light (Opt.)	11-17-64	Inac.
11.9	Back Lighting	9-29-66	NC
11.10	Post Lighting (Opt.)	11-27-67	B
11.11	Map Light, Control Wheel (12 Volt)	9-25-67	NC
11.12	Skydiving Signal Light	7-10-67	NC
12.0	<u>Not Used</u>		

Cessna.

TITLE: WIRING DIAGRAM---
MODEL 205, P206, U206

DRAWING NO.


1270625

DATE: 3-15-68

PAGE: 2.1

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

TABLE OF CONTENTS

PAGE NO.	TITLE	DATE ISSUED	REV
13.0	<u>Heating, Venting & De-icing</u>		
13.1	Cigar Lighter	9-8-64	D
13.2	Heated Pitot Tube & Heated Stall (Warning System, (Opt.))	10-4-66	E
14.0	<u>Control Surface</u>		
14.1	Wing Flaps	10-26-65	G-Inac.
14.1.1	Wing Flaps (Floatplane) (Opt.)	10-26-65	G-Inac.
14.1.2	Wing Flaps	10-26-65	G-Inac.
14.1.3	Wing Flaps (Floatplane) (Opt.)	10-26-65	G-Inac.
14.2.0	Wiring Diagram - Wing Flaps	2-24-66	A
14.2.1	Wiring Diagram - Wing Flaps (Floatplane) (Opt.)	9-13-67	A-Inac.
14.2.2	Wiring Diagram - Wing Flaps	9-13-67	A-Inac.
14.2.3	Wiring Diagram - Wing Flaps (Floatplane) (Opt.)	9-13-67	A-Inac.
14.3	Wiring Diagram - Wing Flaps	9-13-67	NC
14.4	Electric Elevator Trim (Optional)	8-31-67	A
15.0	<u>Not Used</u>		
16.0	<u>Miscellaneous Section</u>		
16.1	Vertically Adjusting Seat (Opt.)	9-8-64	A
		DRAWING NO.	
TITLE: WIRING DIAGRAM--- MODEL 205, P206, U206		1270625	
DATE: 3-15-68		PAGE: 2.2	
CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.			

NOTES

1. WIRE CODE DESIGNATIONS PER CES 1100.
2. WIRE CODE APPLICATION AND WIRE LENGTH TOLERANCES PER CES 1015.
3. "S" SUFFIX ON WIRE GAUGE IN WIRE TABLE DENOTES SHIELDED WIRE.
- (B) 4. "DS" suffix on wire gauge in wire table denotes double-shielded wire per S-1462.
5. NON-SHIELDED WIRES TO BE PER S-1460 white. Wires 10-gauge and larger to be Type II construction.
- (C) 5. SHIELDED WIRES TO BE PER S-1461 white, unless designated otherwise by note on the field of the wiring diagram.
6. Part numbers shown in the "equipment table" of the various pages are for reference only, and do not constitute a material requirement unless specifically noted on the individual page. Refer to the various equipment installation drawings for verification of part numbers.
7. Equipment part numbers shown on the various pages that are for reference only, (see Note 6), will not be changed unless it affects wire terminals and fabrication.
8. Vendor codes per S-1400. Vendor codes are shown in parentheses.
9. Wires noted herein as ("opt") are optional to the standard airplane.
10. All wires not specified as ("opt") are to be installed as standard equipment. The airplane assembly will specify the additional equipment required for deluxe versions.
11. When ("opt") is used in the title block of a diagram, all wires shown therein are optional except where noted as ("std").

Cessna.

DRAWING NO.

DRAWN	WJR	TITLE: WIRING DIAGRAM--- MODEL 205 & 206 SERIES
DATE	4-23-64	
APP'D	RES and B HML	

1270625

REV D

PAGE: 3.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

FORM NO. 80-160

D. C. POWER SECTION

Cessna.

DRAWING NO.

1270625

PAGE: 4.0


DRAWN	G WOOD	TITLE: WIRING DIAGRAM---
DATE	1-25-62	MODEL 205 & 206

APP'D	<i>W. W. RRS</i>	REV:
-------	------------------	------

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

(SR 3694-10)

CHG	REVISION	BY	CHK
LET		DATE	APPRO
A	REMOVED N/A FROM STD WIRES. ADD (OPT) TO OPT WIRES (SR3694-10)	GLW	2/23
B	ADD MODEL 20G 1270461-1 BUS BAR ADD 1213505-16-2 INST CLUSTER 5-1360-50 CIRCUIT BREAKER ADDED DETAIL A (SR3983-6)(SR4038-6)	GLW	2/23
C	ADD 5-550B KLIPVOLT SUPPRESSOR (SR 447B)	GLW	2/23
D	ADDED LIMITING SERIALS TO FIELD; REMOVED 1270461-1 S-1360 FROM E/T; ADDED WIRE LENGTHS TO WIT; ADDED F206 & U206 TO MCLELL BLOCK; C667502-0104 WAS 1213505-1 & 1213505-2 (SR4456) & (SR4457)	WJR	2/23



INACTIVE
SER: 206-0164 & 206-0438 FOR
1-4-16
1-2-16
1-3-16
1-4-16
1-5-16
1-6-16
1-7-16
1-8-16
1-9-16
1-10-16

EFFECTIVE THRU SER U206-0276
P206-0001

ITEM NO	PART NO	DESCRIPTION
13	5-550B	KLIPVOLT SUPPRESSOR (SATA)
12	0713602-1	INST CLUSTER
11		
10	CA-2	CKT BKR (MTCC)
9		
8	0750027-1	START. SOLENOID
7	AN2552-3A	RECEPTACLE
6		
5	5-1360-50	CIRCUIT BREAKER
4	C669502-0104	INST CLUSTER KIT
3	5-1159-1-1	SWITCH (MASTER)
2	0712603-2	CONTACTOR, BAT.
1	0712605-1	BATTERY

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
H-DC1	2					
H-DA2	8					
H-DA1	3					
H-PA6	18					
H-PA5	18					
H-PA4	18					
H-PA3	2					
H-PA2	2					
H-PA1	2					

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

DRAWN	NAME	DATE	TITLE
3	W200	12-6-61	WIRING DIAGRAM—
GROUP	W200	1-9-62	BATTERY & EXTERNAL
CHECK	W200	2-7-62	POWER SYSTEMS
PROJ	W200	2-7-62	

Cessna.

DWS NO. 1270625


SUPERSEDED BY	SUPERSEDES	MODEL	REV.	PAGE
1270625 P6 4.1.1		205, P206 & U206	D	4.1

NOTES:


(SR 3694-10)

- 1 S-1367-2-6 TERMINAL ON SHIELDS.
- 2 S-1367-2-12 TERMINAL ON SHIELD.
- 3 PART OF 1250600 ENGINE INSTALLATION.

CHG LET	REVISION	BY	CHK
		DATE	APPD
A	REMOVED N/A FROM STD WIRES. ADD (OPT) TO OPT WIRES. (SR3694-10)	GLW 4-2-62	CCS
B	ADD MODEL 206 1270461-1 BUS BAR WAS 1270423-1 S-1360-50 CKT BKR WAS S-1336-50 (SR 3583-6) (SR 4039-6)	GLW 6-17-63	CCS NHL LW



Inactive
W.D.R.
SR P206-0657 FOR
P206-0307 FOR
3-26-64
T.M. NMC



WHEN RADIO NOISE FILTER (OPT)
IS REQD, REPLACE H-PB2 AS SHOWN

ITEM NO	PART NO	DESCRIPTION	SERIALS
7	145329	NOISE FILTER (SPR)	
6	H-PAG	WIRE	
5	3	GENERATOR	
4	0413205-11	REGULATOR	
3	S-1159-1-1	SWITCH, MASTER	
2	S-1360-50	CIRCUIT BREAKER	
1	1270461-1	BUS BAR	
EQUIPMENT TABLE			


WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
H-PB6	8			S-1367-4-12 S-1367-4-10	270635 (OPT)	
H-PB5	8			S-1367-4-10 S-1367-4-10	270635 (OPT)	
H-PB4	185			S-1367-1-6 S-1367-1-10		
H-PB3	185			S-1367-1-6 S-1367-1-12		
H-PB2	8			S-1367-4-12 S-1367-4-10		
H-PB1	8			S-1367-4-8 S-1367-4-10		
WIRE TABLE						
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS						
DRAWN	G WOOD	DATE	12-7-61	TITLE		
GROUP	W.D.R.	DATE	1-21-62	WIRING DIAGRAM —		
CHECK	R. Stuck	DATE	3-5-62	GENERATOR		
PROJ	NHL	DATE	2-2-62	SYSTEM		
SUPERSEDED BY 1270625				MODEL		205, 206
PAGE 4.3				REV		B
				PAGE		4.2

Cessna.

DWG NO: 1270625

(SR 4456)
(SR 4457)

CHG LET	REVISION	BY	CHK
		DATE	APPD
A	BY REV: CHANGED WIRE CODE D-PB WAS D-DP (SR4456) (SR4457) S-B-6A	WJR	RES
B	BY REV: C5-FF-10A-568A WAS C4-FF- 10A-568A; 1250209-1 WAS 0770038-2 DWG. INACTIVE (SR4459) (SR4460)	J.J.B	RES



STANDARD

NOTES:

1. TERMINALS C3XB-14462A & B-14463 ARE (FOR) PART NUMBERS.
2. "D" PREFIX USED ON THIS DRAWING INSTEAD OF "H" BECAUSE WIRES ARE SAME AS THOSE USED IN MODEL 182. THIS DRAWING IS SCHEMATICALLY IDENTICAL TO 0770610 PAGE 4.4 AND IS FOR REF ONLY.
3. 8 GAUGE SHIELDED WIRE MATERIAL PER S-1534.
4. OBSERVE POLARITY SYMBOL ON DIODE ASSY WHEN INSTALLING ON SWITCH TERMINALS OR DIODE WILL FAIL WHEN SYSTEM IS ENERGIZED.

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
9	1250209-1	FILTER ASSY	
8	C5-FF-10A-568A	PLUG ASSY (FOR)	
7	145329	NOISE FILTER (SPR)	
6	0770719-1	DIODE ASSY	
5	S-1159-1-1	SWITCH - MASTER	
4	0750216-1	REGULATOR ASSY	
3	S-1360-50	CIRCUIT BREAKER	
2	0750217-1	ALTERNATOR ASSY	
1	0770038-2	FILTER	



EQUIPMENT TABLE

WIRE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
JUMPER 1B					
D-PB16 BS	3				
D-PB15 BS	3				
D-PB14 10					
D-PB13 18S					
D-PB12 18					
D-PE11 BS	3				
WIRE TABLE					
CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS					
DRAWN	NAME	DATE	TITLE		
GROUP	RIDDER	3-26-69	WIRING DIAGRAM—		
CHECK	W. H. H. H.	4-30-69	ALTERNATOR		
PROJ	W. H. H. H.	5-1-69	SYSTEM, 52 AMP		
SUPERSEDED BY 1270625				MODEL	205 g 206
PAGE 4.4				REV	B
				PAGE	4.3

INACTIVE
SR P206-0637 EOW & P206-0307 EOW
1-6-66 LRB
1-20-66 NEW RES
m.c.

(SR 4659)
(SR 4660)

CHG	REVISION	BY	CHK
LET		DATE	APPD
A	FH-PB20 WAS DFH-PB20; FH-PB22 WAS DFH-PB22; FH-PB24 WAS DFH-PB24; FH-PB25 WAS DFH-PB25; S-1629-1 WAS 145329; IN S-41796 WAS 42281-2; IN EIT 0770038-2 WAS 0770038-1 ADDED (OPT) TO FH-PB24 & FH-PB25 (SR 4659) & (SR 4660)	WJR	ERS ALA
B	ADDED C611001-0101 DETAIL A (SR 5206)	WJR	WJR



DETAIL A
SER P206-0257 ON
U206-0585 ON
T210-0169 ON
(SR 5200) ON
WJR
4/10
H. H. H
JAK

NOTES:

1. "D" PREFIX IS USED ON THESE WIRES INSTEAD OF "H" BECAUSE WIRES ARE THE SAME AS THOSE USED IN MODEL 182. THIS DRAWING IS SCHEMATICALLY IDENTICAL TO 0770610 PAGE 4.5.
2. 8 GAUGE SHIELDED WIRE MATERIAL PER 0-534-8-9.
3. OBSERVE POLARITY SYMBOL ON DIODE ASSY WHEN INSTALLING ON SWITCH TERMINALS OR CODE WIRE FROM GEN SYSTEM IS ENERGIZED.
4. AMP TERMINAL 41796 (APP).

Q	C611001-0101	REGULATOR	
8	1250211-1	PLUG ASSY	
7	S-1629-1	NOISE FILTER	
6	0710719-1	DIODE ASSY	
5	S-1159-1-1	SWITCH-VASTER	
4	0750216-1	REGULATOR ASSY	
3	S-1596-60	CIRCUIT BREAKER	
2	C611001-0101	ALTERNATOR ASSY	
1	0770038-2	FILTER	

EQUIPMENT TABLE

WIRE	CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
D-PB29	16		SOLDER	S-1367-2-12	1250211	
D-PB28	18S		S-1367-1-12	4	1250211	
D-PB27	18S		S-1367-1-6	4	1250211	
D-PB26	18S		S-1367-1-6	4	1250211	
FH-PB25	8S		S-1367-1-10	4	1250211	
FH-PB24	8S		S-1367-1-10	4	1250211	
DFH-PB23	10		S-1367-3-13	S-1367-3-12	(OPT)	
FH-PB22	18S		S-1367-1-6	S-1367-1-6	(OPT)	
DFH-PB21	18		S-1367-1-6	S-1367-1-10		
FH-PB20	8S		S-1367-1-10	S-1367-1-10		

WIRE TABLE

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS


DRAWN	NAME	DATE	TITLE
BREE W	4/10/64		WIRING DIAGRAM—
GROUP	4/10/64		ALTERNATOR
PRO	4/10/64		SYSTEM 60 AMP
REV	1-28-65		

Cessna.

1270625


1270625 PG 4.6	1270625 PAGE 4.3	P206 f U206	REV B	PAGE 4.4
----------------	------------------	-------------	-------	----------

(SR 4901)
(SR 4902)

FORM NO. 10-14

(SR5200)

CNS LET	REVISION	BY DATE	CHK APP
A	ADDED DETAIL A; D-PB30, D-PB31, CA-2 (ITEM 9), INACT. DFH-PB21 (SR5158, SR5159) (ON)	VRS 02/7/67	100- 100- 100- 100-



NOTES:

1. AMP TERMINAL 42281-2 ON CONDUCTOR.
AMP TERMINAL 2-323931-2 ON SHIELD & GROUNDING WIRE.
2. 8 GAUGE SHIELDED WIRE MATERIAL PER S-1534-8-9.
3. OBSERVE POLARITY SYMBOL ON DIODE WHEN INSTALLING ON SWITCH TERMINALS OR DIODE WILL FAIL WHEN SYSTEM IS ENERGIZED.
"D" PREFIX IS USED ON THESE WIRES INSTEAD OF "F". THESE WIRES ARE THE SAME AS THOSE USED IN 182. THIS DWG IS SCHEMATICALLY IDENTICAL TO 0770610 P. 4.7.

PART NO.	DESCRIPTION	INSTALLED ON
9	CA-2	CKT BKR (80602)
8	C6AB-10A730A	HOUSING (ECWB)
7	S-1629-1	NOISE FILTER
6	0770719-1	DIODE ASSY
5	S-1159-1-1	SWITCH-MASTER
4	S-1596-60	CIRCUIT BREAKER
3	0770038-2	FILTER
2	C611001-0101	REGULATOR
1	C611501-0101	ALTERNATOR ASSY

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LB	TERMINALS	SERIALS
DFH-PB30		5-1367-1-8	5-1367-1-10		SER(SR5158) ? SR5159 (ON)
D-PB29	18	5-1367-1-12		1	
D-PB28	18S	5-1367-1-8			
D-PB27	18S	5-1367-1-8			
D-PB26	18S	5-1367-1-8			
DH-PB25	8S	5-1367-1-8	5-1367-1-10		INACTIVE (SR 5158, SR5159) (ON)
DH-PB24	8S	5-1367-1-8	5-1367-1-10		INACTIVE (SR 5158, SR5159) (ON)
DFH-PB23	10	5-1367-3-10	5-1367-3-10		
DH-PB22	18S	5-1367-1-8	5-1367-1-10		INACTIVE (SR 5158, SR5159) (ON)
DFH-PB21	18	5-1367-1-6	5-1367-1-10		INACTIVE (SR 5158, SR5159) (ON)
DH-PB20	8S	5-1367-1-6	5-1367-1-10		INACTIVE (SR 5158, SR5159) (ON)

WIRE TABLE

Cessna Aircraft Co. COMMERCIAL AIRPLANE DIVISION, WICHITA, KANSAS

NAME	DATE	TITLE
DRAWN ACKERSON	5-3-66	WIRING DIAGRAM -
CHECK H. W. 6.6	6-3-66	ALTERNATOR
CHECK YAKSHAW	6-30-66	SYSTEM,
PROJ. H. W. 6.6	7-7-66	60 AMP
SUPERSEDED BY	SUPERSEDER	MODEL 206
REV. A	PAGE: 4.6	

Cessna.


DWG NO:
1270625

1000 NO 00 1014

IGNITION SECTION

Cessna.

DRAWING NO.	
1270625	
DRAWN	G WOOD
DATE	1-25-62
TITLE: WIRING DIAGRAM---	
MODEL 205 & 206	
APP'D	REV:
NEW 0/11 RRS [signature]	
PAGE: 5.0	
CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.	




NOTES:

1. TERMINATE WITH 7.
2. SHORTING BAR BETWEEN R* AND UNMARKED TERMINAL ADJACENT TO IT IS NOT USED FOR THIS CIRCUIT.
3. TERMINATE SHIELDS ON JA-1 & JA-2 WIRES AT THE SWITCH WITH S-1367-2-6 TERMINALS & CONNECT TO "GRD"
4. TERMINAL ON SWITCH S-1367-1-10 ON HOT LEAD, S-1367-3-10 ON SHIELD

(SR 3694-10)

CHG	REVISION	BY	DATE	CHK
LET				
A	REMOVED N/A FROM STD WIRES 0713129-1 WAS S-1235-1 ADD NOTE 2 & 3 REMOVED PUSH FROM SWITCH POSITIONS ADD SHIELDED WIRE TO JA1 & JA2 WIRES ADD NOTE 4 (SR 3694-10)	GLW	4-2-62	PLS
B	BDS WAS IBS MATERIAL ON JA1 & JA2 WIRES	GLW	10-17-62	PLS
C	ADD MODEL 206 1270461-1 BUS BAR WAS 1270429-1 S-1360-10 CKT BKR WAS S-1232-10 ON BUS BAR; INST WAS INST LIGHTS (SR 4038-6) (SR 3985-6)	GLW	6-17-63	PLS
D	ADDED PROG 2 U706 TO MODEL BLOCK REMOVED 1270461-1 BUS BAR, H-KA1 & H-KA2 FROM E/T; ADDED WIRE LENGTHS TO W/T	WJR	6-26-64	PLS
E	ON WIRES H-JA1 & H-JA2, 18-5 WIRE WAS 18-05	GLW	11-1-65	PLS



ITEM NO.	PART NO.	DESCRIPTION	SERIALS
9	S-1360-10	CIRCUIT BREAKER	
8			
7			
6			
5	0750027-1	START SOLENOID	
4	SUCK #662	RIGHT MAGNETO	
3	SLICK #662	LEFT MAGNETO	
2			
1	0713129-1	SWITCH	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
H-JA3	18			9 S-1367-1-6S-1367-1-8	
H-JA2	18-5			63 S-1367-1-6	
H-JA1	18-5			63 S-1367-1-6	

WIRE TABLE			
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS			
DRAWN	NAME	DATE	TITLE
G WOOD		12-7-61	WIRING DIAGRAM — IGNITION SYSTEM
CHECK	NAME	DATE	
W. W. W.		1-10-62	
PROJ.	NAME	DATE	
H. W. W.		2-3-62	
SUPERSEDED BY	SUPERSEDES	MODEL	REV
		205, P206, U206	E

Cessna.

DWG NO. 1270625

PAGE: 5.1

FORM NO. 10-61

ENGINE CONTROL SECTION


Cessna.

DRAWING NO:		1270625	
DRAWN	G WOOD	TITLE: WIRING DIAGRAM---	
DATE	1-25-62	MODEL 205, P206 & U206	
APP'D	REV: A		PAGE: 6.0
CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.			

SER 205-0001 THRU
SER 205-0517
SER 206-0001 THRU
SER 206-0275
SER 206-0001 & ON
SER 206-0001 & ON

NOTE:

PART OF 1250600 ENGINE
INSTALLATION.



CHG LET	REVISION	DATE	BY
A	REMOVED N/A FROM STD WIRES 0713129-1 WAS 5-1255-1 (SR654-0)	4-3-62	GLW
B	ADD MODE. 208 5-1360-10 CMT BKR WAS 5-1222-10 1270461-1 BUS BAR WAS 1270461-1 ON BUS BAR, INST WAS INST LIGHTS (SR4038-6) (SR3983-6)	5-17-63	GLW
C	REMOVED 1270461-1 BUS BAR FROM E/T; ADDED 4202 E U 206 TO E/T; REMOVED 4-FAS FROM E/T; ADDED WIRE LENGTHS TO W/T	6-27-64	GLW
D	BY REV: ADD DETAIL A, 1570043-1 & H-KA4 ED ERR 10279	PER 23-68	GLW
E	BY REV: ADD DETAIL 'B' & 'C', 5-1673-1, 5-1391-1 & SR; SER OUT 0750027-1 ED ERR 10465 (SR6222)	MDS 5-23-68	GLW
F	BY REV: C292601-0101 WAS 0713129-1; SER OUT C292601-0101, SER IN C292601-0105; SER OUT 5-1360-10, SER IN 5-1360-10L (SR7126), (SR6766) (REF)	RLY 8-1-72	GLW
G	BY REV: ADD PG 6.1.1 & DETAIL 'C' & SER (SR6259)	RS 6-12-75	GLW

ITEM NO.	PART NO.	DESCRIPTION	SERIALS
10	5-1360-10L	CIRCUIT BKR	
9	C292601-0105	IGNITION SWITCH	
8	5-1391-1	CONTACTOR	
7	1570043	CODE ASSY	
6	5-1360-10	CIRCUIT BREAKER	
5	C292601-0101	SWITCH, MAG	
4	11	STARTER	
3	0750027-1	START. SOLENOID	
2	5-1673-1	CONTACTOR	
1	0712602-2	BAT. CONTACTOR	

EQUIPMENT TABLE

WIRE CODE NO.	SA	MATERIAL	LG	TERMINALS	SERIALS
H-KA4	18			SEE KAZ	5-1393-1
H-KA3	2			12 5-1367-145-1367-14	
H-KA2	18			89 5-1367-165-1367-16	
H-KA1	18			8 5-1367-165-1367-16	

WIRE TABLE

NAME	DATE	FILE
ENGINEER	GWOOD	12-6-61
GROUP	NEW	12-6-62
CHIEF	W. J. J.	12-5-62
WIRE	W. J. J.	12-2-62

WIRING DIAGRAM —
STARTER SYSTEM

Cessna.

1270625

SUPERSEDED BY	SUPERSEDES	MODEL	REV	PAGE
		205, PCC & EU206	F	6.1.0

FUEL AND OIL SECTION

Cessna.

DRAWING NO.

1270625

PAGE: 7.0


DRAWN G WOOD TITLE: WIRING DIAGRAM---

DATE 1-25-62 MODEL 205 & 206

APP'D

REV:

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.



NOTE:

▷ F" PREFIX USED ON THIS DRAWING
INSTEAD OF "H" BECAUSE WIRES ARE
SAME AS THOSE USED IN MODEL 210.
THIS DIAGRAM IS SCHEMATICALLY
IDENTICAL TO 17045E PAGE 7.2.

(SR 3694-10)

CHG LET	REVISION	BY	CHK
A	ADD OPT TO TITLE (SR 3694-10)	GLW	APD
B	ADD MODEL 206 S-1360-10 CIR BAR WAS S-1232-10 1270461-1 BUS BAR WAS 127041-2 (S-1232-10 WAS 1232-10)	GLW	APD
C	CHANGED SERVICE WIRE FROM 1270461-1 TO 127041-2, REASONING WAS 127041-2 WAS 127041-2	GLW	APD
D	1270461-1 WAS 127041-2 FOR 127041-2 ADD 127041-2 TO 127041-2 LENS TO FIT	GLW	APD
E	ADDED F-QB3 (SEE 127041-2) 127041-2 WAS 127041-2	GLW	APD

F-QB3	18		S-1367-16	S-1367-16/1200711	SEE P206-404 FOR
F-QB2	18	60	S-1367-16	S-1367-16/1200437	INACTIVE SEE P206-404 FOR
F-QB1	18	7	S-1367-16	S-1367-16/1200711	
H-QB2	18	60	S-1367-16	S-1367-16/1200437	OBSOLETE
H-QB1	18	7	S-1367-16	S-1367-16/1200437	OBSOLETE
WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
				N/A	

WIRE TABLE

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS

DATE	FILE	WIRING DIAGRAM —	Cessna.
12-27-61		OIL DILUTION	DWG NO.
1-19-62		SYSTEM (OPT)	1270625
2-27-62			REV E
2-27-62			PAGE 7.2
SUPPLIES:	SUPPLIES	MODE: 205, P206 40206	

ITEM NO	PART NO	DESCRIPTION	SE-11615
4			
3	AN-107B-1	OIL DIL VALVE	
2	S-1158-1-1	SWITCH	
1	S-1360-10	CIRCUIT BREAKER	

EQUIPMENT TABLE

ENGINE INSTRUMENTS SECTION

Cessna.

DRAWING NO.

1270625

PAGE: 3.0

DRAWN G WOOD TITLE: WIRING DIAGRAM---

DATE 1-25-62 MODEL 205 & 206

APP'D *NEW (11) 1-25-62 N/W* REV:

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.



Two triangles are shown, labeled 1 and 2. Triangle 1 is a right-angled triangle with the right angle at the top-left vertex. Triangle 2 is a right-angled triangle with the right angle at the bottom-left vertex.

COLOR: BROWN

The diagram illustrates the electrical wiring for the engine instrument panel. A vertical dashed line separates the 'ENGINE' section on the left from the 'INST PANEL' section on the right.

- ENGINE Section:**
 - A battery symbol is connected to a terminal labeled '4' (in a hexagon).
 - A fuel gauge (represented by a vertical scale) is connected to terminal '4'.
 - A wire labeled 'BROWN' runs from the fuel gauge to the instrument panel.
- INST PANEL Section:**
 - The 'BROWN' wire connects to a terminal labeled '6' (in a hexagon).
 - A variable resistor (potentiometer) is connected between terminal '6' and the 'CYL HD TEMP' gauge.
 - The 'CYL HD TEMP' gauge is part of a dashed box containing two gauges: 'FUEL LH' and 'CYL HD TEMP'.
 - A wire connects the 'FUEL LH' gauge to a terminal labeled '3' (in a hexagon).
 - A long wire runs from terminal '3' down to a terminal block labeled 'INST'.
 - At the 'INST' terminal block, the wire is connected to terminal '1' (in a hexagon), which is also labeled 'HF-EB1 (REF)'.

CHD LET	REVISION	BY DATE	CHK APPRO
A	REMOVED N/A FROM STD WIRES	GLW 4-1-62	RBS HIV
B	ADDED 0713505-1 POTENTIOMETER SR 3981	GLW 8-27-62	RBS HIV
C	ADD MODEL 206 5-1560-10 CKT BKR WAS 5-1232-10 1270461-1 WAS BAR WAS 1270429-1 1213505-1 WAS 0713602-1; ADD 1213505-2 ON BUS BAR, INST WAS INST LIGHTS H-E-BI WIRE WAS 0706003-1 HBI WIRE ADDED NOTE 1 MATL WAS PER MIL-W-5086A, TYPE 1 (SR 4-0386-6) (SR 3983-6)	GLW 6-18-63	RBS HIV HMC HFW
D	BY REVISION: [] WAS MATL PER MIL- W-16878D TYPE E 2000 GRADE EXTRUDED TEFLON DIELECTRIC. REMOVED [] FROM H-E-CI ADDED [] IN FIELD, BROWN WAS H-ELI SER (SR 44649)	GLW 2-12-64	RBS HIV HMC
E	ADDED WIRE LENGTHS TO WJT; ADDED R206 & R206 TO TITLE BLOCK; REMOVED 1210494-1, B05 BAR, 6-1270429-1 FROM EIT; C649502-2010 WAS 1213505-1 & 1213505-2	WJR 7-6-64	RBS HIV

7			
6	0713602-4	POTENTIOMETER	
5			
4	S-1372-1	BULB, CYL HD TEMP	
3	6669502-0104	INST CLUSTER KIT	
2			
1	S-1360-10	CIRCUIT BREAKER	
	PART NO	DESCRIPTION	SERIALS


EQUIPMENT TABLE

BROWN	18	1	5-1367-1-8	5-1367-1-4	NO. 6 CYL	2	205-0455 & ON
BROWN	18	1	93 5-1367-1-8	5-1367-1-4	NO. 1 CYL	2	205-0443 THRU 205-0484 206-0023 & 206-0031 ON
H-ECI	18		93 5-1367-1-8	5-1367-1-4	NO. 1 CYL		INACTIVE 205-0443 & ON 206-0023 & ON
WIRE CODE NO	GA	MATERIAL	LG	TERMINALS			SERIALS

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS

DRAWN	NAME	DATE	TITLE
G WOOD	NEW DWM	12-27-61	WIRING DIAGRAM — CYLINDER HEAD TEMPERATURE
CHECK	R. SLICK	2-7-62	
PROJ	H. M. C. T.	2-7-62	



Cessna.

WORK NO. **1270625**

SUPERSEDED BY	SUPERSEDES	MODEL	REV	PAGE
		205, P206 & U206	E	1


[illegible]

CHG LET	REVISION	BY	CNH
		DATE	APPRO
A	BY REVISION: 5-341-2 WAS 5-13671-B ADD SHORT WIRE TO FUEL LEVEL XMTR REMOVED N/A FROM STD WIRES (SR36294)	GLW 2-20-62	ELB H/W
B	ADD MODEL 206 ADD N-EBI WIRE 5-1360-10 CKT BKR WAS 5-1232-10 1213505-1 WAS 0713602-4; ADD 1213505-2 1210461-1 BUS BAR WAS 1210429-1 0726110-1 WAS 0726600-1 ON BUS BAR INST WAS INST IN LIGHTS DELETE 0700603-EBI WIRE (SR4038-6)(SR3983-6)	GLW 6-18-63	ELB H/W
C	ADD WIRE LENGTHS TO WJT 3 N-EBI WIRE 1213505-1 WAS 5-1360-10 ADDED 206G 4 U206 TO B/M; REMOVED 1210461-1 BUS BAR FROM EIT; C667902 -1004 WAS 1213505-1; 1213505-2	WJR 7-6-64	RCS H/W

6			
5			
4			
3	0726110-1	XMTR. FUEL LEVEL	
2	C669502-0104	INST CLUSTER KIT	
1	S-1360-10	CIRCUIT BREAKER	
	PART NO.	DESCRIPTION	SERIALS

EQUIPMENT TABLE

[illegible]



1. WIRING DIAGRAM SHOWN IS FOR USE WHEN AN OPTIONAL ELECTRIC CLOCK IS INSTALLED. WHEN ELECTRIC CLOCK IS NOT INSTALLED WIRE-DEFI CONNECTS PRESSURE SWITCH TO FUSEHOLDER. INSTALL S-1091-1 FUSE AND S-1640-22 FUSEHOLDER.

5	S-1317NI	CLOCK	
4	C66450-0101	MOULMETER	
3	S-1711-1	ON. PRESSURE SW	
2	S-1091-1	FUSE	
1	S-1579-1	BAT. CONTACTOR	
PART NO.		DESCRIPTION	INSTALLED ON

EQUIPMENT TABLE

[illegible]

FLIGHT INSTRUMENTS SECTION

Cessna.

DRAWING NO.

1270625

DRAWN G WOOD TITLE: WIRING DIAGRAM---

DATE 1-25-62 MODEL 205 & 206



APP'D *WOW* *CRS* *Wm* *Wm* REV:

PAGE: 9.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

(SR 3694-10)

CHG LET	REVISION	BY DATE	CHK APPD
A	REMOVED N/A FROM STD WIRES. ADD OPT TO OPT WIRES. (SR3694-10)	GLW 1-4-62	RES
B	ADD MODEL 206. ADDED 12704G1-1 BU'S, BAR, DETAIL A (SR4038-G) (SR3983-G)	GLW 6-18-63	RES
C	ADDED LIMITING SIGNALS TO FIELD & INACTIVATED WIRES H-FE1 THRU H-FE4. ADDED F206 & U206 TO B1M, REMOVED H-DB1, 12704G1-1. 270429-1 FROM E/T; ADDED WIRE LENGTHS TO W/T (SR4456) & (SR4457)	WJR 7-19-64	RES





QTY	PART NO	DESCRIPTION	TERMS
9			
8	S-1365-1	SWITCH, VACUUM	
7			
6	S-1284-1	SWITCH	
5	S-1326NI	IND, GYRO HORIZON	
4	S-1302NI	INDICATOR, T & B	
3	S-1318	INDICATOR, FLAP POS	
2			
1	CA-2	CKT BKR (MTC)	

EQUIPMENT TABLE

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
H-FE4	20	6	S-341-2	SOLDER	0713705	(OPT) inactive SER 205-0490 ON 205-0490
H-FE3	20	8	S-341-2	SOLDER	0713705	(OPT) inactive SER 205-0490 ON 205-0490
H-FE2	20	6	S-341-2	SOLDER	0713705	(OPT) inactive SER 205-0490 ON 205-0490
H-FE1	20	6	S-341-2	S-1367-1-B	0713705	(OPT) inactive SER 205-0490 ON 205-0490
H-FA2	18	16	S-1367-1-B	S-1367-1-B		
H-FA1	18	11	S-1367-1-B	S-1367-1-10		
WIRE TABLE						
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS						
DRAWN	G WOOD	12-27-61	TITLE			
GROUP	var	12-29-62	WIRING DIAGRAM —			
CHECK	R. H. H.	12-5-62	TURN & BANK AND			
PROJ	H. M. G.	12-7-62	GYRO HORIZON			
				INDICATOR		
				MODEL	205, P206 & U206	REV C
				PAGE	9.1	

(SR 3694-10)

CHG LET	REVISION	BY	CHK
A	REMOVED N/A FROM STD WIRES (SR3694-10)	GLW	225 4-9-62
B	ADD MODEL 206 ADDED 1270461-1 BUC BAR, ADDED S-1360-10 CKT BKR, ADDED DETAIL A (SR-1038-6)(SR-3983-6)	GLW	225 6-17-63
C	BY REVISION: ADD H-F-1 WIRE AUTO RESET WAS INACT. INACTIVATED H-F-1 WIRE, NLLIE S-1360-10 LMT PKR	GLW	225 7-20-63
D	ADDED P206 & U206 TO E/F-1 HF-FC3 WAS H-FC3, ADDED WIRE LENGTHS TO W/T; REMOVED H-DB1, 1270429-1 & 1270431-1 FROM E/T; S-1407-6 WAS 0511062-10 (SR4456) (SR4457)	WJR	225 7-14-64
E	INACTIVATED HF-FC3; ADDED TAN WIRE; ADDED TP206 & TU206 TO MODEL BLOCK & DETAIL "B" (SR4900) (SR4908)	WJR	225 1-21-66
F	ADD H-FC3 TO DETAIL "A" (SR4901) (SR4902)	JH	225 5-17-66



DETAIL 13
THRU SER P206-0657
P206-0307

WIRE CODE NO	QUANTITY	MATERIAL	QUANTITY	TERMINALS	N/A	SERIALS
H-FC3	18	S-1367-1-6	5-1367-1-6			SER P206-0657 & ON
TAN	18	S-1407-6	5-1367-1-6			SER P206-0657 & ON
H-FC4	18	80	5-1367-1-6	5-1367-1-6		SER 205-0481, SER 206-0001 & ON
HF-FC3	18	100	5-1367-1-6	5-1367-1-6		SER 206-0657 & ON
H-FC2	18	61	5-1367-1-6	5-1367-1-6		SER 206-0657 & ON
H-FC1	18	27	5-1367-1-6	5-1367-1-6		INACTIVE SER 205-0481 & ON


WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS


DRAWN: S. WOOD 12-7-64 GROUP: 121-1-66 CHECK: 1-1-66 PROJ: H. M. G. 2-7-66	WIRING DIAGRAM — STALL WARNING SYSTEM (NON- HEATED)	DWG NO 1270625
MODEL: P206, U206 REV: 205, TP206, TU206	F	PAGE: 9.2

EQUIPMENT TABLE

QTY	PART NO.	DESCRIPTION
1	CA-2	CKT BKR (MTC)
1	5-1318-1	IND, FLAP POSITION
1	0511062-4	XMTR, STALL WARN.
1	5-1407-6	HORN, STALL WARN.



AUTO RESET




PRIMARY BUS


OFF THRU SER 205-0480

SER P206-0657 & ON
P206-0307 & ON


1 ▷ TURN COORDINATOR INDICATOR INCLUDES ALL WIRES AND CABLES BETWEEN INVERTER, INDICATOR AND CIRCUIT BREAKER.



REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED

2	6661003-0901	TURN COORDINATOR
1	CA-2	(KT BKR (73803)
	PART NO.	DESCRIPTION
	EQUIPMENT TABLE	

[illegible]



3	MS3106A10S13S	CONNECTOR	
2	CA-2	CIRCUIT BREAKER	(B0602)
1	261003-0201	TURN COORDINATOR	
PART NO.		DESCRIPTION	
EQUIPMENT TABLE			
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXX OR CMXXXX-CESSNA STD. NO.		SUPERSEDED: SUPERSEDED BY:	

OTHER INSTRUMENTS SECTION

Cessna.

DRAWING NO.

1270625

DRAWN	G WOOD	TITLE: WIRING DIAGRAM--- MODEL 205 & 206
DATE	2-5-62	

APP'D	NEW <i>[Signature]</i> <i>RRS from Nare</i>
-------	---


REV:

PAGE: 10.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

(SR3694-10)

CHG LET	REVISION	BY	CHK
A	REMOVED N/A FROM STD WIRES (SR3694-10)	GLW	RES
B	REMOVED OBSOLETE NEVER USED FROM FACE OF DRAWING: S-1091-1 WAS -2; S-1090-22 WAS -18 (SR4021)	WJR	RES
C	ADD MODEL 206 (SR3983-6)	GLW	WJR
D	ADDED PROW & U206 TO B/M; ADDED WIRE LENGTHS TO W/T; REMOVED H-PA1, H-PA2 & H-PA4 FROM EIT	WJR	RES
E	BY REV: ADD DETAIL A, H-DC4, ITEM 6, SER OUT H-DC1 & H-DC2	LPB	RES
F	ADDED H-DC5; INACTIVATED H-DC2 (SR4659) (SR4660)	WJR	RES



ITEM NO	PART NO.	DESCRIPTION	SERIALS
8	0770728-1	DIODE ASSY.	
7	0712605-1	BATTERY	
6	S-1579-1	CONTACTOR, BAT.	
5	0712603-2	CONTACTOR, BAT.	
4			
3	S-1091-1	FUSE	
2	S-1090-22	FUSEHOLDER	
1	S-1317N1	CLOCK ASSY	

EQUIPMENT TABLE

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
H-DC5	18			S-1367-1-6 SOLDER		SER P206-0161 & ON
H-DC4	18			S-1367-2-13 SOLDER		SER P206-0161 & ON
H-DC3	18			S-1367-1-6 S-1367-1-8		205-0129 & ON
H-DC2	18			S-1367-1-6 SOLDER		205-0129 THRU 205-0129
H-DC1	18			S-1367-1-6 SOLDER		205-0129 THRU 205-0129

WIRE TABLE			
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS			
NAME	DATE	TITLE	
DRAWN: G WOOD	12-27-61	WIRING DIAGRAM —	
GROUP: WJR	1-24-62	CLOCK	
CHECK: R. H. H.	2-5-62		
PROJ: H. H. H.	2-7-62		
SUPERSEDED BY:		SUPERSEDES	MODEL: 205, P206 & U206
REV: F		PAGE: 101	


Cessna.

1270625

FORM NO. 8048

(SR 4946)

CHG LET	REVISION	BY	CHK
		DATE	APP
A	INACTIVATED HF-DB4 ; ADDED GRAY WIRE (SR4901) & DETAIL 'A' (SR4902)	JH 2-14-44	CPS JH JAW



WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
GRAY	18	5-1460-18-B	177	5-341-2	5-341-2
HF-DB4	18		177	5-341-2	5-341-2
H-DB6	18		6	5-1367-1-B	SOLDER
H-DB5	18		26	5-1367-1-B	5-341-2
H-DB1	18		37	5-1367-1-B	5-1367-10

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS

NAME	DATE	TITLE
DRAWN G WOOD	10-19-63	WIRING DIAGRAM—
GROUP Y WOOD	10-19-63	FLAP POSITION
CHECK J. H. P.	10-21-63	INDICATOR
PROJ. J. H. P.	11-1-63	

Cessna.

DWO NO.
1270625

REV A PAGE 10.2

PART NO.	DESCRIPTION	INSTALLED ON
3 C590501-0101	TRANSMITTER	
2 C668001-0102	INDICATOR	
1 S-1360-10	CIRCUIT BREAKER	

EQUIPMENT TABLE

LIGHTING SECTION

Cessna.

DRAWING NO.

1270625

DRAWN G WOOD TITLE: WIRING DIAGRAM---



DATE 1-25-62 MODEL 205 & 206

APP'D *H.W. (Mr) RRS [Signature] H.H.C* REV:

PAGE: 11.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

(SR3694-10)



CHG LET	REVISION	BY	DATE	APPD
A	REMOVED N/A FROM STD WIRES (SR 3694-10)	GLW	4-4-62	RES
B	ADD MODEL 206 S-1360-10 CKT BKR WAS S-1232-10 1270461-1 BUS BAR WAS 1270429-1 ADD NOTE 1 ON BUS BAR CABIN LIGHTS WAS NAVIGATION LIGHTS (SR 4038-G) (SR 3983-G)	GLW	6-18-63	RES
C	ADDED P206 & U206 TO B/M; REMOVED 1270461-1 FROM E/T; ADDED WIRE LENGTHS TO W/T HF-LAS WAS H-LAS & HF-LA7 WAS H-LA7 (SR 4456) (SR 4457)	WJR	7-16-64	RES
D	INACTIVATED HF-LAS & HF-LA7; ADDED GREEN WIRES (2) ADDED TP206 & TU206 TO MODEL BLOCK; ADDED DETAIL "A" (SR 4901) (SR 4902)	WJR	11-21-66	RES

NOTE:

- COURTESY LIGHTS ARE OPTIONAL
SER 205-0481 & ON, SER U206-0001
& ON & P206-0001 & ON. WIRES ARE
STD.

ITEM NO	PART NO	DESCRIPTION	SERIALS
5			
4	1270430-1	LIGHT ASSY	
3	181522	LIGHT ASSY (UCTE)	
2	0713029	SWITCH	
1	S-1360-10	CIRCUIT BREAKER	

EQUIPMENT TABLE

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
GREEN	18	S-1460-18-5	150	S-341-2	S-341-2	SER P206-0657 & ON
GREEN	18	S-1460-18-5	150	S-341-2	S-341-2	SER P206-0657 & ON
HF-LA7	18		150	S-341-2	S-341-2	Imagined SER P206-0657 & ON
H-LA6	18		88	S-341-2	SEE H-LA4	
HF-LA5	18		150	S-341-2	S-341-2	Imagined SER P206-0657 & ON
H-LA4	18		51	S-1367-16	S-341-1	
H-LA3	18		43	S-341-1	S-341-2	
H-LA2	18		36	S-1367-16	SEE H-LA3	
H-LA1	18		114	S-1367-16	S-1367-16	

WIRE TABLE

NAME	DATE	TITLE
DRAWN G WOOD	12-19-61	WIRING DIAGRAM — DOME & COURTESY LIGHTS
GROUP	WJR	12-19-61
CHECK	R. J. J. J.	1-5-62
PROJ	H. J. J. J.	2-7-62

Cessna.

1270625



REV D PAGE 11.1

(SR 3694-10)

NOTES:


1 WHEN (OPT) POST & BACK LIGHTING IS INSTALLED, WIRE H-LB3 IS CONNECTED TO CONSOLE SIDE OF S-1238-2-1 SWITCH REF 1270405 PAGE 11.7.

2. JUMPERS ARE 20 GA. WIRE



DETAIL A
EFF THRU SER P206-0160
AND SER U206-0437

CHG LET	REVISION	BY	CHK
A	REMOVED N/A FROM STD WIRES (SR3694-10)	GLW	RCS
B	ADD MODEL 208 S-1360-10 CKT BKR WAS S-1232-10 1270461-1 BUS BAR WAS 1270429-1 0700621-3 LIGHT INSTL WAS 0700621-1 R-12 1-B-R514 WAS 0105-351 ON BUS BAR, CABIN LIGHTS WAS INST LIGHTS (SR4038-6) (SR3583-6)	GLW	RCS
C	REMOVED 1270461-1 FROM E/T; ADDED P206 & U206 TO MODEL BLOCK; ADDED H-LB4, H-LB5 & C669502-0104; ADDED WIRE LENGTHS TO WIT; C660501-0101 WAS 0713068-1 (SR44569-1) (SR4457-7) ADDED 12	WJR	RCS
D	ADDED S-341-2 TO H-LB4 & ADDED JUMPER TO INST CLUSTER; ADDED DETAIL "A"; ADDED HF-LB8 & HF-LB9; H-LB6 (SR4659-1) (SR4660-1) (SR4660-1)	WJR	RCS
E	ADDED DETAIL "B" & NOTE 2 ADDED 25-240XP16 & 336R LAMP TO E/T (SR4901) (SR4902)	JH	RCS
F	ITEM 2 XR6637 WAS R12 1/2-B-R164 (SR5158, SR5159) (ON)	VES	RCS



ITEM NO	PART NO.	DESCRIPTION	SERIALS
7	336R	LAMP (GE)	
6	C669502-0104	INST CLUSTER KIT	
5	25-240XP16	LAMP HOLDER (LECO)	
4	C660501-0101	COMPASS	
3	0700621-3	LIGHT INSTL	
2	XR6637	RHEOSTAT (B3777)	
1	S-1360-10	CIRCUIT BREAKER	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
HF-LB9	18					(SR4659), (SR4660) (ON)
HF-LB8	18					(SR4659), (SR4660) (ON)
H-LB6	18					
H-LB5	20					P206-0001, U206-0276 (ON)
H-LB4	20					P206-0001, U206-0276 (ON)
H-LB3	18					
H-LB2	18					
H-LB1	18					

WIRE TABLE


NAME	DATE	TITLE
G WOOD	12-27-61	WIRING DIAGRAM —
GROUP	1-28-62	INSTRUMENT LIGHTS
CHECK	2-5-62	
PROJ	1-11-62	
SUPERSEDED BY	SUPERSEDES	MODEL 205, P206 & U206
REV: F	PAGE: 11.2	

Cessna.

1270625

(SR3694-10)

CHG LET	REVISION	BY	CHK
		DATE	APPRO
A	REMOVE N/A FROM STD WIRES (SR3694-10)	GLW 4-9-62	RES
B	ADD MODEL 206 S-1360-15 CRT BKR WAS S-1332-15 127046-1 BUS BAR 1270429-1 ON WIRES H-LC2 & H-LC5 14 GA WAS 16GA (SR 4038-6) (SR3983-6)	GLW 6-19-62	NMC
C	S-1360-20 CRT BKR WAS S-1360-15 (SR 4356)	HLW 7-17-62	NMC
D	ADDED P206 & U206 TO MODEL BLOCK; ADDED WIRE LENGTHS TO WIT; REMOVED 1270461-1 FROM E/T; OBSOLETE H-LC3, H-LC4, H-LC6 & H-LC7; HF-LCB WAS H-LC4; HF-LC9 WAS H-LC3; HF-LC10 WAS H-LC7; HF-LC11 WAS 9-LC6 (SR445042 (SR4357) 9	WJR 8-10-62	RES
E	INBD WAS OUTBD; OUTBD WAS INBD; INACTIVATED HF-LCB; HF-LC9, HF-LC10 & HF-LC11; ADDED GRAY, BLK, TAN & BLK WIRES & DETAIL "A" (SR4902) (SR4901)	WJR 7-25-64	RES




BLACK	16	S-1460-14-0	6	S-1367-2-8	S-1367-2-8	1220090	SER P206-0307	EON
TAN	14	S-1460-14-0	180	S-341-1	S-1367-2-8	1220090	SER P206-0307	EON
BLACK	16	S-1460-16-0	6	S-1367-2-8	S-1367-2-8	1220090	SER P206-0307	EON
GRAY	14	S-1460-14-8	74	S-341-1	S-1367-2-8	1220090	SER P206-0307	EON
HF-LC11	14		180	S-1367-2-8	S-341-1	1220090	P206-0001 U206-0276 THRU SER P206-0657	
HF-LC10	14		6	S-1367-2-8	S-1367-2-8	1220090	P206-0001 U206-0276 THRU SER P206-0657	
HF-LC9	14		74	S-1367-2-8	S-341-1	1220090	P206-0001 U206-0276 THRU SER P206-0657	
HF-LC8	14		6	S-1367-2-8	S-1367-2-8	1220090	P206-0001 U206-0276 THRU SER P206-0657	
H-LC7	14		6	S-1367-2-8	S-1367-2-8		OBSOLETE	
H-LC6	14		155	S-1367-2-8	S-341-1		OBSOLETE	
H-LC5	14		26	S-1367-2-8	S-341-1			
H-LC4	14		6	S-1367-2-8	S-1367-2-8		OBSOLETE	
H-LC3	14		161	S-1367-2-8	S-341-1		OBSOLETE	
H-LC2	14		26	S-1367-2-8	S-341-1			
H-LC1	14		4	S-1367-2-8	S-1367-2-8			
WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS		

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS			
DRAWN	NAME	DATE	TITLE
GROUP	G WOOD	12-30-61	WIRING DIAGRAM —
CHECK	R. D. DICK	1-22-62	LANDING LIGHTS
PROJ	W. J. M. S.	2-7-62	
SUPERSEDED BY		SUPERSEDES	MODEL
			206, 206's
REV		E	PAGE: 11.3

ITEM NO	PART NO	DESCRIPTION	SERIALS
4			
3	0523118-1	LANDING LIGHT	
2	S-1160-1-1	SWITCH	
1	S-1360-20	CIRCUIT BREAKER	
ITEM NO	PART NO	DESCRIPTION	SERIALS
EQUIPMENT TABLE			

SER 205-0001 & ON



STANDARD
SER 205-0481 & ON
SER 206-0001 & ON

OPTIONAL
SER 205-0481 THRU 205-0577

CHG LET	REVISION	BY DATE	CHK APPD	CHG LET	REVISION	BY DATE	CHK APPD
F	BY REV: C622001-0201 WAS 0426006-12 & 13, C622001-0102 WAS 0433006-7, ITEM 4 WAS ITEM 5 & H-LD22 WAS H-LD7, H-LD23 WAS H-LD10, H-LD24 WAS H-LD4, H-LD25 WAS H-LD17; ADD 5-1637-1 & 5-1637-2 DELETE 2 RED & 2 BLACK WIRES (EDRR 01163) (EDRR 01335)	RLY 1-6-67	RLY	A	REMOVED N/A FROM STD WIRES SER 205-0001 & ON	GLW 1-4-62	RLY
				B	ADDED OPTIONAL & STANDARD CONFIGURATIONS; ADDED WIRES H-LD13, H-LD14 & H-LD15; S-1158-2-1 SWITCH, 1270461-1 BUS, BAL. H-LD2 THRU H-LD4, H-LD6 & H-LD7 & H-LD10 BECOME OPT SER 205-0481 & ON, SER 206-0001 & ON	WJR 3-15-63	RLY
				C	ADD MODEL 206 WIRE HF-LD17 WAS H-LD5 H-LD5 WIRE BECOMES OBSOLETE	GLW 6-19-65	RLY
				D	ADDED P206 & U206 TO MODEL BLOCKS; ADDED WIRE LENGTHS TO WIT; ADDED LIMITING SERIALS TO FIELD; INACTIVATED H-LD2, H-LD3, H-LD4, H-LD6, H-LD7 & H-LD10; REMOVED 1270429-1 & 1270461- FROM E/T; S-1360-10 WAS S-1232-10; OBSOLETE H-LD8, H-LD9, H-LD11 & H-LD12; HF-LD18 WAS H-LD8; HF-LD19 WAS H-LD11; HF-LD20 WAS H-LD12; HF-LD21 WAS H-LD9 SER U206-0276 & ON; SER P206-0001 & ON	WJR 8-11-69	RLY
				E	INACTIVATED HF-LD18, HF-LD19, HF-LD20 & HF-LD21. ADDED RED & BLACK WIRES (C, GRN) ADDED DETAIL SER U206-0657 & ON, SER P206-0307 & ON	WJR 1-24-66	RLY

H-LD25	18	20	S-1636-1	S-1635-1		
H-LD24	18	335	S-1367-1-6	S-1635-1		
H-LD23	18	65	S-1367-1-6	S-1635-1		
H-LD22	18	66	S-1367-1-6	S-1635-1		
HF-LD21	18	14	S-1367-1-8	SOLDER	P206-0001, U206-0276 THRU SER U206-0657 & ON, SER P206-0307 & ON	
HF-LD20	18	14	S-1367-1-8	SOLDER	P206-0001, U206-0276 THRU SER U206-0657 & ON, SER P206-0307 & ON	
HF-LD19	18	250	S-341-2	SOLDER	P206-0001, U206-0276 THRU SER U206-0657 & ON, SER P206-0307 & ON	
HF-LD18	18	250	S-341-2	SOLDER	P206-0001, U206-0276 THRU SER U206-0657 & ON, SER P206-0307 & ON	
HF-LD17	18	20	S-341-2	SOLDER		
H-LD15	18	27	S-341-2	S-1367-1-6	205-0481, 206-0001 & ON	
H-LD14	18	352	S-341-2	S-1367-1-6	205-0481, 206-0001 & ON	
H-LD13	18	50	S-341-2	S-1367-1-6	205-0481, 206-0001 & ON	
H-LD12	18	14	S-1367-1-8	SOLDER	OBSOLETE	
H-LD11	18	230	S-341-2	SOLDER	OBSOLETE	
H-LD10	18	65	S-1367-1-6	S-341-2	1270462 (OPT) direction EFF THRU 205-0577	
H-LD9	18	14	SOLDER	S-1367-1-8	OBSOLETE	
H-LD8	18	230	S-341-2	SOLDER	OBSOLETE	
H-LD7	18	66	S-1367-1-6	S-341-2	1270462 (OPT) direction EFF THRU 205-0577	
H-LD6	18	19	S-1367-1-6	S-1367-1-8	1270462 (OPT) direction	
H-LD5	18	23	S-341-2	SOLDER	OBSOLETE	
H-LD4	18	335	S-1367-1-6	S-341-2	1270462 (OPT) direction	
H-LD3	18	45	S-1367-1-6	S-1367-1-6	1270462 (OPT) direction	
H-LD2	18	45	S-1367-1-6	S-1367-1-6	1270462 (OPT) direction	
H-LD1	18	4	S-1367-1-8	S-1367-1-6		
WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS

WIRE TABLE			
Cessna Aircraft Co. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS			
DRAWN	G WOOD	12-18-61	TITLE
GROUP	WJR	1-29-62	WIRING DIAGRAM —
CHECK	E. Stuck	2-5-62	NAVIGATION LIGHTS
PROJ	H.M. Galt	2-7-62	
SUPERSEDED BY		SUPERSEDES	
MODEL	205 & 206	REV: F	PAGE: 11.4

ITEM NO	PART NO	DESCRIPTION	SERIALS
10			
9	S-1360-10	CIRCUIT BREAKER	
8	S-1158-2-1	SWITCH	
7			
6	C622001-0102	POSITION LIGHT	
5	S-1637-2	HOUSING	
4	C622001-0201	POSITION LIGHT	
3	0713511-1	FLASHER, NAV LT	
2	S-1160-1-1	SWITCH	
1	S-1637-1	HOUSING	


EQUIPMENT TABLE

Cessna.

1270625

(SR3694-10)

- | CHG | REV | BY | CHK |
|-----|--|----------------|------------|
| NO | DESCRIPTION | DATE | APPD |
| A | REMOVED N/A FROM STD WIRES
ADD OPT TO OPT WIRE (SR35694-1) | GLW
4-4-69 | WJR
H/W |
| B | ADD MODEL 208
ADD OPT TO TITLE
HOF-LF3 WIRE WAS H-LF3 WIRE
REMOVED OPT FROM H-LF1 WIRE
ADD STD TO H-LF1 WIRE 3 WIRES
S-1560-10 CKT ENR WAS S-1232-10
1270461-1 BUS BAR WAS 1270429-1
ADD NOTE 2
0770610-LF1 WIRE WAS 0770608-LF4
(SR-4038-6) (SR3983-6) | GLW
8-13-69 | WJR
H/W |
| C | ADDED P206 & U206 TO MODEL
BLOCK; REMOVED (OPT) FROM
TITLE; DFK-LF3 WAS HOF-LF3;
ADDED WIRE LENGTHS TO WIT;
REMOVED 1270461-1 & 0770610-
LF4; ADDED FLOAT PLANE VERSION
H-LF4 & H-LF5 (SR4464) (SR4457)
DELETED NOTE D | WJR
8-11-69 | WJR
H/W |



6
ROT.
BCN

Inactive SER P206-0657 & ON
P206-0307 & ON

WJR 12-29-65
N & W 1-24-66
R's Ninc

H-LF5	16		75	S-341-1	S-341-1	1270672
H-LF4	16		60	S-341-1	S-341-1	1231000
DFH-LF3	16		70	S-341-1	S-341-1	
H-LF2	16		325	S-1367-2-6	S-341-1	
H-LF1	16		4	S-1367-2-6	S-1367-2-8	1270427
WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT CO. 100 W. CHRYSLER BLVD.

	NAME	DATE	TITLE	
DRAWN	G Wood	12-28-62	WIRING DIAGRAM— ROTATING BEACON	
GROUP	W. Wood	1-19-62		
CHECK	R. Wood	2-5-62		
PROJ.	A. Wood	2-7-62		
SUPERSEDED BY			MODEL	REV.
1270625			205, P2064U206	C
PAGE 11.5			PAGE 11.5	



FORM NO. 80-101

5			
4			
3	0700120-1	ROTATING BEACON	
2	S-1158-2-1	SWITCH	
1	S-1360-10	CIRCUIT BREAKER	
	PART NO.	DESCRIPTION	INSTALLED ON

EQUIPMENT TABLE

(SR4901)
(SR4902)

CHG	REVISION	BY	CHK
LET		DATE	APPD
A	BY REV: SERIALIZE OUT DETAIL (SR5226)	JWH	12K
		3-1-67	12K



DETAIL A
APPLIES TO FLOATPLANE ONLY
THUR SER (SR 3226)

NOTES:

- 1 S-1636-2 SOCKET & S-1637-2 HOUSING - PLUG.
- 2 S-1635-2 PIN & S-1637-1 HOUSING - CAP.

PART NO	DESCRIPTION	INSTALLED ON
4	C594501-0101	FLASHER UNIT
3	C621001-0101	LIGHT ASSY
2	S-1158-2-1	SWITCH
1	S-1360-10	CIRCUIT BREAKER

EQUIPMENT TABLE

WIRE CODE NO	GA	MATERIAL	LO	TERMINALS	SERIALS
H-LF11	16			2	S-1636-2
H-LF10	16			2	1
H-LF9	16			5-1367-2-8	1
H-LFB	16			5-1367-2-6	5-1367-2-8
DFH-LF7	16			2	S-1636-2

WIRE TABLE

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

NAME	DATE	TITLE
RIDDER	12-29-65	WIRING DIAGRAM - FLASHING BEACON LIGHT
GROUP	W. W. 1-29-66	
CHECK	R. J. 1-25-66	
PROJ	H. H. 1-27-66	
SUPERSEDED BY:	SUPERSEDED PAGE	MODEL
	1270625 11.5	P206 & U206
REV:	A	PAGE: 11.5.1

Cessna.


DWG NO: 1270625

(SR5226)

CHG LET	REVISION	BY DATE	CHK APPD

NOTES:

1. S-1636-2 SOCKET & S-1637-2 HOUSING - PLUG
2. S-1635-2 PIN & S-1637-1 HOUSING - CAP



WIRE CODE NO.	GA	MATERIAL	LO	TERMINALS	SERIALS
YEL	16	B	S-1636-2	S-1635-2	
YEL	16	B	S-1636-2	S-1635-2	
RED	16	B	S-1636-2	S-1635-2	
H-LF9	16			S-1637-2-6	
H-LFB	16			S-1637-2-6	
DFH-LF7	16			S-1637-2-6	

WIRE TABLE

NAME	DATE	TITLE
DRAWN J.W. HARRIS	3-1-67	WIRING DIAGRAM -
GROUP	3-7-67	FLASHING BEACON
CHECK YAKIMOW	3-3-67	LIGHT (FLOATPLANE)
PROJ H.M. Selt	3-8-67	

Cessna.

1270625


REV. 11.5.2


PART NO.	DESCRIPTION	INSTALLED ON
6	S-1636-2 HOUSING PLUG	
5	S-1635-2 HOUSING CAP	
4	C594601-0101 FLASHER UNIT	
3	C621001-0101 LIGHT ASSY	
2	S-1158-2-1 SWITCH	
1	S-1360-10 CIRCUIT BREAKER	

EQUIPMENT TABLE

(SR 4038)
(SR 3983)

- | CHG
LET | REVISION | BY | CHK |
|------------|---|----------------|-----------|
| | | DATE | APP |
| A | REMOVED 1270461-1 FROM E/T
& INACTIVATED DWG | WJR
8-12-64 | RS
HFL |
| | | | |

[illegible]



NOTES:

1 WIRES DHF-LA18 & DHF-LA19 READ FOR RH MAP LIGHT INSTL. RH INSTL IS OPTIONAL (INSTALLED WITH OPT POST LIGHTS).

(SR4456)
(SR4457)

CHG LET	REVISION	BY	CHK
A	REMOVED OPT FROM T/D ADD OPT INFO TO NOTE 1 REMOVED IT-1 INSULATOR FROM DWG. DHF-LA18 WAS H-LA18 DHF-LA19 WAS H-LA19 (SR4301)(SR4302)-6	ALH	ALH
B	ITEM 2 XRG637 WAS R12H-A-R934 (SR5158)(SR5159) E.D.N.	VRS	ALH

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
DHF-LA19	18	SOLDER	S-341-2		OPT
DHF-LA18	18	S-1367-1-6	S-341-2		OPT
DHF-LA17	18	S-1367-1-6	S-341-2		
DHF-LA16	18	SOLDER	S-341-2		
DHF-LA15	18	SOLDER	S-341-2	0770725	
DHF-LA14	18	S-1367-1-8	S-1367-1-10	0770725	
DHF-LA13	18	SOLDER	S-341-2	0770725	
DHF-LA12	18	SOLDER	S-341-2	0770725	
DHF-LA11	18	SOLDER	S-341-2	0770725	

WIRE TABLE

CESNA AIRCRAFT CO. WIRE TABLE FOR CESSNA 441 Q

ITEM NO.	PART NO.	DESCRIPTION	INSTALLED ON
5			
4	1470089-14	LIGHT ASSY	
3	S-1501-1	SWITCH	
2	XRG637	RHEOSTAT	(B3777)
1	S-1360-10	CIRCUIT BREAKER	

EQUIPMENT TABLE

NAME	DATE	TITLE
RIDDER	8-13-64	WIRING DIAGRAM — MAP LIGHT
GROUP	8-13-64	
CHECK	8-24-64	
PROJ	8-24-64	
SUPERSEDED BY	1270625	PAGE 11.6
MODEL	P206E U206	REV. B
SERIALS	1270625	PAGE 11.6.1


Cessna.

1270625

FORM NO. 80-181

(SR4456)
(SR4457)

CHG LET	REVISION	BY DATE	CHK APPRO



Inactive SER P206-0028 & U206-0318 & ON
W.A.R. 10-30-64
173

BLACK	22	5-1940-22-0	5-1367-1-8	5-1367-1-10	0770646	
WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA, KANSAS

PART NO.	DESCRIPTION	INSTALLED ON
3	AS299-12 LIGHT ASSY (GMC)	
2	R-12-8-RS34 RHEOSTAT (TRTA)	
1	S-1360-10 CIRCUIT BREAKER	

EQUIPMENT TABLE


DRAWN	NAME	DATE	TITLE
GROUP			
CHECK			
PROJ			
SUPERSEDED BY:			SUPERSEDES
MODEL:			REV:
205, P206 & U206			PAGE: 11.8

WIRING DIAGRAM—
NAV-O-MATIC 300
POST LIGHT
(OPT)

Cessna.

DWG NO: 1270625

1-1000 LPI	REVISION	BY	CUR
		DATE	APP



NOTES:

- 1 TERMINATE WITH 5-1370-1 SPLICE
2 TERMINATE WITH 5-1370-2 SPLICE
3 JUMPER TO BE 20 GA WIRE

[illegible]

WIRE TABLE

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

4			
3	R-124 B-R534	RHEOSTAT (IRIA) (INST	
2	XP6085	RHEOSTAT (IRIA) (PADIO)	(200 124 WAT
1	336	BULB (GE)	
	PART NO	DESCRIPTION	INSTALLED ON


EQUIPMENT TABLE

EQUIPMENT TABLE



DRAWN: S. WOOD 6-10-66		DATE: 6-10-66		TITLE: WIRING DIAGRAM— BACK LIGHTING		Cessna.	
GROUP: H. Wood 9-17-66		CHECK: R. Black 9-28-66		FMO: H. Wood 9-28-66		1270625	
SUPERSEDED BY:		SUPERSEDER: 1270625 PAGE 11.7		MODEL: 170C, 170C TP 200, TP 200		REV: PAGE: 11.9	

CHG LET	REVISION	BY	CHK
A	ITEM 2 XRG637 WMS D12 V2 - 8-R53A SER U206-0915/ON, SER P206-0420/ON	YMS	VAK
B	BY REV. ADD DETAIL A, NOTE 3.	YMS	VAK

SHOCK PANEL POST LIGHTING



MAN. PRES, TACH, FLAP IND, SUCTION
CARB. AIR & ECON. PWR.
POST LIGHTING





HF-LB51


DHF-LB81
S-341-2 (2)
DHF-LB84
DHF-LB85
S-341-2
DHF-LB80

PEDESTAL

DHF-LB83



DETAIL A
SER U206-0915/ON, SER P206-0420/ON



NOTES:

1. ALL RED/YEL & BLACK WIRES INTERCONNECTING LAMPS TO BE S-1460-22 WITH SOLDER AS TERMINATION UNLESS OTHERWISE IDENTIFIED. WIRES IDENTIFIED AS "JUMPER" ARE TO BE 20 GA.
2. WHEN POST LIGHTS ARE INSTALLED H-LB3 IS CONNECTED TO "CONSOLE" SIDE OF SWITCH INSTEAD OF XRG637 RHEOSTAT.
3. STANDARD EQUIPMENT SER U206-0915/ON, SER P206-0420/ON

PART NO	DESCRIPTION	INSTALLED ON
10	FRL-5-2 20OHM RESISTOR (TRTA)	
9	1B13/2 LWI CAPS (APMH)	
8	S-123B-2-1 SWITCH	
7	C669502-024 INST CLUSTER	
6	336 LAMP (GE)	
5	5952-3RH-CW-K LIGHT ASSY (GBN)	
4	25-240XPI6 LAMPHOLDER (LECR)	
3	5952-3LH-CW-14 LIGHT ASSY (GBN)	
2	XRG637 RHEOSTAT (B3777)	
1	S-1360-10 CIRCUIT BKR	


WIRE	CODE NO	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
DHF-LB83	20		S-341-2	S-1370-1	1200686		
DHF-LB84	20		S-341-2	S-1370-2			
DHF-LB85	20		SOLDER	S-1367-18			
DHF-LB82	20		SOLDER	SOLDER			
DHF-LB81	20		S-341-2	S-1367-18			
DHF-LB80	20		S-341-2	S-1367-18			
HF-LB51	18		S-1367-16	S-341-2	1200686		

WIRE TABLE			
NAME	DATE	TITLE	
DRAWN	J. HUSTON	12-12-66	WIRING DIAGRAM—
GROUP	H. WISE	12-12-66	POST LIGHTING
CHECK	YAKSHAN	12-19-66	(OPT)
PROJ	MCB	12-11-66	
SUPERSEDED BY	1270625	11.7	MODEL P206-0206
REV	B	PAGE	11.9

Cessna.
1270625


1. ALL MATERIALS DEFINED ON THIS
DRAWING ARE FOR REFERENCE AND
TECHNICAL USE ONLY

REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED

[illegible]

ITEM NO	PART NO.	DESCRIPTION
EQUIPMENT TABLE		

REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED



ITEM NO.	PART NO.	DESCRIPTION
4	VM 304-7	LIGHT ASSY (87034)
3	VM 304-6	LIGHT ASSY (87034)
2	S-123B-1-1	SWITCH
1	S-1360-10	CKT BKR

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
RED	20	S-1460-20-2	5-1367-1-6	SOLDER	
RED	20	S-1460-20-2	5-1367-1-6	SOLDER	
GRN	20	S-1460-20-5	5-1367-1-6	SOLDER	
BLK	18	S-1460-18-0	5-1367-1-6	S-1367-8	

WIRE TABLE

CONTRACT NO.		Cessna AIRCRAFT CO.		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE		
GROUP	H. Wise	7-8-67	WIRING DIAGRAM - SKYDIVING SIGNAL LIGHT		
DRAWN	SWANEY	6-22-67			
CHECK	YAKSHAW	6-23-67			
STRESS	and	7-5-67			
PROJECT	H. M. C. L.	7-10-67	SIZE	CODE IDENT. NO.	DWG NO.
APPD	R. L. H. H. H.	6-28-67	C	71379	1270625
SCALE: NONE			(SR 5158)-IX		PAGE: 11/12

HEATING, VENTILATING, AND DE-ICING SECTION


Cessna.

DRAWING NO.

1270625

PAGE: 13.0


DRAWN G WOOD TITLE: WIRING DIAGRAM---


DATE 1-25-62 MODEL 205 & 206

APP'D *Howlin* *ERS* *Wm Hone* REV:

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

(SR 3694-10)


CHG LET	REVISION	BY	CHK
A	REMOVED N/A FROM STD WIRES (SR 3694-10)	GLW	ERS
B	ADD 60232-1 CKT BKR TO CIGAR LIGHTER. ADD H-HC2 WIRE ADD NOTE  , CA-2 CKT BKR, 0713602-1 OBSOLETE F-HC1 H-HC1 WAS 18 GA 5-1367-2-B TERM WAS 5-1367-18TERM (SR 4081)	GLW	ERS
C	ADD MODEL 206 5-1360-10 CKT BKR 1270461-015 BAR 1213505-1 INST CLUSTER 54360-30 CKT BKR 1213505-2 INST CLUSTER & DETAIL A (SR 4038-G) (SR 3783-G)	GLW	ERS
D	ADDED P206 & U206 TO MODEL BLOCK ADDED WIRE LENGTHS TO W/T; C667502-0104 WAS 0713602-1 1213505-2 & 1213505-1, REMOVED 1270429-1, 1270461, 5-1360-10 & 1270625-DA1 FROM E/T	WJR	ERS



THRU SER 205-0319

DETAIL 
EFFECTIVE 205-0320
THRU SER 205-0480

NOTE:

 CIRCUIT BREAKER IS RESET BY
INSERTING A PROBE INTO THE
 $\frac{5}{64}$ DIA HOLE IN BREAKER FACE
AND PUSHING LIGHTLY UNTIL A
CLICK IS HEARD.

12	5-1232-10	CIRCUIT BREAKER	
11	C6695C2-0104	INST CLUSTER KIT	
10	CA-2	CKT BKR (MTCC)	
9			
8			
7	5-1360-50	CIRCUIT BREAKER	
6	60232-1	CKT BKR (CUE)	
5			
4			
3			
2	0513039-7	CIGAR LIGHTER	
1			
TEMP NO	PART NO	DESCRIPTION	INSTALLED ON

EQUIPMENT TABLE

																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					</
--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	----

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

NAME	DATE	TITLE
DRAWN G WOOD	12-30-61	WIRING DIAGRAM —
GROUP <i>W. Wood</i>	1-29-62	CIGAR LIGHTER
CHECK <i>R. H. H. H.</i>	2-5-62	
PROJ <i>H. H. H. H.</i>	2-7-62	
SUPERSEDED BY	SUPERSEDES	MODEL 205, P206 & U206
REV 0	PAGE: 13.1	

Cessna.



DWS NO
1270625

FORM NO. 60-461

NOTE:

ONLY HEATER CIRCUIT SHOWN.
FOR STALL WARNING CIRCUIT,
SEE PAGE 9.2.

(SR 3694-10)



ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
5	0511062-5	XMTR STALL WARN, HTD	
4	0721105-15	PITOT TUBE, HEATED	
3	0721105-15	PITOT TUBE, HEATED	
2	5-1158-2-1	SWITCH	
1	5-1360-15	CIRCUIT BREAKER	

EQUIPMENT TABLE

CHG LET	REVISION	BY	CHK
		DATE	APPRO
A	1200400 WAS 1270626 ADD OPT TO TITLE (SR3694-10)	GLW	RES
B	ADD MODEL 208 S-1360-10 CKT BKR WAS S-1232-10 1270461-1 BUS BAR WAS 1270429-1 (SR 4038-6)(SR3983-6)	GLW	RES
C	ADDED P206-0307 TO MODEL BLOCK ADDED WIRE LENGTHS TO WIT REMOVED 1270461-1 FROM E/T. HF-FB3 WAS H-FB3; HF-FB4 WAS H-FB4; HF-FB5 WAS F-FB5 (SR4456) (SR4457)	WJR	RES
D	INACTIVATE HF-FB3, HF-FB4 & HF-FB5; ADDED BLUE, BLACK BLUE WIRE AND DETAIL 'A' 0721105-15 WAS 0721105-2 (SR401)(SR44902)	WJR	RES
E	S-1360-15 WAS S-1360-10 (SA5144)	GLW	RES

WIRE	GA	MATERIAL	LC	TERMINALS	SERIALS
BLUE	16	S-1460-16-6	50	SEE BLUE	S-341-1 1220090 (STD) P206-0657 E ON
BLACK	18	S-1460-18-0	8	S-1367-1-8	1220090 (STD) P206-0657 E ON
BLUE	16	S-1460-16-6	92	S-341-1	1220090 (STD) P206-0657 E ON
HF-FB5	18		50	SEE H-FB3	S-341-2 1220090 (STD) P206-0657 E ON
HF-FB4	18		8	S-1367-1-8	1220090 (STD) P206-0657 E ON
HF-FB3	16		92	S-341-1	1220090 (STD) P206-0657 E ON
H-FB2	16		35	S-1367-2-6	S-341-1 1200440
H-FB1	16		4	S-1367-2-6	S-1367-2 1200440

WIRE TABLE

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

DRAWN	NAME	DATE	TITLE
G WOOD		12-26-61	WIRING DIAGRAM -
GROUP		1/29-62	HEATED PITOT TUBE &
CHECK		2-5-62	HEATED STALL
PROJ		2-7-62	WARNING SYSTEM (OPT)

Cessna.

1270625

REV E PAGE 19.2

CONTROL SURFACE SECTION


Cessna.

DRAWING NO.

1270625


DRAWN G WOOD TITLE: WIRING DIAGRAM---

DATE 1-25-62 MODEL 205 & 206

APP'D *HCW (117) RRS [Signature]* REV:

PAGE: 14.0

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.



NOTE:

1. FLAP SWITCH SHOWN IN FLAP "DOWN" POSITION
2. THIS DIAGRAM APPLICABLE TO MODEL 206 THRU 206-0195 REFER TO PAGE 14.1.2 FOR LATER SERIALS.
3. GND. BLACK WIRE TO TRANSMITTER MTG. BOLT.

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
14	CS90501-0101	TRANSMITTER	
13	666001-0101	INDICATOR	
12	113-00M	SWITCH (CRYE)	
11	82-7RW204	LIMIT SWITCH (MCS)	
10	CA-2	LKT BKR (MTC)	
9			
8	28INT-12D	SOLENOID (GN)	
7			
6	126006B-2	AMTR, FLAP POS	
5	5-1318-1	INDICATOR, FLAP POS	
4	5-1317-10	BREAKER	
3	0760651-1	FLAP ACTUATOR	
2	0760632-1	SWITCH, ELECTRIC FLAP	
1	5-1317-15	CIRCUIT BREAKER	

EQUIPMENT TABLE

WIRE CODE NO	WIRE NO	MATERIAL	LG	TERMINALS	N/A	SERIALS
H-CC14	16		100	5-1493-2	5-341-1	SER 206-0196 & ON
H-CC13	16		100	5-1493-2	5-341-1	SER 206-0196 & ON
H-CC12	16		155	5-1367-2-6	SEE H-CC4	SER 206-0064 & ON
H-CC11	16		149	5-1367-2-6	5-341-1	SER 206-0064 & ON
H-CC10	16		25	5-1367-2-6	5-341-1	SER 206-0064 & ON
H-CC9	16		8	5-341-1	5-1367-1-8	
H-DB6	18		6	SOLDER	5-1367-1-8	
H-DB5	18		26	5-341-2	5-1367-1-10	
H-DB4	18		177	5-341-2	5-341-2	
H-DB3	18		177	5-341-2	5-341-2	INACTIVE SER 206-0196 & ON
H-DB2	18		26	5-1367-1-10	5-341-2	INACTIVE SER 206-0196 & ON
H-DB1	18		37	5-1367-1-10	5-1367-1-8	
H-CC8	16		5	5-1367-2-8	5-1367-2-6	
H-CC7	16		129	5-341-1	5-341-1	
H-CC6	16		129	5-341-1	5-341-1	
H-CC5	16		129	5-341-1	5-341-1	
H-CC4	16		25	5-1367-2-6	5-341-1	
H-CC3	16		25	5-1367-2-6	5-341-1	
H-CC2	16		25	5-1367-2-6	5-341-1	
H-CC1	16		34	5-1367-2-6	5-1367-2-8	

WIRE TABLE


CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS

DRAWN	NAME	DATE	TITLE
GROUP	G. WOOD	12-21-61	WIRING DIAGRAM — WING FLAPS
CHECK	R. H. HICK	1-29-62	
PROJ	H. M. G. H.	2-7-62	

Cessna.

1270625

SUPPLEMENT	PAGE	SUPPLEMENTS	MODEL	REV	PAGE
1270625	14.2.0		206, 206E, 206G	G	14.1.0



NOTE:


1. FLAP SWITCH SHOWN IN FLAP "DOWN" POSITION.
2. REF 1270625 PAGE 14.10 FOR WIRE TABLE.
3. CARGO DOOR SWITCH SHOWN ACTUATED (CARGO DOORS CLOSED).
4. (12) SWITCH & WIRES H-CC13 & H-CC14 APPLICABLE SER 206-0196 & ON.
5. GND. BLACK WIRE TO TRANSMITTER MTG. BOLT.

ITEM NO	PART NO.	DESCRIPTION	INSTALLED ON
EQUIPMENT TABLE			

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
WIRE TABLE					
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS					
NAME	DATE	TITLE			
DRAWN G WOOD	10-28-63	WIRING DIAGRAM —			
GROUP J. W. W.	11-5-63	WING FLAPS			
CHECK R. H. G.	11-5-63	(FLOATPLANE)			
PROJ H. H. G.	11-6-63	(OPT)			
SUPERSEDED BY PAGE 10, 2		SUPERSEDES	MODEL	REV	PAGE
1270625 PAGE 14.2.1			206 & U206	6	14.1.1

Cessna.

DWG NO
1270625




Inactive
SER 8206-0240 F ON
10-11-65 8206-0551 F ON
Gu 4 PW
ERS
Nme


1. FLAP SWITCH SHOWN IN FLAP "DOWN" POSITION.
2. REF 1270625 PAGE 14.10 FOR WIRE TABLE.
3. CARGO DOOR SWITCH SHOWN ACTUATED (CARGO DOORS CLOSED).
4. THIS DIAGRAM APPLICABLE SER 206-0196 & ON REFER TO PAGE 14.10 FOR PRIOR SERIALS.
5. GND. BLACK WIRE TO TRANSMITTER MTG. BOLT.

ITEM NO.	PART NO.	DESCRIPTION	INSTALLED ON
EQUIPMENT TABLE			

[illegible]

CESSNA AIRCRAFT CO COMMERCIAL AIRCRAFT DIVISION WICHITA KANSAS

DRAWN		NAME		DATE		TITLE			
G WOOD		3-2-64				WIRING DIAGRAM —			
GROUP		3-10-64				WING FLAPS			
CHECK		3-11-64							
PROJ.		9-9-64							
SUPPLEMENTED BY PAGE 102 1270625								DWG NO 1270625	
SUPPLIES 1270625				MODEL 206 & 206		REV G		PAGE 14.12	




1. FLAP SWITCH SHOWN IN FLAP "DOWN" POSITION.
2. REF 1270625 PAGE 14.1.0 FOR WIRE TABLE.
3. GND. BLACK WIRE ON TRANSMITTER MTG. BOLT.

ITEM NO	PART NO	DESCRIPTION	INSTALLED ON
EQUIPMENT TABLE			

[illegible]

(SR4946)

CHG LET	REVISION	BY	CHK
A	0760657-B WAS 2301001-0101; INACTIVATED FH-CC15, HF-CC16, H-CC18, H-CC19 & H-CC21; ADDED ORANGE, BLACK, BROWN, VIOLET & BLACK WIRES; ADD DETAILS A&B (SR4901), (SR4902)	GLW 10/26/65	ARM H/W



- NOTE:
- SWITCH SHOWN IS A "MOMENTARY ON" "ON" - "MOMENTARY ON" CONFIGURATION. THE MOTOR IS SHORTED WHEN THE SWITCH IS IN THE CENTER "ON" POSITION. THE SWITCH IS SHOWN IN CENTER "ON" POSITION.
 - SWITCH TERMINALS SHOWN AS VIEWED FROM TOGGLE SIDE OF SWITCH.

PART NO.	DESCRIPTION	INSTALLED ON
7 BZ-7RW2704	LIMIT SWITCH (MCS)	
8 E-3-00M	SWITCH (CRYE)	
5 0760657-B	FLAP MOTOR ASSY	
4 S-1638-2	HOUSING- CAP	
3 S-1638-1	HOUSING- PLUG	
2 S-166-1	SWITCH ASSY	
1 S-360-15	CIRCUIT BREAKER	

EQUIPMENT TABLE


WIRE CODE NO.	G.A.	MATERIAL	LG	TERMINALS	SERIALS
BLACK 16	5-1460-16-0	10	5-1367-26	5-1367-28	SEE P206-0657 FOR ON
VIOLET 16	5-1460-16-7	149	5-1367-26	5-341-1	SEE P206-0657 FOR ON
BROWN 16	5-1460-16-1	55	5-1367-26	5-341-1	SEE P206-0657 FOR ON
BLACK 16	5-1460-16-0	142	5-341-1	5-1636-2	SEE P206-0657 FOR ON
ORANGE 16	5-1460-16-3	142	5-341-1	5-1636-2	SEE P206-0657 FOR ON
H-CC1	16	10	5-1367-26	5-1367-28	SEE P206-0657 FOR ON
H-CC2	16	25	5-1367-26	5-341-1	SEE P206-0657 FOR ON
H-CC3	16	149	5-1367-26	5-341-1	SEE P206-0657 FOR ON
H-CC18	16	55	5-1367-26	5-341-1	SEE P206-0657 FOR ON
H-CC17	16	25	5-1367-26	5-341-1	SEE P206-0657 FOR ON
FH-CC16	16	142	5-341-1	5-1636-2	SEE P206-0657 FOR ON
FH-CC15	16	142	5-341-1	5-1636-2	SEE P206-0657 FOR ON
H-CC14	16	100	5-1493-2	5-341-1	SEE P206-0657 FOR ON
H-CC13	16	00	5-1493-2	5-341-1	SEE P206-0657 FOR ON
H-CC8	16	5	5-1367-26	5-1367-26	SEE P206-0657 FOR ON
H-CC3	16	25	5-1367-26	5-341-1	SEE P206-0657 FOR ON
H-CC2	16	25	5-1367-26	5-341-1	SEE P206-0657 FOR ON
H-CC1	16	34	5-1367-26	5-1367-28	SEE P206-0657 FOR ON

WIRE TABLE			
CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS			
DRAWN	NAME	DATE	TITLE
GROUP	H. Wood	3-9-65	WIRING DIAGRAM - WING FLAPS
CHECK	H. Wood	10-19-65	
PROJ	H. Wood	12-15-65	
SUPERSEDED BY		SUPERSIDES	MODEL
		1270625 PAGE 11.0	TP206 P206
REV: A		PAGE: 14.2.0	

Cessna.

1270625

FORM NO. 10-14-65



INACTIVE
SER P206-0420
8:22-67
JH
JFW

2. REF 1270625 PAGE 14.2.0 FOR WIRE TABLE.

WIRE TABLE

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS


TEMP NO	PART NO.	DESCRIPTION	INSTALLED ON
EQUIPMENT TABLE			

[illegible]

8	MS 26255-1	SWITCH	
7	C30K001-0303	ACTUATOR ASSY	
6	C30K001-0301	ACTUATOR ASSY	
5	S-1638-2	HOUSING - CAP	
4	S-1638-1	HOUSING - PLUG	
3	E13-00M	SWITCH	(01963)
2	E33-10K	SWITCH	(01963)
1	S-1360-15	CIRCUIT BREAKER	
ITEM NO.	PART NO.		DESCRIPTION
	EQUIPMENT TABLE		VENDOR
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CMXXXX-CESNA STD. NO.			SUPERSEDES: 1270625 PAGE 14.2. SUPERSEDED BY:

CONTRACT NO:			WIRE TABLE Cessna AIRCRAFT CO. COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	G. WOOD	8-21-67	TITLE WIRING DIAGRAM - WING FLAPS		
GROUP	H. WOOD	8-21-67			
DRAWN	J. HUSTON	8-21-67			
CHECK	YAKSHAW	8-24-67			
STRESS	and	8-27-67			
PROJECT	71 P/W. 1. 10-18-67		SIZE	CODE IDENT. NO.	DWG NO.
APPD			C	71379	1270625
			SCALE:		SER 0206-091504
					PAGE: 14.3

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD NOTE 3 & 52'S. (SR5158)(SR5159) IX	JWH 8-30-67	YAK H/W



- NOTES:
1. WITH RED MOTOR LEAD NEGATIVE & BLACK LEAD POSITIVE, MOTOR WILL ROTATE IN A CLOCKWISE DIRECTION (LOOKING INTO SHAFT).
 2. BLK GND WIRE IS DESCRIBED ON 1270675, PG 2:48.0
 3. PART NO. IS 329636, VENDOR CODE IS 00779.

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
F.CD7	18			S-067-85-B67-1-6	
F.CD5	20			S-1367-1-8	
4				SEE-CD5	
3				SEE-CD2	
2				SEE-CD2	
F.CD1	20			S-1367-1-8	

PART NO.	DESCRIPTION	VENDOR
5	7271-B-3	CKT BKR (82647)
4	1570141-2	FUSE ASSY
3	B-171	TERM BLOCK (71785)
2	1560321-12	CLUTCH
1	1560322-26	MOTOR ASSY

EQUIPMENT TABLE		
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX=CESSNA SPEC. NO. S-XXX OR CMXXXX=CESSNA STD. NO.		
SUPERSEDES: SUPERSEDED BY:		

WIRE TABLE		
CONTRACT NO:		
DESIGN	HARDEN	7-28-67
GROUP	N. W. Lee	7-29-67
DRAWN	HARDEN	7-28-67
CHECK	*YACSHAW	8-30-67
STRESS	ang	8-31-67
PROJECT	m. G. G.	8-4-67
APPD		
SIZE	C	1270625
CODE IDENT. NO.	71379	
DWG NO.	1270625	
SCALE:	NONE	206's
PAGE:	14.4	

MISCELLANEOUS SECTION

Cessna.

DRAWING NO.

1270625

PAGE: 16.0

DRAWN	GLW	TITLE: WIRING DIAGRAM---
DATE	9-5-63	MODEL 205, 206

APP'D


RRS
[Signature]

REV:

CESSNA AIRCRAFT CO., COMMERCIAL AIRCRAFT DIV., WICHITA, KANS.

(SR 4204)

CHG LIST	REVISION	BY DATE	CHK APPD
A	ADDED WIRE LENGTHS TO WIT; REMOVED 1270461-1 FROM E/T ADDED P206 & U206 TO MODEL BLOCK	WJR 8-18-63	RES TV NAC



NOTES:

1. COLOR CODED WIRES ARE VENDOR FURNISHED.
2. "F" PREFIX USED ON THIS DRAWING INSTEAD OF "H" BECAUSE THE WIRES ARE THE SAME AS THOSE USED IN MODEL 210. THIS DIAGRAM IS SCHEMATICALLY IDENTICAL TO 1270405 PAGE 16.1 WIRING DIAGRAM AND IS FOR REF ONLY.

ITEM NO.	PART NO.	DESCRIPTION	INSTALLED ON
5			
1	S-1360-15	CIRCUIT BREAKER	
3	1414249-2	MOTOR ASSY	
2	S-1491-1	BUSHING TERMINAL	
1	1414268-1	SWITCH ASSY	

EQUIPMENT TABLE

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	N/A	SERIALS
F-MB4	16		113	S-1493-2	S-1367-2-6	0700718
F-MB3	16		26	S-1493-2	S-1367-2-6	0700718
F-MB2	16		12	S-1493-2	S-1493-2	0700718
F-MB1	16		131	S-1367-2-6	S-1493-2	0700718

WIRE TABLE

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIVISION, WICHITA, KANSAS

DRAWN	NAME	DATE	TITLE
G. WOOD		9-6-63	WIRING DIAGRAM -
CHKD	R. H. H. H.	9-11-63	VERTICALLY
CHECK	R. H. H. H.	9-23-63	ADJUSTING SEAT
PROJ	H. H. H. H.	9-23-63	(OPT)

Cessna.

CHG NO. 1270625

SUPERSEDED BY	SUPERSEDES	MODEL	REV	PAGE
		206, P206 & U206	A	16.1

FORM NO. 80-18

APPENDIX A

HYDRAULIC COMPONENTS REPAIR

TABLE OF CONTENTS

	Page
A1 GENERAL INFORMATION	A1-1
A2 REPAIR OF POWER PACK	A2-1
A3 REPAIR OF HYDRAULIC PUMP	A3-1
A4 REPAIR OF MAIN GEAR ACTUATOR	A4-1
A5 REPAIR OF NOSE GEAR ACTUATOR	A5-1
A6 REPAIR OF LOCK, UNLOCK, & SEQUENCE CYLINDERS . .	A6-1
A7 REPAIR OF DOOR CYLINDERS	A7-1

SECTION A

GENERAL INFORMATION

A1-1. The following pages cover, in step-by-step procedure, the repair of the Power Pack and other hydraulic system components. Since emphasis here is on repair, not overhaul, of the basic components of the hydraulic system, it is unlikely that the mechanic will go through all of the operations described. Instead, he will repair the particular item which is causing the difficulty.

NOTE

To isolate the hydraulic item causing malfunction, see the Trouble Shooting Charts in Section 5A, and if possible, perform Hydro Test testing.

A1-2. REPAIR VERSUS REPLACEMENT. Often the moderate trade-in price for a factory-rebuilt component is less than the accumulated cost of labor, parts, and (often time consuming) trial and error adjustment. Repair or replacement of a component will depend on the time, equipment, and skilled labor that is locally available.

A1-3. REPAIR parts and equipment are available from the Cessna Service Parts Center.

A1-4. EQUIPMENT AND TOOLS.

A1-5. HYDRO TEST. The Hydro Test is a portable Hydraulic Service Unit, designed specifically to supply hydraulic pressure for cycling the landing gear for checking or servicing this system when the engine is not operating. In addition to cycling the landing gear, the Hydro Test can be used for filling the Power Pack reservoir, bleeding the system, reading system pressure, and testing components prior to installation. The unit is mounted in a metal cabinet and is on wheels.

A1-6. HAND TOOLS. The following tools are necessary for repair work on the Power Pack and other hydraulic components:

- Snap Ring Pliers
- Strap Wrench (for removing door solenoid and various cylinder barrels of the hydraulic actuators)
- Needle-nose Pliers
- Pin Punches
- Duck-bill Pliers
- Box and Open End Wrenches

Locally fabricated items, handy for Power Pack repair, are various 1/4" aluminum rods ground to a gradual taper and hooks formed from brass welding rod to extricate small plungers from hydraulic ports. Hook formed on brass welding rod must not be over 1/16-inch in length so as not to scratch or score the bore. Various sizes of Allen wrenches may be welded or brazed to "T" handles for use when removing, installing, or adjusting the various internal wrenching plugs or valves.

A1-7. COMPRESSED AIR. The easiest way to remove some hydraulic parts in inaccessible galleries

of the Power Pack is a quick blast of compressed air from behind. Parts can be blown out in seconds which would take endless "fishing" operations to extricate otherwise. An air hose and nozzle is a common-sense tool.

A1-8. GENERAL REASSEMBLY CONDITIONS. During reassembly of the hydraulic components, lubricate O-rings and back-up rings with Dow Corning DC-4 compound applied sparingly. All other moving parts should be lubricated with hydraulic fluid.

SHOP NOTES:

SECTION A2

REPAIR OF POWER PACK

TABLE OF CONTENTS

	Page	
POWER PACK DISASSEMBLY	A2-1	
Disassembly of Manifold	A2-4	Primary Relief Valve
COMPONENTS DISASSEMBLY	A2-4	Secondary Relief Valve
Hand Pump Valves	A2-4	Hand Pump Valves
Secondary Relief Valve	A2-4	Manifold Assembly
Primary Relief Valve	A2-4	Handle and Handle-Release Mechanism .
Priority Valve	A2-4	Manifold Installation
System Inlet Check Valve	A2-7	PRESSURE ADJUSTMENTS
Standpipe and Filter	A2-7	General Conditions
Door Vent Valve	A2-9	Handle-Release Mechanism
Handle and Handle-Release Mechanism .	A2-9	Secondary Relief Valve
POWER PACK REASSEMBLY	A2-9	Primary Relief Valve
Door Vent Valve	A2-9	Priority Valve
Standpipe and Filter	A2-9	Door Solenoid Valve
System Inlet Check Valve	A2-9	Door Vent Valve
Priority Valve	A2-9	Emergency Hand Pump Test
		Reservoir Leakage Test

NOTE

The door vent valve, shown in figures A2-1 and A2-2, is not installed in early 1966 model Power Packs. However, replacement Power Packs (new or remanufactured) have this valve installed.

A2-1. POWER PACK DISASSEMBLY. After the Power Pack has been removed from the airplane and all ports are capped or plugged, spray with cleaning solvent (Federal Specification P-S-661, or equivalent) to remove all accumulated dust or dirt. Dry with filtered compressed air. To disassemble the unit, proceed as follows:

- a. Remove reservoir cover retaining nut and O-ring. Cover is a snug fit on reservoir. Use a soft mallet and tap cover lightly to remove. Remove large O-ring.
- b. Remove spacer from center bolt, cut safety wire and remove baffle from reservoir. Drain remaining hydraulic fluid from reservoir.
- c. Remove reservoir cover attaching stud (center). This stud may be removed by using a double lock nut at top of stud. Use care to prevent damage to stud threads.
- d. Turn Power Pack upside down so that top of reservoir serves as a support base.

NOTE

A holding fixture (Part No. HF-1025) may be used instead of removing the center stud if desired. This is a plate type fixture for use in a vise. The fixture is available from the Cessna Service Parts Center.

- e. Remove pivot clevis pin and forward clevis pin from hand pump handle linkage, and remove hand pump handle assembly.
- f. Remove screws attaching electrical wires to terminal strip and Power Pack. Remove small capacitor from beneath electrical wires and remove terminal strip.

NOTE

All electrical wires are coded with color stripes. Disregard color of wire terminals or plastic sleeving. If color codes are matched when wires are reinstalled, the wires will be connected correctly.

- g. Cut safety wire and remove screws attaching landing gear up-down switch and bracket. Retain washers between bracket and Power Pack.
- h. Cut safety wire and remove four Allen head screws attaching hand pump bracket, and remove bracket.
- i. Remove lock-out solenoid retaining nut from hand pump bracket and remove solenoid from bracket. Use care to prevent damage to solenoid electrical wires.
- j. Turn Power Pack over and cut safety wire at time-delay valve.

* Items 27 through 33 are deleted on the 1968 model Power Packs. On remanufactured Power Packs, these parts are replaced with an O-ring and plug.




Figure A2-1. Reservoir and Main Body Components

References for Figure A2-1

1. Standpipe and Filter

PRIMARY RELIEF VALVE

2. Poppet Seat
3. O-Ring
4. Back-Up Ring
5. Poppet
6. Ball
7. Button
8. Spring
9. Button
10. Retainer
11. Adjusting Screw
12. Lock Nut

PRIORITY VALVE

13. Poppet O-Ring
14. Poppet
15. Poppet Seat
16. Poppet Seat O-Ring
17. Retainer O-Ring
18. Retainer

19. Baffle
20. Spacer
21. Snap Ring
22. Vent Filter
23. Reservoir Cover O-Ring
24. Reservoir Cover
25. O-Ring
26. Cap Nut

SECONDARY RELIEF VALVE

27. Adjusting Plug
28. Retainer
29. Spring
30. Button
31. Ball
32. Seat
33. Seat O-Ring
34. Sight Gage

HANDPUMP INLET VALVE

35. Snap Ring
36. Spacer
37. Filter
38. Seat O-Ring
39. Seat
40. Ball
41. Spring

TIME-DELAY VALVE

42. Retainer
43. Retainer Hex O-Ring
44. Retainer Body O-Ring
45. Ball
46. Spring
47. Spacer

48. Center Bolt
49. Reservoir and Body Assembly

DOOR VENT VALVE

50. Retainer
51. O-Ring
52. Spring
53. Poppet
54. Body
55. Pin

PRIORITY VALVE ADJUSTMENT

56. Button
57. Spring
58. Retainer (Adjusting Plug)

INLET CHECK VALVE

59. Spring
60. Plunger
61. O-Ring
62. Fitting O-Ring
63. Pressure Inlet Fitting
64. Snap Ring
65. Filler Line Filter

SHOP NOTES:

[illegible]

- k. Remove time-delay valve ball, spring, spacer, and spring by removing time-delay valve retainer.

NOTE

Do not remove time-delay valve plunger until after manifold assembly has been removed.

- l. Cut safety wire and remove screws attaching gear and rack protective cover. Remove cover.
- m. Remove clamp attaching electrical wires to door solenoid valve and remove safety wire from door solenoid valve.
- n. Cut safety wire and remove four screws attaching manifold assembly. Work manifold assembly from Power Pack, taking care to prevent loss of transfer tubes between manifold and Power Pack.
- o. Remove the seven transfer tubes from manifold or Power Pack.

CAUTION

As the manifold is separated from the Power Pack body, the rack on the landing gear selector spool becomes disengaged from the gear on the handle. This will permit the selector spool to move. Do NOT move the selector spool from its position. Never move it to a position that is more than flush with the manifold body at the end opposite the selector spool rack. If moved beyond this position, an O-ring will become caught and the selector spool will then be extremely difficult to remove.

A2-2. DISASSEMBLY OF MANIFOLD.

- a. Remove door solenoid by unscrewing from manifold. This solenoid is hand tightened. Use strap wrench or strip of sandpaper to grip door solenoid for removal. Remove plunger return spring.
- b. Remove plunger and spool by carefully pulling from manifold.
- c. Using a hook formed from brass welding rod and inserted into oil hole in transfer sleeve, withdraw sleeve from manifold.

NOTE

Be sure that end of hook is not over 1/16-inch long, and use with care to prevent scratching the bore in manifold. The sleeve will be hard to withdraw due to O-ring friction.

- d. Remove time-delay valve plunger, using a small wooden dowel inserted in center of plunger. The plunger should slide out of manifold easily.
- e. Remove landing gear selector spool by grasping rack end of spool and carefully pulling from manifold.

NOTE

Do not bend selector spool. Pull straight out. Do not remove gear rack from selector spool unless it is necessary to replace selector spool and manifold. The landing gear selector spool, time-delay plunger, and manifold are matched, lapped parts. If it is necessary to replace any one of these three parts, replace them as an assembly only.

- f. Remove landing gear handle-release retainer (adjusting plug), spring, and poppet from manifold. The end of the poppet has a ball which should remain in the poppet. If it doesn't, remove ball from manifold.
- g. Remove caps from fittings and wash manifold in cleaning solvent (Federal Specification P-S-661, or equivalent) and dry with filtered compressed air. Be sure internal passages are clean, then reinstall caps on fittings.

A2-3. COMPONENTS DISASSEMBLY.

A2-4. HAND PUMP VALVES.

- a. Pull hand pump plunger from Power Pack body.
- b. Using snap ring pliers, remove snap ring at inboard end of hand pump plunger.
- c. Remove gland and scraper from plunger.
- d. Inside reservoir, remove snap ring, spacer, and filter screen. Use a brass hook to remove seat, ball, and spring.

A2-5. SECONDARY RELIEF VALVE. (PRIOR TO 1968 MODELS.)

- a. Remove adjusting plug at top of secondary relief valve.
- b. Remove secondary relief valve retainer by unscrewing from body.
- c. Remove spring, button, and ball from body.
- d. Use a brass hook to remove seat from body. Use with care to prevent scratching bore.
- e. Remove O-ring from bottom of cavity.

A2-6. PRIMARY RELIEF VALVE.

- a. Loosen lock nut at top of primary relief valve.
- b. Remove adjusting screw and lock nut from top of relief valve.
- c. Unscrew retainer.
- d. Remove two buttons, spring, and ball.
- e. Remove poppet from poppet seat by lifting out of poppet assembly. The poppet and poppet seat are matched parts.
- f. Using a brass hook not over 1/8-inch long, pull poppet seat up out of body. Hook through holes in side of seat and use care not to damage bore in body.

A2-7. PRIORITY VALVE.

- a. Remove priority retainer from reservoir.




Figure A2-2. Center Section Components

HAND PUMP OUTLET VALVE

LANDING GEAR HANDLE LOCK-OUT SOLENOID

HAND PUMP OUTLET VALVE

- 22. Washer
- 23. Cotter Pin
- 24. Handle Stop
- 25. Clamp
- 26. Handle Guard
- 27. Pin
- 28. Handle Latch Spring
- 29. Screw
- 30. Washer
- 31. Pin
- 32. Handle Knob
- 33. Handle Stop
- 34. Handle
- 35. Lever Assembly
- 36. Pin

- 13. Spring
- 14. Ball
- 15. Seat O-Ring
- 16. Seat
- 17. Snap Ring
- 18. Power Pack Body

LANDING GEAR HANDLE LOCK-OUT SOLENOID

- 19. Solenoid
- 20. Retaining Nut
- 21. Stroke Adjusting Nut

- 1. Link
- 2. Pin
- 3. Washer
- 4. Cotter Pin
- 5. Allen Screw
- 6. Hand Pump Bracket
- 7. Scraper
- 8. Gland O-Ring (Internal)
- 9. Gland
- 10. Gland O-Ring (External)
- 11. Hand Pump Plunger
- 12. Plunger O-Ring




Figure A2-4. Handle and Handle-Release Mechanism

b. Turn Power Pack upside down and remove retainer (adjusting plug), spring, and button from bottom of Power Pack.

c. While Power Pack is upside down, push poppet and poppet seat into reservoir, using a punch of 1/8 inch maximum diameter. Make sure that face of punch is square and flat.

A2-8. SYSTEM INLET CHECK VALVE.

- a. Remove system pressure port fitting.
- b. Remove O-ring, plunger, and spring. Spring


and plunger should fall out of Power Pack after O-ring is removed. Use hook, if necessary, to remove O-ring.

A2-9. STANDPIPE AND FILTER.

a. The standpipe and filter assembly should not be removed unless it is damaged, since it is a press fit in the reservoir.

b. Remove vent filter by removing the snap ring.

c. Remove fill line filter by removing the fitting and snap ring.



LANDING GEAR SELECTOR SPOOL

1. Screw
2. Rack
3. Laminated Shim
4. Spool
5. Spool O-Ring

TIME-DELAY PLUNGER

9. Plunger
10. Spring

TRANSFER SLEEVE

11. Sleeve
12. Sleeve O-Ring

13. Spool

14. O-Ring

15. Transfer Tube O-Rings

16. Transfer Tubes

HANDLE RELEASE VALVE

17. O-Ring

18. Poppet

19. Poppet O-Ring

20. Spring

21. Retainer (Adjusting Plug)

DOOR SOLENOID VALVE

22. Plunger

23. Pin

24. Spring

25. Solenoid O-Ring

26. Solenoid

Figure A2-5. Manifold Assembly

A2-10. DOOR VENT VALVE.

- a. Remove door vent valve from reservoir. The door vent valve should not be disassembled except for replacement of parts.
- b. Remove pin from valve body and retainer. Use care when removing pin, as the spring is under a slight load.
- c. Remove retainer, O-ring, and poppet from valve body.

A2-11. LANDING GEAR HANDLE AND HANDLE-RELEASE MECHANISM.

- a. Remove two hex-head retainers (adjusting plugs), springs, and plungers from handle return housing.
- b. Cut safety wire and remove two screws attaching handle release housing to Power Pack, and remove the housing.
- c. Using a punch, drive roll pin from cam, and remove cam from landing gear handle shaft.
- d. Pull handle assembly from Power Pack.

NOTE

Do not remove spacer, handle, or gear from handle shaft except for replacement of parts.

- e. Landing gear handle may be disassembled as illustrated in figure A2-4.

NOTE

On the 1968 models, an oilite bushing is added to the Power Pack housing to support the landing gear control shaft through the Power Pack. Do not remove bushing except for replacement.

- f. Emergency hydraulic hand pump handle may be disassembled as illustrated in figure A2-3.

A2-12. POWER PACK REASSEMBLY. After Power Pack has been completely disassembled, remove and discard all O-rings and gaskets. Wash all parts in dry cleaning solvent (Federal Specification P-S-661, or equivalent) and dry with filtered compressed air. Inspect all threaded surfaces for serviceable condition and cleanliness. Inspect all parts for scratches, scores, chips, cracks, and indications of excessive wear. Use new O-rings and gaskets during reassembly. Lubricate all O-rings with Dow-Corning DC-4 compound during reassembly. Lubricate all threaded surfaces on the various valves in the Power Pack with MIL-G-7711 grease (or equivalent) before installing.

A2-13. DOOR VENT VALVE.

- a. Install poppet in body and insert spring in body. Be sure that spring enters poppet.
- b. Lubricate and install O-ring on retainer and insert retainer in valve body. Align holes in retainer with holes in valve body.
- c. Install pin through valve body and retainer.
- d. Lubricate threads on valve body (MIL-G-7711) and install assembly in reservoir. Tighten securely.

A2-14. STANDPIPE AND FILTER.

- a. If standpipe and filter assembly was removed, press into body until standpipe bottoms.
- b. Replace vent filter and snap ring.
- c. Install filler line filter and secure with snap ring.
- d. Install back-up ring and O-ring on fill and drain tee, and install tee as shown in figure 5-9.

A2-15. SYSTEM INLET CHECK VALVE.

- a. With pressure port up, drop spring into port.
- b. Drop in plunger, making sure that small end of plunger goes into spring. Check freeness of plunger in body by depressing plunger against spring. Use small wood dowel or plastic rod to depress plunger when checking freedom of movement. Plunger must move freely in body bore.
- c. Lubricate and install O-rings on flange of fitting and at end of fitting. Lubricate threads (MIL-G-7711), insert fitting, start the threads, and tighten securely.

A2-16. PRIORITY VALVE.

- a. Lubricate and install O-ring on poppet and insert poppet in body through reservoir. Push poppet down firmly. Either surface may be used as seating surface.
- b. Inspect poppet seat for sharp seating edge. Lap as necessary to obtain a sharp seating edge. Lubricate and install O-ring on poppet seat.
- c. Install poppet seat in body through reservoir, with sharp seating edge toward poppet. Push poppet seat down firmly against poppet.
- d. Lubricate and install O-ring on retainer assembly, lubricate retainer threads (MIL-G-7711), and install retainer. Tighten securely.
- e. Turn Power Pack upside down, lubricate spring and button (MIL-G-7711) and install body. Apply lubricant to hold button in spring and install with button in hole first.
- f. Lubricate (MIL-G-7711) threads on retainer (adjusting plug) and install. This plug provides adjustment for the priority valve. Install flush at this time.

A2-17. PRIMARY RELIEF VALVE.

- a. Inspect poppet and poppet seat for pitting or scoring. Since they are matched parts, if either or both are pitted or scored, replace as an assembly only.
- b. Lubricate and install O-ring and back-up ring on seat, insert poppet in seat, and install assembly in body.
- c. Lubricate ball, buttons, and spring (MIL-G-7711). Install with ball entering hole first. Be sure that ball enters cavity at top of poppet.
- d. Lubricate threads on retainer (MIL-G-7711) and install over button and spring. Tighten securely.
- e. Lubricate threads of adjusting screw (MIL-G-7711) and install at top of retainer. Turn adjusting screw full down to lock primary relief valve closed, but do not tighten lock nut. This is done so that the secondary relief valve, which opens at a higher pressure, can be adjusted before the primary relief valve is adjusted.




Figure A2-6. Timing of Handle and Selector Spool

A2-18. SECONDARY RELIEF VALVE (PRIOR TO 1968 MODELS.)

- Lubricate and install O-ring in body. Make sure O-ring seats properly.
- Inspect seating surface of seat. It should have a very sharp edge. Seat may be lapped to obtain a sharp edge.
- Install seat in body, with sharp edge of seating surface up.
- Apply lubricant (MIL-G-7711) to hold ball, button and spring together, and insert in body with ball toward seat.
- Lubricate threads on retainer (MIL-G-7711). Start retainer over spring and tighten securely.
- Lubricate threads on adjusting plug (MIL-G-7711) and install at top of retainer. Do not tighten adjusting plug. Screw it down only until spring is contacted. This is done so that air may be bled from valve during adjustment.

A2-19. HAND PUMP VALVES.

- Insert spring and ball in body through reservoir.
- Inspect seating surface of seat. It should have a very sharp edge. Seat may be lapped if necessary to obtain a sharp edge.
- Lubricate and install O-ring on seat and install seat in body through reservoir.

- Install filter screen, spacer, and snap ring in body through reservoir.
- Install spring and ball in hand pump plunger.
- Inspect seating surface. It should have a very sharp edge. Seat may be lapped if necessary to obtain a sharp edge.
- Lubricate and install O-ring on seat and install seat in hand pump plunger. Secure with snap ring.
- Lubricate and install O-ring on plunger, and internal and external O-rings on bronze gland.
- Install gland on plunger, and insert plunger and gland into body.
- Install scraper ring in counterbore of gland. Install so that flat surface of scraper is in counterbore of gland and inner protruding part of scraper faces outward.
- Thread lock-out solenoid wires through hand pump bracket, position solenoid, and install retainer nut. Do not tighten lock-out solenoid retainer nut at this time.

- Attach hand pump bracket to Power Pack. Shift bracket so that lock-out solenoid plunger does not bind in any way with the landing gear handle barrier, then tighten bracket attaching screws, but do not safety at this time.

- Install hand pump handle with pivot and linkage pins. Secure with cotter pins.

A2-20. MANIFOLD ASSEMBLY.

- a. Lubricate and install the O-ring on landing gear selector spool, and the O-ring in manifold at the opposite end.

NOTE

If landing gear selector spool, manifold, and time-delay plunger are being replaced, install rack with a new laminated shim on selector spool. The landing gear selector spool, time-delay valve plunger, and manifold are matched, lapped parts. If necessary to replace, replace as an assembly only.

- b. Insert selector spool in manifold from landing gear handle end of manifold. Insert only until end of selector spool is flush with solenoid end of manifold.

CAUTION

If the selector spool is moved much more than flush with the manifold at the end opposite the rack (before the manifold is installed and the rack engaged properly with the gear on the landing gear handle), an O-ring will become caught. The selector spool will then have to be removed, the manifold cleaned to remove all O-ring particles, and a new O-ring installed. The selector spool then must be re-installed correctly.

- c. Check that spool slides freely.
- d. Inspect door solenoid spool for freedom of movement within the transfer sleeve assembly.

NOTE

Spool and sleeve are matched parts. If necessary to replace, replace as an assembly only.

- e. Lubricate and install O-rings on transfer sleeve and install sleeve in manifold.
- f. Attach plunger to door selector spool with pin.
- g. Lubricate and install O-ring on solenoid.
- h. Lubricate solenoid threads and spring (MIL-G-7711) and insert into plunger, then install solenoid over spring and plunger. Screw solenoid into manifold. Do not overtighten solenoid, but tighten securely by hand. Safety the solenoid to adjacent Power Pack mounting lug.

A2-21. LANDING GEAR HANDLE AND HANDLE-RELEASE MECHANISM.

- a. Assemble emergency hydraulic hand pump handle as illustrated in figure A2-3.
- b. If the landing gear handle was disassembled, assemble as illustrated in figure A2-4. When assembling gear handle, insert pin in spring and place in slot of handle. Using a small punch, compress spring slightly to install clevis pin.
- c. If the landing gear handle shaft or gear was removed, the parts must be indexed and assembled as shown in figure A2-6.
- d. Lubricate shaft (MIL-G-7711), install spacer on shaft with roll pin, and insert shaft into Power Pack.
- e. Install cam with roll pin. Both sides of cam

surfaces are identical. Check landing gear handle for freedom of movement in Power Pack. Check for slight end play in shaft. If handle binds, remove cam and lap inside boss of cam to obtain slight end play in shaft with cam installed.

- f. Install handle-release housing and safety attaching screws. Check landing gear handle for freedom of movement.

NOTE

Do not install plungers, springs, and hex-head retainers (adjusting plugs) at this time.

A2-22. MANIFOLD INSTALLATION.

- a. Lubricate and install O-rings on the seven transfer tubes.
- b. Insert transfer tubes into Power Pack body.
- c. Install time-delay valve plunger in manifold. Plunger must move freely in manifold without binding.
- d. Mate manifold to Power Pack body, using care to prevent damage to O-rings on transfer tubes. Align dowel pin in Power Pack with dowel hole in manifold.

NOTE

When installing manifold, time the landing gear handle assembly to rack on selector spool as shown in figure A2-6. Refer to the following steps if binding exists.

- e. Install four manifold attaching screws and washers. Torque screws to 35 pound-inches and safety. Do not over-torque screws, as this will cause binding in the movement of landing gear handle.

NOTE

If a new landing gear selector spool, time-delay plunger, and manifold (a matched assembly) are being installed, the rack on the selector spool must be shimmed properly to provide a slight backlash (free movement) between the teeth of the rack and the teeth of the gear on the handle. This adjustment is provided by a laminated shim. If excessive backlash exists, a new shim must be used. If no backlash exists, or if a new shim is being installed, the "trial-and-error" method should be used, since the backlash is determined after manifold attaching screws are installed and torqued. Remove one lamination at a time until backlash exists when screws are torqued properly, then do not remove any more laminations. Apply Loctite to rack retainer screws only after final adjustment of shim has been determined and screws are being installed for the last time.

- f. Lubricate and install two O-rings on time-delay valve retainer.
- g. Lubricate (MIL-G-7711) and insert larger spring and spacer in body through reservoir.
- h. Lubricate (MIL-G-7711) and insert ball and smaller spring in time-delay valve retainer (ball next to top of retainer).

i. Lubricate threads on time-delay valve retainer (MIL-G-7711) and install retainer in body through reservoir. Do not overtighten time-delay valve retainer as this will cause the landing gear selector to bind in the manifold. After tightening time-delay valve retainer, check for freedom of movement of landing gear handle and selector spool.

j. Thoroughly lubricate handle return springs and plungers (MIL-G-7711) and install in housing with hex-head retainers. Do not tighten retainers at this time.

k. Lubricate and install two O-rings on landing gear handle release plunger and insert plunger in body.

l. Lubricate landing gear handle release spring and retainer (MIL-G-7711) and install in body. Tighten retainer (adjusting plug) until almost flush with body.

m. Install gear and rack protective cover. Safety attaching screws.

n. Install landing gear up-down switch and the switch attaching bracket. Note that washers are used between the bracket and Power Pack. Switch bracket has slotted holes for switch adjustment.

NOTE

With landing gear handle at centerline of barrier, adjust up-down switch so that switch clicks at an equal distance up and down from centerline of barrier as landing gear handle is moved up and down.

o. Install terminal strip and place capacitor alongside the strip. Connect electrical wires to terminal strip and ground, clamping wires to door solenoid valve. If the wires from the handle lock-out solenoid are not long enough, rotate the lock-out solenoid until the wires will reach their connections. Tighten the lock-out solenoid retainer nut, and safety the retainer nut and hand pump bracket attaching screws together.

NOTE

Electrical wires are coded with color stripes. Disregard color of wire terminals or plastic sleeving. If color codes are matched when wires are installed, the wires will be connected correctly.

p. A small nut is provided at the handle lock-out solenoid to adjust the stroke of the solenoid plunger. Adjust the nut so that the solenoid plunger fully engages the handle detent when released, but clears the handle when it is actuated, even when slight side-pressure is exerted manually on the handle.

q. Continue reassembly of Power Pack after pressure adjustments have been completed.

A2-23. PRESSURE ADJUSTMENTS.

NOTE

This procedure requires a minimum of test equipment and is intended for bench-testing the Power Pack after field repair.

TEST EQUIPMENT.

- a. One hydraulic hand pump of 2000 psi capacity.
- b. One hydraulic pressure gage of 2000 psi capacity.
- c. One hydraulic pressure gage of 150 psi capacity.
- d. High pressure hose to attach hand pump to Power Pack inlet fitting.
- e. Drain hose to connect to Power Pack reservoir drain fitting.

A2-24. GENERAL CONDITIONS. Use only clean hydraulic fluid (MIL-H-5606). Install a tee at the hand pump pressure outlet, and attach the 2000 psi pressure gage and the pressure hose to the tee. Connect the hose from the hand pump to the Power Pack pressure inlet fitting, labeled "PUMP." Connect drain hose to Power Pack reservoir fill and drain tee. Cap all other fittings with high-pressure caps.

NOTE

Some Hydro Test units are equipped with a hand pump, and others are provided with a pressure jack and provisions to install a hand pump.

A2-25. HANDLE-RELEASE MECHANISM. (See figure A2-7.) The following procedure outlines preliminary adjustments to set the handle-release detent spring load and the handle-return spring load adjusting plugs in approximately their correct positions before installing the Power Pack in the airplane. After it has been installed, the system must be checked and final adjustments, if needed, made at that time.

- a. With handle-return spring adjusting plugs (2 and 3) not tightened, screw in detent spring adjusting plug (1) until it is approximately flush. The spring, however, must not bottom out.
- b. Place handle in up-detent position, then hold it beyond this position (in overtravel).
- c. Tighten forward handle-return spring adjusting plug (2) until handle just starts to move out of overtravel, then loosen the adjusting plug one turn.
- d. Place handle in down-detent position, then hold it beyond this position (in overtravel).
- e. Tighten aft handle-return spring adjusting plug (3) until handle just starts to move out of overtravel, then loosen the adjusting plug one turn.
- f. Place handle in up-detent position and tighten handle-release detent spring adjusting plug (1) until the spring bottoms out, then back the adjusting plug out two turns.
- g. Handle must hold in both detent positions, but must return with a positive snap when manually released from either detent position. Handle-release detent spring adjusting plug (1) may be readjusted slightly more or slightly less than the two turns specified in the preceding step if necessary.

A2-26. SECONDARY RELIEF VALVE. (PRIOR TO 1968 MODELS.)

- a. With landing gear handle in either up or down position, apply test pump pressure very slowly until fluid flows from secondary relief valve.

CAUTION

It is very important that the test pump be

operated very slowly as pressure is being increased to bleed the secondary relief valve. If the test pump is operated rapidly, damage to the valve can occur as air permits parts to "slam" against each other.

- b. Bleed air from Power Pack by cracking cap on door-open fitting.
- c. Adjust retainer plug at top of valve until valve cracks at 1950 ± 00 , -50 psi (using a slow flow). Bleed pressure by cracking cap on door-open fitting after each adjustment.
- d. Safety wire the secondary relief valve to the time-delay valve.

A2-27. PRIMARY RELIEF VALVE.

- a. Loosen lock nut and back adjusting screw at top of valve out until very little load is left on spring.
- b. With landing gear handle in neutral, apply pressure until fluid flows from primary relief valve.
- c. Adjust primary relief valve until valve cracks at 1700 psi. Adjusting this valve to 1700 psi cracking pressure will give approximately 1800 psi when valve is in a flow condition. Bleed pressure after each adjustment by cracking cap on door-open fitting. Tighten lock nut on adjusting screw after obtaining correct adjustment.

A2-28. PRIORITY VALVE.

- a. Place landing gear handle in up position and remove cap from gear-up fitting.
- b. Apply pressure and note priority valve cracking pressure by observing pressure gage when fluid first starts to flow from gear-up port.

- c. Adjust priority valve to crack at 750 psi. Bleed pressure after each adjustment by cracking cap on door-open fitting.
- d. Disconnect test pump and cap all open fittings.

A2-29. DOOR SOLENOID VALVE.

- a. Remove caps from door-open and door-close fittings on Power Pack.
- b. Connect Test Harness as shown in figure 5A-23.
- c. With Test Harness switch in OFF position, and landing gear handle in either up or down neutral, apply pressure and note that fluid flows from door-open fitting.
- d. With Test Harness switch in either gear up or down position, landing gear handle in either up or down neutral, apply pressure and note that fluid flows from door-close fitting.
- e. Disconnect test equipment and cap all open fittings.

A2-30. DOOR VENT VALVE.

- a. Remove cap from door-open fitting on Power Pack, and attach pressure hose from hand pump with 150 psi pressure gage to door-open fitting.
- b. Slowly apply 50 psi pressure and check to see that fluid flows from door vent valve.
- c. Increase pressure to 100 psi minimum and check to see that door vent valve shuts off fluid flow, except for slight fluid seepage through the valve.
- d. Relieve pressure by cracking hose fitting from hand pump.
- e. Disconnect test pump and cap all open fittings.




Figure A2-7. Handle Release Adjustment

A2-31. EMERGENCY HAND PUMP TEST.

- a. Fill reservoir with clean MIL-H-5606 hydraulic fluid to the top of the standpipe in reservoir.
- b. Remove cap from door-open port and operate emergency hand pump until fluid flows from port with no evidence of air in the system. Replenish reservoir with clean hydraulic fluid as necessary to maintain fluid level.
- c. After pump is primed and bled of all air, remove fitting and install 2000 psi gage at door-open port.
- d. Operate emergency hand pump very slowly until pressure on gage stops increasing, indicating that the secondary relief valve has opened.

CAUTION

It is very important that the hand pump be operated very slowly as pressure is being increased to bleed the secondary relief valve. If the hand pump is operated rapidly, damage to the valve can occur as air permits parts to "slam" against each other.

Maximum indication on the gage should be 1900 to 1950 psi. During the pumping operation, the emergency hand pump should not feel spongy in either the up or down stroke.

- e. Crack gage in door-open port to release pressure, remove gage, reinstall and cap door-open fitting, and drain fluid from reservoir.

To complete the reassembly of the Power Pack, proceed as follows:

- a. Install reservoir cover attaching stud. Install with longer threaded end down, and screw in until stud bottoms in reservoir.
- b. Install baffle and center stud spacer. Safety wire primary relief valve lock nut to screened standpipe.
- c. Lubricate and install O-ring in groove of reservoir cover.

- d. Position reservoir cover on reservoir, aligning index marks on reservoir and cover. Vent fitting in cover points to the left with Power Pack in airplane.

CAUTION

Be sure that the large O-ring is positioned properly in the groove of the reservoir cover and that the O-ring is not pinched as the cover is installed.

- e. Lubricate and install O-ring at top of cover around center stud.
- f. Install cover retaining nut (cap nut), tighten, and safety.

A2-32. RESERVOIR LEAKAGE TEST.

- a. Remove filler and drain tee, and attach hand test pump and 150 psi gage to filler port.
- b. Remove cap from reservoir vent fitting at top of reservoir and operate test hand pump until reservoir is completely full, indicated by fluid coming out of the fitting.
- c. Cap reservoir vent fitting.
- d. Operate test hand pump very slowly until pressure gage indicates 15 psi maximum.
- e. Check for leaks. There should be no external leakage.
- f. Crack vent fitting to release pressure, remove test equipment, drain reservoir, and cap fittings.
- g. Hydraulic Power Pack is now ready to be installed in the airplane.

NOTE

After Power Pack is installed in airplane, refill reservoir.

SHOP NOTES:

SECTION A3

REPAIR OF HYDRAULIC PUMP

A3-1. DISASSEMBLY. (See figure A3-1.)

- a. Plug all ports and clean outside of pump with solvent.
- b. Clamp pump in vise, shaft down and remove cap screws and washers (1 and 2).
- c. Remove rear housing (3) by rocking from side to side and sliding it off the gear shafts and dowel pins. In case of sticking, gently tap, with either plastic or rubber hammer, from side to side. Do not pry sections apart with a screwdriver. Scratches caused by pry tool will prevent sealing of mating surfaces.

NOTE

Do not disassemble rear housing (3).

- d. Remove idler gear assembly (16).
- e. Remove snap ring (4) from drive shaft, being careful not to scratch bearing surface of drive shaft.
- f. Remove gear (5) and key (6) from drive shaft (11).
- g. Remove remaining snap ring (4) from drive shaft (11).
- h. Remove drive shaft (11) from front housing (12) by pulling it out of housing by splined end.
- i. Remove diaphragm (15) from front plate (12) by prying with a sharp tool.
- j. Remove phenolic back-up gasket (7) and protector gasket (14) from front plate (12).
- k. Remove diaphragm seal (8) from front plate (12).
- l. Remove snap ring (10) and drive shaft seal (9) from bore in front plate (12).

A3-2. INSPECTION OF PUMP. Clean all metal parts with cleaning solvent and dry with filtered compressed air. Prior to reassembly of the pump, inspect all parts as follows:

ITEM	INSPECTION	REPAIR
Gears and Shafts.	Inspect drive gear shaft for broken splines.	Replace shaft if damaged.
Gears and Shafts.	Inspect both the drive gear and idler gear shaft at bearing points and shaft seal areas for rough surfaces and excessive wear. If shafts measure less than .4360 in bearing area, they should be replaced.	Replace drive gear shaft. Replace idler gear shaft.
	Inspect gear face for scoring and excessive wear. If gear width is below .1950, drive gear or idler gear should be replaced.	Replace drive gear. Replace idler gear.
	Visually inspect snap rings on idler gear shaft. They should be in grooves.	Replace if necessary.
	Visually inspect edges of gear teeth to see if they are too sharp.	Break sharp edge with emery cloth.
	Visually inspect bearings for scratches or scoring. Measure I.D. bearings. If I.D. measures more than .4400, front plate should be replaced.	Replace front plate assembly (Bearings are not available as separate items).
Front Plate.	Visually inspect bearings for proper positioning. Bearings should be flush with islands in groove pattern. Splits in bearings should be in line with dowel pin holes and in position closest to the respective dowel pin hole.	Replace front plate assembly if bearings are out of position. (Bearings are not available as separate items).

Rear Housing.

Visually inspect inside gear pockets for excessive scoring or wear. Also measure I. D. and depth of gear pockets. I. D. should not exceed 1.691 and depth should not exceed .1972.

If badly scored or wear exceeds dimensions given, replace rear housing assembly.

Visually inspect bearings for scratches or scoring. I. D. should not exceed .4400.

If I. D. of bearing exceeds dimensions given, replace rear housing assembly.

Visually inspect bearings for proper positioning. Splits in bearings should be in line with dowel pins and in position closest to the respective dowel pin.

If bearings are out of position, replace rear housing. (Bearings are not available as separate items).




Figure A3-1. Engine-Driven Hydraulic Pump

A3-3. REASSEMBLY.

NOTE

The diaphragm (15), phenolic gasket (7), protector gasket (14), diaphragm seal (8), drive gear snap rings (4), shaft seal (9), snap ring (10), copper crush washer (2), and key (6) should be replaced with new parts when reassembling hydraulic pump. Major Seal Repair Kit No. 20240-36 consisting of the above parts is available from the Cessna Service Parts Center.

- a. Install new shaft seal (9) in front plate with flat metal side of seal in front plate and the tapered internal part of seal toward pump shaft splines. Install snap ring (10) in groove in front plate with sharp edge of snap ring toward shaft splines.
- b. Place diaphragm seal (8) on front plate (12) with flat side of seal down (cup side of seal up). Using a dull pointed tool, work diaphragm seal to bottom of grooves in front plate. Be sure that seal is all the way down in grooves of front plate.
- c. Press protector gasket (14) and phenolic back-up gasket (7) into cup of diaphragm seal.
- d. Place diaphragm (15) on top of phenolic back-up gasket with bronze face of diaphragm up, next to the gears. The two small depressions on the bronze

face must match the two depressed areas in the rear housing.

NOTE

Protector gasket (14), phenolic back-up gasket (7), and diaphragm (15) must fit inside cup of diaphragm seal (8).

- e. Coat drive shaft (12) with grease to prevent damage to seal (9) as drive shaft is installed.
- f. Work drive shaft (12) through shaft seal (9) and into position.
- g. Install snap ring (4) in groove on shaft next to diaphragm.
- h. Place key (6) in slot in drive shaft and install gear (5) over key in shaft.
- i. Install snap ring (4) in groove of shaft (11) next to gear (5).
- j. Install idler gear assembly (16).
- k. Slide rear housing assembly (3) over gear shafts until dowel pins (13) are engaged.
- l. Install cap screws (1) with copper crush washer (2) on the 1-3/4 inch long screw which passes through the suction port of the pump. Tighten cap screws evenly to torque value of 7-10 lb ft.
- m. Rotate pump shaft by hand. Pump will have small amount of drag, but should turn freely after short period of use.

SHOP NOTES:

SECTION A4

REPAIR OF MAIN GEAR ACTUATOR

A4-1. LEADING PARTICULARS.

Cylinder Bore Diameter	2.125 in.
Piston Diameter	2.122 in.
Piston Rod Diameter	0.934 in.
Cylinder Stroke	2.937 in.
Shaft Rotation - Loaded	161°(min)
Shaft Rotation - Unloaded	167°(max)

A4-2. DISASSEMBLY. (See figure A4-1.)

- Remove screw (11) and remove end gland (10) and metering pin (13) by unscrewing end gland from cylinder body (2).
- Remove cap plug (24) and rotate shaft (1) to remove piston (5). Using a small rod push piston from cylinder body.
- Cut safety wire and remove cap (18) by removing screws (20) and washers (19).
- Remove set screw (21) from sector (16) and remove sector and shaft (1) from cylinder body. Retain washers (15).

NOTE

Unless defective, do not remove helicoils, name plate, bearings (14, 17 and 22), or roller (23).

- Remove O-ring (4) from cylinder body (2).
- Remove snap ring (8) and remove metering pin (13) from end gland (10). Remove and discard O-rings (7 and 9) from end gland.
- Thoroughly clean all parts in solvent (Federal Specification P-S-661, or equivalent).

A4-3. INSPECTION OF PARTS. Perform the following inspections to ascertain that all parts are in serviceable condition.

- Inspect all threaded surfaces for cleanliness and freedom from cracks and wear.
- Inspect cap (18), washers (15), sector (16), shaft (1), piston (5), roller (23) and cylinder body (2) for cracks, chips, scratches, scoring, wear, or surface irregularities which may affect their function or the overall operation of the actuator.
- Inspect bearings (14, 17 and 22) for freeness of motion, scores, scratches and Brinell marks.

A4-4. REPLACEMENT/REPAIR OF PARTS.

- Repair of small parts of the main gear actuator is impractical. Replace all defective parts with serviceable parts. Minor scratches or score may be removed by polishing with abrasive crocus cloth (Federal Specifications P-C-458) providing their removal does not affect the operation of the unit.
- During reassembly install all new O-rings.

A4-5. ASSEMBLY (See figure A4-1.)

NOTE


Use MIL-G-3278 lubricant on roller (23), bearings (14, 17 and 22), and sector (16), when installing parts in cylinder body.

- Press one bearing (22) into cylinder body until flush. Install roller (23) and press other bearing (22) in place to hold roller. Use care to prevent damage to bearings and roller.
- Press bearing (14) in until seated against retaining base in cylinder body. Press bearing (17) in until flush in cap (18).
- Place shaft (1) in cylinder body and place one washer (15) over shaft in cylinder body.
- Position sector (16) on splines of shaft so that index marks on shaft and sector are aligned, with teeth of sector toward cylinder end of actuator. Install and tighten set screw (21). Be sure end of set screw enters depression in shaft.
- Install new O-ring (4) in cylinder body bore and install new O-ring (6) on piston (5).
- Slide piston (5) into cylinder body, rotating shaft as necessary to engage first tooth on sector with first tooth on piston rack. Use care to prevent damage to O-rings in cylinder body bore and on piston.

NOTE

Lubricate sector and piston rack gears with MIL-G-3278 lubricant. Apply grease sparingly. Overgreasing may cause contamination of the hydraulic cylinder with grease, which may work past O-ring (4).

- Install washer (15) on shaft next to sector and install cap (18), washers (19) and screws (20). Tighten screws evenly to a torque value of 90-100 lbs-in. and install lockwire.
- Install new O-ring (9) in end gland (10) and install a new O-ring (7) on end gland.
- Install metering pin (13) in end gland (10) and install snap ring (8) on metering pin.
- Install end gland and metering pin assembly in cylinder and tighten until end of end gland is flush with end of cylinder. Install and tighten set screw (11).
- Install cap plug (24) at end of actuator assembly.



NOTE

Lubricate sector, piston rack gears, and all bearings with MIL-G-3278 grease during assembly of the main gear actuator.

1. Shaft
2. Cylinder Body
3. Name Plate
4. O-Ring
5. Piston
6. O-Ring
7. O-Ring
8. Snap Ring

9. O-Ring
10. End Gland
11. Set Screw
12. Locknut
13. Metering Pin
14. Bearing
15. Washer
16. Sector

17. Bearing
18. Cap
19. Washer
20. Screw
21. Set Screw
22. Bearing
23. Roller
24. Cap Plug

Figure A4-1. Main Gear Actuator

SECTION A5

REPAIR OF NOSE GEAR ACTUATOR

A5-1. LEADING PARTICULARS.

Cylinder Bore Diameter	0.740 in.
Piston Rod Diameter	0.437 in.
Stroke	8.238±0.065 in.
Length (C/L bushing to C/L of hook pins) (retracted)	11.580±0.031 in.
Ball Lock (unlocking pressure)	100±25 psi
Ball Lock (locking pressure)	275 psi (max)
Hook Lock (unlocking pressure)	250 psi (max)

A5-2. DISASSEMBLY (See figure A5-1.)

- Unlock cylinder by applying hydraulic pressure to port in head (25).
- Loosen locknut (12) at end of piston rod and unscrew parts (1 thru 11) as an assembly from piston rod. Remove locknut (12) from piston rod.
- Mark barrel (33) and head (25) so that same end of barrel may be reinstalled in head (25) when reassembling actuator. Remove safety wire from locknuts (32 and 35).
- Remove setscrew (18) in bearing end (17) and loosen locknut (35). While using a strap wrench on barrel (33), remove bearing end (17) from barrel.
- Pull piston (20) from barrel using care to prevent loss of balls (23) as piston is removed from barrel.
- Remove setscrew (18) from head (25) and loosen locknut (32). Using a strap wrench on barrel (33), remove head (25) from barrel.
- Remove O-ring (19) from head (25) and remove plunger (29) and parts (26 thru 31) by applying a sharp blast of air in the vent hole located in head (25).
- Remove all O-rings and backup rings.
- Disassemble hook assembly.

A5-3. INSPECTION OF PARTS. Make the following inspections to ascertain that all parts are in a serviceable condition.

- Inspect all threaded surfaces for cleanliness and for freedom from cracks and excessive wear.
- Inspect spring (6) for evidence of breaks and distortion. The free length of the spring must be 2.460±.080 inches and compress to 2.00 inches under a 19.5±1.95 pound load.
- Inspect spring (26) for evidence of breaks and distortion. The free length of the spring must be 1.055 inches and compress to .875 inch under a 35±3.5 pound load.
- Inspect hooks (4 and 10), spring guide (7), bearing end (17), piston and stop assembly (20), barrel (33), head (25) and bushing (24) for cracks, chips, scratches, scoring, wear, or surface irregularities which may affect their function or the overall function of the nose landing gear actuator.

A5-4. REASSEMBLY. Repair of most parts of the nose gear actuator assembly is impractical. Replace defective parts with serviceable parts. Minor scratches and scores may be removed by polishing with fine abrasive crocus cloth (Federal Specification P-C-458) providing their removal does not affect the operation of the unit. Install all new O-

rings and backup rings during reassembly of the actuator.

- Install O-ring (28) and backup ring (27) in groove on plunger (29).
- Insert spring (26) and plunger (29) into head (25). Install stop washer (30) and race (31) over end of plunger (29) and install O-ring (19) in groove in head (25).
- With locknut (32) on barrel, screw barrel (33) into head (25) until tapped hole in head is aligned with hole in barrel.

NOTE

Be sure that marked end of barrel is installed in head (25). Barrel should tighten against race to prevent any movement between stop washer and race.

- Install and tighten set screw (18) in head (25). Tighten locknut (32).
- Install O-ring (22) and backup rings (21) in groove on piston and install balls (23) in holes of piston.
- Insert piston into barrel. Be sure all six balls are in place in piston.
- Install O-rings (19 and 14) and backup rings (13) in grooves in bearing end (17).
- With locknut (35) on barrel, screw bearing end (17) on barrel until tapped hole in bearing end is aligned with hole in barrel. Install and tighten set-screw in bearing head (17). Tighten locknut (35).

NOTE


Centerline of hook pins and centerline of bushing hole must align within .005 inch with cylinder locked at a length of 11.580 ±.031 inches from centerline of hookpins to centerline of bushing (24) in head (25).

- Install locknut (12) on end of piston. Assemble and install hook assembly on piston.

NOTE

When assembling hook assembly, lubricate as shown in Section 2.

- After repair, rig nose gear actuator as shown in Section 5A.



1. Cotter Pin
2. Nut
3. Washers
4. Hook
5. Spring Guide
6. Spring
7. Shield
8. Bolt
9. Crossbar
10. Hook
11. Rod End
12. Nut

13. Back-Up Ring
14. O-Ring
15. Pin
16. Pin
17. Bearing End
18. Setscrew
19. O-Ring
20. Piston
21. Back-Up Rings
22. O-Ring
23. Balls

24. Bushing
25. Head
26. Spring
27. Back-Up Ring
28. O-Ring
29. Plunger
30. Washer
31. Race
32. Nut
33. Barrel
34. Nameplate
35. Nut

Figure A5-1. Nose Gear Actuator

SECTION A6

REPAIR OF LOCK, UNLOCK, & SEQUENCE CYLINDERS

A6-1. LEADING PARTICULARS.

Cylinder Bore Diameter	1.00 + .002, -.000 in.
Rod Diameter	.343 + .001, -.002 in.
Piston Stroke (total)	.812 in.
Piston Stroke (to unseat valve)	.719 ± .031 in.

A6-2. DISASSEMBLY (See figure A6-1.)

- a. Remove fitting (13), spring (11), and balls (10) and (9).
- b. Cut safety wire and unscrew end plug (1) from barrel and valve body (8).
- c. Remove springs (2 and 3) and push piston (5) from barrel and valve body.
- d. Remove and discard O-rings (4, 6, and 14) and remove and discard back-up rings (7 and 15).

A6-3. INSPECTION OF PARTS. Make the following inspections to ascertain that all parts are in a serviceable condition.


- a. Inspect all threaded surfaces for cleanliness and for freedom from cracks and excessive wear.
- b. Inspect spring (3) for evidence of breaks and distortion. The free length of the spring must be $2.95 \pm .09$ inches and compress to 1.969 inches under a 22.5 ± 2.2 pound load.
- c. Inspect spring (2) for evidence of breaks and distortion. The free length of the spring must be $2.98 \pm .09$ inches and compress to 1.969 inches under a 10.6 ± 1.1 pound load.
- d. Inspect spring (11) for evidence of breaks and distortion. The free length of the spring must be $.446 \pm .015$ and compress to .359 inches under a $.18 \pm .02$ pound load.

- e. Inspect plug (1), piston and rod (5), barrel and valve body (8), balls and ball seats for cracks, chips, scratches, scoring, wear, or surface irregularities which may affect their function or the overall function of the unit.

A6-4. REASSEMBLY. Repair of most parts of the lock cylinder is impractical. Replace defective parts with serviceable parts. Minor scratches and scores may be removed by polishing with fine abrasive crocus cloth (Federal Specification P-C-458) providing their removal does not affect the operation of the unit. Install all new O-rings and back-up rings during reassembly of the lock cylinder.

- a. Install new O-rings (4 and 6) and back-up ring (8) in grooves on piston and rod (5).
- b. Install new O-ring (14) and back-up ring (15) in groove of barrel and valve body (8).
- c. Slide piston and rod (5) into barrel and valve body (8). Use care to prevent damage to O-rings and back-up rings.
- d. Insert springs (2 and 3), then install and safety end plug to barrel and valve body.
- e. Insert balls (9 and 10) and spring (11) in barrel and valve body.
- f. Install a new O-ring (12) on fitting (13), install and tighten fitting.

SHOP NOTES:



- | | | |
|-------------------|--------------------------|------------------|
| 1. End Plug | 6. O-Ring | 11. Spring |
| 2. Spring | 7. Back-Up Ring | 12. O-Ring |
| 3. Spring | 8. Barrel and Valve Body | 13. Fitting |
| 4. O-Ring | 9. Ball | 14. O-Ring |
| 5. Piston and Rod | 10. Ball | 15. Back-Up Ring |

Figure A6-1. Lock, Unlock, and Sequence Cylinders

SHOP NOTES:

SECTION A7

REPAIR OF DOOR ACTUATORS

A7-1. LEADING PARTICULARS.

Cylinder Bore Diameter	0.625 in.
Piston Rod Diameter	0.3125 in.
Stroke (nose gear and main gear strut)	5.75 + .06, -.03 in.
Stroke (main gear wheel)	5.35 + .06, -.03 in.
Length - extended (nose gear and main gear strut)	17.50 + .06, -.03 in.
Length - extended (main gear wheel)	17.11 + .06, -.03 in.
Length - retracted (all)	11.75 + .06, -.03 in.
Ball lock (unlocking pressure)	100±25 psi
Ball lock (locking pressure)	275 psi(max)

A7-2. DISASSEMBLY. (See figure A7-1.)

- a. Unlock cylinder by applying hydraulic pressure to port in clevis end (22) of actuator.
- b. Loosen locknut (2) and remove rod end (1) from piston rod. Remove locknut from piston.
- c. Remove safety wire from knurled nuts (13) and loosen knurled nuts.
- d. Remove gland end (5) from barrel (17), using a strap wrench on barrel.
- e. Remove clevis end (22) from barrel, then push piston (7) from barrel. Use care when pushing piston from barrel, to prevent loss of balls (12).
- f. Remove spacer (6) from barrel. Spacer (6) is used only in the main landing gear wheel door actuator.
- g. Remove O-ring (4) and back-up ring (3) from gland end (5).
- h. Apply a sharp blast of air to hydraulic port of clevis end (22) to remove plunger (18), washer (11), and race (10). Remove spring (21) from clevis end.
- j. Remove and discard O-rings and back-up rings from barrel, piston, and plunger.


A7-3. INSPECTION OF PARTS. Make the following inspections to ascertain that all parts are in a serviceable condition.

- a. Inspect all threaded surfaces for cleanliness and for freedom from cracks and excessive wear.
- b. Inspect spring (21) for evidence of breaks and distortion. The free length of the spring must be 1.055 inches and compress to .875 inch under a 35 ±3.5 pound load.
- c. Inspect gland end (5), spacer (6), piston (7), barrel (17), plunger (18) and clevis end (22) for cracks, chips, scratches, scoring, wear or surface irregularities which may affect their function or the overall function of the door actuator cylinder.

A7-4. REASSEMBLY. Repair of most parts of the landing gear door actuator assembly is impractical. Replace defective parts with serviceable parts. Minor scratches and scores may be removed by polishing with fine abrasive crocus cloth (Federal Specification P-C-458) providing their removal does not affect the operation of the unit. Install all new O-rings and back-up rings during reassembly of the actuator.

- a. Install O-ring (19) and back-up ring (20) in groove on plunger (18).
- b. Insert spring (21) and plunger (18) into clevis end (22). Install washer (11) and race (10) over end of plunger (18).
- c. With knurled nuts (13) on barrel (17), install O-rings (14) and back-up rings (15) in grooves on barrel.
- d. Install O-ring (9) and back-up rings (8) in groove on piston (7) and install balls (12) in holes of piston.
- e. Insert piston into barrel. Be sure that all six balls are in place in piston as piston is inserted in barrel.
- f. Screw barrel (17) into clevis end (22). Tighten barrel down snugly against race, then tighten knurled nut.
- g. Insert spacer (6) in barrel (17). Spacer (6) is used only in main landing gear wheel door actuator.
- h. Install O-ring (4) and back-up ring (3) in bore groove of gland end (5), lubricate piston rod and slide gland end over rod. Tighten gland end on barrel, aligning hydraulic port fittings of the gland end with the port fitting in the clevis end.
- i. Tighten knurled nuts (13) to a torque value of 130±10 lb. in. Install lockwire on both knurled nuts.
- j. Install locknut (2) and rod end (1).
- k. Check actuator per paragraph B8-1 specifications.

* Spacer (6) used only in the main landing gear wheel door actuator.



- 1. Rod End
- 2. Nut
- 3. Back-Up Ring
- 4. O-Ring
- 5. Gland End
- * 6. Spacer
- 7. Piston and Plug

- 8. Back-Up Ring
- 9. O-Ring
- 10. Race
- 11. Washer
- 12. Balls
- 13. Nut
- 14. O-Ring
- 15. Back-Up Ring

- 16. Nameplate
- 17. Barrel
- 18. Plunger
- 19. O-Ring
- 20. Back-Up Ring
- 21. Spring
- 22. Clevis End

Figure A7-1. Door Actuator