
Service Manual

**1985
Thru
1986**

MODEL P210 SERIES



FAA APPROVAL HAS BEEN OBTAINED ON TECHNICAL DATA IN THIS PUBLICATION THAT AFFECTS AIRPLANE TYPE DESIGN.

REVISION 2 TO THE BASIC MANUAL IS BEING SUPPLIED TO PROVIDE ADDITIONAL INFORMATION NECESSARY TO MAINTAIN THE AIRPLANE AND INCORPORATES TEMPORARY REVISIONS NUMBER 1, DATED 1 DECEMBER 1992, AND NUMBER 2, DATED 3 OCTOBER 1994.

COPYRIGHT © 1986
CESSNA AIRCRAFT COMPANY
WICHITA, KANSAS, USA

D2074-2-13
(RGI-50-7/98)

31 JANUARY 1986

REVISION 2

1 AUGUST 1996



TEMPORARY REVISION NUMBER 4

DATE 5 April 2004

MANUAL TITLE 1985 Thru 1986 Model P210 Service Manual
MANUAL NUMBER - PAPER COPY D2074-2-13
MANUAL NUMBER - AEROFICHE D2074-2-13AF
TEMPORARY REVISION NUMBER D2074-2TR4
MANUAL DATE 31 January 1986 **REVISION NUMBER** 2 **DATE** 1 August 1996

This Temporary Revision consists of the following pages, which affect and replace existing pages in the paper copy manual and supersede aerofiche information.

SECTION	PAGE	AEROFICHE FICHE/FRAME	SECTION	PAGE	AEROFICHE FICHE/FRAME
2	33	1/C17			
2	34	1/C18			
2	39	1/C23			

REASON FOR TEMPORARY REVISION

1. To add the cleaning interval of the engine fuel injection nozzles.

FILING INSTRUCTIONS FOR THIS TEMPORARY REVISION

1. For Paper Publications, file this cover sheet behind the publication's title page to identify the inclusion of the Temporary Revision into the manual. Insert the new pages into the publication at the appropriate locations and remove and discard the superseded pages.
2. For Aerofiche Publications, draw a line with permanent red ink marker, through any aerofiche frame (page) affected by the Temporary Revision. This will be a visual identifier that the information on the frame (page) is no longer valid and the Temporary Revision should be referenced. For "added" pages in a Temporary Revision, draw a vertical line between the applicable frames. Line should be wide enough to show on the edges of the pages. Temporary Revisions should be collected and maintained in a notebook or binder near the aerofiche library for quick reference.



TEMPORARY REVISION NUMBER 3

DATE 7 July 2003

MANUAL TITLE 1985 Thru 1986 Model P210 Service Manual

MANUAL NUMBER - PAPER COPY D2074-2-13

MANUAL NUMBER - AEROFICHE D2074-2-13AF

TEMPORARY REVISION NUMBER D2074-2TR3

MANUAL DATE 31 January 1986 **REVISION NUMBER** 2 **DATE** 1 August 1996

This Temporary Revision consists of the following pages, which affect and replace existing pages in the paper copy manual and supersede aerofiche information.

SECTION	PAGE	AEROFICHE FICHE/FRAME	SECTION	PAGE	AEROFICHE FICHE/FRAME
2	39	1/C23			
2	40	1/C24			
2	40A	Added			
2	40B	Added			
2	40C	Added			
2	40D	Added			
16	26C	Added			

REASON FOR TEMPORARY REVISION

1. To add a Component Time Limits section and a fuel quantity indicating system operational test.

FILING INSTRUCTIONS FOR THIS TEMPORARY REVISION

1. For Paper Publications, file this cover sheet behind the publication's title page to identify the inclusion of the Temporary Revision into the manual. Insert the new pages into the publication at the appropriate locations and remove and discard the superseded pages.
2. For Aerofiche Publications, draw a line with permanent red ink marker, through any aerofiche frame (page) affected by the Temporary Revision. This will be a visual identifier that the information on the frame (page) is no longer valid and the Temporary Revision should be referenced. For "added" pages in a Temporary Revision, draw a vertical line between the applicable frames. Line should be wide enough to show on the edges of the pages. Temporary Revisions should be collected and maintained in a notebook or binder near the aerofiche library for quick reference.

MODEL P210 SERIES SERVICE MANUAL

LIST OF EFFECTIVE PAGES

INSERT LATEST REVISED PAGES. DESTROY SUPERSEDED PAGES.

NOTE

The portion of the text affected by the revision is indicated by a vertical line in the outer margins of the page. Changes to illustrations are indicated by miniature pointing hands.

* The asteric indicates pages revised, added or deleted by the current revision.

Original	0	31 Jan 1986
Revision	1	1 May 1992
Revision	2	1 Aug 1996

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 662

Page No.	Revision No.	Page No.	Revision No.
*Title	2	11-1 thru 11-4	0
*A	2	12-1 thru 12-24	0
*i thru iv	2	*12-25	2
1-1	1	12-26 thru 12-50	0
1-2 thru 1-14	0	*13-1	2
1-15 thru 1-21	1	13-2 thru 13-5	0
1-22 Blank	1	13-6	1
2-1	1	13-7 thru 13-10	0
2-2 thru 2-6	0	13-10A	0
2-6A	0	13-10B Blank	0
2-6B Blank	0	13-11	1
*2-7	2	*13-12	2
2-8 thru 2-10	0	13-13 thru 13-20	0
2-10A thru 2-10B	0	*13-21 thru 13-22	2
2-11 thru 2-21	0	*13-22A	2
2-22 Blank	0	*13-22B Blank	2
2-23 thru 2-26	1	13-23	0
*2-27 thru 2-39	2	*13-24	2
2-40 thru 2-43	1	13-25 thru 13-27	0
*2-44 thru 2-81	2	13-28 Blank	0
2-82 Blank	2	14-1 thru 14-7	0
3-1 thru 3-5	0	14-8 Blank	0
3-5A	0	15-1 thru 15-7	0
3-5B Blank	0	*15-8	2
3-6 thru 3-20	0	15-9 thru 15-14	0
3-21	1	15-15	0
3-22 thru 3-28	0	*15-16	2
4-1 thru 4-6	0	15-17 thru 15-27	0
*5-1 thru 5-3	2	*15-28	2
5-4 thru 5-6	0	15-29 thru 15-66	0
*5-7	2	*15-67	2
5-8 thru 5-10	2	15-68	0
*5-11 thru 5-16	2	*15-69 thru 15-70	2
5-17 thru 5-22	0	15-71 thru 15-72	0
*5-23 thru 5-26	2	*15-73	2
*5-26A thru 5-26C	2	15-74 thru 15-76	0
*5-26D Blank	2	*16-1	2
5-27 thru 5-28	2	16-2 thru 16-21	0
*5-29	2	*16-22	2
5-30	0	16-23	0
*5-31 thru 5-36	2	*16-24 thru 16-26	2
5-37 thru 5-51	0	*16-26A thru 16-26B	2
*5-52	2	16-27 thru 16-37	0
5-53 thru 5-54	0	16-38 Blank	0
*5-55	2	17-1	0
5-56	0	*17-2	2
*5-57 thru 5-58	2	17-3 thru 17-45	0
5-59 thru 5-60	0	*17-46 thru 17-49	2
*6-1	2	17-50 thru 17-51	0
6-2 thru 6-8	0	17-52 Blank	0
*6-9	2	18-1 thru 18-39	0
6-10	0	18-40 Blank	0
7-1 thru 7-9	0	19-1 thru 19-3	0
7-10 Blank	0	19-4 Blank	0
8-1 thru 8-3	0	20-1 thru 20-50	0
*8-4	2	20-50A thru 20-50B	0
8-5 thru 8-7	0	20-51 thru 20-56	0
8-8 Blank	0	20-56A	0
9-1 thru 9-12	0	20-56B Blank	0
10-1 thru 10-8	0	20-57 thru 20-90	0

MODEL P210 SERIES SERVICE MANUAL

SECTION

Page No.
Aerofiche/Manual

1.	GENERAL DESCRIPTION	1A7/1-1
2.	GROUND HANDLING, SERVICING, CLEANING, LUBRICATION, AND INSPECTION	1B5/2-1
3.	FUSELAGE	1E23/3-1
4.	WINGS AND EMPENNAGE	1G9/4-1
5.	LANDING GEAR, BRAKES AND HYDRAULIC SYSTEM	1G19/5-1
6.	AILERON CONTROL SYSTEM	1J11/6-1
7.	WING FLAP CONTROL SYSTEM	1K1/7-1
8.	ELEVATOR CONTROL SYSTEM	1K15/8-1
9.	ELEVATOR TRIM CONTROL SYSTEM	1L3/9-1
10.	RUDDER CONTROL SYSTEM	2A3/10-1
11.	RUDDER TRIM CONTROL SYSTEM	2A15/11-1
12.	ENGINE NORMALLY ASPIRATED	2A23/12-1
13.	FUEL SYSTEM	2D5/13-1
14.	PROPELLERS AND PROPELLER GOVERNORS	2F15/14-1
15.	UTILITY SYSTEMS	2F3/15-1
16.	INSTRUMENTS AND INSTRUMENT SYSTEMS	2I11/16-1
17.	ELECTRICAL SYSTEMS	3A3/17-1
18.	STRUCTURAL REPAIR	3C11/18-1
19.	EXTERIOR PAINTING	3E7/19-1
20.	WIRING DIAGRAMS	3E15/20-1

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand, nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire, or a component malfunction, could cause the propeller to rotate.

MODEL P210 SERIES SERVICE MANUAL

CROSS REFERENCE LISTING OF POPULAR NAME VS. MODEL NUMBERS AND SERIALS

All aircraft, regardless of manufacturer, are certified under model number designations. However, popular names are often used for marketing purposes. To provide a consistent method of referring to these aircraft, the model number will be used in this publication unless the popular name is necessary to differentiate between versions of the same basic model. The following table provides a listing of popular name, model number and serial number.

POPULAR NAME	MODEL YEAR	MODEL	BEGINNING	SERIAL ENDING
PRESSURIZED CENTURION	1985	P210R	P21000835	P21000866
PRESSURIZED CENTURION WITH VALUE GROUPS A & B	1986	P210R	P21000867	P21000874

MODEL P210 SERIES SERVICE MANUAL

INTRODUCTION

This manual contains factory-recommended procedures and instructions for ground handling, servicing, and maintaining the airplane. Besides serving as a reference for the experienced mechanic, this book also covers step-by-step procedures for the less experienced.

This service manual is designed for aerofiche presentation. To facilitate the use of the aerofiche, refer to the aerofiche header for basic information.

IMPORTANT INFORMATION CONCERNING KEEPING CESSNA PUBLICATIONS CURRENT

The information in this publication is based on data available at the time of publication and is updated, supplemented, and automatically amended by all information issued in service newsletters, service bulletins, supplier service notices, revisions, reissues and temporary revisions. All such amendments become part of and are specifically incorporated within this publication. Users are urged to keep abreast of the latest amendments to this publication through the Cessna Product Support subscription services. Cessna Service Stations have also been supplied with a group of supplier publications which provide disassembly, overhaul, and parts breakdowns for some of the various supplier equipment items. Supplier's publications are updated, supplemented, and specifically amended by supplier issued revisions and service information which may be reissued by Cessna; thereby automatically amending this publication and is communicated to the field through Cessna's Authorized Service Stations and/or through Cessna's subscription services.

WARNING: ALL INSPECTION INTERVALS, REPLACEMENT TIME LIMITS, OVERHAUL TIME LIMITS, THE METHOD OF INSPECTION, LIFE LIMITS, CYCLE LIMITS, ETC., RECOMMENDED BY CESSNA ARE SOLELY BASED ON THE USE OF NEW, REMANUFACTURED, OR OVERHAULED CESSNA APPROVED PARTS. IF PARTS ARE DESIGNED, MANUFACTURED, REMANUFACTURED, OVERHAULED, AND/OR APPROVED BY ENTITIES OTHER THAN CESSNA, THEN THE DATA IN CESSNA'S MAINTENANCE/SERVICE MANUALS AND PARTS CATALOGS ARE NO LONGER APPLICABLE AND THE PURCHASER IS WARNED NOT TO RELY ON SUCH DATA FOR NON-CESSNA PARTS. ALL INSPECTION INTERVALS, REPLACEMENT TIME LIMITS, OVERHAUL TIME LIMITS, THE METHOD OF INSPECTION, LIFE LIMITS, CYCLE LIMITS, ETC., FOR SUCH NON-CESSNA PARTS MUST BE OBTAINED FROM THE MANUFACTURER AND/OR SELLER OF SUCH NON-CESSNA PARTS.

REVISIONS.

1. Revisions/changes are issued as required and include only pages that require updating.

REISSUE.

1. A reissued manual is a complete manual incorporating all the latest information and outstanding revisions and temporary revisions. It supersedes and replaces previous issue(s) of the manual.

CHANGES / REVISIONS and REISSUES.

1. Individual copies can be purchased from your Cessna Service Station or directly from Cessna Parts Distribution, Dept. 701, Cessna Aircraft Company, P.O. Box 949, Wichita, KS. 67201 (walk-in address: 5800 East Pawnee, Wichita, Kansas 67218).
2. Subscriptions, service bulletin listings, revision status checkcards and temporary revisions may be purchased through Propeller Aircraft Product Support, P.O. Box 7706, Wichita, KS. 67277, phone (316) 941-7674 or fax (316) 942-9006.

MODEL P210 SERIES SERVICE MANUAL

TEMPORARY REVISIONS.

1. Additional information which becomes available may be provided by temporary revisions. This service is used to provide, without delay, new information which will assist in maintaining safe flight/ground operations. Temporary revisions are designed to replace or add to existing pages in the manual and are numbered to match pages in the manual. Temporary revisions are normally incorporated into this manual at the next scheduled change, revision or reissue.

REVISION BARS.

1. Additions, or revisions to text in an existing section will be identified by a revision bar on the page adjacent to the change.
2. When technical changes cause unchanged text to appear on a different page/pages, a revision bar will be placed in the margin opposite the page number of all affected pages providing no other revision bar appears on the page.
3. When extensive technical changes are made to text in an existing section that requires a complete retype of copy, revision bars will appear the full length of the page.
4. When art in an existing illustration is revised, a pointing hand will appear in the illustration and will point to the area of the art revision.
5. New art added to an existing section will be identified by a single pointing hand adjacent to the figure title and figure number.
6. Revision bars are not shown for:
 - a. Introductory material, indexes and tabular data.
 - b. Blank spaces which are the result of text, illustration or table deletion.
 - c. Correction of minor inaccuracies, such as punctuation, etc., unless such a correction changes the meaning of instructive information and procedures.

CUSTOMER CARE SUPPLIES AND PUBLICATIONS CATALOG.

A Customer Care Supplies and Publications Catalog is available from your Cessna Service Station or directly from Cessna Propeller Aircraft Product Support, P.O. Box 7706, Wichita, KS. 67277, phone (316) 941-7950 or fax (316) 942-9006. This catalog lists all publications and Customer Care Supplies available from Cessna for prior year models as well as new products. To maintain this catalog in a current status, it is revised yearly and issued in paper and Aerofiche format.

SUPPLEMENTAL TYPE CERTIFICATE INSTALLATIONS.

Inspection, maintenance and parts requirements for supplemental type certificate (STC) installations are not included in this manual. When an STC installation is incorporated on the airplane, those portions of the airplane affected by the installation must be inspected in accordance with the inspection program published by the owner of the STC, since STC installations may change systems interface, operating characteristics and component loads or stresses on adjacent structures. Cessna provided inspection criteria may not be valid for airplanes with STC installations.

CUSTOMER COMMENTS ON MANUAL.

Cessna Aircraft Company has endeavored to furnish you with an accurate, useful, up-to-date manual. This manual can be improved with your help. Please use the Customer Comment Card provided with your manual, to report any errors, discrepancies, and omissions in this manual as well as any general comments you wish to make.

MODEL P210 SERIES SERVICE MANUAL

SECTION 1 GENERAL DESCRIPTION

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
GENERAL DESCRIPTION	1A7/1-1	SAFETY WIRE PROCEDURES	1A14/1-8
PRESSURIZED CENTURION	1A7/1-1	USE OF COTTER PINS	1A18/1-12
Description	1A7/1-1	USE OF LOCKING CLIPS	1A20/1-14
Aircraft Specifications	1A7/1-1	USE OF LOCKWASHERS	1A20/1-14
Stations	1A7/1-1	USE OF SELF-LOCKING NUTS	1A20/1-14
GENERAL AIRFRAME PRACTICES	1A10/1-4	CONTROL CABLE WIRE BREAKAGE	
TORQUEING PROCEDURES	1A10/1-4	AND CORROSION	
Calculating Torque	1A10/1-4	LIMITATIONS	1A22/1-16
Torque Values - Bolts	1A10/1-4	ADHESIVES, CEMENTS AND	
Torque Values - Fittings	1A13/1-7	SEALANTS-SHELF LIFE	
SAFETYING PROCEDURES	1A14/1-8	AND STORAGE	1A24/1-18

1-1. GENERAL DESCRIPTION.

1-2. MODEL 210 SERIES.

1-3 DESCRIPTION. The Cessna Pressurized, Centurion and Centurion II (P210 Series) Airplanes described in this manual, are high-wing, single-engine, monoplanes of all metal, semi-monocoque construction. Wings are full cantilever with integral fuel bays (wet wing). The fully retractable landing gear consists of tubular-spring steel main gear struts, and a steerable air/hydraulic nose gear strut. Seating arrangement is six place conventional. Powering the Pressurized Centurion Series is a Continental, air-cooled, horizontally-opposed, six-cylinder, fuel-injected, turbocharged engine, driving a constant speed, three blade propeller. The pressurization system is designed for maximum passenger comfort at altitudes up to airplane ceiling, by maintaining a 3.35 psi maximum cabin pressure, or the equivalent to a 10,000 ft cabin altitude at 20,000ft actual.

1-4. AIRCRAFT SPECIFICATIONS. Leading particulars of these airplanes, with dimensions based on gross weight, are given in figure 1-1. If these dimensions are used in computing clearance for construction of a hanger or other shelter, it should be noted that strut inflation, tire pressure, tire size, and load distribution will change some dimensions significantly.

1-5. STATIONS. A station diagram is shown in figure 1-2 to assist in locating equipment when a written description is inadequate or impractical.

MODEL P210 SERIES SERVICE MANUAL

MODEL P210

GROSS WEIGHT	
Takeoff	4100 lb
Landing	3900 lb
FUEL CAPACITY	
Standard Wing	
Total	90 gal
Usable	87 gal
Extended Range Wing	
Total	120 gal
Usable	115 gal
OIL CAPACITY	11 qt
ENGINE MODEL	CONTINENTAL TSIO-520-CE
PROPELLER (Constant-Speed)	
(Three Bladed)	80" McCAULEY
LANDING GEAR (Retractable, Hydraulically-Actuated)	Tricycle
MAIN WHEEL TIRES	
Pressure	6.00 x 6
	55 psi
NOSE WHEEL TIRE	
Pressure	5.00 x 5
	88 psi
NOSE GEAR STRUT PRESSURE (Strut Extended)	90 psi
WHEEL ALIGNMENT (At Empty Weight)	
Camber	4° ± 1° 30'
Toe-In	0" to .06"
AILERON TRAVEL	
Up	20° ± 2°
Down	15° ± 2°
WING FLAP TRAVEL (Electrically-Actuated)	0° ± 0° to 30°, +1° -2°
RUDDER TRAVEL (Measured parallel to water line)	
Right	24° ± 1°
Left	24° ± 1°
RUDDER TRAVEL (Measured perpendicular to hinge line)	
Right	27° 13' ± 1°
Left	27° 13' ± 1°
ELEVATOR TRAVEL	
Up	25° ± 1°
Down	20° ± 1°
ELEVATOR TRIM TAB TRAVEL	
Up	20° ± 1°
Down	15° ± 1°
PRINCIPAL DIMENSIONS	
Wing Span	465.96"
Tail Span	192.00
Length	339.80"
Fin Height (Maximum with Nose Gear Depressed and Flashing Beacon Installed on Fin).	112.92
Track Width	104.20
BATTERY LOCATION	Left Side of Firewall

Figure 1-1. Aircraft Specifications

MODEL P210 SERIES SERVICE MANUAL




Figure 1-2. Aircraft Specifications.

MODEL P210 SERIES SERVICE MANUAL

1-6. **GENERAL.** This chapter deals with general torque and safetying practices used to ensure security of installation and prevent overstressing of components. Special torque values, when required, are specified with the specific component maintenance and installation instructions.

1-7. **TORQUEING PROCEDURES.** The importance of correct application cannot be overemphasized. Undertorque can result in unnecessary wear of nuts and bolts as well as parts they are holding together. When insufficient pressures are applied, uneven loads will be transmitted throughout assembly, which may result in excessive wear or premature failure due to fatigue. Overtorque can be equally damaging because of failure of a bolt or nut from overstressing threaded areas.

a. **Calculating Torque.** There are a few simple, but very important, procedures that should be followed to assure that correct torque is applied:

1. Calibrate torque wrench periodically to assure accuracy; and recheck frequently.

2. When using a torque wrench adapter which changes distance from torque wrench drive to adapter drive, the indicated reading must be adjusted for desired torque reading. (See Figure 1-2.)

3. Be sure that bolt and nut threads are clean and dry unless otherwise specified.

4. Determine friction drag torque and add to specified dry torque value to ensure proper bolt utilization.

(a) Hand-turn nut onto bolt until it stops.

(b) Using a torque wrench, measure running torque (torque required to turn nut on bolt).

(c) This running torque must be added to specified dry torque value to ensure proper bolt utilization.

EXAMPLE

Average running torque for a nut	= 15 in.-lbs.
Dry torque required	= 125 ± 5 in.-lbs.
<u>Final torque wrench reading</u>	<u>= 140 ± 5 in.-lbs.</u>

(d) Since running torque will become less due to nut/bolt re-use (in accepted applications), this procedure must be repeated each time.

(e) When necessary to tighten from bolt head, increase torque value by an amount equal to shank torque (torque required to turn bolt when installed). Measure with a torque wrench.

EXAMPLE

Average running torque for a nut	= 15 in.-lbs.
Average running shank torque for installed bolt	= 10 in.-lbs.
Dry torque required	= 125 ± 5 in.-lbs.
<u>Final torque wrench reading</u>	<u>= 150 ± 5 in.-lbs.</u>

b. **Torque Values - Bolts and Nuts.** (See Table 1-1.)

1. Tables included in this section do not apply to the following exceptions:

(a) Sheet metal screws should be tightened firmly, but with no specific torque value.

(b) Screws attached to nutplates should be tightened firmly, but with no specific torque value.

(c) Bolts, nuts, and screws used in control systems and installations where required torque would cause binding or interfere with proper operation of parts.

(d) Screws used with dimpled washers should not be drawn tight enough to eliminate washer crown.

(e) Fasteners that have a specified torque in a specific installation.

2. The values shown in Table 1-1 are based on parts being clean and dry with no lubricants added.

3. Castellated nuts requiring cotter pins should be tightened to low torque value. Torque can be increased to install cotter pin, but should never exceed maximum torque value.

NOTE

Self-locking castellated nuts, MS17825 and MS17826, require a separate torque range. These values are shown separately in torque value tables.

MODEL P210 SERIES SERVICE MANUAL

NOTE

When using a torque wrench adapter which changes the distance from torque wrench drive to adapter drive, apply following formula to obtain corrected torque reading.

FORMULA

$$\frac{T \times L}{L + E} = Y$$

LEGEND

T = Desired Torque
 Y = Indicated Torque
 L = Effective Length Lever
 E = Effective Length of Extension


SHORT OPEN END ADAPTER




SETScrew ADAPTER



HOSE CLAMP ADAPTER




OPEN-END WRENCH ADAPTER



FLARE NUT WRENCH ADAPTER



SPANNER WRENCH ADAPTER




EXAMPLE

T = 135 In.-Lbs
 Y = Unknown
 L = 10.0 In.-Lbs
 E = 1.5 In.

$$Y = \frac{135 \times 10}{10 + 1.5} = \frac{1350}{11.5} = 117.39$$

Y = 117 In.-Lbs



EXAMPLE

T = 135 In.-Lbs
 Y = Unknown
 L = 10.0 In.-Lbs
 E = -1.5 In.

$$Y = \frac{135 \times 10}{10 - 1.5} = \frac{1350}{8.5} = 158.82$$

Y = 159 In.-Lbs

Figure 1-3. Torque Wrench Adapter Adjustment

MODEL P210 SERIES SERVICE MANUAL

BOLT TORQUE VALUES										
Tension				Shear						
BOLTS				BOLTS						
AN3 thru AN20 AN42 thru AN49 AN73 thru AN81 AN173 thru AN186 AN509NK9 AN525NK525 MS20033 thru MS20046 MS20073 MS20074 MS24694 MS27039				NOTE: Bolts in tension column may be used with shear nuts. Bolts in shear column should not be used unless a minimum of two threads extend beyond nut after installation.				MS20004 thru MS20024 NAS144 thru NAS148 NAS172 NAS174 NAS333 thru NAS340 NAS585 thru NAS590 NAS624 thru NAS644 NAS1303 thru NAS1320 NAS517		NAS464
NUTS				NUTS						
AN310 AN315 AN363 AN365 MS20365 MS20500 MS21045 NAS679 NAS1021		AN320 AN364 MS20364 NAS1022		AN310 AN315 NA363 AN365 MS20365 MS21045 NAS679 NAS1021 NAS1291		AN320 AN364 NAS1022 MS20364				
FINE THREAD SERIES										
Nut-bolt size	Torque Limits in.-lbs.		Torque Limits in.-lbs.		Nut-bolt size	Torque Limits in.-lbs.		Torque Limits in.-lbs.		
	MIN.	MAX.	MIN.	MAX.		MIN.	MAX.	MIN.	MAX.	
8-36	12	15	7	9	10-32	25	30	15	20	
10-32	20	25	12	15	1/4-28	80	100	50	60	
1/4-28	50	70	30	40	5/16-24	120	145	70	90	
5/16-24	100	140	60	85	3/8-24	200	250	120	150	
3/8-24	160	190	95	110	7/16-20	520	630	300	400	
7/16-20	450	500	270	300	1/2-20	770	950	450	550	
1/2-20	480	690	290	410	9/16-18	1100	1300	650	800	
9/16-18	800	1000	480	600	5/8-18	1250	1550	750	950	
5/8-18	1100	1300	660	780	3/4-16	2650	3200	1600	1900	
3/4-16	2300	2500	1300	1500	7/8-14	3550	4350	2100	2600	
7/8-14	2500	3000	1500	1800	1-14	4500	5500	2700	3300	
1-14	3700	4500	2200	3300	1-1/8-12	6000	7300	3600	4400	
1-1/8-12	5000	7000	3000	4200	1-1/4-12	11000	13400	6600	8000	
1-1/4-12	9000	11000	5400	6600						
COURSE THREAD SERIES										
Nut-bolt size	Torque Limits in.-lbs.		Torque Limits in.-lbs.		Nut-bolt size	MS17825 Torque Limits in.-lbs.		MS17826 Torque Limits in.-lbs.		
	MIN.	MAX.	MIN.	MAX.		MIN.	MAX.	MIN.	MAX.	
8-32	12	15	7	9	10-32	28	35	16	20	
10-24	20	25	12	15	1/4-28	65	80	35	45	
1/4-20	40	50	25	30	5/16-24	180	225	70	90	
5/16-18	80	90	48	55	3/8-24	260	325	100	125	
3/8-16	160	185	95	110	7/16-20	460	575	180	225	
7/16-14	235	255	140	155	1/2-20	720	900	240	300	
1/2-13	400	480	240	290	9/16-18	880	1100	320	400	
9/16-12	500	700	300	420	5/8-18	1300	1600	480	600	
5/8-11	700	900	420	540	3/4-16	2200	2800	880	1100	
3/4-10	1150	1600	700	950	7/8-14	3700	4600	1500	1900	
7/8-9	2200	3000	1300	1800	1-14	5400	6800	2400	3000	
1-8	3700	5000	2200	3000	1-1/8-12	8000	10000	4000	5000	
1-1/8-8	5500	6500	3300	4000	1-1/4-12	11000	14000	5600	7000	
1-1/4-8	6500	8000	4000	5000						

Table 1-1. Torque Values - Bolts and Nuts

MODEL P210 SERIES SERVICE MANUAL

c. Torque Value - Threaded Straight Fittings.

NOTE

Tables in this section are for general applications. Refer to specific installations for special torque values and procedures.

1. Connectors installed in bosses with no required orientation should be installed using torque values given in Table 1-2.

THREADED CONNECTOR					
TUBE OUTSIDE DIAMETER (Inches)	THREAD	JAM-NUT		CONNECTOR w/ PACKING w/o JAM-NUT	
		Torque-Limits (in.-lbs.)		Torque-Limits (in.-lbs.)	
		MIN.	MAX.	MIN.	MAX.
1/8	5/16-24	35	50	50	55
3/16	3/8-24	65	80	65	75
1/4	7/16-20	85	105	95	105
5/16	1/2-20	105	125	125	135
3/8	9/16-18	120	150	155	165
1/2	3/4-16	240	280	280	305
5/8	7/7-14	320	380	380	405
3/4	1/16-12	500	600	550	600
1	1-5/16-12	720	880	800	900
1-1/4	1-5/8-12	960	1200	900	1000
1-1/2	1-7/8-12	1200	1440	900	1000
2	2-1/2-12	1400	1500	900	1000

**Table 1-2. Torque Values
Jam-Nuts and Threaded Connector**

2. Connectors installed in bosses requiring a specific orientation do not use a torque value, but use the following steps:

(a) Place jam-nut on fitting along with retainer and packing.

(b) Turn nut down until packing is firmly against lower threaded section of fitting.

(c) Install fitting into boss and tighten until there is a sudden increase in torque.

(d) Tighten fitting 1-1/2 turns.

(e) Orientation is accomplished by tightening fitting, but not exceeding one turn.

(f) Tighten jam-nut to torque values in Table 1-2.

3. Bulkhead fittings are installed with jam-nuts and should be torqued to values in Table 1-2.

4. Torque values for hose end fittings (nipple or nut) are given in Table 1-3.

TORQUE VALUE - HOSE ASSEMBLIES				
HOSE INSIDE DIAMETER	Nipple or Nut			
	ALUMINUM Torque-Limits in.-lbs.		STEEL Torque-Limits in.-lbs.	
	MIN.	MAX.	MIN.	MAX.
1/8	20	30	75	85
3/16	25	35	95	105
1/4	50	65	135	150
5/16	70	90	170	200
3/8	110	130	270	300
1/2	230	260	450	500
5/8	330	360	650	700
3/4	460	500	900	1000
1	500	700	1200	1400
1-1/4	800	900	1520	1680
1-1/2	800	900	1900	2100
1-3/4	—	—	—	—
2	1800	2000	2660	2940

**Table 1-3. Torque Values
Hose Assemblies**

5. Torque values for straight threaded fittings used with rigid lines are given in Table 1-4.

MODEL P210 SERIES SERVICE MANUAL

THREADED STRAIGHT FITTING TORQUE VALUE (RIGID TUBE)													
TUBE OUTSIDE DIAMETER	FLARED END						STRAIGHT END						
	ALUMINUM Torque-Limits in-lbs.		ALUMINUM On Oxygen Lines Torque-Limits in-lbs.		STEEL Torque-Limits in-lbs.		6061-0 ALUMINUM 5052-0 ALUMINUM Torque-Limits in-lbs.		STEEL Torque-Limits in-lbs.		6061-T(X) ALUMINUM w/ steel sleeve Torque-Limits in-lbs.		
	MIN.	MAX.	MIN.	MAX.	MIN.	MAX.	MIN.	MAX.	MIN.	MAX.	TUBE WALL	MIN.	MAX.
1/8					90	100	20	30	45	55	0.028	45	55
3/16							30	40	90	100			
1/4	40	65			135	150	40	65	135	150	0.022	80	105
											0.028	80	105
											0.035	80	105
											0.049	90	115
5/16	60	80	100	125	180	200	60	80	180	200	0.028	80	105
											0.035	80	105
											0.042	125	175
3/8	75	125			270	300	75	125	270	300	0.028	125	175
											0.035	125	175
											0.049	125	175
1/2	150	250			450	500	150	250	450	500	0.028	135	180
											0.035	200	300
											0.049	400	500
											0.058	400	500
											0.065	400	500
5/8	200	350			700	800	200	350	700	800	All	500	600
3/4	300	500			1100	1150	300	500	1100	1150	All	600	700
1	500	700			1200	1400	500	700	1200	1400	All	1000	1300
1-1/4	600	900			1300	1450	600	900	1300	1450	All	1300	1500
1-1/2	600	900			1350	1500	600	900	1350	1500	All	1400	1700
2							600	900	1500	1700			

Table 1-4. Torque Values - Straight Threaded Fittings (Line)

1-8. SAFETYING PROCEDURES. The use of safety wire, cotter pins, lockwashers, and self-locking nuts is to prevent relative movement of critical components subject to vibration, torque, tension, etc., which could cause attaching parts to be broken, loosened, and/or detached.

1-9. SAFETY WIRE PROCEDURES.

a. Identification. Lockwire comes in three types which are identified by size and color. The three types are classified by use.

1. Inconel and Monel wire is used for general lockwiring and is identified by a natural wire color.

(a) Inconel can withstand temperatures up to 1500°F.

(b) Monel can withstand temperatures up to 800°F.

2. Copper that is cadmium-plated and dyed yellow is used for shear and seal wiring applications.

(a) Shear applications are those where it is necessary to break or shear wire to permit operation or actuation of emergency devices.

(b) Seal applications are where wire is used with a lead seal to prevent tampering or use of a device without indication.

3. Aluminum Alloy (Alclad 5056) is dyed blue and is used exclusively for safety-wiring magnesium parts.

4. Size of wire is dependent on material and purpose of installation.

(a) 0.020-inch diameter copper wire should be used for shear and seal application.

(b) 0.020-inch diameter wire may be used to lockwire parts with tie holes smaller than 0.045 in-

MODEL P210 SERIES SERVICE MANUAL

ches; or, on parts with tie hole diameters between 0.045 and 0.062 when spacing between ports is less than two inches; or, when bolts and screws of 0.25-inch diameter or less are closely spaced.

(c) 0.032-inch minimum diameter wire is used for general purpose lockwiring.

NOTE

When using single-wire method of locking, the largest wire that will fit tie holes should be used.

b. Lockwire Installation. There are two basic forms of lockwiring. The single-wire method has limited application; the double-twist method is the common method of lockwiring.

1. Use new wire for each application; do not try to re-use old wire.

2. Single-wire method is accomplished by passing a single wire through tie holes and back with ends then twisted together. (See Figure 1-4.)

(a) Single-wire method is used for shear and seal wiring applications.

(b) Single-wire method can be used in closely spaced, closed geometric patterns. Closely spaced is defined as spacing two inches or less between centers of parts.

CAUTION

Screws in closely spaced geometric patterns which secure hydraulic or air seals, hold hydraulic pressure, or are used in critical areas should use double-twist method of lockwiring.

3. Lockwiring by the double-twist method is really one wire twisted on itself several times and is accomplished by the following steps (see Figure 1-4).

(a) Insert one end of wire through tie holes of bolt head and firmly loop around bolt head.

NOTE

This does not necessarily apply to castellated nuts when slot is close to top of nut. The wire will be more secure if it is made to pass along side of stud.

(b) While taut, twist strands to within 1/8 inch of next part. The twisting keeps wire taut without overstressing and prevents wire from becoming nicked, kinked, or mutilated.

(c) Lockwiring multiple groups by double-twist method is accomplished in a similar manner except twists between parts are alternated between clockwise and counterclockwise.

(d) After last tie hole, wire is twisted three to five times to form a pigtail.

(e) Cut off any excess wire and bend pigtail towards part.

4. When lockwiring widely spaced multiple groups by double-twist method, three units shall be the maximum number in a series.

NOTE

Widely spaced multiple groups shall mean those in which fasteners are from four to six inches apart. Lockwiring shall not be used to secure fasteners or fittings which are spaced more than six inches apart, unless tie points are provided on adjacent parts to shorten span of lockwire to less than six inches.

5. When lockwiring closely spaced multiple groups, the number of units that can be lockwired by a 24-inch length of wire shall be the maximum number in a series.

6. Parts should be lockwired so that wire is placed in tension (pulled on) if a part attempts to loosen.

c. Required Lockwire Installation Applications.

1. Bolts and other fasteners securing critical parts that affect airplane safety and operation.

(a) In blind-tapped hole applications or bolts or castellated nuts on studs, lockwiring is installed in same manner as described for bolt heads.

(b) Hollow head bolts are safetied in manner prescribed for regular bolts.


(c) Drain plugs and cocks may be safetied to a bolt, nut, or other part having a free tie hole in accordance with instructions described.

(d) External snap rings may be locked if necessary using general locking principles as described and illustrated. Internal snap rings should not be lockwired.


(e) When locking is required on electrical connectors which use threaded coupling rings, or on plugs which employ screws or rings to fasten individual parts of plug together, they shall be lockwired with 0.020-inch diameter wire in accordance with locking principles as described and illustrated. It is preferable to lockwire all electrical connectors individually. Do not lockwire one connector to another unless it is necessary to do so.

(f) Drilled head bolts and screws need not be lockwired if installed into self-locking nuts or installed with lockwashers. Castellated nuts with cotter pins or lockwire are preferred on bolts or studs with drilled shanks, but self-locking nuts are permissible within limitations described in Paragraph 1-13.

2. For new design, lockwire shall not be used to secure nor shall lockwire be dependent upon fracture as basis for operation of emergency devices such as handles, switches, and guard-covering handles that operate emergency mechanisms such as emergency exits, fire extinguishers, emergency cabin pressure release, emergency landing gear release, and the like. However, where existing structural equipment or safety of flight emergency devices requires shear wire to secure equipment while not in use, but which are dependent upon shearing or breaking of lockwire for successful emergency operation of equipment, particular care exercised to assure that wiring under these circumstances shall not prevent emergency operations of these devices.




BOLTS IN CLOSELY SPACED, CLOSED GEOMETRICAL PATTERN. SINGLE-WIRE METHOD.




EXTERNAL SNAP RING SINGLE-WIRE METHOD

NOTE

RIGHT-HAND THREADED PARTS SHOWN. REVERSE DIRECTION FOR LEFT-HAND THREADS.



SINGLE FASTENER APPLICATION DOUBLE-TWIST METHOD




CASTELLATED NUTS ON DRILLED STUDS DOUBLE-TWIST METHOD

Figure 1-4. Lockwire Safelying (Sheet 1 of 2)


MODEL P210 SERIES SERVICE MANUAL

DOUBLE-TWIST METHOD


- STEP 1. Insert wire through bolt A and bend around bolt (if necessary, bend wire across bolt head). Twist wires clockwise until they reach bolt B.
- STEP 2. Insert one end of wire through bolt B. Bend other end around head of bolt (if necessary, bend wire across head of bolt). Twist wires counterclockwise 1/2 inch or six twists. Clip ends. Bend pigtail back against part.



DOUBLE-TWIST METHOD



MULTIPLE FASTENER APPLICATION
DOUBLE-TWIST METHOD



ELECTRICAL CONNECTION

Figure 1-4. Lockwire Safetying (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

1-10. USE OF COTTER PINS.

a. Cotter Pin Installation. Castellated nuts and pins may be safetied with cotter pins or lockwire. The preferred method is to use cotter pins.

1. Select cotter pin material in accordance with temperature, atmosphere, and service limitations (see Table 1-5).

COTTER PINS (MS24665)		
MATERIAL	TEMP	USE
Carbon Steel	Up to 450°F	Pins that contact cadmium-plated surfaces. General Applications Normal Atmospheres
Corrosion-Resistant	Up to 800°F	Pins that contact corrosion-resistant steel. Corrosive atmospheres

Table 1-5. Cotter Pin Temperature and Use

2. Cotter pins shall be new upon each application.

3. When nuts are to be secured to fastener with cotter pins, tighten nut to low side (minimum) of applicable specified or selected torque range, unless otherwise specified, and if necessary, continue tightening until slot aligns with hole. In no case shall you exceed high side (maximum) torque range.

4. If more than 50 percent of cotter pin diameter is above nut castellation, a washer should be used under nut or a shorter fastener should be used. A maximum of two washers may be permitted under a nut.

5. The largest diameter cotter pin which hole and slots will accommodate should be used, but in no application to a nut, bolt, or screw shall pin size be less than sizes described in Table 1-6.

(6) Install cotter pin with head firmly in slot of nut with axis of eye at right angles to bolt shank. Bend prongs so that head and upper prong are firmly seated against bolt (see figure 1-5).


COTTER PIN - MINIMUM SIZE	
THREAD SIZE	MINIMUM PIN SIZE
6	0.028
8	0.044
10	0.044
1/4	0.044
5/16	0.044
3/8	0.072
7/16	0.072
1/2	0.072
9/16	0.086
5/8	0.086
3/4	0.086
7/8	0.086
1	0.086
1-1/8	0.116
1-1/4	0.116
1-3/8	0.116
1-1/2	0.116

Table 1-6. Cotter Pin Minimum Size


(7) In pin applications, install cotter pin with axis of eye parallel to shank of clevis pin or rod end. Bend prongs around shank of pin or rod end (see Figure 1-5).

CAUTION

Cadmium-plated cotter pins should not be used in applications bringing them in contact with fuel, hydraulic fluid, or synthetic lubricants.



CASTELLATED NUT ON BOLT



PIN APPLICATION

Figure 1-5. Installation of Cotter Pins

MODEL P210 SERIES SERVICE MANUAL

1-11. USE OF LOCKING CLIPS.

a. Safelying Turnbuckles. (See Figure 1-6.)

1. Prior to safelying, both threaded terminals shall be screwed an equal distance into turnbuckle body and shall be screwed in at least so far that not more than three threads of any terminal are exposed outside body.

2. After turnbuckle has been adjusted to its locking position, with slot indicator groove on terminals and slot indicator notch on body aligned, insert end of locking clip into terminal and body (refer to Figure 1-6) until U-curved end of locking clip is over hole in center of body.

(a) Press locking clip into hold to its full extent.

(b) Curved end of locking clip will expand and latch in body slot.

(c) To check proper seating of locking clip, attempt to remove pressed "U" end from body hole with fingers only.

NOTE

Do not use tool as locking clip could be distorted.

3. Locking clips are for one time use only and shall not be re-used.

4. Both locking clips may be inserted in same hole of turnbuckle body or in opposite holes of turnbuckle body.

1-12. USE OF LOCKWASHERS.

a. Lockwashers can be used only under the following conditions.

1. When self-locking feature cannot be provided in externally or internally threaded part.

2. When a cotter pin cannot be used to prevent rotation of internal threads with respect to external threads.

3. When lockwire cannot be used to prevent loosening of threaded parts.

4. When fastening is not used for fabrication of primary structure.

5. When loosening of threaded parts would not endanger safety of airplane or people.

6. When corrosion encouraged by gouging aluminum or magnesium alloys by edges of teeth on tooth-locked washers would not cause malfunctioning of parts being fastened together.

1-13. USE OF SELF-LOCKING NUTS.

a. Restrictions.

1. Self-locking nuts cannot be used under certain conditions.

(a) Used, reworked, or reprocessed nuts should not be installed for any application.

(b) Do not use if at joints in control systems for singular attach points.

(c) Do not use on externally threaded parts that serve as an axle of rotation for another part where torsional (torque) loads can cause nut to loosen and/or become separated. Examples are pulleys, levers, linkages, and cam followers.

NOTE

Self-locking nuts can be used when threaded parts are held by a positive locking device that requires shearing or rupture before torsional loads can act on threaded parts.

(d) Do not use where a loose nut, bolt, or screw could fall or be drawn into an area that would impede or damage or otherwise distort operation.

(e) Do not use to attach access panels and doors or to assemble components that are routinely disassembled or removed for access and servicing.

(f) In general, do not use self-locking nuts where loss of bolt affects safety of flight.

2. Bolts, studs, or screws, excluding Hi-Locks, must extend through self-locking nut for a length equivalent of two threaded pitches. This length includes chamfer.

3. Self-locking nuts which are attached to structure shall be attached in a positive manner to eliminate possibility of their rotation or misalignment when tightening is to be accomplished by rotating bolts to structure, and permit replacement of nuts.

MODEL P210 SERIES SERVICE MANUAL




Figure 1-8. Safetying Turnbuckle Assemblies

MODEL P210 SERIES SERVICE MANUAL

1-14. CONTROL CABLE WIRE BREAKAGE AND CORROSION LIMITATIONS.

a. Inspection of Control Cables.

1. Control cable assemblies are subject to a variety of environmental conditions and forms of deterioration that ultimately may be easy to recognize such as wire/strand breakage, or the not so readily visible types of deterioration including corrosion and/or distortion. The following information will aid in detecting these cable conditions.

2. Broken Wire.

(a) Examine cables for broken wires by passing a cloth along length of cable. This will detect broken wires, if cloth snags on cable. Critical areas for wire breakage are those sections of cable which pass through fairleads, across roob blocks, and around pulleys. If no snags are found, then no further inspection is required. If snags are found or broken wires are suspected, then a more detailed inspection is necessary which requires that the cables be bent in a loop to confirm broken wires (refer to figure 1-7). Loosen or remove cable to allow it to be bent in a loop as shown. While rotating cable, inspect bent area for broken wires.

(b) Wire breakage criteria for cables in flap,


aileron, rudder, and elevator systems are as follows:

(1) Individual broken wires are acceptable in primary and secondary control cables at random locations when there are no more than six broken wires in any given ten-inch cable length.

3. Corrosion.

(a) Carefully examine any cable for corrosion that has a broken wire in a section not in contact with wear-producing airframe components such as pulleys, fairleads, rub blocks, etc. It may be necessary to remove and bend cable to properly inspect it for internal strand corrosion as this condition is usually not evident on outer surface of cable. Replace cable if internal corrosion is found. If a cable has been wiped clean of its corrosion-preventive lubricant and metal-brightened, the cable shall be examined closely for corrosion. For description of control cable corrosion, refer to FAA Advisory Circular AC43-4.

MODEL P210 SERIES SERVICE MANUAL



DO NOT BEND INTO LOOP SMALLER THAN 50 CABLE DIAMETERS

55611119

Figure 1-7. Cable Broken Wire Inspection

MODEL P210 SERIES SERVICE MANUAL

1-15. ADHESIVES, CEMENTS AND SEALANTS - SHELF LIFE AND STORAGE.

a. General.

1. This section provides information which defines the proper storage and usable life (shelf life) of adhesives, cements and sealants which are used for maintenance and/or repair of the airplane. Also included in this section is the criteria used for testing these materials after the normal shelf life has expired, to determine if an extension to the shelf life is possible.

2. Shelf life refers to a specified period of time usually from the date of manufacture (normally stamped or printed on the product container) to the expiration date (which should be determined using limits specified in Table 1-7 or if applicable, the manufacturer's expiration date printed or stamped on the product container). The specified shelf life is dependent on proper storage in accordance with the limits specified in this section and/or the manufacturer's instructions.

b. Storage Criteria.

1. Storage of Adhesives and Cements.

All adhesives and cements shall be stored under controlled temperature conditions. If open shop storage becomes necessary, these products shall in no case be stored in an area which will subject them to temperatures in excess of 95°F. Containers shall be tightly closed prior to being placed into the proper storage environment. For proper storage environment, refer to Table 1-7 and the following paragraphs.

(a) Class I - These adhesives are epoxy base materials and have one year storage at room temperature. 0°F storage will extend the storage life. Refer to the product container instructions for storage temperature and life.

(b) Class II, III and IV - These adhesives are rubber and resin base and are good for six months at room temperature storage. 40°F storage will extend the storage life. Refer to the product container instructions for limits of each adhesive.

(c) Class V - These are silicone rubber adhesives. If stored in their original containers at a temperature below 80°F, have a shelf life of one year or as indicated on the storage container.

(d) Class VI - These are solvent bonding solvents. They should be stored in their original containers and tightly closed, and stored at 40°F temperature.

(e) Class VII - Cyanoacrylate base materials must be stored in the original containers at 40°F or as specified on the container instructions.

(f) Class VIII - These are pressure sensitive materials. The shelf life is two years when stored at 75°F and 50 percent relative humidity.

(g) Class IX - These are polyurethane products. Store in original container, between 70 and 100°F. Urethanes are moisture sensitive and precautions should be taken to ensure complete protection from moisture contamination. Container must be tightly closed at all times.

(h) Class X - These are acrylic base materials. They require storage at 40°F or per instructions on product container.

c. Storage of Sealants.

1. All sealants shall be stored under controlled temperature conditions. If open shop storage becomes necessary, these products shall in no case be stored in an area which will subject them to temperatures in excess of 95°F or below 40°F. Containers shall be tightly closed prior to placing them in the proper storage environment. For proper storage environment, refer to Table 1-7 and the following paragraphs.

(a) Premixed and frozen sealants shall be stored at -40°F or colder and shall not be used more than six weeks after the date of mixing even if all storage is at -40°F or colder. If storage temperatures rise above -40°F, but not warmer than -30°F, the material may be stored for a maximum of two weeks warmer than -40°F plus time at -40°F or colder for a combined total not to exceed five weeks beyond the date of mixing. If storage temperatures rise above -40°F but are not warmer than -20°F, the materials may be stored for a maximum of one week above -30°F plus time at -40°F or colder for a combined total not to exceed four weeks beyond the date of mixing.

(b) Unmixed sealants shall be stored at a controlled temperature of between 40 and 80°F and have a shelf life of approximately six months when stored within this temperature range. Unmixed sealants stored at temperatures exceeding 80°F shall be used within five weeks.

2. All materials should be used on a "first in-first out" basis. The adhesives, cements and sealants should be rotated so this requirement can be accomplished. All material containers should be clearly marked with a "use by" date, consisting of the year and month. All materials not used by this date must be tested prior to use. Refer to Testing criteria and Table 1-7.

d. Testing Criteria.

1. Any material (adhesive, cement or sealant) not used within its shelf life will be tested and the results reviewed to determine if the material is usable. If there is doubt about the material being usable, it must be properly disposed of. Material that has exceeded its original shelf life may be retested to determine if the material meets its requirements. Materials meeting their requirements will have their shelf life extended as specified in Table 1-7. Materials with shelf life extensions must be retested after a specified period of time. Refer to Table 1-7.

MODEL P210 SERIES SERVICE MANUAL

2. Testing of Overaged Adhesives and Cements.

NOTE

Overaged adhesives and cements are those that have exceeded their original shelf life and must be tested prior to use and/or given extended shelf life.

(a) Class I Epoxy Adhesive - Examine both components to ensure that they are still workable. Check for gelling and/or contamination. Stir components and mix a small amount of adhesive. Verify that adhesive sets up and hardens.

(b) Class II, III and IV Rubber and Resin Base Adhesives - Open containers and check for gelling and/or contamination. Check for spreading and drying.

(c) Class V Silicone Rubber Adhesives - Examine adhesive for hardness. If adhesive is still soft and can be spread, it is acceptable. Verify that adhesive will harden.

(d) Class VI Solvent Bonding Solvents - Check for signs of apparent contamination. Solvents should be clean and clear with no signs of cloudiness.

(e) Class VII Cyanoacrylic Base Adhesives - Verify that product is still liquid with no visible signs of contamination.

(f) Class VIII Pressure Sensitive Materials - Open containers and inspect for hardening, gelling and contamination. Stir components and mix a small amount of adhesive. Verify that adhesive sets up properly.

(g) Class X Acrylic Adhesives - Inspect base material to ensure that it is still liquid. Mix a small amount of the components and verify that it sets up properly.

3. In general, if these materials exhibit normal physical properties, with no signs of hardening, gelling or contamination and set up and/or harden properly as applicable, the shelf life may be extended as specified in Table 1-7.

e. Testing of Overaged Sealants.

NOTE

Overaged sealants are those that have exceeded their original shelf life and must be tested prior to use and/or given extended shelf life.

1. For identification of sealants Classification, refer to Fuel, Weather, Pressure and High-Temperature Sealing - Maintenance Practices.
2. Overaged sealants to be tested for possible

shelf life extension shall be properly mixed using the correct materials, procedures and equipment.

3. Overaged premixed frozen sealants, along with unmixed sealants should be visually inspected. Sealants which show conclusive evidence of separation, discoloration and/or gelling prior to the addition of a thinner or curing agent shall be discarded. When in doubt of the sealant quality, the overaged sealant should be compared with the same type of sealant, under six months old, which is known to be satisfactory.

4. The mixed sealants may be tested by placing a small amount of sealant (sample buttons) on a sheet of paper. After the sample buttons have cured, they should be cut in half and examined. The sealant should show no signs of spots or streaks of unmixed base compound or curing agent. However, sample buttons containing spots, streaks, discoloration and/or variations in uniformity of color are acceptable if these spots, streaks, etc., are tack free upon inspection. All mixed sealant should be as void free as possible.

5. Contaminated sealant, premixed sealant that have been thawed and refrozen shall be discarded.

6. Type I, Class A sealants should be checked for appearance, application time, tack-free time, cure time and adhesion.

7. Type I, Class B sealants should be checked for appearance, application time, cure time, tack-free time and adhesion. In addition, Class B-2 and B-4 sealants should be checked for initial flow.

8. Type I, Class C sealants should be checked for appearance, application time, cure time and adhesion. In addition, Class C sealants should be tested to determine that they ARE NOT at a tackfree condition at the end of their rated work life (squeeze out life).

9. Type II sealants should be checked for appearance, application time, tack-free time and cure time.

10. Type III sealants should be easily thinned with MEK, when difficulty is encountered in thinning the sealant, it should be discarded.

11. Type IV sealants should be checked for appearance, application time, tack-free time and cure time.

12. Type V and VI sealants should be checked for appearance, tack-free time and cure time.

13. Type VII sealants should be checked for appearance, application time, tack-free time and cure time.

14. Type VIII sealants should be checked for appearance, application time, tack-free time, cure time and adhesion. Adhesion to aluminum should be (peel) less than two-pounds per inch of width.

MODEL P210 SERIES SERVICE MANUAL

PRODUCT	STORAGE CONDITION (TEMPERATURE IN DEGREES FAHENHEIT)	SHELF LIFE IN MONTHS	EXTEND SHELF LIFE IN MONTHS	RETEST IN MONTHS
ADHESIVES AND CEMENTS				
EA9309.3NA	40 TO 80°F	12 Months	6 Months	6 Months
EA9339	40 TO 80°F	12 Months	6 Months	6 Months
EA9314	40 TO 80°F	12 Months	6 Months	6 Months
EA9330	40 TO 80°F	12 Months	6 Months	6 Months
EA907	40 TO 80°F	12 Months	6 Months	6 Months
Devcon F	40 TO 80°F	12 Months	6 Months	6 Months
EA934NA	40 TO 80°F	12 Months	6 Months	6 Months
380/6	40 TO 80°F	12 Months	6 Months	6 Months
A1186B	40 TO 80°F	12 Months	6 Months	6 Months
EC2216	40 TO 80°F	12 Months	6 Months	6 Months
#10 Fastset	40 TO 80°F	12 Months	6 Months	6 Months
608 Quickset	40 TO 80°F	12 Months	6 Months	6 Months
EC880	40 TO 80°F	8 Months	3 Months	3 Months
EC847	40 TO 80°F	8 Months	3 Months	3 Months
EC1300L	40 TO 80°F	*6 Months	*3 Months	*3 Months
5452	40 TO 80°F	12 Months	6 Months	6 Months
56431	40 TO 80°F	12 Months	6 Months	6 Months
1636	40 TO 80°F	12 Months	6 Months	6 Months
RTV - 157	40 TO 80°F	12 Months	6 Months	6 Months
RTV - 158	40 TO 80°F	12 Months	6 Months	6 Months
RTV - 159	40 TO 80°F	12 Months	6 Months	6 Months
RTV732	40 TO 80°F	12 Months	6 Months	6 Months
RTV102	40 TO 80°F	12 Months	6 Months	6 Months
RTV103	40 TO 80°F	12 Months	6 Months	6 Months
RTV106	40 TO 80°F	12 Months	6 Months	6 Months
RTV108	40 TO 80°F	12 Months	6 Months	6 Months
RTV109	40 TO 80°F	12 Months	6 Months	6 Months
RTV94034	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 222	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 242	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 271	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 277	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 290	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 416	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 495	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 515	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 569	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 592	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 595	40 TO 80°F	12 Months	6 Months	6 Months

* Do not use after three months of storage in the 81°F to 90°F range
Do not use after five days of storage above 90°F.

MODEL P210 SERIES SERVICE MANUAL

PRODUCT	STORAGE CONDITION (TEMPERATURE IN DEGREES FAHENHEIT)	SHELF LIFE IN MONTHS	EXTEND SHELF LIFE IN MONTHS	RETEST IN MONTHS
ADHESIVES AND CEMENTS (CONTINUED)				
Loctite 601	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 620	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 680	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 1282	40 TO 80°F	12 Months	6 Months	6 Months
Loctite 1283	40 TO 80°F	12 Months	6 Months	6 Months
DA-5521	40 TO 80°F	12 Months	6 Months	6 Months
PS-18	40 TO 80°F	12 Months	6 Months	6 Months
PS-30	40 TO 80°F	12 Months	6 Months	6 Months
XA-3678	40 TO 80°F	12 Months	6 Months	6 Months
XF-3585	40 TO 80°F	12 Months	6 Months	6 Months
LR-100-226	40 TO 80°F	12 Months	6 Months	6 Months
EC776	40 TO 80°F	* 8 Months	* 3 Months	*3 Months
SB and P2	40 TO 80°F	12 Months	6 Months	6 Months
SEALANTS				
Pro-Seal 890	40 TO 80°F	6 Months	2 Months	2 Months
GC-408	40 TO 80°F	6 Months	2 Months	2 Months
PR1422	40 TO 80°F	6 Months	2 Months	2 Months
PR1440	40 TO 80°F	6 Months	2 Months	2 Months
GC435	40 TO 80°F	6 Months	2 Months	2 Months
Pro-Seal 567	40 TO 80°F	6 Months	2 Months	2 Months
PR810	40 TO 80°F	6 Months	2 Months	2 Months
Pro-Seal 700	40 TO 80°F	6 Months	2 Months	2 Months
GC1900	40 TO 80°F	6 Months	2 Months	2 Months
PR366	40 TO 80°F	6 Months	2 Months	2 Months
Pro-Seal 735	40 TO 80°F	6 Months	2 Months	2 Months
Pro-Seal 895	40 TO 80°F	6 Months	2 Months	2 Months
Pro-Seal 706B	40 TO 80°F	6 Months	2 Months	2 Months
PR1321	40 TO 80°F	6 Months	2 Months	2 Months
GC200	40 TO 80°F	6 Months	2 Months	2 Months
RTV-730	40 TO 80°F	6 Months	2 Months	2 Months
Pro-Seal 815	40 TO 80°F	6 Months	2 Months	2 Months
GC402	40 TO 80°F	6 Months	2 Months	2 Months
PR-1005L	40 TO 80°F	*8 Months	*3 Months	*3 Months
GC-3001	40 TO 80°F	*8 Months	*3 Months	*3 Months
444R	40 TO 80°F	*8 Months	*3Months	*3 Months

* Do not use after three months of storage in the 81°F to 90°F range
Do not use after five days of storage above 90°F.

MODEL P210 SERIES SERVICE MANUAL

SECTION 2

GROUND HANDLING, SERVICING, CLEANING, LUBRICATION AND INSPECTION

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand, nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire, or a component malfunction, could cause the propeller to rotate.

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
GROUND HANDLING	1B5/2-1	Landing Gear Hydraulic Retraction System	1B16/2-10
Towing	1B5/2-1	Hydraulic Fluid Sampling and Contamination Check	1B16/2-10
Hoisting	1B5/2-1	Oxygen System	1B17/2-10A
Jacking	1B5/2-1	Face Masks	1B17/2-10A
Leveling	1B6/2-2	CLEANING	1B17/2-10A
Weighing	1B6/2-2	General Description	1B17/2-10A
Parking	1B6/2-2	Upholstery and Interior	1B17/2-10A
Tie-Down	1B6/2-2	Plastic Trim	1B17/2-10A
Flyable Storage	1B6/2-2	Windshield and Windows	1B18/2-10B
Returning Aircraft to Service	1B6/2-2	Materials Required	1B18/2-10B
Temporary Storage	1B9/2-5	Waxing	1B19/2-11
Inspection During Storage	1B9/2-5	Preventive Maintenance	1B19/2-11
Returning Aircraft to Service	1B9/2-5	Interior Trim	1B19/2-11
Indefinite Storage	1B9/2-5	Aluminum Surfaces	1B19/2-11
Inspection During Storage	1B10/2-6	Painted Surfaces	1B20/2-12
Returning Aircraft to Service	1B10/2-6	Engine/Engine Compartment	1B20/2-12
SERVICING	1B11/2-6A	Propeller	1B21/2-13
Description	1B11/2-6A	Wheels	1B21/2-13
Fuel Tanks	1B11/2-6A	LUBRICATION	1B21/2-13
Fuel Additives	1B11/2-6A	General Description	1B21/2-13
Fuel Drains	1B14/2-8	Nose Gear Torque Links	1B21/2-13
Engine Oil	1B14/2-8	Tachometer Drive Shaft	1B21/2-13
Hydraulic Fluid	1B15/2-9	Wheel Bearing Lubrication	1B21/2-13
Engine Induction Air Filter	1B15/2-9	Wing Flap Actuator	1B21/2-13
Vacuum System Filter	1B15/2-9	Rod End Bearings	1B21/2-13
Battery	1B15/2-9	INSPECTION	1C7/2-23
Tires	1B15/2-9		
Nose Gear Strut	1B16/2-10		
Nose Gear Shimmy Dampener	1B16/2-10		
Hydraulic Brake Systems	1B16/2-10		

2-1. GROUND HANDLING.

2-2. TOWING. Moving the aircraft by hand is accomplished by using the landing gear struts as push points. A tow bar attached to the nose gear should be used for steering and maneuvering the aircraft.

CAUTION

When towing the aircraft, never turn the nose wheel more than 35 degrees either side of center or the nose gear will be damaged. Do not push on control surfaces or outboard empennage surfaces. When pushing on the tailcone, always apply pressure at a bulkhead to avoid buckling the skin.

2-3. HOISTING. The aircraft may be hoisted with a hoist of two-ton capacity by using suitable slings.

The front sling should be hooked to the engine lifting eye, and the aft sling should be positioned around the fuselage at the first bulkhead forward of the leading edge of the stabilizer.

2-4. JACKING. Refer to figure 2-2 for jacking procedures.

CAUTION

When using the landing gear strut jack pad, flexibility of the gear strut will cause the main wheel to slide inboard as the wheel is raised, tilting the jack. The jack must then be lowered for a second jacking operation. Jacking both wheels simultaneously with landing gear strut jack pad is not recommended.

MODEL P210 SERIES SERVICE MANUAL

TOW BAR: PART NUMBER 0501019-1 OR 0700315-4 (TELESCOPING)
IS AVAILABLE FROM THE CESSNA SUPPLY DIVISION.




Figure 2-1. Typical Tow Bar

2-4A. LEVELING. Longitudinally leveling of the aircraft is accomplished by backing out the two screws on the left side of the fuselage and then placing a level across the screws. Corresponding points on either the upper or lower main door sills may be used to level the aircraft laterally.

2-4B. WEIGHING AIRCRAFT. Refer to Pilot's Operating Handbook.

2-5. PARKING. Parking precautions depend principally on local conditions. As a general precaution, it is wise to set the parking brake or chock the wheels, and install the control lock. In severe weather, and high wind conditions, tie down the aircraft as outlined in paragraph 2-6 if a hangar is not available.

2-6. TIE-DOWN. When mooring the aircraft in the open, head into the wind if possible. Secure control surfaces with the internal control lock and set brakes.

CAUTION

Do not set parking brakes during cold weather when accumulated moisture may freeze the brakes or when the brakes are overheated.

a. Tie ropes, cables or chains to the wing tie-down fittings located midwing in line with the outboard edge of the flaps. Secure the opposite ends of ropes, cables or chains to ground anchors.

b. Secure a tie-down rope (no chains or cables) to upper trunion of the nose gear, and secure opposite end of rope to ground anchor.

c. Secure the middle of a rope to the tail tie-down ring. Pull each end of rope away at a 45-degree angle and secure to ground anchors at each side of tail.

d. Secure control lock on pilot control column. If control lock is not available, tie pilot control wheel back with front seat belt.

e. These aircraft are equipped with a spring-loaded steering bungee which affords protection against normal wind gusts. However, if extremely high wind gusts are anticipated, additional locks may be installed.

2-7. FLYABLE STORAGE. Flyable storage is defined as a maximum of 30 days non-operational storage and/or the first 25 hours of intermittent engine operation.

NOTE

The aircraft is delivered from Cessna with a Corrosion Preventive Aircraft Engine Oil (Military Specification MIL-C-6529, Type II). This engine oil is a blend of aviation grade straight mineral oil and a corrosion preventive compound. This engine oil should be used for the first 25 hours of operation use only aviation grade straight mineral oil of the correct viscosity.


During the 30 day non-operational storage or the first 25 hours of intermittent engine operation, every seventh day the propeller shall be rotated by hand without running the engine. After rotating the engine five revolutions, stop the propeller 45° to 90° from the position it was in. If the aircraft is stored outside, tie-down in accordance with paragraph 2-6. In addition, the pitot tube, static air vents, air vents, openings in the engine cowling, and other similar openings shall have protective covers installed to prevent entry of foreign material. If at the end of thirty (30) days aircraft will not be removed from storage, the engine shall be started and run. The preferred method would be to fly the aircraft for thirty (30) minutes, and up to, but not exceeding normal oil and cylinder temperatures.

CAUTION

Excessive ground operation shall be avoided.

2-8. RETURNING AIRCRAFT TO SERVICE. After flyable storage, returning the aircraft to service is accomplished by performing a thorough pre-flight inspection. At the end of the first 25 hours of engine operation, drain engine oil and change external oil filter element. Service engine with correct grade and quantity of oil. Refer to figure 2-4 and paragraph 2-20 for correct grade of engine oil.

MODEL P210 SERIES SERVICE MANUAL



ITEM NUMBER	TYPE AND PART NUMBER	REMARKS
①	Block Cessna #1200028-1	1 x 4 x 4 padded with 1/4" rubber Jack point (SEE NOTE 1)
②	Cessna #2-168	Universal tail stand (SEE NOTE 2)
③	#2-170 Basic jack #2-109 Leg Extension #2-70 Slide tube extension	Closed height: 69-1/2 inches; extended height: 92" (Insert slide tube extension into basic jack)

- Provisions are furnished on the bottom of each wing for installation of optional 1200028-1 jack points.
- Weighted adjustable stand attaches to tie-down ring.

Wing jack points are aft of the aircraft center-of-gravity. This causes the aircraft to be nose heavy when on jacks. Place additional weights (shot bags or sand bags) on the weighted tail stand to hold the tail down. In addition, the base of adjustable tail stand (2-168) is to be filled with concrete for additional weight as a safety factor.

- Items (1), (2) and (3) are available from the Cessna Supply Division.

Figure 2-2. Jacking Details (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL

JACKING AIRCRAFT

1. Lower the aircraft tail so that wing jack and stands can be placed at wing jack points.
2. Raise aircraft tail and attach tail stand to tail tie-down ring. BE SURE the tail stand weighs enough to keep the tail down under all conditions and that it is strong enough to support any weight that may be placed upon it.
3. Raise jacks evenly until desired height is reached. When jacking the aircraft, the main landing gear wheels must be a minimum of 16" above shop floor for landing gear retraction.
4. The jack point on the bottom of the step may be used to raise only one main wheel. Do not use brake casting as a jack point.
5. The nose may be raised by weighting down the tail. Place weight on each side of stabilizer, next to fuselage.
6. Whenever the landing gear is to be operated in the shop, use the wing jack and tail jack points to raise the aircraft.
7. The aircraft may be hoisted as outlined in paragraph 2-3.

REMOVING AIRCRAFT FROM JACKS.

1. Place landing gear control handle in gear down position.
2. Operate ground hydraulic power source or aircraft emergency hydraulic hand pump until landing gear is down and locked, and the green (DOWN) light is illuminated.
3. Disconnect ground hydraulic power source and/or stow emergency hydraulic hand pump handle.
4. Ascertain that green (DOWN) light is illuminated; then place master switch in OFF position.
5. Lower jacks evenly until aircraft rests on the landing gear and remove wing jacks and tail stand.
6. Compress nose landing gear shock strut to static position.

Figure 2-2. Jacking Details (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

2-9. **TEMPORARY STORAGE.** Temporary storage is defined as aircraft in a non-operational status for a maximum of 90 days. The aircraft is constructed of corrosion-resistant alclad aluminum, which will last indefinitely under normal conditions if kept clean. However, these alloys are subject to oxidation. The first indication of corrosion on unpainted surfaces is in the form of white deposits or spots. On painted surfaces, the paint is discolored or blistered. Storage in a dry hangar is essential to good preservation and should be procured, if possible. Varying conditions will alter the measures of preservation, but under normal conditions in a dry hangar, and for storage periods not to exceed 90 days, the following methods of treatment are suggested.

- a. Fill fuel bays with correct grade of gasoline.
- b. Clean and wax aircraft thoroughly.
- c. Clean any oil or grease from tires, and coat tires with a tire preservative. Cover tires to protect against grease or oil.
- d. Either block up fuselage to relieve pressure on tires or rotate wheels every 30 days to prevent flat spotting the tires.
- e. Lubricate all airframe items and seal or cover all openings which could allow moisture and/or dust to enter.

NOTE

The aircraft battery serial number is recorded in the aircraft equipment list. To assure accurate warranty records, the battery should be reinstalled in the same aircraft from which it was removed. If the battery is returned to service in a different aircraft, appropriate record changes must be made and notification sent to the Cessna Claims Department.

- f. Remove battery and store in a cool, dry place; service battery periodically and charge as required.

NOTE

An engine treated in accordance with the following may be considered being protected against normal atmospheric corrosion for a period not to exceed 90 days.

- g. Disconnect spark plug leads and remove upper and lower spark plugs from each cylinder.

NOTE

The preservative oil must be Lubricating Oil-Contact and Volatile, Corrosion Inhibited, MIL-L-46002, Grade 1, or equivalent.

- h. Using a portable pressure sprayer, spray preservative oil through the upper spark plug hole of each cylinder with the piston in a down position. Rotate crankshaft as each pair of cylinders is sprayed.
 - i. After completing step "h," rotate crankshaft so that no piston is at a top position.
 - j. Again, spray each cylinder without moving the crankshaft, to thoroughly cover all interior surfaces of the cylinder above the piston.

- k. Install spark plugs and connect spark plug leads.
 - l. Apply preservative oil to the engine interior by spraying approximately two ounces of the preservative oil through the oil filler tube.
 - m. Seal all engine openings exposed to the atmosphere, using suitable plugs or non-hygroscopic tape. Attach a red streamer at each point that a plug or tape is installed.
 - n. If the aircraft is to be stored outside, perform the procedures outlined in paragraph 2-6. In addition, the pitot tube, static source vents, air vents, openings in the engine cowling, and other similar openings should have protective covers installed to prevent entry of foreign material.
 - o. Attach a warning placard to the propeller to the effect that the propeller shall not be moved while the engine is in storage.

2-10. INSPECTION DURING STORAGE.

- a. Inspect airframe for corrosion at least once a month. Remove dust collections as frequently as possible. Clean and wax aircraft as required.
- b. Inspect the interior of at least one cylinder through the spark plug hole for corrosion at least once each month.

NOTE

Do not move crankshaft when inspecting interior of cylinder for corrosion.

- c. If at the end of the 90 day period, the aircraft is to be continued in non-operational storage, repeat the procedural steps "g" thru "o" of paragraph 2-9.

2-11. **RETURNING AIRCRAFT TO SERVICE.** After temporary storage, use the following procedure to return the aircraft to service.

- a. Remove aircraft from blocks. Check tires for proper inflation.
- b. Check and install battery.
- c. Check that oil sump has proper grade and quantity of engine oil.
- d. Service induction air filter and remove warning placard from propeller.
- e. Remove materials used to cover openings.
- f. Remove, clean and gap spark plugs.
- g. While spark plugs are removed, rotate propeller several revolutions to clear excess rust preventive oil from cylinders.
- h. Clean, gap and install spark plugs. Torque plugs to value listed in Section 12.
- i. Check fuel strainer. Remove and clean filter screen, if necessary. Check fuel bays and fuel lines for moisture and sediment. Drain enough fuel to eliminate moisture and sediment.
- j. Perform a thorough pre-flight inspection, then start and warm-up engine.

2-12. **INDEFINITE STORAGE.** Indefinite storage is defined as aircraft in a non-operational status for an indefinite period of time. Engines treated in accordance with the following may be considered protected against normal atmospheric corrosion, provided the procedures outlined in paragraph 2-13 are performed at the intervals specified.

MODEL P210 SERIES SERVICE MANUAL

- a. Operate engine until oil temperature reaches normal operating range. Drain engine oil sump and reinstall drain plug.
- b. Fill oil sump to normal operating capacity with corrosion preventive mixture.

NOTE

Corrosion preventive mixture consists of one part compound MIL-C-6529, Type I, mixed with three parts new lubricating oil of the grade recommended for service.

- c. Immediately after filling the oil sump with corrosion preventative mixture, fly the aircraft for a period of time not to exceed a maximum of 30 minutes.
- d. With engine operating at 1200 to 1500 rpm and induction air filter removed, spray corrosion preventive mixture into induction airbox, at the rate of one-half gallon per minute, until heavy smoke comes from exhaust stack, then increase the spray until the engine is stopped.

CAUTION

Injecting corrosion-preventive mixture too fast can cause a hydrostatic lock.

- e. Do not rotate propeller after completing step "d."
- f. Remove all spark plugs and spray corrosion-preventive mixture, which has been pre-heated (221° to 250°F), into all spark plug holes.

NOTE

To thoroughly cover all surfaces of the cylinder interior, move the nozzle of the spray gun from the top to the bottom of the cylinder. If by accident the propeller is rotated following this spraying, respray the cylinders to insure an unbroken coverage on all surfaces.

- g. Install lower spark plugs or install solid plugs, and install dehydrator plugs in upper spark plug holes. Be sure that dehydrator plugs are blue in color when installed.
- h. Cover spark plug lead terminals with shipping plugs (AN4060-1) or other suitable covers.
 - i. With throttle in full open position, place a bag of desiccant in the induction air intake and seal opening with moisture resistant paper and tape.
 - j. Place a bag of desiccant in the exhaust tailpipe and seal opening with moisture resistant tape.
 - k. Seal cold air inlet to the heater muff with moisture resistant tape.
 - l. Seal engine breather by inserting a protex plug in the breather hose and clamping in place.
 - m. Seal all other engine openings exposed to atmosphere using suitable plugs or non-hygroscopic tape.

NOTE

Attach a red streamer to each place plugs or tape is installed. Either attach red streamers outside of the sealed area with tape or to the inside of the sealed area with safety wire to prevent wicking of moisture into the sealed area.

- n. Drain corrosion-preventive mixture from engine sump and reinstall drain plug.

NOTE

The corrosion-preventive mixture is harmful to paint and should be wiped from painted surfaces immediately.

- o. Attach a warning placard on the throttle control knob, to the effect that the engine contains no lubricating oil. Placard the propeller to the effect that it should not be moved while the engine is in storage.
- p. Prepare airframe for storage as outlined in paragraph 2-9 thru step "f."

NOTE

As an alternate method of indefinite storage, the aircraft may be serviced in accordance with paragraph 2-9 providing the aircraft is run up at maximum intervals of 90 days and then reserviced per paragraph 2-9.

2-13. INSPECTION DURING STORAGE. Aircraft in an indefinite storage shall be inspected as follows:

- a. Inspect cylinder protex plugs each 7 days.
- b. Change protex plugs if their color indicates an unsafe condition.
- c. If the dehydrator plugs have changed color in one half of the cylinders, all desiccant material in the engine shall be replaced with new material.
- d. Every 6 months respray the cylinder interiors with corrosion-preventive mixture and replace all desiccant and Protex plugs.

NOTE

Before spraying, inspect the interior of one cylinder for corrosion through the spark plug hole and remove at least one rocker box cover and inspect the valve mechanism.

2-14. RETURNING AIRCRAFT TO SERVICE.

After indefinite storage, use the following procedure to return the aircraft to service.

- a. Remove aircraft from blocks and check tires for correct inflation. Check for correct nose gear strut inflation.
- b. Check battery and install.
- c. Remove all materials used to seal and cover openings.
- d. Remove warning placards posted at throttle and propeller.

MODEL P210 SERIES SERVICE MANUAL

- e. Remove oil sump drain plug and drain sump. Install and safety drain plug.
- f. Remove existing filter, install new oil filter.

NOTE

The corrosion-preventive mixture will mix with the engine lubricating oil, so flushing the oil system is not necessary. Draining the oil sump will remove enough of the corrosion-preventive mixture.

- g. Service and install the induction air filter.
- h. Remove dehydrator plugs and spark plugs or plugs installed in spark plug holes and rotate propeller by hand several revolutions to clear corrosion-preventive mixture from cylinders.
- i. Clean, gap and install spark plugs. Torque plugs to value listed in Section 12.
- j. Check fuel strainer. Remove and clean filter screen. Check fuel tanks and fuel lines for moisture and sediment, and drain enough fuel to eliminate.
- k. Perform a thorough pre-flight inspection, then start and warm-up engine.
- l. Thoroughly clean aircraft and flight test aircraft.

2-15. SERVICING.

2-16. DESCRIPTION. Servicing requirements are shown in figure 2-4. The following paragraphs supplement this figure by adding details not included in the figure.

2-17. FUEL BAYS. An area of each wing is sealed to form an integral fuel tank. Recommended fuel grade is listed in figure 2-4, and fuel capacities are given in figure 1-1. Fuel bays should be filled immediately after flight to lessen condensation in the bays and lines.

NOTE

Before refueling or when airplane is parked on a slope, place the fuel selector handle in the LEFT ON or RIGHT ON position, whichever corresponds to the low wing. This will minimize crossfeeding from the fuller bay and reduce fuel seepage from the wing vents. This note applies only to 1985 models.

WARNING

DURING ALL FUELING PROCEDURES, FIRE-FIGHTING EQUIPMENT MUST BE AVAILABLE. TWO GROUND WIRES FROM DIFFERENT POINTS ON THE AIRPLANE TO SEPARATE APPROVED GROUND STAKES SHALL BE USED TO PREVENT ACCIDENTAL DISCONNECTION OF ONE GROUND WIRE. ENSURE THAT FUELING NOZZLE IS GROUNDED TO THE AIRPLANE.

- a. Tie-down rings should be used as grounding points for all grounding wires during re-fueling procedures.
- b. Plugs or caps should be placed on all disconnected hoses, lines, and fittings to prevent residual fuel drainage, thread damage, or entry of dirt or foreign material into fuel system.

2-18. USE OF FUEL ADDITIVES FOR COLD WEATHER OPERATION. Strict adherence to recommended preflight draining instructions will eliminate any free water accumulations from the tank sumps. While small amounts of water may still remain in solution in the gasoline, it will normally be consumed and go unnoticed in the operation of the engine.

MODEL P210 SERIES SERVICE MANUAL

One exception to this can be encountered when operating under the combined effect of: 1) use of certain fuels, with 2) high humidity conditions on the ground 3) followed by flight at high altitude and low temperature. Under these unusual conditions small amounts of water in solution can precipitate from the fuel stream and freeze in sufficient quantities to induce partial icing of the engine fuel system.

While these conditions are quite rare and will not normally pose a problem to owners and operators, they do exist in certain areas of the world and consequently must be dealt with when encountered.

Therefore, to alleviate the possibility of fuel icing occurring under these unusual conditions it is permissible to add isopropyl alcohol or ethylene glycol monomethyl ether (EGME) compound to the fuel supply. See figure 2-3 for fuel additive mixing ratio.

CAUTION

Diethylene glycol monomethyl ether (DEGME) has NOT been approved by engine manufacturer for use with propeller single engine aircraft.

The introduction of alcohol or EGME compound into the fuel provides two distinct effects: 1) it absorbs the dissolved water from the gasoline and 2) alcohol has a freezing temperature depressant effect.

Alcohol, if used, is to be blended with the fuel in a concentration of 1% by volume. Concentrations greater than 1% are not recommended since they can be detrimental to fuel tank materials.

The manner in which the alcohol is added to the fuel is significant because alcohol is most effective when it is completely dissolved in the fuel. To insure proper mixing the following is recommended.

1. For best results the alcohol should be added during the fueling operation by pouring the alcohol directly on the fuel stream issuing from the fuel nozzle.
2. An alternate method that may be used is to pre-mix the complete alcohol dosage with some fuel in a separate clean container (approximately 2-3 gallon capacity) and then transfer this mixture to the tank prior to the fuel operation.

Any high quality isopropyl alcohol may be used, such as: Anti-icing fluid (MIL-F-5566) or isopropyl alcohol (Federal Specification TT-I-735a).

Ethylene glycol monomethyl ether (EGME) compound in compliance with MIL-I-27686 or Phillips PFA-55MB, if used, must be carefully mixed with the fuel in concentrations not to exceed 0.15% by volume.

CAUTION

Mixing of the EGME compound with the fuel is extremely important because concentration in excess of that recommended (0.15 percent by volume maximum) will result in detrimental effects to the fuel tanks, such as deterioration of protective primer and sealants and damage to O-rings and seals in the fuel system and engine components. Use only blending equipment that is recommended by the manufacturer to obtain proper proportioning.

Do not allow the concentrated EGME compound to come in contact with the airplane finish or fuel cell as damage can result.

Prolonged storage of the airplane will result in a water buildup in the fuel which "leeches out" the additive. An indication of this is when an excessive amount of water accumulates in the fuel tank sumps. The concentration can be checked using a differential refractometer. It is imperative that the technical manual for the differential refractometer be followed explicitly when checking the additive concentration.

MODEL P210 SERIES SERVICE MANUAL




Figure 2-3. Fuel Additive Mixing Ratio Chart

2-19. FUEL DRAINS. Drains are located at various places throughout the fuel system. Refer to Section 13 for locations of the various drains in the system.

Remove drain plugs, actuate strainer drain and open all drain valves at the intervals specified in figure 2-4. Drain valves are installed in the fuel bays and in the reservoirs, and a fuel sampler cup is furnished. To activate the drain for sampling, place cup to valve and depress valve with rod protruding from cup. If water is found during daily inspection of the fuel strainer and fuel bay sump drains, open all drain valves and remove all fuel drain plugs to drain all water from the fuel system.

2-20. ENGINE OIL. Check engine lubricating oil with the dipstick five to ten minutes after the engine has been stopped. The aircraft should be in as near a level position as possible when checking the engine oil so that a true reading is obtained. Engine oil should be drained while the engine is still hot, and the nose of the aircraft should be raised slightly for more positive draining of any sludge which may have collected in the engine oil sump. Engine oil should be changed every six months, even though less than the specified hours have accumulated. Reduce these intervals for prolonged operations in dusty areas and in cold climates where sludging conditions exist, or where short flights and long idle periods are encountered, which cause sludging conditions. Always change oil and change external filter element whenever oil on the dipstick appears dirty. Aviation grade ashless dispersant oil conforming to Continental Motors Specification MHS-24, and all revisions or supplements thereto, and conforming with current Continental Aircraft Engine Service Bulletins shall be used.

NOTE

The aircraft is delivered from Cessna with a corrosion preventive aircraft engine oil (MIL-C-6259, Type II). If oil must be added during the first 25 hours of operation, use only aviation grade straight mineral oil conforming to Specification MIL-L-6082. After the first 25 hours of operation, drain engine oil sump and change filter element. Refill sump with correct quantity and grade of ashless dispersant oil conforming to Continental Motors Specification MHS-24 and with current Continental Aircraft Engine Service Bulletins. Newly overhauled engines should also be operated on aviation grade straight mineral oil conforming to Specification MIL-L-6082 until a total of 25 hours have accumulated.

When changing engine oil, install a new filter element. To drain oil, proceed as follows:

- Operate engine until oil temperature is at normal operating temperature.
- Remove oil drain plug from engine sump and allow oil to drain into a container.
- After engine oil has drained, install and safety drain plug.
- Change external oil filter element.
- Service engine with correct quantity and viscosity of aviation grade engine oil.

NOTE

Refer to inspection charts for intervals for changing engine oil and filters. Refer to figure 2-4 for correct viscosities and capacities of aviation grade engine oil.

MODEL P210 SERIES SERVICE MANUAL

2-20A. HYDRAULIC FLUID. Refer to figure 2-4.

2-21. ENGINE INDUCTION AIR FILTER. The induction air filter keeps dust and dirt from entering the induction system. The value of maintaining the air filter in a good clean condition can never be overstressed. More engine wear is caused through the use of a dirty or damaged air filter than is generally believed. The frequency with which the filter should be removed, inspected and cleaned will be determined primarily by aircraft operating conditions. A good general rule, however, is to remove, inspect and clean the filter at least every 100 hours of engine operating time, and more frequently if warranted by operating conditions. Under extremely dusty conditions, daily servicing of the filter is recommended. To service the induction filter, proceed as follows:

a. Remove filter from aircraft.

NOTE

Use care to prevent damage to filter element when cleaning filter with compressed air.

b. Clean filter by blowing with compressed air (not over 100 psi) from direction opposite of normal air flow. Arrows on filter case indicate direction of normal air flow.

CAUTION

Do not use solvent or cleaning fluids to wash filter. Use only a water and household detergent solution when washing the filter.

c. After cleaning as outlined in step "b", the filter may be washed, if necessary, in a solution of warm water and a mild household detergent. A cold water solution may be used.

NOTE

The filter assembly may be cleaned with compressed air a maximum of 30 times or it may be washed a maximum of 20 times. A new filter should be installed after using 500 hours of engine operating time or one year, whichever should occur first. However, a new filter should be installed anytime the existing filter is damaged. A damaged filter may have sharp or broken edges in the filtering panels which would allow unfiltered air to enter the induction system. Any filter that appears doubtful, shall have a new filter installed in its place.

d. After washing, rinse filter with clear water until rinse water draining from filter is clear. Allow water to drain from filter and dry with compressed air (not over 100 psi).

NOTE

The filtering panels of the filter may become distorted when wet, but they will return to their original shape when dry.

- e. Be sure airbox is clean, and inspect filter. If filter is damaged, a new filter should be installed.
- f. Install filter at entrance to airbox with gasket on aft face of filter frame and with flow arrows on filter frame pointed in the correct direction.

2-22. VACUUM SYSTEM AIR FILTER. The disposable type central air filter keeps dust and dirt from entering the vacuum-operated instruments. Inspect filter every 100 hours for damage. The filter should be replaced every 500 hours of operation and whenever it becomes sufficiently clogged to cause suction gage readings to drop below 4.6 in. Hg. The system should not be operated at anytime without a filter, nor are any lines to be left open when performing maintenance on the system, as minute particles of dust or other foreign materials may enter the lines and could severely damage the gyro instruments.

CAUTION

Smoking will cause premature filter clogging.

2-23. BATTERY. Battery servicing involves adding distilled water to maintain the electrolyte even with the horizontal baffle plate or split ring at the bottom of the filler holes, checking cable connections, and neutralizing and cleaning off any spilled electrolyte or corrosion. Use bicarbonate of soda (baking soda) and clean water to neutralize electrolyte or corrosion. Follow with a thorough flushing with clean water. Do not allow bicarbonate of soda to enter battery. Brighten cable and terminal connection with a wire brush, then coat with petroleum jelly before connecting. Check the battery every 100 hours (or at least every 90 days), oftener in hot weather. Add only distilled water, not acid or "rejuvenators," to maintain electrolyte level in the battery. Inspect the battery box and clean and remove any evidence of corrosion.

2-24. TIRES. Maintain tire pressure at the value specified in Section 1. When checking pressure, examine tire for wear, cuts, bruises and slippage.

NOTE

Recommended tire pressure should be maintained. Especially in cold weather, remember that any drop in temperature of the air inside a tire causes a corresponding drop in pressure.

MODEL P210 SERIES SERVICE MANUAL

2-25. NOSE GEAR STRUT. The nose gear strut requires periodic checking to ascertain that the strut is filled with hydraulic fluid and is inflated to the correct air pressure. To fill the nose gear strut with hydraulic fluid and air, proceed as follows:

- a. Remove valve cap and release all air.
- b. Remove valve housing assembly.
- c. Compress strut completely (stops in contact with outer barrel hub).
- d. Oil level.
 1. Fluid used should comply with specification MIL-O-5606.
 2. Fill strut to bottom of valve installation hole.
 3. Maintain oil level at bottom of valve installation hole.
- e. Fully extend strut.
- f. Replace valve housing assembly.
- g. With strut fully extended and nose wheel clear of ground, inflate strut to 80 PSL.

NOTE

The nose landing gear shock strut will normally require only a minimum amount of service. Maintain the strut extension pressure as shown in Section 1. Lubricate landing gear as shown in figure 2-5. Check the landing gear daily for general cleanliness, security of mounting, and for hydraulic fluid leakage. Keep machined surfaces wiped free of dirt and dust, using a clean lint-free cloth saturated with hydraulic fluid (MIL-H-5606) or kerosene. All surfaces should be wiped free of excessive hydraulic fluid.

2-26. NOSE GEAR SHIMMY DAMPENER. The shimmy dampener should be serviced at least every 100 hours. The dampener must be filled completely with hydraulic fluid, free of entrapped air with the compensating piston bottomed in the rod. Check that piston is completely bottomed as follows:

- a. Remove shimmy dampener from the aircraft.
- b. While holding the shimmy dampener in a vertical position with the filler plug pointed upward, loosen the filler plug.
- c. Allow the spring to bottom out the floating piston inside the shimmy dampener rod.
- d. When the fluid stops flowing, insert a length of stiff wire through the air bleed hole in the setscrew at the end of the piston rod until it touches the floating piston. The depth should be 3-13/16 inches.

NOTE

If the wire insertion is less than 3-13/16 inches, the floating piston is lodged in the shaft. If the wire cannot be used to free the piston, the rod assembly and piston should be replaced.

Service the shimmy dampener as follows:

- a. Remove filler plug from dampener.
- b. Move piston completely to opposite end from filler plug.

- c. Fill dampener with clean hydraulic fluid completely full.
- d. Reinstall plug and safety.
- e. Wash dampener in solvent and wipe dry with a cloth.
- f. Reinstall shimmy dampener in aircraft.

NOTE

Keep shimmy dampener, especially the exposed portions of the dampener piston shaft, clean to prevent collection of dust and grit which could cut the seals in the dampener barrel. Keep machined surfaces wiped free of dirt and dust, using a clean lint-free cloth saturated with hydraulic fluid (MIL-H-5606) or kerosene. All surfaces should be wiped free of excessive hydraulic fluid.

2-27. HYDRAULIC BRAKE SYSTEMS. Check brake master cylinders and refill with hydraulic fluid as specified in the inspection charts. Bleed the brake system of entrapped air whenever there is a spongy response to the brake pedals. Refer to Section 5 for filling and bleeding the brake systems.

2-28. LANDING GEAR HYDRAULIC RETRACTION SYSTEM. Draining, filling and bleeding of the landing gear hydraulic system can be accomplished by the following method.

- a. Place aircraft master switch in OFF position and place aircraft on jacks as shown in figure 2-2. Bleed pressure from system by moving landing gear selector valve to gear UP position.

CAUTION

Do not turn master switch ON while hydraulic system is open to atmosphere. The pump will automatically start, causing hydraulic fluid to spray from any open line.

- b. Drain system by removing cap from elbow on right side of power pack (behind access cover) and attaching a drain hose to the elbow. Place end of hose in a container of at least one gallon capacity and using emergency hand pump, pump fluid into container. When power pack reservoir is empty, replace cap.

- c. Fill power pack reservoir with MIL-H-5606 hydraulic fluid by inserting a funnel or filler hose in dipstick opening on top of power pack body.

- d. Bleed system by cycling landing gear through several cycles. Refill power pack reservoir with MIL-H-5606 hydraulic fluid and remove aircraft from jacks.

2-29. HYDRAULIC FLUID SAMPLING AND CONTAMINATION CHECK. At the first 50 and first 100 hour inspection and thereafter at each 500 hour inspection or one year, whichever should occur first, a sample of fluid should be taken and examined for sediment and discoloration. This may be done as follows:

MODEL P210 SERIES SERVICE MANUAL

a. Place aircraft master switch in OFF position and replace aircraft on jacks as shown in figure 2-2. Bleed pressure from system by moving landing gear selector valve to gear UP position.

CAUTION

Do not turn master switch ON while hydraulic system is open to atmosphere. The pump will automatically start, causing hydraulic fluid to spray from any open line.

b. Remove cap from elbow on right side of power pack (behind access cover) and place a nonmetal container below opening.

c. Place landing gear selector valve in DOWN position and operate emergency hand pump to pump fluid into container.

d. If the drain fluid is clear and not appreciably darker in color than new fluid, continue to use the present fluid.

e. If the fluid color is doubtful, place a fluid sample in a nonmetallic container and insert a strip of polished copper in the fluid.

f. Keep copper in the fluid for six hours at a temperature of 70°F or more. A slight darkening of the copper is permissible, but there should be no pitting or etching is evident, drain fluid from power pack reservoir. Fill power pack with MIL-H-5606 hydraulic fluid and bleed air from system.

2-30. OXYGEN SYSTEM. Refer to Section 15.

2-31. FACE MASKS. Refer to Section 15.

2-32. CLEANING.

2-33. GENERAL DESCRIPTION. Keeping the aircraft clean is important. Besides maintaining the trim appearance of the aircraft, cleaning lessens the possibility of corrosion and makes inspection and maintenance easier.

2-34. UPHOLSTERY AND INTERIOR. Cleaning prolongs the life of upholstery fabrics and interior trim. To clean the interior, proceed as follows;

a. Empty all the ash trays.

b. Brush out or vacuum clean the upholstery and carpeting to remove dirt.

c. Wipe leather and plastic surfaces with a damp cloth.

d. Soiled upholstery fabrics and carpet may be cleaned with a foam-type detergent, used according to the manufacturer's instructions.

e. Oily spots and stains may be cleaned with household spot removers, used sparingly. Before using any solvent, read the instructions on the container and test it on an obscure place in the fabric to be cleaned. Never saturate the fabric with a volatile solvent; it may damage the packing and backing material.

f. Scrape off sticky materials with a dull knife, then spot clean the area.

NOTE

Repair kits are available for the repair of cracks in ABS, PBC, PVCP, graphite and fiberglass material. (Cessna Supply Division, P.O. Box 949, Wichita, KS 67201, 316/685-9111, Telex 417-489.)

2-35. PLASTIC TRIM. The instrument panel, plastic trim and control knobs need only be wiped off with a damp cloth. Oil and grease on the control wheel and control knobs can be removed with a cloth moistened with Stoddard solvent.

CAUTION

Do not use gasoline, alcohol, benzene, acetone, carbon tetrachloride, fire extinguisher fluid, de-icer fluid, lacquer thinner or glass window cleaning spray. These solvents will soften and craze the plastic.

MODEL P210 SERIES SERVICE MANUAL

2-36. CLEANING WINDSHIELD AND WINDOWS.

2-36A. MATERIALS REQUIRED.

NAME	MANUFACTURER	USE
Mild soap or detergent (hand dishwashing type without abrasives).	Commercially available.	Cleaning windshields and windows.
Aliphatic Naphtha Type II conforming to Federal Specification TT-N-95.	Commercially available.	Removing deposits which cannot be removed with mild soap solution on acrylic windshields and windows.
*Polishing wax.		Waxing acrylic windshields and windows
● Turtle Wax (paste).	Turtle Wax, Inc. Chicago, IL. 60638	
● Great Reflections Paste Wax	E.I. duPont de Nemours and Co. (Inc.) Wilmington, DE 19898	
● Slip-Stream Wax (paste)	Classic Chemical Grand Prairie, TX 75050	
● Acrylic polish conforming to Federal Specification P-P-560 such as:		Cleaning and polishing acrylic windshields and windows.
Permatex plastic cleaner No. 403D	Permatex Company, Inc. Kansas City, KS 66115	
Cotton flannel or cotton terry cloth material.	Commercially available.	

● These are the only polishing waxes tested and approved for use by Cessna Aircraft Company.

CAUTION

Windshields and windows are easily damaged by improper handling and cleaning techniques.

- Place airplane inside hangar or in shaded area and allow to cool from heat of sun's direct rays.
- Using clean (preferably running) water, flood surface. Use bare hands with no jewelry to feel and dislodge any dirt or abrasive materials.
- Using a mild soap or detergent (such as dishwashing liquid) in water, wash surface. Again use only bare hands to provide rubbing force. (A clean cloth may be used to transfer soap solution to surface, but extreme care must be exercised to prevent scratching surface.)

- On acrylic windshields and windows only, if soils which cannot be removed by a mild detergent remain, Type II aliphatic naphtha applied with a soft clean cloth may be used as a cleaning solvent. Be sure to frequently refold cloth to avoid redepositing soil and/or scratching windshield with any abrasive particles.
- Rinse surface thoroughly with clean fresh water and dry with a clean cloth.

CAUTION

DO NOT use any of the following on or for cleaning windshields and windows: methanol, denatured alcohol, gasoline, benzene, xylene, MEK, acetone, carbon tetrachloride, lacquer thinners, commercial or household window cleaning sprays.

MODEL P210 SERIES SERVICE MANUAL

2-36B. WAXING.

- a. Hand polishing wax should be applied to acrylic surfaces. (The wax has an index of refraction nearly the same as transparent acrylic and tend to mask any shallow scratches on windshield surface).
- b. Acrylic surfaces may be polished using a polish meeting Federal Specification P-P-560 applied per manufacturer's instructions.

CAUTION

DO NOT use rain repellent on acrylic surfaces.

NOTE

When applying and removing wax and polish, use a clean soft cloth.

2-36C. PREVENTIVE MAINTENANCE.

NOTE

Utilization of the following techniques will help minimize windshield and window crazing.

- a. Keep all surfaces of windshields and windows clean.
- b. If desired, wax acrylic surfaces.
- c. Carefully cover all surfaces during any painting, powerplant cleaning or other procedure that calls for use of any type of solvents or chemicals. The following coatings are approved for use in protecting surfaces from solvent attack.
 1. White Spary Lab, MIL-C-8799, Type I, Class II.
 2. WPL-3 Masking Paper - St. Regis, Newton, MA.
 3. 5 X N - Poly-Spotstick - St. Regis, Newton, MA.
 4. Protex 40 - Mask Off Company, Monrovia, CA, and Southwest Paper Co., Wichita, KS.

5. Protex 10VS - Mask Off Company, Monrovia, CA, and Southwest Paper Co., Wichita, KS.

6. Scotch 344 Black Tape - 3M Company.

- d. Do not park or store airplane where it might be subjected to direct contact with or vapors from: methanol, denatured alcohol, gasoline, benzene, xylene, MEK, acetone, carbon tetrachloride, lacquer thinners, commercial or household window cleaning sprays, paint strippers, or other types of solvents.
- e. Do not use solar screens or shields installed on inside of airplane or leave sun visors up against windshield. The reflected heat from these items causes elevated temperatures which accelerate crazing and may cause formation of bubbles in the inner ply of multiple ply windshields.
- f. Do not use a power drill motor or other powered device to clean, polish, or wax surfaces.

2-36D. INTERIOR TRIM. The instrument panel, interior plastic trim, and control knobs need only be wiped with a damp cloth. Oil and grease on the control wheels and control knobs can be removed with a cloth moistened with Stoddard solvent. Volatile solvents, mentioned in the caution note of paragraph 2-36, must never be used since they soften and craze the plastic trim.

2-37. ALUMINUM SURFACES. The aluminum surfaces require a minimum of care, but should never be neglected. The aircraft may be washed with clean water to remove dirt and may be washed with non-alkaline grease solvents to remove oil and/or grease. Household-type detergent soap powders are effective cleaners, but should be used cautiously since some of them are strongly alkaline. Many good aluminum cleaners, polishes and waxes are available from commercial suppliers of aircraft products.

MODEL P210 SERIES SERVICE MANUAL

2-38. **PAINTED SURFACES.** The painted exterior surfaces of your new Cessna have a durable, long lasting finish. Approximately 10 days are required for the paint to cure completely; in most cases, the curing period will have been completed prior to delivery of the airplane. In the event that polishing or buffing is required within the curing period, it is recommended that the work be done by someone experienced in handling uncured paint. Any Cessna Dealer can accomplish this work.

Generally, the painted surfaces can be kept bright by washing with water and mild soap, followed by a rinse with water and drying with cloths or a chamois. Harsh or abrasive soaps or detergents which cause corrosion or scratches should never be used. Remove stubborn oil and grease with a cloth moistened with Stoddard solvent.

To seal any minor surface chips or scratches and protect against corrosion, the airplane should be waxed regularly with a good automotive wax applied in accordance with the manufacturer's instructions. If the airplane is operated in a seacoast or other salt water environment, it must be washed and waxed more frequently to assure adequate protection. Special care should be taken to seal around rivet heads and skin laps, which are the areas most susceptible to corrosion. A heavier coating of wax on the leading edges of the wings, and tail and on the cowl nose cap and propeller spinner will help reduce the abrasion encountered in these areas. Reapplication of wax will generally be necessary after cleaning with soap solutions or after chemical de-icing operations.

2-39. **ENGINE AND ENGINE COMPARTMENT.** An engine and accessories wash down should be accomplished during each 100-hour inspection to remove oil, grease, salt corrosion or other residue that might conceal component defects during inspection. Also, periodic cleaning can be very effective in preventive maintenance.

Precautions should be taken when working with cleaning agents such as wearing of rubber gloves, an apron or coveralls and a face shield or goggles. Use the least toxic of available cleaning agents that will satisfactorily accomplish the work. These cleaning agents include: (1) Stoddard Solvent (Specification P-D-680 type II), (2) A water alkaline detergent cleaner (MIL-C-25769J) mixed, 1 part cleaner, 2 or 3 parts water and 8 to 12 parts Stoddard solvent or (3) A solvent base emulsion cleaner (MIL-C-4361B) mixed 1 part cleaner and 3 parts Stoddard solvent.

CAUTION

Do not use gasoline or other highly flammable substances for wash down.

Perform all cleaning operations in well ventilated work areas and ensure that adequate firefighting and safety equipment is available. Do not smoke or expose a flame, within 100 feet of the cleaning area. Compressed air, used for cleaning agent, application or drying, should be regulated to the lowest practical

pressure. Use of a stiff bristle brush rather than a steel brush is recommended if cleaning agents do not remove excess grease and grime during spraying.

A recommended procedures for cleaning an engine and accessories is as follows:

CAUTION

Do not attempt to wash an engine which is still hot or running. Allow the engine to cool before cleaning.

- a. Remove engine cowling.
- b. Carefully cover the coupling area between the vacuum pump and the engine drive shaft so that no cleaning solvent can reach the coupling or seal.
- c. Cover the open end of the vacuum discharge tube.
- d. Cover the vacuum relief valve filter, if installed in the engine compartment.
- e. Use fresh water for wash down when the engine is contaminated with salt or corrosive chemicals. A cleaning agent such as described previously may then be used to remove oil and grime.

CAUTION

Care should be exercised to not direct cleaning agents or water streams at openings on the starter, magnetos, alternator, vacuum pump or turbocharger relief valve.

- f. Thoroughly rinse with clean warm water to remove all traces of cleaning agents.

CAUTION

Cleaning agents should never be left on engine components for an extended period of time. Failure to remove them may cause damage to components such as neoprene seals and silicone fire sleeves, and could cause additional corrosion.

- g. Completely dry engine and accessories using clean, dry compressed air.
- h. Remove the cover over the coupling area.
- i. Remove the cover from the vacuum discharge tube.
- j. Remove the cover from the vacuum relief valve filter, if installed.
- k. If desired, engine cowling may be washed with the same cleaning agents, then rinsed thoroughly and wiped dry. After cleaning engine, relubricate all control arms and moving parts as required.
- l. Reinstall engine cowling.

WARNING

For maximum safety, check that the magneto switches are OFF, the throttle is closed, the mixture control is in the idle cut-off position, and the airplane is secured before rotating the propeller by hand. Do not stand within the arc of the propeller blades while turning the propeller.

MODEL P210 SERIES SERVICE MANUAL

m. Before starting engine rotate the propeller by hand no less than four complete revolutions.

2-40. **PROPELLER.** The propeller should be wiped occasionally with an oily cloth to remove grass and bug stains. In salt water areas, this will assist in corrosion-proofing the propeller.

2-41. **WHEELS.** The wheels should be washed periodically and examined for corrosion, chipped paint, and cracks or dents in the wheel halves or in the flanges or hubs. If defects are found remove and repair in accordance with Section 5. Discard cracked wheel halves, flanges or hubs and install new parts.

2-42. LUBRICATION.

WARNING

The U.S. Environmental Protection Agency advises that mechanics and other workers who handle engine oil are advised to minimize skin contact with used oil and promptly remove used oil from the skin. In a laboratory study, mice developed skin cancer after skin was exposed to used engine oil twice a week without being washed off, for most of their life span. Substances found to cause cancer in laboratory animals may also cause cancer in humans.

2-43. **GENERAL DESCRIPTION.** Lubrication requirements are outlined in figure 2-5. Before adding lubricant to a fitting, wipe the fitting free of dirt. Lubricate until grease appears around part being lubricated and wipe excess grease from parts. The following paragraphs supplement figure 2-5 by adding details not shown in the figure.

2-44. **NOSE GEAR TORQUE LINKS.** Lubricate torque links every 50 hours. When operating in dusty conditions, more frequent lubrication is recommended.

2-45. **TACHOMETER DRIVE SHAFT.** Refer to Section 16 for lubrication instructions.

2-46. **WHEEL BEARING LUBRICATION.** Clean and repack wheel bearings at the first 100-hour inspection and at each 500-hour inspection thereafter. If more than the usual number of take-off and landings are made, extensive taxiing is required or the aircraft is operated in dusty areas or under seacoast conditions, clean and lubricate wheel bearings at each 100-hour inspection.

2-47. **WING FLAP ACTUATOR.** Clean and lubricate wing flap actuator jack screw each 100 hours as follows:

- a. Expose jack screw by operating flaps to full-down position.
- b. Clean jack screw threads with solvent rag and dry with compressed air.

NOTE

It is not necessary to remove actuator from aircraft to clean or lubricate threads.

- c. With oil can, apply light coat of No. 10 weight, non-detergent oil to threads of jack screw.

2-48. **ROD END BEARINGS.** Periodic inspection and lubrication is required to prevent corrosion of the bearing in the rod end. At each 100-hour inspection, disconnect the control rods at the aileron and inspect each rod end for corrosion. If no corrosion is found, wipe the surface of the rod end balls with general purpose oil and rotate ball freely to distribute the oil over its entire surface and connect the control rods to the aileron. If corrosion is detected during inspection, install new rod ends.

MODEL P210 SERIES SERVICE MANUAL




Figure 2-4. Servicing (Sheet 1 of 4)

MODEL P210 SERIES SERVICE MANUAL

HYDRAULIC FLUID:
SPEC. NO. MIL-H-5606

SPECIFIED AVIATION GRADE FUELS:

WARNING


ONLY AVIATION GRADE FUELS ARE APPROVED FOR USE.

ENGINE MODEL	APPROVED FUEL GRADES	NOTE
Continental TSIO-520-CE	100LL (blue)	1
	100 (green) (formerly 100/130)	1

NOTE

- Compliance with Continental Aircraft Engine Service Bulletin M82-8, and all supplements or revisions thereto, must be accomplished.

SPECIFIED AVIATION GRADE OIL:



Aviation grade ashless dispersant oil, conforming to Continental Motors Specification M8S-24, and all revisions or supplements thereto, must be used except as noted in paragraph 2-20, herein. Refer to Continental Aircraft Engine Service Bulletin M82-8, and any superseding bulletins, revisions or supplements thereto, for further recommendations.

Oil capacities for the aircraft are given in the following chart. To minimize loss of oil through the breather, fill to specified oil level on dipstick for normal operation (flight of less than three hours duration). For extended flight, fill to FULL mark on dipstick. Do not operate with less than MINIMUM FOR FLIGHT quantities listed. If an external oil filter is installed, one additional quart of oil is required when filter is changed.

CAPACITY (TOTAL)	CAPACITY (TOTAL WITH FILTER)	NORMAL OPERATION	MINIMUM FOR FLIGHT
10	11	8	7

Figure 2-4. Servicing (Sheet 2 of 4)

MODEL P210 SERIES SERVICE MANUAL



DAILY

- 1 **FUEL BAYS:**
Service after each flight. Keep full to retard condensation. Refer to paragraph 2-17 for details.
- 6 **FUEL BAY SUMP DRAINS:**
Drain off any water and sediment before first flight of the day.
- 19 **FUEL STRAINER:**
Drain off any water and sediment before first flight of the day.
- 15 **OIL DIPSTICK:**
Check on preflight. Add oil as necessary. Refer to paragraph 2-20 for details. Check that filler cap is tight and oil filler is secure.
- 8 **PITOT AND STATIC PORTS:**
Check for obstructions before first flight of the day.
- 7 **OXYGEN CYLINDERS:**
Check for anticipated requirements before each flight. Refer to Section 15 for details.
- 17 **NOSE GEAR SHOCK STRUT:**
Check on preflight. Check inner barrel showing below outer barrel to be 1.00-2.00 (approximately 1.20) inches after bouncing. Deviation from these dimensions is cause to check and service strut per paragraph 2-25.



25 HOURS

- 16 **ENGINE OIL SYSTEM: FIRST 25 HOURS**
Drain engine oil and change external oil filter (if equipped). Refill engine with ashless dispersant oil.
- 21 **HYDRAULIC POWER PACK**
Check fluid level each 25 hours and after a gear extension which utilizes the emergency hand pump.



50 HOURS

- 21 **HYDRAULIC POWER PACK FLUID SAMPLE AND CONTAMINATION CHECK:**
Refer to Paragraph 2-29 for details.



100 HOURS

- 2 **FUEL AIR CONTROL UNIT SCREEN:**
Remove and clean screen.
- 4 **INDUCTION AIR FILTER:**
Clean filter per paragraph 2-21. Replace as required.
- 5 **VACUUM RELIEF VALVE FILTER:**
Replace each 100 hours.

Figure 2-4. Servicing (Sheet 3 of 4)

MODEL P210 SERIES SERVICE MANUAL

 100 HOURS

- 11 **VACUUM SYSTEM CENTRAL AIR FILTER:**
Inspect filter element for damage. Refer to paragraph 2-22.
- 6 **FUEL BAY SUMP DRAINS:**
Drain off any water or sediment.
- 9 **FUEL RESERVOIR DRAIN:**
Open drain valve(s) and drain off water and sediment.
- 12 **BRAKE MASTER CYLINDERS:**
Check fluid level and fill as required with hydraulic fluid.
- 13 **BATTERY:**
Check electrolyte level and clean battery compartment each 100 hours or each 90 days.
- 18 **SHIMMY DAMPER :**
Check fluid level and refill as required in accordance with paragraph 2-26.
- 10 **TIRES:**
Maintain correct tire inflation as listed in Section 1. Refer to paragraph 2-24.
- 17 **NOSE GEAR SHOCK STRUT:**
Keep strut filled and inflated to correct pressure. Refer to paragraph 2-25.
- 16 **ENGINE OIL SYSTEM:**
Change oil and long filter (approximately 5.8 inches long) each 100 hours or every six months, whichever occurs first.
- 19 **FUEL STRAINER:**
Disassemble and clean strainer bowl and screen.
- 21 **HYDRAULIC POWER PACK FLUID SAMPLE AND CONTAMINATION CHECK:**
Refer to Paragraph 2-29 for details.

 200 HOURS

- 14 **GROUND SERVICE RECEPTACLE:**
Connect to 24-volt, D.C. negative-ground power unit for cold weather starting and lengthy ground maintenance of the aircraft electrical equipment with the exception of electronic equipment. Master switch should be turned on before connecting a generator-type or battery-type power source. Refer to Section 17.

 500 HOURS

- 11 **VACUUM SYSTEM CENTRAL AIR FILTER:**
Replace every 500 hours or annually. Refer to paragraph 2-22.
- 4 **INDUCTION AIR FILTER:**
Replace every 500 hours or annually. Refer to paragraph 2-21.
- 21 **HYDRAULIC POWER PACK FLUID SAMPLE AND CONTAMINATION CHECK:**
Check sample of hydraulic fluid for sediment and discoloration.
Refer to Paragraph 2-29 for details.

Figure 2-4. Servicing (Sheet 4 of 4)

MODEL P210 SERIES SERVICE MANUAL

FREQUENCY (HOURS)

50

100

200

500

1000

METHOD OF APPLICATION

HAND

GREASE
GUN

OIL
CAN

SYRINGE
(FOR POWDERED
GRAPHITE)

WHERE NO INTERVAL IS SPECIFIED,
LUBRICATE AS REQUIRED AND
WHEN ASSEMBLED OR INSTALLED.

NOTE

The military specifications listed below are not mandatory, but are intended as guides in choosing satisfactory materials. Products of most reputable manufacturers meet or exceed these specifications.

LUBRICANTS

PG	SS-G-659	POWDERED GRAPHITE
GR	MIL-G-81322A	GENERAL PURPOSE GREASE
GM	MIL-G-23827A	AIRCRAFT AND INSTRUMENT GREASE
GL	MIL-G-21164C	HIGH AND LOW TEMPERATURE GREASE
OG	MIL-L-7870A	GENERAL PURPOSE OIL
PL	VV-P-236	PETROLATUM
GT		NO. 10WT NON-DETERGENT OIL
OL	VV-L-800A	LIGHT OIL




Figure 2-5. Lubrication (Sheet 1 of 4)

MODEL P210 SERIES SERVICE MANUAL




Figure 2-5. Lubrication (Sheet 2 of 4)

MODEL P210 SERIES SERVICE MANUAL







Figure 2-5. Lubrication (Sheet 3 of 4)

MODEL P210 SERIES SERVICE MANUAL

SPRAY BOTH SIDES OF SHADED AREAS WITH ELECTROFILM LUBRI-BOND "A" WHICH IS AVAILABLE IN AEROSOL SPRAY CANS, OR AN EQUIVALENT LUBRICANT. TORQUE ATTACHING BOLT TO 10-20 LB-IN.



THE LOCKING HOOKS HAVE BEEN DRY FILM LUBRICATED AT THE FACTORY AND SHOULD LAST THE LIFE OF THE PARTS. HOWEVER, THEY MAY BE LUBRICATED WITH THE FOLLOWING PRODUCTS:

- *1. LUBRI-BOND A.
- *2. LUBRI-BOND 220.
- 3. PERMASILK.

AFTER APPLICATION, ALLOW PARTS TO AIR DRY FOR SIX HOURS, OR DRY FOR ONE HOUR AT 120°F.

* May be purchased from:
Electra-Film Inc.
7116 Laurel Canyon Blvd.
Hollywood Ca. 91605.

● May be purchased from:
Everlube Corp.
P. O. Box 2200
Hi-Way 52 N. W.
West Lafayette, Ind 47906

NOTES

Sealed bearings require no lubrication.

McCauley propellers are lubricated at overhaul and require no other lubrication.

Do not lubricate roller chains or cables except under seacoast conditions. Wipe with a clean, dry cloth.

Lubricate unsealed pulley bearings, Oilite bearings, pivot and hinge points, and any other friction point obviously needing lubrication, with general purpose oil every 1000 hours or oftener, if required.

Paraffin wax rubbed on seat rails will ease sliding the seats fore and aft.

Lubricate door latching mechanism with MIL-S-8660 silicone compound or equivalent lubricant, applied sparingly to friction points, every 1000 hours or oftener if binding occurs. No lubrication is recommended for the rotary clutch.

Apply DOOR - EZE - lubricant to latch bolt.

Figure 2-5. Lubrication (Sheet 4 of 4)

MODEL P210 SERIES SERVICE MANUAL

2-49. GENERAL INSPECTION (MODEL P210 AIRPLANES).

NOTE

Cessna Aircraft Company recommends PROGRESSIVE CARE for airplanes flown 200 hours or more per year, and 100-HOUR INSPECTION for airplanes flown less than 200 hours per year.

A. Inspection Requirements.

(1) Two basic types of inspections are available as defined below:

- (a) As required by Federal Aviation Regulation Part 91.409(a), all civil airplanes of U.S. registry must undergo an annual inspection each 12 calendar months. In addition an annual 100 hour inspection, airplanes operated commercially (for hire) must also have a complete inspection each 100 hours of operation as required by Federal Aviation Regulation Part 91.409(b).
- (b) In lieu of the above requirements, an airplane may be inspected in accordance with a progressive inspection program in accordance with Federal Aviation Regulation Part 91.409(d), which allows the work load to be divided into smaller operations that can be accomplished in a shorter time period. The CESSNA PROGRESSIVE CARE PROGRAM has been developed to satisfy the requirements of Part 91.409 (d).

B. Inspection Program Selection.

(1) As a guide for selecting the inspection program that best suits the operation of the airplane, the following is provided:

- (a) If the airplane is flown less than 200 hours annually, the following conditions apply:
 1. If flown for hire.
 - a. An airplane operating in this category must be inspected each 100 hours of operation (100-HOUR) and each 12 calendar months of operation (ANNUAL).
 2. If not flown for hire.
 - a. An airplane operating in this category must be inspected each 12 calendar months of operation (ANNUAL). It is recommended that between annual inspections, all items be inspected at the intervals specified in the Inspection Time Limits Charts and Component Time Limits Charts.
- (b) If the airplane is flown more than 200 hours annually, the following condition applies:
 1. Whether flown for hire or not, it is recommended that airplanes operating in this category be placed on the CESSNA PROGRESSIVE CARE PROGRAM. However, if not placed on the CESSNA PROGRESSIVE CARE PROGRAM, the inspection requirements for airplanes in this category are the same as those defined under Paragraph B. (1)(a)1.a. or 2.a. CESSNA PROGRESSIVE CARE PROGRAM may be utilized as a total concept program which ensures that the inspection intervals in the inspection charts are not exceeded. Manuals and forms which are required for conducting the CESSNA PROGRESSIVE CARE PROGRAM inspections are available from the Cessna Supply Division.

MODEL P210 SERIES SERVICE MANUAL

C. Inspection Charts.

NOTE

Cessna has prepared these Inspection Charts to assist the owner or operator in meeting the foregoing responsibilities and to meet the intent of Federal Aviation Regulation Part 91.409(d). The Inspection Charts are not intended to be all-inclusive, for no such charts can replace the good judgment of a certified airframe and powerplant mechanic in performance of his duties. As the one primarily responsible for this airworthiness of the airplane, the owner or operator should select only qualified personnel to maintain the airplane.

- (1) The following Inspection Charts (Inspection Time Limits, Component Time Limits, Progressive Care Inspection, and Expanded Inspection) show the recommended intervals at which items are to be inspected based on normal usage under average environmental conditions. Airplanes operated in extremely humid tropics, or in exceptionally cold, damp climates, etc., may need more frequent inspections for wear, corrosion, and lubrication. Under these adverse conditions, perform periodic inspections in compliance with this chart at more frequent intervals until the operator can set his own inspection periods based on field experience. The operator's inspection intervals shall not deviate from the inspection time limits shown in this manual except as provided below:
 - (a) Each inspection interval can be exceeded by 10 hours or can be performed early at any time prior to the regular interval as provided below:
 1. In the event of late compliance of any operation scheduled, the next operation in sequence retains a due point from the time the late operation was originally scheduled.
 2. In the event of early compliance of any operation scheduled, that occurs 10 hours or less ahead of schedule, the next phase due point may remain where originally set.
 3. In the event of early compliance of any operation scheduled, that occurs more than 10 hours ahead of schedule, the next phase due point must be rescheduled to establish a new due point from the time of early accomplishment.
- (2) As shown in the charts, there are items to be checked at 50 hours, 100 hours, 200 hours, or at Special or Yearly inspection. Special or Yearly inspection items require servicing or inspection at intervals other than 50, 100, or 200 hours. If two inspection time requirements are listed for one inspection item, one hourly and the yearly, both apply and whichever requirement occurs first determines the time limit.
 - (a) When conducting a 50-hour inspection, check all items listed under EACH 50 HOURS. A 100-hour inspection includes all items listed under EACH 50 HOURS and EACH 100 HOURS. The 200-hour inspection includes all items listed under EACH 50 HOURS, EACH 100 HOURS, and EACH 200 HOURS. All of the items listed would be inspected, serviced, or otherwise performed as necessary to ensure compliance with the inspection requirements.
 - (b) A COMPLETE AIRPLANE INSPECTION includes all 50-, 100-, and 200-hour items plus those Special and Yearly Inspection Items which are due at the specified time.
 - (c) Component Time Limits Charts should be checked at each inspection interval to ensure proper overhaul and replacement requirements are accomplished at the specified times.

MODEL P210 SERIES SERVICE MANUAL

D. Inspection Guidelines.

- (1) The Inspection Charts are to be used as a recommended inspection outline. Detailed information of systems and components in the airplane will be found in various chapters of this Maintenance Manual and the pertinent vendor publications. It is recommended that reference be made to the applicable portion of this manual for service instructions, installation instructions, and to the vendor's data or publications specifications for torque values, clearances, settings, tolerances, and other requirements.
- (2) For the purpose of this inspection, the term on condition is defined as follows: The necessary inspections and/or checks to determine that a malfunction or failure will not occur prior to the next scheduled inspection.
- (3) **MOVABLE PARTS:** Inspect for lubrication, servicing, security of attachment, binding, excessive wear, safetizing, proper operation, proper adjustment, correct travel, cracked fittings, security of hinges, defective bearings, cleanliness, corrosion, deformation, sealing, and tension.
- (4) **FLUID LINES AND HOSES:** Inspect for leaks, cracks, bulging, collapsed, twisted, dents, kinks, chafing, proper radius, security, discoloration, bleaching, deterioration, and proper routing; rubber hoses for stiffness and metal lines for corrosion.
- (5) **METAL PARTS:** Inspect for security of attachment, cracks, metal distortion, broken spotwelds, condition of paint (especially chips at seams and around fasteners for onset of corrosion) and any other apparent damage.
- (6) **WIRING:** Inspect for security, chafing, burning, arcing, defective insulation, loose or broken terminals, heat deterioration, and corroded terminals.
- (7) **STRUCTURAL FASTENERS:** Inspect for correct torque in accordance with applicable torque values. Refer to Bolt Torque Data during installation or when visual inspection indicates the need for a torque check.

NOTE

Torque values listed are not to be used for checking tightness of installed parts during service.

- (8) **FILTERS, SCREENS, AND FLUIDS:** Inspect for cleanliness and the need for replacement at specified intervals.
- (9) **System check (operation or function) requiring electrical power must be performed using 28.5 ± 0.25 volts bus voltage. This will ensure all components are operating at their designed requirements.**
 - (a) **Airplane file.**
 1. **Miscellaneous data, information, and licenses are a part of the airplane file. Check that the following documents are up-to-date and in accordance with current Federal Aviation Regulations. Most of the items listed are required by the Federal Aviation Regulations. Since the regulations of other nations may require other documents and data, owners of exported airplanes should check with their own aviation officials to determine their individual requirements.**
 - a. **To be displayed in the airplane at all times:**
 - 1) **Standard Airworthiness Certificate (FAA Form 8100-2).**
 - 2) **Aircraft Registration Certificate (FAA Form 8050-3).**
 - 3) **Aircraft Radio Station License (Federal Communication Commission Form 556 if transmitter is installed).**
 - 4) **Radio Telephone Station License (Federal Communication Commission Form 409 if Flitephone Radio Telephone is installed).**
 - b. **To be carried in the airplane at all times:**
 - 1) **Weight and Balance Data Sheets and associated papers (all copies of the Repair and Alteration Form, FAA Form 337, are applicable).**
 - 2) **Equipment List.**
 - 3) **Pilot's Operating Handbook and FAA-Approved Airplane Flight Manual.**
 - c. **To be made available upon request:**
 - 1) **Airframe, Engine, Propeller, and Avionics Maintenance Records.**

MODEL P210 SERIES SERVICE MANUAL

2-50. PRE-INSPECTION CHECKS. (MODEL P210 AIRPLANES.)

A. Pre-inspection Operational Checks.

- (1) Before beginning the step-by-step inspection, start and run up the engine and upon completion, shut down the engine in accordance with instructions in the Pilot's Operating Handbook and FAA-Approved Airplane Flight Manual. During the run-up, observe the following, making note of any discrepancies or abnormalities:
 - (a) Engine temperatures and pressures.
 - (b) Static RPM. (Also refer to Section 12 of this manual.)
 - (c) Magneto drop. (Also refer to Section 12 of this manual.)
 - (d) Engine response to changes in power.
 - (e) Any unusual engine noises.
 - (f) Fuel selector and/or shutoff valve; operate engine on each tank (or cell) position and OFF position long enough to ensure shutoff and/or selector valve functions properly.
 - (g) Idling speed and mixture; proper idle cut-off.
 - (h) Alternator and ammeter.
 - (i) Suction gage.
 - (j) Fuel flow indicator.
- (2) After the inspection has been completed, an engine run-up should again be performed to determine that any discrepancies or abnormalities have been corrected.
- (3) Some of the items in the Inspection Time Limits paragraph are optional, therefore not applicable to all airplanes.

Mechanic's Pre-inspection Discrepancies or Abnormalities to be Checked:

Mechanic's Post-inspection Corrective Action Taken:

MODEL P210 SERIES SERVICE MANUAL

2-51 INSPECTION TIME LIMITS. (MODEL P210 AIRPLANES.)

EACH 50 HOURS	EACH 100 HOURS	EACH 200 HOURS	SPECIAL INSPECTIONS	
HOURS	HOURS	HOURS	HOURS	YEARS

A	Placards (Refer to Pilot's Operating Handbook).					
A	1 Placards and Decals - Inspect presence, legibility, and security. Consult Pilot's Operating Handbook and FAA-Approved Airplane Flight Manual for required placards.			•		
B	Fuselage (Section 3).					
B	1 Fuselage Surface - Inspect for skin damage, loose rivets, condition of paint, and check pitot-static ports and drain holes for obstruction. Inspect covers and fairings for security.		•		A	
B	2 Internal Fuselage Structure - Inspect bulkheads, doorposts, stringers, doublers, and skins for corrosion, cracks, buckles, and loose rivets, bolts and nuts.			•	B	
B	3 Control Wheel Lock - Check general condition and operation.			•		
B	4 Fuselage Mounted Equipment - Check for general condition and security of attachment.			•		
B	5 Antennas and Cables - Inspect for security of attachment, connection, and condition.			•		
B	6 Emergency Locator Transmitter - Inspect for security of attachment and check operation by verifying transmitter output. Check cumulative time and useful life of batteries in accordance with FAR Part 91.52. Refer to Section 17 - Operational Test of Emergency Locator Transmitter.		•			
B	7 Instrument Panel Shock Mounts, Ground Straps, and Covers - Inspect for deterioration, cracks, and security of attachment.			•		
B	8 Pilot's and Copilot's Inertia Reels - Inspect for security of installation, proper operation, and evidence of damage.		•			
B	9 Seats, Seat Belts, and Shoulder Harnesses - Check general condition and security. Check operation of seat stops and adjustment mechanism. Inspect belts for condition and security of fasteners.		•			
B	10 Windows, Windshield, Doors, and Seals - Inspect general condition. Check latches, hinges, and seals for condition, operation, and security of attachment.		•			
B	11 Upholstery, Headliner, Trim, and Carpeting - Check condition and clean as required.				EACH 400	EACH 1
B	12 Flight Controls - Check freedom of movement and proper operation through full travel with and without flaps extended. Check electric trim controls for operation (as applicable).		•			
B	13 Aileron, Elevator, and Rudder Stops - Check for damage and security.		•			
B	14 Portable Hand Fire Extinguisher - Inspect for proper operating pressure, condition, security of installation, and servicing date.		•			
B	15 Seat Tracks and Stops - Inspect seat tracks for condition and security of installation. Check seat track stops for damage and correct location. Ensure inspection of seat rails for cracks EACH 50 HOURS. Refer to Section 3.	•				

MODEL P210 SERIES SERVICE MANUAL

2-51 INSPECTION TIME LIMITS. (MODEL P210 AIRPLANES.)

		EACH 50 HOURS	EACH 100 HOURS	EACH 200 HOURS	SPECIAL INSPECTIONS	
					HOURS	YEARS
B	16 Control Column - Inspect pulleys, cables, sprockets, bearings, chains, bungees, and turnbuckles for condition and security.			•		
B	17 Fuel Line and Selector Valve Drain(s) - Remove plug and drain.		•			
B	46 Pressurization Outflow Valves and Safety Valves - Inspect for condition and security.			•		
B	47 Pressurization Electrical Components - Inspect wiring and components for condition and security.			•		
B	48 Pressurization Plumbing Components - Inspect for condition, security, and loose connections.			•		
B	49 Pressurization Bleed Air Dump Valves - Inspect for condition, security and smooth operation.		•			
B	50 Pressurization Controls and Units - Inspect for condition and security. Clean and perform operational check.			•		
C	Wings and Empennage (Section 4).					
C	1 Wing Surfaces and Tips - Inspect for skin damage, loose rivets, and condition of paint.		•			
C	2 Wing Spar Fittings - Check for evidence of wear. Check attach bolts for indications of looseness and retorque as required.			•		
C	3 Wing Structure - Inspect spars, ribs, skins, and stringers for cracks, wrinkles, loose rivets, corrosion, or other damage.			•		
C	4 Metal Lines, Hoses, Clamps, and Fittings - Check for leaks, condition, and security. Check for proper routing and support.			•		
C	5 Wing Access Plates - Check for damage and security of installation.			•		
C	6 Vertical and Horizontal Stabilizers, Tips and Tailcone - Inspect externally for skin damage and condition of paint.		•			
C	7 Vertical and Horizontal Stabilizers and Tailcone structure - Inspect bulkheads, spars, ribs, and skins for cracks, wrinkles, loose rivets, corrosion, or other damage. Inspect vertical and horizontal stabilizer attach bolts for looseness. Retorque as necessary. Check security of inspection covers, fairings, and tips.		•			
D	Landing Gear and Brakes (Section 5).					
D	1 Brakes, Master Cylinders, and Parking Brake - Check master cylinders and parking brake mechanism for condition and security. Check fluid level and test operation of toe and parking brake.		•			
D	2 Main Gear Tubular Struts - Inspect for cracks, dents, corrosion, condition of paint or other damage. Check axles for condition and security.		•			
D	3 Brake Lines, Wheel Cylinders, Hoses, Clamps, and Fittings - Check for leaks, condition, and security and hoses for bulges and deterioration. Check brake lines and hoses for proper routing and support. (See Cessna SEB92-8)				EACH 400	EACH 1

MODEL P210 SERIES SERVICE MANUAL

2-51 INSPECTION TIME LIMITS. (MODEL P210 AIRPLANES.)

		EACH 50 HOURS	EACH 100 HOURS	EACH 200 HOURS	SPECIAL INSPECTIONS	
					HOURS	YEARS
D	4 Wheels, Brake Discs, and Linings - Inspect for wear, cracks, warps, dents, or other damage. Check wheel through-bolts and nuts for looseness.		•			
D	5 Tires - Check tread wear and general condition. Check for proper inflation.		•			
D	6 Main Landing Gear Strut-to-Pivot Attachment - Check for damage, cracks, loose rivets, bolts and nuts and security of attachment.			•		
D	7 Nose Gear Steering Mechanism - Check for wear, security, and proper rigging.			•		
D	8 Nose Gear - Inspect torque links, steering rods, and boots for condition and security of attachment. Check strut for evidence of leakage and proper extension. Check strut barrel for corrosion, pitting, and cleanliness. Check shimmy damper and/or bungees for operation, leakage, and attach points for wear and security.		•			
D	9 Nose Gear Fork - Inspect for cracks, general condition, and security of attachment.			•		
D	10 Wheel Bearings - Clean, inspect and lube.				C	
D	11 Nose Gear Attachment Structure - Inspect for cracks, corrosion, or other damage and security of attachment.		•			
D	12 Landing Gear - Perform five fault-free cycles.		•			
	NOTE: The airplane must be placed on jacks before inspection of landing gear retraction system. An external power source of at least 60 amperes should be used in place of the airplane battery while operating the system.					
D	13 Main Landing Gear - Check downlock engagement.		•			
D	14 Landing Gear System - Check adjustment of main and nose gear up and down switches, and operation of gear position indicator.		•			
D	15 Throttle Operated Gear Warning System - Check condition of wiring and security of components. Perform rigging check (refer to Figure 5-8).			•		
D	16 Nose Gear Doors and Linkage - Check for .25 inch minimum clearance throughout up and down cycles, and proper fit when closed. Check linkage for wear, damaged bearings, distortion, and superficial damage.		•			
D	17 Hydraulic System - Check all components for leaks and external damage to components or mounting structure.		•			
D	18 Emergency Hand Pump - Check operation, check lines and components for damage and leaks.			•		
D	19 Powerpack - Clean self relieving check valve filter.		•			
D	20 Powerpack - Hydraulic fluid contamination check.				D	
D	21 Powerpack - Check condition and wear of brushes in servomotor.				E	
D	22 Powerpack - Perform hydraulic pressure checks of primary relief valve, thermal relief valve, and pressure switch. Can be operationally pressure checked in the aircraft without power pack removal from aircraft (refer to paragraph 5-6A). To determine if relief valve disassembly or adjustment is necessary, relief valves can be bench checked after removal from power pack (refer to paragraph 5-12A).		•			

MODEL P210 SERIES SERVICE MANUAL

2-51 INSPECTION TIME LIMITS. (MODEL P210 AIRPLANES.)		EACH 50 HOURS	EACH 100 HOURS	EACH 200 HOURS	SPECIAL INSPECTIONS	
					HOURS	YEARS
D	23 Landing Gear System - Overhaul main gear downlock actuators, main and nose gear actuators, landing gear selector valve, emergency hand pump, and pressure switch. Replace all rubber goods.					F
D	24 Brake System - Overhaul brake discs, parking brake system, wheel cylinders, and master cylinders. Replace brake pads and all rubber goods.					F
E	Aileron Control System (Section 6).					
E	1 Ailerons, Hinges - Check condition, security and operation.		•			
E	2 Aileron Structure, Control Rods, Hinges, Balance Weights, Bellcranks, Linkage, Bolts, Pulleys, and Pulley Brackets - Check condition, operation, and security of attachment.		•			
E	3 Ailerons and Cables - Check operation and security of stops. Check cables for tension, routing, fraying, corrosion, and turnbuckle safety. Check travel if cable tension requires adjustment or if stops are damaged. Check fairleads and rub strips for condition.			•		
E	4 Autopilot Rigging - Check per Avionics Installation Manual.				G	EACH 1
E	5 Aileron Controls - Check freedom of movement and proper operation through full travel with and without flaps extended.		•			
F	Wing Flap Control System (Section 7).					
F	1 Flaps - Check tracks, rollers, and control rods for security of attachment. Check rod end bearings for corrosion and lubricate. Check operation.		•			
F	2 Flap Actuator Threads - Clean and lubricate. Refer to paragraph 2-47 for detailed instructions.		•			
F	3 Flap Structure, Linkage, Bellcranks, Pulleys, and Pulley Brackets - Check for condition, operation and security.			•		
F	4 Wing Flap Control - Check operation through full travel and observe Flap Position indicator for proper indication.			•		
F	5 Flaps and Cables - Check cables for proper tension, routing, fraying, corrosion, and turnbuckle safety. Check travel if cable tension requires adjustment.			•		
F	6 Flap Motor, Actuator, and Limit Switches (electric flaps) - Check wiring and terminals for condition and security. Check actuator for condition and security.			•		
G	Elevator Control System (Section 8).					
G	1 Elevator Control - Check freedom of movement and proper operation through full travel with and without flaps extended.		•			
G	2 Elevator, Hinges, and Cable Attachment - Check condition, security, and operation.		•			
G	3 Elevator Control System - Inspect pulleys, cables, sprockets, bearings, chains, and turnbuckles for condition, security, and operation.			•		

MODEL P210 SERIES SERVICE MANUAL

2-51 INSPECTION TIME LIMITS. (MODEL P210 AIRPLANES.)		EACH	EACH	EACH	SPECIAL	
		50	100	200	HOURS	YEARS
		HOURS	HOURS	HOURS	HOURS	YEARS
G	4 Elevator Arm - Check bolts, linkage, and push-pull tube for condition, operation, and security. Check travels if cables require tension adjustment or if stops are damaged.		•			
H	Elevator Trim Tab Control System (Section 9).					
H	1 Elevator Trim Tab and Hinges - Check condition, security, and operation.		•			
H	2 Elevator Trim System - Check cables, push-pull rods, bellcranks, pulleys, turnbuckles, fairleads, rub strips, etc. for proper routing, condition, and security.		•			
H	3 Trim Controls and Indicators - Check freedom of movement and proper operation through full travel. Check pulleys, cables, sprockets, bearings, chains, bungees, and turnbuckles for condition and security. Check electric trim controls for operation as applicable.			•		
H	4 Elevator Trim Tab Stop Blocks - Inspect for damage and security.			•		
H	5 Elevator Trim Tab Actuator - Clean, lubricate, and check free-play.				H	
H	6 Elevator Trim Tab Actuator - Free-Play limits inspection. (Refer to Section 9-14).			•		
I	Rudder Control System. (Section 10).					
I	1 Rudder - Inspect the rudder skins for cracks and loose rivets, rudder hinges for condition, cracks and security; hinge bolts, hinge bearings, hinge attach fittings, and bonding jumper for evidence of damage and wear, failed fasteners, and security. Inspect the rudder hinge bolts for proper safeying of nuts with cotter pins. Inspect balance weight for looseness and the supporting structure for damage.		•			
I	2 Rudder Pedals and Linkage - Check for general condition, proper rigging, and operation. Check for security of attachment.			•		
I	3 Rudder Tips, Hinges, Stop Bolts, Clips, and Cable Attachments - Check condition, security, and operation.		•			
I	4 Rudder - Check internal surfaces for corrosion, condition of fasteners, and balance weight attachment.			•		
J	Engine (Section 12).					
J	1 Cowling and Cowl Flaps - Inspect for cracks, dents, and other damage, security of cowl fasteners, and cowl mounted landing lights for attachment. Check cowl flaps for condition, security, and operation.	•				
J	2 Engine - Inspect for evidence of oil and fuel leaks. Wash engine and check for security of accessories.	•				
J	3 Cowl Flap Controls - Check freedom of movement through full travel.	•				
J	4 Engine Propeller Controls, and Linkage - Check general condition, freedom of movement through full range. Check for proper travel, security of attachment, and for evidence of wear. Check friction locks for proper operation.	•			G	I

MODEL P210 SERIES SERVICE MANUAL

2-51 INSPECTION TIME LIMITS. (MODEL P210 AIRPLANES.)		EACH	EACH	EACH	SPECIAL	
		50	100	200	INSPECTIONS	YEARS
		HOURS	HOURS	HOURS	HOURS	YEARS
J	5 Ignition Switch and Electrical Harness - Inspect for damage, condition, and security.		•			
J	6 Firewall Structure - Inspect for wrinkles, damage, cracks, sheared rivets, etc. Check cowl shock mounts for condition and security.			•		
J	7 Engine Shock Mounts, Engine Mount Structure, and Ground Straps - Check condition, security, and alignment.			•		
J	8 Induction System - Check security of clamps, tubes, and ducting. Inspect for evidence of leakage.	•				
J	9 Induction Airbox, Valves, Doors, and Controls - Remove air filter and inspect hinges, doors, seals, and attaching parts for wear and security. Check operation. Clean and inspect air filter and re-oil if flock-coated.		•			
J	10 Induction Air Filter - Remove and clean. Inspect for damage, and service per paragraph 2-21.		•		J	
J	11 Alternate Induction Air System - Check for obstructions, operation, and security.	•				
J	12 Alternator and Electrical Connections - Check condition and security of alternator and support brackets. Check alternator belts for condition and proper adjustment.	•			K	
J	13 Alternator - Check brushes, leads, commutator or slip ring for wear.				L	
J	14 Starter, Starter Solenoid, and Electrical Connections - Check for condition of starter brushes, brush leads, and commutator.		•			
J	15 Oil Cooler - Check for obstructions, leaks, and security of attachment.	•				
J	16 Exhaust System - Inspect couplings, seals and expansion joints for cracks and security. Air leak check exhaust system. Refer to Sections 12 and 12A, Paragraphs 12-98 and 12A-102, for inspection procedures.	•				
J	17 Exhaust System (turbocharged engine) - Inspect couplings, seals, clamps, and expansion joints for cracks. Air leak check exhaust stem and security. Refer to Sections 12 and 12A, Paragraphs 12-98 and 12A-102, for inspection procedures.	•				
J	18 Auxiliary (Electric) Fuel Pump - Check pump and fittings for condition, operation, security. Remove and clean filter (as applicable).		•			U
J	19 Engine Driven Fuel Pump - Check for evidence of leakage, security of attachment, and general condition.		•			
J	20 Magnetos - Check external condition, security, and electrical leads for condition. Check timing to engine and internal timing if engine timing requires adjustment.		•		M	
J	21 Magnetos - Timing Procedures and intervals, lubrication, and overhaul procedures.				N	
J	22 Ignition Harness and Insulators - Check for proper routing, deterioration, and condition of terminals.		•			
J	23 Spark Plugs - Remove, clean analyze, test, gap, and rotate top plugs-to-bottom and bottom plugs-to-top.		•			
J	24 Cylinder Compression - Perform differential compression test.			•		
J	25 Fuel Injection System - Check security of fuel-air control unit, manifold valve, nozzles, screws and pump. Check fuel lines for leaks, interference, and proper routing.		•			

MODEL 210 & T210 SERIES SERVICE MANUAL

2-51	INSPECTION TIME LIMITS. (MODEL P210 AIRPLANES.)	EACH 50 HOURS	EACH 100 HOURS	EACH 200 HOURS	SPECIAL INSPECTIONS	
					HOURS	YEARS
J 26	Engine Primer - Check for leakage, operation, and security.		•			
J 27	Hoses, Metal Lines, and Fittings - Inspect for signs of oil and fuel leaks. Check for abrasions, chafing, security, proper routing and support and for evidence of deterioration.	•				O
J 28	Cold and Hot Air Hoses - Check condition, routing, and security.		•			
J 29	Engine Cylinders, Rocker Box Covers, and Pushrod Housings - Check for fin damage, cracks, oil leakage, security of attachment, and general condition.		•			
J 30	Engine Baffles and Seals - Check condition and security of attachment.	•				
J 31	Crankcase, Oil Sump, and Accessory Section - Inspect for cracks and evidence of oil leakage. Check bolts and nuts for looseness and retorque as necessary. Check crankcase breather lines for obstructions, security, and general condition.		•			
J 32	Turbocharger – a. Inspect turbocharger mounting brackets, ducting, linkage, and attaching parts for general condition, leakage or damage, and security of attachment. b. Check waste gate, actuator, controller, oil and vent lines, over boost relief valve, and compressor housing for leakage, apparent damage, security of attachment, and evidence of wear. Check waste gate return spring for condition and security.	•				P
J 33	Turbocharger – a. Remove heat shields and inspect for burned areas, bulges or cracks. Remove tailpipe and ducting. Inspect turbine for coking, carbonization, oil deposits, and turbine impellers for damage.			•		P
J 34	Heater Components - Inspect all components for condition and security.		•			
J 35	Engine Oil Change - Turbocharged and Normally Aspirated Engines With Oil Filters: a. Remove and replace short oil filter (approximately 4.8 inches long). b. Add recommended grade aviation oil to replace oil lost in existing filter.	•				O
J 36	Engine Oil Change - Turbocharged and Normally Aspirated Engines With Oil Filters: c. Drain oil sump and refill with recommended grade aviation oil (when system is equipped with short oil filter). d. Drain oil sump, remove and replace long oil filter (approximately 5.8 inches long), and refill with recommended grade aviation oil.			•		O
J 37	Engine Oil Change – Normally Aspirated Engines Without Oil Filters: a. Engine Oils Without Oil Filter - Drain oil sump and oil cooler, clean and inspect screens, and refill with recommended grade aviation oil.	•				O

MODEL 210 & T210 SERIES SERVICE MANUAL

2-51	INSPECTION TIME LIMITS. (MODEL 210 & T210 AIRPLANES.)	EACH 50 HOURS	EACH 100 HOURS	EACH 200 HOURS	SPECIAL INSPECTIONS	
					HOURS	YEARS
J 38	Fuel Manifold - Valves, Valve Covers, and Fuel System.		•		X	
J 39	Engine Fuel Injection Nozzles.				Y	
K	Fuel System (Section 13).					
K 1	Integral Fuel Tanks - Check for evidence of leakage and condition of fuel caps, adapters, and placards.		•			
K 2	Integral Fuel Tanks - Drain fuel and check tank interior and outlet screens.				R	
K 3	Fuel System - Inspect plumbing and components for mounting and security.		•			
K 4	Fuel Tank Drains - Drain water and sediment.	•				
K 5	Fuel Tank Vent Lines and Vent Valves - Check vents for obstruction and proper positioning. Check valves for operation.		•			
K 6	Fuel Selector Valve - Check controls for detent in each position, security of attachment, and for proper placards.		•			
K 7	Throttle - Operated Auxiliary Fuel Pump Switch. Check condition of wiring and security of components. Perform rigging check (refer to Paragraph 13-35).		•			
K 8	Fuel Strainer, Drain Valve, and Controls - Check freedom of movement, security, and proper operation. Disassemble, flush, and clean screen and bowl.		•			
K 9	Fuel Quantity Indicators - Check for damage, security of installation, and perform accuracy test.					Each 1
L	Propeller and Propeller Governor (Section 14).					
L 1	Propeller Governor and Control - Inspect for oil and grease leaks. If leakage is evident, refer to McCauley Service Manual.	•				
L 2	Propeller Mounting - Check for security of installation.	•				
L 3	Propeller Blades - Inspect for cracks, dents, nicks, scratches, erosion, corrosion, or other damage.	•				
L 4	Spinner - Check general condition and attachment.	•				
L 5	Spinner and Spinner Bulkhead - Remove spinner, wash, and inspect for cracks and fractures.		•			
L 6	Propeller Mounting Bolts - Inspect mounting bolts and safety wire for signs of looseness. Retorque mounting bolts as required.			•		
L 7	Propeller Hub - Check general condition.			•		
L 8	Propeller Governor and Control - Check for security and operation of controls.			•		
L 9	Propeller Assembly - Overhaul.				S	
M	Utility Systems (Section 15).					
M 1	Ventilation System - Inspect clamps, hoses, and valves for condition and security.				400	Each 1
M 2	Heater Components, Inlets, and Outlets - Inspect all lines, connections, ducts, clamps, seals, and gaskets for condition, restriction, and security.		•			
M 3	Cabin Heat and Ventilation Controls - Check freedom of movement through full travel. Check friction locks for proper operation.			•		

MODEL P210 SERIES SERVICE MANUAL

2-51 INSPECTION TIME LIMITS. (MODEL P210 AIRPLANES.)		EACH	EACH	EACH	SPECIAL	
		50	100	200	INSPECTIONS	YEARS
		HOURS	HOURS	HOURS	HOURS	
M	4 Pitot Tube and Stall Warning Vane - Check for condition and obstructions.	•				
M	5 Pitot Tube Heater Element - Perform operational check.	•				
M	6 Propeller Anti-ice Slip Rings, Brushes and Boots - Inspect for condition, and security. Perform operational check.	•				
M	7 Heated Windshield Panel - Check operation, security of installation, electrical wiring, and condition of storage bag.			•		
M	8 Oxygen System - Inspect masks, hoses, lines, and fittings for condition, routing, and support. Test operation and check for leaks.			•		
M	9 Oxygen Cylinder - Inspect for condition, check hydrostatic test date and perform hydrostatic test, if due.					EACH 5
N	Instruments and Instrument Systems (Section 16).					
N	1 Vacuum System - Inspect for condition and security.		•			
N	2 Vacuum System Hoses - Inspect for hardness, deterioration, looseness, or collapsed hoses.		•			
N	3 Vacuum Pump - Check for condition and security. Check vacuum system breather line for obstructions, condition, and security.		•			
N	4 Vacuum System Air Filter - Inspect for damage, deterioration and contamination. Clean or replace, if required. NOTE: Smoking will cause premature filter clogging.		•		T	
N	5 Vacuum System relief Valve - Inspect for condition and security.		•		U	
N	6 Instruments - Check general condition and markings for legibility.		•			
N	7 Instrument Lines, Fittings, Ducting, and Instrument Panel Wiring - Check for proper routing, support, and security of attachment.			•		
N	8 Static System - Inspect for security of installation, cleanliness, and evidence of damage.			•		
N	9 Navigation Indicators, Controls, and Components - Inspect for condition and security.			•		
N	10 Airspeed Indicator, Vertical Speed Indicator, and Magnetic Compass - Calibrate.					EACH 2
N	11 Altimeter and Static System - Inspect in accordance with FAR Part 91.411.					EACH 2
N	12 Instrument Panel Mounted Avionics Units (Including Audio Panel, VHF Nav/Com(s), ADF, Transponder, DME, and Compass System - Inspect for deterioration, cracks, and security of instrument panel mounts. Inspect for security of electrical connections, condition, and security of wire routing.			•		
N	13 Avionics Operating Controls - Inspect for security and proper operation of controls and switches and ensure that all digital segments will illuminate properly.			•		
N	14 Remote Mounted Avionics - Inspect for security of units and electrical connectors, condition and security of wire routing. Also check for evidence of damage and cleanliness.			•		

MODEL P210 SERIES SERVICE MANUAL

2-51 INSPECTION TIME LIMITS. (MODEL P210 AIRPLANES.)		EACH	EACH	EACH	SPECIAL	
		50	100	200	HOURS	YEARS
		HOURS	HOURS	HOURS		
N	15 Microphones, Headsets, and Jacks - Inspect for cleanliness, security, and evidence of damage.			•		
N	16 Magnetic Compass - Inspect for security of installation, cleanliness, and evidence of damage.			•		
O	Electrical Systems (Section 17).					
O	1 General Airplane and System Wiring - Inspect for proper routing, chafing, broken or loose terminals, general condition, broken or inadequate clamps, and sharp bends in wiring.			•		
O	2 Instrument, Cabin, Navigation, Beacon, Strobe, and Landing Lights - Check operation, condition of lens, and security of attachment.		•			
O	3 Circuit Breakers and Fuses - Check operation and condition. Check for required number of spare fuses.		•			
O	4 Battery - Check general condition and security. Check level of electrolyte.		•		V	
O	5 Battery Box and Cables - Clean and remove any corrosion. Check cables for routing, support, and security of connections.		•			
O	6 Switch and Circuit Breaker Panel, Terminal Blocks, and Junction Boxes - Inspect wiring and terminals for condition and security.			•		
O	7 Alternator Control Unit - Inspect wiring, mounting, condition, and wire routing.			•		
O	8 Switches - Check operation, terminals, wiring, and mounting for conditions, security, and interference.			•		
O	9 Instrument Panel and Control Pedestal - Inspect wiring, mounting, and terminals for condition and security. Check resistance between stationary panel and instrument panel for proper ground.			•		
O	10 External Power Receptacle and Power Cables - Inspect for condition and security.			•		
P	Post Inspection.					
P	1 Replace all fairings, doors, and access hole covers - Ground check engine, alternator charging rate, oil pressure, tachometer, oil temperature and pressure gages, and general operation of components.					
Q	Perform the Following Operational Checks:					
Q	1 Brakes - Test toe brakes and parking brake for proper operation.		•			
R	Service Bulletins - Airworthiness Directives.					
R	1 Check that all applicable Cessna Service Bulletins, and Supplier Service Bulletins are complied with.					
R	2 Check that all applicable Airworthiness Directives, and Federal Aviation Regulations are complied with.					

MODEL P210 SERIES SERVICE MANUAL

2-51 INSPECTION TIME LIMITS. (MODEL P210 AIRPLANES.)

R 3 Ensure all Maintenance Record Entries required by Federal Aviation Regulations are completed before returning the airplane to service.

EACH 50 HOURS	EACH 100 HOURS	EACH 200 HOURS	SPECIAL INSPECTIONS	
			HOURS	YEARS

MODEL P210 SERIES SERVICE MANUAL

Special Inspections Legends:

- A. First 12,000 hours and each 1000 hours thereafter: Check fuselage skins adjacent to cabin windows, emergency exit door and main cabin door for cracks. Check emergency exit door for cracks. Check de-ice light lens for cracks.
First 10,000 hours and every 500 hours thereafter: Check belly skins for cracks and failed rivets. Check main cabin door hinges for failed screws. Check emergency exit door jamb for cracks.
First 6000 hours and each 200 hours thereafter: Check main cabin door jamb for cracks.
First 4000 hours and each 200 hours thereafter: Check main cabin door fillet for cracks and rivet failure.
- B. First 10,000 hours and each 500 hours thereafter: Check bulkhead at sta. 55, 80, and 90 for cracks.
First 12,000 hours and each 1000 hours thereafter: Check bulkheads at sta. 8, 27, 35, 103 and aft pressure bulkhead for cracks.
First 11,000 hours and each 3000 hours thereafter: Check front carry-thru spar and front doorpost intersection for cracks and rivet failure.
First 4000 hours and each 200 hours thereafter: Check instrument panel and bulkhead at sta. 18 for cracks and rivet failure.
- C. First 100 hours and each 500 hours thereafter. More often if operated under prevailing wet or dusty conditions.
- D. At the first 50 hours, first 100 hours, and each 500 hours thereafter, or one year, whichever comes first.
- E. Each 500 hours, and whenever improper operation is suspected. Replace brushes when worn to .25 inch or less.
- F. Overhaul components and replace rubber goods on-condition basis.
- G. Each 600 hours or 1 year, whichever comes first.
- H. Lubrication of the actuator is required each 1000 hours or 3 years, whichever comes first. Refer to figure 2-5 for grease specification.
- I. Lubricate each 100 hours (except in extreme dusty conditions). These controls are not repairable and should be replaced every 1500 hours or sooner if required.
- J. Clean filter per paragraph 2-21. Replace paper filters at least each 500 hours.
- K. Check belt tension after 10 to 25 hours of operation. Refer to Section 17.
- L. Inspect each 500 hours.
- M. At the first 25 hours, first 50 hours, first 100 hours, and each 100 hours thereafter, the contact breaker point compartment and magneto-to-engine timing should be inspected and checked. If magneto-to-engine timing is correct within plus zero to minus two degrees, internal timing need not be checked. If timing is out of tolerance, remove magneto from engine. Detailed Maintenance and Overhaul Information covering Slick magnetos is available from Cessna Supply Division. Order 1037C1-13 for 4200/6200 series magnetos.
- N. Every 500 hours of operation, perform the following items:
 - a. Inspect contact points for condition and adjust or replace as required.
 - b. Inspect carbon brush, high-tension lead, and distributive block for condition. Clean or replace parts as required.
 - c. Inspect impulse coupling and pawls for condition and replace as required. Use **light** pressure only. **Do not force** when checking pawls.
 - d. Inspect and lubricate bearings; replace as required.
 - e. Lubricate contact point cam.The magnetos **must** be overhauled or replaced with new or rebuilt magnetos at every engine overhaul.
- O. Replace engine compartment rubber hoses (Cessna installed only) every 5 years, or at engine overhaul, whichever occurs first. This does not include drain hoses. Hoses which are beyond these limits, and are in a serviceable condition, must be placed on order immediately and then be replaced within 120 days after receiving the new hoses(s) from Cessna. Replace drain hoses on condition. Engine flexible hoses (Continental Motors installed): refer to Continental Motors Maintenance Manual and Continental Motor Engine Service Bulletins.
- P. Replace check valves in turbocharger oil lines each 1000 hours.
- Q. First 25 hours: Use MIL-L-6082 Aviation grade straight mineral oil to replenish supply. After first 25 hours: Drain sump and remove and replace filter. Refill sump with recommended grade of ashless dispersant oil. Change oil and replace filter at least every six months, regardless of accumulated hours.
- R. Each 1000 hours.
- S. See McCauley Service Manual; refer to list of publication.
- T. Replace every 500 hours.
- U. Replace filter each 100 hours.
- V. Check electrolyte level and clean battery box each 100 hours or 90 days.

MODEL P210 SERIES SERVICE MANUAL

- W. Overhaul or replace Dukes Electrical Fuel Boost Pump at 10 years. Refer to Dukes Mandatory Service Bulletin No. 0003, or latest revision.
- X. Each 100 hours of operation or whenever fuel flow fluctuation is encountered. Inspect fuel manifold valves, valve covers, and fuel system components and lines for signs of leaks. Refer to Teledyne Continental Motors Service Bulletin SB95-7, or latest revision.
- Y. At the first 100-hour inspection on new, rebuilt or overhauled engines, remove and clean the fuel injection nozzles. Thereafter, the fuel injection nozzles must be cleaned at 300-hour intervals or more frequently if fuel stains are found.

2-52. COMPONENT TIME LIMITS.

1. General.

- A. Most components listed throughout Section 2 should be inspected as detailed elsewhere in this section and repaired, overhauled or replaced as required. Some components, however, have a time or life limit, and must be overhauled or replaced on or before the specified time limit.

NOTE: Overhaul - Item may be overhauled as defined in FAR 43.2 or it can be replaced.

NOTE: Replacement - Item must be replaced with a new item or a serviceable item that is within its service life and time limits or has been rebuilt as defined in FAR 43.2.

- B. This section provides a list of items which must be overhauled or replaced at specific time limits. Table 1 lists those items which Cessna has mandated must be overhauled or replaced at specific time limits. Table 2 lists component time limits which have been established by a supplier to Cessna for the supplier's product.
- C. In addition to these time limits, the components listed herein are also inspected at regular time intervals set forth in the Inspection Charts, and may require overhaul/replacement before the time limit is reached, based on service usage and inspection results.

2. Cessna-Established Replacement Time Limits.

- A. The following component time limits have been established by Cessna Aircraft Company.

Table 1: Cessna-Established Replacement Time Limits

COMPONENT	REPLACEMENT TIME	OVERHAUL
Restraint Assembly Pilot, Copilot, and Passenger Seats	10 years	NO
Trim Tab Actuator	1,000 hours or 3 years, whichever occurs first	YES
Vacuum System Filter	500 hours	NO
Vacuum System Hoses	10 years	NO
Pitot and Static System Hoses	10 years	NO
Vacuum Relief/Regulator Valve Filter (If Installed)	500 hours	NO

MODEL P210 SERIES SERVICE MANUAL

COMPONENT	REPLACEMENT TIME	OVERHAUL
Engine Compartment Flexible Fluid-Carrying Teflon Hoses (Cessna-Installed) Except Drain Hoses (Drain hoses are replaced on condition)	10 years or engine overhaul, whichever occurs first (Note 1)	NO
Engine Compartment Flexible Fluid-Carrying Rubber Hoses (Cessna-Installed) Except Drain Hoses (Drain hoses are replaced on condition)	5 years or engine overhaul, whichever occurs first (Note 1)	NO
Engine Air Filter	500 hours or 36 months, whichever occurs first (Note 9)	NO
Engine Mixture, Throttle, and Propeller Controls	At engine TBO	NO
Check Valve (Turbocharger Oil Line Check Valve)	Every 1,000 hours of operation (Note 10)	NO
Oxygen Bottle - Lightweight Steel (ICC-3HT, DOT-3HT)	Every 24 years or 4380 cycles, whichever occurs first	NO
Oxygen Bottle - Composite (DOT-E8162)	Every 15 years	NO
Engine-Driven Dry Vacuum Pump Drive Coupling (Not lubricated with engine oil)	6 years or at vacuum pump replacement, whichever occurs first	NO
Engine-Driven Dry Vacuum Pump (Not lubricated with engine oil)	500 hours (Note 11)	NO
Standby Dry Vacuum Pump	500 hours or 10 years, whichever occurs first (Note 11)	NO

MODEL P210 SERIES SERVICE MANUAL

3. Supplier-Established Replacement Time Limits

- A. The following component time limits have been established by specific suppliers and are reproduced as follows:

Table 2: Supplier-Established Replacement Time Limits

COMPONENT	REPLACEMENT TIME	OVERHAUL
ELT Battery	(Note 3)	NO
Vacuum Manifold	(Note 4)	NO
Magnetos	(Note 5)	YES
Engine	(Note 6)	YES
Engine Flexible Hoses (Lycoming Installed)	(Note 2)	NO
Auxiliary Electric Fuel Pump	(Note 7)	YES
Propeller	(Note 8)	YES

NOTES:

Note 1: This life limit is not intended to allow flexible fluid-carrying Teflon or rubber hoses in a deteriorated or damaged condition to remain in service. Replace engine compartment flexible Teflon (AE3663819BXXXX series hose) fluid-carrying hoses (Cessna-installed only) every ten years or at engine overhaul, whichever occurs first. Replace engine compartment flexible rubber fluid-carrying hoses (Cessna-installed only) every five years or at engine overhaul, whichever occurs first (this does not include drain hoses). Hoses which are beyond these limits and are otherwise in a serviceable condition, must be placed on order immediately and then be replaced within 120 days after receiving the new hose from Cessna.

Note 2: For Textron Lycoming engines, refer to latest Textron Lycoming Engine Service Bulletins.

Note 3: Refer to FAR 91.207 for battery replacement time limits.

Note 4: Refer to Airborne Air & Fuel Product Reference Memo No. 39, or latest revision, for replacement time limits.

Note 5: For airplanes equipped with Slick magnetos, refer to Slick Service Bulletin SB2-80C, or latest revision, for time limits.

For airplanes equipped with TCM/Bendix magnetos, refer to Teledyne Continental Motors Service Bulletin No. 643, or latest revision, for time limits.

Note 6: Refer to Teledyne Continental Service Information Letter SIL98-9, or latest revision, for time limits.

Note 7: Refer to Cessna Service Bulletin SEB94-7 Revision 1/Dukes Inc. Service Bulletin NO. 0003, or latest revision.

Note 8: Refer to the applicable McCauley Service Bulletins and Overhaul Manual for replacement and overhaul information.

MODEL P210 SERIES SERVICE MANUAL

Note 9: The air filter may be cleaned. Refer to Section 2 of this service manual. For airplanes equipped with an air filter manufactured by Donaldson, refer to Donaldson Aircraft Filters Service Instructions P46-9075 for detailed servicing instructions. The address for Donaldson Aircraft Filters is:

Customer Service
115 E. Steels Corners RD
Stow OH. 44224

Do not overservice the air filter. Overservicing increases the risk of damage to the air filter from excessive handling. A damaged/worn air filter may expose the engine to unfiltered air and result in damage/excessive wear to the engine.

Note 10: Replace the turbocharger oil line check valve every 1,000 hours of operation (Refer to Cessna Service Bulletin SEB91-7 Revision 1, or latest revision).

Note 11: Replace engine driven dry vacuum pump not equipped with a wear indicator every 500 hours of operation, or replace according to the vacuum pump manufacturer's recommended inspection and replacement interval, whichever occurs first.

Replace standby vacuum pump not equipped with a wear indicator every 500 hours of operation or 10 years, whichever occurs first, or replace according to the vacuum pump manufacturer's recommended inspection and replacement interval, whichever occurs first.

For a vacuum pump equipped with a wear indicator, replace pump according to the vacuum pump manufacturer's recommended inspection and replacement intervals.

MODEL P210 SERIES SERVICE MANUAL

2-53. SCHEDULED MAINTENANCE CHECKS. (MODEL P210 AIRPLANES)

2-54. PROGRESSIVE CARE PROGRAM. (MODEL P210 AIRPLANES)

A. Progressive Inspection Program.

(1) Purpose and Use.

- (a) As detailed in Federal Aviation Regulation Part 91.409, paragraph (d), airplanes that desire to use a Progressive Inspection Program must be inspected in accordance with an authorized progressive inspection program. This chapter presents the current progressive inspection program for the Cessna Model P210, recommended by the Cessna Aircraft Company.

B. Introduction.

- (1) Following is the recommended Progressive Care Program for Model P210 airplanes.
- (2) This program is divided into four separate operations which are to be accomplished initially after 50 hours of operation and each 50 hours of operation thereafter. Additional special requirements indicated as Special Inspection, which are required at other intervals, are specified separately.
- (3) Recommended progressive care inspection may be accomplished by one of the following.

NOTE

Some 100 HOUR items are covered in Operations 1 and 3. Also, some 200 HOUR items are covered in Operations 1, 2, 3, and 4. These items are placed here for convenience and expediency of the total inspection. After the first completion of all four Operations, these items will be at the proper intervals.

- (a) **NEW DELIVERED AIRCRAFT** - A new delivered aircraft must have less than 50 hours of total time in service and enough calendar time remaining since the issuance date of the original Airworthiness Certificate to allow the owner/operator to complete a cycle of all four Operations before the first annual inspection becomes due. Operation 1 will be due at 50 hours time in service. Operation 2 will be due at 100 hours. Operation 3 will be due at 150 hours and Operation 4 will be due at 200 hours. There are additional inspection requirements for new aircraft at the FIRST 50 HOUR inspection point. In addition to performing Operation 1, the FIRST 50 HOUR ITEMS listed in the inspection Time Limits Charts in 2-54 must also be performed. After these FIRST 50 HOUR items have been accomplished, they have permanent inspection time limits which are covered in the Operations Schedules.
- (b) **ALL OTHER AIRCRAFT** - To qualify other aircraft which have more than 50 hours time in service for the Progressive Inspection Program, conduct a **COMPLETE AIRPLANE INSPECTION**. Operation 1 will become due 50 hours from the time the **COMPLETE AIRPLANE INSPECTION** was accomplished.
- (4) Performance of the inspections as listed herein at the specified points will assure compliance with the Inspection Time Limits detailed in 2-51. Special inspections shall be complied with at prescribed intervals and/or intervals coinciding with operations 1 through 4 as outlined in 2-54.
- (5) An operator may elect to perform the recommended inspections on a schedule other than that specified. Any inspection schedule requiring the various inspection items detailed in this chapter may be performed at a frequency equal to that specified herein or more frequently is acceptable. Any inspection item performed at a time period in excess of that specified herein must be approved by the appropriate regulating agency.
- (6) As defined in Federal Aviation Regulations Part 91.409(d), the frequency and detail of the Progressive Inspection Program shall provide for the complete inspection of the airplane within each 12 calendar months. If the airplane is approaching the end of a 12-calendar-month period, but the complete cycle of 4 operations has not been accomplished, it will be necessary to complete the remaining operations, regardless of airplane hours before the end of the 12-calendar-month period. If the Progressive inspection Program is to be discontinued, an annual inspection becomes due at the time when any item reaches a maximum of 12 calendar months from the last time it was inspected under the Progressive Inspection Program. Refer to Federal Aviation Regulation Part 91.409(d) for detailed information.

MODEL P210 SERIES SERVICE MANUAL

(THIS PAGE INTENTIONALLY LEFT BLANK)

MODEL P210 SERIES SERVICE MANUAL

C. Inspection Time Limitations.

- (1) Each inspection interval may be exceeded by 10 hours or can be performed early at any time prior to the regular interval as provided below:
 - (a) In the event of late compliance of any operation scheduled, the next operation in sequence retains a due point from the time the late operation was originally scheduled.
 - (b) In the event of early compliance of any operation scheduled, that occurs 10 hours or less ahead of schedule, the next phase due point may remain where originally set.
 - (c) In the event of early compliance of any operation scheduled, that occurs more than 10 hours ahead of schedule, the next phase due point must be rescheduled to establish a new due point from the time of early accomplishment.

D. Procedures.

- (1) The following instructions are provided to aid in implementation of the Model P210 Series Progressive Care Program Schedule.
 - (a) Use the Progressive Care Program Inspection Chart, provided herein, for each airplane. The chart is to be placed in the airplane flight log book for use as a quick reference for pilots and maintenance personnel in determining when inspections are due and that they are performed within prescribed flight time intervals.
 - (b) Use the Progressive Care Program Component Overhaul and Replacement Log, provided herein, for each airplane. This log is to be kept with the airplane maintenance records and serves as a periodic reminder to maintenance personnel when various components are due for overhaul or replacement.
 - (c) To start the Progressive Care Program, begin conducting the inspections defined herein and refer to Federal Aviation Regulations Part 91.409(d) for procedures to notify the Federal Aviation Administration of the intent to begin a progressive inspection program.
 - (d) Accomplish each inspection and maintenance item per the checklists on the operation sheets of the Progressive Care and Maintenance Schedule. Spaces have been provided for the mechanic's and inspectors signatures as required, as well as any remarks. These are to become part of the maintenance records for each airplane. Each inspection is to be logged in the airplane and/or engine log books. Refer to Federal Aviation Regulation Part 43 for the recommended entry statement.

MODEL P210 SERIES SERVICE MANUAL

PROGRESSIVE CARE PROGRAM (MODEL P210 AIRPLANES)

COMPONENT OVERHAUL AND REPLACEMENT RECORD

COMPONENT	DATE	REASON FOR REPLACEMENT	REPLACEMENT PART NUMBER SERIAL NUMBER	NEXT OVERHAUL AIRPLANE HOURS DATE
	X			
	X			
	X			
	X			
	X			
	X			
	X			
	X			
	X			
	X			

MODEL P210 SERIES SERVICE MANUAL

PROGRESSIVE CARE PROGRAM INSPECTION CHART

AIRPLANE MODEL: P210

REGISTRATION NUMBER:

INSPECTION POINTS	TIME		TIME	
	INSPECTION DUE	INSPECTION ACCOMPLISHED	INSPECTION DUE	INSPECTION ACCOMPLISHED
OPERATION 1				
OPERATION 2				
OPERATION 3				
OPERATION 4				

EXAMPLE:

The airplane in this example was placed on the Progressive Care Program after flying a total of 110 hours. At that point, a complete initial inspection of the airplane was performed. The following steps indicate what will have taken place up through an hourmeter reading of 261 hours.

1. After the initial inspection at 110 hours, the first Inspection Due Column was filled out to show the total flying time at which each of the four (4) operation inspections would be due.
2. As each inspection was performed, the total flying time was recorded in the Inspection Accomplished column. The next Inspection Due space for that particular operation is also filled in at this time. These times will always be 200 hours from the last due point providing the operation was actually accomplished within the ten (10) hours limit.
3. The sample airplane now has a total flying time of 261 hours and the inspection chart shows that a Phase 4 will be due at 310 hours.

INSPECTION POINTS	TIME		TIME	
	INSPECTION DUE	INSPECTION ACCOMPLISHED	INSPECTION DUE	INSPECTION ACCOMPLISHED
OPERATION 1	160	162	360	
OPERATION 2	210	209	409	
OPERATION 3	260	261	460	
OPERATION 4	310			

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 1

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

B 13 Aileron, Elevator, and Rudder Stops - Check for damage and security.

B 15 Seat Tracks and Stops - Inspect seat tracks for condition and security of installation. Check seat track stops for damage and correct location. Ensure inspection of seat rails for cracks EACH 50 HOURS. Refer to Section 3.

C 1 Wing Surfaces and Tips - Inspect for skin damage, loose rivets, and condition of paint.

C 6 Vertical and Horizontal Stabilizers, Tips and Tailcone - Inspect externally for skin damage and condition of paint.

C 7 Vertical and Horizontal Stabilizers and Tailcone structure - Inspect bulkheads, spars, ribs, and skins for cracks, wrinkles, loose rivets, corrosion, or other damage. Inspect vertical and horizontal stabilizer attach bolts for looseness. Retorque as necessary. Check security of inspection covers, fairings, and tips.

E 1 Ailerons, Hinges - Check condition, security and operation.

E 2 Aileron Structure, Control Rods, Hinges, Balance Weights, Bellcranks, Linkage, Bolts, Pulleys, and Pulley Brackets - Check condition, operation, and security of attachment.

E 5 Aileron Controls - Check freedom of movement and proper operation through full travel with and without flaps extended.

F 1 Flaps - Check tracks, rollers, and control rods for security of attachment. Check rod end bearings for corrosion and lubricate. Check operation.

F 2 Flap Actuator Threads - Clean and lubricate. Refer to paragraph 2-47 for detailed instructions.

G 1 Elevator Control - Check freedom of movement and proper operation through full travel with and without flaps extended.

G 2 Elevator, Hinges, and Cable Attachment - Check condition, security, and operation.

G 4 Elevator Arm - Check bolts, linkage, and push-pull tube for condition, operation, and security. Check travels if cables require tension adjustment or if stops are damaged.

H 1 Elevator Trim Tab and Hinges - Check condition, security, and operation.

H 2 Elevator Trim System - Check cables, push-pull rods, bellcranks, pulleys, turnbuckles, fairleads, rub strips, etc. for proper routing, condition, and security.

I 1 Rudder - Inspect the rudder skins for cracks and loose rivets, rudder hinges for condition, cracks and security; hinge bolts, hinge bearings, hinge attach fittings, and bonding jumper for evidence of damage and wear, failed fasteners, and security. Inspect the rudder hinge bolts for proper safetying of nuts with cotter pins. Inspect balance weight for looseness and the supporting structure for damage.

I 3 Rudder Tips, Hinges, Stop Bolts, Clips, and Cable Attachments - Check condition, security, and operation.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 1

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

-
- J 1 Cowlings and Cowl Flaps - Inspect for cracks, dents, and other damage, security of cowl fasteners, and cowl mounted landing lights for attachment. Check cowl flaps for condition, security, and operation.
-
- J 2 Engine - Inspect for evidence of oil and fuel leaks. Wash engine and check for security of accessories.
-
- J 3 Cowl Flap Controls - Check freedom of movement through full travel.
-
- J 4 Engine Propeller Controls, and Linkage - Check general condition, freedom of movement through full range. Check for proper travel, security of attachment, and for evidence of wear. Check friction locks for proper operation.
-
- J 5 Ignition Switch and Electrical Harness - Inspect for damage, condition, and security.
-
- J 6 Firewall Structure - Inspect for wrinkles, damage, cracks, sheared rivets, etc. Check cowl shock mounts for condition and security.
-
- J 7 Engine Shock Mounts, Engine Mount Structure, and Ground Straps - Check condition, security, and alignment.
-
- J 8 Induction System - Check security of clamps, tubes, and ducting. Inspect for evidence of leakage.
-
- J 9 Induction Airbox, Valves, Doors, and Controls - Remove air filter and inspect hinges, doors, seals, and attaching parts for wear and security. Check operation. Clean and inspect air filter and re-oil if flock-coated.
-
- J 10 Induction Air Filter - Remove and clean, inspect for damage, and service per paragraph 2-21.
-
- J 11 Alternate Induction Air System - Check for obstructions, operation, and security.
-
- J 12 Alternator and Electrical Connections - Check condition and security of alternator and support brackets. Check alternator belts for condition and proper adjustment.
-
- J 14 Starter, Starter Solenoid, and Electrical Connections - Check for condition of starter brushes, brush leads, and commutator.
-
- J 15 Oil Cooler - Check for obstructions, leaks, and security of attachment.
-
- J 16 Exhaust System - Inspect couplings, seals and expansion joints for cracks and security. Air leak check exhaust system. Refer to Sections 12 and 12A, Paragraphs 12-98 and 12A-102, for inspection procedures.
-
- J 17 Exhaust System (turbocharged engine) - Inspect couplings, seals, clamps, and expansion joints for cracks. Air leak check exhaust stem and security. Refer to Sections 12 and 12A, Paragraphs 12-98 and 12A-102, for inspection procedures.
-
- J 18 Auxiliary (Electric) Fuel Pump - Check pump and fittings for condition, operation, security. Remove and clean filter (as applicable)
-
- J 19 Engine Driven Fuel Pump - Check for evidence of leakage, security of attachment, and general condition.
-
- J 20 Magnetos - Check external condition, security, and electrical leads for condition. Check timing to engine and internal timing if engine timing requires adjustment.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 1

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

-
- J 22 Ignition Harness and Insulators - Check for proper routing, deterioration, and condition of terminals.
-
- J 23 Spark Plugs - Remove, clean analyze, test, gap, and rotate top plugs-to-bottom and bottom plugs-to-top.
-
- J 24 Cylinder Compression - Perform differential compression test.
-
- J 25 Fuel Injection System - Check security of fuel-air control unit, manifold valve, nozzles, screws and pump. Check fuel lines for leaks, interference, and proper routing.
-
- J 26 Engine Primer - Check for leakage, operation, and security.
-
- J 27 Hoses, Metal Lines, and Fittings - Inspect for signs of oil and fuel leaks. Check for abrasions, chafing, security, proper routing and support and for evidence of deterioration.
-
- J 28 Cold and Hot Air Hoses - Check condition, routing, and security.
-
- J 29 Engine Cylinders, Rocker Box Covers, and Pushrod Housings - Check for fin damage, cracks, oil leakage, security of attachment, and general condition.
-
- J 30 Engine Baffles and Seals - Check condition and security of attachment.
-
- J 31 Crankcase, Oil Sump, and Accessory Section - Inspect for cracks and evidence of oil leakage. Check bolts and nuts for looseness and retorque as necessary. Check crankcase breather lines for obstructions, security, and general condition.
-
- J 32 Turbocharger -
a. Inspect turbocharger mounting brackets, ducting, linkage, and attaching parts for general condition, leakage or damage, and security of attachment.
b. Check waste gate, actuator, controller, oil and vent lines, overboost relief valve, and compressor housing for leakage, apparent damage, security of attachment, and evidence of wear. Check waste gate return spring for condition and security.
-
- J 33 Turbocharger -
a. Remove heat shields and inspect for burned areas, bulges or cracks. Remove tailpipe and ducting - Inspect turbine for coking, carbonization, oil deposits, and turbine impellers for damage.
-
- J 34 Heater Components - Inspect all components for condition and security.
-
- J 35 Engine Oil Change -
Turbocharged and Normally Aspirated Engines With Oil Filters:
a. Remove and replace short oil filter (approximately 4.8 inches long).
b. Add recommended grade aviation oil to replace oil lost in existing filter.
-
- J 37 Engine Oil Change -
Normally Aspirated Engines Without Oil Filters:
a. Engine Oils Without Oil Filter - Drain oil sump and oil cooler. Clean and inspect screens, and refill with recommended grade aviation oil.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 1

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

-
- | | | |
|-------|----|---|
| K | 1 | Integral Fuel Tanks - Check for evidence of leakage and condition of fuel caps, adapters, and placards. |
| <hr/> | | |
| K | 3 | Fuel System - Inspect plumbing and components for mounting and security. |
| <hr/> | | |
| K | 4 | Fuel Tank Drains - Drain water and sediment. |
| <hr/> | | |
| K | 5 | Fuel Tank Vent Lines and Vent Valves - Check vents for obstruction and proper positioning. Check valves for operation. |
| <hr/> | | |
| K | 7 | Throttle - Operated Auxiliary Fuel Pump Switch. Check condition of wiring and security of components. Perform rigging check (refer to Paragraph 13-35). |
| <hr/> | | |
| K | 8 | Fuel Strainer, Drain Valve, and Controls - Check freedom of movement, security, and proper operation. Disassemble, flush, and clean screen and bowl. |
| <hr/> | | |
| L | 1 | Propeller Governor and Control - Inspect for oil and grease leaks. If leakage is evident, refer to McCauley Service Manual. |
| <hr/> | | |
| L | 2 | Propeller Mounting - Check for security of installation. |
| <hr/> | | |
| L | 3 | Propeller Blades - Inspect for cracks, dents, nicks, scratches, erosion, corrosion, or other damage. |
| <hr/> | | |
| L | 4 | Spinner - Check general condition and attachment. |
| <hr/> | | |
| L | 5 | Spinner and Spinner Bulkhead - Remove spinner, wash, and inspect for cracks and fractures. |
| <hr/> | | |
| L | 6 | Propeller Mounting Bolts - Inspect mounting bolts, and safety-wire for signs of looseness. Retorque mounting bolts as required. |
| <hr/> | | |
| L | 7 | Propeller Hub - Check general condition. |
| <hr/> | | |
| L | 8 | Propeller Governor and Control - Check for security and operation of controls. |
| <hr/> | | |
| M | 2 | Heater Components, Inlets, and Outlets - Inspect all lines, connections, ducts, clamps, seals, and gaskets for condition, restriction, and security. |
| <hr/> | | |
| M | 4 | Pitot Tube and Stall Warning Vane - Check for condition and obstructions. |
| <hr/> | | |
| M | 5 | Pitot Tube Heater Element - Perform operational check. |
| <hr/> | | |
| M | 6 | Propeller Anti-ice Slip Rings, Brushes and Boots - Inspect for condition, and security. Perform operational check. |
| <hr/> | | |
| N | 3 | Vacuum Pump - Check for condition and security. Check vacuum system breather line for obstructions, condition, and security. |
| <hr/> | | |
| O | 5 | Battery Box and Cables - Clean and remove any corrosion. Check cables for routing, support, and security of connections. |
| <hr/> | | |
| O | 7 | Alternator Control Unit - Inspect wiring, mounting, condition, and wire routing. |
| <hr/> | | |
| O | 10 | External Power Receptacle and Power Cables - Inspect for condition and security. |

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 1

INSPECTION
COMPLETED BY

SPECIAL INSPECTION AND YEARLY ITEMS

HOURS YEARS

Please review each of these items for required compliance

B	1	Fuselage Surface - Inspect for skin damage, loose rivets, condition of paint, and check pitot-static ports and drain holes for obstruction. Inspect covers and fairings for security.	A	
B	2	Internal Fuselage Structure - Inspect bulkheads, doorposts, stringers, doublers, and skins for corrosion, cracks, buckles, and loose rivets, bolts and nuts.	B	
B	10	Windows, Windshield, Doors, and Seals - Inspect general condition. Check latches, hinges, and seals for condition, operation, and security of attachment.		
B	11	Upholstery, Headliner, Trim, and Carpeting - Check condition and clean as required.	EACH 400	EACH 1
D	3	Brake Lines, Wheel Cylinders, Hoses, Clamps, and Fittings - Check for leaks, condition, and security and hoses for bulges and deterioration. Check brake lines and hoses for proper routing and support. (See Cessna SEB92-8)	EACH 400	EACH 1
D	6	Main Landing Gear Strut-to-Pivot Attachment - Check for damage, cracks, loose rivets, bolts and nuts and security of attachment.		
D	10	Wheel Bearings - Clean, inspect and lube.	C	
D	20	Powerpack - Hydraulic fluid contamination check.	D	
D	21	Powerpack - Check condition and wear of brushes in servomotor.	E	
D	23	Landing Gear System - Overhaul main gear downlock actuators, main and nose gear actuators, landing gear selector valve, emergency hand pump, and pressure switch. Replace all rubber goods.		F
D	24	Brake System - Overhaul brake discs, parking brake system, wheel cylinders, and master cylinders. Replace brake pads and all rubber goods.		F
E	4	Autopilot Rigging - Check per Avionics Installation Manual.	G	EACH 1
H	5	Elevator Trim Tab Actuator - Clean, lubricate, and check free-play.	H	
J	4	Engine Propeller Controls, and Linkage - Check general condition, freedom of movement through full range. Check for proper travel, security of attachment, and for evidence of wear. Check friction locks for proper operation.	G	I
J	10	Induction Air Filter - Remove and clean, inspect for damage, and service per paragraph 2-21.	J	
J	12	Alternator and Electrical Connections - Check condition and security of alternator and support brackets. Check alternator belts for condition and proper adjustment.	K	
J	13	Alternator - Check brushes, leads, commutator or slip ring for wear.	L	
J	20	Magnetos - Check external condition, security, and electrical leads for condition. Check timing to engine and internal timing if engine timing requires adjustment.	M	
J	21	Magnetos - Timing Procedures and intervals, lubrication, and overhaul procedures.	N	
J	27	Hoses, Metal Lines, and Fittings - Inspect for signs of oil and fuel leaks. Check for abrasions, chafing, security, proper routing and support and for evidence of deterioration.		O

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 1

SPECIAL INSPECTION AND YEARLY ITEMS

HOURS YEARS

INSPECTION
COMPLETED BY

Please review each of these items for required compliance

J	32 Turbocharger - a. Inspect turbocharger mounting brackets, ducting, linkage, and attaching parts for general condition, leakage or damage, and security of attachment. b. Check waste gate, actuator, controller, oil and vent lines, overboost relief valve, and compressor housing for leakage, apparent damage, security of attachment, and evidence of wear. Check waste gate return spring for condition and security.	P		
J	33 Turbocharger - a. Remove heat shields and inspect for burned areas, bulges or cracks. Remove tailpipe and ducting - Inspect turbine for coking, carbonization, oil deposits, and turbine impellers for damage.	P		
J	35 Engine Oil Change - Turbocharged and Normally Aspirated Engines With Oil Filters: a. Remove and replace short oil filter (approximately 4.8 inches long). b. Add recommended grade aviation oil to replace oil lost in existing filter.	O		
J	37 Engine Oil Change - Normally Aspirated Engines Without Oil Filters: a. Engine Oils Without Oil Filter - Drain oil sump and oil cooler. Clean and inspect screens, and refill with recommended grade aviation oil.	O		
K	2 Integral Fuel Tanks - Drain fuel and check tank interior and outlet screens.	R		
K	9 Fuel Quantity Indicators - Check for damage, security of installation, and perform accuracy test.		EACH 1	
L	9 Propeller Assembly - Overhaul.	S		
M	1 Ventilation System - Inspect clamps, hoses, and valves for condition and security.	400	EACH 1	
M	9 Oxygen Cylinder - Inspect for condition, check hydrostatic test date and perform hydrostatic test, if due.		EACH 5	
N	4 Vacuum System Air Filter - Inspect for damage, deterioration and contamination. Clean or replace, if required. NOTE: Smoking will cause premature filter clogging.	T		
N	5 Vacuum System relief Valve - Inspect for condition and security.	U		
N	10 Airspeed Indicator, Vertical Speed Indicator, and Magnetic Compass - Calibrate.		EACH 2	
N	11 Altimeter and Static System - Inspect in accordance with FAR Part 91.411.		EACH 2	
O	4 Battery - Check general condition and security. Check level of electrolyte.	V		
P	1 Replace all fairings, doors, and access hole covers - Ground check engine, alternator charging rate, oil pressure, tachometer, oil temperature and pressure gages, and general operation of components.			
R	1 Check that all applicable Cessna Service Bulletins, and Supplier Service Bulletins are complied with.			
R	2 Check that all applicable Airworthiness Directives, and Federal Aviation Regulations are complied with.			

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 1

SPECIAL INSPECTION AND YEARLY ITEMS

HOURS YEARS

INSPECTION
COMPLETED BY

Please review each of these items for required compliance

- | | | HOURS | YEARS | |
|---|---|--|-------|--|
| R | 3 | Ensure all Maintenance Record Entries required by Federal Aviation Regulations are completed before returning the airplane to service. | | |

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 1

Special Inspections Legends:

- A. First 12,000 hours and each 1000 hours thereafter: Check fuselage skins adjacent to cabin windows, emergency exit door and main cabin door for cracks. Check emergency exit door for cracks. Check de-ice light lens for cracks.
First 10,000 hours and every 500 hours thereafter: Check belly skins for cracks and failed rivets. Check main cabin door hinges for failed screws. Check emergency exit door jamb for cracks.
First 6000 hours and each 200 hours thereafter: Check main cabin door jamb for cracks.
First 4000 hours and each 200 hours thereafter: Check main cabin door fillet for cracks and rivet failure.
- B. First 10,000 hours and each 500 hours thereafter: Check bulkhead at sta. 55, 80, and 90 for cracks.
First 12,000 hours and each 1000 hours thereafter: Check bulkheads at sta. 8, 27, 35, 103 and aft pressure bulkhead for cracks.
First 11,000 hours and each 3000 hours thereafter: Check front carry-thru spar and front doorpost intersection for cracks and rivet failure.
First 4000 hours and each 200 hours thereafter: Check instrument panel and bulkhead at sta. 18 for cracks and rivet failure.
- C. First 100 hours and each 500 hours thereafter. More often if operated under prevailing wet or dusty conditions.
- D. At the first 50 hours, first 100 hours, and each 500 hours thereafter, or one year, whichever comes first.
- E. Each 500 hours, and whenever improper operation is suspected. Replace brushes when worn to .25 inch or less.
- F. Overhaul components and replace rubber goods on-condition basis.
- G. Each 600 hours or 1 year, whichever comes first.
- H. Lubrication of the actuator is required each 1000 hours or 3 years, whichever comes first. Refer to figure 2-5 for grease specification.
- I. Lubricate each 100 hours (except in extreme dusty conditions). These controls are not repairable and should be replaced every 1500 hours or sooner if required.
- J. Clean filter per paragraph 2-21. Replace paper filters at least each 500 hours.
- K. Check belt tension after 10 to 25 hours of operation. Refer to Section 17.
- L. Inspect each 500 hours.
- M. At the first 25 hours, first 50 hours, first 100 hours, and each 100 hours thereafter, the contact breaker point compartment and magneto-to-engine timing should be inspected and checked. If magneto-to-engine timing is correct within plus zero to minus two degrees, internal timing need not be checked. If timing is out of tolerance, remove magneto from engine. Detailed Maintenance and Overhaul Information covering Slick magnetos is available from Cessna Supply Division. Order 1037C1-13 for 4200/6200 series magnetos.
- N. Every 500 hours of operation, perform the following items:
 - a. Inspect contact points for condition and adjust or replace as required.
 - b. Inspect carbon brush, high-tension lead, and distributive block for condition. Clean or replace parts as required.
 - c. Inspect impulse coupling and pawls for condition and replace as required. Use light pressure only. **Do not force** when checking pawls.
 - d. Inspect and lubricate bearings; replace as required.
 - e. Lubricate contact point cam.The magnetos **must** be overhauled or replaced with new or rebuilt magnetos at every engine overhaul.
- O. Replace engine compartment rubber hoses (Cessna installed only) every 5 years, or at engine overhaul, whichever occurs first. This does not include drain hoses. Hoses which are beyond these limits, and are in a serviceable condition, must be placed on order immediately and then be replaced within 120 days after receiving the new hoses(s) from Cessna. Replace drain hoses on condition. Engine flexible hoses (Continental Motors installed): refer to Continental Motors Maintenance Manual and Continental Motor Engine Service Bulletins.
- P. Replace check valves in turbocharger oil lines each 1000 hours.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 1

- Q. First 25 hours: Use MIL-L-6082 Aviation grade straight mineral oil to replenish supply. After first 25 hours: Drain sump and remove and replace filter. Refill sump with recommended grade of ashless dispersant oil. Change oil and replace filter at least every six months, regardless of accumulated hours.
- R. Each 1000 hours.
- S. See McCauley Service Manual; refer to list of publication.
- T. Replace every 500 hours.
- U. Replace filter each 100 hours.
- V. Check electrolyte level and clean battery box each 100 hours or 90 days.
- W. Overhaul or replace Dukes Electrical Fuel Boost Pump at 10 years. Refer to Dukes Mandatory Service Bulletin No. 0003.
- X. Each 100 hours or whenever fuel flow fluctuation is encountered, inspect fuel manifold valves, valve covers, and fuel system components and lines for signs of leaks. Refer to Teledyne Continental Motors Service Bulletin SB95-7.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 2

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

-
- B 1 Fuselage Surface - Inspect for skin damage, loose rivets, condition of paint, and check pitot-static ports and drain holes for obstruction. Inspect covers and fairings for security.
-
- B 6 Emergency Locator Transmitter - Inspect for security of attachment and check operation by verifying transmitter output. Check cumulative time and useful life of batteries in accordance with FAR Part 91.52. Refer to Section 17 - Operational Test of Emergency Locator Transmitter.
-
- B 8 Pilot's and Copilot's Inertia Reels - Inspect for security of installation, proper operation, and evidence of damage.
-
- B 9 Seats, Seat Belts, and Shoulder Harnesses - Check general condition and security. Check operation of seat stops and adjustment mechanism. Inspect belts for condition and security of fasteners.
-
- B 10 Windows, Windshield, Doors, and Seals - Inspect general condition. Check latches, hinges, and seals for condition, operation, and security of attachment.
-
- B 12 Flight Controls - Check freedom of movement and proper operation through full travel with and without flaps extended. Check electric trim controls for operation (as applicable).
-
- B 14 Portable Hand Fire Extinguisher - Inspect for proper operating pressure, condition, security of installation, and servicing date.
-
- B 15 Seat Tracks and Stops - Inspect seat tracks for condition and security of installation. Check seat track stops for damage and correct location. Ensure inspection of seat rails for cracks EACH 50 HOURS. Refer to Section 3.
-
- B 17 Fuel Line and Selector Valve Drain(s) - Remove plug and drain.
-
- D 1 Brakes, Master Cylinders, and Parking Brake - Check master cylinders and parking brake mechanism for condition and security. Check fluid level and test operation of toe and parking brake.
-
- D 2 Main Gear Tubular Struts - Inspect for cracks, dents, corrosion, condition of paint or other damage. Check axles for condition and security.
-
- D 4 Wheels, Brake Discs, and Linings - Inspect for wear, cracks, warps, dents, or other damage. Check wheel through-bolts and nuts for looseness.
-
- D 5 Tires - Check tread wear and general condition. Check for proper inflation.
-
- D 6 Main Landing Gear Strut-to-Pivot Attachment - Check for damage, cracks, loose rivets, bolts and nuts and security of attachment.
-
- D 7 Nose Gear Steering Mechanism - Check for wear, security, and proper rigging.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 2

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

D 8 Nose Gear - Inspect torque links, steering rods, and boots for condition and security of attachment. Check strut for evidence of leakage and proper extension. Check strut barrel for corrosion, pitting, and cleanliness. Check shimmy damper and/or bungees for operation, leakage, and attach points for wear and security.

D 9 Nose Gear Fork - Inspect for cracks, general condition, and security of attachment.

D 11 Nose Gear Attachment Structure - Inspect for cracks, corrosion, or other damage and security of attachment.

D 12 Landing Gear - Perform five fault-free cycles.

NOTE: The airplane must be placed on jacks before inspection of landing gear retraction system. An external power source of at least 60 amperes should be used in place of the airplane battery while operating the system.

D 13 Main Landing Gear - Check downlock engagement.

D 14 Landing Gear System - Check adjustment of main and nose gear up and down switches, and operation of gear position indicator.

D 15 Throttle Operated Gear Warning System - Check condition of wiring and security of components. Perform rigging check (refer to Figure 5-8).

D 16 Nose Gear Doors and Linkage - Check for .25 inch minimum clearance throughout up and down cycles, and proper fit when closed. Check linkage for wear, damaged bearings, distortion, and superficial damage.

D 17 Hydraulic System - Check all components for leaks and external damage to components or mounting structure.

D 19 Powerpack - Clean self relieving check valve filter.

D 22 Powerpack - Perform hydraulic pressure checks of primary relief valve, thermal relief valve, and pressure switch. Can be operationally pressure checked in the aircraft without power pack removal from aircraft (refer to paragraph 5-6A). To determine if relief valve disassembly or adjustment is necessary, relief valves can be bench checked after removal from power pack (refer to paragraph 5-12A).

J 1 Cowling and Cowl Flaps - Inspect for cracks, dents, and other damage, security of cowl fasteners, and cowl mounted landing lights for attachment. Check cowl flaps for condition, security, and operation.

J 2 Engine - Inspect for evidence of oil and fuel leaks. Wash engine and check for security of accessories.

J 3 Cowl Flap Controls - Check freedom of movement through full travel.

J 4 Engine Propeller Controls, and Linkage - Check general condition, freedom of movement through full range. Check for proper travel, security of attachment, and for evidence of wear. Check friction locks for proper operation.

J 8 Induction System - Check security of clamps, tubes, and ducting. Inspect for evidence of leakage.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 2

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

-
- J 11 Alternate Induction Air System - Check for obstructions, operation, and security.
-
- J 12 Alternator and Electrical Connections - Check condition and security of alternator and support brackets. Check alternator belts for condition and proper adjustment.
-
- J 15 Oil Cooler - Check for obstructions, leaks, and security of attachment.
-
- J 16 Exhaust System - Inspect couplings, seals and expansion joints for cracks and security. Air leak check exhaust system. Refer to Sections 12 and 12A, Paragraphs 12-98 and 12A-102, for inspection procedures.
-
- J 17 Exhaust System (turbocharged engine) - Inspect couplings, seals, clamps, and expansion joints for cracks. Air leak check exhaust stem and security. Refer to Sections 12 and 12A, Paragraphs 12-98 and 12A-102, for inspection procedures.
-
- J 27 Hoses, Metal Lines, and Fittings - Inspect for signs of oil and fuel leaks. Check for abrasions, chafing, security, proper routing and support and for evidence of deterioration.
-
- J 30 Engine Baffles and Seals - Check condition and security of attachment.
-
- J 32 Turbocharger -
a. Inspect turbocharger mounting brackets, ducting, linkage, and attaching parts for general condition, leakage or damage, and security of attachment.
b. Check waste gate, actuator, controller, oil and vent lines, overboost relief valve, and compressor housing for leakage, apparent damage, security of attachment, and evidence of wear. Check waste gate return spring for condition and security.
-
- J 35 Engine Oil Change -
Turbocharged and Normally Aspirated Engines With Oil Filters:
a. Remove and replace short oil filter (approximately 4.8 inches long).
b. Add recommended grade aviation oil to replace oil lost in existing filter.
-
- J 37 Engine Oil Change -
Normally Aspirated Engines Without Oil Filters:
a. Engine Oils Without Oil Filter - Drain oil sump and oil cooler, Clean and inspect screens, and refill with recommended grade aviation oil.
-
- K 4 Fuel Tank Drains - Drain water and sediment.
-
- K 6 Fuel Selector Valve - Check controls for detent in each position, security of attachment, and for proper placards.
-
- L 1 Propeller Governor and Control - Inspect for oil and grease leaks. If leakage is evident, refer to McCauley Service Manual.
-
- L 2 Propeller Mounting - Check for security of installation.
-
- L 3 Propeller Blades - Inspect for cracks, dents, nicks, scratches, erosion, corrosion, or other damage.
-
- L 4 Spinner - Check general condition and attachment.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 2

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

M 4 Pitot Tube and Stall Warning Vane - Check for condition and obstructions.

M 5 Pitot Tube Heater Element - Perform operational check.

M 6 Propeller Anti-ice Slip Rings, Brushes and Boots - Inspect for condition, and security. Perform operational check.

N 1 Vacuum System - Inspect for condition and security.

N 2 Vacuum System Hoses - Inspect for hardness, deterioration, looseness, or collapsed hoses.

N 4 Vacuum System Air Filter - Inspect for damage, deterioration and contamination. Clean or replace, if required.

NOTE: Smoking will cause premature filter clogging.

N 5 Vacuum System relief Valve - Inspect for condition and security.

N 6 Instruments - Check general condition and markings for legibility.

O 2 Instrument, Cabin, Navigation, Beacon, Strobe, and Landing Lights - Check operation, condition of lens, and security of attachment.

O 3 Circuit Breakers and Fuses - Check operation and condition. Check for required number of spare fuses.

Q 1 Brakes - Test toe brakes and parking brake for proper operation.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 2

SPECIAL INSPECTION AND YEARLY ITEMS

HOURS YEARS

INSPECTION
COMPLETED BY

Please review each of these items for required compliance

B	1	Fuselage Surface - Inspect for skin damage, loose rivets, condition of paint, and check pitot-static ports and drain holes for obstruction. Inspect covers and fairings for security.	A	
B	2	Internal Fuselage Structure - Inspect bulkheads, doorposts, stringers, doublers, and skins for corrosion, cracks, buckles, and loose rivets, bolts and nuts.	B	
B	10	Windows, Windshield, Doors, and Seals - Inspect general condition. Check latches, hinges, and seals for condition, operation, and security of attachment.		
B	11	Upholstery, Headliner, Trim, and Carpeting - Check condition and clean as required.	EACH 400	EACH 1
D	3	Brake Lines, Wheel Cylinders, Hoses, Clamps, and Fittings - Check for leaks, condition, and security and hoses for bulges and deterioration. Check brake lines and hoses for proper routing and support. (See Cessna SEB92-8)	EACH 400	EACH 1
D	6	Main Landing Gear Strut-to-Pivot Attachment - Check for damage, cracks, loose rivets, bolts and nuts and security of attachment.		
D	10	Wheel Bearings - Clean, inspect and lube.	C	
D	20	Powerpack - Hydraulic fluid contamination check.	D	
D	21	Powerpack - Check condition and wear of brushes in servomotor.	E	
D	23	Landing Gear System - Overhaul main gear downlock actuators, main and nose gear actuators, landing gear selector valve, emergency hand pump, and pressure switch. Replace all rubber goods.		F
D	24	Brake System - Overhaul brake discs, parking brake system, wheel cylinders, and master cylinders. Replace brake pads and all rubber goods.		F
E	4	Autopilot Rigging - Check per Avionics Installation Manual.	G	EACH 1
H	5	Elevator Trim Tab Actuator - Clean, lubricate, and check free-play.	H	
J	4	Engine Propeller Controls, and Linkage - Check general condition, freedom of movement through full range. Check for proper travel, security of attachment, and for evidence of wear. Check friction locks for proper operation.	G	I
J	10	Induction Air Filter - Remove and clean, inspect for damage, and service per paragraph 2-21.	J	
J	12	Alternator and Electrical Connections - Check condition and security of alternator and support brackets. Check alternator belts for condition and proper adjustment.	K	
J	13	Alternator - Check brushes, leads, commutator or slip ring for wear.	L	
J	20	Magnetos - Check external condition, security, and electrical leads for condition. Check timing to engine and internal timing if engine timing requires adjustment.	M	
J	21	Magnetos - Timing Procedures and intervals, lubrication, and overhaul procedures.	N	
J	27	Hoses, Metal Lines, and Fittings - Inspect for signs of oil and fuel leaks. Check for abrasions, chafing, security, proper routing and support and for evidence of deterioration.		O

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 2

INSPECTION
COMPLETED BY

SPECIAL INSPECTION AND YEARLY ITEMS

HOURS YEARS

Please review each of these items for required compliance

J	32 Turbocharger - a. Inspect turbocharger mounting brackets, ducting, linkage, and attaching parts for general condition, leakage or damage, and security of attachment. b. Check waste gate, actuator, controller, oil and vent lines, overboost relief valve, and compressor housing for leakage, apparent damage, security of attachment, and evidence of wear. Check waste gate return spring for condition and security.	P		
J	33 Turbocharger - a. Remove heat shields and inspect for burned areas, bulges or cracks. Remove tailpipe and ducting - Inspect turbine for coking, carbonization, oil deposits, and turbine impellers for damage.	P		
J	35 Engine Oil Change - Turbocharged and Normally Aspirated Engines With Oil Filters: a. Remove and replace short oil filter (approximately 4.8 inches long). b. Add recommended grade aviation oil to replace oil lost in existing filter.	O		
J	37 Engine Oil Change - Normally Aspirated Engines Without Oil Filters: a. Engine Oils Without Oil Filter - Drain oil sump and oil cooler, Clean and inspect screens, and refill with recommended grade aviation oil.	O		
K	2 Integral Fuel Tanks - Drain fuel and check tank interior and outlet screens.	R		
K	9 Fuel Quantity Indicators - Check for damage, security of installation, and perform accuracy test.		EACH 1	
L	9 Propeller Assembly - Overhaul.	S		
M	1 Ventilation System - Inspect clamps, hoses, and valves for condition and security.	400	EACH 1	
M	9 Oxygen Cylinder - Inspect for condition, check hydrostatic test date and perform hydrostatic test, if due.		EACH 5	
N	4 Vacuum System Air Filter - Inspect for damage, deterioration and contamination. Clean or replace, if required. NOTE: Smoking will cause premature filter clogging.	T		
N	5 Vacuum System relief Valve - Inspect for condition and security.	U		
N	10 Airspeed Indicator, Vertical Speed Indicator, and Magnetic Compass - Calibrate.		EACH 2	
N	11 Altimeter and Static System - Inspect in accordance with FAR Part 91.411.		EACH 2	
O	4 Battery - Check general condition and security. Check level of electrolyte.	V		
P	1 Replace all fairings, doors, and access hole covers - Ground check engine, alternator charging rate, oil pressure, tachometer, oil temperature and pressure gages, and general operation of components.			
R	1 Check that all applicable Cessna Service Bulletins, and Supplier Service Bulletins are complied with.			
R	2 Check that all applicable Airworthiness Directives, and Federal Aviation Regulations are complied with.			

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 2

SPECIAL INSPECTION AND YEARLY ITEMS

Please review each of these items for required compliance

HOURS YEARS

INSPECTION
COMPLETED BY

- | | | | | | |
|---|---|--|--|--|--|
| R | 3 | Ensure all Maintenance Record Entries required by Federal Aviation Regulations are completed before returning the airplane to service. | | | |
|---|---|--|--|--|--|

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 2

Special Inspections Legends:

- A. First 12,000 hours and each 1000 hours thereafter: Check fuselage skins adjacent to cabin windows, emergency exit door and main cabin door for cracks. Check emergency exit door for cracks. Check de-ice light lens for cracks.
First 10,000 hours and every 500 hours thereafter: Check belly skins for cracks and failed rivets. Check main cabin door hinges for failed screws. Check emergency exit door jamb for cracks.
First 6000 hours and each 200 hours thereafter: Check main cabin door jamb for cracks.
First 4000 hours and each 200 hours thereafter: Check main cabin door fillet for cracks and rivet failure.
- B. First 10,000 hours and each 500 hours thereafter: Check bulkhead at sta. 55, 80, and 90 for cracks.
First 12,000 hours and each 1000 hours thereafter: Check bulkheads at sta. 8, 27, 35, 103 and aft pressure bulkhead for cracks.
First 11,000 hours and each 3000 hours thereafter: Check front carry-thru spar and front doorpost intersection for cracks and rivet failure.
First 4000 hours and each 200 hours thereafter: Check instrument panel and bulkhead at sta. 18 for cracks and rivet failure.
- C. First 100 hours and each 500 hours thereafter. More often if operated under prevailing wet or dusty conditions.
- D. At the first 50 hours, first 100 hours, and each 500 hours thereafter, or one year, whichever comes first.
- E. Each 500 hours, and whenever improper operation is suspected. Replace brushes when worn to .25 inch or less.
- F. Overhaul components and replace rubber goods on-condition basis.
- G. Each 600 hours or 1 year, whichever comes first.
- H. Lubrication of the actuator is required each 1000 hours or 3 years, whichever comes first. Refer to figure 2-5 for grease specification.
- I. Lubricate each 100 hours (except in extreme dusty conditions). These controls are not repairable and should be replaced every 1500 hours or sooner if required.
- J. Clean filter per paragraph 2-21. Replace paper filters at least each 500 hours.
- K. Check belt tension after 10 to 25 hours of operation. Refer to Section 17.
- L. Inspect each 500 hours.
- M. At the first 25 hours, first 50 hours, first 100 hours, and each 100 hours thereafter, the contact breaker point compartment and magneto-to-engine timing should be inspected and checked. If magneto-to-engine timing is correct within plus zero to minus two degrees, internal timing need not be checked. If timing is out of tolerance, remove magneto from engine. Detailed Maintenance and Overhaul Information covering Slick magnetos is available from Cessna Supply Division. Order 1037C1-13 for 4200/6200 series magnetos.
- N. Every 500 hours of operation, perform the following items:
 - a. Inspect contact points for condition and adjust or replace as required.
 - b. Inspect carbon brush, high-tension lead, and distributive block for condition. Clean or replace parts as required.
 - c. Inspect impulse coupling and pawls for condition and replace as required. Use light pressure only. **Do not force** when checking pawls.
 - d. Inspect and lubricate bearings; replace as required.
 - e. Lubricate contact point cam.The magnetos **must** be overhauled or replaced with new or rebuilt magnetos at every engine overhaul.
- O. Replace engine compartment rubber hoses (Cessna installed only) every 5 years, or at engine overhaul, whichever occurs first. This does not include drain hoses. Hoses which are beyond these limits, and are in a serviceable condition, must be placed on order immediately and then be replaced within 120 days after receiving the new hoses(s) from Cessna. Replace drain hoses on condition. Engine flexible hoses (Continental Motors installed): refer to Continental Motors Maintenance Manual and Continental Motor Engine Service Bulletins.
- P. Replace check valves in turbocharger oil lines each 1000 hours.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 2

- Q. First 25 hours: Use MIL-L-6082 Aviation grade straight mineral oil to replenish supply. After first 25 hours: Drain sump and remove and replace filter. Refill sump with recommended grade of ashless dispersant oil. Change oil and replace filter at least every six months, regardless of accumulated hours.
- R. Each 1000 hours.
- S. See McCauley Service Manual; refer to list of publication.
- T. Replace every 500 hours.
- U. Replace filter each 100 hours.
- V. Check electrolyte level and clean battery box each 100 hours or 90 days.
- W. Overhaul or replace Dukes Electrical Fuel Boost Pump at 10 years. Refer to Dukes Mandatory Service Bulletin No. 0003.
- X. Each 100 hours or whenever fuel flow fluctuation is encountered, inspect fuel manifold valves, valve covers, and fuel system components and lines for signs of leaks. Refer to Teledyne Continental Motors Service Bulletin SB95-7.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 3

Registration No. _____

Airplane Model and SN _____

Airplane Time _____

INSPECTION COMPLETED BY _____

- B 13 Aileron, Elevator, and Rudder Stops - Check for damage and security.
- B 15 Seat Tracks and Stops - Inspect seat tracks for condition and security of installation. Check seat track stops for damage and correct location. Ensure inspection of seat rails for cracks EACH 50 HOURS. Refer to Section 3.
- C 1 Wing Surfaces and Tips - Inspect for skin damage, loose rivets, and condition of paint.
- C 2 Wing Spar Fittings - Check for evidence of wear. Check attach bolts for indications of looseness and retorquing as required.
- C 3 Wing Structure - Inspect spars, ribs, skins, and stringers for cracks, wrinkles, loose rivets, corrosion, or other damage.
- C 4 Metal Lines, Hoses, Clamps, and Fittings - Check for leaks, condition, and security. Check for proper routing and support.
- C 5 Wing Access Plates - Check for damage and security of installation.
- C 6 Vertical and Horizontal Stabilizers, Tips and Tailcone - Inspect externally for skin damage and condition of paint.
- C 7 Vertical and Horizontal Stabilizers and Tailcone structure - Inspect bulkheads, spars, ribs, and skins for cracks, wrinkles, loose rivets, corrosion, or other damage. Inspect vertical and horizontal stabilizer attach bolts for looseness. Retorque as necessary. Check security of inspection covers, fairings, and tips.
- E 1 Ailerons, Hinges - Check condition, security and operation.
- E 2 Aileron Structure, Control Rods, Hinges, Balance Weights, Bellcranks, Linkage, Bolts, Pulleys, and Pulley Brackets - Check condition, operation, and security of attachment.
- E 3 Ailerons and Cables - Check operation and security of stops. Check cables for tension, routing, fraying, corrosion, and turnbuckle safety. Check travel if cable tension requires adjustment or if stops are damaged. Check fairleads and rub strips for condition.
- E 5 Aileron Controls - Check freedom of movement and proper operation through full travel with and without flaps extended.
- F 1 Flaps - Check tracks, rollers, and control rods for security of attachment. Check rod end bearings for corrosion and lubricate. Check operation.
- F 2 Flap Actuator Threads - Clean and lubricate. Refer to paragraph 2-47 for detailed instructions.
- F 3 Flap Structure, Linkage, Bellcranks, Pulleys, and Pulley Brackets - Check for condition, operation and security.
- F 4 Wing Flap Control - Check operation through full travel and observe Flap Position indicator for proper indication.
- F 5 Flaps and Cables - Check cables for proper tension, routing, fraying, corrosion, and turnbuckle safety. Check travel if cable tension requires adjustment.
- F 6 Flap Motor, Actuator, and Limit Switches (electric flaps) - Check wiring and terminals for condition and security. Check actuator for condition and security.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 3

Registration No. _____ Airplane Model and SN _____ Airplane Time _____

INSPECTION COMPLETED BY _____

- | | | |
|---|----|--|
| G | 1 | Elevator Control - Check freedom of movement and proper operation through full travel with and without flaps extended. |
| G | 2 | Elevator, Hinges, and Cable Attachment - Check condition, security, and operation. |
| G | 4 | Elevator Arm - Check bolts, linkage, and push-pull tube for condition, operation, and security. Check travels if cables require tension adjustment or if stops are damaged. |
| H | 1 | Elevator Trim Tab and Hinges - Check condition, security, and operation. |
| H | 2 | Elevator Trim System - Check cables, push-pull rods, bellcranks, pulleys, turnbuckles, fairleads, rub strips, etc. for proper routing, condition, and security. |
| H | 4 | Elevator Trim Tab Stop Blocks - Inspect for damage and security. |
| H | 6 | Elevator Trim Tab Actuator - Free-Play limits inspection. (Refer to Section 9-14). |
| I | 1 | Rudder - Inspect the rudder skins for cracks and loose rivets, rudder hinges for condition, cracks and security; hinge bolts, hinge bearings, hinge attach fittings, and bonding jumper for evidence of damage and wear, failed fasteners, and security. Inspect the rudder hinge bolts for proper safetying of nuts with cotter pins. Inspect balance weight for looseness and the supporting structure for damage. |
| I | 3 | Rudder Tips, Hinges, Stop Bolts, Clips, and Cable Attachments - Check condition, security, and operation. |
| I | 4 | Rudder - Check internal surfaces for corrosion, condition of fasteners, and balance weight attachment. |
| J | 1 | Cowling and Cowl Flaps - Inspect for cracks, dents, and other damage, security of cowl fasteners, and cowl mounted landing lights for attachment. Check cowl flaps for condition, security, and operation. |
| J | 2 | Engine - Inspect for evidence of oil and fuel leaks. Wash engine and check for security of accessories. |
| J | 3 | Cowl Flap Controls - Check freedom of movement through full travel. |
| J | 4 | Engine Propeller Controls, and Linkage - Check general condition, freedom of movement through full range. Check for proper travel, security of attachment, and for evidence of wear. Check friction locks for proper operation. |
| J | 5 | Ignition Switch and Electrical Harness - Inspect for damage, condition, and security. |
| J | 8 | Induction System - Check security of clamps, tubes, and ducting. Inspect for evidence of leakage. |
| J | 9 | Induction Airbox, Valves, Doors, and Controls - Remove air filter and inspect hinges, doors, seals, and attaching parts for wear and security. Check operation. Clean and inspect air filter and re-oil if flock-coated. |
| J | 10 | Induction Air Filter - Remove and clean, inspect for damage, and service per paragraph 2-21. |
| J | 11 | Alternate Induction Air System - Check for obstructions, operation, and security. |

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 3

Registration No. _____ Airplane Model and SN _____ Airplane Time _____

INSPECTION COMPLETED BY _____

- | | | |
|---|----|--|
| J | 12 | Alternator and Electrical Connections - Check condition and security of alternator and support brackets. Check alternator belts for condition and proper adjustment. |
| J | 14 | Starter, Starter Solenoid, and Electrical Connections - Check for condition of starter brushes, brush leads, and commutator. |
| J | 15 | Oil Cooler - Check for obstructions, leaks, and security of attachment. |
| J | 16 | Exhaust System - Inspect couplings, seals and expansion joints for cracks and security. Air leak check exhaust system. Refer to Sections 12 and 12A, Paragraphs 12-98 and 12A-102, for inspection procedures. |
| J | 17 | Exhaust System (turbocharged engine) - Inspect couplings, seals, clamps, and expansion joints for cracks. Air leak check exhaust stem and security. Refer to Sections 12 and 12A, Paragraphs 12-98 and 12A-102, for inspection procedures. |
| J | 18 | Auxiliary (Electric) Fuel Pump - Check pump and fittings for condition, operation, security. Remove and clean filter (as applicable). |
| J | 19 | Engine Driven Fuel Pump - Check for evidence of leakage, security of attachment, and general condition. |
| J | 20 | Magnetos - Check external condition, security, and electrical leads for condition. Check timing to engine and internal timing if engine timing requires adjustment. |
| J | 22 | Ignition Harness and Insulators - Check for proper routing, deterioration, and condition of terminals. |
| J | 23 | Spark Plugs - Remove, clean analyze, test, gap, and rotate top plugs-to-bottom and bottom plugs-to-top. |
| J | 25 | Fuel Injection System - Check security of fuel-air control unit, manifold valve, nozzles, screws and pump. Check fuel lines for leaks, interference, and proper routing. |
| J | 26 | Engine Primer - Check for leakage, operation, and security. |
| J | 27 | Hoses, Metal Lines, and Fittings - Inspect for signs of oil and fuel leaks. Check for abrasions, chafing, security, proper routing and support and for evidence of deterioration. |
| J | 28 | Cold and Hot Air Hoses - Check condition, routing, and security. |
| J | 29 | Engine Cylinders, Rocker Box Covers, and Pushrod Housings - Check for fin damage, cracks, oil leakage, security of attachment, and general condition. |
| J | 30 | Engine Baffles and Seals - Check condition and security of attachment. |
| J | 31 | Crankcase, Oil Sump, and Accessory Section - Inspect for cracks and evidence of oil leakage. Check bolts and nuts for looseness and retorque as necessary. Check crankcase breather lines for obstructions, security, and general condition. |

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 3

Registration No. _____ Airplane Model and SN _____ Airplane Time _____

INSPECTION COMPLETED BY _____

-
- J 32 Turbocharger -
- a. Inspect turbocharger mounting brackets, ducting, linkage, and attaching parts for general condition, leakage or damage, and security of attachment.
 - b. Check waste gate, actuator, controller, oil and vent lines, overboost relief valve, and compressor housing for leakage, apparent damage, security of attachment, and evidence of wear. Check waste gate return spring for condition and security.
-
- J 34 Heater Components - Inspect all components for condition and security.
-
- J 35 Engine Oil Change - Turbocharged and Normally Aspirated Engines With Oil Filters:
- a. Remove and replace short oil filter (approximately 4.8 inches long).
 - b. Add recommended grade aviation oil to replace oil lost in existing filter.
-
- J 37 Engine Oil Change - Normally Aspirated Engines Without Oil Filters:
- a. Engine Oils Without Oil Filter - Drain oil sump and oil cooler, Clean and inspect screens, and refill with recommended grade aviation oil.
-
- K 1 Integral Fuel Tanks - Check for evidence of leakage and condition of fuel caps, adapters, and placards.
-
- K 3 Fuel System - Inspect plumbing and components for mounting and security.
-
- K 4 Fuel Tank Drains - Drain water and sediment.
-
- K 5 Fuel Tank Vent Lines and Vent Valves - Check vents for obstruction and proper positioning. Check valves for operation.
-
- K 7 Throttle - Operated Auxiliary Fuel Pump Switch. Check condition of wiring and security of components. Perform rigging check (refer to Paragraph 13-35).
-
- K 8 Fuel Strainer, Drain Valve, and Controls - Check freedom of movement, security, and proper operation. Disassemble, flush, and clean screen and bowl.
-
- L 1 Propeller Governor and Control - Inspect for oil and grease leaks. If leakage is evident, refer to McCauley Service Manual.
-
- L 2 Propeller Mounting - Check for security of installation.
-
- L 3 Propeller Blades - Inspect for cracks, dents, nicks, scratches, erosion, corrosion, or other damage.
-
- L 4 Spinner - Check general condition and attachment.
-
- L 5 Spinner and Spinner Bulkhead - Remove spinner, wash, and inspect for cracks and fractures.
-
- M 2 Heater Components, Inlets, and Outlets - Inspect all lines, connections, ducts, clamps, seals, and gaskets for condition, restriction, and security.
-
- M 4 Pitot Tube and Stall Warning Vane - Check for condition and obstructions.
-
- M 5 Pitot Tube Heater Element - Perform operational check.
-
- M 6 Propeller Anti-ice Slip Rings, Brushes and Boots - Inspect for condition, and security. Perform operational check.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 3

Registration No. _____

Airplane Model and SN _____

Airplane Time _____

INSPECTION COMPLETED BY _____

-
- N 3 Vacuum Pump - Check for condition and security. Check vacuum system breather line for obstructions, condition, and security
-
- O 5 Battery Box and Cables - Clean and remove any corrosion. Check cables for routing, support, and security of connections.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 3

SPECIAL INSPECTION AND YEARLY ITEMS

HOURS YEARS

INSPECTION
COMPLETED BY

Please review each of these items for required compliance

B	1	Fuselage Surface - Inspect for skin damage, loose rivets, condition of paint, and check pitot-static ports and drain holes for obstruction. Inspect covers and fairings for security.	A	
B	2	Internal Fuselage Structure - Inspect bulkheads, doorposts, stringers, doublers, and skins for corrosion, cracks, buckles, and loose rivets, bolts and nuts.	B	
B	10	Windows, Windshield, Doors, and Seals - Inspect general condition. Check latches, hinges, and seals for condition, operation, and security of attachment.		
B	11	Upholstery, Headliner, Trim, and Carpeting - Check condition and clean as required.	EACH 400	EACH 1
D	3	Brake Lines, Wheel Cylinders, Hoses, Clamps, and Fittings - Check for leaks, condition, and security and hoses for bulges and deterioration. Check brake lines and hoses for proper routing and support. (See Cessna SEB92-8)	EACH 400	EACH 1
D	6	Main Landing Gear Strut-to-Pivot Attachment - Check for damage, cracks, loose rivets, bolts and nuts and security of attachment.		
D	10	Wheel Bearings - Clean, inspect and lube.	C	
D	20	Powerpack - Hydraulic fluid contamination check.	D	
D	21	Powerpack - Check condition and wear of brushes in servomotor.	E	
D	23	Landing Gear System - Overhaul main gear downlock actuators, main and nose gear actuators, landing gear selector valve, emergency hand pump, and pressure switch. Replace all rubber goods.		F
D	24	Brake System - Overhaul brake discs, parking brake system, wheel cylinders, and master cylinders. Replace brake pads and all rubber goods.		F
E	4	Autopilot Rigging - Check per Avionics Installation Manual.	G	EACH 1
H	5	Elevator Trim Tab Actuator - Clean, lubricate, and check free-play.	H	
J	4	Engine Propeller Controls, and Linkage - Check general condition, freedom of movement through full range. Check for proper travel, security of attachment, and for evidence of wear. Check friction locks for proper operation.	G	I
J	10	Induction Air Filter - Remove and clean, inspect for damage, and service per paragraph 2-21.	J	
J	12	Alternator and Electrical Connections - Check condition and security of alternator and support brackets. Check alternator belts for condition and proper adjustment.	K	
J	13	Alternator - Check brushes, leads, commutator or slip ring for wear.	L	
J	20	Magnetos - Check external condition, security, and electrical leads for condition. Check timing to engine and internal timing if engine timing requires adjustment.	M	
J	21	Magnetos - Timing Procedures and intervals, lubrication, and overhaul procedures.	N	
J	27	Hoses, Metal Lines, and Fittings - Inspect for signs of oil and fuel leaks. Check for abrasions, chafing, security, proper routing and support and for evidence of deterioration.		O

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 3

SPECIAL INSPECTION AND YEARLY ITEMS

HOURS YEARS

INSPECTION
COMPLETED BY

Please review each of these items for required compliance

J	32 Turbocharger - a. Inspect turbocharger mounting brackets, ducting, linkage, and attaching parts for general condition, leakage or damage, and security of attachment. b. Check waste gate, actuator, controller, oil and vent lines, overboost relief valve, and compressor housing for leakage, apparent damage, security of attachment, and evidence of wear. Check waste gate return spring for condition and security.	P		
J	33 Turbocharger - a. Remove heat shields and inspect for burned areas, bulges or cracks. Remove tailpipe and ducting - Inspect turbine for coking, carbonization, oil deposits, and turbine impellers for damage.	P		
J	35 Engine Oil Change - Turbocharged and Normally Aspirated Engines With Oil Filters: a. Remove and replace short oil filter (approximately 4.8 inches long). b. Add recommended grade aviation oil to replace oil lost in existing filter.	O		
J	37 Engine Oil Change - Normally Aspirated Engines Without Oil Filters: a. Engine Oils Without Oil Filter - Drain oil sump and oil cooler, Clean and inspect screens, and refill with recommended grade aviation oil.	O		
K	2 Integral Fuel Tanks - Drain fuel and check tank interior and outlet screens.	R		
K	9 Fuel Quantity Indicators - Check for damage, security of installation, and perform accuracy test.		EACH 1	
L	9 Propeller Assembly - Overhaul.	S		
M	1 Ventilation System - Inspect clamps, hoses, and valves for condition and security.	400	EACH 1	
M	9 Oxygen Cylinder - Inspect for condition, check hydrostatic test date and perform hydrostatic test, if due.		EACH 5	
N	4 Vacuum System Air Filter - Inspect for damage, deterioration and contamination. Clean or replace, if required. NOTE: Smoking will cause premature filter clogging.	T		
N	5 Vacuum System relief Valve - Inspect for condition and security.	U		
N	10 Airspeed Indicator, Vertical Speed Indicator, and Magnetic Compass - Calibrate.		EACH 2	
N	11 Altimeter and Static System - Inspect in accordance with FAR Part 91.411.		EACH 2	
O	4 Battery - Check general condition and security. Check level of electrolyte.	V		
P	1 Replace all fairings, doors, and access hole covers - Ground check engine, alternator charging rate, oil pressure, tachometer, oil temperature and pressure gages, and general operation of components.			
R	1 Check that all applicable Cessna Service Bulletins, and Supplier Service Bulletins are complied with.			
R	2 Check that all applicable Airworthiness Directives, and Federal Aviation Regulations are complied with.			

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 3

SPECIAL INSPECTION AND YEARLY ITEMS

HOURS YEARS

INSPECTION
COMPLETED BY

Please review each of these items for required compliance

- | | HOURS | YEARS | INSPECTION COMPLETED BY |
|--|-------|-------|-------------------------|
| R 3 Ensure all Maintenance Record Entries required by Federal Aviation Regulations are completed before returning the airplane to service. | | | |

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 3

Special Inspections Legends:

- A. First 12,000 hours and each 1000 hours thereafter: Check fuselage skins adjacent to cabin windows, emergency exit door and main cabin door for cracks. Check emergency exit door for cracks. Check de-ice light lens for cracks.
First 10,000 hours and every 500 hours thereafter: Check belly skins for cracks and failed rivets. Check main cabin door hinges for failed screws. Check emergency exit door jamb for cracks.
First 6000 hours and each 200 hours thereafter: Check main cabin door jamb for cracks.
First 4000 hours and each 200 hours thereafter: Check main cabin door fillet for cracks and rivet failure.
- B. First 10,000 hours and each 500 hours thereafter: Check bulkhead at sta. 55, 80, and 90 for cracks.
First 12,000 hours and each 1000 hours thereafter: Check bulkheads at sta. 8, 27, 35, 103 and aft pressure bulkhead for cracks.
First 11,000 hours and each 3000 hours thereafter: Check front carry-thru spar and front doorpost intersection for cracks and rivet failure.
First 4000 hours and each 200 hours thereafter: Check instrument panel and bulkhead at sta. 18 for cracks and rivet failure.
- C. First 100 hours and each 500 hours thereafter. More often if operated under prevailing wet or dusty conditions.
- D. At the first 50 hours, first 100 hours, and each 500 hours thereafter, or one year, whichever comes first.
- E. Each 500 hours, and whenever improper operation is suspected. Replace brushes when worn to .25 inch or less.
- F. Overhaul components and replace rubber goods on-condition basis.
- G. Each 600 hours or 1 year, whichever comes first.
- H. Lubrication of the actuator is required each 1000 hours or 3 years, whichever comes first. Refer to figure 2-5 for grease specification.
- I. Lubricate each 100 hours (except in extreme dusty conditions). These controls are not repairable and should be replaced every 1500 hours or sooner if required.
- J. Clean filter per paragraph 2-21. Replace paper filters at least each 500 hours.
- K. Check belt tension after 10 to 25 hours of operation. Refer to Section 17.
- L. Inspect each 500 hours.
- M. At the first 25 hours, first 50 hours, first 100 hours, and each 100 hours thereafter, the contact breaker point compartment and magneto-to-engine timing should be inspected and checked. If magneto-to-engine timing is correct within plus zero to minus two degrees, internal timing need not be checked. If timing is out of tolerance, remove magneto from engine. Detailed Maintenance and Overhaul Information covering Slick magnetos is available from Cessna Supply Division. Order 1037C1-13 for 4200/6200 series magnetos.
- N. Every 500 hours of operation, perform the following items:
 - a. Inspect contact points for condition and adjust or replace as required.
 - b. Inspect carbon brush, high-tension lead, and distributive block for condition. Clean or replace parts as required.
 - c. Inspect impulse coupling and pawls for condition and replace as required. Use light pressure only. **Do not force** when checking pawls.
 - d. Inspect and lubricate bearings; replace as required.
 - e. Lubricate contact point cam.The magnetos **must** be overhauled or replaced with new or rebuilt magnetos at every engine overhaul.
- O. Replace engine compartment rubber hoses (Cessna installed only) every 5 years, or at engine overhaul, whichever occurs first. This does not include drain hoses. Hoses which are beyond these limits, and are in a serviceable condition, must be placed on order immediately and then be replaced within 120 days after receiving the new hoses(s) from Cessna. Replace drain hoses on condition. Engine flexible hoses (Continental Motors installed): refer to Continental Motors Maintenance Manual and Continental Motor Engine Service Bulletins.
- P. Replace check valves in turbocharger oil lines each 1000 hours.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 3

- Q. First 25 hours: Use MIL-L-6082 Aviation grade straight mineral oil to replenish supply. After first 25 hours: Drain sump and remove and replace filter. Refill sump with recommended grade of ashless dispersant oil. Change oil and replace filter at least every six months, regardless of accumulated hours.
- R. Each 1000 hours.
- S. See McCauley Service Manual; refer to list of publication.
- T. Replace every 500 hours.
- U. Replace filter each 100 hours.
- V. Check electrolyte level and clean battery box each 100 hours or 90 days.
- W. Overhaul or replace Dukes Electrical Fuel Boost Pump at 10 years. Refer to Dukes Mandatory Service Bulletin No. 0003.
- X. Each 100 hours or whenever fuel flow fluctuation is encountered, inspect fuel manifold valves, valve covers, and fuel system components and lines for signs of leaks. Refer to Teledyne Continental Motors Service Bulletin SB95-7.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 4

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

- A 1 Placards and Decals - Inspect presence, legibility, and security. Consult Pilot's Operating Handbook and FAA-Approved Airplane Flight Manual for required placards.

- B 1 Fuselage Surface - Inspect for skin damage, loose rivets, condition of paint, and check pitot-static ports and drain holes for obstruction. Inspect covers and fairings for security.

- B 2 Internal Fuselage Structure - Inspect bulkheads, doorposts, stringers, doublers, and skins for corrosion, cracks, buckles, and loose rivets, bolts and nuts.

- B 3 Control Wheel Lock - Check general condition and operation.

- B 4 Fuselage Mounted Equipment - Check for general condition and security of attachment.

- B 5 Antennas and Cables - Inspect for security of attachment, connection, and condition.

- B 6 Emergency Locator Transmitter - Inspect for security of attachment and check operation by verifying transmitter output. Check cumulative time and useful life of batteries in accordance with FAR Part 91.52. Refer to Section 17 - Operational Test of Emergency Locator Transmitter.

- B 7 Instrument Panel Shock Mounts, Ground Straps, and Covers - Inspect for deterioration, cracks, and security of attachment.

- B 8 Pilot's and Copilot's Inertia Reels - Inspect for security of installation, proper operation, and evidence of damage.

- B 9 Seats, Seat Belts, and Shoulder Harnesses - Check general condition and security. Check operation of seat stops and adjustment mechanism. Inspect belts for condition and security of fasteners.

- B 10 Windows, Windshield, Doors, and Seals - Inspect general condition. Check latches, hinges, and seals for condition, operation, and security of attachment.

- B 12 Flight Controls - Check freedom of movement and proper operation through full travel with and without flaps extended. Check electric trim controls for operation (as applicable.)

- B 14 Portable Hand Fire Extinguisher - Inspect for proper operating pressure, condition, security of installation, and servicing date.

- B 15 Seat Tracks and Stops - Inspect seat tracks for condition and security of installation. Check seat track stops for damage and correct location. Ensure inspection of seat rails for cracks EACH 50 HOURS. Refer to Section 3.

- B 16 Control Column - Inspect pulleys, cables, sprockets, bearings, chains, bungees, and turnbuckles for condition and security.

- B 17 Fuel Line and Selector Valve Drain(s) - Remove plug and drain.

- B 46 Pressurization Outflow Valves and Safety Valves - Inspect for condition and security.

- B 47 Pressurization Electrical Components - Inspect wiring and components for condition and security.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 4

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

-
- B 48 Pressurization Plumbing Components - Inspect for condition, security, and loose connections.
-
- B 49 Pressurization Bleed Air Dump Valves - Inspect for condition, security and smooth operation.
-
- B 49 Pressurization Bleed Air Dump Valves - Inspect for condition, security and smooth operation.
-
- B 50 Pressurization Controls and Units - Inspect for condition and security. Clean and perform operational check.
-
- B 50 Pressurization Controls and Units - Inspect for condition and security. Clean and perform operational check.
-
- D 1 Brakes, Master Cylinders, and Parking Brake - Check master cylinders and parking brake mechanism for condition and security. Check fluid level and test operation of toe and parking brake.
-
- D 2 Main Gear Tubular Struts - Inspect for cracks, dents, corrosion, condition of paint or other damage. Check axles for condition and security.
-
- D 4 Wheels, Brake Discs, and Linings - Inspect for wear, cracks, warps, dents, or other damage. Check wheel through-bolts and nuts for looseness.
-
- D 5 Tires - Check tread wear and general condition. Check for proper inflation.
-
- D 8 Nose Gear - Inspect torque links, steering rods, and boots for condition and security of attachment. Check strut for evidence of leakage and proper extension. Check strut barrel for corrosion, pitting, and cleanliness. Check shimmy damper and/or bungees for operation, leakage, and attach points for wear and security.
-
- D 11 Nose Gear Attachment Structure - Inspect for cracks, corrosion, or other damage and security of attachment.
-
- D 12 Landing Gear - Perform five fault-free cycles.
- NOTE: The airplane must be placed on jacks before inspection of landing gear retraction system. An external power source of at least 60 amperes should be used in place of the airplane battery while operating the system.
-
- D 13 Main Landing Gear - Check downlock engagement.
-
- D 14 Landing Gear System - Check adjustment of main and nose gear up and down switches, and operation of gear position indicator.
-
- D 16 Nose Gear Doors and Linkage - Check for .25 inch minimum clearance throughout up and down cycles, and proper fit when closed. Check linkage for wear, damaged bearings, distortion, and superficial damage.
-
- D 17 Hydraulic System - Check all components for leaks and external damage to components or mounting structure.
-
- D 18 Emergency Hand Pump - Check operation, check lines and components for damage and leaks.
-
- D 19 Powerpack - Clean self-relieving check valve filter.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 4

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

- D 22 Powerpack - Perform hydraulic pressure checks of primary relief valve, thermal relief valve, and pressure switch. Can be operationally pressure checked in the aircraft without power pack removal from aircraft (refer to paragraph 5-6A). To determine if relief valve disassembly or adjustment is necessary, relief valves can be bench checked after removal from power pack (refer to paragraph 5-12A).
-
- G 3 Elevator Control System - Inspect pulleys, cables, sprockets, bearings, chains, and turnbuckles for condition, security, and operation.
-
- H 3 Trim Controls and Indicators - Check freedom of movement and proper operation through full travel. Check pulleys, cables, sprockets, bearings, chains, bungees, and turnbuckles for condition and security. Check electric trim controls for operation as applicable.
-
- I 2 Rudder Pedals and Linkage - Check for general condition, proper rigging, and operation. Check for security of attachment.
-
- J 1 Cowling and Cowl Flaps - Inspect for cracks, dents, and other damage, security of cowl fasteners, and cowl mounted landing lights for attachment. Check cowl flaps for condition, security, and operation.
-
- J 2 Engine - Inspect for evidence of oil and fuel leaks. Wash engine and check for security of accessories.
-
- J 3 Cowl Flap Controls - Check freedom of movement through full travel.
-
- J 4 Engine, Propeller Controls, and Linkage - Check general condition, freedom of movement through full range. Check for proper travel, security of attachment, and for evidence of wear. Check friction locks for proper operation.
-
- J 8 Induction System - Check security of clamps, tubes, and ducting. Inspect for evidence of leakage.
-
- J 11 Alternate Induction Air System - Check for obstructions, operation, and security.
-
- J 12 Alternator and Electrical Connections - Check condition and security of alternator and support brackets. Check alternator belts for condition and proper adjustment.
-
- J 15 Oil Cooler - Check for obstructions, leaks, and security of attachment.
-
- J 16 Exhaust System - Inspect couplings, seals and expansion joints for cracks and security. Air leak check exhaust system. Refer to Section 12 and 12A, Paragraphs 12-98 and 12A-102, for inspection procedures.
-
- J 17 Exhaust System (turbocharged engine) - Inspect couplings, seals, clamps, and expansion joints for cracks. Air leak check exhaust stem and security. Refer to Sections 12 and 12A, Paragraphs 12-98 and 12A-102, for inspection procedures.
-
- J 27 Hoses, Metal Lines, and Fittings - Inspect for signs of oil and fuel leaks. Check for abrasions, chafing, security, proper routing and support and for evidence of deterioration.
-
- J 30 Engine Baffles and Seals - Check condition and security of attachment.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 4

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

-
- J 32 Turbocharger -
- a. Inspect turbocharger mounting brackets, ducting, linkage, and attaching parts for general condition, leakage or damage, and security of attachment.
 - b. Check waste gate, actuator, controller, oil and vent lines, overboost relief valve, and compressor housing for leakage, apparent damage, security of attachment, and evidence of wear. Check waste gate return spring for condition and security.
-
- J 35 Engine Oil Change -
Turbocharged and Normally Aspirated Engines With Oil Filters:
- a. Remove and replace short oil filter (approximately 4.8 inches long).
 - b. Add recommended grade aviation oil to replace oil lost in existing filter.
-
- J 37 Engine Oil Change -
Normally Aspirated Engines Without Oil Filters:
- a. Engine Oils Without Oil Filter - Drain oil sump and oil cooler, clean and inspect screens, and refill with recommended grade aviation oil.
-
- K 4 Fuel Tank Drains - Drain water and sediment.
-
- K 6 Fuel Selector Valve - Check controls for detent in each position, security of attachment, and for proper placarding.
-
- L 1 Propeller Governor and Control - Inspect for oil and grease leaks. If leakage is evident, refer to McCauley Service Manual.
-
- L 2 Propeller Mounting - Check for security of installation.
-
- L 3 Propeller Blades - Inspect for cracks, dents, nicks, scratches, erosion, corrosion, or other damage.
-
- L 4 Spinner - Check general condition and attachment.
-
- M 3 Cabin Heat and Ventilation Controls - Check freedom of movement through full travel. Check friction locks for proper operation.
-
- M 4 Pitot Tube and Stall Warning Vane - Check for condition and obstructions.
-
- M 5 Pitot Tube Heater Element - Perform operational check.
-
- M 6 Propeller Anti-ice Slip Rings, Brushes and Boots - Inspect for condition, and security. Perform operational check.
-
- M 7 Heated Windshield Panel - Check operation, security of installation, electrical wiring, and condition of storage bag.
-
- M 8 Oxygen System - Inspect masks, hoses, lines, and fittings for condition, routing, and support. Test operation and check for leaks.
-
- N 1 Vacuum System - Inspect for condition and security.
-
- N 2 Vacuum System Hoses - Inspect for hardness, deterioration, looseness, or collapsed hoses.
-
- N 4 Vacuum System Air Filter - Inspect for damage, deterioration and contamination. Clean or replace, if required.

NOTE: Smoking will cause premature filter clogging.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 4

Registration No. _____ Airplane Model and SN _____ Airplane Time _____
INSPECTION COMPLETED BY _____

-
- | | | |
|---|---|--|
| N | 5 | Vacuum System relief Valve - Inspect for condition and security. |
|---|---|--|
-
- | | | |
|---|---|--|
| N | 6 | Instruments - Check general condition and markings for legibility. |
|---|---|--|
-
- | | | |
|---|---|---|
| N | 7 | Instrument Lines, Fittings, Ducting, and Instrument Panel Wiring - Check for proper routing, support, and security of attachment. |
|---|---|---|
-
- | | | |
|---|---|--|
| N | 8 | Static System - Inspect for security of installation, cleanliness, and evidence of damage. |
|---|---|--|
-
- | | | |
|---|---|---|
| N | 9 | Navigation Indicators, Controls, and Components - Inspect for condition and security. |
|---|---|---|
-
- | | | |
|---|----|--|
| N | 12 | Instrument Panel Mounted Avionics Units (Including Audio Panel, VHF Nav/Com(s), ADF, Transponder, DME, and Compass System - Inspect for deterioration, cracks, and security of instrument panel mounts. Inspect for security of electrical connections, condition, and security of wire routing. |
|---|----|--|
-
- | | | |
|---|----|---|
| N | 13 | Avionics Operating Controls - Inspect for security and proper operation of controls and switches and ensure that all digital segments will illuminate properly. |
|---|----|---|
-
- | | | |
|---|----|---|
| N | 14 | Remote Mounted Avionics - Inspect for security of units and electrical connectors, condition and security of wire routing. Also check for evidence of damage and cleanliness. |
|---|----|---|
-
- | | | |
|---|----|---|
| N | 15 | Microphones, Headsets, and Jacks - Inspect for cleanliness, security, and evidence of damage. |
|---|----|---|
-
- | | | |
|---|---|---|
| O | 1 | General Airplane and System Wiring - Inspect for proper routing, chafing, broken or loose terminals, general condition, broken or inadequate clamps, and sharp bends in wiring. |
|---|---|---|
-
- | | | |
|---|---|---|
| O | 2 | Instrument, Cabin, Navigation, Beacon, Strobe, and Landing Lights - Check operation, condition of lens, and security of attachment. |
|---|---|---|
-
- | | | |
|---|---|---|
| O | 3 | Circuit Breakers and Fuses - Check operation and condition. Check for required number of spare fuses. |
|---|---|---|
-
- | | | |
|---|---|--|
| O | 6 | Switch and Circuit Breaker Panel, Terminal Blocks, and Junction Boxes - Inspect wiring and terminals for condition and security. |
|---|---|--|
-
- | | | |
|---|---|---|
| O | 8 | Switches - Check operation, terminals, wiring, and mounting for conditions, security, and interference. |
|---|---|---|
-
- | | | |
|---|---|---|
| O | 9 | Instrument Panel and Control Pedestal - Inspect wiring, mounting, and terminals for condition and security. Check resistance between stationary panel and instrument panel for proper ground. |
|---|---|---|
-
- | | | |
|---|---|--|
| Q | 1 | Brakes - Test toe brakes and parking brake for proper operation. |
|---|---|--|

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 4

SPECIAL INSPECTION AND YEARLY ITEMS

HOURS YEARS

INSPECTION
COMPLETED BY

Please review each of these items for required compliance

B	1	Fuselage Surface - Inspect for skin damage, loose rivets, condition of paint, and check pitot-static ports and drain holes for obstruction. Inspect covers and fairings for security.	A	
B	2	Internal Fuselage Structure - Inspect bulkheads, doorposts, stringers, doublers, and skins for corrosion, cracks, buckles, and loose rivets, bolts and nuts.	B	
B	10	Windows, Windshield, Doors, and Seals - Inspect general condition. Check latches, hinges, and seals for condition, operation, and security of attachment.		
B	11	Upholstery, Headliner, Trim, and Carpeting - Check condition and clean as required.	EACH 400	EACH 1
D	3	Brake Lines, Wheel Cylinders, Hoses, Clamps, and Fittings - Check for leaks, condition, and security and hoses for bulges and deterioration. Check brake lines and hoses for proper routing and support. (See Cessna SEB92-8)	EACH 400	EACH 1
D	6	Main Landing Gear Strut-to-Pivot Attachment - Check for damage, cracks, loose rivets, bolts and nuts and security of attachment.		
D	10	Wheel Bearings - Clean, inspect and lube.	C	
D	20	Powerpack - Hydraulic fluid contamination check.	D	
D	21	Powerpack - Check condition and wear of brushes in servomotor.	E	
D	23	Landing Gear System - Overhaul main gear downlock actuators, main and nose gear actuators, landing gear selector valve, emergency hand pump, and pressure switch. Replace all rubber goods.		F
D	24	Brake System - Overhaul brake discs, parking brake system, wheel cylinders, and master cylinders. Replace brake pads and all rubber goods.		F
E	4	Autopilot Rigging - Check per Avionics Installation Manual.	G	EACH 1
H	5	Elevator Trim Tab Actuator - Clean, lubricate, and check free-play.	H	
J	4	Engine Propeller Controls, and Linkage - Check general condition, freedom of movement through full range. Check for proper travel, security of attachment, and for evidence of wear. Check friction locks for proper operation.	G	I
J	10	Induction Air Filter - Remove and clean, inspect for damage, and service per paragraph 2-21.	J	
J	12	Alternator and Electrical Connections - Check condition and security of alternator and support brackets. Check alternator belts for condition and proper adjustment.	K	
J	13	Alternator - Check brushes, leads, commutator or slip ring for wear.	L	
J	20	Magnetos - Check external condition, security, and electrical leads for condition. Check timing to engine and internal timing if engine timing requires adjustment.	M	
J	21	Magnetos - Timing Procedures and intervals, lubrication, and overhaul procedures.	N	
J	27	Hoses, Metal Lines, and Fittings - Inspect for signs of oil and fuel leaks. Check for abrasions, chafing, security, proper routing and support and for evidence of deterioration.		O

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 4

SPECIAL INSPECTION AND YEARLY ITEMS		HOURS	YEARS	INSPECTION COMPLETED BY
Please review each of these items for required compliance				
J	32 Turbocharger - a. Inspect turbocharger mounting brackets, ducting, linkage, and attaching parts for general condition, leakage or damage, and security of attachment. b. Check waste gate, actuator, controller, oil and vent lines, overboost relief valve, and compressor housing for leakage, apparent damage, security of attachment, and evidence of wear. Check waste gate return spring for condition and security.	P		
J	33 Turbocharger - a. Remove heat shields and inspect for burned areas, bulges or cracks. Remove tailpipe and ducting - Inspect turbine for coking, carbonization, oil deposits, and turbine impellers for damage.	P		
J	35 Engine Oil Change - Turbocharged and Normally Aspirated Engines With Oil Filters: a. Remove and replace short oil filter (approximately 4.8 inches long). b. Add recommended grade aviation oil to replace oil lost in existing filter.	O		
J	37 Engine Oil Change - Normally Aspirated Engines Without Oil Filters: a. Engine Oils Without Oil Filter - Drain oil sump and oil cooler, Clean and inspect screens, and refill with recommended grade aviation oil.	O		
K	2 Integral Fuel Tanks - Drain fuel and check tank interior and outlet screens.	R		
K	9 Fuel Quantity Indicators - Check for damage, security of installation, and perform accuracy test.		EACH 1	
L	9 Propeller Assembly - Overhaul.	S		
M	1 Ventilation System - Inspect clamps, hoses, and valves for condition and security.	400	EACH 1	
M	9 Oxygen Cylinder - Inspect for condition, check hydrostatic test date and perform hydrostatic test, if due.		EACH 5	
N	4 Vacuum System Air Filter - Inspect for damage, deterioration and contamination. Clean or replace, if required. NOTE: Smoking will cause premature filter clogging.	T		
N	5 Vacuum System relief Valve - Inspect for condition and security.	U		
N	10 Airspeed Indicator, Vertical Speed Indicator, and Magnetic Compass - Calibrate.		EACH 2	
N	11 Altimeter and Static System - Inspect in accordance with FAR Part 91.411.		EACH 2	
O	4 Battery - Check general condition and security. Check level of electrolyte.	V		
P	1 Replace all fairings, doors, and access hole covers - Ground check engine, alternator charging rate, oil pressure, tachometer, oil temperature and pressure gages, and general operation of components.			
R	1 Check that all applicable Cessna Service Bulletins, and Supplier Service Bulletins are complied with.			
R	2 Check that all applicable Airworthiness Directives, and Federal Aviation Regulations are complied with.			

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 4

SPECIAL INSPECTION AND YEARLY ITEMS

Please review each of these items for required compliance

HOURS YEARS

INSPECTION
COMPLETED BY

- | | HOURS | YEARS | INSPECTION COMPLETED BY |
|--|-------|-------|-------------------------|
| R 3 Ensure all Maintenance Record Entries required by Federal Aviation Regulations are completed before returning the airplane to service. | | | |

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 4

Special Inspections Legends:

- A. First 12,000 hours and each 1000 hours thereafter: Check fuselage skins adjacent to cabin windows, emergency exit door and main cabin door for cracks. Check emergency exit door for cracks. Check de-ice light lens for cracks.
First 10,000 hours and every 500 hours thereafter: Check belly skins for cracks and failed rivets. Check main cabin door hinges for failed screws. Check emergency exit door jamb for cracks.
First 6000 hours and each 200 hours thereafter: Check main cabin door jamb for cracks.
First 4000 hours and each 200 hours thereafter: Check main cabin door fillet for cracks and rivet failure.
- B. First 10,000 hours and each 500 hours thereafter: Check bulkhead at sta. 55, 80, and 90 for cracks.
First 12,000 hours and each 1000 hours thereafter: Check bulkheads at sta. 8, 27, 35, 103 and aft pressure bulkhead for cracks.
First 11,000 hours and each 3000 hours thereafter: Check front carry-thru spar and front doorpost intersection for cracks and rivet failure.
First 4000 hours and each 200 hours thereafter: Check instrument panel and bulkhead at sta. 18 for cracks and rivet failure.
- C. First 100 hours and each 500 hours thereafter. More often if operated under prevailing wet or dusty conditions.
- D. At the first 50 hours, first 100 hours, and each 500 hours thereafter, or one year, whichever comes first.
- E. Each 500 hours, and whenever improper operation is suspected. Replace brushes when worn to .25 inch or less.
- F. Overhaul components and replace rubber goods on-condition basis.
- G. Each 600 hours or 1 year, whichever comes first.
- H. Lubrication of the actuator is required each 1000 hours or 3 years, whichever comes first. Refer to figure 2-5 for grease specification.
- I. Lubricate each 100 hours (except in extreme dusty conditions). These controls are not repairable and should be replaced every 1500 hours or sooner if required.
- J. Clean filter per paragraph 2-21. Replace paper filters at least each 500 hours.
- K. Check belt tension after 10 to 25 hours of operation. Refer to Section 17.
- L. Inspect each 500 hours.
- M. At the first 25 hours, first 50 hours, first 100 hours, and each 100 hours thereafter, the contact breaker point compartment and magneto-to-engine timing should be inspected and checked. If magneto-to-engine timing is correct within plus zero to minus two degrees, internal timing need not be checked. If timing is out of tolerance, remove magneto from engine. Detailed Maintenance and Overhaul Information covering Slick magnetos is available from Cessna Supply Division. Order 1037C1-13 for 4200/6200 series magnetos.
- N. Every 500 hours of operation, perform the following items:
 - a. Inspect contact points for condition and adjust or replace as required.
 - b. Inspect carbon brush, high-tension lead, and distributive block for condition. Clean or replace parts as required.
 - c. Inspect impulse coupling and pawls for condition and replace as required. Use light pressure only. Do not force when checking pawls.
 - d. Inspect and lubricate bearings; replace as required.
 - e. Lubricate contact point cam.The magnetos must be overhauled or replaced with new or rebuilt magnetos at every engine overhaul.
- O. Replace engine compartment rubber hoses (Cessna installed only) every 5 years, or at engine overhaul, whichever occurs first. This does not include drain hoses. Hoses which are beyond these limits, and are in a serviceable condition, must be placed on order immediately and then be replaced within 120 days after receiving the new hoses(s) from Cessna. Replace drain hoses on condition. Engine flexible hoses (Continental Motors installed): refer to Continental Motors Maintenance Manual and Continental Motor Engine Service Bulletins.
- P. Replace check valves in turbocharger oil lines each 1000 hours.

MODEL P210 SERIES SERVICE MANUAL

CESSNA PROGRESSIVE CARE MODEL P210

OPERATION NO. 4

- Q. First 25 hours: Use MIL-L-6082 Aviation grade straight mineral oil to replenish supply. After first 25 hours: Drain sump and remove and replace filter. Refill sump with recommended grade of ashless dispersant oil. Change oil and replace filter at least every six months, regardless of accumulated hours.
- R. Each 1000 hours.
- S. See McCauley Service Manual; refer to list of publication.
- T. Replace every 500 hours.
- U. Replace filter each 100 hours.
- V. Check electrolyte level and clean battery box each 100 hours or 90 days.
- W. Overhaul or replace Dukes Electrical Fuel Boost Pump at 10 years. Refer to Dukes Mandatory Service Bulletin No. 0003.
- X. Each 100 hours or whenever fuel flow fluctuation is encountered, inspect fuel manifold valves, valve covers, and fuel system components and lines for signs of leaks. Refer to Teledyne Continental Motors Service Bulletin SB95-7.

MODEL P210 SERIES SERVICE MANUAL

SECTION 3

FUSELAGE

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
FUSELAGE	1E23/3-1	3rd and 4th	1F18/3-18
WINDOWS/WINDSHIELD	1E23/3-1	Description	1F18/3-18
Description	1E23/3-1	Removal/Installation	1F18/3-18
Cleaning/Waxing	1E23/3-1	Bench (5th and 6th)	1F18/3-18
Windshield/Window		Description	1F18/3-18
Installation Techniques	1E23/3-1	Removal/Installation	1F18/3-18
Repairs	1E24/3-2	Repair	1F18/3-18
Scratches	1E24/3-2	CABIN UPHOLSTERY	1F18/3-18
Inspection Criteria	1F1/3-3	Materials and Tools	1F18/3-18
WINDSHIELD	1F4/3-5A	Soundproofing	1F18/3-18
Removal/Installation	1F4/3-5A	Cabin Headliner	1F24/3-24
WINDOWS	1F4/3-5A	Removal	1F24/3-24
Foul Weather Removal	1F4/3-5A	Installation	1F24/3-24
Main Cabin Removal	1F4/3-5A	UPHOLSTERY PANELS	1F24/3-24
CABIN DOOR	1F6/3-6	Removal/Installation	1F24/3-24
Description	1F6/3-6	CARPETING	1G1/3-25
Removal/Installation	1F6/3-6	Removal/Installation	1G1/3-25
Removal/Installation	1F6/3-6	SAFETY PROVISIONS	1G1/3-25
Installing New Door	1F6/3-6	Baggage Net	1G1/3-25
Rigging	1F6/3-6	Description	1G1/3-25
Lock	1F6/3-6	Safety Belts	1G1/3-25
Seals	1F6/3-6	Description	1G1/3-25
EMERGENCY DOOR	1F17/3-17	Shoulder Harness	1G1/3-25
Removal/Installation	1F17/3-17	Description	1G1/3-25
Disposal of Gas Spring	1F17/3-17	Inertia Reel Harness	1G1/3-25
BAGGAGE DOOR	1F17/3-17	Description	1G1/3-25
Removal	1F17/3-17	Removal/Installation	1G1/3-25
Installation	1F17/3-17	SEALANT TABLE	1G1/3-25
SEATS	1F17/3-17	SEAT RAIL INSPECTION	1G4/3-28
Pilot	1F17/3-17		
Copilot	1F17/3-17		

3-1. FUSELAGE.

3-2. WINDOWS AND WINDSHIELD.

3-3. DESCRIPTION. The windshield and windows are single-piece acrylic plastic panels held by formed retainers secured to the fuselage with screws and nuts. Sealer EC-1608 B and A (accelerator) (3 M Co), or equivalent sealers are used throughout the pressurized cabin construction.

3-4. CLEANING AND WAXING. (Refer to Section 2.)

3-5. WINDSHIELD AND WINDOW INSTALLATION TECHNIQUES:

Special drills must be used when drilling holes in acrylic. Standard drills will cause the hole to be oversized, distorted, or excessively chipped.

Whenever possible, a coolant such as a plastic drilling wax should be used to lubricate the drill bit. Cessna recommends "Reliance" drill wax or Johnson No. 140 Stick Wax.

Drilled holes should be smooth with a finish of 125 rhr.

The feed and speed of the drill is critical. The following chart indicates drill speed for various thicknesses of acrylic.

Material Thickness	Drill Speed
1/16" to 3/16"	1500 to 4500 rpm
1/4" to 3/8"	1500 to 2000 rpm
7/16"	1000 to 1500 rpm
1/2"	500 to 1000 rpm
3/4"	500 to 800 rpm
1"	500 rpm

Specifications for the twist drill used to drill acrylics is as follows:

Shallow holes - when hole depth to hole diameter ratio is less than 1.5 to 1, the drill shall have an included tip angle of 55 degrees to 60 degrees and a lip clearance angle of 15 degrees to 20 degrees.

Medium deep holes - when hole depth to hole diameter ratio is from 1.5 to 1 up to 3 to 1, the drill shall have an included tip angle of 60 degrees to 140 degrees and a lip clearance angle of 15 degrees to 20 degrees.

MODEL P210 SERIES SERVICE MANUAL

Deep holes - when hole depth to hole diameter ratio is greater than 3.0 to 1, the drill shall have an included tip angle of 140 degrees and a lip clearance of 12 degrees to 15 degrees.

Parts which must have holes drilled shall be backed up with a drill fixture. Holes may be drilled through the part from one side. However, less chipping around holes will occur if holes are drilled by drilling the holes from both sides. This is accomplished by using a drill with an acrylic backup piece on the opposite side. Remove the drill from the hole and switch the backup plate and finish drilling from the opposite side.

3-6. REPAIRS.

WARNING

If temporary repairs are made, aircraft must be operated in unpressurized mode until replacement of windows can be made.

No repairs of any kind are recommended on highly stressed or compounded curves where the repair would be likely to affect the pilots or copilots field of vision.

Damaged window panels and windshield may be removed and replaced if the damage is extensive. However, certain repairs as prescribed in the following paragraphs can be made successfully without removing the damaged part from the aircraft. Curved areas are more difficult to repair than flat areas and any repaired area is both structurally and optically inferior to the original surface.

3-7. SCRATCHES on clear plastic surfaces can be removed by hand-sanding operations followed by buffing and polishing, if steps below are followed carefully.

a. Wrap a piece of No. 320 (or finer) sandpaper or abrasive cloth around a rubber pad or wood block. Rub the surface around the scratch with a circular motion, keeping the abrasive constantly wet with

DEFECTS	CRITICAL VISION AREA		NON-CRITICAL VISION AREA	
	MAXIMUM REPAIRABLE	MAXIMUM PERMISSIBLE WITHOUT REPAIRING	MAXIMUM REPAIRABLE	MAXIMUM PERMISSIBLE WITHOUT REPAIRING
NICKS AND DENTS				
Maximum Diameter.	Not repairable.	0.025 inch.	0.250 inch.	0.125 inch.
Depth.	Not repairable.	0.016 inch.	0.060 inch.	0.032 inch.
Frequency.	None	2 per sq. ft.	2 per sq. ft.	1 per sq. ft.
SCRATCHES.				
Length.	12 inches total per area.	12 inches total per area.	24 inches total per area.	24 inches total per area.
Width.	0.020 inch.	0.020 inch.	0.050 inch.	0.020 inch.
Depth.	0.016 inch.	0.008 inch.	0.008 inch.	0.008 inch.
Frequency.	12 inches total per area.	12 inches total per area.	20% of total area.	Total length of scratches equals 3 times longest dimension of area.
CRACKS.				
Length.	Not repairable.	None.	Not repairable.	None.
Frequency.	Not repairable.	None.	Not repairable.	None.




Figure 3-1. Windshield Installation.

clean water to prevent scratching the surface further. Use minimum pressure and cover an area large enough to prevent the formation of "bull's-eyes" or other optical distortions.

b. Continue the sanding operation, using progressively finer grade of abrasives until the scratches disappear.

c. When the scratches have been removed, wash the area thoroughly with clean water to remove all gritty particles. The entire sanded area will be clouded with minute scratches which must be removed to restore transparency.

d. Apply fresh tallow or buffing compound to a motor-driven buffing wheel. Hold the wheel against the plastic surface, moving it constantly over the damaged area until cloudy appearance disappears. A 2000-foot-per-minute surface speed is recommended to prevent overheating and distortion.

NOTE

Polishing can be accomplished by hand but it will require a considerably longer period of time to attain the same result as a buffing wheel.

e. When buffing is finished, wash the area thoroughly and dry with a soft flannel cloth. Allow the surface to cool and inspect the area to determine if full transparency has been restored. Then apply a thin coat of hard wax and polish the surface lightly with a clean flannel cloth.

3-8. PLASTIC WINDOWS INSPECTION CRITERIA.

NOTE

Rubbing the plastic surface with a dry cloth will build up an electrostatic charge which attracts dirt particles and may eventually cause scratching of the surface. After the wax has hardened, dissipate this charge by rubbing the surface with a slightly damp chamois. This will also remove the dust particles which have collected while the wax is hardening.

f. Minute hairline scratches can often be removed by rubbing with commercial automobile body cleaner or fine-grade rubbing compound. Apply with a soft, clean, dry cloth or imitation chamois.

MODEL P210 SERIES SERVICE MANUAL




Figure 3-2. Fuselage Assembly.

MODEL P210 SERIES SERVICE MANUAL

3-8. PLASTIC WINDOWS INSPECTION CRITERIA (Cont).

DEFECTS	CRITICAL VISION AREA		NON-CRITICAL VISION AREA	
	MAXIMUM REPAIRABLE	MAXIMUM PERMISSIBLE WITHOUT REPAIRING	MAXIMUM REPAIRABLE	MAXIMUM PERMISSIBLE WITHOUT REPAIRING
CRAZING.				
Slight.	Not repairable.	Crazing adjacent to the edges of the glass must not extend more than 1 inch into the critical vision area.	Not repairable.	Shall be contained in a 9.00 inch circle.
Severe.	Not repairable.	Crazing adjacent to the edge of the glass must not extend more than 1 inch into the critical vision area.	Not repairable.	Shall be contained in a 6.00 inch circle.
DISCOLORATION.				
	Not repairable.	None.	Not repairable.	May extend 1 inch from all edges of non-critical areas.




Figure 3-3. Critical Vision Diagram

3-9. WINDSHIELD. (Refer to figure 3-2).

3-10. REMOVAL AND INSTALLATION.

- a. Remove sun visors and upper windshield moulding.
- b. Remove screws securing upper inside retainer.
- c. Remove screws securing outside center strip.
- d. Remove screws securing lower outside retainer.
- e. Ease windshield forward, at the bottom, out of the side retainer strips and from under the cabin top skin.
- f. Clean all retainer strips and channels using procedures in Section 16.
- g. Inspect all retainers for damage and repair or replace as necessary.
- h. Reverse the preceding steps for installation.
- i. When installing a new windshield check fit and carefully file or grind away excess plastic.
- j. Install new plastic sleeves over screws and dip screw heads in sealer before installing.
- k. After installation remove excess sealer from inside and outside of windshield.

3-11. WINDOWS. Only the foul weather window is movable in its mount, the others are stationary. The foul weather window, most forward on main cabin door, unlatches at the rear edge, swings outward, and slides aft to open.

3-12. FOUL WEATHER WINDOW REMOVAL AND INSTALLATION.

- a. Unlatch, pull outward, and slide window aft.
- b. Remove four screws from inside trim, and remove trim.
- c. Remove stop bolts from slide and pull window assembly from slide.
- d. Replace or repair as necessary, inspect seal condition, and reverse above sequence for installation.

3-13. REMOVAL AND REPLACEMENT OF MAIN CABIN WINDOWS.

- a. Remove trim from inside windows.
- b. Remove all screws around window periphery from out side.

MODEL P210 SERIES SERVICE MANUAL

c. Remove retainer inside, and push window from outside to remove.

d. To install, reverse above procedures. Seal as directed in applicable illustrations.

3-14. CABIN DOOR.

3-15. DESCRIPTION. Entry is provided through the left main cabin door. The right half door is for emergency exit only. Both doors use the same type latches, three (3) holding the emergency door, and nine (9) on the main cabin door. Anytime parts are removed and replaced, or latch push-pull rods are disconnected, the rigging should be checked to insure positive latching prior to next flight. Refer to paragraph 3-18 for rigging procedures. All latches are operated with a three-position handle: OPEN, CLOSE, and LATCH.

3-16. REMOVAL AND INSTALLATION. (Refer to figure 3-4.)

- a. Remove door travel limit.
- b. Disconnect door stop arm.
- c. Holding door firmly, and remove six (6) hinge mount screws.
- d. To reinstall, reverse above sequence.

NOTE

When fitting a new door, be cautious, because seal must make a definite contact, and door contour must be trimmed to fair.

e. With new door, set to contour by removing the receptacle assembly from the door jamb; loosen the inner receptacle nut and adjust inboard or outboard as required. Retorque nut to 50 to 70 lb-in. On final fitting of door, check side clearance between bolts and their receptacles (use grease to check clearance). Readjust inner receptacle sideways as required. Note inboard and outboard position before loosening receptacle nut

- f. Refer to paragraph 3-19 for rigging.

3-17. REMOVAL AND INSTALLATION OF DOOR LATCHES.

- a. Remove inside trim to expose latch-mount screws.
- b. Disconnect latch mechanisms: push-pull rods, cables, bellcranks, etc. There are nine (9) latches on the main door and three on the emergency exit door.
- c. If replacing door, refer to paragraph 3-18.
- d. To install door latches, reverse procedures outlined in steps "a" and "b".

3-18. INSTALLING NEW DOOR. (See figure 3-6.)

When installing a new door, lock plates and latches, mounted on the door posts and upper and lower door frames, will have to be rigged to receive lock bolts. There are nine (9) door latches in the cabin door. The following information will be helpful and assist in door installation.

- a. There are two types of lockplates and receptacles used to secure the main cabin door. A seven degree (7°) plate/receptacle assembly and a three degree (3°) plate/receptacle are utilized in the main cabin door in-

stallation. The differences are shown in the illustration (figure 3-7). The three degree assemblies are used on the forward and aft faces of the door jamb. The seven degree assemblies are used on the top and bottom faces of the door jamb.

b. Adjustment of the lock plate/receptacle is accomplished by moving the receptacle up or down or inboard or outboard. Maximum adjustment is limited to two teeth in any one direction.

3-19. RIGGING MAIN DOOR LATCH. If replacing latch or parts of a latch, the push-pull rods will be disconnected. If realignment is primary, then disconnect push-pull rods as necessary to allow rig pin installation, and with the door latch in the CLOSE position complete the following:

- a. Install rigging pins in bellcranks and rotary clutch bolt guide assembly.
- b. Rig all latch pins to dimensions shown in figure 3-5.
- c. Rig upper center latch pin to dimensions specified in detail A.
- d. With rigging pins installed, adjust push-pull rods to fit, and connect to latch pins and bellcranks.
- e. Remove rigging pins and check travel dimensions specified in detail A.
- f. Check rotary clutch and bolt dimensions specified in detail C.

3-20. MAIN DOOR LOCK

a. The outside door key-lock consists of locking the outside door handle with a cam sliding into a slot in the door handle. It does not lock the door latching mechanism in any other manner. Maintenance consists of removal and replacement only.

b. The interior door lock, immobilizes both latch handles. It is activated on the inside by pushing a tab IN until flush with door. An emergency release is located on the outside immediately above the door handle. It is in the form of a push button, and functions to UNLOCK the inside lock mechanism from the outside if required for an emergency entry. The push button is sealed to maintain cabin pressure when operating in the pressurized mode.

c. If the lock is to be replaced, the new one may be modified to accept the original key. This is desirable, because the same key is used for the ignition switch and the cabin door lock. After removing the old lock from the door, proceed as follows:

1. Remove the lock cylinder from new housing.
2. Insert the original key into the new cylinder, and file off any protruding tumblers flush with cylinder. Without removing key, check that cylinder rotates freely in the housing.
3. Install the lock assembly in door and check lock operation with the door open.
4. Destroy the new key and disregard the code number on the cylinder.

3-21. DOOR SEALS. This airplane uses adhesive only to fasten seals to doors. Seal is placed with small pressurizing holes toward pressure source (cabin). As the cabin is pressurized, the seal is inflated at the same rate to insure a constant seal between doors and door frames.

MODEL P210 SERIES SERVICE MANUAL




Figure 3-4. Main Cabin Door Assembly.

MODEL P210 SERIES SERVICE MANUAL

- 1 Window Mount
- 2 Spring-Attach Anchor
- 3 Spring
- 4 Upper Bracket
- 5 Upper Link
- 6 Frame Assembly
- 7 Mount
- 8 Lower Link
- 9 Lower Bracket
- 10 Stop Nut
- 11 Hinge Half
- 12 Hinge Pin
- 13 Hinge Half
- 14 Mount
- 15 Link Spacer
- 16 Slide Bar
- 17 Handle
- 18 Insert
- 19 Spring Washer
- 20 Doubler
- 21 Striker
- 22 Spacer
- 23 Screws

NOTE

With cabin door closed and latched, check area of sliding window for water leaks. If water leaks in around seal, loosen 4 screws (23) and move window frame assembly outboard to maximum allowed by the floating nutplates on window frame assembly. Retorque screws and recheck for water leaks.




Figure 3-5. Cabin Door Sliding Window Installation.

MODEL P210 SERIES SERVICE MANUAL





Figure 3-6. Door Latch Mechanism (Sheet 1 of 4).




1. Pin.
2. Lock Pin Handle.
3. Lock Pin Cover.
4. Rod.
5. Link.
6. Bracket.
7. Piston.
8. O-Ring.
9. Housing.
10. Spring
11. Button.
12. Rod.
13. Spacer.
14. Connector.
15. Nut.
16. Nut.
17. Sleeve.
18. Pin.
19. Ball.
20. Clip.

Cabin Door Pin Lock Installation

Figure 3-6. Door Latch Mechanism (Sheet 2 of 4).

MODEL P210 SERIES SERVICE MANUAL



NOTE

Apply Door-Eze lubricant to latch bolt.

- | | |
|--------------------------------|---------------------------|
| 1. Inside Door Handle. | 16. Clevis. |
| 2. Pin. | 17. Clevis. |
| 3. Pin. | 18. Upper Bell Crank. |
| 4. Bellcrank. | 19. Pin. |
| 5. Clevis. | 20. Bolt Guide Assembly. |
| 6. Cover. | 21. Forward Spring. |
| 7. Gasket. | 22. Washer. |
| 8. Cabin Door Lock Cam. | 23. Aft Spring. |
| 9. Cabin Door Structure. | 24. Bolt Guide. |
| 10. Cabin Door Lock Assembly. | 25. Setscrew. |
| 11. Spring. | 26. Outer Plate Assembly. |
| 12. Handle. | 27. Rod. |
| 13. Packing. | 28. Bushing. |
| 14. Cabin Door Handle Spindle. | 29. Lower Bell Crank. |
| 15. Rotary Latch Base Plate. | 30. Check Nut. |

Figure 3-6. Door Latch Mechanism (Sheet 3 of 4).

MODEL P210 SERIES SERVICE MANUAL




Figure 3-6. Door Latch Mechanism (Sheet 4 of 4).

MODEL P210 SERIES SERVICE MANUAL

NOTE

Torque nut(5) to 50-70 lb-in.




Figure 3-7. Main Door Receptacle Installation (Sheet 1 of 2).

MODEL P210 SERIES SERVICE MANUAL

- Shim, .040 or .080, combination shall not exceed .160 maximum build-up.

Install .53 dimension side of parts on outboard side of door jamb.


Install parts with 7° dimension on top and bottom faces of door jamb.

Install parts with 3° dimension on forward and aft faces of door jamb.

- Maximum adjustment, two teeth in any direction from center.


Grease cored area of receptacle before checking latch fit.

TORQUE TO 50/70 LB. IN.




Detail C

Grease cored area of receptacle before checking latch fit.



Detail A

ADJUSTMENT SEQUENCE



1. Receptacle
2. Plate
3. Door Jamb
4. Nut

Scribe a pencil line around periphery of cover assembly prior to removal to facilitate reinstallation.

Detail B

Figure 3-7. Main Door Receptacle Installation (Sheet 2 of 2).

MODEL P210 SERIES SERVICE MANUAL




Figure 3-8. Emergency Exit Door Installation (Sheet 1 of 2).

MODEL P210 SERIES SERVICE MANUAL




Figure 3-8. Emergency Exit Door Installation (Sheet 2 of 2).

MODEL P210 SERIES SERVICE MANUAL




Figure 3-9. Disposal of Gas Spring Assembly.

3-22. **EMERGENCY EXIT DOOR.** The right cabin half door is for exiting from the inside only, there is no provision for entry. Two stationary windows are mounted in the emergency door. A preloaded gas cylinder door lift assist is utilized, because no maintenance is required; simply remove and replace when defective.

3-23. REMOVAL AND INSTALLATION.

- a. Remove the nut from the door lift assist cylinder piston rod (lower end). Door must be supported as this is removed.
- b. Remove the hinge screws, and the door.
- c. To install, reverse above procedures.

3-24. **DISPOSAL OF GAS SPRING.** (See figure 3-9.)

WARNING

When removed, depressurize the gas spring as described before discarding. Protective eye covering must be worn while performing the following steps.

- a. Place cylinder horizontally in bench vise and tighten vise.
- b. Place several layers (4 layers minimum) of shop towels or rags over end of cylinder in vise.
- c. Measure 1 1/2" in from fixed end of cylinder and, using a scratch awl or pointed center punch and hammer, drive awl or punch through the towels and into the cylinder until the gas begins to escape.
- d. Hold the towels and scratch awl in place until

all gas has escaped (a few seconds). Then, slowly remove scratch awl. Escaping oil will be absorbed by the towels.

- e. While still holding towels over hole, push bright shaft completely into cylinder to purge remaining oil.
- f. Remove from vise and discard.

3-25. **BAGGAGE DOOR.** (See figure 3-11.)

3-26. **REMOVAL.** (See figure 3-11.)

- a. Disconnect door stop rod (23).
- b. Remove hinge pin (4).

3-27. **INSTALLATION.** (See figure 3-12.)

- a. Install hinge pin (4) from aft end of door, with end bent inboard of hinge.
- b. Install shims (2) as required to obtain engagement shown in detail C between striker (1) and baggage door latch (20).

NOTE

The baggage door is of bonded construction. Reforming of this door is not permissible, as material separation may occur in the flange area.

3-28. **SEATS.** (Refer to figure 3-12.)

3-29. **PILOT.**

- a. **ARTICULATING RECLINE/VERTICAL ADJUST.**

3-30. **COPILOT.**

- a. **ARTICULATING RECLINE.**

MODEL P210 SERIES SERVICE MANUAL

b. ARTICULATING RECLINE/VERTICAL ADJUST.

3-31. 3RD AND 4TH.

a. ARTICULATING RECLINE.

3-32. DESCRIPTION. These Seats are manually-operated throughout their full range of operation. Seat stops are provided to limit fore-and-aft travel.

3-33. REMOVAL AND INSTALLATION.

- a. Remove seat stops.
- b. Disengage the seat adjustment pin.
- c. Slide seat fore-and-aft to disengage seat rollers from rails.
- d. Lift seat out.
- e. Reverse preceding steps for reinstallation. Ensure all seat stops are reinstalled.

WARNING

It is extremely important that the pilot's seat stops are installed. Acceleration and deceleration could possibly permit seat to become disengaged from the seat rails and create a hazardous situation, especially during take-off and landing.

3-34. BENCH. (5th and 6TH.)

a. DOUBLE-WIDTH BOTTOM/DOUBLE-WIDTH BACK.

3-35. DESCRIPTION. These seats are permanently bolted to the cabin structure and incorporate no adjustment provisions.

3-36. REMOVAL AND INSTALLATION.

- a. Pull up on knob (1) to unlatch seat back.
- b. Remove pin (10) from guide (8) on each side of seat back.
- c. Remove bolts (14) from the three seat legs.
- d. Remove bolts (9) from both sides of seat bottom.

NOTE

Bolts (9) are located inside the main gear wheel well.

- e. With the seat back folded down, use care and slide the two inside seat belts out from between the seat back and bottom. Remove seat from aircraft.
- f. Reverse preceding steps for reinstallation.


3-37. REPAIR. Replacement of defective parts is recommended in repair of seats. However, a cracked framework may be welded, provided the crack is not in an area of stress concentration (close to a hinge or bearing point). The square-tube framework is 6061 aluminum, heat-treated to a T-6 condition. Use a heliarc weld on these seats, as torch welds will destroy heat-treatment of frame structure.

3-38. CABIN UPHOLSTERY. Due to the wide selection of fabrics, styles and colors, it is impossible to depict each particular type of upholstery. The following paragraphs describe general procedures which will serve as a guide in removal and replacement of upholstery. Major work, if possible, should be done by an experienced mechanic. If the work must be done by a mechanic unfamiliar with upholstery practices, the mechanic should make careful notes during removal of each item to facilitate replacement later.

3-39. MATERIALS AND TOOLS. Materials and tools will vary with the job. Scissors for trimming upholstery to size and a dull-bladed putty knife for wedging material beneath retainer strips are the only tools required for most trim work. Use industrial rubber cement to hold soundproofing mats and fabric edges in place. Refer to Section 18 for thermo-plastic repairs.

3-40. SOUNDPROOFING. The aircraft is insulated with spun glass mat-type insulation and a sound deadener compound applied to inner surfaces of the skin in most areas of the cabin and baggage compartment. All soundproofing material should be replaced in its original position any time it is removed. A soundproofing panel is placed in the gap between wing and fuselage and held in place by the wing root fairings.

MODEL P210 SERIES SERVICE MANUAL



- 1. Window
- 2. Windshield
- 3. Door
- 4. Frame
- 5. Seal
- 6. Sealer (Type I). (See Table, page 3-25)
- 7. Retainer
- 8. Sealer (Type II). (See Table, page 3-25)

Figure 3-10. Door and Window Sealing.

MODEL P210 SERIES SERVICE MANUAL





Figure 3-11. Baggage Door Installation

MODEL P210 SERIES SERVICE MANUAL



WARNING
 ASSURE THAT SEAT IS LOCKED IN POSITION
 PRIOR TO TAKE OFF, AND LANDING. FAILURE
 TO PROPERLY LATCH SEAT AND HEED ALL
 SAFETY INSTRUCTIONS CAN RESULT IN BODILY
 INJURY OR DEATH. 8700097-1

IN CLEAR VIEW OF THE PILOT

- | | |
|-----------------------------------|------------------------|
| 1. Vertical Adjustment Handle | 11. Seat Back |
| 2. Fore/Aft Adjustment Handle | 12. Spacer |
| 3. Adjustment Pin | 13. Channel |
| 4. Guide | 14. Torque Tube |
| 5. Spring | 15. Seat Frame |
| 6. Link | 16. Cam Stop Lever |
| 7. Seat Bottom | 17. Bellcrank |
| 8. Articulating Adjustment Handle | 18. Trim |
| 9. Adjustment Screw | 19. Seat Belt Retainer |
| 10. Bellcrank | 20. Collar |


**INFINITELY ADJUSTABLE
 PILOT AND CO-PILOT SEAT**

Figure 3-12. Seat Installation (Sheet 1 of 3)

MODEL P210 SERIES SERVICE MANUAL

NOTE

3rd and 4th seat assemblies are left and right hand and must be installed on their respective side. When not installed properly the aisle to the rear seat is eliminated.




- | | |
|-----------------------------------|--------------------------------|
| 1. Seat Bottom | 10. Roller |
| 2. Articulating Adjustment Handle | 11. Adjustment Pin |
| 3. Bellcrank | 12. Fore/Aft Adjustment Handle |
| 4. Adjustment Screw | 13. Stiffener |
| 5. Seat Back | 14. Trim |
| 6. Spacer | 15. Seat Belt Retainer |
| 7. Seat Structure | |
| 8. Spring | |
| 9. Bushing | |

ARTICULATING 3RD AND 4TH SEATS

Figure 3-12. Seat Installation (Sheet 2 of 3)

MODEL P210 SERIES SERVICE MANUAL



- | | |
|------------------------------|-----------------------------|
| 1. Seat Back Assembly | 7. Spacer |
| 2. Bolt | 8. Seat Belt |
| 3. Seat Frame | 9. Outboard Leg |
| 4. Seat Belt Attach Brackets | 10. Removeable Seat Cushion |
| 5. Bolt | 11. Skirt |
| 6. Bolt | 12. Bolt |

BENCH (5TH AND 6TH)

Figure 3-12. Seat Installation (Sheet 3 of 3)

MODEL P210 SERIES SERVICE MANUAL




Figure 3-13. Cabin Headliner Installation

3-41. CABIN HEADLINER. (Refer to figure 3-13.)

3-42. REMOVAL.

a. Remove all overhead oxygen, ventilating and light consoles, sun visors, dome lights, all inside finish strips and plates and any other visible retainers securing headliner.

b. Work edges of headliner free from metal teeth which hold fabric.

c. Starting at the front of headliner and working toward the rear, work headliner down, removing screws through the metal tabs which hold the wire bows to cabin top. Pry outer ends of bows loose from retainers above doors. Detach each wire bow in succession.

d. Remove headliner assembly and bows from the aircraft.

NOTE

Due to the difference in length and contour of wire bows, each bow should be tagged to assure proper location in the headliner.

e. Remove the spun glass soundproofing panels.

NOTE

The lightweight soundproofing panels are held in place with industrial rubber cement.

3-43. INSTALLATION.

a. Before installation, check all items concealed by headliner for security. Use wide cloth tape to secure loose wires to the fuselage and to seal any openings in the wing roots. Straighten tabs bent during removal of headliner.

b. Apply cement to inside of skin in the areas where soundproofing panels are not supported by wire bows and press soundproofing in place.

c. Insert wire bows into headliner seams and secure the two bows at rear of headliner. Stretch the material along edges to properly center, but do not stretch it tight enough to destroy ceiling contours or distort wire bows. Secure edges of headliner with the metal teeth.

d. Work headliner forward, installing each wire bow in place with the metal tabs. Wedge ends of wire bows into the retainer strips. Stretch headliner just taut enough to avoid wrinkles and maintain a smooth contour.

e. When all bows are in place and fabric edges are secured, trim off excess fabric and reinstall all items removed.

3-44. UPHOLSTERY PANELS.

3-45. REMOVAL AND INSTALLATION. Removal of the upholstery side panels is accomplished by removing the seats for access and removing screws, retaining strips and ash trays as required to free the panels. When reinstalling side panels, do not overtighten

MODEL P210 SERIES SERVICE MANUAL

screws. Larger screws may be used in enlarged holes as long as the area behind the hole is checked for wiring, fuel lines and other components which might be damaged by using a longer screw. Automotive type spring clips attach the door panels and a dull putty knife makes an excellent tool for prying the clips loose. The rear baggage panel is secured to the aft cabin wall with cloth retaining strips for easy removal.

NOTE

The belt half with the buckle should be installed on the outboard side of the seat to ensure proper operation of the shoulder harness.

3-46. CARPETING.

3-47. REMOVAL AND INSTALLATION. Cabin and baggage compartment carpeting is held in place by rubber cement, small sheet metal screws and retaining strips. Cloth retaining strips are also installed on some aircraft near access plate locations for quick-removal of the carpeting and inspection in these areas. When fitting a new carpet, use the old one as a pattern for trimming and marking screw holes.

3-48. SAFETY PROVISIONS.

3-49. BAGGAGE RETAINING NET.

3-50. DESCRIPTION. A nylon baggage net having a frame and hinges retains the baggage in the area behind the main gear wheel wells.

3-51. SAFETY BELTS. (See figure 3-14.)

3-52. DESCRIPTION.

Safety belts should be replaced if frayed or cut, latches are defective or stitching is broken. Attaching parts should be replaced if excessively worn or defective. The pilot and copilot seat safety belts are attached to brackets bolted to the cabin floor. The 3rd and 4th seat belts are attached to brackets bolted to the cabin floor and fuselage structure. The bench seat belts are attached to a bracket bolted to the cabin floor and to the seats themselves.

3-58. TABLE OF RECOMMENDED SEALERS.

TYPE I	TYPE II
890 and 890 A Accelerator Coast Pro-Seal, Los Angeles, Ca.	EC-1608 Part A and B (3M Co) Minnesota Mining & Mfg Co.
CS3204 Part A and B Chem Seal Corp., Los Angeles, Ca.	Pro-Seal 706 Coast Pro-Seal, Compton, Ca.
GC-408 Part A and B Churchill Chemical Co., Vernon, Ca.	GC-200 Goal Chemical Corp., Los Angeles, Ca.
PR-1440 Part A and B Products Research Co., Burbank, Ca.	
FIREWALL SEALANT	
Dapocast #18-4 D Aircraft Products Co., Anaheim, Calif.	TBS-758 Thermal Coating General Electric, Waterford, Connecticut

3-53. SHOULDER HARNESS

3-54. DESCRIPTION. (See figure 3-14.) Individual shoulder harnesses may be installed for each seat. The pilot and copilot harnesses are bolted to the upper console reel, and the 3rd, 4th and bench seat harnesses are bolted to the aft cabin structure. Component parts should be replaced as outlined in paragraph 3-54.

3-55. INERTIA REEL HARNESS.

3-56. DESCRIPTION. (See figure 3-15.)

An inertia reel harness assembly may be installed for the Pilot and Co-Pilot positions. The inertia reels are installed in a mounting base located in the aft center overhead console. The shoulder and lap belt are one assembly with an adjuster to position the shoulder harness. The reel is designed to lock and hold when a 2 to 3 "g" force is applied and 12 inches of webbing remain on the reel. The reel can be checked for proper operation by giving webbing a quick tug, the reel should lock and hold.

3-57. REMOVAL AND INSTALLATION.

- Remove the screws retaining the escutcheon on aft center console and remove the oxygen outlet covers by rotating counter-clockwise if installed.
- Remove screws in mounting bracket and remove (2) screws in each reel assembly and pull belt through bracket.
- Re-install by reversing the procedure.

MODEL P210 SERIES SERVICE MANUAL






Figure 3-14. Safety Belts

MODEL P210 SERIES SERVICE MANUAL



1. Inertia Reel-Belt Assembly(Right Hand).
2. Inertia Reel.
3. Inertia Reel-Belt Assembly(Left Hand).
4. Bolt.
5. Seat Belt Fitting.
6. Spacer.
7. Bolt.




Detail A

Figure 3-15. Inertia Reel Harness

MODEL P210 SERIES SERVICE MANUAL

3-59. SEAT RAIL INSPECTION. A special inspection of the seat rails should be conducted each 50 hours. See figure 3-16 for inspection procedures.



REPLACE SEAT RAIL WHEN:

- Any portion of web or lower flange is cracked, (index 2).
- Any crack in crown of rail is in any direction other than right angle to length of rail.
- Number of cracks on any one rail exceeds four, or any two cracks (index 1) are closer than one-inch.

NOTE

Use of seat rail cargo tie-downs is not permissible on seat rails with cracks.

Figure 3-16. Seat Rail Inspection

MODEL P210 SERIES SERVICE MANUAL

SECTION 4

WINGS AND EMPENNAGE

TABLE OF CONTENTS Page No.
Aerofiche/Manual

WINGS AND EMPENNAGE	1G9/4-1	Horizontal Stabilizer	1G10/4-2
Wings	1G9/4-1	Description	1G10/4-2
Description	1G9/4-1	Removal	1G11/4-3
Removal	1G9/4-1	Repair	1G11/4-3
Repair	1G10/4-2	Installation	1G11/4-3
Installation	1G10/4-2	Stabilizer Abrasion Boots	1G11/4-3
Adjustment	1G10/4-2	Description	1G11/4-3
Vertical Fin	1G10/4-2	Removal	1G11/4-3
Description	1G10/4-2	Installation	1G11/4-3
Removal	1G10/4-2		
Repair	1G10/4-2		
Installation	1G10/4-2		

4-1. WINGS AND EMPENNAGE.

4-2. WINGS. (See figure 4-1.)

4-3. **DESCRIPTION.** Each all-metal wing panel is a full cantilever type, with a single main spar, two fuel spars, formed ribs and stringers. The front fuel spar also serves as an auxiliary spar and provides the forward attachment point for the wing. An inboard section of the wing, forward of the main spar, is sealed to form an integral fuel bay area. Stressed skin is riveted to the spars, ribs and stringers to complete the structure. An all-metal, balanced aileron, flap, and a detachable wing tip are part of each wing assembly. A navigation light is mounted in each wing tip.

4-4. **REMOVAL.** Wing panel removal is most easily accomplished if four men are available to handle the wing. Otherwise, the wing should be supported with a sling or maintenance stand when the fastenings are loosened.

- a. Remove wing gap fairings and fillets.
- b. Drain fuel from wing being removed. (Observe precautions outlined in Section 13.)
- c. Remove cabin headliner in accordance with procedures outlined in Section 3.
- d. Disconnect:
 1. Electrical wires at wing root disconnects.
 2. Fuel lines at wing root.
 3. Pitot line (left wing only) at wing root.
 4. Cabin ventilator hose at wing root.
 5. Aileron carry-thru cable and aileron direct cables of wing being removed, at turnbuckles behind headliner front shield and doorpost shield.
 6. Disconnect and cap wing de-ice hoses if installed.

NOTE

To ease rerouting the cables, a guide wire may be attached to each cable before it is pulled free from the wing. Then disconnect cable from wire and leave the guide wire routed through the wing; it may be attached again to the cable during reinstallation and used to pull the cable into place.

- f. If right wing is being removed, disconnect flap cables from right flap drive pulley, and remove cable guards and/or pulleys as required to pull flap cables into right wing root area.
- g. If left wing is being removed, relieve tension on right flap cables at right flap drive pulley. Disconnect right flap cables at flap actuator in left wing and remove pulleys to pull flap cables into left wing root area.

NOTE

- Rigging of flap actuator and components in left wing need not be disturbed to remove either wing. It is recommended that flap be secured in streamlined position with tape during wing removal to prevent damage, since flap will swing freely.
- h. Remove nut, washer and bolt attaching front fuel spar to fuselage.
 - i. Remove bolts, washers and retainers holding main spar dowel pins in position.
 - j. Support wing at inboard and outboard ends, and

MODEL P210 SERIES SERVICE MANUAL

remove dowel pins that attach main wing spar to fuselage. It is recommended to remove the top dowel pin first, then lower outboard end of wing before removing bottom dowel pin.

NOTE

It may be necessary to use a long punch to drive out main wing spar attaching dowel pins, or to rock wing slightly while removing pins. Care must be taken not to damage dowel pins, spar fittings or spar carry-thru fittings as these are reamed holes and close tolerance dowel pins.

k. Remove wing and lay on padded stand.

4-5. **REPAIR.** A damaged wing panel may be repaired in accordance with instructions outlined in Section 18. Extensive repairs of wing skin or structure are best accomplished by using the wing repair jig, which may be obtained from Cessna. The jig serves not only as a holding fixture, making work on the wing easier, but also assures absolute alignment of the repaired wing.

4-6. **INSTALLATION.**

NOTE

Refer to figure 4-1 for lubrication of dowel pins prior to installation.

- a. Hold wing in position with wing tip low.
- b. Install:
 1. Dowel pins attaching main spar to fuselage. (Install bottom pin first, then rotate wing tip up, and install top pin.)
 2. Bolts, washers and nuts that hold main spar attach dowel pins in position.
 3. Front fuel spar attach bolt, washer and nut.
- c. Route flap and aileron cables and make proper connections.
- d. Connect:
 1. Electric wires at wing root disconnects.
 2. Fuel lines at wing root.
 3. Pitot line (if left wing is being installed.)
 4. Cabin ventilator hose at wing root.
 5. Aileron carry-thru cable and aileron direct cables of wing being installed, at turnbuckles behind headliner front shield and doorpost shield.
 6. Wing de-ice hoses if installed.
- e. Rig aileron system (Section 6).
- f. Rig flap system (Section 7).
- g. Refill wing fuel bays and check all connections for leaks.

h. Check operation of navigation, courtesy and landing lights.

- i. Check operation of fuel quantity indicator.
- j. Install wing gap fairings and fillets.

NOTE

Be sure to install soundproofing panel in wing gap before replacing fairing.

- k. Install headliner, interior panels, upholstery and inspection plates.
 1. Test operation of flap and aileron systems.

4-7. **ADJUSTMENT (CORRECTING "WING-HEAVY" CONDITION).** If considerable control wheel pressure is required to keep the wings level in normal flight, a wing-heavy condition exists. Refer to Section 6 for adjustment of aileron tabs.

4-8. **VERTICAL FIN.** (See figure 4-2.)

4-9. **DESCRIPTION.** The fin is primarily of metal construction, consisting of ribs and spars covered with skin. Fin tips are glass fiber/ABS construction. Hinge brackets at the rear spar attach the rudder.

4-10. **REMOVAL.** The fin may be removed without first removing the rudder. However, for access and ease of handling, the rudder may be removed if desired, following the procedures outlined in Section 10.

- a. Remove fairings on both sides of fin.
- b. Disconnect flashing beacon lead, tail navigation light lead, antennas and antenna leads and rudder cables if rudder has not been removed.
- c. Remove screws attaching dorsal fin to fuselage.
- d. Remove bolts attaching fin front and rear spars to fuselage.
- e. Remove fin.

4-11. **REPAIR.** (Refer to Section 18.)

4-12. **INSTALLATION.** Reverse procedures outlined in paragraph 4-10 to install the fin. Be sure to check and reset rudder and elevator travel if any stop bolts were removed or settings disturbed. Refer to Sections 8 and 10 respectively for setting elevator and rudder travel. Refer to figure 1-1 for control surface travels.

4-13. **HORIZONTAL STABILIZER.** (See figure 4-3.)

4-14. **DESCRIPTION.** The horizontal stabilizer is

MODEL P210 SERIES SERVICE MANUAL

primarily of metal construction, consisting of ribs and a front and rear spar which extends throughout the full span of the stabilizer. The skin is riveted to both spars and ribs. Stabilizer tips are constructed of ABS. The elevator tab actuator screw is contained within the horizontal stabilizer assembly, and is supported by a bracket riveted to the rear spar. The underside of the stabilizer contains an opening which provides access to the elevator tab actuator screw. Hinges on the rear spar support the elevator.

4-15. REMOVAL

- a. Remove elevators and rudder in accordance with procedures outlined in Sections 8 and 10.
- b. Remove vertical fin in accordance with procedures outlined in paragraph 4-10.
- c. Disconnect elevator trim control cables at clevis, turnbuckle and clamps inside tailcone, remove pulleys which route the aft cables into horizontal stabilizer, and pull cables out of tailcone.
- d. Remove bolts securing horizontal stabilizer to fuselage.
- e. Remove horizontal stabilizer.

4-16. REPAIR. (Refer to Section 18.)

4-17. **INSTALLATION.** Reverse the procedures outlined in paragraph 4-15 to install the horizontal stabilizer. Rig the control systems as necessary, following instructions outlined in applicable sections. Set control surface travels to values listed in figure 1-1.

4-18. STABILIZER ABRASION BOOTS.

NOTE

An Accessory Kit (AK182-217) is available from the Cessna Service Parts Center for installation of abrasion boots on aircraft not so equipped.

4-19. **DESCRIPTION.** The aircraft may be equipped with two extruded rubber abrasion boots, one on the leading edge of each horizontal stabilizer. These boots are installed to protect the stabilizer leading edge from damage caused by rocks thrown back by the propeller.

4-20. **REMOVAL.** The abrasion boots can be removed by loosening one end of the boot and pulling it off the stabilizer with an even pressure. Excess adhesive or rubber can be removed with Methyl-Ethyl-Ketone.

4-21. **INSTALLATION.** Install abrasion boots as outlined in the following procedures.

- a. Trim boots to desired length.
- b. Mask off boot area on leading edge of stabilizer with one-inch masking tape, allowing 1/4-inch margin.
- c. Clean metal surfaces of stabilizer, where boot is to be installed, with Methyl-Ethyl-Ketone.
- d. Clean inside of abrasion boot with Methyl-Ethyl Ketone and a Scotch Brite pad to ensure complete removal of paraffin/talc. Then a normal wipe down with MEK on a cloth will leave surface suitable for bonding to the aluminum.

NOTE

Boots may be applied over epoxy primer, but if the surface has been painted, the paint shall be removed from the bond area. This shall be done by wiping the surfaces with a clean, lint-free rag, soaked with solvent, and then wiping the surfaces dry, before the solvent has time to evaporate, with a clean, dry lint-free rag.


- e. Stir cement (EC-1300, Minnesota Mining and Manufacturing Co.) thoroughly.
- f. Apply one even brush coat to the metal and the inner surface of the boot. Allow cement to air-dry for a minimum of 30 minutes, and then apply a second coat to each surface. Allow at least 30 minutes (preferably one hour) for drying.
- g. After the cement has thoroughly dried, reactivate the surface of the cement on the stabilizer, and boot, using a clean, lint-free cloth, heavily moistened with Toluol. Avoid excess rubbing, which would remove the cement from the surfaces.
- h. Position the boot against leading edge, exercising care not to trap air between boot and stabilizer.

NOTE

Should boot be attached "off-course", pull it up immediately, with a quick motion, and reposition it properly.

- i. Press roll entire surface of boot to assure positive contact between the two surfaces.
- j. Apply a coat of GACO N700A sealer, or equivalent, conforming to MIL-C-21067, along the trailing edges of the boot to the surface of the skin to form a neat, straight fillet.
- k. Remove masking tape and clean stabilizer of excess material.
- l. Mask to the edge of the boot for painting stabilizer.

MODEL P210 SERIES SERVICE MANUAL



Detail A

Detail B

NOTE

Remove fillets and inspect fuselage-to-wing attachment at intervals specified in section 2. Check dowel pin retaining hardware, carry-thru spar, and wing fittings thoroughly.

Lubricate dowel pins (5) with Electro Moly No. 11 (MIL-G-21164) grease upon installation.

NOTE

● When installing fairing (16), seal with Presstite 579.6 sealant approximately 3/4 inch wide strip around entire periphery on underside of fairing.

* When installing fillets (15), apply Permacel 672 tape 5/8 inch wide 3/16 inch from edge, around entire periphery on underside of fillet and seal with Inmont Corp. 576.1 sealant between tape and edge of fillet.


NOTE

If there is damage to bushings in fittings (17) or (18), notify factory before anticipating replacement, as these are critical areas.

- | | | |
|--------------|-------------------------|------------------------|
| 1. Bolt | 7. Trim Tab | 13. Stall Warning Unit |
| 2. Washer | 8. Aileron | 14. Access Plate |
| 3. Nut | 9. Tip Assembly | 15. Fillet |
| 4. Retainer | 10. Navigation Light | 16. Fairing |
| 5. Dowel Pin | 11. Bonded Leading Edge | 17. Fuselage Fitting |
| 6. Flap | 12. Pitot Tube | 18. Wing Fitting |

Figure 4-1. Wing Installation

MODEL P210 SERIES SERVICE MANUAL



NOTE

Torque bolts (5) to 70-100 lb inches

- 1. Fin Assembly
- 2. Upper Rudder Hinge
- 3. Center Rudder Hinge
- 4. Lower Rudder Hinge
- 5. Bolt
- 6. Washer
- 7. Nut
- 8. Bolt
- 9. Fairing

Figure 4-2. Vertical Fin Installation

MODEL P210 SERIES SERVICE MANUAL




Figure 4-3. Horizontal Stabilizer Installation

MODEL P210 SERIES SERVICE MANUAL

SECTION 5 LANDING GEAR, BRAKES AND HYDRAULIC SYSTEM

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand, nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire, or a component malfunction, could cause the propeller to rotate.

	Page No. Aerofiche/ Manual		Page No. Aerofiche/ Manual
TABLE OF CONTENTS			
LANDING GEAR SYSTEM	1G20/5-2	Rigging Main gear Down	
Description	1G20/5-2	Limit Switches	1H23/5-26C
Trouble Shooting	1G21/5-3	Rigging Main gear Up	
Hydraulic System Leak Check	1H1/5-7	Limit Switches	1I4/5-29
Power Pack	1H5/5-11	Main Wheel and Tire Assembly	1I4/5-29
Description	1H5/5-11	Description	1I4/5-29
On-Aircraft hydraulic power pack		Removal of Main Wheel/ Tire Assembly	1I5/5-30
Operational Checks	1H5/5-11	Disassembly of Main Wheel/ Tire Assembly	1I5/5-30
Removal	1H5/5-11	Inspection/Repair of Main Wheel/Tire Assembly	1I6/5-31
Disassembly	1H6/5-12	Reassembly of Main Wheel/ Tire Assembly	1I6/5-31
Inspection	1H7/5-13	Main Wheel Balancing/ Alignment	1I6/5-31
Reassembly	1H7/5-13	Main Wheel/Axle Removal	1I6/5-31
Installation	1H8/5-14	Main Wheel/Axle Installation	1I6/5-31
Primary and Thermal Relief Valve Assemblies	1H8/5-14	Main Gear Actuator	1I6/5-31
Bench Check of Primary and Thermal Relief Valves	1H8/5-14	Removal	1I6/5-31
Removal	1H8/5-14	Disassembly	1I6/5-31
Disassembly	1H8/5-14	Inspection	1I8/5-33
Inspection	1H9/5-15	Parts Repair/Replacement	1I8/5-33
Assembly/Adjustment	1H9/5-15	Reassembly	1I8/5-33
Installation	1H9/5-15	Installation	1I8/5-33
Pressure Switch	1H9/5-15	Main Gear Pivot Assembly	1I8/5-33
Description	1H9/5-15	Removal	1I8/5-33
Removal/Installation	1H9/5-15	Inspection/Repair	1I8/5-33
Disassembly	1H9/5-15	Installation	1I8/5-33
Inspection/Repair	1H10/5-16	Gear Position Indicator	
Reassembly	1H10/5-16	Switches	1I9/5-34
Adjustment	1H11/5-17	Description	1I9/5-34
Emergency Hand Pump	1H11/5-17	Downlock Mechanism	1I9/5-34
Description	1H11/5-17	Description	1I9/5-34
Removal/Installation	1H11/5-17	Removal/Installation	1I9/5-34
Disassembly	1H11/5-17	Downlock Actuator	1I9/5-34
Inspection/Repair	1H11/5-17	Disassembly	1I9/5-34
Reassembly	1H12/5-18	Inspection and Repair	1I9/5-34
Landing Gear Selector Valve	1H12/5-18	Reassembly	1I9/5-34
Description	1H12/5-18	Main Gear Strut Step	1I9/5-34
Removal/Installation	1H12/5-18	Description	1I9/5-34
Disassembly/Reassembly	1H13/5-19	Removal	1I9/5-34
Inspection/Repair	1H13/5-19	Installation	1I11/5-36
Rigging Throttle-Operated Gear		NOSE GEAR SYSTEM	1I11/5-36
Warning Horn Microswitch	1H13/5-19	Description	1I11/5-36
MAIN LANDING GEAR	1H13/5-19	Operation	1I11/5-36
Description	1H13/5-19	Trouble Shooting	1I12/5-37
Trouble Shooting	1H15/5-21	Removal of Nose Gear Assembly	1I12/5-37
Removal of main gear strut	1H15/5-21		
Installation of Main Gear Strut	1H15/5-21		
Rigging Main landing gear	1H19/5-25		
Rigging Main landing gear (thru P21000874)	1H19/5-26C		

MODEL P210 SERIES SERVICE MANUAL

	Page No. Aerofiche/ Manual		Page No. Aerofiche/ Manual
Disassembly of Nose Gear Assembly	1I13/5-38	Rigging Nose Gear Up Limit Switch	1I24/5-49
Inspection/Repair of Nose Gear Shock Strut Components	1I15/5-40	Rigging Nose Gear Squat Switch	1I24/5-49
Reassembly of Nose Gear Strut	1I15/5-40	Rigging Nose Gear Doors	1I24/5-49
Installation of Nose Gear Strut	1I16/5-41	Final Landing Gear Systems Check	1J3/5-52
Shimmy Dampener Description	1I16/5-41	Nose Wheel/Tire Assembly Description	1J3/5-52
Removal	1I16/5-41	Operation	1J3/5-52
Disassembly	1I16/5-41	Removal	1J3/5-52
Inspection/Repair	1I16/5-41	Disassembly	1J3/5-52
Reassembly	1I16/5-41	Inspection/Repair	1J3/5-52
Torque Links Description	1I17/5-42	Reassembly	1J3/5-52
Removal	1I17/5-42	Installation	1J5/5-54
Disassembly/Reassembly	1I17/5-42	BRAKE SYSTEM	1J5/5-54
Installation	1I17/5-42	Description	1J5/5-54
Nose Gear Downlock Mechanism Description	1I19/5-44	Trouble Shooting	1J5/5-54
Removal/Installation	1I19/5-44	Break Master Cylinder Description	1J6/5-55
Nose Gear Actuator Description	1I19/5-44	Removal	1J6/5-55
Removal	1I19/5-44	Disassembly	1J6/5-55
Disassembly	1I19/5-44	Inspection/Repair	1J6/5-55
Inspection/Repair	1I21/5-46	Reassembly	1J6/5-55
Reassembly	1I21/5-46	Installation	1J6/5-55
Installation	1I22/5-47	Hydraulic Brake Lines Description	1J6/5-55
Removal/Installation of Nose Gear Uplock/Release Actuator	1I22/5-47	Wheel Brake Assemblies Description	1J6/5-55
Nose Gear Door System Description	1I22/5-47	Removal	1J6/5-55
Removal/Installation	1I22/5-47	Disassembly	1J6/5-55
Nose Wheel Steering System Description	1I22/5-47	Inspection/Repair	1J6/5-55
Removal/Installation	1I22/5-47	Reassembly	1J8/5-57
Rigging	1I22/5-47	Installation	1J8/5-57
Trouble Shooting	1I22/5-47	Brake Linings	1J8/5-57
Rigging Nose Landing Gear	1I22/5-47	Brake Burn-in	1J8/5-57
Rigging Nose Gear Down Limit Switch	1I24/5-49	Checking Brake Lining Wear	1J8/5-57
		Installation	1J8/5-57
		Brake System Bleeding	1J9/5-58
		Parking Brake System Description	1J9/5-58
		Removal/Installation	1J9/5-58
		Inspection/Repair	1J9/5-58

5-1 LANDING GEAR SYSTEM.

5-2 DESCRIPTION. Retraction and extension of the landing gear is accomplished by a hydraulically-powered system, integrated with electrical circuits which help control and indicate gear position. Retraction and extension of the landing gear incorporates a nose gear actuator and two main gear actuators. The main gear actuators control the main gear struts through a sector gear arrangement. The nose gear doors are mechanically-operated. The doors are closed with the gear retracted and are open with the landing gear extended. The main gears have no doors. Hydraulic fluid is supplied to the landing gear actuating cylinders by an electrically-powered power pack assembly, located inside the center console. The hydraulic reservoir is an integral part of the power pack assembly. Gear selection is accomplished manually by moving a gear selector handle, located immediately left of center, in the switch panel. It is necessary to pull

out on the gear selector to move the handle up or down. For emergency extension of the gear, the selector handle must be in the DOWN position before the hand pump will energize the system. A pressure switch is mounted on the pump body. This switch opens the electrical circuit to the pump solenoid when pressure in the system increases to approximately 1500 psi. The pressure switch will continue to hold the electrical circuit open until pressure in the system drops to approximately 1000 psi. This will occur whether the gear selector handle is in either the UP or DOWN position. During a normal cycle, landing gear extended and locked can be detected by illumination of the gear DOWN indicator (green) light. The GEAR UNSAFE (red) light is on anytime the gear is in transit (retract or extend), or whenever system pressure drops below 1000 psi with the safety (squat) switch closed. The nose gear squat switch, activated by the nose gear, electrically averts inadvertent retraction when ever the nose gear strut is compressed by weight of the airplane.

MODEL P210 SERIES SERVICE MANUAL

NOTE

It is possible to have the red and green lights on momentarily at the same time after the completion of the extend cycle, or when rotating during takeoff. However, if both stay on after the completion of the extend cycle, or if the red light stays on longer than 6 to 8 seconds during the retract cycle, a malfunction has occurred.

5-3. TROUBLE SHOOTING.

Just because this chart lists a probable cause, proper checkout procedures cannot be deleted and the replacement of a part is not necessarily the proper solution to the problem. The mechanic should always look for obvious problems such as loose or broken parts, external leaks, broken wiring, etc. To find the exact cause of a problem, a mechanic should use a hand pump, pressure gage and a voltmeter to iso-

late each item in the system. Hydraulic fluid will foam if air is pumped into system, causing fluid to be blown overboard thru pack vent line. The problems listed are all with the systems controls in their normal operating position: Master switch ON, Hydraulic pump breaker IN and landing gear breaker IN. During landing gear system servicing, a power supply capable of maintaining 27.5 volts throughout the gear cycle must be used to augment the ship's battery.

CAUTION

Prior to using Hydro-Test unit with power pack, Remove and dry off filler plug and dipstick. Adjust cap tension so that no movement of cap is apparent. Failure to accomplish these procedures could result in filler cap coming loose from power pack.

TROUBLE	PROBABLE CAUSE	REMEDY
MOTOR PUMP WILL NOT OPERATE GEAR BUT EMERGENCY HAND PUMP WILL OPERATE GEAR.	Low voltage (in flight).	Check alternator and wiring.
	Fluid level low in reservoir.	Refill reservoir.
	Motor pump failure.	Replace pump.
	Faulty check valve	Replace valve
	NOTE	
	Motor and pump are not repairable and must be replaced.	
	Pump frozen.	Remove motor and coupling from top of power pack and replace pump.
	Broken pump or motor drive shaft or coupling.	Remove motor and pump from top of power pack and replace motor, pump and coupling.
	If motor was not turning, check wiring and motor.	Check motor for loose or broken connections; check for frozen pump or coupling. Check circuit breaker in pedestal.
	Bad pump shaft seal.	Replace pump.
External leakage around top of pump assembly.	Remove motor and pump assemblies from top of power pack and replace upper packing and/or back-up rings.	
Air lock in pump (new pack installation or pump replacement).	Remove filter and intermittently bump start switch until fluid flows. Replace filter.	
PUMP OR EMERGENCY PUMP WILL NOT BUILD PRESSURE IN SYSTEM	No fluid in reservoir.	Refill reservoir.

MODEL P210 SERIES SERVICE MANUAL

5-3. TROUBLE SHOOTING (Cont)

TROUBLE	PROBABLE CAUSE	REMEDY
PUMP OR EMERGENCY PUMP WILL NOT BUILD PRESSURE IN SYSTEM. (Cont).	Broken hydraulic line.	Check for evidence of leakage and repair or replace line. Flush out system and refill reservoir.
	Bad O-ring actuator piston; O-ring left out after repair.	Disconnect line upstream from actuator and check for pressure. Perform this check for all actuators in system.
	Bad O-ring on gear control valve.	Replace O-ring.
	Thermal relief valve stuck open.	Replace valve.
HAND PUMP DOES NOT BUILD PRESSURE, BUT ELECTRIC PUMP OPERATES PROPERLY.	Check valve in hand pump sticking.	Inspect check valve.
	Defective hand pump outlet check valve.	Replace valve.
	Main gear or downlock actuator O-ring leaking.	Disassemble actuator and replace O-rings.
	Filter in outlet check valve improperly positioned in filter body, or seal between filter and check valve improperly positioned.	Replace seal and position filter in retainer with Petrolatum.
LANDING GEAR OPERATION EXTREMELY SLOW.	Downlock rod adjustment incorrect (mainly LH rod).	Adjust rod end to lengthen actuator one turn.
	Pump failure.	Replace pump.
	Low voltage in electrical system.	Check alternator and wiring.
	Pump motor brushes worn.	Replace pump motor.
	Fluid leak in gear line.	Locate and repair or replace broken line or fitting.
	Excessive internal power pack leakage.	Remove and repair or replace power pack.
POWER PACK EXTERNAL LEAKAGE.	Static seals (all fittings).	Remove and replace O-rings and/or back-up rings as required. Check tubing flares for leaks.
	Reservoir cover.	Remove power pack and remove cover; replace seals.
GEAR DOWN-LOCK WILL NOT RETURN TO FULL-LOCK POSITION.	Binding in spring and tube assemblies.	Check operation to locate binding and eliminate.

MODEL P210 SERIES SERVICE MANUAL

5-3. TROUBLE SHOOTING. (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
LANDING GEAR FAILS TO RETRACT.	Hydraulic pump motor circuit breaker open.	Reset, determine cause for opening. Repair or replace components as necessary.
	Instrument panel gear indicator circuit breaker open.	Reset breaker. Determine cause for tripped breaker.
	Hydraulic pump motor circuit wires disconnected or broken.	Repair or replace wiring.
	Instrument panel gear indicator circuit wires disconnected or open.	Repair or replace wiring.
	Nose gear squat switch inoperative.	Install new switch.
	Pressure switch defective.	Install new switch.
	Hydraulic pump motor solenoid defective.	Install new solenoid.
	Hydraulic pump motor ground.	Check for ground.
	Hydraulic pump motor defective.	Replace motor.
	Reservoir fluid level below operating level.	Fill reservoir with hydraulic fluid.
Battery low or dead.	Check battery condition. Install new battery.	
GEAR RETRACTION OR EXTENSION EXTREMELY SLOW.	Reservoir fluid level below operating level.	Fill reservoir with hydraulic fluid (Refer to Section 2).
	Restriction in hydraulic system.	Isolate and remove restrictions.
PUMP MOTOR STOPS BEFORE GEAR IS RETRACTED.	Hydraulic pump motor circuit breaker open.	Reset, determine cause for opening. Repair or replace components as necessary.
	Instrument panel gear indicator circuit breaker open.	Reset circuit breaker. Determine cause of tripped circuit breaker.
	Pressure switch out of adjustment.	Remove, adjust or install new switch.
	Restriction in hydraulic system, allowing pressure to build up and shut off pump motor before gear is retracted.	Isolate and determine cause. Remove restriction.
PUMP MOTOR STOPS BEFORE GEAR IS EXTENDED.	Hydraulic pump motor circuit breaker open.	Reset, determine cause for opening. Repair or replace components as necessary.
	Instrument panel gear indicator circuit breaker open.	Reset circuit breaker. Determine cause of tripped circuit breaker.

MODEL P210 SERIES SERVICE MANUAL

5-3. TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
PUMP MOTOR CONTINUES TO RUN AFTER GEAR IS FULLY RETRACTED OR EXTENDED.	Pressure switch defective.	Install new switch.
	Pressure switch out of adjust.	Remove, adjust or install new switch.
	Hydraulic pump motor solenoid defective.	Install new solenoid.
	Internal leakage in system.	Check actuators for internal leakage. Repair or install new actuators.
	External system leakage.	Check all lines and hose for leakage. Repair or install new parts.
	Power pack relief valve out of adjustment.	Disassemble and repair or replace valve assembly.
	Hydraulic motor solenoid defective.	Install new solenoid.
PUMP MOTOR CYCLES EXCESSIVELY AFTER GEAR IS RETRACTED.	Pressure switch out of adjustment.	Remove, adjust or install new switch.
	Internal leakage in system.	Check actuators for internal leakage. Repair or install new actuators.
	External system leakage.	Check all lines and hose for leakage. Repair or install new parts.
GEAR DOES NOT FULLY RETRACT, BUT PUMP MOTOR CONTINUES TO RUN.	Internal leakage in system.	Check actuators for internal leakage. Repair or install new actuators.
	Reservoir fluid level below operating level.	Fill reservoir with hydraulic fluid (Refer to Section 2).
LANDING GEAR FAILS TO EXTEND.	Battery low or dead.	Check battery condition. Install new battery.
	Hydraulic pump motor circuit breaker open.	Reset, determine cause for opening. Repair or replace components as necessary.
	Instrument panel gear indicator circuit breaker open.	Reset circuit breaker. Determine cause of tripped circuit breaker.
	Hydraulic pump motor circuit wires disconnected or broken.	Repair or replace wiring.
	Hydraulic pump motor solenoid defective.	Install new solenoid.

MODEL P210 SERIES SERVICE MANUAL

5-3. TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
LANDING GEAR FAILS TO EXTEND(cont).	Hydraulic pump motor ground.	Check ground.
	Hydraulic pump motor defective.	Replace motor.
	Reservoir fluid level below operating level.	Fill reservoir with hydraulic fluid (Refer to Section 2.)
	Nose gear contacts stop bolts.	Adjust stop bolts to obtain proper clearance. (Refer to paragraph 5A-87).
RH GEAR UNLOCKS BUT LH GEAR WILL NOT UNLOCK.	Improper setting of RH downlock actuator rod.	Check rigging procedures outline in this Section.
BOTH RH AND LH MAIN GEAR UNLOCK BUT ONLY NOSE GEAR WILL RETRACT.	Improper setting of LH downlock actuator rod.	Check rigging procedures outlined in this Section.
MOTOR PUMP WILL NOT TURN ON BY WORKING SELECTOR SWITCH. HAND PUMP WILL PUT GEAR DOWN.	Defective pressure switch circuit.	Check circuit continuity.
		Check switch adjustment.
SET SCREW ON CAM NOT EXTENDED ENOUGH FOR GEAR TO MOVE CAM OVER CENTER.	Check washers under bolt on downlock arm assembly.	Add AN960-10 washer under bolt downlock arm assembly.
MAIN GEAR WILL NOT LOCK OVER CENTER.	Main gear not centered in support.	Rerig saddle per rigging instructions.
MALFUNCTION OF GEAR INDICATOR LIGHTS.	<ol style="list-style-type: none"> 1. Both lights on at same time. 2. Light will change from green to amber or in reverse when gear control switch is moved. 	Check ground wire for proper connection.

5-4. HYDRAULIC SYSTEM LEAK CHECK. (Refer to figure 5-2.)

- a. Jack airplane in accordance with procedures outlined in Section 2 of this Manual.
- b. To relieve system pressure, pull the GEAR PUMP circuit breaker to OFF and move the gear selector handle to UP and back to the DOWN position.
- c. Install a 0-2000 PSI gage at the service tee (Index 29, figure 5-3) on the left-hand side of the power pack.
- d. Push the GEAR PUMP circuit breaker to the ON position, turn ON the master switch and move the gear selector handle to the UP position.
- e. Monitor pressure gage after retraction cycle is complete for pressure bleed down.
- f. If bleed down occurs, it can be an internal or external leak anywhere in the system.

NOTE

When any line is disconnected, be prepared for fluid leakage.

- g. Disconnect the return line from the gear selector. If fluid comes from the selector, the internal leak is in the system.
- h. If no leak is found, it can be assumed there is an internal leak in the power pack. If leak is found proceed to step "j". Reconnect the return line.
- i. Power pack internal leakage can only be attributed to a bad thermal relief valve, check valve or check valve O-ring. The only way to isolate part that is leaking is to systematically replace the check valve O-ring, check valve, and then thermal relief valve.

MODEL P210 SERIES SERVICE MANUAL




Figure 5-1. Landing Gear Schematic (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 5-1. Landing Gear Schematic (Sheet 2 of 2)




Figure 5-2. Landing Gear System Component Locator

MODEL P210 SERIES SERVICE MANUAL

Repeat leak test after replacement of each part to ensure leak correction.

- j. Remove gear DOWN line from the selector. If fluid comes from the line, one or more of the gear actuators is leaking. To locate the leaking actuator, disconnect the return line from each actuator, the leaking actuator will have fluid draining from the actuator port. Following the appropriate paragraphs in this section, remove, overhaul and reinstall the actuator.
- k. Reconnect gear down line to the selector.
- l. Recheck all lines that were disconnected for security.
- m. Lower the landing gear. Following the procedures in step "b", relieve the system pressure.
- n. Remove the pressure gage from the service tee.
- o. In accordance with the procedures in Section 2 of this Manual, replenish the power pack reservoir with MIL-H-5606 hydraulic fluid and bleed the system.
- p. Remove aircraft from jacks.

5-5. POWER PACK. (Refer to figure 5-3)

5-6. DESCRIPTION. The hydraulic power pack located in the pedestal, is a multi-purpose unit. It contains a hydraulic reservoir, valves, an electrically driven motor, and the pump. An emergency hand pump, located between the pilot's and copilot's seats. Uses reservoir fluid to permit extension of the landing gear.

NOTE

The hydraulic power pack primary relief valve, thermal relief valve, and pressure switch can be operationally checked on the aircraft without power pack removal from the aircraft or disassembly. Refer to paragraph 5-6A. for specific instructions. Refer to paragraph 5A-12A for primary and thermal relief valve bench check instructions if the power pack is removed from aircraft.

5-6A. ON-AIRCRAFT HYDRAULIC POWER PACK OPERATIONAL CHECKS. (Refer to figure 5-3.) The primary and thermal relief valves and pressure switch should be pressure checked each 100 hours. They can be operationally checked without removal from aircraft. For bench check instructions after removal from power pack, refer to paragraph 5A-12A.

NOTE

Checks are to be performed with external power set at 28.5 volts.

- a. **Primary Relief Valve.**
 - (1) Jack aircraft in accordance with procedures outlined in Section 2.
 - (2) Remove cap and install pressure gage at tee (29) fitting on left side of power pack.
 - (3) Pull landing gear circuit breaker.
 - (4) Select landing gear handle to DOWN position.
 - (5) Install 18 gage (minimum) jumper wire between buss side of contactor and small terminal on pump motor contactor (to energize coil).
 - (6) Push landing gear circuit breaker in; power pack should run; monitor pressure.
 - (7) Primary relief valve should open at 1800 PSI, +0 or -50 PSI.
 - (8) After check is complete, remove pressure from system, remove pressure gage, install cap on tee (29), pull landing gear circuit breaker, remove jumper wire, push

landing gear circuit breaker back in, and return system to original configuration.

b. Thermal Relief Valve.

- (1) With aircraft on jacks and pressure gage installed at tee (29) fitting on left side of power pack, pull landing gear circuit breaker.
- (2) Select landing gear to DOWN position.
- (3) Extend emergency gear pump handle.
- (4) Pump emergency gear pump handle and monitor pressure. Thermal relief valve should open at 2200 PSI, -0 or +50 PSI.
- (5) After check is complete, remove pressure from system, remove pressure gage, and install cap on tee (29).
- (6) Push in landing gear circuit breaker, and return system to original configuration.

c. Pressure Switch.

- (1) With aircraft on jacks and pressure gage installed at tee (29) fitting on left side of power pack, pull landing gear circuit breaker.
- (2) Select landing gear UP and DOWN several times to relieve pressure in landing gear system.
- (3) Select landing gear UP, and push in landing gear circuit breaker.
- (4) After gear raising cycle is complete, check pressure. Pressure should be 1500 PSI.
- (5) Select gear DOWN. After gear lowering cycle is complete, pressure should be 1500 PSI.
- (6) After check is complete, remove pressure from system, remove pressure gage, install cap on tee, and return system to original configuration.

5-7. REMOVAL. (Refer to figure 5-3.)

- a. Jack aircraft in accordance with procedures outlined in Section 2 of this manual.
- b. Turn master switch OFF and place gear selector handle in a neutral position to relieve system pressure. After 15 seconds, return gear selector handle to DOWN position


NOTE

As hydraulic lines are disconnected or removed, plug or cap all openings to prevent entry of foreign material into the lines or fittings.

- c. Remove front seats and spread drip cloth over front carpet.
- d. Remove decorative cover from pedestal as outlined in Section 9 of this manual.
- e. Remove upper panel assembly from aft face of pedestal.
- f. Remove screws attaching indicator assembly at top of pedestal; remove indicator assembly.
- g. Remove four bolts attaching wheel and gear box assembly; remove wheel and gear box assembly.
- h. Loosen idler sprocket assembly by loosening bolt and sliding sprocket inboard in slot.
- i. Disconnect chin at connecting link.
- j. Remove left-hand and right -hand chain guards.
- k. Allow chain to remain on gimbal assembly in lower pedestal area.
- l. Position gallon container under drain elbow at right-hand side of pedestal.
- m. Remove cap from elbow and attach drain hose. bracket to sides of pedestal.
- n. Using hand pump, drain reservoir fluid into container.
- o. Disconnect and cap or plug all hydraulic lines at power pack.
- p. Disconnect wiring at pressure switch.

MODEL P210 SERIES SERVICE MANUAL

1. Packing
2. Dipstick
3. Pressure Switch
4. Packing
5. Body Assembly
6. Packing
7. Packing
8. Thermal Relief Valve
9. Bolt
10. Bolt
11. Washer
12. Packing
13. Reservoir
14. Primary Relief Valve
15. Hydraulic Pump
16. Packing
17. Coupling
18. Packing
19. Fluid Filter Screen
20. Self Relieving Check Valve
21. Packing
22. Filter Assembly Self-Relieving Check Valve
23. Retainer
24. Back-Up Ring
25. Motor Assembly
26. Bolt
27. Packing
28. Washer
29. Tee



NOTE

Install new packings and back-up rings lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

Figure 5-3. Hydraulic Power Pack Assembly (Sheet 1 of 2)

- q. Remove three mounting bolts, one at the forward side of power pack, and two, attaching power pack bracket to sides of pedestal.
- r. Remove power pack and bracket from pedestal.

NOTE

It should not be necessary to disturb studs on left and right sides of pedestal to remove power pack.

5-8. DISASSEMBLY. (Refer to figure 5-3.)

- a. Remove bolts (10), washers (11), and packing (12) from reservoir (13).
- b. Remove reservoir (13) from body assembly (5).

NOTE

If reservoir will not disengage from body, assembly (5), install a capped fitting in the pressure and return openings of the power pack assembly and attach an air hose to vent fitting at top of body assembly (5). Apply air pressure (not to exceed 15 PSI, reservoir proof pressure), and remove reservoir (1). A strap clamp is not recommended as clamp may damage reservoir.

- c. Remove packing (6) from body assembly (5).

NOTE

Disassembly of relief valves (14) and (8) is normally not required. Refer to applicable paragraphs for specific instructions regarding relief valves. Before removal, tag each relief valve (primary) or (thermal) to ensure correct reinstallation.

- d. Cut safety wire and remove relief valve assemblies (14), and (8) from body assembly (5).
- e. Remove dipstick (2), and fluid filter screen (19) from body assembly (5).
- f. Remove retainer (23), filter assembly self-relieving check valve (22), back-up ring (24), packing (1), packing (21), and self-relieving check valve (20) from body assembly (5).

MODEL P210 SERIES SERVICE MANUAL




Figure 5-3. Hydraulic Power Pack Assembly (Sheet 2 of 2)

NOTE

If self-relieving check valve (20) will not fall from hole in body assembly (5), place a drift or punch made of soft material into the pressure opening of body assembly and tap spacer from body assembly.

- g. Remove pressure switch (3) and packing (4) from body assembly (5).
- h. Remove bolts (9) attaching hydraulic pump (15) to body assembly (5), and remove pump (15) and coupling (17) from body assembly. Remove packings (18) and (7).
- i. Remove motor assembly (25) from body assembly (5) by removing attaching bolts (26).

5-9 INSPECTION. (Refer to figure 5-3.)

- a. Wash all parts in cleaning solvent (Federal

Specification P-S-611, or equivalent) and dry with filtered air.

- b. Inspect all threaded surfaces for serviceable condition and cleanliness.
- c. Inspect all parts for scratches, scores, chips, cracks and indications of excessive wear.
- d. Clean to ensure that all screens and filters are completely clean and undamaged.

5-10. REASSEMBLY. (Refer to figure 5-3.)

NOTE

Install new packings and back-up rings lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

MODEL P210 SERIES SERVICE MANUAL

- a. Using new packings (7) and (18), install hydraulic pump (15) and coupling (17) into body assembly (5) with bolts (9).
- b. Install motor assembly (25) on top of body assembly (5) after aligning coupling (17) to match mating connection in motor. Secure motor to body with bolts (26), safety-wire bolts as shown in View A-A.
- c. Using new packing (4), install and tighten pressure switch (3) onto body assembly (5).
- d. Using new back-up ring (24) and packings (1) and (21), install and tighten self-relieving check valve (20), filler assembly self-relieving check valve (22) and retainer (23) into body assembly (5).
- e. Install primary relief valve (14) and thermal relief valve (8) assemblies along with packings (27) and (16) onto body assembly (5).

CAUTION

Ensure that relief valves are installed in their correct location. Refer to View A-A.

- f. Install fluid filter screen (19) and dipstick (2) into body assembly (5).

NOTE

Safety-wire relief valves (14) and (8) to hydraulic pump mounting bolts (9) as shown in view A-A.

- g. Using new packing (6), washers (11) and (28), and packing (12), install and tighten reservoir (13) onto body assembly (5).
- h. Torque bolts (10) to 30-35 inch-pounds.

5-11 INSTALLATION. (Refer to figure 5-3.)

- a. Work power pack and bracket assembly into position and install three bolts, securing power pack to pedestal.
- b. Connect all hydraulic lines to power pack fittings. Ensure that all fittings are properly installed, with jamnuts tight, after lines are tightened.
- c. Install wheel and gear box assembly and indicator assembly in top of pedestal.
- d. Install left-hand and right-hand chain guards for rubber trim chain.
- e. Connect chain at connecting link after stringing chain over idler sprocket.
- f. Tighten idler sprocket assembly by sliding sprocket outboard in slot and tightening bolt.
- g. Connect ground wire to pressure switch (3), and wire to motor.
- h. Connect power pack wiring to plug.
- i. Install upper panel assembly on pedestal.
- j. Fill reservoir (13) on right-hand side of power pack with clean hydraulic fluid in accordance with procedures outlined in Section 2 of this manual.
- k. Operate gear through several cycles to bleed system. Check for correct operation and signs of fluid leakage. A 28 volt power supply should be used to augment the aircraft's battery.

5-12 PRIMARY AND THERMAL RELIEF VALVE ASSEMBLIES. (REFER TO FIGURE 5A-3)

The primary relief valve (14), located between the self-relieving check valve (20) and hydraulic pump (15), serves to limit that amount of pressure which can be generated by the hydraulic pump. The thermal relief valve (8), located on the system side of the self-relieving check valve (20), serves to limit the system pressure. System pressure may increase due to thermal expansion. Both valves are identical except for differing pressure relief settings. Refer to figure 5-4.

5-12A BENCH CHECK OF PRIMARY AND THERMAL RELIEF VALVES. (Refer to figure 5-4).

NOTE

The hydraulic power pack primary relief valve, thermal relief valve, and pressure switch can be operationally checked on the aircraft without power pack removal from the aircraft or disassembly. Refer to paragraph 5-6A for specific instructions.

If on-aircraft pressure checking of the power pack reveals out-of-tolerance relief valve opening, it may be necessary to determine if relief valve disassembly or adjustment is necessary. Once removed from power pack, individual relief valves can be bench checked.

NOTE

Adequate precautions should be taken to recover hydraulic fluid which will be expelled from the primary relief valve while under pressure.

CAUTION

As primary and thermal relief valves are identical except for differing pressure relief settings, special care should be exercised to ensure relief valves are reinstalled in their correct locations. (Refer to figure 5-3, view A-A).

a. Primary Relief Valve.

- (1) Using a hydraulic pump with a flow rate of 0.5 to 0.7 gallons per minute connected to a hydraulic reservoir, a pressure gage with 2500 PSI capacity, and a hose with appropriate fittings, connect hydraulic pump to adapter (2) of the primary relief valve.
- (2) Apply pressure slowly to ensure that relief valve assembly opens at correct pressure reading. Primary relief valve should open at 1800 PSI, +0 or -50 PSI. Refer to paragraph 5A-15 for adjustment instructions.

b. Thermal Relief Valve.

- (1) Using a hand pump connected to a hydraulic reservoir, a pressure gage with 2500 PSI capacity, and a hose with appropriate fittings, connect hand pump to adapter (2) of the thermal relief valve.
- (2) Manually pump pressure up slowly to ensure that relief valve assembly opens at correct pressure reading. Thermal relief valve should open at 2200 PSI, -0 or +50 PSI. Refer to paragraph 5A-15 for adjustment instructions.

5-13 REMOVAL. (Refer to figure 5-3).

- a. Cut safety wire and remove primary relief valve (14) and thermal relief valve (8) from body assembly (5).

5-14 DISASSEMBLY. (Refer to figure 5A-4.)

NOTE

Relief valve assemblies (5) and (23) are preset by the factory and normally will not require disassembly.

- a. Remove jamnut (13) and adjustment screw (12) from housing (8).
- b. Remove spring (11), guide (10), balls (6), and piston (9) from housing (8).
- c. Loosen jamnut (7) and remove adapter (2) from housing (8).
- d. Remove poppet (4) and orifice (3) from adapter (2).

MODEL P210 SERIES SERVICE MANUAL




Figure 5-4. Relief Valve Assembly

5A-15 INSPECTION. (Refer to figure 5A-4).

- a. Wash all parts in cleaning solvent (Federal Specification P-S-611 or equivalent) and dry with filtered air.
- b. Inspect all threaded surfaces for serviceable condition and cleanliness.
- c. Inspect all parts for scratches, scores, chips, cracks, and indications of excessive wear.

5A-16 ASSEMBLY AND ADJUSTMENT. (Refer to figure 5A-4).

NOTE

Use new packings during reassembly. Lubricate all packings with MIL-H-5606 hydraulic fluid. Lubricate threads with Petrolatum.

- a. Install orifice (3) and poppet (4) into adapter (2). (New packing (5) must be installed on poppet (4)).
- b. Install jamnut (7) and housing (8) on adapter (2).
- c. Tighten adapter (2) into housing (8) and torque to 100-150 lb-in.
- d. Tighten jamnut (7) against housing (8), and torque to 100-150 lb-in.
- e. Install one ball (6) into housing (8), so that it rests on poppet (4). Install piston (9) into housing (8), then install remaining ball (6) into end of piston (9).
- f. Insert guide (10) and spring (11) into housing (8), making sure that balls (6) and piston (9) remain in correct position.
- g. Turn adjustment screw (12) into housing (8) until it just contacts spring (11), then turn in one additional turn. Start jamnut (13) onto adjustment screw (12) and snug against housing (8).

h. Connect hydraulic pump with a flow rate of 0.5 to 0.7 gallons-per-minute and a pressure gage with 2500 PSI capacity to relief valve. Apply pressure slowly to ensure that relief valve assembly opens at correct pressure reading. Primary relief valve opens at 1800 PSI, +0 or -50 PSI and reset at 1500 PSI MINIMUM (no leakage). Thermal relief valve opens at 2200 PSI, +50 or -0 PSI.

i. If adjustment of either relief valve is necessary, loosen jamnut (13) and turn adjustment screw (12) in to increase pressure or back adjustment screw (12) out to decrease pressure. Tighten jamnut (13) against housing (8) and torque to 100-150 lb-in. Recheck pressure adjustments.

5-17. INSTALLATION. (Refer to figure 5A-3).

a. Install relief valve assemblies (8) and (14) along with new packings onto body assembly (5).

CAUTION

Ensure that relief valves are installed in their correct locations. (Refer to View A-A). Safety wire relief valves as shown in View A-A.

5-18. PRESSURE SWITCH. (Refer to figure 5-5).

5-19. DESCRIPTION. A pressure switch is located in the cover of the power pack. The switch opens the electrical circuit to the pump solenoid when the pressure in the system increases to approximately 1500 PSI. The pressure switch will continue to hold the electrical circuit open until pressure in the system drops to approximately 1000 PSI, at which time, the pump will again operate to build up pressure to approximately 1500 PSI, regardless of gear selector handle position.

NOTE

The hydraulic power pack primary relief valve, thermal relief valve, and pressure switch can be operationally checked on the aircraft without power pack removal from the aircraft or disassembly. Refer to paragraph 5-6A for specific instructions.

5-20. REMOVAL AND INSTALLATION. (Refer to figures 5-3 and 5-5).

- a. Move left seat to full aft position and spread a drip cloth beneath power pack.
- b. Assure that master switch is OFF, and disconnect leads at terminals at pressure switch.
- c. Remove pressure switch from power pack.
- d. Reverse procedures for installation.

5-21. DISASSEMBLY. (Refer to figure 5-5).

- a. Remove bolt pin (10).
- b. Unscrew housing (11) from fitting (2).
- c. Remove spring (9).
- d. Remove washers (8) from flange of stop (7).

NOTE

Chart in figure 5-6 lists washers by part number, thickness and effect on operating pressure PSI.

MODEL P210 SERIES SERVICE MANUAL




Figure 5-5. Pressure Switch

e. Unscrew guide (5) from fitting (2).

NOTE

Do not damage lip of guide (5). Threads of guide (5), snubber (1), and internal threads of fitting (2) are primed with Loctite grade T primer and sealed with Loctite grade AV sealer.

- f. Remove piston (6).
- g. Remove seal (3) and packing (4).
- h. Remove snubber (1) from fitting (2).

5-22. INSPECTION AND REPAIR. (See figure 5-5.)

- a. Clean sealant from threads of snubber (1), fitting (2) and guide (5) with wire brush.
- b. Clean all parts with cleaning solvent (Federal Specification P-S-661, or equivalent, and dry thoroughly.
- c. Discard seal (3) and packing (4), and replace with new parts.
- d. Inspect all pressure switch parts for scratches, scores, chips, cracks and indications of wear.
- e. All damaged parts shall be replaced with new parts.

- f. Snubber (1) can be cleaned with solvent, then blown out with high pressure compressed air.
- g. Assure that 0.062-inch vent hole is open in stop (7).

5-23. REASSEMBLY. (Refer to figure 5-5).

NOTE

Threads of snubber (1), guide (5), and internal threads of fitting (2) are to be primed with Loctite grade T primer and sealed with Loctite grade AV sealant. Allow primer to cure for a minimum of three minutes before sealant application. Allow sealant to set from five to 40 minutes after assembling parts.

NOTE

Install new seal (3) and packing (4) and existing piston (6), stop (7) and spring (9), lubricated with a film of Petrolatum VV-P-238, Hydraulic fluid MIL-H-5606, or Dow-Corning DC-7. Lubricate guide (5), however, keep lubricant away from threaded end of part.

MODEL P210 SERIES SERVICE MANUAL

- a. Install snubber (1) into fitting (2) and tighten with slotted screwdriver.
- b. Install packing (4) in fitting (2).
- c. Install seal (3) in guide (5).
- d. Install guide (5) into fitting (2) and finger tighten.

NOTE

It is possible to assemble, fill and test the pressure switch in the aircraft. This can be accomplished by the installation of a test gage in the capped port of the tee fitting on the right-hand side of the power pack, and pumping the emergency hand pump. Master switch must be OFF and selector handle must be in DOWN position.

- e. After installing test fitting and assuring that sealant in fitting (2) is dry, screw fitting assembly into power pack body.
- f. Pump emergency hand pump just enough for fluid to seep from top of guide (5). (Refer to Section 2 of this Manual.)
- g. Insert piston (6) into hole in guide (5).
- h. Install stop (7) over guide (5).
- i. Install exact number and thickness of washers removed.
- j. Install spring (9) over washers (8).
- k. Screw housing (11) on fitting (2).

NOTE

If same number of washers (8) are installed as were removed, pressure should not require readjustment. If readjustment is necessary, the washer applicability table lists washer part numbers, thickness, and effect in pressure. Washers are available from the Cessna Supply Division.

- l. Check fluid level in power pack reservoir. (Refer to Section 2 of this Manual.)

5-24. ADJUSTMENT. (See figure 5-5.)

- a. Jack aircraft as outlined in Section 2 of this Manual.)
- b. Screw housing (11) on fitting (2), enough to bottom out against stop (7).
- c. Adjust switch (12) to bottom out plunger against stop (7).
- d. Turn housing (11) back from full thread engagement one turn, plus 0, minus one-fourth turn to locate hole in fitting (2) in slot in skirt of housing assembly (11).
- e. Attach electrical connections to pressure switch and attach external power source.
- f. Turn master switch ON.
- g. Pump emergency hand pump to obtain 1500 ± 50 psi.
- h. The switch should open the electrical circuit to the pump solenoid when pressure in the system increases to approximately 1500 ± 50 psi.
- i. If switch opens electrical circuit prematurely, disassemble pressure switch down to washers (8)

- and add washers (8) as necessary to obtain desired pressure; repeat steps "b" and "d" only if switch (12) was loosened during this step. (But not "c".)
- j. If switch opens electrical circuit later than 1500 ± 50 psi, disassemble pressure switch down to washers (8) and remove washers (8) as necessary to obtain desired pressure; repeat steps "b" and "d" only if switch was loosened with this step.
- k. After final pressure adjustment, install pin (10) in slot of housing (11).
- l. Turn master switch OFF.

5-25. EMERGENCY HAND PUMP. (Refer to figure 5-6.)

5-26. DESCRIPTION. The emergency hand pump is mounted below the floor between the pilot and co-pilot seats. The pump handle extends to the cabin. The pump supplies a flow of pressurized hydraulic fluid to extend the landing gear in the event of normal hydraulic pump failure.

5-27. REMOVAL AND INSTALLATION.

- a. Remove seats as required for access.
- b. Remove screws attaching cover over hand pump and remove cover.
- c. Peel back carpet as required for access to pump mounting bolts.
- d. Wedge cloth under hydraulic fittings to absorb fluid, then disconnect the two hydraulic lines and plug or cap open fittings to prevent entry of foreign material.
- e. Remove two bolts, washers and nuts securing pump to mounting bracket.
- f. Work pump from aircraft.
- g. Install hand pump by reversing the preceding steps, bleeding lines and pump as lines are connected.
- h. Fill reservoir as required.

5-28. DISASSEMBLY. (Refer to figure 5-6.)

NOTE

After emergency hand pump has been removed from aircraft, and ports are capped or plugged, spray with cleaning solvent (Federal Specification P-S-611, or equivalent) to remove all accumulated dust or dirt. Dry with filtered compressed air.

- a. Remove hand pump handle by removing pivot and linkage pins after removing cotter pins.
- b. Remove end fitting from body assembly.
- c. Push piston from body assembly.
- d. Remove retaining ring from end fitting to remove valve assemblies.
- e. Remove and discard all O-rings and back-up rings.

5-29. INSPECTION AND REPAIR.

- a. Inspect seating surfaces of valves.

MODEL P210 SERIES SERVICE MANUAL




Figure 5-6. Emergency Hand Pump

b. Inspect piston for scores, burrs or scratches which could cut O-rings. This is a major cause of external and internal leakage. The piston may be polished with extremely fine emery paper. Never use paper coarser than No. 600 to remove scratches or burrs. If defects do not polish out, replace piston.

NOTE

Install new packing (9), (17) and back-up rings (7), lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606 or Dow-Corning DC-7.

5-30. REASSEMBLY. (Refer to figure 5-6.) Assemble the emergency hand pump, using the figure as a guide. Also, for detailed instructions, reverse the procedures outlined in paragraph 5-28.

5-31. LANDING GEAR SELECTOR VALVE. (Refer to figure 5-7.)

5-32. DESCRIPTION. A mechanical gear position selector valve is located on the switch panel. The pilot shuttles the valve mechanically when he changes gear handle position. The handle must be pulled out prior to selecting gear position. Moving the selector rod opens and closes ports in the valve, enabling fluid under pressure to flow to the various system components to retract or extend the gear.

5-33. REMOVAL AND INSTALLATION. (Refer to figure 5-7.)

a. Remove knob (5) from rod (14).

MODEL P210 SERIES SERVICE MANUAL




Figure 5-7. Gear Selector Valve

CAUTION

As hydraulic lines are disconnected, fluid will leak. Precautions must be taken to prevent excessive leakage, such as spreading drip cloths under fittings and capping lines and fittings.

- b. Disconnect hydraulic lines routed to valve.
- c. Remove screws attaching valve to instrument panel.
- d. Remove selector valve.
- e. Reverse preceding steps to install gear selector valve.

5-34. DISASSEMBLY AND REASSEMBLY. (Refer to figure 5-7.)

- a. Remove cover (1), retaining ring (2) and cap (3).
- b. Remove cotter pin (15), washer (6), and spring (7).
- c. Pull rod (14) from disc (9); remove disc.
- d. Remove seals (11) and springs (12).
- e. Reverse preceding steps for reassembly.

5-35. INSPECTION AND REPAIR. (Refer to figure 5-7.) Replace packing (8) and (10). Check valve for wear, foreign or abrasive materials. Disc (9) may be refaced (lapped) if worn or abraded.

5-36. RIGGING THROTTLE-OPERATED GEAR WARNING HORN MICRO-SWITCH. (Refer to figure 5-8.) Rigging procedures for sea level or turbo-charged aircraft are outlined in figure 5-8.

5-37. MAIN LANDING GEAR. (Refer to figure 5-9.)

5-38. DESCRIPTION. The tubular main gear struts rotate aft and inboard to stow the main wheels beneath the baggage compartment. The main gear utilizes hydraulic pressure for positive uplock and mechanical downlocks. Main gear uplock pressure is maintained automatically by the pump assembly. Rotation of the gear to extend or retract the struts is achieved through pivot assemblies which in turn are bolted through a splined shaft, to the hydraulic main gear rotary actuators.

CAUTION

Use of recapped tires or new tires not listed on the aircraft equipment list are not recommended due to possible interference between the tire and structure when landing gear is in the retracted position.


MODEL P210 SERIES SERVICE MANUAL

SETTING THROTTLE SWITCHES

1. During flight at 120 MPH (IAS), 2500', prop control full forward for maximum RPM, and with the gear and flaps up, mark the throttle control position corresponding to $15.0'' \pm 1.0''$ manifold pressure.

2. Then adjust the gear warning horn throttle switch on the ground to activate at the throttle control position as marked in flight.

"For each 1000 feet above 2500' MSL, decrease the manifold pressure at which the throttle control position is marked by 0.5 inches."



VIEW LOOKING AFT AND INBOARD AT RIGHT-HAND SIDE OF FIREWALL

- | | | |
|-------------------------|----------------------------------|----------------------------|
| 1. Cover | 8. Spacer | 16. Throttle Lever |
| 2. Clamp Bolt | 9. Mounting Bracket | 17. Clamp Bolt |
| 3. Fuel Pump Switch Cam | 10. Lower RH Firewall | 18. Cabin Throttle Control |
| 4. Arm Assembly | 11. Spacer | 19. Clamp Half |
| 5. Thick Washer | 12. Gear Warning Switch | 20. Clamp Assembly |
| 6. Fuel Pump Switch | 13. Gear Warning Cam | 21. Bushing |
| 7. Spacer | 14. Throttle Control (Secondary) | 22. Spacer |
| | 15. Cable Clamp Mount | |

Figure 5-8. Rigging Throttle-Operated Gear Warning Horn Switch

MODEL P210 SERIES SERVICE MANUAL

5-39. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
AIRCRAFT LEANS TO ONE SIDE	Incorrect tire inflation.	Inflate to correct pressure.
	Sprung main gear strut.	Remove and replace strut.
	Bent axle.	Install new axle.
UNEVEN OR EXCESSIVE TIRE WEAR.	Incorrect tire inflation.	Inflate to correct pressure.
	Wheel out of alignment.	Align wheels.
	Wheels out of balance.	Balance wheels
	Sprung main gear strut.	Replace strut.
	Bent axle.	Install new axle.
	Dragging brakes.	Jack wheel and check brake.
	Wheel bearings not adjusted properly.	Tighten axle nut properly.

5-40. REMOVAL. (Refer to figure 5-9.)

- a. Jack aircraft in accordance with procedures outlined in Section 2 of this Manual.
- b. Bleed fluid from brake line at wheel brake cylinder.
- c. Turn master switch off; move gear position selector valve to up position, then turn master switch on until main gear downlocks disengage. Turn master switch off and pull pump motor circuit breaker to ensure that pump cannot be actuated accidentally. Place gear position selector handle in a neutral position so that gear rotates freely.

NOTE

If the pump motor cannot be used to unlock the main gear because of an opening in the hydraulic system, the spring-loaded main gear downlocks can be manually unlocked by pushing them forward with a screwdriver or other similar tool, and holding them forward, until the main gear has rotated past.

WARNING

It is advisable to have an assistant hold the gear strut up while the locks are pushed forward to prevent the strut from rotating suddenly, possibly causing personal injury. Ensure that master switch is OFF and pump motor circuit breaker pulled.

- d. Remove strut attach bolt (26) and work strut (29) and plug (25) from pivot assembly (14).

- e. Disconnect brake line from union (23) and plug union and brake line.
- f. Remove O-rings (24) from plug (25) and clean plug and strut (29).

5-41. INSTALLATION. (Refer to figure 5-9.)

NOTE

The following procedure installs the landing gear as a complete assembly. Refer to applicable paragraphs for installation of individual components.


- a. Lubricate new O-rings (24) and end of strut (29) with Petrolatum VV-P-233, hydraulic fluid MIL-L-5606, or Corning DC-7 (keep DC-7 away from areas to be painted) before installation. Install O-rings (24) on plug (25).
- b. Remove caps from union (23) and brake line, attach brake line to union (23), and work plug (25) and strut (29) into pivot (14).

NOTE

When installing a new pivot assembly (14), burnishing the 2.100" I. D. bore may be required to facilitate assembly of landing gear strut (29).

- c. Align hole in plug (25) with holes in pivot assembly (14) using special tool No. SE934.

MODEL P210 SERIES SERVICE MANUAL



- 1. Bolt
- 2. Retainer
- 3. Washer 38
- 4. Cap
- 5. Bearing
- 6. Washer
- 7. Sector Gear
- 8. Shaft
- 9. Seal
- 10. Bearing
- 11. Inner Race
- 12. Bearing
- 13. Actuator Clamp
- 14. Pivot Assembly
- 15. Packing
- 16. Collar
- 17. Shaft
- 18. Bushing
- 19. Setscrew
- 20. Nut
- 21. Washer
- 22. Brake Line
- 23. Union
- 24. Packing
- 25. Plug
- 26. Bolt
- 27. Inboard Forging
- 28. Outboard Forging
- 29. Strut
- 30. Axle Fitting
- 31. Axle
- 32. Brake Assembly
- 33. Wheel and Tire
- 34. Axle Nut
- 35. Hub Cap
- 36. Shim
- 37. Wheel Alignment Shim
- 38. Bracket
- 39. Actuator

Figure 5-9. Main Landing Gear

MODEL P210 SERIES SERVICE MANUAL




Figure 5-10. Rigger Main Landing Gear (Sheet 1 of 3)

MODEL P210 SERIES SERVICE MANUAL




Figure 5-10. Rigging Main Landing Gear (Sheet 2 of 3)

MODEL P210 SERIES SERVICE MANUAL




Figure 5-10. Rigging Main Landing Gear (Sheet 3 of 3)

NOTE

Special tool No. SE934 is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations. This tool is designed to install strut attaching bolt without damaging the O-rings in the plug.

d. Install the strut attaching bolt (26) by pushing the SE934 tool through the aligned holes of the pivot (14), strut (29), and plug (25), with the threaded end of the bolt (26). Install and tighten nut and washer on the bolt (26).

e. Fill and bleed brake system in accordance with paragraph 5-156 in this Manual.

f. Rig landing gear in accordance with procedures outlined in this Section.

a. (Refer to figure 5-10.) With main gear unlocked and main landing gear support forging assembled loose to the outboard support assembly (13), bring main landing gear strut (14) into DOWN position and adjust as follows:

1. Center and shim simultaneously main landing gear support assembly (13), using shims (P/N 1241629) between outboard forging (index 28, figure 5-9), and landing gear support assembly (13), as shown in sheet 1, to level wings and assure that end points of main landing gear wheel axles are within $\pm .25$ -inch of water line plane. Total of shims to be within $.025$ -inch to $.075$ -inch.

2. Check landing gear spring-to-support pad surface contact, and maintain surface contact at 75% or better.

5-42A. RIGGING MAIN LANDING GEAR.

WARNING

Turn master switch OFF and pull hydraulic pump circuit breaker to prevent accidental extension or retraction of the landing gear whenever work is being performed in the wheel well or pivot area.

NOTE

All of the following rigging adjustments shall be accomplished with the aircraft on jacks and in a level condition, using the ship's power pack to supply pressure. A ground power source should augment the ship's battery.

NOTE

The following shims are available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations:

1241629-1016-inch
1241629-2025-inch
1241629-3050-inch
1241629-4071-inch

b. Adjust hook setscrew (8) to stop hook assembly $.040$ to $.090$ -inch over center as shown on sheet 2.

MODEL P210 SERIES SERVICE MANUAL

NOTE

The downlock hook (7) shall have positive clearance with both inboard and outboard ears of the gear pivot, in all conditions of hook operation, locked, normal operation and malfunction operation. Adjust downlock hook (7) inboard and outboard as required, by locating spacers, installed on the required side of the hook. In some cases, all of the spacers will be installed on one side of the downlock hook to achieve the required clearance.

- c. A new downlock actuator assembly is received with a preassembled length of 12.45-inches, and the three hydraulic ports in the same plane. Install actuator assembly, attaching it to fuselage structure and arm assembly (5).
- d. With landing gear free, hydraulic pressure off, and downlock systems in position shown on sheet 1, swing landing gear into the DOWN position and adjust downlock adjustment screw (6) as follows:

NOTE

To relieve hydraulic pressure, pull hydraulic pump circuit breaker off, and move gear selector handle up and down two or three times.

1. If downlock locks, turn downlock adjustment screw (6) 1/4 turn out at a time until lock will not lock; then turn back in 1/4 turn and secure pin.
2. If downlock does not lock, turn downlock adjustment screw (6) 1/4 turn in at a time until lock will lock, then secure pin.
- e. Readjust hook setscrew (8) to stop hook assembly .040 to .090-inch overcenter. When checking overcenter measurement of arm assembly (5), landing gear should be as shown on sheet 2, with nut, washer and spacer removed, which retains the arm assembly (5). Use downlock overcenter gages (P/N SE960) to determine if downlock hook assembly is still within tolerances shown on sheet 2. Use gages as follows:

NOTE

Overcenter gages, P/N SE960 are available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations.

1. Remove nut, washer and spacer which retain arm assembly to support assembly.
2. Install .090-inch downlock gage (SE960) on inboard side of downlock hook (7) as shown on sheet 2. Upper portion of gage should rest against head of pin attaching downlock adjustment screw (6). If downlock hook (7) is under maximum overcenter tolerance, green area of gage will contact spacer on gear pivot, while red area will not make contact with .50-inch diameter shoulder, as shown in the figure. When downlock hook (7) is in maximum overcenter tolerance, both green and red areas will make contact. If red area makes contact and green area does not, the hook setscrew (8) should be adjusted INWARD to bring overcenter dimension within tolerance.

3. Install .040-inch downlock gage (SE960) on inboard side of downlock hook (7) as shown on sheet 2. If downlock hook (7) is over minimum overcenter tolerance, green area of gage will contact shoulder, while red area will not make contact with spacer.

4. When downlock hook (7) is in minimum overcenter tolerance, both red and green areas will make contact.

5. If overcenter tolerance is less than .040-inch, the red area will make contact, while the green area will not. If this condition exists, the next step is to determine if the downlock adjustment screw (6) is making contact with the hook setscrew (8). This is accomplished by lifting the landing gear spring upward off the hook assembly and checking for possible rotation of the hook assembly, by hand, with hydraulic pressure off.

6. If a slight rotation is possible, hook setscrew (8) is not contacting downlock adjustment screw (6). If contact is not being made, downlock actuator will have to be re-adjusted by backing off actuators rod end (19) one-half turn at a time (one and one half turn maximum adjustment) until hook assembly is .040-inch or more overcenter, and contact is being made between hook setscrew (8) and adjustment screw (6). If contact is being made, hook setscrew (8) should be adjusted outward to increase overcenter measurement to within tolerance.

NOTE

For correct rigging, hook setscrew (8) must make contact with downlock adjustment green areas of both gages must contact as shown on sheet 2.

f. Now that downlock adjustment screw (6) has been adjusted following procedures outlined in step "e", check actuator rod end (19) adjustment as follows:


1. Connect all hydraulic lines, fill system with MIL-H-5606 hydraulic fluid and purge system of air by cycling gear through several cycles.

NOTE

Check fluid level in power pack reservoir frequently during purging and rigging procedures.


2. Reset hydraulic pump circuit breaker to ON.
3. With gear in down and locked position, move gear selector handle to GEAR UP position and note actuation of main gear downlock hooks.
4. As soon as left downlock hook (7) is actuated to unlock the left gear, move gear selector handle back to GEAR DOWN position to simulate what would occur if the pilot were to select gear down before the gear was fully retracted. If downlock hooks (7) do not lock the gear in the down position, check downlock system for misalignment.
- g. Place gear selector handle in GEAR UP position and allow gear to retract to UP position.
- h. Check that gear up indicator switches are closed (light out) and some free travel exists on switch plunger (plunger not bottomed out). Adjust position as necessary.
- i. Lower gear, turn master switch OFF, and replace panels, carpeting, and items removed for access. Remove aircraft from jacks.

MODEL P210 SERIES SERVICE MANUAL



- | | |
|----------------------|---|
| 1. Actuator Assembly | 15. Bushing |
| 2. Bolt | 16. Washer |
| 3. Washer | 17. Pin |
| 4. Actuator Bracket | 18. Main Gear Downlock Switch |
| 5. Bolt | 19. Limit Switch Attachment |
| 6. Washer | 20. Screw |
| 7. Nut | 21. Plate Assembly Limit
Switch Attachment |
| 8. Screw | 22. Actuator |
| 9. Cotter Pin | 23. Lock Washer |
| 10. Washer | 24. Washer |
| 11. Nut | 25. Screw |
| 12. Downlock Hook | 26. Nut |
| 13. Bolt | 27. Hook Link |
| 14. Bushing | |

Figure 5-10A. Rigging Main Landing Gear (Sheet 1 of 2)



- 1. Pivot Lock Pin
- 2. Downlock Hook
- 3. Safety Wire
- 4. Downstop Backing Plate
- 5. Bulkhead Forging
- 6. Pivot Bolt
- 7. Adjustment Cam
- 11. Actuator
- 12. Switch
- 13. Actuator
- 14. Switch Plate
- 15. Downstop Pad

Figure 5-10A. Rigging Main Landing Gear (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

5-42. RIGGING MAIN LANDING GEAR
(THRU P21000874). (Refer to figure 5-10A).

WARNING

Turn master switch OFF and pull hydraulic pump circuit breaker to prevent accidental extension or retraction of the landing gear whenever work is being performed in the wheel well or pivot area.

NOTE

A new main landing gear downlock mechanism has been incorporated on serials THRU P21000874. A single acting downlock sequence actuator and downlock hook replaces the double acting actuator, arm assembly, and downlock hook. Figure 5-10A illustrates the replacement downlock mechanism while figure 5-10 illustrates the unchanged associated parts and structure and may also be used as a guide for determining relationship of parts.

a. (Refer to figure 5-10.) With main gear unlocked and main landing gear support forging assembled loose to the outboard support assembly (13), bring main landing gear strut (14) into DOWN position and adjust as follows:

1. Center and shim simultaneously main landing gear support assembly (13), using shims (P/N 1241629) between outboard forging (Index 28, figure 5-9), and landing gear support assembly (13), as shown in sheet 1, to level wings and assure that end points of main landing gear wheel axles are within $\pm .25$ -inch of water line plane. Total of shims to be within .025-inch to .075-inch.

NOTE

The following shims are available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations:

1241629-1016-inch
1241629-2025-inch
1241629-3050-inch
1241629-4071-inch

2. Check landing gear spring-to-support pad surface contact, and maintain surface contact at 75% or better.

NOTE

For 21065001 and On the downlock mechanism does not have an arm assembly (Index 5, figure 5-10, sheet 1) with downlock adjustment screw (Index 6, figure 5-10, sheet 1) and thus does not require downlock hook overcenter measurement and adjustment.

b. (Refer to figure 5-10A, sheet 1.) Install actuator assembly, attaching it to fuselage structure and downlock hook (12) using hook links (27).

c. With landing gear free, hydraulic pressure off, and downlock systems in position shown on sheet 2, check clearance between downlock hook (2) and pivot lock pin (1) with gear in down and locked position. Clearance must not exceed .008-inch. If adjustment of downlock

hook is necessary, work through access opening (access panels in cabin, under carpet, above main gear pivot assemblies) and remove safety wire (3). Loosen pivot bolt (6) and turn cam (7) until clearance is within tolerance; tighten pivot bolt (6).

d. Check rigging of downlock hook and main gear down limit switches as follows:

1. Temporarily insert a .025-inch shim (P/N SE997-1 or -2) between pivot assembly (Index 14, figure 5-9) and downstop pad (15, figure 5-10A, sheet 2).

WARNING

Stay clear of main landing gear when making this check.

2. Place gear selector handle in DOWN position and reset gear pump circuit breaker. Turn master switch ON and allow gear to rotate to full down position, leaving the master switch ON.

3. With SE997-1 or -2 shim in place, downlock hook (2) should not engage pivot lock pin (1), and light should be OFF.

4. Recycle gear UP, remove shim SE997-1 or -2, and then gear DOWN. Light should be ON. Refer to paragraph 5-43 for rigging and adjustment of main gear downlimit switches.

e. Refer to figure 5-10, sheet 1. Check actuator rod end (19) adjustment as follows:

1. Connect all hydraulic lines, fill system with MIL-H-5606 hydraulic fluid, and purge system of air by cycling gear through several cycles.

NOTE

Check fluid level in power pack reservoir frequently during purging and rigging procedures.

2. Reset hydraulic pump circuit breaker to ON.

3. With gear in down and locked position, move gear selector handle to GEAR UP position and note actuation of main gear downlock hooks.

4. As soon as left downlock hook (7) is actuated to unlock the left gear, move gear selector handle back to GEAR DOWN position to simulate what would occur if the pilot were to select gear down before the gear was fully retracted. If downlock hooks (7) do not lock the gear in the down position, check downlock system for misalignment.

f. Place gear selector handle in GEAR UP position and allow gear to retract to UP position.

g. Check that gear up indicator switches are closed (light out) and some free travel exists on switch plunger (plunger not bottomed out). Adjust position as necessary.

h. Lower gear, turn master switch OFF, and replace panels, carpeting, and items removed for access. Remove aircraft from jacks.

5-43. RIGGING MAIN GEAR DOWN LIMIT SWITCHES. (Refer to figure 5-10, sheet 2.) The main gear down limit switches are attached to brackets which are welded to the downlock hooks. Adjustment is accomplished by loosening the lock nut and either tightening or loosening the adjustment nut and retightening the lock nut against the bracket behind the adjustment nut. Down limit switches are to be adjusted to the dimension stipulated in the figure.

MODEL P210 SERIES SERVICE MANUAL





Figure 5-11. Wheel Alignment (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL


TOP VIEW OF TOE-IN CHECK

Measure toe-in at edges of wheel flange. Difference in measurements is toe-in for one wheel. (half of toe-in.)




FRONT VIEW OF CAMBER CHECK

Measure camber by reading protractor level held vertically against outboard flanges of wheel.



NOTE

See Section 1, figure 1-1 for toe-in and camber tolerances. Setting toe-in and camber within these tolerances while the cabin and fuel tanks are empty will give approximately zero toe-in and zero camber at gross weight. Therefore, if normal operation is less than gross weight and abnormal tire wear occurs, realign the wheels to obtain the ideal setting for the load conditions. Always use the least number of shims possible to obtain the desired results.



NOTE

To assure adequate thread engagement of the mounting bolts, use 0541111-2 or 0441139-6 shim alone and/or 0541157-1, -2, -3, or 0441139-5 in any combination as required to get zero camber at normal operating weight. Total thickness of shims at upper bolts must not exceed .195. If any tapered shims are used, all AN960 washers must be removed from the upper bolts.

Figure 5-11. Wheel Alignment (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 5-12. Main Landing Gear Wheel, Tire and Brake Assembly

5-44. RIGGING MAIN GEAR UP LIMIT SWITCHES. (Refer to figure 5-10, sheet 3.) The main gear up limit switches are mounted in brackets which are attached to the underside of the removable floorboards, immediately above the main landing gear pivot assemblies. The switches are contacted by actuators, bonded to clamps, which are attached to the aft leg of the landing gear strut pivot assembly. When replacing a clamp/actuator assembly, adjust the actuator tab prior to bonding, so that it actuates the gear-up indicator light switch. Bond the actuator to the clamp with HYSOL EA-9309 or 3M EC-2216

adhesive. Trim off excess end tab of clamp and position clamp helix approximately as shown in the figure, to avoid interference with gear-up switch wiring. Additional switch adjustment is provided by slotted holes in the switch mounting brackets. Adjust actuator tab-to-switch clearance to dimension stipulated in the figure. With landing gear full up and clearance as specified in Figure 5-10., check that GEAR UNSAFE light is out.

5-45. MAIN WHEEL AND TIRE ASSEMBLY.

5-46. DESCRIPTION. The aircraft is equipped with Cleveland wheel and tire assemblies.




Figure 5-13. Main Landing Gear Actuator

CAUTION

Use of recapped tires or new tires not listed on the aircraft equipment list are not recommended due to possible interference between the tire and structure when landing gear is in the retracted position.

5-47. REMOVAL OF MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-12.)

NOTE

It is not necessary to remove the main wheel to reline brakes or remove brake parts, other than the brake disc or torque plate.

- a. Using the jack point under step on main gear strut, jack-up wheel being removed.
- b. Remove hub caps.
- c. Remove cotter pin and axle nut.
- d. Remove bolts and washers attaching back plate and remove back plate.
- e. Pull wheel from axle.

5-48. DISASSEMBLY OF MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-12.)

- a. Deflate tire and break tire beads loose.

CAUTION

Avoid damaging wheel flanges when breaking tire beads loose. A scratch, gouge or nick may cause wheel failure.

- b. Remove thru-bolts and separate wheel halves, removing tire, tube and brake disc.
- c. Remove grease seal rings, felts and bearing cones from wheel halves.

NOTE

The bearing cups are a press fit in the wheel halves and should not be removed unless replacement is necessary. To remove the bearing cups, heat the wheel half in boiling water for 15 minutes. Using an arbor press, if available, press out the bearing cup and press in the new cup while the wheel is still hot.

MODEL P210 SERIES SERVICE MANUAL

5-49. INSPECTION AND REPAIR OF MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-12.)

- a. Clean all metal parts and the grease seal felts in solvent and dry thoroughly.
- b. Inspect wheel halves for cracks. Cracked wheel halves should be replaced. Sand out nicks, gouges and corroded areas. When the protective coating has been removed, the area should be cleaned thoroughly, primed with zinc chromate and repainted with aluminum lacquer.
- c. Brake disc should be replaced if excessively scored or warped. Small nicks and scratches should be sanded smooth.
- d. Bearing cups and cones should be inspected carefully for damage and discoloration. After cleaning, repack cones with clean aircraft wheel bearing grease (Section 2) before installation in the wheel.

5-50. REASSEMBLY OF MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-12.)

- a. Insert thru-bolts through brake disc and position in the inner wheel half, using the bolts to guide the disc. Assure the disc is bottomed in wheel half.
- b. Position tire and tube with the inflation valve through hole in outboard wheel half. Place inner wheel half in position. Apply a light force to bring wheel halves together. Maintaining the light force, assemble a washer and nut on one thru-bolt and tighten snugly. Assemble remaining washers and nuts on thru-bolts and torque to 150 lb-in.

CAUTION

Uneven or improper torque of thru-bolt nuts may cause failure of bolts, with resultant wheel failure.

- c. Clean and repack bearing cones with clean aircraft wheel bearing grease (refer to Section 2 of this Manual).
- c. Assemble bearing cones, grease seal felts and rings into wheel halves.
- e. Inflate tire to seat tire beads, then adjust to correct pressure.

5-51. MAIN WHEEL BALANCING AND ALIGNMENT. Wheel alignment procedures are outlined in figure 5-11.

5-52. MAIN WHEEL AND AXLE REMOVAL. (Refer to figure 5-9.)

- a. Remove hub caps.
- b. Remove wheel and tire in accordance with applicable paragraph of this Section.
- c. Disconnect, drain and plug hydraulic brake line at the brake cylinder.
- d. Remove bolts, washers, nuts and stud securing axle and brake components to fitting at lower end of strut.

NOTE

When removing axle from strut fitting, note number and position of wheel alignment shim. Mark these shims or tape together carefully so they can be reinstalled in exactly the same position to ensure that wheel alignment is not disturbed. Also, note position of stud attaching axle to fitting so that the stud may be installed in the same position. Stud is the uplock for the main gear.

5-53. MAIN WHEEL AND AXLE INSTALLATION. (Refer to figure 5-9.)

- a. Secure axle and brake components to strut fitting, making sure that wheel alignment shims and stud are reinstalled in their original position.

NOTE

Shim: P/N 1241061-3, available from the Cesana Parts Distribution (CPD 2) through Cesana Service Stations, can be installed between axle and fitting, if necessary, to maintain .050 inch minimum clearance between axle fitting and brake disc.

- b. Install wheel assembly on axle in accordance with applicable paragraph of this Section.
- c. Connect hydraulic brake line to brake cylinder.
- d. Fill and bleed affected brake system.
- e. Install hub caps.
- f. Check wheel alignment.

5-54. MAIN GEAR ACTUATOR. (Refer to figure 5-13.)


5-55. REMOVAL.

- a. Remove seats and peel back carpet as necessary to gain access to plate above actuator; remove access plate.
- b. Remove access plate from bulkhead forward of actuator.
- c. Disconnect and drain hydraulic fluid at wheel brake cylinders.
- d. Place landing gear control handle UP, with master switch OFF, and operate emergency hand pump until main gear downlocks release.
- e. Disconnect and cap or plug all hydraulic lines at the actuator.
- f. Remove bolts attaching actuator mounting flange to bulkhead forging.
- g. Work actuator free of forging and pivot assembly; remove actuator.

5-56. DISASSEMBLY. (Refer to figure 5-13.)

- a. Remove setscrew (8) and remove end gland (7) by unscrewing from actuator body (3).
- b. Remove cap (1) from end of actuator.
- c. Using a small rod, push piston (12) from actuator body.

MODEL P210 SERIES SERVICE MANUAL




1. WRENCH USED TO TIGHTEN OR LOOSEN JAMNUT ON MAIN GEAR ACTUATOR.
2. STRAIGHTEN HANDLE AS SHOWN.



MATERIAL:

7/8-INCH BOX END WRENCH
(SEARS CRAFTSMAN, OR
EQUIVALENT.)



1. WRENCH USED TO INSTALL OR REMOVE END GLAND ON MAIN GEAR ACTUATOR.
2. INSERT PINS THROUGH HOLES IN WRENCH AND TORCH BRAZE USING BRAZING ROD (SIL-BOND 45, UNITED WIRE AND SUPPLY) OR EQUIVALENT.

TORCH BRAZING - Flux joint and filler material thoroughly. Filler material may be either pre-positioned or hand fed. The torch shall be adjusted for a non-oxidizing flame, and manipulated in such a manner as to braze in the direction the flame is pointing. This will tend to prevent flux inclusion and entrapment of foreign particles. After the assembly has solidified the excess flux shall be removed with hot water. (180° F. approximately.)

Figure 5-14. Fabrication of Main Landing Gear Actuator End Gland Removal Tool

MODEL P210 SERIES SERVICE MANUAL

NOTE

Unless defective, do not remove nameplate, bearings (2) or roller (13).

- d. Remove packing (5) and back-up ring (4) from cylinder body (3). Discard packing (5).
- e. Remove packing (10) and back-up ring (9) from end gland (7). Discard packing (10).
- f. Remove and discard packing (11) from piston (12).

5-57. INSPECTION.

- a. Thoroughly clean all parts in cleaning solvent (Federal Specification PS-661, or equivalent.)
- b. Inspect all threaded surfaces for cleanliness, cracks and wear.
- c. Inspect cap (1), piston (12), roller (13), if removed, and actuator body (3) for cracks, chips, scratches, scoring, wear or surface irregularities which may affect their function or the overall operation of the actuator.
- d. Inspect bearings (2), if removed, for freedom of motion, scores, scratches or Brinell marks.

5-58. PARTS REPAIR/REPLACEMENT. Repair of small parts of the main landing gear actuator is impractical. Replace all defective parts. Minor scratches or score marks may be removed by polishing with abrasive crocus cloth (Federal Specification P-C-458), providing their removal does not affect operation of the unit. During assembly, install all new packings.

5-59. REASSEMBLY. (Refer to figure 5-13.)

NOTE

Use MIL-G-2116C lubricant on roller (13) and bearings (2), if removed.

- a. If bearings (2) and roller (13) were removed, press one bearing into actuator body until it is flush. Install roller and press second bearing in place to hold roller. Use care to prevent damage to bearings or roller.
- b. Install back-up ring (4) and new packing (5) in actuator body core. Install new packing (11) and back-up rings (6) on piston (12).

NOTE

Lubricate piston rack gears with MIL-G-21164C lubricant. Apply lubricant sparingly. Over-greasing might cause contamination of hydraulic cylinder assembly with grease which might work past packing.

- c. Slide piston (12) into cylinder body (3).
- d. Install back-up ring (9) and new packing (10) on end gland.
- e. Install end gland in cylinder and tighten until end of gland is flush with end of cylinder body. Install and tighten setscrew (8).
- f. Install cap (1) at end of actuator assembly.

5-60. INSTALLATION.

- a. With main landing gear in the down and locked position, install actuator into bulkhead forging so that piston rack gear and sector gear engage as shown in figure 5-9, Section A-A.
- b. Lubricate swivel fitting on actuator with MIL-G-21164 lubricant, install packing in fitting.
- c. Install cap (4), washer (3), retainer (2) and swivel fitting on actuator as shown in figure 5-9.
- d. Install bolts (1) and torque to 100-140 lb-in. and safety-wire. Safety-wire swivel fitting to shaft (8).
- e. Connect all hydraulic lines to their source locations. Lubricate threads with Petrolatum.
- f. Connect brake line at wheel cylinder. Fill and bleed brake system in accordance with procedures outlined in applicable paragraph in this Section.
- g. Rig landing gear in accordance with procedures outlined in applicable paragraph in this Section.
- h. Remove aircraft from jacks and install access covers, carpeting and seats removed for access.

5-61. MAIN GEAR PIVOT ASSEMBLY.

5-62. REMOVAL. (Refer to figure 5-9.)

- a. Remove strut from pivot assembly in accordance with procedures outlined in applicable paragraph in this Section.
- b. Remove actuator in accordance with procedures outlined in applicable paragraph in this Section.
- c. Remove setscrew from sector gear (7).
- d. Bend tangs of washer (21) from notches in nut (20) and completely unscrew nut (20) from threaded area of shaft (17).
- e. Push shaft (17) into pivot assembly (14) and pull pivot assembly free of shaft (8).

5-63. INSPECTION AND REPAIR. (Refer to figure 5-9.)

- a. Thoroughly clean all parts in cleaning solvent (Federal Specification PS-661 or equivalent.)
- b. Inspect all parts for indications of damage, cracks or excessive wear and replace as necessary.
- c. Inspect outboard pivot bushing and inboard pivot bearing (10) (pressed into bulkhead forgings in aircraft) for damage and excessive wear. Replace bushing or bearing as required.

NOTE

The outboard pivot bushing is locked into the bulkhead forging by a setscrew located above the bushing. This setscrew must be turned out several turns before the bushing can be removed.

5-64. INSTALLATION. (Refer to figure 5-9.)

- a. Lubricate all bushings and bearings with MIL-G-21164 grease. Slide shaft (17) into pivot assembly (14).
- b. Install pivot with bearing (12) and race (11) installed, into inboard bearing in bulkhead forging. Pull shaft from pivot and install washer (21) and nut (20) on shaft.

- c. Insert end of shaft into outboard bushing in bulk-head forging. Hand-tighten nut to remove all end play and safety in place by bending corresponding tang of washer into notch of nut. pivot must rotate freely.
- d. Install seal (9) and sector gear (7) on inboard end of pivot assembly so that setscrew hole in sector gear lines up with setscrew hole in shaft (8); install setscrew into sector gear and shaft with Loctite 242 locking compound and tighten screw.

5-65. GEAR POSITION INDICATOR SWITCHES.

5-66. DESCRIPTION. The gear down indicator switches are attached to brackets which are welded to the downlock hooks. The main gear up limit switches are mounted in brackets which are attached to the underside of the removable floorboards immediately above the main landing gear pivot assemblies. Refer to the paragraphs in this section which outline procedures for rigging the main gear up and down switches.

5-67. DOWNLOCK MECHANISM. (Refer to figure 5-15.)

5-68. DESCRIPTION. The downlock mechanism is comprised of hydraulic actuators connected to arm assemblies, which trip downlock hooks, releasing the main landing gear struts. Figure 5-15 illustrates the downlock mechanism and may be used as a guide for determining relationship of parts. A locator illustration is also provided, which shows station numbers, bulk-heads, ribs and parts of the downlock mechanism. To locate a specific fuselage station, refer to the station 1 of this manual.

NOTE

A new main landing gear downlock mechanism has been incorporated. A single acting downlock sequence actuator and downlock hook replaces the double acting actuator, arm assembly, and downlock hook. Figure 5-10A illustrates the replacement downlock mechanism while figures 5-10 and 5-15 each illustrate the unchanged associated parts and structure and may also be used as a guide for determining relationship of parts.

5-69. REMOVAL AND INSTALLATION OF COMPONENTS. (Refer to figure 5-15.) The downlock mechanism located just forward and aft of the rear door post under the floorboard. Access to the mechanism is gained by removing the seats, peeling back the carpet and removing the access plates immediately forward and aft of the rear door post on either side of the aircraft. Figure 5-15 may be used as a guide for removal and installation of components of the downlock mechanism. Upon complete reassembly of the downlock mechanism, rig the main landing gear in accordance with procedures outlined in the applicable paragraph in this section.

NOTE

A new main landing gear downlock mechanism has been incorporated. Figure 5-10A illustrates the replacement downlock mechanism while figures 5-10 and 5-15 each illustrate the unchanged associated parts and structure and may also be used as a guide for removal and installation of components of the replacement downlock mechanism.

5-70. DOWNLOCK ACTUATOR.

- 5-71. DISASSEMBLY.** (Refer to figure 5-16).
- Loosen nut (1) and unscrew end fitting (2) from body (3). Spring (4) can also be removed.
 - Remove hose valve assembly (5), O-ring (14), spring guide (15), spring (6), ball (7) and ball (8) from body (3).
 - Remove piston/rod (9) from body.
 - Remove and discard all packings and back-up rings from end fitting (2), body (3) and piston/rod (9).

5-72. INSPECTION AND REPAIR.

- Inspect all threaded surfaces for cleanliness and for freedom of cracks and excessive wear.
- Inspect ball spring (6) for evidence of breaks and distortion.
- Inspect piston spring (4) for evidence of breaks and distortion.
- Inspect end fitting, piston/rod, barrel, valve body, balls and ball seats for cracks, scratches, scoring wear or surface irregularities which might affect their function or the overall function of the unit.
- Repair of most parts of the uplock actuator is impractical. Replace defective parts. Minor scratches and scores may be removed by polishing with fine abrasive crocus cloth (Federal Specification PC-458), providing their removal does not affect operation of the unit.

5-73. REASSEMBLY.

NOTE

Install new O-rings and back-up rings lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dowcorning DC-7.

- Assemble by reversing procedures outlined in paragraph 5-70.

5-74. MAIN GEAR STRUT STEP. (Refer to figure 5-9).

5-75. DESCRIPTION. The step is constructed of Uralite 3121 polyurethane casting, with a molded depression area, located in the top of the step. An adhesive-backed "Walkway" material with rough surface is pressed into the depressed area of the strut.


5-76. REMOVAL.

NOTE

The step is bonded to the landing gear with Uralite 3121 bonding material.

- Using a heat gun, heat step mat a temperature of 200°-250° F, until step material becomes pliable.
- Using a sharp knife, remove step material down to the metal strut.
- Clean off remaining step material with a wire wheel and sandpaper. Leave surface slightly rough or abraded. Clean oil and grease from strut with solvent, wipe off excess solvent with dry cloth and let surface dry.
- Apply zinc chromate primer-green or yellow, to clean area on strut. Dry film thickness to be .0003 to .0005 inch.

MODEL P210 SERIES SERVICE MANUAL



1. Tie
2. Boot
3. Pin
4. Spacer
5. Arm Assembly
6. Downlock Adjustment Screw
7. Downlock Hook
8. Hook Setscrew
9. Downlock Switch
10. Spring Assembly
11. Eyebolt
12. Shim
13. Support Assembly
14. Landing Gear Strut
15. Shell Assembly
16. Stud
17. Bolt
18. Rod End
19. Actuator

* Install internal tooth washer under bolt heads.

* Prime bolts with LOCTITE GRADE "T" PRIMER and seal with LOCTITE CV or CATALOG #85 or #83.




Figure 5-15. Main Landing Gear Downlock Installation

MODEL P210 SERIES SERVICE MANUAL




Figure 5-16. Main Landing Gear Downlock Actuator

5-77. INSTALLATION.

- a. Jack aircraft in accordance with procedures outlined in Section 2 of this Manual.
- b. Mark position of removed step so new step will be installed in approximately the same position on the strut.
- c. Clean surfaces to be bonded together thoroughly. If a solvent is used, remove all traces of the solvent with a clean, dry cloth. It is important that the bonding surfaces be clean and thoroughly dry.
- d. Mix adhesive (Uralite 3121), in accordance with manufacturer's direction. Note pot life.
- e. Spread a coat of mixed adhesive on bonding surfaces of strut and step; install step on strut.

NOTE

Top of strut should be parallel to the ground ($\pm 5^\circ$) when gear is in down position.

- f. Cycle landing gear to check clearance of step in tunnel.
- g. Form a small fillet of adhesive at all edges of bonding surfaces. Remove excess adhesive.
- h. Remove aircraft from jacks.

- i. Allow adhesive to thoroughly cure according to manufacturer's recommendations before flexing gear spring or applying loads to step.
- j. Paint gear spring and step after curing is completed.

5-78. NOSE GEAR SYSTEM.

5-79. DESCRIPTION. The nose gear consists of a pseudraulic shock assembly, mounted in a trunnion assembly, a steering arm and bungee, shimmy dampener, nose wheel, tire and tube, hub cap, bearing, seals and a double-acting hydraulic actuator for extension and retraction. A claw-like hook on the actuator serves as a downlock for the nose gear.

5-80. OPERATION. The nose gear shock strut is pivoted just forward of the firewall. Retraction and extension of the nose gear is accomplished by a double-acting hydraulic cylinder, the forward end of which contains the nose gear downlock. Initial action of the cylinder disengages the downlock before retraction begins. Nose gear doors are mechanically closed as the nose gear retracts. As the nose gear extends, the doors are mechanically opened.

MODEL P210 SERIES SERVICE MANUAL

5-81. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
HYDRAULIC FLUID LEAKAGE FROM NOSE STRUT.	Defective strut seals and/or defects in lower strut.	Replace defective seals; stone out small defects in lower strut. Replace lower strut if badly scored or damaged.
NOSE STRUT WILL NOT HOLD AIR PRESSURE.	Defective filler valve or valve not tight.	Check gasket and tighten loose valve. Replace defective valve.
	Defective O-ring at top of strut.	Replace O-ring.
	Result of fluid leakage at bottom of strut.	Replace defective seals; stone out small defects in lower strut. Replace lower strut if badly scored or damaged.
NOSE WHEEL SHIMMY.	Nose strut attachment loose.	Secure attaching parts.
	Shimmy dampener lacks fluid.	Service shimmy dampener.
	Defective shimmy dampener.	Repair or replace dampener.
	Loose or worn steering components.	Tighten loose parts; replace if defective.
	Loose torque links.	Add shim washers and replace parts as necessary.
	Loose wheel bearings.	Replace bearings if defective; tighten axle nut properly.
	Nose wheel out of balance.	Refer to applicable paragraph.

5-82. REMOVAL OF NOSE GEAR ASSEMBLY.

a. Jack aircraft or weight the tail of aircraft to raise nose wheel off the ground

WARNING

Before working in landing gear wheel wells, PULL-OFF hydraulic pump circuit breaker. The pump circuit breaker is located in the circuit breaker panel, located immediately forward of the left forward doorpost.

b. Open landing gear doors and disconnect nose wheel door push-pull rods.

c. Tag for identification and disconnect electrical wires at gear-down microswitch located on forward end of nose gear safety switch on torque links, and remove clamps attaching wires to nose strut.

d. Tag for identification and disconnect electrical wires at nose gear safety switch on torque links, and remove clamps attaching wires to nose gear strut.

e. Disconnect steering bungee from steering bellcrank.

f. Disconnect nose gear actuator from strut by removing cotter pin, castellated nut, washers and bolt.

NOTE

Retain spacer washers between downlock hooks on end of actuator.

g. Disconnect nose gear strut door tie rods from nose gear. Remove trunnion bolts.

NOTE

Trunnion bolts are accessible from inside the cabin, at the very forward end of the tunnel cover at the firewall. Two men will be required to remove these bolts, one working inside the cabin, the other working in the nose wheel well.

h. Work entire nose gear assembly free of the aircraft.




Figure 5-17. Nose Gear Installation

5-83. DISASSEMBLY OF NOSE GEAR STRUT. (Refer to figure 5-18.)

NOTE

The following procedure applies to the nose gear shock strut after it has been removed from the aircraft, and the nose wheel has been removed. In many cases, separating the upper and lower struts will permit inspection and parts replacement without removal or complete strut disassembly.

WARNING

Deflate strut completely before removing bolt (33), lock ring (31) or bolt (2). Also deflate strut before disconnecting torque links.

- a. Remove torque links. Note position of washers, shims, spacers and bushings.
- b. Remove shimmy dampener and steering bungee.
- c. Remove link from steering shaft and collar.

- d. Remove lock ring from groove inside lower end of upper strut. A small access hole is provided at the lock ring groove to facilitate removal of lock ring.

NOTE

Hydraulic fluid will drain from strut as lower strut is pulled from upper strut.


- e. Using a straight, sharp pull, remove lower strut from upper strut. Invert lower strut and drain hydraulic fluid from strut.
- f. Remove lock ring and bearing from lower strut.
- g. Slide shims, if used, packing support ring, scraper ring, retaining ring and lock ring from lower strut.

NOTE

Note number of shims, relative position and top side of each ring and bearing to aid in reassembly.

- h. Remove and discard O-rings and back-up rings

MODEL P210 SERIES SERVICE MANUAL



NOTE

Shims (22) are used as required above lower washer (20). Shims (42) are used as required above packing support ring (28).

- | | |
|--------------------------|----------------------------|
| 1. Brace | 32. Torque Link Attachment |
| 2. Bolt | 33. Bolt |
| 3. Upper Trunnion | 34. Fork |
| 4. Bushing | 35. O-Ring |
| 5. Filler Valve | 36. Base Plug |
| 6. O-Ring | 37. O-Ring |
| 7. Orifice Support | 38. Metering Pin |
| 8. Lower Trunnion | 39. Back-Up Ring |
| 9. Roll Pin | 40. O-Ring |
| 10. Barrel | 41. O-Ring |
| 11. Bearing | 42. Shim |
| 12. Dowel Pin | 43. Bolt |
| 13. Roll Pin | 44. Tab Washer |
| 14. Steering Arm | |
| 15. Bushing | |
| 16. Roller | |
| 17. Steering Shaft | |
| 18. Link | |
| 19. Rod Assemblies | |
| 20. Washer | |
| 21. Collar | |
| 22. Shim | |
| 23. Collar | |
| 24. Lock Ring | |
| 25. Bearing | |
| 26. Bolt | |
| 27. Lower Strut | |
| 28. Packing Support Ring | |
| 29. Scraper Ring | |
| 30. Retaining Ring | |
| 31. Lock Ring | |

Figure 5-18. Nose Gear Shock Strut Assembly

MODEL P210 SERIES SERVICE MANUAL

from packing support ring.

- i. Remove metering pin and base plug by removing bolt from lower strut and fork assembly.

NOTE

Lower strut and fork are a press fit, drilled on assembly. Separation of these parts is not recommended, except for replacement of parts.

- j. Remove and discard O-rings from metering pin and base plug.
- k. Remove orifice support by removing bolt at top of strut. Remove and discard O-ring from orifice support.
- l. Remove collar from upper strut. To remove collar, remove bolt and tab washer. Remove washers, shims, if installed, and steering collar.

NOTE

Upper and lower trunnions are press fitted to the upper strut with braces installed during assembly. Pin is also press fitted to the lower trunnion.

5-84. INSPECTION AND REPAIR OF SHOCK STRUT COMPONENTS. (Refer to figure 5-18.)

- a. Bushings and bearings in upper trunnion and lower trunnion may be replaced as required. Needle bearing in collar should not be replaced. Replace entire steering collar if needle bearing is defective.
- b. Thoroughly clean all parts in solvent and inspect them carefully. Replace all worn or defective parts and all O-rings, seals and back-up rings with new parts.
- c. Sharp metal edges should be smoothed with No. 400 emery paper, then cleaned with solvent.

5-85. REASSEMBLY OF NOSE GEAR STRUT. (Refer to figure 5-18.)

NOTE

Install new seals and existing lock ring, lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

- a. Install top washer (20), steering collar (21), shims (22) (as many as were removed), and collar (23). Screw collar (23) up threads on lower end of upper strut (10) until it is flush with the lower end of the strut, to the nearest one-third turn. Use shims as required above lower washer, to fill gap between collars. Shims are available from the Cessna Supply Division, as follows:

1243030-5	0.006"
1243030-6	0.012"
1243030-7	0.020"

NOTE

When correct number of shims are installed, secure collar (23) with bolt (43) and secure bolt with tab washer (44) by bending tabs of washer.

- b. Install O-ring (37) on base plug (36).
- c. Install O-ring (35) on metering pin (38), and install in base plug (36).
- d. Install bolt (33) through holes in fork (34) and base plug (36). Install nut on bolt.
- e. Install lock ring (31), retaining ring (30) and scraper ring (29) down over lower strut (27). Ensure they are installed in same positions as they were when removed.
- f. Install O-rings (40) and (41) and back-up rings (39) in packing support ring (28).

NOTE

Install contoured back-up rings (39), one on each side of O-ring (40) with concave surface of back-up rings next to O-ring.

- g. Install bearing (25) and lock ring (24) at upper end of lower strut assembly.

NOTE

Ensure that beveled edge of bearing is installed up next to lock ring.

- h. Install upper strut assembly over lower strut assembly.
- i. Install lock ring (31) in groove in lower end of barrel (10). Position lock ring so that one of its ends covers the small access hole in the lock ring groove.
- j. Install steering shaft (17) up through hole in lower trunnion (8) and hole in upper trunnion (3).
- k. Install steering arm (14) over steering shaft (17) and secure with roll pins.
- l. Install link (18) to bottom of steering shaft (17) and attach opposite end to steering collar (21).
- m. If braces (1) were removed, they should be installed, connecting at upper trunnion (3) and lower trunnion (8).
- n. Attach lower torque link to torque link fitting (32) and upper torque link to steering collar (21).
- o. Install O-ring (6) and filler valve (5) on orifice support (7).
- p. Install orifice support in barrel (10), install bolt (2).
- q. Service shock strut as outlined in Section 2 of this manual.

MODEL P210 SERIES SERVICE MANUAL

5-85. INSTALLATION OF NOSE GEAR STRUT.

WARNING

Before working in landing gear wheel wells, PULL-OFF hydraulic pump circuit breaker. The pump circuit breaker is located in the circuit breaker panel, located immediately forward of the left forward doorpost.

- a. Work entire nose gear assembly into nose gear wheel well.

NOTE

Trunnion bolts are accessible from inside the cabin, at the very forward end of the tunnel cover at the firewall. Two men will be required to install these bolts, one inside the cabin, the other in the nose wheel well.

- b. Install trunnion bolts.
- c. Install nose gear strut door tie rods.

NOTE

On aircraft equipped with retractable step, install right-hand tie rod on outboard side of eyebolt only, when connecting nose gear strut doors. Left-hand tie rod should be installed in normal manner.

- d. Install nose gear actuator and install castellated nut and cotter pin. On aircraft equipped with retractable step, rig step in accordance with applicable paragraph, after nose strut is installed and rigged.

NOTE

When connecting nose gear actuator to strut, lubricate and torque bolt as outlined in Section 2 of this manual.

- e. Install steering bungee to steering bellcrank.
- f. Identifying tagged applicable electrical wires, connect wires at safety switch on torque links and install clamps attaching wires to nose strut.
- g. Identifying tagged applicable electrical wires, connect wires at gear-down microswitch located on forward end of nose gear actuator at bracket on bearing end.
- h. Connect nose wheel door push-pull rods.
- i. Rig nose gear and nose gear doors in accordance with procedures outlined in applicable paragraph in this Section.

5-86. SHIMMY DAMPENER. (Refer to figure 5-19.)

5-87. DESCRIPTION. The shimmy dampener is a self-contained hydraulic cylinder which acts as a restrictor. When the steering system reacts too rapidly, the shimmy dampener maintains pressure against the steering arm by means of a piston which permits a restricted flow of hydraulic fluid from either end of the cylinder to the other through an orifice in the piston.

5-88. REMOVAL. (Refer to figure 5-17.)

- a. Remove bolt securing shimmy dampener to steering shaft.
- b. Remove bolt attaching dampener to bracket, attached to lower trunnion.
- c. Remove shimmy dampener from aircraft.

5-89. DISASSEMBLY. (Refer to figure 5-19.)

- a. Remove outer retaining ring (7).
- b. Remove bearing head (8).
- c. Remove O-rings (15) and (17) from bearing head (8).
- d. Remove internal retaining ring (5).
- e. Remove rod assembly (8).
- f. Remove O-ring (19) and back-up ring (9).
- g. Remove setscrew (14), spring (13), floating piston (12) and O-ring (3).
- h. Remove bolt (1) and Stat-O-Seal (2).
- i. Remove O-ring (20).

5-90. INSPECTION AND REPAIR OF SHIMMY DAMPENER. (Refer to figure 5-19.)

- a. Thoroughly clean all parts in solvent and inspect carefully.
- b. Sharp metal edges should be smoothed with No. 400 emery paper, then thoroughly cleaned with solvent.
- c. Replace all worn or defective parts.

5-91. REASSEMBLY OF SHIMMY DAMPENER (Refer to figure 5-19.)

NOTE

Install new seals, O-rings, and back-up rings, lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606. or Dow-Corning DC-7.

- a. If piston (10) was removed, install piston and install roll pin (11).

NOTE

Orifice in piston (10) connects to passage in rod (8).

MODEL P210 SERIES SERVICE MANUAL




Figure 5-19. Shimmy Dampener

- b. Install O-ring (3), floating piston (12), spring (13) and setscrew (14) in rod assembly (8).
- c. Install O-ring (20) in barrel (4).
- d. Install rod assembly (8) in barrel (4).
- e. Install back-up ring (9) and O-ring (19).
- f. Install internal retaining ring (5).
- g. Install O-rings (15) and (17) on bearing head (6).
- h. Install bearing head (6) over shaft assembly (8) in barrel (4).
- i. Install outer retaining ring (7).
- j. Install Stat-O-Seal (2) on bolt (1).
- k. Install bolt (1) in barrel (4).
- l. Service shimmy dampener in accordance with procedures outlined in Section 2 of this manual.

5-92. TORQUE LINKS. (Refer to figure 5-20.)

5-93. DESCRIPTION. The torque links align the lower strut with the nose gear steering system, but permit shock strut action.

5-94. REMOVAL OF TORQUE LINKS. (Refer to figure 5-20.)

NOTE

DEFLATE NOSE GEAR SHOCK STRUT COMPLETELY BEFORE REMOVING TORQUE LINKS.

- a. Remove nuts and washers attaching safety switch (8) to bracket (9); remove switch from bracket.
- b. Remove washers, shims, spacers, bolts and nuts. Note position of attaching hardware for reinstallation.

5-95. DISASSEMBLY AND REASSEMBLY. (Refer to figure 5-20.) The figure may be used as a guide for disassembly and reassembling the torque links. Bushings should not be removed except for replacement of parts. Replace any parts if excessively worn.

5-96. INSTALLATION OF TORQUE LINKS.
 a. With shock strut completely deflated, install upper torque link to collar on nose gear strut.

MODEL P210 SERIES SERVICE MANUAL




Figure 5-20. Nose Gear Torque Links

b. Install lower torque link to torque link attach point on nose gear fork.

c. Install upper key washer and nut on safety switch, install switch in bracket, and install star washer and nut on threads of switch.

d. Tighten attaching bolt nuts snugly, then tighten to align next castellation with cotter pin hole in bolt.

e. Check upper and lower torque links for looseness. If looseness is apparent, remove attaching nuts and install shims (4) as necessary to take up any looseness. This will assist in preventing nose wheel shimmy.

f. Retighten attaching nuts snugly, then tighten to align next castellation with cotter pin hole in bolt; install cotter pin.

g. Fill and inflate shock strut in accordance with procedures outlined in Section 2 of this manual.

MODEL P210 SERIES SERVICE MANUAL

5-101. NOSE GEAR DOWNLOCK MECHANISM.
(Refer to figure 5-22.)

5-102. DESCRIPTION. The nose gear downlock mechanism is a hook at the piston rod end of the nose gear actuator.

5-103. REMOVAL AND INSTALLATION OF NOSE GEAR DOWNLOCK MECHANISM. (Refer to figure 5-22.) Refer to "Removal of Nose Gear Actuator" paragraph of this Section.

5-104. NOSE GEAR ACTUATOR. (Refer to figure 5-23.)

5-105. DESCRIPTION. The nose gear actuator extends and retracts the nose gear and serves as a rigid drag strut in the gear-down position. A spring clip attaches the retractable step cable turnbuckle to the nose gear actuator.

5-106. REMOVAL OF NOSE GEAR ACTUATOR.

- a. Open doors and jack aircraft or weight down tail to raise nose wheel off the ground.
- b. Tag for identification and disconnect electrical wires at the gear-down switch, located at the forward end of the actuator.
- c. Disconnect hydraulic hoses from actuator. Cap or plug hose and fitting openings to prevent entry of foreign material.
- d. Disconnect actuator from lower trunnion by removing cotter pin, castellated nut, washers and bolt.
- e. Retain components of downlock mechanism which will be freed by removing bolt.

5-107. DISASSEMBLY OF NOSE GEAR ACTUATOR.
(Refer to figure 5-23.)

- a. Loosen lock nut at end of piston rod and remove rod end assembly as a unit; remove lock nut from piston rod.

MODEL P210 SERIES SERVICE MANUAL

NOTE

The downlock hooks (2) and (7) have been dry film lubricated at the factory and should last the life of the parts. However, they may be field lubricated by spraying with Lubri-Bond "A", Lubri Bond 220, or Perma-Silk. After application, allow parts to air dry for six hours, or dry for one hour at 120° F. Lubri Bond "A" and Lubri Bond 220 are products of Electro-Film Inc. , North Hollywood, Ca. Perma-Silk is a product of the Everlube Corp. , North Hollywood, Ca.




Figure 5-22. Nose Gear Downlock Mechanism

MODEL P210 SERIES SERVICE MANUAL




Figure 5-23. Nose Gear Actuator

- b. Remove safety wire from knurled nut, and loosen knurled nut.
- c. Remove bearing end from cylinder, and remove nut from cylinder.
- d. Pull piston from cylinder.
- e. Remove O-rings and back-up rings from bearing end and piston.
- f. Disassemble hook assembly.

5-108. INSPECTION AND REPAIR OF PARTS OF NOSE GEAR ACTUATOR.

- a. Inspect all threaded surfaces for cleanliness and for cracks or excessive wear.
- b. Inspect downlock hook spring for evidence of breaks and distortion. Free length of spring must be 2.406 ± 0.080 -inches, and compressed to 2.00-inches under a 19.80 ± 2.0 pound load.
- c. Inspect hooks, spring guide, bearing end, piston, cylinder and bushing for cracks, chips, scratches, scoring, wear or surface irregularities which may affect their function or the overall function of the nose gear actuator.
- d. Repair of most parts of the actuator assembly is impractical. Replace defective parts with serviceable parts.
- e. Minor scratches and scores may be removed by polishing with fine abrasive crocus cloth (Federal Specification PC-458), providing their removal does not affect operation of the unit.

5-109. REASSEMBLY OF NOSE GEAR ACTUATOR. (Refer to figure 5-23.)

NOTE

Install new O-rings and back-up rings lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

- a. Install O-rings and back-up rings in bearing end.
- b. Install O-rings and back-up rings on piston.
- c. Insert piston into cylinder. Do not damage back-up rings and O-rings when inserting piston.
- d. With knurled nut on cylinder, install bearing end of cylinder. Use care to avoid damage to O-rings and back-up rings when installing bearing end of cylinder.

NOTE

Centerline of hook pins and centerline of bushing hole must align within 0.005-inch with cylinder assembled at a length of 11.98 ± 0.03 -inches, measured from centerline of hook pins to centerline of bushing in cylinder in cylinder anchor end.

MODEL P210 SERIES SERVICE MANUAL

- e. Tighten and safety wire knurled nut.
- f. Install lock nut on end of piston.
- g. Assemble and install hook assembly on piston.

5-110. INSTALLATION OF NOSE GEAR ACTUATOR.

NOTE

Before installing nose gear actuator, check condition of fit and attaching bolts and bushings. Replace any defective parts. Fill actuator with hydraulic fluid.

- a. Attach aft end of actuator to fuselage structure with bolt, washer and nut. Safety nut with cotter pin.
- b. Assemble and attach nose gear downlock mechanism to lower trunnion as shown in figure 5-18.

5-111. REMOVAL AND INSTALLATION OF NOSE GEAR ACTUATOR.

- a. Disconnect uplock spring.
- b. Disconnect and cap or plug hydraulic lines at actuator.
- c. Disconnect and tag up-limit switch electrical wires.
- d. Remove cotter pin and clevis pin attaching actuator link to bellcrank arm. Note position of spacer washers and direction of clevis pin.
- e. Remove nuts, washers and bolts attaching actuator to wheel well tunnel wall. Note and retain shims between actuator and tunnel wall.
- f. Remove bolt, washer and nut attaching bellcrank at top of nose wheel.

NOTE

Use care to avoid dropping bearings in bellcrank assembly. Retain washers used as shims at each end of bellcrank.

- g. Install uplock mechanism and actuator by reversing the preceding steps. Install shims and washers as noted during removal.

5-112. NOSE GEAR DOOR SYSTEM. (Refer to figure 5-24.)

5-113. DESCRIPTION. The nose gear door system consists of a right and left forward door, actuated by push-pull rods and a torque tube assembly. The aft doors are attached to the torque tube assembly with springs.

5-114. REMOVAL AND INSTALLATION. (Refer to figure 5-24.)

- a. Remove hinge bolts, nuts, washers and bushings.
- b. Remove nuts from push-pull rods and remove forward doors.
- c. Disconnect spring from aft door eyebolt, and remove aft doors.
- d. Reverse preceding steps to install nose gear doors.

NOTE

Upon completion of installation, safety-wire bolts (*) to clips (13).

NOTE

Check nose gear door-to-cowling clearance to be 0.12-inch to 0.15-inch on the left and right sides of the nose gear doors each time the turbine access door on turbocharged models is re-installed.

5-115. NOSE WHEEL STEERING SYSTEM. (Refer to figure 5-25.)

5-116. DESCRIPTION. The nose wheel steering system links the rudder pedals to the nose wheel fork, affording steering control through use of the rudder pedals. The nose gear torque links straighten the nose wheel as the landing gear is retracted.

5-117. REMOVAL AND INSTALLATION OF NOSE WHEEL STEERING SYSTEM COMPONENTS. (Refer to figure 5-25.) Refer to the figure as a guide in determining relationship of steering system components. Also, the illustration may be used as a guide during removal and installation of system components.

5-118. RIGGING OF NOSE WHEEL STEERING SYSTEM. Since the nose wheel steering system is connected with the rudder control system, adjustment to one system would directly affect the other. Refer to Section 10 of this manual for rigging procedures for the rudder system and the nose wheel steering system.

5-119. TROUBLE SHOOTING. (Refer to paragraph 5-80.)

5-120. RIGGING NOSE LANDING GEAR. (Refer to figure 5-26.)


NOTE

Nose gear shock strut must be correctly inflated prior to rigging the nose gear. Refer to Section 1 of this manual for correct nose gear shock strut inflation pressure.

- a. Jack aircraft in accordance with procedures outlined in Section 2 of this manual.
- b. Actuator locking hooks (1) on the nose gear actuator shall completely engage downlock pins (2) without drag, and cross bar (3) shall rotate freely to indicate it is not bearing on either side of slot in rod end (4). Adjust rod end of actuator as required.

MODEL P210 SERIES SERVICE MANUAL

* Safety wire bolts to clips (13).




- | | |
|---------------------|-----------------------------|
| 1. RH Fwd Door | 13. Clip |
| 2. Bushing | 14. Switch Assembly |
| 3. Washer | 15. Bellcrank Weld Assembly |
| 4. Barrel Assembly | 16. Bearing |
| 5. Up-Stop | 17. Washer |
| 6. Bearing Assembly | 18. RH Aft Door |
| 7. Spacer | 19. LH Aft Door |
| 8. Spacer | 20. Hinge Pin |
| 9. Arm | 21. Eyebolt |
| 10. Bolt | 22. LH Fwd Door |
| 11. Spring | |
| 12. Stop Assembly | |

NOTE

REFER TO PARAGRAPH 5-124 FOR COMPLETE DOOR RIGGING PROCEDURES.

Figure 5-24. Nose Gear Doors

MODEL P210 SERIES SERVICE MANUAL



5-25. Nose Wheel Steering System

CAUTION

The piston rod is flattened near the threads to provide a wrench pad. Do not grip the piston rod with pliers, as tool marks will cut the O-ring seal in the actuator.

5-121. RIGGING NOSE GEAR DOWN LIMIT SWITCH. (Refer to figure 5-26.) The nose gear down limit switch is mounted on a tab which is a part of the bearing end (5) of the nose gear actuator. The switch is actuated by the right-hand actuator locking hook (1). Switch adjustment is accomplished by loosening the lock nut and either tightening or loosening the adjustment nut and re-tightening the lock nut against the tab behind the adjustment nut. Down limit switch is to be adjusted to the dimension stipulated in the figure.


5-122. RIGGING NOSE GEAR UP LIMIT SWITCH. (Refer to figure 5-26.) The nose gear up limit switch

is mounted to a bracket, located in the left-hand forward area of the nose wheel well. The switch is activated by the left-hand arm of the bellcrank weld assembly. Switch adjustment is provided by slots in the switch mounting bracket. Up limit switch is to be adjusted to the dimension stipulated in the figure.

5-123. RIGGING OF NOSE GEAR SQUAT SWITCH. (Refer to figure 5-26.) The nose gear squat switch (safety) switch is mounted in a bracket, attached to the upper nose gear torque link. The switch is operated by an actuator, attached to the nose gear lower torque link. Adjust squat switch so that contacts close when nose gear strut is .12 to .25-inch from fully-extended position.


5-124. RIGGING OF NOSE GEAR DOORS. (See figure 5-24.) Nose gear door adjustments are accomplished by adjusting push-pull rod ends as required to cause the doors to close snugly. Doors must fair

MODEL P210 SERIES SERVICE MANUAL



NOTE

The locking hooks (1) have been dry film lubricated at the factory and should last the life of the parts. However, they may be field lubricated by spraying with Lubri-Bond "A", Lubri Bond 220, or Perma-Silk. After application, allow parts to air dry for six hours, or dry for one hour at 120° F. Lubri Bond "A" and Lubri Bond 220 are products of Electro-Film Inc., North Hollywood, Ca. Perma-Silk is a product of the Everlube Corp., North Hollywood, Ca.



1. Locking Hook
2. Downlock Pin
3. Cross Bar
4. Rod End
5. Bearing End
6. Stop Assembly
7. Arm
8. Bellcrank Weld Assembly

Figure 5-26. Rigging Nose Landing Gear (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 5-26. Rigging Nose Landing Gear (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

when the nose gear is fully retracted. Link rods are to be adjusted so that the doors, when in the open position, clear any part of the nose gear assembly by a minimum of 0.25-inch during retraction. Nose gear doors are designed to overlap the lower cowl skin. Adjust stop bolts on stop assemblies (12) as required to contact arms (9) on bellcrank weld assembly (15) when forward nose gear doors are in FULL-OPEN position. Adjust barrel assemblies (4) as required to fair forward nose gear doors in closed position. Pack bearings (16) with MIL-G-21164 grease. Safety wire bolts (*) to clips (23).

5-125. FINAL LANDING GEAR SYSTEMS CHECK. After landing gear systems have been installed and rigged, prior to removal from jacks, cycle landing gear through 25 cycles using the system's emergency hand pump.

NOTE

Check fluid level in power pack reservoir frequently during purging and system checks.

One of the 25 cycles shall consist of a downlock malfunction check, consisting of the following procedure, using a 28 volt DC, 60 amp electrical power supply.

- a. Pull hydraulic circuit breaker off.
- b. With gear in down and locked position, move gear selector handle GEAR UP position and note actuation of main gear downlock hooks.
- c. As soon as left downlock hook is actuated to unlock the left gear, move gear selector handle back to GEAR DOWN position to simulate what would occur if the pilot were to select gear down before the gear was fully retracted. If downlock hooks do not lock the gear in the down position, check downlock system for misalignment.

NOTE

This malfunction check is in addition to the check used during the rigging procedure.

- d. Remove aircraft from jacks.

5-126. NOSE WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-27.)

5-127. DESCRIPTION. The aircraft are equipped with McCauley wheel assemblies.

NOTE

Use of recapped tires or new tires not listed on the aircraft equipment list are not recommended due to possible interference between the tire and structure when landing gear is in the retracted position.

5-128. OPERATION. The nose gear wheel is free-rolling on an independent axle and is used to steer the aircraft while taxiing by means of the nose wheel steering system.

5-129. REMOVAL OF NOSE WHEEL AND TIRE ASSEMBLY.

- a. Weight tail of aircraft to raise nose wheel off the ground.
- b. Remove nose wheel axle bolt.
- c. Use a rod or long punch inserted in ferrule to tap opposite ferrule out of nose wheel fork.
- d. Remove spacers, axle tube and hub caps before disassembling nose wheel.
- e. Reverse preceding steps to install nose wheel. Tighten axle bolt until a slight bearing drag is obvious when the wheel is turned. Back off nut to nearest castellation and install cotter pin.

5-130. DISASSEMBLY OF NOSE WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-27.)

WARNING

Injury can result from attempting to separate wheel halves with the tire inflated. Avoid damaging wheel flanges when breaking tire beads loose.

- a. Remove valve core, completely deflate tire, and break tire beads loose.
- b. Remove thru-bolts and separate wheel halves.
- c. Remove tire and tube.
- d. Remove bearing retaining rings, grease seals and bearing cones.

NOTE

The bearing cups are a press fit in the wheel halves and should not be removed unless replacement is necessary. To remove, heat wheel half in boiling water for 15 minutes. Using an arbor press, if available, press out bearing cup and press in the new one while the wheel is still hot.


5-131. INSPECTION AND REPAIR OF NOSE WHEEL AND TIRE ASSEMBLY. Procedures outlined in paragraphs regarding the main wheel and tire assemblies may be used as a guide for inspection and repair of the nose wheel and tire assembly.

5-132. REASSEMBLY OF NOSE WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-27.)

- a. Place tube inside tire and align balance marks on tire and tube.
- b. Place tire and tube on wheel half with tube valve stem through hole in wheel half.

CAUTION

Uneven or improper torque of the thru-bolt nuts may cause bolt failure with resultant wheel failure.



NOTE

Tighten nuts (11) evenly and torque to 140-150 lb-in.

Do not use impact wrenches on thru-bolts (7) or nuts (11).

- 1. Snap Ring
- 2. Grease Seal Ring
- 3. Bearing
- 4. Tire
- 5. Tube
- 6. Grease Seal Felt
- 7. Thru-Bolt
- 8. Bearing Cup
- 9. Wheel Half
- 10. Washer
- 11. Nut

Figure 5-27. Nose Gear Wheel and Tire Assembly

MODEL P210 SERIES SERVICE MANUAL

- c. Insert thru-bolts, position other wheel half and secure with nuts and washers. Torque bolts to value stipulated in figure 5-27.
- d. Clean and repack bearing cones with clean wheel bearing grease.
- e. Assemble bearing cones, seals, and retainers into wheel half.
- f. Inflate tire to seat tire beads, then adjust to correct pressure.

5-133. INSTALLATION OF NOSE WHEEL AND TIRE ASSEMBLY.

- a. Install nose wheel in fork and install ferrules.
- b. Install axle stud.
- c. Tighten axle stud until a slight bearing drag is obvious when the wheel is turned. Back off nut to nearest castellation and install cotter pins.

5-134. BRAKE SYSTEM.

5-135. DESCRIPTION. The hydraulic brake system consists of two master cylinders, brake lines, connecting each master cylinder to its corresponding wheel brake cylinder, and the single, disc-type brake assembly, located at each main landing gear wheel.

CAUTION

After connecting brake hose, ensure that hose does not contact or rub against brake disc, causing brake hose failure.

5-136. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
DRAGGING BRAKES.	Brake pedal binding.	Check and adjust properly.
	Parking brake linkage holding brake pedal down.	Check and adjust properly.
	Worn or broken piston return spring. (In master cylinder.)	Repair or replace master cylinder.
	Restriction in hydraulic lines of restriction in compensating port in master brake cylinder.	Drain brake lines and clear the inside of the brake line with filtered compressed air. Fill and bleed brakes. If cleaning the lines fail to give satisfactory results, the master cylinder may be faulty and should be repaired.
	Worn, scored, or warped brake discs.	Replace brake disc and linings.
BRAKES FAIL TO OPERATE.	Damage or accumulated dirt restricting free movement of wheel brake parts.	Clean and repair or replace parts as necessary.
	Leak in system.	Check entire system for leaks. If brake master cylinders or wheel assemblies are leaking, they should be repaired or replaced.
	Air in system.	Bleed system.
	Lack of fluid in master cylinders.	Fill and bleed systems.

MODEL P210 SERIES SERVICE MANUAL

5-137. BRAKE MASTER CYLINDER. (Refer to figure 5-28.)

5-138. DESCRIPTION. The brake master cylinders, located immediately forward of the pilot's rudder pedals, are actuated by applying pressure at the top of the rudder pedals. A small reservoir is incorporated into each master cylinder for the fluid supply. When dual brakes are installed, mechanical linkage permits the copilot pedals to operate the master cylinders.

5-139. REMOVAL.

- a. Remove bleeder screw at wheel brake assembly and drain hydraulic fluid from brake cylinders.
- b. Remove front seats and rudder bar shield for access to brake master cylinders.
- c. Disconnect parking brake linkage and disconnect brake master cylinders from rudder pedals.
- d. Disconnect hydraulic hose from brake master cylinders and remove cylinders.
- e. Plug or cap hydraulic fittings, hose and lines to prevent entry of foreign material.

5-140. DISASSEMBLY. (Refer to figure 5-28.)

- a. Unscrew clevis (1) and nut (2).
- b. Remove filler plug (3).

NOTE

A special tool, brake master cylinder wrench No. 34-101 is available from Watkins Supply 711 W 2nd Wichita, KS. 67203. Use to accomplish the following step.

- c. Unscrew cover (4) and remove up over piston (5).
- d. Remove piston (5) and spring (8).
- e. Remove packing (7) and back-up ring (6) from piston (5).

5-141. INSPECTION AND REPAIR. (Refer to figure 5-28.) Repair is limited to installation of new parts and cleaning. Use clean hydraulic fluid (MIL-H-5606) as a lubricant during reassembly of the cylinder. Replace packings and back-up rings. Filler plug (3) must be vented so pressure cannot build up during brake operation. Remove plug and drill 1/16-inch hole, 30° from vertical, if plug is not vented. Refer to View A-A for location of hole.

5-142. REASSEMBLY. (Refer to figure 5-28.)

- a. Install spring (8) into cylinder body (9).
- b. Install back-up ring (6) and packing (7) in groove of piston (5).
- c. Install piston (5) in cylinder body (9).
- d. Install cover (4) over piston (5) and screw cover into cylinder body (9).
- e. Install nut (2) and clevis (1).
- f. Install filler plug (3), making sure vent hole is open.

5-143. INSTALLATION.

- a. Connect hydraulic hoses to brake master cylinders.
- b. Connect brake master cylinders to rudder pedals and connect parking brake linkage.
- c. Install rudder bar shield and install front seats.
- d. Install bleeder screw at wheel brake assembly and fill and bleed brake system in accordance with

applicable paragraph in Section 5.

5-144. HYDRAULIC BRAKE LINES.

5-145. DESCRIPTION. The brake lines are of rigid tubing, except for flexible hose used at the brake master cylinders. A separate line is used to connect each brake master cylinder to its corresponding wheel brake cylinder.

WARNING

After connecting brake hose, ensure that hose does not contact or rub against brake disc, causing brake hose failure.

5-146. WHEEL BRAKE ASSEMBLIES.

(Refer to figure 5-12.)

5-147. DESCRIPTION. The wheel brake assemblies employ a floating brake assembly and a disc which is attached to the main wheel.

5-148. WHEEL BRAKE REMOVAL. (Refer to figure 5-12.) Wheel brake assemblies can be removed by disconnecting the brake line (drain fluid when disconnecting the brake line) and removing the brake back plate. The brake disc is removed after the wheel is removed and disassembled. To remove the torque plate, remove wheel and axle.

5-149. WHEEL BRAKE DISASSEMBLY.

Refer to figure 5-12 for a breakdown of wheel brake parts. This figure may be used as a guide for disassembling the wheel brakes.

5-150. WHEEL BRAKE INSPECTION AND REPAIR.

- a. Clean all parts except brake linings and O-rings in dry cleaning solvent and dry thoroughly.
- b. Install all new O-rings. If O-ring reuse is necessary, wipe with a clean cloth saturated in hydraulic fluid and inspect for damage.

NOTE

Thorough cleaning is important. Dirt and chips are the greatest single cause of malfunctions in the hydraulic brake system.

- c. Check brake lining for deterioration and maximum permissible wear. (Refer to applicable paragraph for maximum wear limit.)
- d. Inspect brake cylinder bore for scoring. A scored cylinder will leak or cause rapid O-ring wear. Install a new-brake cylinder if the bore is scored.
- e. If the anchor bolts of the brake assembly are nicked or gouged, they shall be sanded smooth to prevent binding with the pressure plate or torque plate. When new anchor bolts are to be installed, press out old bolts and install new bolts with a soft mallet.
- f. Inspect wheel brake disc for minimum thickness. If disc is below minimum thickness, install a new part. Minimum thickness of Cleveland disc No. 164-07800 is .450 inch.

MODEL P210 SERIES SERVICE MANUAL




Figure 5-28. Master Brake Cylinder

MODEL P210 SERIES SERVICE MANUAL

5-151. WHEEL BRAKE REASSEMBLY. (Refer to figure 5-12).

NOTE

Lubricate parts with a clean hydraulic fluid during brake reassembly.

a. Refer to figure 5-10 as a guide while reassembling wheel brakes.

5-152. WHEEL BRAKE INSTALLATION.

a. Place brake assembly in position with pressure plate in place.

NOTE

If torque plate was removed, install as the axle is installed, or install on axle. If the brake disc was removed, install as wheel is assembled.

5-153. BRAKE LINING. The brake lining pads used in this assembly are either non-asbestos organic composition or iron based metallic composition. Brake pads must be properly conditioned (glazed) before use in order to provide optimum service life. This is accomplished by a brake burn-in. Burn-in also wears off brake high spots prior to operational use. If brake use is required before burn-in, use brakes intermittently at LOW taxi speeds.

5-153A. BRAKE BURN-IN.

CAUTION

Brake burn-in must be performed by a qualified person familiar with acceleration and stop distances of the airplane.

a. Non-asbestos Organic Composition burn-in.

1. Taxi the airplane for 1500 feet, with engine at 1700 RPM, applying brake pedal force as needed to maintain 5 to 10 M.P.H. (5 to 9 Knots).

2. Allow brakes to cool for 10 to 15 minutes.

3. Apply brakes and check to see if a high throttle static engine run-up can be held with normal pedal force. If so, conditioning burn-in is complete.

4. If static run-up cannot be held, repeat Steps 1. thru 3. as needed.

b. Metallic Composition Burn-in.

1. Taxi the airplane at 34 to 40 M.P.H. (30 to 35 Knots) and perform full stop braking application.

CAUTION

Brake conditioning using successive stops at higher speeds could cause brakes to overheat resulting in warped discs and/or pressure plates.

2. Without allowing brake discs to cool substantially, repeat Step 1. for second full stop braking application.

3. Apply brakes and check to see if a high throttle static engine run-up can be held with normal pedal force. If so, conditioning burn-in is complete.

4. If static run-up cannot be held, repeat Steps 1. thru 3. as needed.

NOTE

Normal brake usage should generate enough heat to maintain the glaze throughout the life of the lining. Light brake usage can cause the glaze to wear off, resulting in reduced brake performance. Visual inspection of brake disc will indicate brake lining condition. A smooth, non-grooved surface indicates linings are properly glazed. Rough, grooved linings must be reglazed. In such cases, the lining may be conditioned again following the instructions set forth above.

NOTE

Do not set parking brakes while brake discs are hot.

5-154. CHECKING BRAKE LINING WEAR. New brake lining should be installed when the existing lining has worn to a thickness of 3/32-inch. A 3/32-inch strip of material held adjacent to each lining can be used to determine amount of wear. The shank end of a drill bit of the correct size can also be used to determine wear of brake linings.

5-155. BRAKE LINING INSTALLATION. (Refer to figure 5-12).

a. Remove bolts securing back plate, and remove back plate

b. Pull brake cylinder out of torque plate and slide pressure plate off anchor bolts.

c. Place back plate on a table with lining side down flat. Center a 9/64-inch (or slightly smaller punch) in the rolled rivet, and hit the punch sharply with a hammer. Punch out all rivets securing the linings to the back plate in the same manner.

NOTE

A rivet setting kit, Part. No. 199-1, is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations. This kit contains a punch and an anvil.

d. Clamp the flat side of the anvil in a vise.

e. Align new lining on back plate and place brake rivet in hole with rivet head in the lining. Place the head against the anvil.

f. Center rivet setting punch on lips of rivet. While holding back plate down firmly against lining, hit punch with a hammer to set rivet. Repeat blows on punch until lining is firmly against back plate.

g. Realign the lining on the back plate and install and set rivets in the remaining holes.

h. Install a new lining on pressure plate in the same manner.

i. Position pressure plate on anchor bolts and place cylinder in position so that anchor bolts slide into the torque plate.

j. Install back plate with bolts and washers.

WARNING

After reinstallation of the brake assembly, check brake line clearance to the disc in the area above the axle.

MODEL P210 SERIES SERVICE MANUAL

5-156. BRAKE SYSTEM BLEEDING.

NOTE

Bleeding with a clean hydraulic pressure source connected to the wheel cylinder bleeder is recommended.

- a. Remove brake master cylinder filler plug and screw flexible hose with appropriate fitting into the filler hole at top of the brake master cylinder.
- b. Immerse opposite end of flexible hose into a container with enough hydraulic fluid to cover end of the hose.
- c. Connect a clean hydraulic pressure source, such as a hydraulic hand pump or Hydro-Fill unit to the bleeder valve in the wheel cylinder.
- d. As fluid is pumped into the system, observe the immersed end of the hose at the master cylinder for evidence of air bubbles being forced from the brake system. When bubbling has ceased, remove bleeder source from wheel cylinder and tighten the bleeder valve.

5-157. PARKING BRAKE SYSTEM. (Refer to figure 5-29).

5-158. DESCRIPTION. The parking brake system consists of a handle and ratchet mechanism, connected by a cable to linkage at the brake master cylinders. Pulling out on the handle depresses both brake master cylinder piston rods and the handle ratchet locks the handle in this position until the handle is turned and released.

5-159. REMOVAL AND INSTALLATION OF COMPONENTS. (Refer to figure 5-29). For relative location of system components. The illustration may be used as a guide during removal and installation of components.

5-160. INSPECTION AND REPAIR OF SYSTEM COMPONENTS. Inspect lines for leaks, cracks, dents, chafing, improper radius, security, corrosion, deterioration, obstructions and foreign matter. Check brake master cylinders and repair or replace as outlined in applicable paragraph in this Section. Check parking brake handle and ratchet for proper operation and release. Replace worn or damaged parts.





Figure 5-29. Parking Brake System (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL



- 12. Bracket
- 13. Pulley
- 14. Spacer
- 15. Bellcrank
- 16. Cotter Pin
- 17. Cable
- 18. Brake Line
- 19. Fitting
- 20. Nut
- 21. O-Ring
- 22. Hose
- 23. Grommet
- 24. Brake Master Cylinder
- 25. Sleeving

Figure 5-29. Parking Brake System (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

SECTION 6

AILERON CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
AILERON CONTROL SYSTEM	1J13/6-1	Installation	1J21/6-9
Description	1J13/6-1	Repair	1J21/6-9
Trouble Shooting	1J13/6-1	Aileron	1J21/6-9
Control Column	1J14/6-2	Removal/Installation	1J21/6-9
Description	1J14/6-2	Repair	1J21/6-9
Removal/Installation	1J14/6-2	Aileron Trim Tab	1J21/6-9
Repair	1J20/6-8	Removal/Installation	1J21/6-9
Bearing Roller Adjustment	1J20/6-8	Adjustment	1J22/6-10
Aileron Bellcrank	1J20/6-8	Cables and Pulleys	1J22/6-10
Removal	1J20/6-8	Removal/Installation	1J22/6-10
		Rigging	1J22/6-10

6-1. **AILERON CONTROL SYSTEM.** (Refer to figure 6-1.)

comprised of push-pull rods, bellcranks, cables, pulleys, quadrants and components forward of the instrument panel, all of which link the control wheels to the ailerons.

6-2. **DESCRIPTION.** The aileron control system is

6-3. **TROUBLE SHOOTING.**

NOTE

Due to remedy procedures in the following trouble shooting chart it may be necessary to rerig system. Refer to paragraph 6-17.

TROUBLE	PROBABLE CAUSE	REMEDY
LOST MOTION IN CONTROL WHEEL.	Loose control cables.	Check cable tension. Adjust cables to proper tension.
	Broken pulley or bracket, cable off pulley or worn rod end bearings.	Check visually. Replace worn or broken parts, install cables correctly.
RESISTANCE TO CONTROL WHEEL MOVEMENT.	Cables too tight.	Check cable tension. Adjust cables to proper tension.
	Pulleys binding or cable off.	Observe motion of the pulleys. Check cables visually. Replace defective pulleys. Install cables correctly.
	Bellcrank distorted or damaged.	Check visually. Replace defective bellcrank.
	Defective quadrant assembly.	Check visually. Replace defective quadrant.
	Clevis bolts in system too tight.	Check connections where used. Loosen, then tighten properly and safety.

MODEL P210 SERIES SERVICE MANUAL

6-3. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
CONTROL WHEELS NOT LEVEL WITH AILERONS NEUTRAL.	Improper adjustment of cables.	Refer to paragraph 6-17.
	Improper adjustment of aileron push-pull rods.	Adjust push-pull rods to obtain proper alignment.
DUAL CONTROL WHEELS NOT COORDINATED.	Cables improperly adjusted.	Refer to paragraph 6-17.
INCORRECT AILERON TRAVEL.	Push-pull rods not adjusted properly.	Refer to paragraph 6-17.
	Incorrect adjustment of travel stop bolts.	Refer to paragraph 6-17.

6-4. CONTROL COLUMN. (Refer to figure 6-2.)

6-5. DESCRIPTION. Rotation of the control wheel rotates four bearing roller assemblies (2) on the end of the control wheel tube (12), which in turn rotates a square control tube assembly (17) inside and extending from the control wheel tube (12). Attached to this square tube (17) is a quadrant (32) which operates the aileron system. This same arrangement is provided for both control wheels. Synchronization of the control wheels is obtained by the interconnect cable (29), turnbuckle (37) and adjustable terminals (31). The forward end of the square control tube (17) is mounted in a bearing block (33) on firewall (36) and does not move fore-and-aft, but rotates with the control wheel. The four bearing roller assemblies (2) on the end of the control wheel tube reduce friction as the control wheel is moved fore-and-aft for elevator system operation. A sleeve weld assembly (6), containing bearings which permit the control wheel tube to rotate within it, is secured to the control wheel tube by a sleeve and retaining ring in such a manner it moves fore-and-aft with the control wheel tube. This movement allows the push-pull tube (18) attached to the sleeve weld assembly (6) to operate an elevator arm assembly (19), to which one elevator cable (20) is attached. A torque tube (22) connects this arm assembly (19) to the one on the opposite end of the torque tube (22), to which the other elevator cable is attached. The copilot's control wheel is linked to the aileron and elevator control systems in the same manner as the pilot's control wheel.

6-6. REMOVAL AND INSTALLATION. (Refer to figure 6-2, sheet 3).

- Remove bolts securing adapter to control wheel tube assembly (41).
- Disconnect electrical wiring to map light, mike

switch and electric trim switch at connector.

c. (Refer to figure 6-2, sheet 1.) Remove decorative cover from instrument panel.

d. Remove screw securing adjustable glide plug (15) to control tube assembly (17) and remove plug (15) and glide (16).

e. Disconnect push-pull tube (18) at sleeve weld assembly (6).

f. Remove screws securing cover plate (14) at instrument panel.

g. Using care, pull control wheel tube assembly (12) aft and work assembly out through instrument panel.

NOTE

To ease removal of control wheel tube assembly (12), snap rings (10) may be removed from their locking grooves to allow sleeve weld assembly (6) additional movement.

If removal of control tube assembly (17) or quadrant (32) is necessary, proceed to step "h."

h. Remove safety wire and relieve direct cable tension at turnbuckles (index 2, figure 6-1).

i. Remove safety wire, relieve interconnect cable tension at turnbuckle (37) and remove cables from quadrant (32).

j. Remove safety wire and remove roll pin (30) through quadrant (32) and control tube assembly (17).

k. Remove pin, nut (34) and washer from control tube assembly (17) protruding through bearing block (33) on forward side of firewall (36).

l. Using care, pull control tube assembly (17) aft and remove quadrant (31).

m. Reverse the preceding steps for reinstallation. Rig aileron, interconnect and elevator control sys-

MODEL P210 SERIES SERVICE MANUAL





Figure 6-1. Aileron Control System (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL



- 6. Spacer
- 7. Housing
- 8. Pressure Seal
- 9. Bushing
- 10. Cable (Carry-Thru)
- 11. Pivot Bolt
- 12. Upper Wing Skin
- 13. Upper Support
- 14. Brass Washer
- 15. Bushing
- 16. Needle Bearing
- 17. Travel Stop Bolt
- 18. Push-Pull Rod
- 19. Lower Support
- 20. Bellcrank

Figure 6-1. Aileron Control System (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL





Figure 6-2. Control Column Installation (Sheet 1 of 3)

MODEL P210 SERIES SERVICE MANUAL


- 17. Control Tube Assembly
- 24. Retainer
- 25. Bearing Roller
- 26. Washer
- 27. Aileron Control Cable
- 28. Cable Guard
- 29. Interconnect Cable
- 30. Roll Pin
- 31. Interconnect Cable Adjustment Terminal
- 32. Quadrant
- 33. Bearing Block
- 34. Nut
- 35. Spacer
- 36. Firewall
- 37. Interconnect Cable Turnbuckle



VIEW A-A

NOTES

Washers (39) are of various thicknesses and are used to obtain dimension shown in view A-A.



NOTES

Allow 0.030" maximum clearance between bearing block (31) and nut (30) after tightening.

Adjust interconnect cable (32) tension to 30 ± 10 lbs.

*Safety wire these items.

Figure 6-2. Control Column Installation (Sheet 2 of 3)

MODEL P210 SERIES SERVICE MANUAL

- 12. Control Wheel Tube
- 38. Map Light Rheostat
- 39. Transponder Identification
- 40. Pitch Sync
- 41. Control Wheel
- 42. Mike Switch
- 43. Go Around
- 44. Electric Trim Switch
- 45. Map Light Assembly
- 46. Knob
- 47. Trim Disengage
- 48. Autopilot Disengage
- 49. Cover




Figure 6-2. Control Column Installation (Sheet 3 of 3)

MODEL P210 SERIES SERVICE MANUAL




Figure 6-3. Aileron Installation

tems in accordance with paragraphs 6-17 and Section 8 respectively. Safety turnbuckles and all other items previously safetied. Tighten nut (34) securing control tube assembly (17) to firewall snugly, then loosen nut to 0.030" maximum clearance between nut and bearing block, align cotter pin hole and install pin.

6-7. REPAIR. Worn, damaged or defective shafts, bearings, quadrants, cables or other components should be replaced. Refer to Section 2 for lubrication requirements.

6-8. BEARING ROLLER ADJUSTMENT. (Refer to figure 6-2.) Each bearing assembly (11) has an 0.062" eccentric adjustment when installed. for aligning the control tube weld assembly and push-pull tube (18) with the guide assembly (23). For alignment, proceed as follows:

- a. Remove control wheel assembly in accordance with paragraph 6-6.
- b. Install cover plate (14) backwards (bearing on aft side) and leave loose with instrument panel.

c. Align control wheel tube assembly (12) for free travel of push-pull tube (18) along full length of guide assembly (23).

d. Center cover plate (14) over tube and bearing assembly and secure plate to instrument panel.

e. Adjust each bearing (11) to control wheel tube assembly and tighten bearings in place.


f. Remove cover plate and reinstall with bearings facing forward.

6-9. AILERON BELLCRANK. (Refer to figure 6-1.)

6-10. REMOVAL.

- a. Remove access plate inboard of each bellcrank (20) on underside of wing.
- b. Remove safety wire and relieve cable tension at turnbuckles (1).
- c. Disconnect control cables from bellcrank (20).
- d. Disconnect push-pull tube (18) at bellcrank (20).
- e. Remove bolts (11) securing bellcrank to wing structure.

MODEL P210 SERIES SERVICE MANUAL



AVAILABLE FROM CESSNA PARTS DISTRIBUTION (CPD 2)
THROUGH CESSNA SERVICE STATIONS (TOOL NO. SE716)

Figure 6-4. Inclinometer for Measuring Control Surface Travel

- f. Remove bellcrank through access opening, using care that bushing (13) is not dropped from bellcrank.

NOTE

Brass washers (12) may be used as shims between each end of bellcrank and supports (11 and 17). Retain these shims. Tape open ends of bellcrank to prevent dust and dirt from entering bellcrank needle bearings (14).

6-11. INSTALLATION.

- Connect control cables (4 and 7) to bellcrank (18) prior to installing bellcrank.
- Place bushing (13) in bellcrank and position bellcrank in wing.
- Install brass washers (12) as required between upper and lower end of bellcrank and wing supports to shim out excess clearance.
- Install bellcrank pivot bolt (9).
- Connect push-pull rod (16) to bellcrank.
- Re-rig aileron system in accordance with paragraph 6-21. safety turnbuckles and reinstall all items removed for access.

6-12. REPAIR. Repair of bellcranks consists of replacement of defective parts. If needle bearings are dirty or in need of lubrication. Clean thoroughly and lubricate as outlined in Section 2.

6-13. AILERONS. (Refer to figure 6-3.)

6-14. REMOVAL AND INSTALLATION

- Remove access plate (4) and disconnect push-pull rod (5) at aileron.
- Remove wing tip for access to outboard hinge bolt.
- Run flaps to full down position for access to inboard hinge bolt.
- Remove hinge bolts (6) securing aileron and carefully remove aileron from wing.
- Reverse the preceding steps for reinstallation. Rig system, if necessary, in accordance with paragraph 6-21 and reinstall all items removed for access.

NOTE

If rigging was correct and push-pull rod adjustment was not disturbed, it should not be necessary to re-rig system.

6-15. REPAIR. Aileron repair and static balance may be accomplished in accordance with instructions outlined in Section 18. Before installation, ensure balance weights and hinges are securely attached.

6-16. AILERON TRIM TAB. (Refer to figure 6-3.)

6-17. REMOVAL AND INSTALLATION.

- Remove screws on lower side of tab.
- Drill out rivets on upper side of tab and remove tab.
- Reverse the preceding steps for reinstallation.

MODEL P210 SERIES SERVICE MANUAL

- b. Drill out rivets on upper side of tab and remove tab.
- c. Reverse the preceding steps for reinstallation.

6-18. **ADJUSTMENT.** Adjustment is accomplished by loosening the screws, shifting tab trailing edge up to correct for a wing-heavy condition or down to correct for a wing-light condition. Divide correction equally on both tabs. When installing a new wing or aileron, set tab in neutral and adjust as necessary after flight test.

6-19. **CABLES AND PULLEYS.** (Refer to figure 6-1.)

6-20. **REMOVAL AND INSTALLATION.**

- a. Remove access plates, wing root fairings and upholstery as required.
- b. Remove safety wire and relieve cable tension at turnbuckles (1 and 2).
- c. Disconnect cables from aileron bellcranks (20) and quadrants (index 32, figure 6-2.)
- d. Remove cable guards, pulleys and pressure seals as required to work cables from aircraft.

NOTE

To ease routing of cables, a length of wire may be attached to end of the cable before being withdrawn from aircraft. Leave wire in place, routed through structure; then attach the cable being installed and use wire to pull cable into position.

- e. Reverse the preceding steps for reinstallation.
- f. After cables are routed in position, install pulleys and cable guards. Ensure cables are positioned in pulley grooves before installing guards.
- g. Re-rig aileron system in accordance with paragraph 6-17, safety turnbuckles and install access plates, fairings and upholstery removed in step "a."

6-17. **RIGGING.**

- a. (Refer to figure 6-1.) Remove access plates and upholstery as required.
- b. Remove safety wire and relieve all cable tension at turnbuckles (1 and 2).
- c. Disconnect push-pull rods (18) at bellcranks (20).
- d. (Refer to figure 6-2.) Adjust turnbuckle (37) and adjustment nuts (31) on interconnect cable (29) to remove slack, acquire proper tension (30±10 pounds) and position both control wheels level (synchronized).
- e. Tape a bar across both control wheels to hold them in neutral position.
- f. (Refer to figure 6-1.) Adjust direct cable turnbuckles (1) and carry-thru cable turnbuckle (2) to position bellcranks (20) approximately in neutral while maintaining 40±10 pounds tension on carry-thru cable (10).
- f. Streamline ailerons with reference to flaps (flaps full UP and disregarding aileron trim tabs), then adjust push-pull rods (18) to fit and install.
- g. With ailerons streamlined, mount an inclinometer on trailing edge of aileron and set pointer to 0°.

NOTE

An inclinometer for measuring control surface travel is available from the Cessna Supply Division. Refer to figure 6-4.

- h. Remove bar from control wheels and adjust travel stop bolts (17) to degree of travel specified in figure 1-1.
- i. Ensure all turnbuckles are safetied, all cables and cable guards are properly installed, all jam nuts are tight and replace all parts removed for access.

WARNING

Be sure ailerons move in correct direction when operated by the control wheels.

MODEL P210 SERIES SERVICE MANUAL

SECTION 7

WING FLAP CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
WING FLAP CONTROL SYSTEM	1K1/7-1	Removal/Installation	1K3/7-3
Description	1K1/7-1	Repair	1K7/7-7
Operational Check	1K1/7-1	Bellcranks	1K7/7-7
Trouble Shooting	1K2/7-2	Removal/Installation	1K7/7-7
Flap Motor/Transmission/		Repair	1K7/7-7
Actuator Assembly	1K3/7-3	Flaps	1K7/7-7
Removal/Installation	1K3/7-3	Removal/Installation	1K7/7-7
Repair	1K3/7-3	Repair	1K7/7-7
Flap Control Lever	1K3/7-3	Cables and Pulleys	1K7/7-7
Removal/Installation	1K3/7-3	Removal/Installation	1K7/7-7
Drive Pulleys	1K3/7-3	Rigging	1K7/7-7

7-1. WING FLAP CONTROL SYSTEM. (Refer to figure 7-1.)

7-2. DESCRIPTION. The wing flap control system consists of an electric motor and transmission assembly, drive pulleys, synchronizing push-pull tubes, bellcranks, push-pull rods, cables, pulleys and a follow-up control. Power from the motor and transmission assembly is transmitted to the flaps by a system of drive pulleys, cables and synchronizing tubes. Electrical power to the motor is controlled by two microswitches mounted on a "floating" arm, a control lever and a follow-up control. As the control lever is moved to the desired flap setting, a switch is tripped actuating the flap motor. As the flaps move, the floating arm is rotated by the follow-up control until the active switch clears the control lever cam, breaking the circuit. To reverse the direction of flap travel, the control lever is moved in the opposite direction. When the control lever cam contacts the second switch the flap motor is energized in the opposite direction. Likewise, the follow-up control moves the floating arm until the second switch is clear of the control lever cam.

7-3. OPERATIONAL CHECK.

- a. Operate flaps through their full range of travel, observing for uneven or jumpy motion, binding, and lost motion in the system. Ensure flaps are moving together through their full range of travel.
- b. Check for positive shut-off of motor at the flap travel extremes, **FLAP MOTOR MUST STOP OR DAMAGE WILL RESULT.**
- c. Check wing flaps for sluggishness in operation.
- d. With flaps full UP, mount an inclinometer on one flap and set to 0°. Lower flaps to full DOWN position and check flap angle as specified in figure 1-1. Check approximate mid-range percentage setting against degrees as indicated on inclinometer. Repeat the same procedure for the opposite flap.

NOTE

An inclinometer for measuring control surface travel is available from the Cessna Supply Division. Refer to Section 6.

- e. Remove access plates and attempt to rock drive pulleys and bellcranks to check for bearing wear.
- f. Inspect flap rollers and tracks for evidence of binding and defective parts.

MODEL P210 SERIES SERVICE MANUAL

7-4. TROUBLE SHOOTING.

NOTE

Due to remedy procedures in the following trouble shooting chart it may be necessary to re-rig system, refer to paragraph 7-21.

TROUBLE	PROBABLE CAUSE	REMEDY
BOTH FLAPS FAIL TO MOVE.	Popped circuit breaker.	Reset and check continuity. Replace breaker if defective.
	Defective switch.	Place jumper across switch. Replace switch if defective.
	Defective motor.	Remove and bench test. Replace motor if defective.
	Broken or disconnected wires.	Run continuity check of wiring. Connect or repair wiring as necessary.
	Disconnected or defective transmission.	Connect transmission. Remove, bench test and replace transmission if defective.
	Defective limit switch.	Check continuity of switches. Replace switches found defective.
	Follow-up control disconnected or slipping.	Secure control or replace if defective.
BINDING IN SYSTEM AS FLAPS ARE RAISED AND LOWERED.	Cables not riding on pulleys.	Open access plates and observe pulleys. Route cables correctly over pulleys.
	Bind in drive pulleys.	Check drive pulleys in motion. Replace drive pulleys found defective.
	Broken or binding pulleys.	Check pulleys for free rotation or breaks. Replace defective pulleys.
	Frayed cable.	Check condition of cables. Replace defective cables.
	Flaps binding on tracks.	Observe flap tracks and rollers. Replace defective parts.
LEFT FLAP FAILS TO MOVE.	Disconnected or broken cable.	Check cable tension. Connect or replace cable.
	Disconnected push-pull rod.	Attach push-pull rod.
FLAPS FAIL TO RETRACT.	Disconnected or defective UP operating switch.	Check continuity of switch. Connect or replace switch.

MODEL P210 SERIES SERVICE MANUAL

7-4. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
FLAPS FAIL TO EXTEND.	Disconnected or defective DOWN operating switch.	Check continuity of switch. Connect or replace switch.
INCORRECT FLAP TRAVEL.	Incorrect rigging.	Refer to paragraph 7-21.
	Defective limit switch.	Check continuity of switches. Replace switches found defective.

7-5. FLAP MOTOR, TRANSMISSION AND ACTUATOR ASSEMBLY. (Refer to figure 7-1, sheet 2.)

7-6. REMOVAL AND INSTALLATION.

- a. Run flaps to full DOWN position.
- b. Disconnect battery cables at the battery and insulate cable terminals as a safety precaution.
- c. Remove access plates from under actuator assembly on left wing and adjacent to the drive pulleys on both wings.
- d. Relieve cable tension at turnbuckles (indexes 6, 7, 8 and 9, sheet 1.)

NOTE

Remove motor (3), transmission (18), actuator assembly (17) and lower support as a unit.

- e. Disconnect cables from actuator cable drive assembly (17).
- f. Remove bolt (11) securing follow-up control bell-crank (10) to actuator assembly (17). Retain spacer (9).
- g. Disconnect flap motor and microswitch wiring and tag for reference on reinstallation.
- h. Remove bolts (12 and 20) securing lower support to upper support. Retain spacer (9), bushing (19) and washers.
- i. Remove bolt (21) securing motor and transmission assembly to upper support (7).

NOTE

Although not required, nuts (2) securing motor (3) to transmission (18) may be removed to swing motor clear of working area for easier removal of bolt (21).

- j. Using care, work assembly out of wing through access opening.
- k. Reverse the preceding steps for reinstallation. Rig system in accordance with paragraph 7-21, safety turnbuckles and reinstall all items removed for access.

7-7. REPAIR. Repair consists of replacement of motor, transmission or coupling. Lubricate in accordance with Section 2.

7-8. FLAP CONTROL LEVER. (Refer to figure 7-1, sheet 3.)

7-9. REMOVAL AND INSTALLATION.

- a. Remove follow-up control (8) from switch mounting arm (30).
- b. Remove flap operating switches (28 and 29) from switch mounting arm (30). DO NOT disconnect electrical wiring at switches.
- c. Remove knob (27) from control lever (26).
- d. Remove remaining items by removing bolt (32). Use care not to drop parts into tunnel area.
- e. Reverse the preceding steps for reinstallation. Do not overtighten bolt (32) causing lever (26) to bind. Rig system in accordance with paragraph 7-21.

7-10. DRIVE PULLEYS. (Refer to figure 7-1, sheet 1.)

7-11. REMOVAL AND INSTALLATION.

- a. Run flaps to full DOWN position.
- b. Remove access plates adjacent to drive pulley (11).
- c. Relieve cable tension at turnbuckles (7 and 8) for removal of left hand drive pulley and relieve cable tension at turnbuckles (6 and 9) for removal of right hand drive pulley.
- d. Remove bolt securing flap push-pull rod (17) to drive pulley.
- e. Remove bolt securing synchronizing push-pull tube (13) to drive pulley.
- f. Remove cable guards (14).
- g. Remove cable lock pins (16) and disconnect cables (10 and 18) from drive pulley. Tag cables for reference on reinstallation.
- h. Remove pivot bolt (15) attaching drive pulley to wing structure.
- i. Remove drive pulley (11) through access opening, using care not to drop bushing (12). Retain brass washer between drive pulley and wing structure. Tape open ends of pulley to protect bearings.
- j. Reverse the preceding steps for reinstallation. Rig system in accordance with paragraph 7-21, safety turnbuckles and reinstall all items removed for access.

MODEL P210 SERIES SERVICE MANUAL

NOTE
Brass washer may be used between drive pulley and wing structure.




Figure 7-1. Wing Flap Control System (Sheet 1 of 3)

MODEL P210 SERIES SERVICE MANUAL




Figure 7-1. Wing Flap Control System (Sheet 2 of 3)

MODEL P210 SERIES SERVICE MANUAL

7-12. REPAIR. Repair is limited to replacement of bearings. Cracked, bent or excessively worn drive pulleys must be replaced. Lubricate drive pulley bearings as outlined in Section 2.

7-13. BELLCRANKS. (Refer to figure 7-1, sheet 1.)

7-14. REMOVAL AND INSTALLATION.

- a. Run flaps to full DOWN position.
- b. Remove access plates adjacent to bellcrank (21).
- c. Remove bolt (24) securing push-pull rod (23) to bellcrank (21).
- d. Remove bellcrank pivot bolt (19) and position bellcrank as necessary to expose synchronizing push-pull tube attach point.
- e. Remove bolt (22) securing synchronizing push-pull tube (13) to bellcrank (21) and work bellcrank out through access opening using care not to drop bushing (20). Tape open ends of bellcrank to protect needle bearings.

NOTE

To remove synchronizing push-pull tube (13), disconnect tube at bellcrank (21) and drive pulley (11). Position tube through lightening holes until removal is possible through access opening.

f. Reverse the preceding steps for reinstallation. If the push-pull rod and synchronizing tube adjustments are not disturbed, re-rigging of the system should not be necessary. Check flap travel and rig in accordance with paragraph 7-21, if necessary, and reinstall all items removed for access.

7-15. REPAIR. Repair is limited to replacement of bearings. Cracked, bent or excessively worn bellcranks must be replaced. Lubricate in accordance with Section 2.

7-16. FLAPS. (Refer to figure 7-2.)

7-17. REMOVAL AND INSTALLATION.

- a. Run flaps to full DOWN position.
- b. Remove access plate (7) outboard of the inboard flap track.
- c. Disconnect push-pull rod (3) at both flap attach points.
- d. Remove bolt (6) at each aft flap track, pull flap aft and remove remaining bolts. As flap is removed from wing, all washers, rollers and bushings will fall free. Retain these for reinstallation.
- f. If the push-pull rod adjustment is not disturbed, re-rigging of the system should not be necessary. Check flap travel and rig in accordance with paragraph 7-21, if necessary.

7-18. REPAIR. Flap repair may be accomplished in accordance with instructions outlined in Section 18.

7-19. CABLES AND PULLEYS. (Refer to figure 7-1, sheet 1.)

7-20. REMOVAL AND INSTALLATION.

- a. Remove access plates, fairings and upholstery as required for access.
- b. Relieve cable tension at turnbuckles (6, 7, 8 and 9).
- c. Disconnect cables at drive pulleys (11).
- d. Disconnect cables at actuator cable drive assembly (index 17, sheet 2).
- e. Remove cable guards, pulleys and pressure seals as necessary to work cables free of aircraft.

NOTE

To ease routing of cables, a length of wire may be attached to the end of cable being withdrawn from the aircraft. Leave wire in place, routed through structure; then attach the cable being installed and use wire to pull cable into position.

- f. After cable is routed in position, install pulleys and cable guards. Ensure cable is positioned in pulley grooves before installing guards.
- g. Re-rig flap system in accordance with paragraph 7-21, safety turnbuckles and reinstall all items removed in step "a."

7-21. RIGGING.


- a. (Refer to figure 7-1, sheet 1.) Using care, run flaps to full DOWN position.
- b. Disconnect cables at turnbuckles (6, 7, 8 and 9).
- c. Disconnect push-pull rods (17) at drive pulleys (11).
- d. Disconnect push-pull rods (23) at bellcranks (21).
- e. Disconnect synchronizing push-pull tubes (13) from drive pulleys (11) and bellcranks (21).
- f. If cables are being replaced with drive pulleys (11) installed, rotate drive pulleys beyond their normal range of travel to permit cable attachment. If drive pulleys are not installed, it may be easier to attach the cables prior to installing the drive pulleys in the wings.
- f. Attach the 1/8" direct cable to the forward side of the drive pulleys and the 3/32" retract cable to the aft side of drive pulleys. (Refer to figure 7-3.)
- h. Adjust synchronizing push-pull tubes (13) to 41.87" between centers of rod end holes, tighten jam nuts and install.
- i. Adjust inboard push-pull rods (17) to 10.81" and outboard push-pull rods (23) to 10.39" between centers of rod end holes, tighten jam nuts and install. These dimensions may vary in order to obtain snug fitting of flap in "UP" position.
- j. Ensure cables are properly routed and in pulley grooves and adjust turnbuckles to obtain specified cable tension.
- k. (Refer to figure 7-1, sheet 2.)

NOTE

The ball screw assembly does not have a free-wheeling feature. Therefore, the flap actuator motor MUST be shut-off at travel extremes or structural deformation will occur.




Carefully run flaps to full UP position and adjust

MODEL P210 SERIES SERVICE MANUAL



NOTE

Bushings (5), rollers (4) and spacers (8) are first positioned through the slots in the flap tracks, then secured to the flap roller supports with attaching bolts (6). Nylon rub buttons (2) prevent flap from chafing wing trailing edge.



- 1. Flap Assembly
- 2. Nylon Rub Button
- 3. Push-Pull Rod
- 4. Roller
- 5. Bushing

- 6. Bolt
- 7. Access Plate
- 8. Spacer
- 9. Flap Track

Figure 7-2. Flap Installation

MODEL P210 SERIES SERVICE MANUAL




Figure 7-3. Flap System Schematic

UP-LIMIT switch to operate and shut-off motor at degree of travel specified in figure 1-1.

1. Mount an inclinometer on one flap and set to 0°.

NOTE

An inclinometer for measuring control surface travel is available from the Cessna Supply Division. Refer to Section 6.

m. Carefully run flaps to DOWN position and adjust DOWN-LIMIT switch (16) to operate and shut-off motor to .12±.03 inches between cable drive assembly (17) and transmission (18) as illustrated in VIEW A-A.

n. Operate control lever (26) and run flaps to full UP position.

o. Disconnect follow-up control (8) at switch mounting arm (30).

p. Without moving control lever (26), move arm (30) until cam (25) is centered between switches (28 and 29). Ensure switches are centered in their respective adjustment slots prior to centering cam (25).

q. Adjust flaps DOWN operating switch (28) in slotted holes until roller just clears cam (25) and secure. This adjustment should provide flaps down operation to 10°+0° -2° and 20°+1° -2°. If not readjust switch (28) as necessary.

NOTE

The flaps must NEVER exceed 10° when the

control lever (26) is moved from the 0° to 10° position.

r. Adjust flaps UP operating switch (29) in slotted holes to 0.062" clearance between switch roller and cam (25) when the DOWN operating switch has just opened in the 10° and 20° position.

NOTE

Flap travel on UP cycle may deviate a maximum of 4° from indicated position.

s. Turn master switch ON and run flaps through several cycles, stopping at various mid-range settings, and checking that cable tension is within limits. Retract cable tension may increase to 90 pounds when flaps are fully retracted.

NOTE

Since flap rollers may not bottom in tracks with flaps fully extended, some free play may be noticed in this position.

t. Check all rod ends and clevis ends for sufficient thread engagement, all jam nuts are tight and reinstall all items removed for access.

u. Flight test aircraft and check that follow-up control does not cause automatic cycling of flaps. If cycling occurs, readjust operating switches as necessary per steps "q" and "r".

MODEL P210 SERIES SERVICE MANUAL

SECTION 8

ELEVATOR CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
ELEVATOR CONTROL SYSTEM	1K15/8-1	Bellcrank	1K20/8-6
Description	1K15/8-1	Removal/Installation	1K20/8-6
Trouble Shooting	1K15/8-1	Arm Assembly	1K20/8-6
Control Column	1K16/8-2	Removal/Installation	1K20/8-6
Elevators	1K16/8-2	Cables and Pulleys	1K20/8-6
Removal/Installation	1K16/8-2	Removal/Installation	1K20/8-6
Repair	1K16/8-2	Rigging	1K21/8-7

8-1. ELEVATOR CONTROL SYSTEM. (Refer to figure 8-1.)

8-2. DESCRIPTION. The elevators are operated by power transmitted through fore-and-aft movement of the pilot or copilot control wheels. The system is comprised of control columns, an elevator torque

tube, cables and pulleys. The elevator control cables, at their aft ends, are attached to a bellcrank mounted on a bulkhead in the tailcone. A push-pull tube connects this bellcrank to the elevator arm assembly, installed between the elevators. An elevator trim tab is installed in the trailing edge of the right elevator and is described in Section 9.

8-3. TROUBLE SHOOTING.

NOTE

Due to remedy procedures in the following trouble shooting chart it may be necessary to re-rig system, refer to paragraph 8-14.

TROUBLE	PROBABLE CAUSE	REMEDY
NO RESPONSE TO CONTROL WHEEL FORE-AND-AFT MOVEMENT.	Forward or aft end of push-pull tube disconnected.	Check visually. Attach push-pull tube correctly.
	Cables disconnected.	Check visually. Attach cables and rig system in accordance with paragraph 8-14.

MODEL P210 SERIES SERVICE MANUAL

8-3. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
BINDING OR JUMPY MOTION FELT IN MOVEMENT OF ELEVATOR SYSTEM.	Defective bellcrank or arm assembly pivot bearings or push-pull tube attach bearings.	Move bellcrank or arm to check for play or binding. Disconnect push-pull tube and check that bearings rotate freely. Replace defective parts.
	Cables slack.	Check and adjust to tension specified in figure 8-1.
	Cables not riding correctly on pulleys.	Check visually. Route cables correctly over pulleys.
	Defective control column bearing rollers.	Check visually. Replace defective rollers.
	Defective control column torque tube bearings.	Disconnect necessary items and check that bearings rotate freely. Replace defective bearing.
	Control guide on aft end of control square tube adjusted too tightly.	Loosen screw and tapered plug in end of control tube enough to eliminate binding.
	Defective elevator hinges.	Disconnect push-pull tube and move elevators by hand. Replace defective hinges.
	Defective pulleys or cable guards.	Check visually. Replace defective parts and install guards properly.
ELEVATORS FAIL TO ATTAIN PRESCRIBED TRAVEL.	Stops incorrectly set.	Rig in accordance with paragraph 8-14.
	Cables tightened unevenly.	Rig in accordance with paragraph 8-14.
	Interference at instrument panel.	Rig in accordance with paragraph 8-14.

NOTE

8-4. CONTROL COLUMN.

Section 6 outlines removal, installation and repair of control column.

8-5. ELEVATORS. (Refer to figure 8-2.)

8-6. REMOVAL AND INSTALLATION.

- Remove stinger.
- Disconnect trim tab push-pull tube at tab actuator. (Refer to Section 9.)

NOTE

If trim system is not moved and actuator screw is not turned, re-rigging of trim system should not be necessary after reinstallation of elevator.

- Remove bolts (13) securing elevator torque tubes (7) to arm assembly (8).

If adhesive has been applied to bolt shanks prior to installation, use a heat gun to soften the epoxy before removing bolts.

- Remove bolts (6) from elevator hinges (5).
- Using care, remove elevator.
- To remove left elevator use same procedure, omitting step "b".
- Reverse the preceding steps for reinstallation.
- Set right hand elevator maintaining 0.18" dimension specified in figure 8-2.
- When reinstalling bolts (13) install a washer under the head of each bolt and under each nut.

8-7. REPAIR. Repair may be accomplished as outlined in Section 18. Hinge bearings may be replaced as necessary. If repair has affected static balance, check and rebalance as required.

MODEL P210 SERIES SERVICE MANUAL




Figure 8-1. Elevator Control System

MODEL P210 SERIES SERVICE MANUAL




Figure 8-2. Elevator installation

MODEL P210 SERIES SERVICE MANUAL




Figure 8-3. Elevator Bellcrank Installation




Figure 8-4. Elevator Bellcrank Travel Stop Adjustment

MODEL P210 SERIES SERVICE MANUAL




Figure 8-5. Control Column Neutral Position Rigging Tool

8-8. BELLCRANK. (Refer to figure 8-3.)

8-9. REMOVAL AND INSTALLATION.

- a. Remove access plate below bellcrank on tailcone.

CAUTION

Position a support stand under tail tie-down ring to prevent the tailcone from dropping while working inside.

- b. Remove safety wire, relieve cable tension at turnbuckles (10) and disconnect turnbuckle eyes at bellcrank links (9).
- c. Remove bolt (5) securing push-pull tube (4) to bellcrank (8).
- d. Remove pivot bolt (3) attaching bellcrank (8) to brackets (2) and remove bellcrank.
- e. Reverse the preceding steps for reinstallation. Rig system in accordance with paragraph 8-14, safety turnbuckles and reinstall all items removed for access.

8-10. ARM ASSEMBLY. (Refer to figure 8-2.)

8-11. REMOVAL AND INSTALLATION.

- a. Remove stinger.
- b. Remove bolt (10) securing push-pull tube (11) to arm assembly (8).
- c. Remove bolts (13) securing elevator torque tubes (7) to arm assembly (8). A heat gun may be required to soften epoxy adhesive on bolt (13).

- d. Remove pivot bolt (12) securing arm assembly (8) and slide assembly from between elevator torque tubes.

- e. Reverse the preceding steps for reinstallation and reinstall all items removed for access.

- f. Set right hand elevator maintaining 0.18" dimension specified in figure 8-2.

- g. When reinstalling bolts (13) install a washer under the head of each bolt and under each nut. Apply Adhesive EA-9309 from Hysol Division, Dexter Corp., or its equivalent, only to the shanks of bolts (13). Wipe off excess adhesive after installation.

8-12. CABLES AND PULLEYS. (Refer to figure 8-1.)

8-13. REMOVAL AND INSTALLATION.

CAUTION

Position a support stand under tail tie-down ring to prevent the tailcone from dropping while working inside.

- a. Remove seats, upholstery and access plates as necessary.
- b. Remove safety wire and relieve cable tension at turnbuckles (9).
- c. Disconnect cables at control column arm assemblies (3).
- d. Disconnect cables at bellcrank links (index 16, figure 8-3).
- e. Remove fairleads, cable guards, pulleys and pressure seals as required to work cables from aircraft.

MODEL P210 SERIES SERVICE MANUAL

NOTE

To ease routing of cables, a length of wire may be attached to the end of cable being withdrawn from aircraft. Leave wire in place, routed through structure; then attach the cable being installed and pull cable into position.

- f. Reverse the preceding steps for reinstallation.
- g. After cables are routed in position, install fairleads, pulleys and cable guards. Ensure cables are positioned in pulley grooves before installing guards.
- h. Re-rig system in accordance with paragraph 8-14, safety turnbuckles and reinstall all items removed in step "a".

8-14. RIGGING. (Refer to figure 8-3.)

CAUTION

Position a support stand under tail tie-down ring to prevent the tailcone from dropping while working inside.

- a. Lock control column in neutral position. (Refer to figure 8-5.)
- b. Adjust turnbuckles (10) equally to streamline LEFT elevator with horizontal stabilizer (RIGHT elevator will be higher than the left as illustrated in figure 8-2) and to obtain 30 ± 10 lbs cable tension. Safety turnbuckles.

NOTE

Disregard counterweight areas of elevators when streamlining.

- c. With LEFT elevator streamlined, mount an inclinometer on elevator and set to 0° .

NOTE

An inclinometer for measuring control surface travel is available from the Cessna Supply Division.

- d. Adjust bellcrank travel stop blocks to obtain degree of elevator travel as specified in figure 1-1.

NOTE

The bellcrank stop blocks (8) are four-sided bushings, drilled off-center so they may be rotated to any one of four positions to attain correct elevator travel. Each 90-degree rotation of the stop, changes the elevator travel approximately one degree.

- e. Move control wheel through full range of travel and check cable tension in various positions. Tension should not be less than 20 pounds or more than 40 pounds in any position.
- f. Check all turnbuckles are safetied and all parts are secured, then reinstall all parts removed for access.

WARNING

Be sure elevators move in the correct direction when operated by the control wheels.

MODEL P210 SERIES SERVICE MANUAL

SECTION 9

ELEVATOR TRIM TAB CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual
-------------------	------------------------------

ELEVATOR TRIM TAB CONTROL SYSTEM	1L3/9-1	Pedestal Cover	1L9/9-7
Description	1L3/9-1	Removal/Installation	1L9/9-7
Trouble Shooting	1L3/9-1	Trim Tab Free-Play Inspection	1L9/9-7
Trim Tab	1L4/9-2	Rigging-Manual Trim	1L10/9-8
Removal/Installation	1L4/9-2	Electric Trim Assist Installation	1L11/9-9
Trim Tab Actuator	1L4/9-2	Description	1L11/9-9
Removal/Installation	1L4/9-2	Trouble Shooting	1L11/9-9
Trim Tab Control Wheel	1L4/9-2	Removal/Installation	1L13/9-11
Removal/Installation	1L4/9-2	Clutch Adjustment	1L13/9-11
Cables and Pulleys	1L6/9-4	Trim Tab Simulated Air Load	
Removal/Installation	1L6/9-4	Test	1L13/9-11
		Rigging-Electric Trim Assist	1L13/9-11

9-1. ELEVATOR TRIM TAB CONTROL SYSTEM.
(Refer to figure 9-1.)

9-2. DESCRIPTION. The elevator trim tab, located on the trailing edge of the right elevator, is controlled by a trim wheel mounted in the pedestal. Power to operate the tab is transmitted from the trim control wheel by means of roller chains, cables, an actuator and a push-pull tube. A mechanical pointer,

adjacent to the trim wheel indicates nose attitude of the aircraft. Forward rotation of the wheel trims the nose down and aft rotation of the wheel trims the nose up. An electric trim assist may be installed and is described in paragraph 9-17. When de-energized the electric trim assist has no effect on manual operation.

9-3. TROUBLE SHOOTING.

NOTE

Due to remedy procedures in the following trouble shooting chart it may be necessary to re-rig system, refer to appropriate rigging paragraphs.

TROUBLE	PROBABLE CAUSE	REMEDY
TRIM CONTROL WHEEL MOVES WITH EXCESSIVE RESISTANCE.	Cable tension too high.	Check cable tension and adjust.
	Pulleys binding or rubbing.	Check pulleys visually. Repair or replace as necessary.
	Cables not in place on pulleys.	Check visually. Install cables correctly.
	Trim tab hinge binding.	Disconnect actuator and move tab up and down to check hinge resistance. Lubricate or replace hinge as necessary.
	Defective trim tab actuator.	Remove chain from actuator sprocket and operate actuator manually. Replace defective actuator.
	Rusty chain.	Check visually. Replace rusty chain.

MODEL P210 SERIES SERVICE MANUAL

9-3. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
TRIM CONTROL WHEEL MOVES WITH EXCESSIVE RESISTANCE (CONT).	Damaged sprocket.	Check visually. Replace damaged sprockets.
	Bent sprocket shaft.	Observe motion of sprockets. Replace defective shafts.
LOST MOTION BETWEEN CONTROL WHEEL AND TRIM TAB.	Cable tension too low.	Check cable tension and adjust.
	Broken pulley.	Check visually. Replace defective pulley.
	Cables not in place on pulleys.	Check visually. Install cables correctly.
	Worn trim tab actuator.	Disconnect trim tab and check for play in actuator. Replace defective actuator.
	Actuator attachment loose.	Check actuator for security and tighten.
TRIM INDICATION INCORRECT.	Indicator incorrectly engaged on wheel track.	Check visually. Reset indicator.
INCORRECT TRIM TAB TRAVEL.	Stop blocks loose or incorrectly adjusted.	Adjust stop blocks on cables. Refer to figure 9-5.
	Incorrect rigging.	Refer to paragraph 9-15.

9-4. TRIM TAB. (Refer to figure 9-2.)

9-5. REMOVAL AND INSTALLATION.

a. Disconnect push-pull tube (9) from horn assembly (6).

NOTE

If trim system is not moved and actuator screw is not turned, re-rigging of system should not be necessary after reinstallation of tab.

b. Remove screw (11) securing hinge pin (10), pull pin until free of tab and remove tab.

NOTE

It is not necessary to completely remove hinge pin.

c. Reverse the preceding steps for reinstallation. Rig system, if necessary, in accordance with paragraph 9-15.

9-6. TRIM TAB ACTUATOR. (Refer to figure 9-1.)

9-7. REMOVAL AND INSTALLATION.

- Relieve cable tension at turnbuckle (8).
- Disconnect push-pull tube (24) at actuator (21).
- Remove access plate beneath actuator.
- Remove chain guard (19) and disengage roller chain (16) from actuator sprocket (17).
- Remove screws attaching bracket (20) to bracket (22) and remove actuator (21) through access opening.
- Reverse the preceding steps for reinstallation. Rig system in accordance with paragraph 9-15, safety turnbuckle and reinstall all items removed for access.

9-8. TRIM TAB CONTROL WHEEL. (Refer to figure 9-4.)

- Remove pedestal cover as outlined in paragraph 9-14.
- Remove screws (16) securing chain guard (9) to pedestal structure.
- Remove bolts (1), washers (2), spacer (4) and indicator (3).
- Loosen bolts (17) securing idler sprockets (6), slide sprockets together to relieve cable tension on roller chain (10).
- Remove safety wire, relieve cable tension turnbuckle (8) (Sheet 1 of 5).
- Remove bolt (18) and disengage roller chain (10) from trim wheel (5), remove trim wheel.

MODEL P210 SERIES SERVICE MANUAL




Figure 9-1. Elevator Trim Tab Control System (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 9-1. Elevator Trim Tab Control System (Sheet 2 of 2)

7. Remove bolts (17), washers (8), idler sprockets (6) and bushings (7).
8. Remove bolt (15), disengage roller chains (13) and (10) from drive sprocket (11).
9. Remove drive sprocket (11), bushing (14) and chain guard (9).
10. Reverse this procedure for reinstallation and rig system in accordance with paragraph 9-15.

9-10. CABLES AND PULLEYS.

9-11. REMOVAL AND INSTALLATION.

a. FORWARD CABLE. (Refer to figure 9-1.)

1. Peel back carpeting as necessary to expose access plates in cabin and baggage areas and remove plates.
2. Remove safety wire, relieve cable tension and disconnect turnbuckle (8).
3. Disconnect cable ends (10).
4. (Refer to figure 9-4.) Remove pedestal cover as outlined in paragraph 9-14.
5. Disengage roller chain (3) from drive sprocket (11).
6. Remove cable guards, pulleys and pressure seals as required to remove cables from aircraft.

NOTE

To ease routing of cable, a length of wire may be attached to the end of cable before being withdrawn from aircraft. Leave

wire in place, routed through structure; then attach the cable being installed and pull cable into position.

7. Reverse the preceding steps for reinstallation.
8. After cable is routed in position, install pulleys and cable guards. Ensure cable is positioned in pulley grooves before installing guards. Ensure roller chain (21) is positioned correctly over drive sprocket (18).
9. Re-rig system in accordance with paragraph 9-15, safety turnbuckle (index 8, figure 9-1) and re-install all items removed for access.
- b. AFT CABLE. (Refer to figure 9-1.)
 1. Peel back carpeting as necessary to expose access plates in baggage area and remove plates.
 2. Remove rear baggage compartment wall.
 3. Remove safety wire, relieve cable tension and disconnect turnbuckle (8).

CAUTION

Position a support stand under tail tie-down ring to prevent tailcone from dropping while working inside.

4. Disconnect cable ends (10).
5. Remove travel stop blocks (13).
6. Disconnect electric trim clamps and keepers (indexes 15 and 16, figure 9-6), if installed.
7. Remove access plate beneath trim tab actuator (21) and remove chain guard (19).

MODEL P210 SERIES SERVICE MANUAL




Figure 9-2. Elevator Trim Tab Installation





Figure 9-3. Elevator Trim Tab Actuator Assembly


MODEL P210 SERIES SERVICE MANUAL



- | | |
|-----------------------|------------------------|
| 1. Bolt | 10. Roller Chain |
| 2. Washer | 11. Drive Sprocket |
| 3. Position Indicator | 12. Pedestal Structure |
| 4. Spacer | 13. Roller Chain |
| 5. Trim Wheel | 14. Bushing |
| 6. Idler Sprocket | 15. Bolt |
| 7. Bushing | 16. Screw |
| 8. Washers | 17. Bolts |
| 9. Chain Guard | 18. Bolt |

Figure 9-4. Elevator Trim Wheel Installation

MODEL P210 SERIES SERVICE MANUAL



1. With elevators in neutral, set trim tab to neutral (split the non-faired difference between the inboard and outboard ends.
2. Place inclinometer on trim tab, adjust inclinometer to 0° and lower tab to degree of travel specified in figure 1-1.
3. Position stop block (3) on cable B, maintain 0.125 " between stop block (3) and pulleys (4) when elevator tab is in full down position and secure stop block (3) to cable B.
4. Raise trim tab to specified degree, place stop block (2) against stop block (3) and secure to cable A.
5. Place trim tab in full down position maintaining 0.125 " between stop block (3) and pulleys (4), place stop block (1) against stop block (2) and secure to cable B. (Recheck travel.)

Figure 9-5. Elevator Trim Tab Travel Stop Adjustment

8. Disengage roller chain (16) from actuator sprocket (17).
9. Remove cable guards and pulleys as necessary to work cable free of aircraft.

NOTE

To ease routing of cable, a length of wire may be attached to the end of cable before being withdrawn from aircraft. Leave wire in place, routed through structure; then attach the cable being installed and pull cable into position.

10. Reverse the preceding steps for reinstallation.
11. After cable is routed in position, install pulleys and cable guards. Ensure cable is positioned in pulley grooves before installing guards. Ensure roller chain (16) is positioned correctly over actuator sprocket (17).
12. Re-rig system in accordance with paragraph 9-15, safety turnbuckle (8) and reinstall all items removed for access.

9-12. PEDESTAL COVER.

9-13. REMOVAL AND INSTALLATION.

- a. Turn fuel selector valve to OFF position and drain fuel from strainer and lines.
- b. Remove knurled nut from engine primer if installed and pull plunger from primer body. Protect primer from dirt.

- c. Remove fuel selector handle and placard.
- d. Remove cowl flap handle and knob.
- e. Remove microphone mounting bracket.
- f. Fold carpet back as necessary and remove screws securing cover to floor and pedestal.
- g. Disconnect electrical wiring to pedestal lights.
- h. Carefully work cover from pedestal to prevent damage.
- i. Reverse the preceding steps for reinstallation.

9-14. TRIM TAB FREE-PLAY INSPECTION. (Refer to figure 9-16.)

- a. Place elevators and trim tab in neutral position and secure from movement.
- b. Determine maximum allowable free-play using the following instructions.
 1. Measure chord length of extreme inboard end of the trim tab as shown in detail A, figure 9-6.
 2. Multiply chord length by 0.025 to obtain maximum allowable free-play.
- c. Using moderate pressure, move the trim tab trailing edge up and down by hand to check free-play.

NOTE

Measure free-play at the same point on trim tab that chord length was measured. Total free-play must not exceed maximum allowable. Refer to detail B, Figure 9-6.

- d. If the trim tab free-play is less than the maximum allowable the system is within the prescribed limits.

MODEL P210 SERIES SERVICE MANUAL

e. If the trim tab free-play is more than the maximum allowable, check the following items, for looseness while moving the trim tab up and down.

1. Check push-pull tube to trim tab horn assembly attachment for looseness.
2. Check push-pull tube to actuator assembly threaded rod end attachment for looseness.
3. Check actuator assembly threaded rod end for looseness in actuator assembly with push-pull tube disconnected.

f. If looseness is apparent while checking steps e-1 and e-2, repair by installing new parts.

g. If looseness is apparent while checking step e-3, refer to paragraphs 6-6 thru 9-7. Recheck trim tab free-play.

9-15. RIGGING MANUAL TRIM. (Refer to figure 9-1.)

CAUTION

Position a support stand under tail tie-down ring to prevent tailcone from dropping while working inside.

- a. Remove rear baggage compartment wall and access plates as necessary.
- b. Loosen travel stop blocks (13) on trim tab cables (7 and 12).

- c. Disconnect push-pull tube (24) from actuator (21).
- d. Check cable tension for 20+0. -5 pounds and readjust turnbuckle (8) if necessary.

NOTE

If roller chains and/or cables are being installed, permit actuator screw to rotate freely as roller chains and cables are connected. Adjust cable tension and safety turnbuckle (8).

e. (Refer to figure 9-4.) Rotate trim control wheel (7) full forward (nose down). Ensure pointer (3) does not restrict wheel movement. If necessary to reposition pointer, proceed as follows:

1. Remove pedestal cover as outlined in paragraph 9-14.
2. Loosen nut (9) at trim wheel pivot stud (8).
3. Loosen screws (13) securing chain guard (10) far enough that trim wheel (7) can be moved approximately 1/8 inch, then reposition pointer (3) using a thin screwdriver to pry trailing leg of pointer out of groove in trim wheel. Reposition pointer as required.
4. Tighten nut (9) and screws (13) but do not reinstall pedestal cover until rigging is complete.




Figure 9-6. Trim Tab Free-Play Inspection

MODEL P210 SERIES SERVICE MANUAL

NOTE

Full forward (nose down) position of trim wheel is where further movement is prevented by the roller chain or cable ends contacting sprockets or pulleys.

f. With elevator and trim tab both in neutral (split the non-faired difference between the inboard and outboard ends), mount an inclinometer on trim tab and set to 0°. Disregard counterweight areas of elevators when streamlining. These areas are contoured so they will be approximately 3° down when the elevators are streamlined.

NOTE

An inclinometer for measuring control surface travel is available from the Cessna Supply Division. Refer to Section 6.

g. Rotate actuator screw in or out as required to place trim tab up with a maximum of 2° overtravel, with actuator screw connected to push-pull tube (index 24, figure 9-1).

h. Rotate trim wheel to position trim tab up and down, readjusting actuator screw as required to obtain overtravel in both directions.

i. Position stop blocks and adjust as illustrated in figure 9-5 to degree of trim tab travel specified in figure 1-1.

j. Install pedestal cover and adjust trim tab pointer (3) as follows:

1. Rotate trim control wheel (7) top place tab at 10° up position.

2. Locate the pointer (3) at the TAKE-OFF triangle as viewed from the pilot seat. (Refer to step "e." and reposition pointer if necessary).

3. Bend pointer (3) as required to clear pedestal cover. (Pointer must NOT rub against pedestal cover or clear cover more than .125 inch maximum).

k. Safety turnbuckle and reinstall all items removed in step "a".

WARNING

Be sure trim tab moves in correct direction when operated by trim control wheel. Nose down trim corresponds to tab up position.

9-16. ELECTRIC TRIM ASSIST INSTALLATION. (Refer to figure 9-7.)



9-17. DESCRIPTION. The electric elevator trim assist installation consists of two switches mounted on the pilot's control column, a circuit breaker mounted on the left side panel, wiring running aft to the electric drive assembly and a chain connecting the drive assembly to an additional sprocket mounted on the standard manual elevator trim actuator. When the clutch (16) is not energized, the drive assembly "free wheels" and has no effect on manual trim operation.

9-18. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
SYSTEM INOPERATIVE.	Circuit breaker open.	Check visually. Reset breaker.
	Defective circuit breaker.	Check continuity. Replace defective breaker.
	Defective wiring.	Check continuity. Repair wiring.
	Defective trim switch.	Check continuity. Replace defective switch.
	Defective trim motor.	Remove and bench test. Replace defective motor.
TRIM MOTOR OPERATING - TRIM TAB FAILS TO MOVE.	Defective clutch solenoid.	Check continuity. Replace solenoid.
	Improperly adjusted clutch tension.	Check and adjust spanner nuts for proper tension.
	Disconnected or broken cable.	Operate manual trim wheel. Connect or replace cable.
	Defective actuator.	Check actuator operation. Replace actuator.

MODEL P210 SERIES SERVICE MANUAL

1. Chain
2. Turnbuckle
3. Actuator Assembly
4. Cover
5. Relay
6. Connector
7. Cover
8. Connector
9. Drive Assembly



Detail A

Figure 9-7. Electric Elevator Trim Assist Installation

MODEL P210 SERIES SERVICE MANUAL

9-19. REMOVAL AND INSTALLATION. (Refer to figure 9-6.)

- a. Remove cover (7) below drive assembly (9).
- b. Disconnect wiring at connectors (8).
- c. Remove sprocket guard (Index 5, figure 9-3) from trim tab actuator (3).
- d. Remove mounting bolts from drive assembly and tab actuator and remove from aircraft.
- e. Reverse preceding steps for reinstallation. Check system rigging in accordance with paragraph 9-23.

9-20. CLUTCH ADJUSTMENT. The actuator clutch torque setting is 20 ±4 in. lbs. tension setting for the elevator. For step-by-step procedures, refer to the appropriate Autopilot Service/Parts Manual.

9-21. TRIM TAB SIMULATED AIR LOAD TEST. (Refer to figure 9-8.)

NOTE

The manual elevator trim control system must be properly rigged, the aircraft electrical operating voltage must be normal, the electric trim assist clutch must be properly adjusted and the elevator must be in neutral position prior to completing the following steps.

- a. Attach two angles approximately 18 inches in length to the trailing edge of the trim tab with clamps as illustrated to prevent bending of tab trailing edge.
- b. Attach a cable directly aft of the trim tab horn assembly.
- c. Attach 14 pounds minimum to 22 pounds maximum of weight (including the angles, clamps and

cable) to the cable and operate the trim switch to place the tab in the UP position. The clutch MUST lift 15 pounds weight to the FULL UP position but must slip at 18 pounds.

NOTE

If the electric trim clutch slips prior to lifting the required weight to the full up position, DO NOT READJUST CLUTCH, refer to step "d" or step 5 to locate and remove the reason for excessive friction in the elevator trim control system.

- d. Check the trim tab hinge and linkage for binding, check the trim system cables and chains for proper tension, check system pulleys and actuator for binding.
- e. After the trim system has been thoroughly checked and excessive friction removed, repeat step "c".

9-22. RIGGING - ELECTRIC TRIM ASSIST. (Refer to figure 9-7.)

- a. The standard manual elevator trim control system MUST be rigged in accordance with paragraph 9-15 prior to rigging the electric trim assist.
- b. Move elevator trim tab to full "NOSE UP" position.
- c. Remove access covers (4 and 7) located in underside or right stabilizer.
- d. Locate turnbuckle (2) terminal point 1.80 inch from drive assembly housing and adjust until chain deflection between sprockets is approximately 0.25 inch.
- e. Resafety turnbuckle and reinstall all items removed for access.

MODEL P210 SERIES SERVICE MANUAL




Figure 9-8. Trim Tab Simulated Air Load Test

MODEL P210 SERIES SERVICE MANUAL

SECTION 10

RUDDER CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
RUDDER CONTROL SYSTEM	2A3/10-1	Removal/Installation	2A7/10-5
Description	2A3/10-1	Repair	2A7/10-5
Trouble Shooting	2A3/10-1	Cables and Pulleys	2A7/10-5
Rudder Pedal Assembly	2A7/10-5	Removal/Installation	2A7/10-5
Removal/Installation	2A7/10-5	Rigging	2A10/10-8
Rudder	2A7/10-5		

10-1. **RUDDER CONTROL SYSTEM.** (Refer to figure 10-1.)

prised of the rudder pedals installation, cables and pulleys, all of which link the pedals to the rudder and nose wheel steering.

10-2. **DESCRIPTION.** Rudder control is maintained through use of conventional rudder pedals which also control nose wheel steering. The system is com-

10-3. **TROUBLE SHOOTING.**

NOTE

Due to remedy procedures in the following trouble shooting chart it may be necessary to re-rig system, refer to paragraph 10-11.


TROUBLE	PROBABLE CAUSE	REMEDY
RUDDER DOES NOT RESPOND TO PEDAL MOVEMENT.	Broken or disconnected cables.	Open access plates and check visually. Connect or replace cables.

MODEL P210 SERIES SERVICE MANUAL

10-3. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
BINDING OR JUMPY MOVEMENT OF RUDDER PEDALS.	Cables too tight.	Refer to figure 10-1 for cable tension. Rig system in accordance with paragraph 10-11.
	Cables not riding properly on pulleys.	Open access plates and check visually. Route cables correctly over pulleys.
	Binding, broken or defective pulleys or cable guards.	Open access plates and check visually. Replace defective pulleys and install guards properly.
	Pedal bars need lubrication.	Refer to Section 2.
	Defective rudder bar bearings.	If lubrication fails to eliminate binding. Replace bearing blocks.
	Defective rudder hinge bushings.	Check visually. Replace defective bushings.
	Clevis bolts too tight.	Check and readjust bolts to eliminate binding.
LOST MOTION BETWEEN RUDDER PEDALS AND RUDDER.	Steering rods improperly adjusted.	Rig system in accordance with paragraph 10-11.
	Insufficient cable tension.	Refer to figure 10-1 for cable tension. Rig system in accordance with paragraph 10-11.
INCORRECT RUDDER TRAVEL.	Incorrect rigging.	Rig in accordance with paragraph 10-11.


MODEL P210 SERIES SERVICE MANUAL



- | | |
|------------------------|----------------------|
| 1. Right Rudder Bar | 9. Fairlead |
| 2. Left Rudder Bar | 10. Turnbuckle |
| 3. Right Forward Cable | 11. Right Rear Cable |
| 4. Left Forward Cable | 12. Left Rear Cable |
| 5. Cable Guard | 13. Stop Bolt |
| 6. Spacer | 14. Bellcrank |
| 7. Pulley | 15. Pressure Seal |
| 8. Clip | 16. Retainer |

Figure 10-1. Rudder Control System

MODEL P210 SERIES SERVICE MANUAL




- 1. Anti-Rattle Spring
- 2. Pedal
- 3. Shaft
- 4. Shaft
- 5. Spacer
- 6. Brake Link
- 7. Cable (Left Forward)
- 8. Cable (Right Forward)
- 9. Pedal Extension
- 10. Pin (Stowable Pedals Only)
- 11. Bearing Block
- 12. Right Rudder Cable Arm
- 13. Left Rudder Cable Arm
- 14. Aft Rudder Bar
- 15. Nosewheel Steering Arm
- 16. Rudder Trim Bungee Arm
- 17. Forward Rudder Bar
- 18. Master Cylinder
- 19. Brake Torque Tube
- 20. Bracket
- 21. Bearing
- 22. Bellcrank

CLEARANCE HOLE FORWARD

CLEARANCE HOLE AFT

Detail A

C



Detail C

*** NOTE**

At least one washer (23) must be installed at the location shown.

Figure 10-2. Rudder Pedal Installation

MODEL P210 SERIES SERVICE MANUAL




Figure 10-3. Nose Gear Steering Installation

10-4. RUDDER PEDAL ASSEMBLY.

10-5. REMOVAL AND INSTALLATION. (Refer to figure 10-2.)

- a. Remove carpeting, shields and soundproofing from the rudder pedal and tunnel areas as necessary for access.
- b. Disconnect brake master cylinders (18) and parking brake cables at pilot's rudder pedals.
- c. Remove rudder pedals (2) and brake links (6).
- d. Deleted.
- e. Remove fairing from either side of vertical fin, remove safety wire and relieve cable tension by loosening turnbuckles (index 19, figure 10-1).
- f. Disconnect cables (7 and 8) from rudder bar arms (12 and 13).
- g. Disconnect rudder trim bungee from rudder bar arm (16).
- h. (Refer to figure 10-3.) Disconnect whiffletree link rod assemblies (5) at rudder bar arms (9 and 10).
- i. (Refer to figure 10-2.) Remove bolts securing bearing blocks (11) and carefully work rudder bars out of tunnel area.

NOTE

The two inboard bearing blocks contain clearance holes for the rudder bars at one end and a bearing hole at the other. Tag these bearing blocks for reference on reinstallation.

- j. Reverse the preceding steps for reinstallation. Lubricate rudder bar assemblies as outlined in Section 2. Rig system in accordance with paragraph 10-11, safety turnbuckles and reinstall all items removed for access.

10-6. RUDDER. (Refer to figure 10-4.)

10-7. REMOVAL AND INSTALLATION.

- a. Remove stinger.
- b. Disconnect tail navigation light wire.
- c. Remove fairing from either side of vertical fin, remove turnbuckles (index 10, figure 10-1.)
- d. Disconnect cables (4 and 6) from rudder bellcrank (3).
- e. With rudder supported, remove all hinge bolts (2) and using care, lift rudder free of vertical fin.
- f. Reverse the preceding steps for reinstallation. Rig system in accordance with paragraph 10-11, safety turnbuckles and reinstall all items removed for access.

10-8. REPAIR. Repair may be accomplished as outlined in Section 18.

10-9. CABLES AND PULLEYS. (Refer to figure 10-1.)

10-10. REMOVAL AND INSTALLATION.

- a. Remove seats, upholstery and access plates as necessary.

MODEL P210 SERIES SERVICE MANUAL





Figure 10-4. Rudder Installation

MODEL P210 SERIES SERVICE MANUAL



1. Establish neutral position of rudder by clamping straightedge (such as wooden 2 × 4) on each side of fin and rudder and blocking trailing edge of rudder half the distance between straightedges as shown.
2. Tape a length of soft wire to the stinger in such a manner that it can be bent to index at the lower corner of the rudder trailing edge.
3. Using soft lead pencil, mark rudder at point corresponding to soft wire indexing point (neutral).
4. Remove straightedges and blocks.
5. Hold rudder against right, then left, rudder stop. Measure distance from pointer to pencil mark on rudder in each direction of travel. Distance should be between 8.12" and 8.72".

Figure 10-5. Checking Rudder Travel

MODEL P210 SERIES SERVICE MANUAL

- b. Remove safety wire, relieve cable tension and disconnect cables at turnbuckles (10).
- c. Disconnect cables (3 and 4) at rudder bar arms.
- d. Remove guards, pulleys, fairleads and pressure seals as required to work cables free of aircraft.

NOTE

To ease routing of cables, a length of wire may be attached to end of the cable before being withdrawn from aircraft. Leave wire in place, routed through structure; then attach cable being installed and pull the cable into position.

- e. Reverse the preceding steps for reinstallation.
- f. Reinstall guards, pulleys, fairleads and pressure seals; insure that cable is positioned in pulley grooves before installing cable guards.
- g. Re-rig system in accordance with paragraph 10-11, safety turnbuckles and reinstall all items removed in step "a".

10-11. RIGGING.

- a. Remove fairing from either side of vertical fin, remove safety wire and relieve cable tension at turnbuckles (index 10, figure 10-1).
- b. Open landing gear doors. (Refer to Section 5.)
- c. Tie down or weight tail to raise nosewheel free of ground.
- d. Extend strut and ensure nose gear is centered against the external centering lug. (Neutral position.)
- e. (Refer to figure 10-3.) Disconnect steering bungee adjustable rod end (3) from whiffletree (4).

- f. Remove pedestal cover in accordance with Section 9.
- g. Remove lower pedestal panel (index 14, figure 9-4).
- h. Disconnect rudder trim bungee from rudder bar arm (index 16, figure 10-2).
- i. Clamp rudder pedals in neutral position.
- j. Adjust turnbuckles (index 10, figure 10-1) to streamline rudder with 30 ± 10 lbs tension on cables.
- k. Remove clamps from rudder pedals.
 - 1. Adjust travel stop bolts (index 13, figure 10-1) to obtain degree of travel specified in figure 1-1. Figure 10-5 illustrates correct travel and one method of checking.
- m. Adjust length of rod end (3) to align with whiffletree (4) and install bolt. **DO NOT PRELOAD BUNGEE.**
- n. Connect rudder trim bungee and rig trim system as outlined in Section 11.
- o. Operate rudder system, checking for ease of movement and full travel. Check cable tension with rudder in various positions. Cable tension should not be less than 20 pounds or more than 40 pounds in any position.
- p. Check that all turnbuckles are safetied and re-install all items removed for access.
- q. Lower nosewheel to ground.

WARNING

Be sure rudder moves in the correct direction when operated by the rudder pedals.

MODEL P210 SERIES SERVICE MANUAL

SECTION 11

RUDDER TRIM CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
RUDDER TRIM CONTROL SYSTEM	2A15/11-1	Wheel/Gear Box Assembly	2A17/11-3
Description	2A15/11-1	Chain Assembly	2A17/11-3
Trouble Shooting	2A15/11-1	Gimbal Assembly	2A17/11-3
Removal/Installation of System		Bungee Assembly	2A17/11-3
Components	2A17/11-3	Rigging Rudder Trim System	2A17/11-3
Indicator Assembly	2A17/11-3		

11-1. **RUDDER TRIM CONTROL SYSTEM.** (Refer to figure 11-1.)

11-2. **DESCRIPTION.** The rudder trim system is comprised of a trim control wheel and gear box assembly located in the upper control pedestal, which is connected by a chain assembly to a gimbal assembly in the lower pedestal. The gimbal assembly is

attached to a stop bracket, which is attached to the rudder trim bungee. The bungee's push-rod assembly is attached to the right-hand rudder bar assembly. The rudder control system, rudder trim control system, and the nosewheel steering system are interconnected and adjustments to any one system will affect the others.

11-3. **TROUBLE SHOOTING.**

NOTES

This trouble shooting chart should be used in conjunction with the chart shown in Section 10.

Due to remedy procedures in the following chart, it may be necessary to re-rig the system. Refer to paragraph 11-5.

TROUBLE	PROBABLE CAUSE	REMEDY
FALSE READING ON TRIM POSITION INDICATOR.	Improper rigging.	Refer to note above.
	Worn, bent or disconnected linkage.	Check visually. Repair or replace parts as necessary.
HARD OR SLUGGISH OPERATION OF TRIM WHEEL.	Worn, bent or binding linkage.	Check visually. Repair or replace parts as necessary.
	Incorrect rudder cable tension.	Check and adjust rudder cable tension.
FULL TRIM TRAVEL NOT OBTAINED.	Rudder trim system improperly rigged.	Refer to note above.

MODEL P210 SERIES SERVICE MANUAL




Figure 11-1. Rudder Trim Control System

MODEL P210 SERIES SERVICE MANUAL

11-4. REMOVAL AND INSTALLATION OF SYSTEM COMPONENTS. (Refer to figure 11-1.)

a. INDICATOR ASSEMBLY.

1. Remove pedestal cover in accordance with procedures outlined in Section 9.
2. Remove four screws attaching mounting bracket assembly (19) to pedestal assembly (2).
3. Remove indicator assembly as a unit.
4. Reverse preceding steps for installation.

b. WHEEL AND GEAR BOX ASSEMBLY.

1. Remove pedestal cover as outlined in Section 9.
2. Loosen chain (27) by loosening bolt securing idler sprocket (14) and sliding sprocket inboard in slot in support angle (15).
3. Remove upper panel (3) and disconnect chain (27) at connecting link.
4. Remove four bolts attaching gear box assembly (18) to pedestal assembly (2).
5. Remove bolts attaching idler sprocket (14) and chain guards (12) and (28).
6. Remove wheel and gear box assembly as a unit.

NOTE

If wheel and gear box assembly is disassembled, install washers (16) and (23) as required to nest sprockets and prevent end play.

7. Reverse preceding steps for installation.

c. CHAIN ASSEMBLY.

1. Remove pedestal cover as outlined in Section 9.
2. Remove upper panel (3).
3. Remove access cover directly below and aft of pedestal in floor.
4. Remove fuel selector shaft, then remove lower panel (4).
5. Loosen chain (27) by loosening bolt securing idler sprocket (14) and sliding sprocket inboard in slot in support angle (15).
6. Disconnect chain at connecting link.
7. Remove bolt attaching bungee (13) to stop bracket (11).
8. Pull gimbal assembly (items 5, 6, 7, 8, 9, 10 and 11) aft away from bungee (13).
9. Remove chain (27) from sprocket drive nut (8).
10. Reverse preceding steps for installation.

d. GIMBAL ASSEMBLY.

1. Remove pedestal cover as outlined in Section 9.
2. Remove access cover directly below and aft of pedestal in floor.
3. Remove fuel selector shaft, then remove lower panel (4).
4. Loosen chain (27) by loosening bolt securing idler sprocket (14) and sliding sprocket inboard in slot in support angle (15).
5. Disconnect chain at connecting link.
6. Remove bolt attaching bungee (13) to stop bracket (11).
7. Pull gimbal assembly (items 5, 6, 7, 8, 9, 10 and 11) aft; remove from aircraft.

NOTE

If gimbal assembly is to be disassembled, upon reassembly, shims (9) should be installed between gimbal half assembly (6) and cover plate assembly (10) to maintain .002 to .004-inch end play on sprocket.

8. Reverse preceding steps for installation.

e. BUNGEE ASSEMBLY.

1. Remove pedestal cover as outlined in Section 9.
2. Remove upper panel (3).
3. Remove access cover directly below and aft of pedestal in floor.
4. Remove fuel selector shaft, then remove lower panel (4).
5. Loosen chain (27) by loosening bolt securing idler sprocket (14) and sliding sprocket inboard in slot in support angle (15).
6. Disconnect chain at connecting link.
7. Remove bolts attaching idler sprocket (14) and chain guards (12) and (28) to support angle (15).
8. Remove bolts attaching chain guard to stop bracket (11); remove chain guards.
9. Remove bolt attaching bungee (13) to stop bracket (11).
10. Pull gimbal assembly (items 5, 6, 7, 8, 9, 10 and 11) aft; remove from aircraft.
11. Disconnect bungee push-rod assembly from right-hand rudder bar assembly.
12. Using care, remove bungee from tunnel area, aft, through pedestal.
13. Reverse preceding steps for installation.

NOTE

Upon installation, lubricate bungee screw and sprocket drive nut threads per Section 2.

11-5. RIGGING RUDDER TRIM SYSTEM. (Refer to Figure 11-1.)

NOTE

Rudder control system and nose wheel steering system must be correctly rigged prior to rigging the rudder trim system.

- a. Remove pedestal cover as outlined in Section 9.
- b. Remove upper pedestal panel.
- c. Remove access cover directly below and aft of pedestal in floor.
- d. Remove fuel selector shaft, then remove lower pedestal panel.
- e. Loosen chain by loosening bolt securing idler sprocket, and sliding sprocket inboard in slot in support angle; disconnect chain.
- f. Remove bolt attaching bungee to stop bracket; unscrew gimbal assembly from actuator drive screw.
- g. Disconnect bungee push-pull rod from right-hand rudder bar assembly.
- h. Tie down or weight tail to raise nose wheel free of ground.
- i. Ensure rudder pedals and rudder are in neutral position.

MODEL P210 SERIES SERVICE MANUAL

- j. Attach bungee push-pull rod to right-hand rudder bar assembly.
- k. Install lower panel assembly and bearing brackets.
- l. Screw gimbal assembly onto bungee drive screw until studs on gimbal half assembly align with holes in bearing brackets and nutplate on stop bracket aligns with approximate center of slot in bungee stop arm.
- m. Install and tighten bolts, washers and nuts.
- n. String chain over idler sprocket and sprocket in wheel and gear box assembly; connect chain at connecting link.

NOTE

Indicator assembly should be installed with

rudder pedals in neutral position. If indicator does not line up with centerline of aircraft, bend indicator left or right as required.

- o. Tighten chain by moving idler sprocket outboard in slot in support angle.
- p. Install full selector shaft.
- q. Install upper panel.
- r. Install floor access covers and pedestal cover.
- s. Remove blocking from rudder and pedals.
- t. Lower aircraft.

WARNING

Be sure rudder moves in correct direction when operated by the trim control wheel.

MODEL P210 SERIES SERVICE MANUAL

SECTION 12

ENGINE

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand not allow anyone else to stand within the arc of the propeller, since a loose or broken wire, or a component malfunction, could cause the propeller to rotate.

NOTE

For additional information covering turbocharger and component maintenance, overhaul and trouble shooting refer to the Manufacturer's Overhaul Manual.

TABLE OF CONTENTS Page No. Aerofiche/Manual

ENGINE COWLING	2B1/12-3	ENGINE FUEL SYSTEM	2B16/12-18
Description	2B1/12-3	Description	2B16/12-18
Removal/Installation	2B1/12-3	Fuel-Air Control Unit	2B18/12-20
Cleaning/Inspection	2B1/12-3	Description	2B18/12-20
Repair	2B1/12-3	Removal	2B18/12-20
Cowl Flaps	2B1/12-3	Cleaning/Inspection	2B18/12-20
Description	2B1/12-3	Installation	2B18/12-20
Removal/Installation	2B1/12-3	Adjustments	2B18/12-20
Rigging	2B1/12-3	Oil-Heated Fuel Manifold	
ENGINE	2B1/12-3	Valve	2B20/12-22
Description	2B1/12-3	Description	2B20/12-22
Engine Data	2B2/12-4	Removal	2B20/12-22
Time Between Overhaul (TBO)	2B3/12-5	Cleaning	2B20/12-22
Overspeed Limitations	2B3/12-5	Installation	2B20/12-22
Trouble Shooting	2B4/12-6	Fuel Discharge Nozzles	2B21/12-23
Static Run-Up Procedures	2B8/12-10	Description	2B21/12-23
Removal	2B8/12-10	Removal	2B21/12-23
Cleaning	2B11/12-13	Cleaning/Inspection	2B21/12-23
Accessories Removal	2B11/12-13	Installation	2B21/12-23
Inspection	2B11/12-13	Fuel Injection Pump	2B22/12-24
Build-Up	2B11/12-13	Description	2B22/12-24
Installation	2B11/12-13	Removal	2B22/12-24
Flexible Fluid Hoses	2B12/12-14	Installation	2B23/12-25
Pressure Test	2B12/12-14	Adjustment	2B23/12-25
Replacement	2B13/12-15	INDUCTION AIR SYSTEM	2C1/12-27
Engine Baffles	2B13/12-15	Description	2C1/12-27
Description	2B13/12-15	Airbox	
Cleaning/Inspection	2B13/12-15	Removal/Installation	2C1/12-27
Removal/Installation	2B13/12-15	Cleaning/Inspection	2C1/12-27
Repair	2B13/12-15	Induction Air Filter	2C1/12-27
ENGINE OIL SYSTEM	2B13/12-15	Description	2C1/12-27
Description	2B13/12-15	Removal/Installation	2C1/12-27
Trouble Shooting	2B14/12-16	Cleaning/Inspection	2C1/12-27
Full-Flow Oil Filter	2B16/12-18	IGNITION SYSTEM	2C1/12-27
Description	2B16/12-18	Description	2C1/12-27
Removal/Installation	2B16/12-18	Trouble Shooting	2C3/12-29
Oil Cooler	2B16/12-18	Magnets	2C4/12-30
Description	2B16/12-18		

MODEL P210 SERIES SERVICE MANUAL

Description	2C4/12-30	VARIABLE CONTROLLER AND	
Pressurized Magnetos	2C4/12-30	WASTEGATE ACTUATOR	2C14/12-40
Removal	2C4/12-30	Functions	2C14/12-40
Internal Timing	2C4/12-30	Operation	2C15/12-41
Installation and Timing-		Overboost Exceeding 6 Inches	2C15/12-41
to-Engine	2C4/12-30	Variable Controller Adjustment	2C16/12-42
Maintenance	2C6/12-32	Trouble Shooting	2C18/12-44
Magneto Check	2C6/12-32	Controller, Fuel Flow and Turbo-	
Spark Plugs	2C7/12-33	charger Operational Flight	
ENGINE CONTROLS	2C7/12-33	Check	2C22/12-48
Description	2C7/12-33	Removal/Installation of	
Rigging	2C7/12-33	Turbocharger Controller	2C24/12-50
Throttle Control	2C8/12-34	Removal/Installation of	
Mixture Control	2C8/12-34	Wastegate and Actuator	2C24/12-50
Propeller Control	2C8/12-34	Adjustment of Wastegate	
Rigging Throttle-Operated		Actuator	2C24/12-50
Microswitch	2C8/12-34	EXTREME WEATHER	
Auxiliary Electric Fuel Pump		MAINTENANCE	2C24/12-50
Flow Adjustment	2C9/12-35	Cold Weather	2C24/12-50
Landing Gear Warning Horn	2C9/12-35	Hot Weather	2C24/12-50
STARTING SYSTEM	2C9/12-35	Seacoast/Humid Areas	2C24/12-50
Description	2C9/12-35	Dusty Areas	2C24/12-50
Trouble Shooting	2C9/12-35		
Primary Maintenance	2C10/12-36		
Starter Motor	2C10/12-36		
Removal/Installation	2C10/12-36		
EXHAUST SYSTEM	2C10/12-36		
Description	2C10/12-36		
Removal	2C10/12-36		
Installation	2C10/12-36		
Inspection	2C12/12-38		
TURBOCHARGER	2C12/12-38		
Description	2C12/12-38		
Removal/Installation	2C14/40		

MODEL P210 SERIES SERVICE MANUAL

12-1. ENGINE COWLING.

12-2. DESCRIPTION. The engine cowling is divided into four major removable segments. The left upper cowling segment has two access doors, one at the upper front provides access to the oil filler neck and one at the left aft side provides access to the oil dipstick and ground service receptacle, if installed. The right and left nose caps are fastened to the lower engine nacelle and to each other with screws. The right and left upper cowl segments are secured with quick-release fasteners and either segment may be removed individually. The lower left engine nacelle contains a port on the aft end for venting the cabin heating system and may be removed. The opening in the lower right nacelle, which may be removed by removing screws, supplies ram air to the turbo-charger.

12-3. REMOVAL AND INSTALLATION.

- a. Release the quick-release fasteners attaching the cowling to the fuselage and at the parting surfaces of the left and right segments.
- b. Remove screws securing the left and right nose-cap together and to the lower engine nacelle, and remove caps.
- c. Reverse the preceding steps for reinstallation. Ensure the baffle seals are turned in the correct direction to confine and direct air flow around the engine. The vertically installed seals must fold forward and the side seals must fold upwards.

12-4. CLEANING AND INSPECTION. Wipe the inner surfaces of the cowling segments with a clean cloth saturated with cleaning solvent (Stoddard or equivalent). If the inside surface of the cowling is coated heavily with oil or dirt, allow solvent to soak until foreign material can be removed. Wash painted surfaces of the cowling with a solution of mild soap and water and rinse thoroughly. After washing, a coat of wax may be applied to the painted surfaces to prolong paint life. After cleaning, inspect cowling for dents, cracks, loose rivets and spot welds. Repair all defects to prevent spread of damage.

12-5. REPAIR. If cowling skins are extensively damaged, new complete sections of the cowling should be installed. Standard insert-type patches may be used for repair if repair parts are formed to fit contour of cowling. Small cracks may be stop-drilled and small dents straightened if they are reinforced on the inner surface with a doubler of the same material as the cowling skin. Damaged reinforcement angles should be replaced with new parts. Due to their small size, new reinforcement angles are easier to install than to repair the damaged part.

12-6. COWL FLAPS.

12-7. DESCRIPTION. Cowl flaps are provided to aid in controlling engine temperature. Two cowl flaps, operated by a single control in the cabin, are located in the lower aft engine compartment. The engine exhaust tailpipe extends through a cutout, forward of the right-hand cowl flap.

12-8. REMOVAL AND INSTALLATION. (See figure 12-1.)

- a. Place control lever (2) in the OPEN position.
- b. Disconnect clevis (10) from shock mount on right hand cowl flap.
- c. Disconnect links (13) from arm (15) on left hand cowl flap.
- d. Remove nuts, washers, and bolts at cowl flap attach points (11) and remove cowl flaps.
- e. Reverse the preceding steps for reinstallation. Rig cowl flaps, if necessary, in accordance with paragraph 12-9.

12-9. RIGGING. (Refer to figure 12-1.)

- a. Disconnect control clevises (10) from shock-mount arm.
- b. Check to make sure that the flexible controls reach their internal stops in each direction. Mark controls so that full travel can be readily checked and maintained during the remaining rigging procedures.
- c. Place control lever (2) in the CLOSED position. If the control lever cannot be placed in the closed position, loosen clamp (5) at upper end of controls and slip housings in clamp or adjust controls at upper clevis (4) to position control lever in bottom hole of position bracket (3).
- d. With control lever in CLOSED position, set LH cowl flap flush to cowl skin. Set RH cowl flap trailing edge to a $.62 \pm .06$ -inch gap with lower fuselage skin.

NOTE

If lower control clevis (10) cannot be adjusted to attain desired setting, and still maintain sufficient thread engagement, loosen lower control housing clamp (8) and slide housing in clamp as necessary. Be sure threads are visible in clevis inspection holes.

- e. Check that all clamps and jam nuts are tight.

12-10. ENGINE.

12-11. DESCRIPTION. An air-cooled, horizontally-opposed, direct-drive, fuel-injected, six-cylinder, turbocharged, Continental TSIO-520 series engine, driving a constant-speed propeller, is used to power the aircraft. The cylinders, numbered from rear to front, are staggered to permit a separate throw on the crankshaft for each connecting rod. The right rear cylinder is number 1 and the cylinders on the right side are identified by odd numbers 1, 3 and 5. The left rear cylinder is number 2 and the cylinders on the left side are identified as 2, 4 and 6. Refer to paragraph 12-12 for engine data. For repair and overhaul of the engine, accessories and propeller, refer to the appropriate publications issued by their manufacturer's. These publications are available from the Cessna Supply Division.

MODEL P210 SERIES SERVICE MANUAL

12-12. ENGINE DATA.	P21000835 AND ON
Model (Continental)	TSIO-520-CE
BHP Maximum Including Take-Off RPM (Maximum Continuous)	325 2700
Limiting Manifold Pressure (Sea Level)	37.0 Inches Hg.
Number of Cylinders	6-Horizontally Opposed
Displacement	520 Cubic Inches
Bore	5.25 Inches
Stroke	4.00 Inches
Compression Ratio	7.5:1
Magnetos	Slick Model No. 6220
Right Magneto	Fires 20° ±1° BTC Upper Right and Lower Left.
Left Magneto	Fires 20° ±1° BTC Upper Left and Lower Right.
Firing Order	1-6-3-2-5-4
Spark Plugs	18mm (Refer to Continental Service Bulletin M77-10 for factory approved spark plugs and required gap) 330 ±30 Lb-In.
Torque	
Fuel Metering System	Continental Fuel Injection
Unmetered Fuel Pressure	5.5 to 6.5 PSI at 600 RPM
	29 to 32 PSI at 2600 RPM
Nozzle Pressure	3.5 to 4.0 PSI at 600 RPM 16.9 PSI at 2700 RPM
Oil Sump Capacity	10 U. S. Quarts
With Filter Element Change	11 U. S. Quarts
Tachometer	Mechanical Drive
Oil Pressure (PSI)	
Minimum Idling	10
Normal	30 to 60
Maximum (Cold Oil Starting)	100
Connection Location	Between No. 2 and No. 4 Cylinders
Oil Temperature	
Normal Operating	Within Green Arc (100° to 240° F)
Maximum Permissible	Red Line (240° F)
Probe Location	In front of No. 5 Cylinder Base
Cylinder Head Temperature	
Probe Location	Red Line (460° F) Max. Lower Side No. 1 Cylinder Head
Turbine Inlet Temperature	
Probe Location	Front Crossover Exhaust Runner

MODEL P210 SERIES SERVICE MANUAL

12-13. TIME BETWEEN OVERHAUL (TBO). Teledyne Continental Motors recommended engine overhaul time is 1600 hours. Refer to Continental Aircraft Engine Service Bulletin M81-22, and to any superseding bulletins, revisions or supplements thereto, for further recommendations. At the time of overhaul, engine accessories should be overhauled. Refer to Section 14 for propeller and governor overhaul periods.

12-14. OVERSPEED LIMITATIONS. The engine must not be operated above specified maximum continuous RPM. However, should inadvertent overspeed occur, refer to Continental Aircraft Engine Service Bulletin M75-16, and to any superseding bulletins, revisions or supplements thereto, for further recommendations.




Figure 12-1. Cowl Flaps Installation

MODEL P210 SERIES SERVICE MANUAL

12-15. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE FAILS TO START.	Engine flooded or improper use of starting procedure.	Use proper starting procedure. Refer to Pilot's Operating Handbook.
	Defective aircraft fuel system.	Refer to Section 13.
	Fuel tanks empty.	Service fuel tanks.
	Spark plugs fouled or defective.	Remove, clean, inspect and regap. Use new gaskets. Check cables to persistently fouled plugs. Replace if defective.
	Magneto impulse coupling failure.	Repair or install new coupling.
	Defective magneto switch or grounded magneto leads.	Repair or replace switch and leads.
	Defective ignition system.	Refer to paragraph 12-83.
	Induction air leakage.	Correct cause of air leakage.
	Clogged fuel screen in fuel control unit or defective unit.	Remove and clean. Replace defective unit.
	Clogged fuel screen in fuel manifold valve or defective valve.	Remove and clean screen. Replace defective valve.
	Clogged fuel injection lines or discharge nozzles.	Remove and clean lines and nozzles. Replace defective units.
	Defective auxiliary fuel pump.	Refer to Section 13.
	Engine-driven fuel pump not permitting fuel from auxiliary pump bypass.	Install new engine-driven fuel pump.
	Vaporized fuel in system. (Most likely to occur in hot weather with a hot engine.)	Refer to Pilot's Operating Handbook.
ENGINE STARTS BUT DIES; OR WILL NOT IDLE PROPERLY.	Propeller control in high pitch (low RPM) position.	Use low pitch (high RPM) position for all ground operations.
	Improper idle speed or idle mixture adjustment.	Refer to paragraph 12-50.
	Defective aircraft fuel system.	Refer to Section 13.
	Spark plugs fouled or defective.	Remove, clean, inspect and regap. Use new gaskets. Check cables to persistently fouled plugs. Replace if defective.
	Water in fuel system.	Drain fuel tank sumps, lines and fuel strainer.
	Defective ignition system.	Refer to paragraph 12-83.

MODEL P210 SERIES SERVICE MANUAL

12-15. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE STARTS BUT DIES, OR WILL NOT IDLE PROPERLY (CONT).	Induction air leakage.	Correct cause of air leakage.
	Clogged fuel screen in fuel control unit or defective unit.	Remove and clean. Replace defective unit.
	Clogged fuel screen in fuel manifold valve or defective valve.	Remove and clean. Replace defective valve.
	Restricted fuel injection lines or discharge nozzles.	Remove, clean lines and nozzles. Replace defective units.
	Defective engine-driven fuel pump.	Install and calibrate new pump.
	Vaporized fuel in system. (Most likely to occur in hot weather with a hot engine.)	Refer to Pilot's Operating Handbook.
	Manual engine primer leaking.	Disconnect primer outlet line. If fuel leaks through primer, repair or replace primer.
	Obstructed air intake.	Remove obstruction; service air filter, if necessary.
	Discharge nozzle air vent manifold restricted or defective.	Check for bent lines or loose connections. Tighten loose connections. Remove restrictions and replace defective components.
	Defective engine.	Check compression and listen for unusual engine noises. Check oil filter for excessive metal. Repair engine as required.
ENGINE HAS POOR ACCELERATION, RUNS ROUGHLY AT SPEEDS ABOVE IDLE OR LACKS POWER.	Idle mixture too lean.	Refer to paragraph 12-50.
	Propeller control in high pitch (low RPM) position.	Use low pitch (high RPM) position for all ground operations.
	Incorrect fuel-air mixture, worn control linkage or restricted air filter.	Replace worn elements of control linkage. Service air filter.
	Defective ignition system.	Refer to paragraph 12-83.
	Malfunctioning turbocharger.	Check operation, listen for unusual noise. Check operation of wastegate valve and for exhaust system defects. Tighten loose connections.
	Improper fuel-air mixture.	Check intake manifold connections for leaks. Tighten loose connections. Check fuel controls and linkage for setting and adjustment.

MODEL P210 SERIES SERVICE MANUAL

12-15. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE HAS POOR ACCELERATION, RUNS ROUGHLY AT SPEEDS ABOVE IDLE OR LACKS POWER (CONT).	Spark plugs fouled or defective.	Remove, clean, inspect and regap. Use new gaskets. Check cables to persistently fouled plugs. Replace if defective.
	Fuel pump pressure improperly adjusted.	Refer to paragraph 12-65.
	Restriction in fuel injection system.	Clean out restriction. Replace defective items.
	Propeller out of balance.	Check and balance propeller.
	Defective engine.	Check compression, check oil filter for excessive metal. Listen for unusual noises. Repair engine as required.
	Exhaust system leakage.	Refer to paragraph 12-105.
	Turbocharger wheels rubbing.	Replace turbocharger.
	Improperly adjusted or defective wastegate controller.	Refer to paragraph 12-115.
	Leak in turbocharger discharge pressure system.	Correct cause of leaks. Repair or replace damaged parts.
	Manifold pressure overshoot. (Most likely to occur when engine is accelerated too rapidly.)	Move throttle about two-thirds open. Let engine accelerate and peak. Move throttle to full open.
Engine oil viscosity too high for ambient air.	Refer to Section 2 for proper grade of oil.	
POOR IDLE CUT-OFF.	Mixture control linkage improperly rigged.	Refer to paragraph 12-90.
	Defective or dirty fuel manifold valve.	Remove and clean manifold valve.
	Fuel contamination.	Drain all fuel and flush out fuel system. Clean all screens, fuel strainers, fuel manifold valves, nozzles and fuel lines.
	Defective mixture control valve in fuel pump.	Replace fuel pump.
ENGINE LACKS POWER, REDUCTION IN MAXIMUM MANIFOLD PRESSURE OR CRITICAL ALTITUDE.	Incorrectly adjusted throttle control, "sticky" linkage or dirty air filter.	Check movement of linkage by moving control through range of travel. Make proper adjustments and replace worn components. Service air filter.

MODEL P210 SERIES SERVICE MANUAL

12-15. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE LACKS POWER, REDUCTION IN MAXIMUM MANIFOLD PRESSURE OR CRITICAL ALTITUDE (CONT).	Defective ignition system.	Inspect spark plugs for fouled electrodes, heavy carbon deposits, erosion of electrodes, improperly adjusted electrode gaps and cracked porcelains. Test plugs for regular firing under pressure. Replace damaged or misfiring plugs.
	Improperly adjusted wastegate valve.	Refer to paragraph 12-117.
	Loose or damaged exhaust system.	Inspect entire exhaust system to turbocharger for cracks and leaking connections. Tighten connections and replace damaged parts.
	Loose or damaged manifolding.	Inspect entire manifolding system for possible leakage at connections. Replace damaged components, tighten all connections and clamps.
	Fuel discharge nozzle defective.	Inspect fuel discharge nozzle vent manifolding for leaking connections. Tighten and repair as required. Check for restricted nozzles and lines and clean and replace as necessary.
	Malfunctioning turbocharger.	Check for unusual noise in turbocharger. If malfunction is suspected, remove exhaust and/or air inlet connections and check rotor assembly, for possible rubbing in housing, damaged rotor blades or defective bearings. Replace turbocharger if damage is noted.
BLACK SMOKE EXHAUST.	Turbo coking, oil forced through seal of turbine housing.	Clean or change turbocharger.
HIGH CYLINDER HEAD TEMPERATURE.	Defective cylinder head temperature indicating system.	Refer to Section 16.
	Improper use of cowl flaps.	Refer to Pilot's Operating Handbook.
	Engine baffles loose, bent or missing.	Install baffles properly. Repair or replace if defective.
	Dirt accumulated on cylinder cooling fins.	Clean thoroughly.
	Incorrect grade of fuel.	Drain and refill with proper fuel.

MODEL P210 SERIES SERVICE MANUAL

12-15. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
HIGH CYLINDER HEAD TEMPERATURE (CONT).	Incorrect ignition timing.	Refer to paragraph 12-82.
	Improper use of mixture control.	Refer to Pilot's Operating Handbook.
HIGH OR LOW OIL TEMPERATURE OR PRESSURE.	Defective engine.	Repair as required.
		Refer to paragraph 12-33.
NOTE		
Refer to paragraph 12-112 for trouble shooting of controller and wastegate actuator.		

12-16. **STATIC RUN-UP PROCEDURES.** In a case of suspected low engine power, a static run-up should be conducted as follows:

- a. Run-up engine, using take-off power and mixture settings, with the aircraft facing 90° right and then left to the wind direction.
- b. Record the RPM obtained in each run-up position.

NOTE

Daily changes in atmospheric pressure, temperature and humidity will have a slight effect on static run-up.

c. Average the results of the RPM obtained. The minimum acceptable RPM is 2650 (or 2625 with prop de-ice boots). The average should fall between 2650 (or 2625 with prop de-ice boots) and 2700 RPM.

d. If the average results of the RPM obtained are lower than stated above, the following recommended checks may be performed to determine a possible deficiency.

1. Check governor control for proper rigging. It should be determined that the governor control arm travels to the high RPM stop on the governor and that the high RPM stop screw is adjusted properly. (Refer to Section 13 for procedures).

NOTE

If verification of governor operation is necessary the governor may be removed from the engine and a flat plate installed over the engine pad. Run-up engine to determine that governor was adjusted properly.

2. Check operation of alternate air door spring or magnetic lock to make sure door will remain closed in normal operation.

3. Check magneto timing, spark plugs and ignition harness for settings and conditions.

4. Check fuel injection nozzles for restriction and check for correct unmetered fuel flow.

5. Check condition of induction air filter. Clean if required.

6. Perform an engine compression check. (Refer to engine Manufacturer's Manual).

12-17. **REMOVAL.** If an engine is to be placed in storage or returned to the manufacturer for overhaul, proper preparatory steps should be taken for corrosion prevention prior to beginning the removal procedure. Refer to Section 2 for storage preparation. The following engine removal procedure is based upon the engine being removed from the aircraft as a complete unit with the turbocharger and accessories installed.

NOTE

Tag each item when disconnected to aid in identifying wires, hoses, lines and control linkages when engine is reinstalled. Likewise, shop notes made during removal will often clarify reinstallation. Protect openings, exposed as a result of removing or disconnecting units, against entry of foreign material by installing covers or sealing with tape.

- a. Place all cabin switches in the OFF position.
- b. Place fuel selector or fuel ON-OFF valve in the OFF position.
- c. Remove engine cowling in accordance with paragraph 12-3.
- d. Disconnect battery cables and insulate terminals as a safety precaution. Remove battery and battery box for additional clearance, if desired.
- e. Drain fuel strainer and lines.

MODEL P210 SERIES SERVICE MANUAL

NOTE

During the following procedures, remove any clamps or lacings which secure controls, wires, hoses or lines to the engine, engine nacelle or attached brackets, so they will not interfere with engine removal. Some of the items listed can be disconnected at more than one place. It may be desirable to disconnect some of these items at other than the places indicated. The reason for engine removal should be the governing factor in deciding at which point to disconnect them. Omit any of the items which are not present on a particular engine installation.

- f. Drain the engine oil sump and oil cooler.
- g. Disconnect magneto primary lead wires at magnetos.

WARNING

The magnetos are in a SWITCH ON condition when the switch wires are disconnected. Ground the magneto points or remove the high tension wires from the magnetos or spark plugs to prevent accidental firing.

h. Remove the spinner and propeller in accordance with Section 14. Cover exposed end of crankshaft flange and propeller flange to prevent entry of foreign material.

i. Disconnect throttle, mixture and propeller controls from their respective units. Remove clamps attaching controls to engine and pull controls aft clear of engine. Use care to avoid bending controls too sharply. Note EXACT position, size and number of attaching washers and spacers for reference on reinstallation.

- j. Disconnect wires and cables as follows:
 - 1. Disconnect tachometer drive shaft at adapter.

CAUTION

When disconnecting starter cable do not permit starter terminal bolt to rotate. Rotation of the bolt could break the conductor between bolt and field coils causing the starter to be inoperative.

- 2. Disconnect starter electrical cable at starter.
- 3. Disconnect cylinder head temperature wire at probe.
- 4. Disconnect oil temperature wire at probe below oil cooler.
- 5. Disconnect electrical wires and wire shielding ground at alternator.
- 6. Disconnect exhaust gas temperatures or turbine inlet temperature wires at quick-disconnects.
- 7. Disconnect electrical wires at throttle micro-switches.
- 8. Remove all clamps and lacings attaching wires or cables to engine and pull wires and cables aft to clear engine.
- k. Disconnect lines and hoses as follows:

- 1. Disconnect vacuum hose at vacuum pump and remove oil separator vent line.

WARNING

Residual fuel and oil draining from disconnected lines and hoses constitutes a fire hazard. Use caution to prevent accumulation of such fuel and oil when lines or hoses are disconnected.

- 2. Disconnect fuel supply and vapor return hoses at fuel pump. Disconnect and remove fuel pump drain line.
- 3. Disconnect manifold pressure line at intake manifold.
- 4. Disconnect the fuel-flow gage line at firewall.
- 5. Disconnect the oil pressure line at the engine.
- 6. Disconnect and remove the right and left manifold drain lines and the balance tube drain line.
- 7. Disconnect duct from sonic venturi on inter-cooler.
- 8. Disconnect turbine inlet duct from turbine.
- 9. Disconnect the air vent line to fuel-flow gage at firewall.
- 10. Disconnect engine primer lines at right and left intake manifolds.
- 11. Disconnect the oil drain line from oil deflector under external oil filter.
 - 1. Disconnect cowl flap control from right hand cowl flap.
 - m. Remove screws securing lower right hand cowl and remove cowl.
 - n. Disconnect flexible ducting from heater shroud and cable valve.
 - o. Carefully check the engine again to ensure ALL hoses, lines, wires, cables, clamps and lacings are disconnected or removed which would interfere with the engine removal. Ensure all wires, cables and engine controls have been pulled aft to clear the engine.


CAUTION

Place a suitable stand under tail tie-down ring before removing engine. The loss of engine weight will cause the aircraft to be tail heavy.

- p. Attach a hoist to the lifting lug at the top center of the engine crankcase. Lift engine just enough to relieve the weight from the engine mounts.
- q. Remove mount bolts, ground strap and heat shields.
- r. Slowly hoist engine out of nacelle and clear of aircraft checking for any items which would interfere with the engine removal. Balance the engine by hand and carefully guide the disconnected parts out as the engine is removed.
- s. Remove engine shock-mounts.


MODEL P210 SERIES SERVICE MANUAL

REINFORCED MOUNTS CONTAIN MOULDED-IN WASHER AT THIS LOCATION



LEFT REAR ONLY

Detail A



1. Bolt
2. Ground Strap
3. Tab Lockwasher
4. Lower Mount
5. Engine Mount Support
6. Spacer
7. Upper Mount
8. Barrel Nut
9. Bolt
10. Deflector *
11. Rod Assy. *

* Installed on R. H. Engine Mounts only.

NOTES

It is important that the correct engine mounts be installed in the correct positions. Be sure that the four reinforced mounts are used at the upper, forward positions.

To determine which four of the twelve mounts are the reinforced ones, use fingernail to feel whether moulded-in washer is present.

If shock-mounts will be re-used, mark each one so it will be reinstalled in exactly the same position. If new shock-mounts will be installed, position them as noted above.

● Torque bolts (1) to 300 +50 -00 lb. in.




Figure 12-2. Engine Mount Installation

MODEL P210 SERIES SERVICE MANUAL

NOTE

If shock-mounts will be re-used, mark each one so it will be reinstalled in exactly the same position. If new shock-mounts will be installed, position them as illustrated in figure 12-2.

12-18. **CLEANING.** Clean engine in accordance with instructions in Section 2.

12-19. **ACCESSORIES REMOVAL.** Removal of engine accessories for overhaul or for engine replacement involves stripping the engine of parts, accessories and components to reduce it to the bare engine. During the removal process, removed items should be examined carefully and defective parts should be tagged for repair or replacement with new components.

NOTE

Items easily confused with similar items should be tagged to provide a means of identification when being installed on a new engine. All openings exposed by the removal of an item should be closed by installing a suitable cover or cap over the opening. This will prevent entry of foreign material. If suitable covers are not available, tape may be used to cover the openings.

12-20. **INSPECTION.** For specific items to be inspected, refer to the engine manufacturer's manual.

- a. Visually inspect the engine for loose nuts, bolts, cracks and fin damage.
- b. Inspect baffles, baffle seals and brackets for cracks, deterioration and breakage.
- c. Inspect all hoses for internal swelling, chafing through protective plys, cuts, breaks, stiffness, damaged threads and loose connections. Excessive heat on hoses will cause them to become brittle and easily broken. Hoses and lines are most likely to crack or break near the end fittings and support points.
- d. Inspect for color bleaching of the end fitting or severe discoloration of the hoses.

NOTE

Avoid excessive flexing and sharp bends when examining hoses for stiffness.

- e. Refer to Section 2 for replacement intervals for flexible fluid carrying hoses in the engine compartment.
- f. For major engine repairs, refer to the engine manufacturer's overhaul and repair manual.

12-21. **BUILD-UP.** Engine build-up consists of installation of parts, accessories and components to the basic engine to build up an engine unit ready for installation on the aircraft. All safety wire, lock-washers, nuts, gaskets and rubber connections should be new parts.

12-22. **INSTALLATION.** Before installing the engine on the aircraft, install any items which were removed from the engine or aircraft after the engine was removed.

NOTE

Remove all protective covers, plugs, caps and identification tags as each item is connected or installed. Omit any items not present on a particular engine installation.

- a. Hoist the engine to a point just above the nacelle.
- b. Install engine shock-mounts and ground strap as illustrated in figure 12-2.
- c. Carefully lower engine slowly into place on the engine mounts. Route controls, lines, hoses and wires in place as the engine is positioned on the engine mounts.

NOTE

Be sure engine shock-mounts, spacers and washers are in place as the engine is lowered into position.

- d. Attach ground strap under engine sump bolt and install engine mount bolts. Torque bolts to 300+50-00 lb-in. Bend tab washers to form lock for mount bolts. Install heat shields.
- e. Remove support stand placed under tail tie-down fitting and remove hoist.

NOTE

If the exhaust system was loosened or removed, refer to paragraph 12-105.

- f. Connect flexible ducting on heater shroud and cabin valve.
- g. Route propeller governor control along left side of engine and secure with clamps.

NOTE

Throughout the aircraft fuel system, from the fuel bays to the engine-driven fuel pump, use NS-40 (RAS-4) (Snap-On Tools Corp., Kenosha, Wisconsin), MIL-T-5544 (Thread Compound, Antiseize, Graphite Petrolatum), USP Petrolatum or engine oil as a thread lubricant or to seal a leaking connection. Apply sparingly to male threads only, omitting the first two threads, exercising extreme caution to avoid "stringing" sealer across the end of the fitting. Always ensure that a compound, the residue from a previously

MODEL P210 SERIES SERVICE MANUAL

used compound, or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel-soluble lubricant, such as engine oil, on fitting threads. Do not use any other form of thread compound on the injection system.

- h. Connect lines and hoses as follows:
 - 1. Install and connect the left and right manifold drain lines and the balance tube drain line.
 - 2. Connect the oil pressure line at its fitting.
 - 3. Connect the fuel-flow gage line at firewall.
 - 4. Connect the fuel supply and the vapor return lines at the fuel pump. Connect and install fuel pump drain line.
 - 5. Connect manifold pressure line at intake manifold.
 - 6. Connect vacuum line at the vacuum pump, and install oil separator vent line.
 - 7. Connect air and oil lines at waste-gate controller on firewall.
 - 8. Install lower right hand cowl.
 - 9. Connect turbine inlet duct.
 - 10. Connect cowl flap control to cowl flap.
 - 11. Connect duct to sonic venturi on intercooler.
 - 12. Connect engine primer lines at right and left intake manifolds.
 - 13. Connect oil drain line to oil deflector under external oil filter.
 - 14. Install all clamps securing lines and hoses to engine or structure.
 - i. Connect wires and cables as follows:
 - 1. Connect oil temperature wire at probe below oil cooler.
 - 2. Connect tachometer drive to adapter and torque to 100 lb-in.

WARNING

When connecting starter cable, do not permit starter terminal bolt to rotate. Rotation of the bolt could break conductor between terminal and field coils causing starter to be inoperative.

- 3. Connect starter electrical lead.
- 4. Connect cylinder head temperature wire at probe.
- 5. Connect electrical wires and wire shielding ground to alternator.
- 6. Connect electrical wiring to throttle switches.
- 7. Connect exhaust gas temperature or turbine inlet temperature wires at quick-disconnects.

- 8. Install clamps that attach wires or cables to engine or structure.
- j. Connect engine controls and install block clamps.
- k. Rig engine controls in accordance with paragraphs 12-85, 12-86, and 12-88.
 - l. Install propeller and spinner in accordance with instructions outlined in Section 14.
 - m. Complete a magneto switch ground-out and continuity check, then connect primary lead wires to the magnetos. Remove the temporary ground or connect spark plug leads, whichever procedure was used during removal.

WARNING

Be sure magneto switch is in OFF position when connecting switch wires to magnetos.

- n. Clean and install induction air filter in accordance with Section 2.
- o. Service engine with proper grade and quantity of engine oil. Refer to Section 2 if engine is new, newly overhauled or has been in storage.
- p. Check all switches are in the OFF position and connect battery cables.
- q. Inspect engine installation for security, correct routing of controls, lines, hoses and electrical wiring, proper safetying and tightness of all components.

NOTE

When installing a new or newly overhauled engine, and prior to starting the engine, disconnect the oil inlet line at the controller and the oil outlet line at the controller. Connect these oil lines to a full-flow oil filter, allowing oil to bypass the controller. With filter connected, operate engine approximately 15 minutes to filter out any foreign particles from the oil. This is done to prevent foreign material from entering the controller.

- r. Install engine cowling in accordance with paragraph 12-3.
- s. Perform an engine run-up and make final adjustments on the engine controls.

12-23. FLEXIBLE FLUID HOSES.

12-24. PRESSURE TEST. Refer to Section 2 for pressure test intervals. Perform pressure test as follows:

MODEL P210 SERIES SERVICE MANUAL

- a. Place mixture control in the idle cut-off position.
- b. Operate the auxiliary fuel pump in the high position.
- c. Examine the exterior of hoses for evidence of leakage or wetness.
- d. Hoses found leaking should be replaced.
- e. After pressure testing fuel hoses, allow sufficient time for excess fuel to drain overboard from the engine manifold before attempting an engine start.
- f. Refer to paragraph 12-20 for detailed inspection procedures for flexible hoses.

12-25. REPLACEMENT.

- a. Hoses should not be twisted on installation. Pressure applied to a twisted hose may cause failure or loosening of the nut.
- b. Provide as large a bend radius as possible.
- c. Hoses should have a minimum of one-half inch clearance from other lines, ducts hoses or surrounding objects or be butterfly clamped to them.
- d. Rubber hoses will take a permanent set during extended use in service. Straightening a hose with a bend having a permanent set will result in hose cracking. Care should be taken during removal so that hose is not bent excessively, and during reinstallation to assure hose is returned to its original position.
- e. Refer to AC 43.13, Chapter 10, for additional installation procedures for flexible fluid hose assemblies.

12-26. ENGINE BAFFLES.

12-27. DESCRIPTION. The sheet metal baffles installed on the engine direct the flow of air around the cylinders and other components to provide optimum cooling. Rubber asbestos composition seals, attached to the engine cowling, align with the baffles to form a seal at points of contact to help confine and direct the airflow to the desired area. It is very important to engine cooling that the baffles and seals are in good condition and installed correctly. The vertical seals must fold forward and the side seals must fold upwards. Removal and installation of the

various baffle segments is possible with the cowling removed. Be sure that any new baffles seal properly. The baffle mounting bolts must be torqued to 180 - 210 inch lbs.

12-28. CLEANING AND INSPECTION. The engine baffles should be cleaned with a suitable solvent to remove oil and dirt.

NOTE

The rubber-asbestos seals are oil and grease resistant but should not be soaked in solvent for long periods.

Inspect baffles for cracks in the metal and for loose and/or torn seals. Repair or replace any defective parts.

12-29. REMOVAL AND INSTALLATION. Removal and installation of the various baffle segment is possible with the cowling removed. Be sure that any replaced baffles and seals are installed correctly and that they seal to direct the airflow in the correct direction. Replace sealing strips if they do not seal properly. Other repairs may be made as long as strength and cooling requirements are met. Various lines, hoses, wires and controls are routed through some baffles. Make sure that these parts are reinstalled correctly after installation of baffles.

12-30. REPAIR. Repair of an individual segment of engine baffle is generally impractical, since, due to the small size and formed shape of the part, replacement is usually more economical. However, small cracks may be stop-drilled and a reinforcing doubler may be installed.

12-31. ENGINE OIL SYSTEM.

12-32. DESCRIPTION. The engine lubrication system is a full - pressure, wet - sump type. Refer to applicable engine manufacturer's overhaul manual for specific details and descriptions.

MODEL P210 SERIES SERVICE MANUAL

12-33. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
NO OIL PRESSURE.	No oil in sump.	Check with dipstick. Fill sump with proper grade and quantity of oil. Refer to Section 2.
	Oil pressure line broken, disconnected or pinched.	Inspect pressure lines. Replace or connect lines as required.
	Oil pump defective.	Remove and inspect. Examine engine. Metal particles from damaged pump may have entered engine oil passages.
	Defective oil pressure gage.	Check with a known good gage. If second reading is normal, replace gage.
	Oil congealed in gage line.	Disconnect line at engine and gage; flush with kerosene. Pre-fill with kerosene and install.
	Relief valve defective.	Remove and check for dirty or defective parts. Clean and install; replace valve if defective.
LOW OIL PRESSURE.	Low oil supply.	Check with dipstick. Fill sump with proper grade and quantity of oil. Refer to Section 2.
	Low viscosity oil.	Drain sump and refill with proper grade and quantity of oil.
	Oil pressure relief valve spring weak or broken.	Remove and inspect spring. Replace weak or broken spring.
	Defective oil pump.	Check oil temperature and oil level. If temperature is higher than normal and oil level is correct, internal failure is evident. Remove and inspect. Examine engine. Metal particles from damaged pump may have entered oil passages.
	Secondary result of high oil temperature.	Observe oil temperature gage for high indication. Determine and correct reason for high oil temperature.
	Dirty oil screens.	Remove and clean oil screens.

MODEL P210 SERIES SERVICE MANUAL

12-33. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
HIGH OIL PRESSURE.	High viscosity oil.	Drain sump and refill with proper grade and quantity of oil.
	Relief valve defective.	Remove and check for dirty or defective parts. Clean and install; replace valve if defective.
	Defective oil pressure gage.	Check with a known good gage. If second reading is normal, replace gage.
LOW OIL TEMPERATURE.	Defective oil temperature gage or temperature bulb.	Check with a known good gage. If second reading is normal, replace gage. If reading is similar, the temperature bulb is defective.
	Oil cooler thermostatic bypass valve defective or stuck.	Remove valve and check for proper operation. Replace valve if defective.
HIGH OIL TEMPERATURE.	Oil cooler air passages clogged.	Inspect cooler core. Clean air passages.
	Oil cooler oil passages clogged.	Attempt to drain cooler. Inspect for sediment. Remove cooler and flush thoroughly.
	Thermostatic bypass valve damaged or held open by solid matter.	Feel front of cooler core with hand. If core is cold, oil is bypassing cooler. Remove and clean valve and seat. If still inoperative, replace.
	Low oil supply.	Check with dipstick. Fill sump with proper grade and quantity of oil. Refer to Section 2.
	Oil viscosity too high.	Drain sump and refill with proper grade and quantity of oil.
	Prolonged high speed operation on the ground.	Hold ground running above 1500 RPM to a minimum.
	Defective oil temperature gage.	Check with a known good gage. If second reading is normal, replace gage.
	Defective oil temperature bulb.	Check for correct oil pressure, oil level and cylinder head temperature. If they are correct, check oil temperature gage for being defective; if similar reading is observed, bulb is defective. Replace bulb.

MODEL P210 SERIES SERVICE MANUAL

12-33. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
HIGH OIL TEMPERATURE (Cont.)	Secondary effect of low oil pressure.	Observe oil pressure gage for low indication. Determine and correct reason for low oil pressure.
	Oil congealed in cooler	This condition can occur only in extremely cold temperatures. If congealing is suspected, use an external heater or a heated hangar to warm the congealed oil.
OIL LEAK AT FRONT OF ENGINE.	Damaged crankshaft seal.	Replace.
OIL LEAK AT PUSH ROD HOUSING.	Damaged push rod housing oil seal.	Replace.

12-34. FULL-FLOW OIL FILTER.

12-35. DESCRIPTION. An external oil filter is installed on the engine. The filter is the throw away type and incorporates a bypass valve.

12-36. REMOVAL AND INSTALLATION (Spin-On Filter). (See figure 12-3).

- Remove engine cowling in accordance with paragraph 12-3.
- Remove safety wire from spin-on filter.
- Unscrew spin-on filter from pump.

NOTE

Before discarding filter, cut the filter can open, remove the filter element, and cut through the filter at both ends. Then, carefully unfold the pleated element and examine the material trapped in the element for evidence of internal engine damage, such as chips or particles from bearings. If engine is new or newly overhauled, some small particles or metallic shavings might be found. These are generally of no consequence and should not be confused with particles produced by imparting, abrasion or pressure. Evidence of internal damage found in the oil filter element justifies further examination to determine the cause.

- Before installing the new spin-on filter the gasket should be lightly lubricated with engine oil or Dow Corning Compound (DC-4).
- Torque oil filter to 18-20 ft-lbs and safety.
- Start engine and check for proper oil pressure. Check for oil leakage after warming up the engine.

g. Again check for oil leakage after engine has been run at high power setting (preferably a flight around the field).

h. Check to make sure the filter can has not been making contact with any adjacent parts due to engine torque.

12-37. OIL COOLER.

12-38. DESCRIPTION. A non-congealing remote oil cooler is used. Ram air passes through the oil cooler and is discharged into the engine compartment.

12-39. ENGINE FUEL SYSTEM. (Refer to figure 12-6).

12-40. DESCRIPTION. The fuel injection system is a low pressure system of injecting fuel into the intake port of each cylinder. It is a multi-nozzle continuous flow type which controls fuel flow to match engine airflow. Any change in throttle position, engine speed, or a combination of both, causes changes in fuel flow in the correct relation to engine airflow. A manual mixture control and a fuel flow indicator are provided for leaning. The fuel flow indicator is calibrated in pounds per hour. The continuous-flow system uses a typical rotary vane fuel pump. There are no running parts in this system except for the engine driven fuel pump. The four major components of the system are: the fuel injection pump, fuel-air control unit, fuel manifold valve and fuel discharge nozzles. The fuel injection pump incorporates an adjustable aneroid sensing unit which is pressurized from the discharge side of the turbocharger compressor. Turbocharger discharge air pressure is also used to vent the fuel discharge nozzles and the vent port of the fuel flow gage.

MODEL P210 SERIES SERVICE MANUAL




Figure 12-3. Full-Flow Oil Filter

MODEL P210 SERIES SERVICE MANUAL

NOTE

Throughout the aircraft fuel system, from the fuel bays to the engine-driven fuel pump, use NS-40 (RAS-4, Snap-On Tools Corp., Kenosha, Wisconsin), MIL-T-5544 (Thread Compound, Antiseize, Graphite-Petrolatum) or equivalent, as a thread lubricant or to seal a leaking connection. Apply sparingly to male fittings only, omitting the first two threads. Always ensure that a compound, the residue from a previously used compound or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel soluble lubricant, such as engine lubricating oil, on the fitting threads. Do not use any other form of thread compound on the injection system fittings.

12-41. FUEL-AIR CONTROL UNIT.

12-42. DESCRIPTION. This unit occupies the position ordinarily used for a carburetor, at the intake manifold inlet. The function of this unit is to control engine air intake and to set the metered fuel pressure for proper fuel-air ratio. There are three control elements in this unit, one for air and two for fuel. One of the fuel control elements is for fuel mixture and the other is for fuel metering. Fuel enters the control unit through a strainer and passes to the metering valve. The position of the metering valve controls this fuel passed to the manifold valve and nozzles. A linkage connecting the metering valve to the air throttle proportions airflow to fuel flow. The position of the mixture valve determines the amount of fuel returned to the fuel pump. The fuel control portion of the fuel-air control unit is enclosed in a shroud and is blast-air cooled to help prevent vapor lock.

12-43. REMOVAL

- a. Place all cabin switches and fuel selector or fuel ON-OFF valve in the OFF position.
- b. Remove cowling in accordance with paragraph 12-3.
- c. Loosen clamp and disconnect flexible duct from elbow at top of air throttle.
- d. Tag and disconnect electrical wires from electric fuel pump microswitch.
- e. Disconnect throttle and mixture control rod ends at fuel-air control unit.

NOTE

Cap or plug all disconnected hoses, lines and fittings.

- f. Disconnect and tag all fuel lines at the fuel control valve.
- g. Remove nuts and washers securing triangular brace to fuel-air control unit and engine, at lower end of control unit. Remove brace.

- h. Remove bolt attaching fuel-air control unit to brace at top of control unit.
- i. Loosen hose clamps which secure fuel-air control unit to right and left intake manifold assemblies and slip hoses from fuel-air control unit.
- j. Remove fuel-air control unit.

12-44. CLEANING AND INSPECTION.

- a. Check control connections, levers and linkage for security, safetying and for lost motion due to wear.
- b. Remove the fuel screen assembly and clean in solvent (Stoddard or equivalent). Reinstall and safety.
- c. Check the air control body for cracks and control unit for overall condition.

12-45. INSTALLATION.

- a. Place control unit in position at rear of engine.
- b. Install bolt attaching control unit to brace at top of unit. Ascertain that shock-mount is in place and in good condition.
- c. Install triangular brace at lower end of control unit.
- d. Install hoses and clamps which secure control unit to right and left intake manifold assemblies. Tighten hose clamps.
- e. Connect fuel lines to unit.
- f. Connect throttle and mixture control rod ends to control unit.
- g. Connect electrical wiring to throttle-operated microswitch. Check switch rigging in accordance with Section 13.
- h. Install induction air duct to elbow at top of control unit.
- i. Inspect installation and install cowling.

12-46. ADJUSTMENTS. (Refer to figure 12-7.) The idle speed adjustment is a conventional spring-loaded screw located in the air throttle lever. The idle mixture adjustment is the locknut at the metering valve end of the linkage. Tightening the nut to shorten the linkage provides a richer mixture. A leaner mixture is obtained by backing off the nut to lengthen the linkage. Idle speed and mixture adjustment should be accomplished after the engine has been warmed up. Since idle rpm may be affected by the mixture adjustment, it may be necessary to readjust idle rpm after setting the idle mixture correctly.

- a. Set the throttle stop screw to obtain 600 ± 25 rpm, with throttle control pulled full out against idle stop.

NOTE

Engine idle speed may vary among different engines. An engine should idle smoothly, without excessive vibration and the idle speed should be high enough to maintain idling oil pressure and to preclude any possibility of engine stoppage in flight when the throttle is closed.

MODEL P210 SERIES SERVICE MANUAL




Figure 12-4. Fuel System Schematic

MODEL P210 SERIES SERVICE MANUAL

- b. Advance throttle to increase engine speed to 1000 rpm.
- c. Pull mixture control knob slowly and steadily toward the idle cut-off position, observing tachometer, then return control full IN (RICH) position before engine stops.
- d. Adjust mixture adjusting nut to obtain a slight and momentary gain of 25 to 50 rpm at 1000 rpm engine speed as mixture control is moved from full IN (RICH) toward idle cut-off position. Return control to full IN (RICH) to prevent engine stoppage.
- e. If mixture is set too LEAN, engine speed will drop immediately, thus requiring a richer mixture. Tighten adjusting nut (clockwise) for a richer mixture.
- f. If mixture is set too RICH, engine speed will increase above 5 rpm, thus requiring a leaner mixture. Back off adjusting nut (counterclockwise) for a leaner mixture.

NOTE

After each adjustment to the idle mixture, run engine up to approximately 2000 rpm to clear engine of excess fuel to obtain a correct idle speed.

12-47. OIL HEATED FUEL MANIFOLD VALVE (FUEL DISTRIBUTOR).

12-48. DESCRIPTION. Metered fuel flows to the fuel manifold valve, which provides a central point for distributing fuel to the individual cylinders. An internal diaphragm, operated by fuel pressure, raises or lowers a plunger to open and close the individual cylinder supply ports simultaneously. A needle valve in the plunger ensures that the plunger fully opens the outlet ports before fuel flow starts and closes the ports simultaneously for positive engine shutdown. A fine-mesh screen is included in the fuel manifold valve.

The fuel manifold valve is heated with engine oil to reduce the possibility engine power loss induced by ice formation in the valve cavity. Oil is routed from the forward left hand oil galley to the fuel manifold valve and returned through the oil filler neck.

NOTE

The fuel manifold valves are supplied in two flow ranges. When replacing a valve assembly, be sure the replacement valve has the same suffix letter as the one stamped on the cover of the valve removed.

12-49. REMOVAL.

NOTE

Cap all disconnected lines, hoses and fittings.

- a. Disconnect all fuel and fuel injection lines at the fuel manifold.
- b. Disconnect oil inlet and outlet lines at fuel manifold.
- c. Remove bolts which secure fuel manifold and remove manifold.

12-50. CLEANING.

- a. Remove manifold valve from engine in accordance with paragraph 12-53 and remove safety wire from cover attaching screws.
- b. Hold the top cover down against internal spring until all four cover attaching screws have been removed, then gently lift off the cover. Use care not to damage the spring-loaded diaphragm below cover.
- c. Remove the upper spring and lift the diaphragm assembly straight up.

NOTE

If the valve attached to the diaphragm is stuck in the bore of the body, grasp the center nut, rotate and lift at the same time to work gently out of the body.

CAUTION

Do not attempt to remove needle or spring from inside plunger valve. Removal of these items will disturb the calibration of the valve.

- d. Using clean gasoline, flush out the chamber below the screen.
- e. Flush above the screen and inside the center bore making sure that outlet passages are open. Use only a gentle stream of compressed air to remove dust and dirt and to dry.

CAUTION

The filter screen is a tight fit in the body and may be damaged if removal is attempted. It should be removed only if a new screen is to be installed.

- f. Clean diaphragm, valve and top cover in the same manner. Be sure the vent hole in the top cover is open and clean.
- g. Carefully replace diaphragm and valve. Check that valve works freely in body bore.
- h. Position diaphragm so that horizontal hole in plunger valve is 90 degrees from the fuel inlet port in the valve body.
 - i. Place upper spring in position on diaphragm.
 - j. Place cover in position so that vent hole in cover is 90 degrees from inlet port in valve body. Install cover attaching screws and tighten to 20±1 lb-in. Install safety wire on cover screws.
 - k. Install fuel manifold valve assembly on engine in accordance with paragraph 12-51 and reconnect all lines and hoses to valve.
 - l. Inspect installation and install cowling.

12-51. INSTALLATION.

- a. Secure the fuel manifold to the crankcase with the two crankcase bolts.
- b. Connect oil inlet and outlet lines at fuel manifold.
- c. Connect the fuel lines and the six fuel injection lines. Inspect completed installation and install cowling.

MODEL P210 SERIES SERVICE MANUAL




Figure 12-5. Idle Speed and Idle Mixture Adjustment

12-52. FUEL DISCHARGE NOZZLES.

12-53. DESCRIPTION. From the fuel manifold valve, individual, identical size and length fuel lines carry metered fuel to the fuel discharge nozzles located in the cylinder heads. The outlet of each nozzle is directed into the intake port of each cylinder. An air bleed and nozzle pressurization arrangement is incorporated in each nozzle to aid in vaporization of the fuel. The nozzles are calibrated in several ranges. All nozzles furnished for one engine are of the same calibrated range and are identified by a number and suffix letter stamped on the flat portion of the nozzle body. When replacing a fuel discharge nozzle, be sure that it is of the same calibrated range as the rest of the nozzles in that engine. When a complete set of nozzles is being replaced, the number must be the same as the one removed but the suffix letter may be different, as long as they are the same for all nozzles being installed in a particular engine.

12-54. REMOVAL.

a. Remove engine cowling in accordance with paragraph 12-3.

NOTE

Plug or cap all disconnected lines and fittings.

b. Disconnect nozzle pressurization line at nozzles and disconnect pressurization line at "tee" fitting so that pressurization line may be moved away from discharge nozzles.

c. Disconnect fuel injection line at fuel discharge nozzle.

d. Using care to prevent damage or loss of washers and O-rings, lift sleeve assembly from fuel discharge nozzle.

e. Using a standard 1/2-inch deep socket, remove fuel discharge nozzle from cylinder.

12-55. CLEANING AND INSPECTION. To clean nozzles, immerse in clean solvent and use compressed air to dry them. When cleaning, direct air through the nozzle in the direction opposite of normal fuel flow. Do not remove the nozzle shield or distort it in any way. Do not use a wire or other metal object to clean the orifice or metering jet. After cleaning, check the shield height from the hex portion of the nozzle. The bottom of the shield should be approximately 1/16 inch above the hex portion of the nozzle.

12-56. INSTALLATION.

a. Using a standard 1/2-inch deep socket, install nozzle body in cylinder and tighten to a torque value of 60-80 lb-in.

b. Install O-rings, sleeve assembly and washers.

c. Align sleeve assembly and connect pressurization line to nozzles. Connect pressurization line to "tee" fitting.

d. Install O-ring and washer at top of discharge nozzle and connect fuel injection line to nozzle.

e. Inspect installation for crimped lines and loose fittings.

f. Inspect nozzle pressurization vent system for leakage. A tight system is required, since turbo-charger discharge pressure is applied to various other components of the injection system.

g. Install cowling.

MODEL P210 SERIES SERVICE MANUAL




Figure 12-6. Fuel Injection Pump Adjustment Test Harness

12-57. FUEL INJECTION PUMP.

12-58. DESCRIPTION. The fuel pump is a positive displacement, rotating vane type. It has a splined shaft for connection to the accessory drive section of the engine. Fuel enters the pump at the swirl well of the pump vapor separator. Here, vapor is separated by a swirling motion so that only liquid fuel is fed to the pump. The vapor is drawn from the top center of the swirl well by a small pressure jet of fuel and is fed into the vapor return line where it is returned to the fuel tank. Since the pump is engine-driven changes in engine speed affect total pump flow proportionally. A check valve allows the auxiliary fuel pump pressure to bypass the engine-driven pump for starting, or in the event of engine-driven fuel pump failure in flight. The pump supplies more fuel than is required by the engine; therefore, a relief valve is provided to maintain a constant fuel pump pressure. The engine-driven fuel pump is equipped with an aneroid. The aneroid and relief valve are pressurized from the discharge side of the turbocharger compressor to maintain a proper fuel/air ratio at altitude. The aneroid is adjustable

for fuel pump outlet pressure at full throttle and the relief valve is adjustable for fuel pump outlet pressure at idle.

12-59. REMOVAL.

- Place fuel selector valve handle in OFF position.
- Remove engine cowling in accordance with paragraph 12-3.
- Remove alternator and left rear intake elbow.
- Hoist engine far enough to remove weight from engine mount and remove left rear engine mount leg, shock-mount and alternator bracket.
- Remove flexible duct and shroud, removing fuel lines and fittings as necessary. Tag each fitting and line for identification and cap or seal to prevent entry of foreign material. Flanges of shroud may be straightened to facilitate removal and installation, but must be re-formed after installation. Note angular position of fittings before removal.
- Remove nuts and washers attaching fuel pump to engine and pull pump aft to remove. Remove thin gasket.
- Place temporary cover on pump mounting pad.

MODEL P210 SERIES SERVICE MANUAL

12-60. INSTALLATION.

- a. Install and align any fittings removed after pump removal.
- b. Using new thin gasket, install pump with aneroid chamber down.
- c. Install cooling shroud and remainder of fittings, bending flanges of shroud to their original positions and aligning fittings as noted during removal.
- d. Connect all fuel lines and shroud flexible duct.
- e. Install alternator bracket, shock-mount and engine mount leg. Remove hoist, then adjust alternator drive belt tension. Refer to Section 17.
- f. Install intake elbow.
- g. Start engine and perform an operational check, adjusting fuel pump if required.
- h. Install cowling.

12-61. ADJUSTMENT. Adjustments of the fuel injection pump requires special equipment and procedures. Adjustment to the aneroid applies only to the full throttle setting. Adjustment of the idle position is obtained through the relief valve. To adjust the pump to the pressures specified in paragraph 12-12, proceed as follows:

- a. Remove engine cowling in accordance with paragraph 12-3.
- b. Disconnect the existing engine-driven fuel pump pressure hose at the fuel metering unit or fuel limiter unit and connect the test gage pressure hose and fittings into the fuel injection system as shown in figure 12A-3. Gage MUST be vented to atmosphere.

NOTE

Cessna Service Kit No. SK320-2K provides a test gage, line and fittings for connecting the test gage into the system to perform accurate calibration of the engine-driven fuel pump.

- c. The test gage MUST be held as near to the level of the engine driven fuel pump as possible. Bleed air from test gage line prior to taking readings.

NOTE

The test gage should be checked for accuracy at least every 90 days or anytime an error is suspected. The tachometer accuracy should also be determined prior to making any adjustments to the pump.

- d. Disconnect line from the return (center) port of fuel flow limiter, plug line and cap port. Refer to figure 12-7.

CAUTION

Do not plug side port (inlet) of pressure limiter or limiter may be damaged during adjustment.

- e. Start engine, warm up and run until oil temperature reads 40% to 70% in the green arc range. Oil cooler inlet may have to be partially blocked in cold weather. Set mixture control to full rich position and propeller control full forward (low pitch, high RPM).
- f. Adjust engine idle speed to 600 ± 25 rpm and check test gage for 5.5 - 6.5 PSI. Refer to figure 12-7 for idle mixture adjustment.

NOTE

Do not adjust idle mixture until idle pump pressure is obtained.

DO NOT make fuel pump pressure adjustments while engine is operating.

- g. If the pump pressure is not 5.5 - 6.5 PSI, stop engine and turn the pump relief valve adjustment, on the centerline of the fuel pump clockwise (CW) to increase pressure and counterclockwise (CCW) to decrease pressure.
- h. Maintaining idle pump pressure and idle RPM, obtain correct idle mixture in accordance with paragraph 12-46.
 - i. Completion of the preceding steps have provided:
 1. Correct idle pump pressure.
 2. Correct fuel flow.
 3. Correct fuel metering cam to throttle plate orientation.
 - j. Advance to full throttle and maximum rated engine speed (propeller control full forward) with the mixture control in the full rich position and verify that maximum limit manifold pressure (37.0 \pm 0.5) is indicated. If manifold pressure is incorrect or static RPM is not at least 2650 RPM (or 2625 with prop de-ice boots), refer to paragraph 12-16.
 - k. Retard the propeller control to obtain 2600 ± 25 RPM stabilized.
 - l. Check ships fuel flow gage for 210 - 220 PPH. If fuel flow is incorrect, stop engine and adjust flow by loosening locknut and turning the adjusting screw located at the aneroid counterclockwise (CCW) to increase flow or clockwise (CW) to decrease flow. When fuel flow is correct, verify the unmetered pressure is within the limits specified in paragraph 12-12.
 - m. After correct pressures are obtained, shut down engine and tighten locknut on fuel pump adjustment screw.
 - n. Reconnect line to return (center) port of fuel flow limiter.
 - o. Start engine and advance to full throttle with mixture control full rich and the propeller control full forward. Check the ships fuel flow gage for 220 - 225 PPH. If fuel flow is incorrect, shut down the engine and adjust fuel flow setscrew on fuel flow limiter (clockwise (CW) to increase, counterclockwise (CCW) to decrease to obtain proper fuel flow.
 - p. Remove test equipment, run engine, check for leaks and install cowling.

MODEL P210 SERIES SERVICE MANUAL




Figure 12-7. Fuel-Injection Pump Adjustment/Test

MODEL P210 SERIES SERVICE MANUAL

12-62. INDUCTION AIR SYSTEM.

12-63. DESCRIPTION. Ram air to the engine enters an induction air duct thru a port in lower right cowl. The air is filtered through a dry filter, located in the induction airbox. From the filter, the air passes through a flexible duct to the inlet of the turbocharger compressor. The pressurized air is then routed through a duct thru the intercooler to the fuel-air control unit mounted behind the engine and is then supplied to the cylinders through the intake manifold piping. The fuel-air control unit is connected to the cylinder intake manifold by elbows, hoses and clamps. The intake manifold is attached to each cylinder by four bolts through a welded flange, which is sealed by a gasket. A balance tube passes around the front side of the engine to complete the manifold assembly. An alternate air door, mounted in the duct between the filter and the turbocharger compressor, is held closed by a spring. If the induction air filter should become clogged, suction from the turbocharger compressor will open the door permitting the compressor to draw ambient air through the louvered opening immediately aft of the main induction air scoop. The alternate air door should be checked periodically for freedom of operation and complete closing. The induction air filter should be removed and cleaned as specified in Section 2.

12-64. AIRBOX. Refer to figure 12-8.

12-65. REMOVAL AND INSTALLATION.

- a. Remove right hand upper cowl by releasing the quick-release fasteners attaching cowling to the fuselage and at the parting surfaces of the left and right segments.
- b. Loosen clamp holding flex duct to turbocharger compressor, and disconnect flex duct.
- c. Disconnect control rods from cowl flaps.

- d. Remove screws securing lower right cowl to fuselage and lower engine nacelle.
- e. Remove lower left cowl and air box will come off as it is attached to the cowl.
- f. Reverse the preceding steps for installation.

12-66. CLEANING AND INSPECTION. Clean metal parts of the induction airbox with Stoddard solvent or equivalent. Inspect for cracks, dents, loose rivets, etc. Minor cracks may be stop-drilled. In case of continued or severe cracking, replace airbox. Inspect alternate spring-loaded door for freedom of operation and complete closing.

12-67. INDUCTION AIR FILTER. Refer to figure 12-8.

12-68. DESCRIPTION. An induction air filter, located in the center of the airbox removes dust particles from the ram air entering the engine.


12-69. REMOVAL AND INSTALLATION.

- a. Remove right half of engine cowling in accordance with paragraph 12-3.
- b. Remove the two wing nuts securing the filter retainer in place.
- c. Remove filter retainer and remove air filter.
- d. Reverse the preceding steps for reinstallation.

12-70. CLEANING AND INSPECTION. Clean and inspect filter in accordance with Section 2.

12-71. IGNITION SYSTEM. Refer to figure 12-9.

12-72. DESCRIPTION. The ignition system is comprised of two magnetos, two spark plugs in each cylinder, an ignition wiring harness, an ignition switch mounted on the instrument panel and required wiring between the ignition switch and magnetos.



Detail A

1. Air Scoop
2. Lower Right Cowl
3. Airbox
4. Air Filter
5. Alternate Air Door
6. Cowl Flap

Figure 12-8. Airbox Installation

MODEL P210 SERIES SERVICE MANUAL

12-73. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE FAILS TO START.	Defective ignition switch.	Check switch continuity. Replace if defective.
	Spark plugs defective, improperly gapped or fouled by moisture or deposits.	Clean, regap and test plugs. Replace if defective.
	Defective ignition harness.	If no defects are found by a visual inspection, check with a harness tester. Replace defective parts.
	Magneto "P" lead grounded.	Check continuity. "P" lead should not be grounded in the ON position, but should be grounded in OFF position. Repair or replace "P" lead.
	Failure of impulse coupling.	Impulse coupling pawls should engage at cranking speeds. Listen for loud clicks as impulse couplings operate. Remove magnetos and determine cause. Replace defective magneto.
	Defective magneto.	Refer to paragraph 12-80.
	Broken drive gear.	Remove magneto and check magneto and engine gears. Replace defective parts. Make sure no pieces of damaged parts remain in engine or engine disassembly will be required.
ENGINE WILL NOT IDLE OR RUN PROPERLY.	Spark plugs defective, improperly gapped or fouled by moisture or deposits.	Clean, regap and test plugs. Replace if defective.
	Defective ignition harness.	If no defects are found by a visual inspection, check with a harness tester. Replace defective parts.
	Defective magneto.	Refer to paragraph 12-80.
	Impulse coupling pawls remain engaged.	Listen for loud clicks as impulse coupling operates. Remove magneto and determine cause. Replace defective magneto.
	Spark plugs loose.	Check and install properly.

MODEL P210 SERIES SERVICE MANUAL

12-74. MAGNETOS.

12-75. DESCRIPTION. The magnetos contain a conventional two-pole rotating magnet (rotor), mounted in ball bearings. Driven by the engine through an impulse coupling at one end, the rotor shaft operates the breaker points at the other end of the shaft. The nylon rotor gear drives a nylon distributor gear which transfers high tension current from the wedge-mounted coil to the proper outlet in the distributor block. A coaxial capacitor is mounted in the distributor block housing to serve as the condenser as well as a radio noise suppressor. Both nylon gears are provided with timing marks for clockwise or counterclockwise rotation. The distributor gear and distributor block have timing marks, visible through the air vent holes, for timing to the engine. A timing hole is provided, located in the distributor block. A timing pin or 6-penny nail can be inserted through this timing hole into the mating hole in the rotor shaft to lock the magneto approximately in the proper firing position. The breaker assembly is accessible only after removing the screws fastening the magneto halves together and disconnecting the capacitor slip terminal. Do not separate magneto halves while it is installed on the engine.

12-76. PRESSURIZED MAGNETOS. Pressurized air is taken from the throttle body adaptor assembly and directed by a hose, through a filter, to a tee and then to each magneto. The filter material is enclosed in a transparent case, with a flow arrow imprinted on it. The filter should be replaced when the filtering material is dirty.

12-77. REMOVAL.

- a. Remove engine cowling in accordance with paragraph 12-3.
- b. Tag for identification and remove high tension wires from the magneto being removed.

WARNING

The magneto is in a SWITCH ON condition when the switch wire is disconnected. Remove the high tension wires from magneto or disconnect spark plug leads from the spark plugs to prevent accidental firing.

- c. Disconnect switch wire from condenser terminal at magneto. Tag wire for identification so it may be installed correctly.
- d. Rotate propeller in direction of normal rotation until No. 1 cylinder is coming up on its compression stroke.

NOTE

To facilitate the installation of a replacement magneto, it is good practice to position the crankshaft at the advanced firing angle for No. 1 cylinder during step "d." Any standard

timing device or method can be used. or if the magneto being removed is correctly timed to the engine, the crankshaft can be rotated to a position at which the breaker points will be just opening to fire No. 1 cylinder.

- e. Remove magneto retainer clamps, nuts and washers and pull magneto from crankcase mounting pad.

NOTE

As the magneto is removed from its mounting, be sure that the drive coupling rubber bushing and retainer do not become dislodged from the gear hub and fall into the engine.

12-78. INTERNAL TIMING.

- a. Whenever the gear on the rotor shaft or the cam (which also serves as the key for the gear) has been removed, be sure that the gear and cam are installed so the timing mark on the gear aligns with the "O" etched on the rotor shaft.
- b. When replacing breaker assembly or adjusting contact breaker points, place a timing pin (or 0.093 inch 6-penny nail) through the timing hole located in the distributor block and into the mating hole in the rotor shaft. Adjusting contact breaker points so they are just starting to open in this position will give the correct point setting. Temporarily assemble the magneto halves and capacitor slip terminal and use a timing light to check that the timing marks, visibly through the ventilation plug holes are approximately aligned.

NOTE

The side of the magneto with the manufacturer's insignia has a red timing mark and the side opposite to the insignia has a black timing mark viewed through the vent plug holes. The distributor gear also has a red timing mark and a black timing mark. These marks are used for reference only when installing magneto on the engine. Do not place red and black lines together on the same side.

- c. Whenever the large distributor gear and rotor gear have been disengaged, they must be engaged with their timing marks aligned for correct rotation. Align the timing mark on the rotor gear with the "RH" on the distributor gear. Care must be taken to keep these two gears meshed in this position until the magneto halves are assembled.

12-79. INSTALLATION AND TIMING TO ENGINE. The magneto MUST be installed with its timing marks correctly aligned, with the number one cylinder on its compression stroke and with number one piston at its advanced firing position. Refer to paragraph 12-12 for the advanced firing position of number one piston.

MODEL P210 SERIES SERVICE MANUAL

WARNING

The magneto is grounded through the ignition switch, therefore, any time the switch (primary) wire is disconnected from the magneto, the magneto is in a switch ON or HOT condition. Before turning the propeller by hand, remove the high tension wires from the magneto or disconnect all spark plug leads to prevent accidental firing of the engine.

To locate the compression stroke of number one cylinder, remove the lower spark plugs from each cylinder except number one cylinder. Remove the top plug from number one cylinder. Place thumb of one hand over the number one cylinder spark plug hole and rotate the crankshaft in the direction of normal rotation until the compression stroke is indicated by positive pressure inside the cylinder lifting the thumb off the spark plug hole. After the compression stroke is obtained, locate number one piston at its advanced firing position. Locating the advanced firing position of number one cylinder may be obtained by use of a timing disc and pointer, Timrite, protractor and piston locating gage or external engine timing marks alignment.

NOTE

External engine timing marks are located on a bracket attached to the starter adapter, with a timing mark on the alternator drive pulley as the reference point.

In all cases, it must be definitely determined that the number one cylinder is at the correct firing position and on the compression stroke, when the crankshaft is turned in its normal direction of rotation. After the engine has been placed in the correct firing position, install and time the magneto to the engine in the following manner.

NOTE

Install the magneto drive coupling retainer and rubber bushing into the magneto drive gear hub slot. Insert the two rubber bushings into the retainer with the chamfered edges facing toward the front of the engine.

a. Turn the magneto shaft until the timing marks visible through the ventilation plug holes are aligned (red-to-red or black-to-black) and insert a timing pin (or 0.093 inch 6-penny nail) through the timing hole located in the distributor block and into the mating hole in the rotor shaft. This locks the magneto approximately in the firing position while installing on the engine.

NOTE

If the magneto drive gear was disengaged during magneto removal, hold the magneto in the horizontal position it will occupy when installed, make certain that the drive gear coupling slot is aligned with the magneto coupling lugs. If it is not aligned, pull the magneto drive gear out of mesh with its drive gear and rotate it to the aligned angle, then push it back into mesh. DO NOT WITHDRAW THE MAGNETO DRIVE GEAR FROM ITS OIL SEAL.

- b. After magneto gasket is in place, position the magneto on the engine and secure, then remove the timing pin from the magneto. Be sure to remove this pin before turning the propeller.
- c. Connect a timing light to the capacitor terminal at the front of the magneto and to a good ground.
- d. Turn propeller back a few degrees (opposite of normal rotation) to close the contact points.

NOTE

Do not turn the propeller back far enough to engage the impulse coupling or the propeller will have to be turned in normal direction of rotation until the impulse coupling releases, then backed up to slightly before the firing position.

- e. Slowly advance the propeller in the normal direction of rotation until the timing light indicates the contact points breaking. Magneto mounting clamps may be loosened so that the magneto may be shifted to break the points at the correct firing position.
- f. Tighten magneto mounting nuts and recheck timing.
- g. Repeat steps "a" through "f" for the other magneto.
- h. After both magnetos have been timed, check synchronization of both magnetos. Magnetos must fire at the same time.
- i. Remove timing devices from magneto and engine.
- j. Connect spark plug leads to their correct magneto outlets.

NOTE

The No. 1 magneto outlet is the one closest to the ventilation plug on the side of the magneto having the manufacturer's insignia. The magneto fires at each successive outlet in clockwise direction. Connect No. 1 magneto outlet to No. 1 cylinder spark plug lead. No. 2 outlet to the next cylinder to fire, etc. Engine firing order is listed in paragraph 12-12.

MODEL P210 SERIES SERVICE MANUAL

k. Connect ignition switch (primary) leads to the capacitor terminals on the magnetos.

l. Inspect magneto installation and install engine cowling in accordance with paragraph 12-3.

NOTE

Magneto (primary) lead nut torque range is 13-15 in.-lbs. Exceeding this torque range could result in possible condenser damage.

12-80. MAINTENANCE. At the first 25-hour inspection and at each 100-hour inspection thereafter, the breaker compartment should be inspected. Magneto-to-engine timing should be checked at the first 25-hour inspection, first 50-hour inspection, first 100-hour inspection and thereafter at each 100-hour inspection. If timing is as specified in paragraph 12-12, internal timing need not be checked. If timing is out of tolerance, remove magneto and set internal timing, then install and time to the engine. In the event the magneto internal timing marks are off more than plus or minus five degrees when the breaker points open to fire number one cylinder, remove the magneto and check the magneto internal timing. Whenever the magneto halves are separated the breaker point assembly should always be checked. As long as internal timing and magneto-to-engine timing are within the preceding tolerances, it is recommended that the magneto be checked internally only at 500 hour intervals. It is normal for contact points to burn and the cam to wear a comparable amount so the magneto will remain in time within itself. This is accomplished by having a good area making contact on the surface between the points and the correct amount of spring pressure on the cam. The area on the points should be twenty-five percent of the area making contact. The spring pressure at the cam should be 10.5 to 12.5 ounces. When the contact points burn, the area becomes irregular, which is not detrimental to the operation of the points unless metal transfer is too great which will cause the engine to misfire. Figure 12-11 illustrates good and bad contact points. A small dent will appear on the nylon insulator between the cam follower and the breaker bar. This is normal and does not require replacement.

NOTE

If ignition trouble should develop, spark plugs and ignition wiring should be checked first. If the trouble definitely is associated with a magneto, use the following to help disclose the source of trouble without overhauling the magneto.

a. Moisture Check.

1. Remove magneto from engine and remove screws securing the magneto halves together, disconnect capacitor slip terminal and remove distributor. Inspect for moisture.

2. Check distributor gear finger and carbon brush for moisture.

3. Check breaker point assembly for moisture, especially on the surfaces of the breaker points.

4. If any moisture is evident in the preceding places, wipe with a soft, dry, clean, lint-free cloth.

b. Breaker Compartment Check.

1. Check all parts of the breaker point assembly for security.

2. Check breaker point surface for evidence of excessive wear, burning, deep pits and carbon deposits. Breaker points may be cleaned with a hard-finish paper. If breaker point assembly is defective, install a new assembly. Make no attempt to stone or dress the breaker points. Clean new breaker points with clean, unleaded gasoline and hard-finish paper before installing.

3. Check capacitor mounting bracket for cracks or looseness.

4. Check the carbon brush on the distributor for excessive wear. The brush must extend a minimum of 1/32 inch beyond the end of the gear shaft. The spring which the carbon brush contacts should be bent out approximately 20 degrees from vertical, since spring pressure on the brush holds the distributor gear shaft against the thrust bearing in the distributor block.

5. Oil the bearings at each end of the distributor gear shaft with a drop of SAE 20 oil. Wipe excess oil from parts.

6. Make sure internal timing is correct and reassemble magneto. Install and properly time magneto to engine.

12-81. MAGNETO CHECK. Advanced timing settings in some cases, is the result of the erroneous practice of bumping magnetos up in timing in order to reduce RPM drop on single ignition. NEVER ADVANCE TIMING BEYOND SPECIFICATIONS IN ORDER TO REDUCE RPM DROP. Too much importance is being attached to RPM drop on single ignition. RPM drop on single ignition is a natural characteristic of dual ignition design. The purpose of the following magneto check is to determine that all the following magneto check is to determine that all cylinders are firing. If all cylinders are not firing, the engine will run extremely rough and cause for investigation will be quite apparent. The amount of RPM drop is not necessarily significant and will be influenced by ambient air temperature, humidity, airport altitude, etc. In fact, absence of RPM drop should be cause for suspicion that the magneto timing has been bumped up and is set in advance of the setting specified. Magneto checks should be performed on a comparative basis between individual right and left magneto performance.

a. Start and run engine until the oil and cylinder head temperature is in the normal operating range.

b. Place the propeller control in the full low pitch (high RPM) position.

c. Advance engine speed to 1700 RPM.

d. Turn the ignition switch to the "R" position and note the RPM drop, then return the switch to the "BOTH" position to clear the opposite set of plugs.

e. Turn the switch to the "L" position and note the RPM drop, then return the switch to the "BOTH" position.

MODEL P210 SERIES SERVICE MANUAL




Figure 12-9. Magneto Contact Breaker Points

f. The RPM drop should not exceed 150 RPM on either magneto or show greater than 50 RPM differential between magnetos. A smooth RPM drop-off past normal is usually a sign of a too lean or too rich mixture. A sharp RPM drop-off past normal is usually a sign of a fouled plug, a defective harness lead or a magneto out of time. If there is doubt concerning operation of the ignition system, RPM checks at a leaner mixture setting or at higher engine speeds will usually confirm whether a deficiency exists.

NOTE

An absence of RPM drop may be an indication of faulty grounding of one side of the ignition system, a disconnected ground lead at magneto or possibly the magneto timing is set too far in advance.

12-82. SPARK PLUGS. Two spark plugs are installed in each cylinder and screw into helicoil type thread inserts. The spark plugs are shielded to prevent spark plug noise in the radios and have an internal resistor to provide longer terminal life. Spark plug service life will vary with operating conditions. A spark plug that is kept clean and properly gapped will give better and longer service than one that is allowed to collect lead deposits and is improperly gapped.

NOTE

Refer to Section 2 for inspection intervals. Remove, clean, inspect and regap all spark plugs at these intervals. At this time, install lower spark plugs in upper portion of cylinders and install upper spark plugs in lower portion of cylinders. Since deterioration of lower spark plugs is usually more rapid than that of the upper spark plugs, rotating helps prolong spark plug life.

12-83. ENGINE CONTROLS. Refer to figure 12-10.

12-84. DESCRIPTION. The throttle, mixture and propeller controls are of the push-pull type. The propeller and mixture controls are equipped to lock in any position desired. To move the control, the spring-loaded button, located in the end of the control knob, must be depressed. When the button is released, the control is locked. The propeller and mixture controls also have a vernier adjustment. Turning the control knob in either direction will change the control setting. The vernier is primarily for precision control setting. The throttle control has neither a locking button nor a vernier adjustment, but contains a knurled friction knob which is rotated for more or less friction as desired. The friction knob prevents vibration induced "creeping" of the control. A "Palnut" type locknut is installed in back of the existing locknut at the engine end of the throttle, mixture and propeller controls.

12-85. RIGGING. When adjusting any engine control, it is important to check that the control slides smoothly throughout its full travel, that it locks securely if equipped with a locking device and the arm or lever which it operates moves through its full arc of travel.

CAUTION

Some engine controls have a small retaining ring brazed (or attached with epoxy resin) in a groove .97 inch from the threaded end of the control. The purpose of this retaining ring is to prevent inadvertent withdrawal and possible damage to the knob end of the controls while jam nuts and rod ends are removed.

Whenever engine controls are being disconnected, pay particular attention to the EXACT position, size and number of attaching washers and spacers. Be sure to install attaching parts as noted when connecting controls.

MODEL P210 SERIES SERVICE MANUAL

12-86. THROTTLE CONTROL.

- a. Push throttle control full in. then pull control out approximately 1/8 inch for cushion.
- b. Check that throttle control arm is against the mechanical stop. If necessary, loosen locknut and screw rod end IN or OUT as necessary to align with attachment hole while throttle arm is against the mechanical stop.
- c. Pull control full out and check that throttle arm contacts the idle stop.
- d. The throttle arm must contact the stops in each direction and the control should have approximately 1/8 inch cushion when pushed full in.

NOTE

Refer to the inspection chart in Section 2 for inspection, lubrication and/or inspection interval.

12-87. MIXTURE CONTROL.

- a. Push mixture control full in, then pull control out approximately 1/8 inch for cushion.

- b. Check that mixture control arm is in full rich position (against stop). If necessary, loosen locknut and screw rod end IN or OUT as necessary to align with attachment hole while mixture arm is against the mechanical stop.

- c. Pull control full out and check that mixture arm contacts the idle cut-off stop.


- d. The mixture arm must contact the stops in each direction and the control should have approximately 1/8 inch cushion when pushed full in.

NOTE

Refer to the inspection chart in Section 2 for inspection, lubrication and/or replacement interval.

12-88. PROPELLER CONTROL. Refer to Section 14.

12-89. RIGGING THROTTLE-OPERATED MICRO-SWITCH. Refer to Section 13.



* Torque to 15 ± 2 lb-in.

☆ When torquing nut hold control in this .18" area only.

• • Torque to 20-25 lb-in.

⊛ Install AN356-1032 lock nut behind AN315-3R nuts.

1. Rod End (Throttle Control)
2. Throttle Control Arm
3. Rod End (Mixture Control)
4. Mixture Control Arm
5. Mixture Control
6. Throttle Control
7. Bracket (Typical)
8. Clamp

Safety wire bracket-to-engine mounting bolts to each other.

Figure 12-10. Engine Controls

MODEL P210 SERIES SERVICE MANUAL

12-90. AUXILIARY ELECTRIC FUEL PUMP, FLOW ADJUSTMENT. Refer to Section 13.

12-91. LANDING GEAR WARNING HORN. Refer to Section 5.

12-92. STARTING SYSTEM.

12-93. DESCRIPTION. The automatically-engaged starting system employs an electrical starter motor mounted to a 90-degree adapter. A solenoid is activated by the ignition switch on the instrument panel. When the solenoid is activated, its contacts close and electrical current energizes the motor. Initial rota-

tion of the motor engages the starter through an over-running clutch in the starter adapter, which incorporates worm reduction gears. The starter motor is located just aft of the right rear cylinder.

CAUTION

Never operate the starter motor more than 12 seconds at a time. Allow starter motor to cool between cranking periods to avoid overheating. Longer cranking periods without cooling time will shorten the life of the starter motor.

12-94. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
STARTER WILL NOT OPERATE.	Defective master switch or circuit.	Check continuity. Install new switch or wires.
	Defective starter switch or switch circuit.	Check continuity. Install new switch or wires.
	Defective starter motor.	Check electrical power to motor. Repair or replace starter motor.
STARTER MOTOR RUNS, BUT DOES NOT TURN CRANK-SHAFT.	Defective overrunning clutch or drive.	Check visually. Install new starter adapter.
	Starter motor shaft broken.	Check visually. Install new starter motor.
STARTER MOTOR DRAGS.	Low battery.	Check battery. Charge or install new battery.
	Starter switch or relay contacts burned or dirty.	Install serviceable unit.
	Defective starter motor power cable.	Check visually. Install new cable.
	Loose or dirty connections.	Remove, clean and tighten all terminal connections.
	Defective starter motor.	Check starter motor brushes. brush spring tension, thrown solder on brush cover. Repair or install new starter motor.
	Dirty or worn commutator.	Check visually. Clean and turn commutator.
STARTER EXCESSIVELY NOISY.	Worn starter pinion.	Remove and inspect. Replace starter drive.
	Worn or broken teeth on crankshaft gears.	Check visually. Replace crankshaft gear.

MODEL P210 SERIES SERVICE MANUAL

12-95. **PRIMARY MAINTENANCE.** The starting circuit should be inspected at regular intervals, the frequency of which should be determined by the amount of service and conditions under which the equipment is operated. Inspect the battery and wiring. Check battery for fully charged condition, proper electrolyte level with approved water and terminals for cleanliness. Inspect wiring to be sure that all connections are clean and tight and that the wiring insulation is sound. Check that the brushes slide freely in their holders and make full contact on the commutator. When brushes are worn to one-half of their original length, install new brushes (compare brushes with new brushes). Check the commutator for uneven wear, excessive glazing or evidence of excessive arcing. If the commutator is only slightly dirty, glazed or discolored, it may be cleaned with a strip of No. 00 or No. 000 sandpaper. If the commutator is rough or worn, it should be turned in a lathe and the mica undercut. Inspect the armature shaft for rough bearing surfaces. New brushes should be properly seated when installing by wrapping a strip of No. 00 sandpaper around the commutator (with sanding side out) 1-1/4 to 1-1/2 times maximum. Drop brushes on sandpaper covered commutator and turn armature slowly in the direction of normal rotation. Clean sanding dust from motor after sanding operations.

12-96. STARTER MOTOR.

12-97. REMOVAL AND INSTALLATION

a. Remove engine cowling in accordance with paragraph 12-3.

CAUTION

When disconnecting starter electrical cable, do not permit terminal bolt to rotate. Rotation of the bolt could break the conductor between bolt and field coils causing the starter to be inoperative.

- b. Disconnect battery cables and insulate as a safety precaution.
- c. Disconnect electrical cable at starter motor.
- d. Remove nuts and washers securing motor to starter adapter and remove motor. Refer to engine manufacturer's overhaul manual for adapter removal.
- e. Reverse the preceding steps for reinstallation. Install a new O-ring seal on motor, then install motor. Be sure motor drive engages with the adapter drive when installing.

12-98. EXHAUST SYSTEM. Refer to figure 12-11.

12-99. **DESCRIPTION.** The exhaust system is constructed of Inconel 601 stainless steel. The exhaust system consists of two exhaust stack assemblies, one for the left and one for the right bank of cylinders. These exhaust stack assemblies are joined together to route the exhaust from all cylinders

through the waste-gate or turbine. The three risers on the left bank of cylinders are joined together into a common pipe to form the left stack assembly. The risers on the cylinders are connected to a common pipe to form the right stack assembly. The right stack assembly connects to the left stack assembly at the front of the engine. Mounting pads for the waste-gate and turbine are provided on the right stack assembly. From the exhaust port of the turbine, a tailpipe routes the exhaust overboard through the lower fuselage. The exhaust port of the waste-gate is routed into the tailpipe so the exhaust gas can be expelled from the system when not needed at the turbine. The waste-gate is actuated by the waste-gate actuator which, in turn, is controlled by the waste-gate controller. Also, sleeving is installed on the fuel hose from the engine-driven pump to the fuel metering body and on the hose from the auxiliary fuel pump to the engine-driven pump. This is to prevent excessive heat on these fuel hoses as they route close to the exhaust stack.

12-100. REMOVAL.

- a. Remove engine cowling and right and left nose caps in accordance with paragraph 12-3.
- b. Loosen clamp and disconnect flexible duct at aft end of cabin heater shroud on left exhaust stack.
- c. Remove two screws securing shroud to support brackets.
- d. Remove clamp attaching forward crossover assembly to left exhaust stack assembly.
- e. Remove four nuts and washers attaching exhaust pipe to each cylinder and remove left exhaust stack assembly.
- f. Remove bolts attaching waste-gate to right exhaust stack assembly.
- g. Remove bolts and nuts attaching turbocharger to right exhaust assembly.
- h. Remove EGT probe from exhaust collection.
- i. Remove clamp attaching forward crossover assembly to right exhaust stack assembly.
- j. Remove four nuts and washers attaching exhaust pipe to each cylinder and remove right exhaust stack assembly.

12-101. INSTALLATION.

NOTE

It is important that the complete exhaust system, including the turbocharger and wastegate, be installed without pre-loading any section of the exhaust stack assembly.

Before reassembly of the slip joints, clean the mating surfaces with crocus cloth. The mating surfaces should then be lubricated with Fel-Pro, C5A or ON-OFF.

- a. Use new gaskets between exhaust stacks and engine cylinders, at each end of waste-gate and between turbocharger and exhaust stack.




Figure 12-11. Exhaust system

MODEL P210 SERIES SERVICE MANUAL

b. Loosen turbocharger supporting hardware as required to position the right exhaust stack assembly on cylinders.

c. Install washers and nuts securing exhaust stack assembly to cylinder. torque nuts evenly to 100-110 lb-in.

d. Position turbocharger and install bolts and nuts attaching turbocharger to right exhaust stack (figure 12-15). Tighten bolts securely.

e. Install bolts and nuts attaching waste-gate to right exhaust stack assembly and tighten securely.

f. Install forward crossover assembly on right exhaust stack assembly.

g. Install EGT probe in exhaust collector.

h. Position left exhaust stack assembly and secure with washers and nuts, torque evenly 100-110 lb-in.

i. Connect forward crossover assembly to left exhaust stack assembly with clamp.

j. Install two screws securing cabin heater shroud to support brackets.

k. Connect flexible duct to aft end of cabin heater shroud and tighten clamp.

l. Be sure all parts are secure and safetied as required, then perform step "b" of paragraph 12-105 to check for air leaks.

m. Reinstall any parts removed for access, then install nose caps and cowling.

12-102. INSPECTION. Since exhaust systems of this type are subject to burning, cracking and general deterioration from alternate thermal stresses and vibrations, inspection is important and should be accomplished every 50 hours of operation. Also, a thorough inspection of the engine exhaust system should be made to detect cracks causing leaks which could result in loss of optimum turbocharger efficiency and engine power. To inspect the engine exhaust system proceed as follows:

a. Remove engine cowling as required and remove heater shroud so that ALL surfaces of the exhaust assemblies can be visually inspected.

WARNING

Never use highly flammable solvents on engine exhaust systems. Never use a wire brush or abrasives to clean exhaust systems or mark on the system with lead pencils.

NOTE

Especially check the areas adjacent to welds and slip joints. Look for gas deposits in surrounding areas, indicating that exhaust gases are escaping through a crack or hole or around the slip joints.

b. After visual inspection, an air pressure test should be made on the exhaust system as follows:

1. Attach the pressure side of an industrial vacuum cleaner to the tailpipe opening, using a rubber plug to effect a seal as required.

NOTE

The inside of the vacuum cleaner hose should be free of any contamination that might be blown into the engine exhaust system.

2. With vacuum cleaner operating, all joints in the exhaust system and the heat exchanger area may be checked manually by feel, or by using a soap and water solution and watching for bubbles. The exhaust manifold in the heat exchanger area must be free of air leaks. In other areas, forming of bubbles is acceptable; however, if bubbles are blown away system is not acceptable. Also, some bubbles will appear at the joint of the turbocharger turbine and compressor bearing housing.

c. Where a surface is not accessible for a visual inspection, or for a more positive test, the following procedure is recommended.

1. Remove exhaust stack assemblies.

2. Use rubber expansion plugs to seal openings.

3. Using a manometer or gage, apply approximately 1-1/2 psi (3 inches of mercury) air pressure while each stack assembly is submerged in water. Any leaks will appear as bubbles and can be readily detected.

d. It is recommended that any components of the exhaust system found defective be replaced before the next flight.

e. After installation of exhaust system components, recheck by performing the air pressure test to make sure that system is acceptable.

12-103. TURBOCHARGER.

NOTE

For additional information covering turbocharger and component maintenance, overhaul and trouble shooting refer to the Manufacturer's Overhaul Manual.

12-104. DESCRIPTION. The turbocharger is an exhaust gas-driven compressor, or air pump, which provides high velocity air to the engine intake manifold. The turbocharger is composed of a turbine wheel, compressor wheel, turbine housing and compressor housing. The turbine, compressor wheel and interconnecting drive shaft comprise one complete assembly and are the only moving parts in the turbocharger. Turbocharger bearings are lubricated with filtered oil supplied from the engine oil system. Engine exhaust gas enters the turbine housing to drive the turbine wheel. The turbine wheel, in turn, drives the compressor wheel, producing a high velocity of air entering the engine induction intake manifold. Exhaust gas is then dumped overboard through the exhaust outlet of the turbine housing and exhaust tailpipe. Air is drawn into the compressor through the induction air filter and is forced out of the compressor housing through a tangential outlet to the intake manifold. The degree of turbocharging is varied by means of a waste-gate valve, which varies the amount of exhaust gas allowed to bypass the turbine.

MODEL P210 SERIES SERVICE MANUAL




Figure 12-12. Turbocharger System Schematic

MODEL P210 SERIES SERVICE MANUAL

12-105. REMOVAL, REPLACEMENT AND INSTALLATION. Refer to figure 12-14. The following procedures should be used in conjunction with the Manufacturer's Overhaul Manual.

- a. Remove right-hand upper and lower cowling.

CAUTION

Plug or tape all open lines and fittings, to, from, or on the turbocharger.

- b. Disconnect drain line from wastegate actuator. Loosen the tailpipe clamp. Remove the tailpipe (7) from the turbine housing (8) and the wastegate assembly.
- c. Disconnect line assemblies (2) and (10) from adapters (9) and (12).
- d. Loosen clamps and remove air inlet and outlet ducts from the turbocharger compressor (11).
- e. Remove four bolts (15) attaching turbocharger to exhaust collector (5).
- f. Remove bolts (4), (6) and (17) securing the turbocharger support brackets and remove the turbocharger.
- g. Remove oil inlet (12) and outlet (9) adapters from turbocharger, discard both gaskets, retain the bolts and washers.
- h. Loosen turbine housing bolts (19, a, b, c, and d).
- i. Remove bolts (19, a, b and c) and remove support (16).

NOTE

With turbocharger removed check exhaust collector flange for flatness. Flange is to be flat within .005", resurface the exhaust collector flange as required.

- j. On the new turbocharger, loosen turbine housing bolts (19, a, b, c and d) and remove bolts (19, a, b and c).

CAUTION

Clamp plates must be installed between turbocharger and support (16). Lock plates (18) must be installed between support (16) and bolt heads (19).

- k. Install support (16).
- l. Snug bolts (19, a, b, c and d).

NOTE

DO NOT LOOSEN bolts (19, e and f) so support may be adjusted as required.

DO NOT bend up lock tabs.

m. Remove tape from adapters (9 and 12) and install with new gaskets and retained bolts and washers. Torque bolts to 180-190 pound-inches and safety.

- n. Insert bolts (4) thru bracket (3) and support (16).
- o. Tighten bolts (19, a, b, c and d) so bracket (16) will not slip, this will maintain alignment for bolts (4).
- p. Remove bolts (4) and remove turbocharger.
- q. Torque turbine housing bolts (19, a, b, c, d, e, and f) and 220-250 pound-inches and bend up lock tabs.
- r. Reinstall turbocharger and insert bolts (4), install exhaust collector (5) on turbine housing (8), insert bolts (15) and (6) thru turbocharger support. Install washers and nuts, tighten.
- s. Connect hose assemblies (2) and (10).
- t. Install inlet and outlet ducts and secure with clamps.
- u. When installing discharge duct (1) loosen compressor housing V-band clamp enough to allow for proper fit. Secure clamp and torque nut to 40-60 pound-inches.

NOTE

Be sure all clamps are installed with bolts on the outboard side for easier access.

- v. Install tailpipe (7) and secure with existing clamp to turbine housing (8), torque nut to 40-60 pound-inches. A slip joint is used to attach the tailpipe to the wastegate assembly.
- w. Connect drain line to wastegate actuator.

12-106. VARIABLE CONTROLLER AND WASTE GATE ACTUATOR.

12-107. FUNCTIONS. The wastegate and variable controller use filtered engine oil for supply power to control turbocharger. The wastegate is used to control engine exhaust flow through the turbine and regulate its speed. Since the exhaust energy is the force that drives the turbocharger unit, the output of the compressor is controlled by bleeding or dumping of excess exhaust energy as needed. The wastegate actuator, which is physically connected to the wastegate by mechanical linkage, controls the position of the wastegate butterfly valve. The butterfly valve position is controlled by the variable controller. Engine oil is supplied to the wastegate actuator through the capillary tube where the pressure of oil determines the position of the valve. The variable controller cam arm is connected to the throttle linkage and controls the output of the compressor discharge pressure.

MODEL P210 SERIES SERVICE MANUAL

12-108. OPERATION. The wastegate actuator is spring-loaded to position the wastegate to the normally open position when there is not adequate oil pressure in the wastegate actuator power cylinder during engine shut down. When the engine is started, oil pressure is fed into the wastegate actuator power cylinder through the capillary tube. This automatically fills the wastegate actuator power cylinder and lines leading to the controllers, blocking the flow of oil by normally closed metering and/or poppet valves. As oil pressure builds up in the wastegate actuator power cylinder, it overcomes the force of the wastegate open spring, closing the wastegate. When the wastegate begins to close, the exhaust gases are routed through the turbocharger turbine. As the engine increases its power and speed, the increase of temperature and pressure of the exhaust gases causes the turbocharger to rotate faster, raising the turbocharger compressor outlet pressure. As the compressor outlet pressure rises, the aneroid bellows and the absolute pressure controller sense the increase in pressure. When at high engine speed and load and the proper absolute pressure is reached, the force on the aneroid bellows opens the normally closed metering valve. When the oil pressure in the wastegate actuator power cylinder is lowered sufficiently, the wastegate actuator open spring forces the mechanical linkage to open the wastegate. A portion of the exhaust gases then bypasses the turbocharger turbine, thus preventing further increase of turbocharger speed and holding the compressor discharge absolute pressure to the desired value. Conversely, at engine idle, the turbocharger runs slowly with low compressor pressure output; therefore, the low pressure applied to aneroid bellows is not sufficient to affect the unseating of the normally closed metering valve. Consequently, engine oil pressure keeps the wastegate closed. The overboost control valve acts as a pressure relief valve and will open to prevent an excessive pressure increase to the throttle body.

NOTE

If wastegate movement is sluggish apply either, Kano Aero Kroil (Kano Laboratories, 1000 S. Thompson Lane, Nashville, Tennessee 37211) or Mouse Milk Penetrating Oil (Worldwide Aircraft Filter Corporation, 1685 Abram Court, San Leandro, California 94577) to both EXTERNAL ends of the wastegate shaft. Actuate until smooth operation is obtained. Remove residue.

CAUTION

The turbocharged engine installation is equipped with a controller system which automatically controls the engine within prescribed manifold pressure limits. Although these automatic controller systems are very reliable and eliminate the need for manual control through constant throttle manipulation, they are not infallible. For instance, such things as rapid throttle manipulation (especially with cold oil), momentary wastegate sticking, air in the oil system of the controller, etc, can cause overboosting.

Consequently, it is still necessary that the pilot observe and be prepared to control the manifold pressure, particularly during take-off and power changes in flight.

The slight overboosting of manifold pressure beyond established maximums, which is occasionally experienced during initial take-off roll or during a change to full throttle operation in flight, is not considered detrimental to the engine as long as it is momentary. Momentary overboost is generally in the area of 2 to 4 inches and can usually be controlled by slower throttle movement. No corrective action is required where momentary overboosting corrects itself and is followed by normal engine operation. However, if overboosting of this nature persists, or if the amount of overboost goes as high as 6 inches, the controller and overboost control should be checked for necessary adjustment or replacement of the malfunctioning component.

CAUTION

OVERBOOST EXCEEDING 6 INCHES beyond established maximums is excessive and can result in engine damage. It is recommended that overboosting of this nature be reported to your Cessna Dealer, who will be glad to determine what, if any, corrective action needs to be taken.

MODEL P210 SERIES SERVICE MANUAL

12-109. VARIABLE CONTROLLER ADJUSTMENT.
See figure 12-13.

- a. Remove engine cowling for access.
- b. Advance throttle to full open position (throttle arm against full open stop, on aft side of throttle body.)
- c. With throttle full open, the controller must be spring loaded against high setting stop (6).
- d. Adjust linkage if required to obtain .020 to .040 gap and .52 to .57 compressed spring (11) length.

NOTE

Verify that the controller arm is attached firmly to the controller shaft and that the throttle arm is attached firmly to the throttle shaft.

e. HIGH PRESSURE SETTING.

1. For high pressure setting, start engine and warm-up, with oil temperature at the upper third of the green arc, accelerate the engine gradually to maximum power.

CAUTION

Discontinue acceleration if the manifold pressure exceeds 39 inch Hg or if maximum RPM is exceeded. Maximum manifold at full throttle should read $37 \pm .5$ inch Hg, if not proceed with the following steps.

WARNING

Engine must NOT be running while making adjustments, for safety.

2. Reduce power to idle, shut down engine.
3. Holding high pressure adjustment screw (2), to prevent change of setting, loosen locknut (1).

NOTE

During adjustment, the fork and pin (7) should move in the direction of the cam arm UP, marking (5), to increase manifold pressure and DN to decrease manifold pressure.

4. Rotate screw (2) counterclockwise to increase manifold pressure and clockwise to decrease manifold

pressure. Approximately one complete turn of screw (2) should provide a 1 inch Hg variation of manifold pressure.

5. Repeat adjustments as required to obtain a setting within $37 \pm .5$ inch hg, and tighten locknut (1) taking care to hold screw (2) at the proper setting.

f. LOW PRESSURE SETTING AND CAM ANGLE VERIFICATION.

NOTE

Prior to adjusting the controller low pressure stop, install a calibrated manifold pressure gage to read compressor discharge pressure.

1. A tee fitting with one port capped, is installed at the fuel flow gage in the compressor discharge pressure line. Remove the cap and connect the calibrated manifold pressure gage to this tee. The pressure gage may also be connected where the discharge pressure line connects to the distribution block on the engine, located outboard of the left hand accessory pad.

g. ADJUSTMENT PROCEDURE.

1. Start engine and warm-up until oil temperature is at the upper third of green arc.
2. Adjust the propeller control to maintain a constant 2200 RPM.
3. Adjust throttle control to maintain manifold pressure at 29 inch Hg.
4. Compressor discharge pressure should read $32.2 \pm .5$.
5. Should adjustment be necessary, shut down engine before making adjustment.

NOTE


Approximately 1/4th turn of adjustment screw (9) should provide a 1 inch Hg variation of compressor discharge pressure.

6. If pressure is too high, loosen locknut (8) and turn low pressure adjustment screw (9) counterclockwise to decrease pressure. After adjustment tighten locknut (8).

7. If pressure is too low loosen locknut (8) and turn low pressure adjustment screw (9) clockwise to increase pressure. After adjustment tighten locknut (8).

8. Start engine and repeat steps (1) thru (4).

MODEL P210 SERIES SERVICE MANUAL



- 1. Locknut
- 2. High Pressure Adjustment Screw
- 3. Variable Controller
- 4. Arm
- 5. Low Pressure Reference Markings
- 6. High Pressure Setting Stop
- 7. Fork and Pin Assembly
- 8. Locknut
- 9. Low Pressure Adjustment Screw
- 10. Nut
- 11. Spring
- 12. Jamnuts
- 13. Control

Figure 12-13. Variable Controller Adjustment.

MODEL P210 SERIES SERVICE MANUAL

12-110. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
UNABLE TO GET RATED POWER BECAUSE MANIFOLD PRESSURE IS LOW.	Controller not getting enough oil pressure to close the wastegate.	Check oil pump outlet pressure, oil filter and external lines for obstructions. Clean lines and replace if defective. Replace oil filter.
	Controller out of adjustment or defective	Refer to paragraph 12-109. Replace controller if defective.
	Defective actuator.	Refer to paragraph 12-113. Replace actuator if defective.
	Leak in exhaust system.	Check for cracks and other obvious defects. Replace defective components. Tighten clamps and connections.
	Leak in intake system.	Check for cracks and loose connections. Replace defective components. Tighten all clamps and connections.
ENGINE SURGES OR SMOKES.	Defective controller.	Refer to paragraph 12-112. Replace if not adjustable.
	Wastegate actuator linkage binding.	Refer to paragraph 12-114.
	Wastegate actuator leaking oil.	Replace actuator.
TURBOCHARGER NOISY WITH PLENTY OF POWER.	Turbocharger overspeeding from defective or improperly adjusted controller.	Refer to paragraph 12-109. Replace if defective.
	Wastegate sticking closed.	Correct cause of sticking. Refer to paragraph 12-113. Replace defective parts.
	Controller drain line (oil return to engine sump) obstructed.	Clean line. Replace if defective.
ENGINE POWER INCREASES SLOWLY OR SEVERE MANIFOLD PRESSURE FLUCTUATIONS WHEN THROTTLE IS ADVANCED RAPIDLY.	Overboost control valve out of adjustment or defective.	Replace if defective.
	Wastegate operation is sluggish.	Refer to paragraph 12-113. Replace if defective. Correct cause of sluggish operation.
ENGINE POWER INCREASES RAPIDLY AND MANIFOLD PRESSURE OVERBOOSTS WHEN THROTTLE IS ADVANCED RAPIDLY.	Overboost control valve out of adjustment or defective.	Replace if defective.
	Wastegate operation is sluggish.	Refer to paragraph 12-113. Replace if defective. Correct cause of sluggish operation.

MODEL P210 SERIES SERVICE MANUAL

12-110. TROUBLE SHOOTING (Cont)

TROUBLE	PROBABLE CAUSE	REMEDY
FUEL PRESSURE DECREASES DURING CLIMB, WHILE MANIFOLD PRESSURE REMAINS CONSTANT.	Compressor discharge pressure line to fuel pump aneroid restricted.	Check and clean out restrictions.
	Leaking or other wise defective engine-driven fuel pump aneroid.	Replace engine-driven fuel pump.
MANIFOLD PRESSURE DECREASES DURING CLIMB AT ALTITUDES BELOW NORMAL FULL THROTTLE CRITICAL ALTITUDE, OR POOR TURBOCHARGER PERFORMANCE INDICATED BY CRUISE RPM FOR CLOSED WASTEGATE. (Refer to paragraph 12-108 and 12-111.)	Leak in intake system.	Check for cracks and other obvious defects. Tighten all hose clamps and fittings. Replace defective components.
	Leak in exhaust system.	Check for cracks and other obvious defects. Tighten all clamps and fittings. Replace defective components.
	Leak in compressor discharge pressure line to controller.	Check for cracks and other obvious defects. Tighten all clamps and fittings. Replace defective components.
	Controller seal leaking.	Replace controller.
	Wastegate actuator leaking oil.	Replace actuator.
	Wastegate butterfly - closed gap is excessive.	Refer to paragraph 12-114.
	Intake air filter obstructed.	Service air filter. Refer to Section 2 for servicing instructions.
FUEL FLOW DOES NOT DECREASE AS MANIFOLD PRESSURE DECREASES AT PART-THROTTLE CRITICAL ALTITUDE.	Defective engine-driven fuel pump aneroid mechanism.	Replace engine-driven fuel pump.
	Obstruction or leak in compressor discharge pressure line to engine-driven fuel pump.	Check for leaks or obstruction. Clean out lines and tighten all connections.
FUEL FLOW INDICATOR DOES NOT REGISTER CHANGE IN POWER SETTINGS AT HIGH ALTITUDES.	Moisture freezing in indicator line.	Disconnect lines, thaw ice and clean out lines.
SUDDEN POWER DECREASE ACCOMPANIED BY LOUD NOISE OF RUSHING AIR.	Intake system air leak from hose becoming detached.	Check hose condition. Install hose and hose clamp securely.
MANIFOLD PRESSURE GAGE INDICATION WILL NOT REMAIN STEADY AT CONSTANT POWER SETTINGS.	Defective controller.	Replace controller.
	Wastegate operation is sluggish.	Refer to paragraph 12-113. Replace if defective. Correct cause of sluggish operation.

MODEL P210 SERIES SERVICE MANUAL




Figure 12-14. Turbocharger Installation

MODEL P210 SERIES SERVICE MANUAL




Figure 12-15. Controller And Waste-Gate Installation

MODEL P210 SERIES SERVICE MANUAL

12-111. CONTROLLER. FUEL FLOW AND TURBOCHARGER OPERATIONAL FLIGHT CHECK. The following procedure details the method of checking the operation of the variable controller, overboost valve and a performance check of the turbocharger.

①

TAKE-OFF - VARIABLE CONTROLLER FULL THROTTLE CHECK.

- a. Cowl Flaps - Open.
- b. Airspeed - 110-120 KIAS.
- c. Oil Temperature - Middle of green arc.
- d. Engine Speed - 2700 \pm 25 RPM.
- e. Fuel Flow (Full Rich Mixture) 220 to 225 LBS/HR.
- f. Full Throttle M. P. - Controller should maintain 37.0 -0, +5.

Climb 2000 feet after take-off to be sure manifold pressure has stabilized.

②

NORMAL POWER CLIMBS, FULL RICH FUEL FLOW CHECKS. (Conduct immediately after Item 1 check).

- a. Cowl Flaps - Open.
- b. Airspeed - 110-120 KIAS.
- c. Engine Speed - 2500 RPM.
- d. M. P. - 37 and 30 in. Hg.
- e. Fuel Flow (Full Rich Mixture - MINIMUM of 195 and 145 PPH, respectively.

③

NORMAL CLIMB - VARIABLE CONTROLLER STABILITY CHECK.

- a. Cowl Flaps - Open.
- b. Airspeed - 110-120 KIAS.
- c. Engine Speed - 2500 RPM.
- d. Fuel Flow - Adjust mixture for 140 LBS/HR.
- e. Part-Throttle M. P. - 30.0 in. Hg.
- f. Climb to 10,000 feet - Check during climb.

Once the normal climb power setting is established after take-off, the controller should maintain a steady manifold pressure of no more than 0.75 in. Hg. M. P. rise up to 10,000 feet.

④

CRUISE - VARIABLE CONTROLLER LOW SETTING CHECK.

- a. Cowl Flaps - Closed.
- b. Airspeed - Level Flight.
- c. Pressure Altitude - 10,000 Feet.
- d. Engine Speed - 2500 RPM.
- e. Part Throttle M. P. - 30 and 26 in. Hg.
- f. Fuel Flow - Lean to 140 and 115 PPH, respectively.
- g. Deck Pressure - 33.5 \pm 0.5 and 33.0 \pm 0.5 in. Hg. respectively.

NOTE

A calibrated manifold pressure gage will be required to be installed in the airplane to read turbocharger discharge (deck) pressure. The gage will be attached to the tee fitting on the back of the fuel flow gage.

⑤

CRUISE-VARIABLE CONTROLLER AND TURBOCHARGER PERFORMANCE CHECK.

- a. Cowl Flaps - Closed.
- b. Airspeed - Level Flight.
- c. Pressure Altitude - 17,000 Feet.
- d. Engine Speed - 2700 RPM.
- e. Part-Throttle M. P. - 30 in. Hg.
- f. Fuel Flow - Lean to 164 LBS/Hr.
- g. Propeller Control -
 - (1) Slowly decrease RPM until manifold pressure starts to drop, indicating wastegate is closed.

NOTE

If the wastegate closes at engine speeds lower than shown on the chart in figure 12-15, the turbocharger performance is normal. If the wastegate closes at engine speeds higher than shown in figure 12-15, refer to the trouble shooting chart in paragraph 12-110.

MODEL P210 SERIES SERVICE MANUAL




Figure 12-16. Operational Flight Check

- (2) Note outside air temperature and RPM as manifold pressure starts to drop, which should be in accordance with the chart in figure 12-16.
- (3) After noting temperature and RPM, increase engine speed 50 RPM to stabilize manifold pressure, with the wastegate modulating exhaust flow to control compressor output.

- (6) **MCP CLIMB - VARIABLE CONTROLLER AND TURBOCHARGER PERFORMANCE CHECK.**
 - a. Cowl Flaps - Open.
 - b. Airspeed - 110-120 KIAS.
 - c. Engine Speed - 2700 RPM.
 - d. Fuel Flow - 220 PPH. Above critical altitude, adjust for M. P. in accordance with climb schedule on fuel flow gage.
 - e. Throttle - As required to maintain 37 in. Hg M. P.
 - f. Climb to 23,000 feet - Check full throttle critical altitude during climb.

NOTE

The full throttle critical altitude is where manifold pressure starts decreasing below 37.0 in. Hg during the climb at a rate of approximately 1.0 in. Hg per 1000 feet. Note this altitude and the outside air temperature. If full throttle critical altitude has not been reached by 23,000 feet, discontinue check.

Outside Air Temperature

20°F Below Standard
 Standard Temperature
 20°F Above Standard
 40°F Above Standard

Full-Throttle Critical Altitude (MCP)

21,000 feet
 20,500 feet
 20,000 feet
 19,500 feet

Full-throttle critical altitudes lower than those listed indicate the turbocharger system is not operating properly (Refer to trouble shooting chart in paragraph 12-110). Critical altitudes above those listed indicate turbocharger performance better than normal. However, critical altitudes beyond 2000 feet above those listed may indicate that the wastegate gap is too small. Also check that fuel flow decreases as manifold pressure decreases at critical altitude. Refer to trouble shooting chart if fuel flow does not decrease.

MODEL P210 SERIES SERVICE MANUAL

12-112. REMOVAL AND INSTALLATION OF TURBOCHARGER CONTROLLER.

- a. Disconnect and tag oil lines from controller and plug or cap open lines and fittings.
- b. Disconnect compressor outlet pressure sensing line from controller and plug or cap open line and fitting.
- c. Remove two bolts attaching controller to mounting bracket on firewall.
- d. Remove controller from aircraft, being careful not to drop controller unit.
- e. Installation of the controller may be accomplished by reversing the preceding steps. Resafety bolt attaching controller to bracket.

12-113. REMOVAL AND INSTALLATION OF WASTEGATE AND ACTUATOR.

- a. Disconnect and tag oil lines from actuator and plug or cap open lines and fittings.
- b. Remove bolts, washers and nuts attaching wastegate and actuator assembly to tailpipe.
- c. Loosen clamp attaching tailpipe to turbine exhaust outlet and work tailpipe from turbine.
- d. Remove bolts, washers and nuts attaching the assembly to the exhaust manifold.
- e. Remove the assembly from aircraft, being careful not to drop the unit.
- f. Installation may be accomplished by reversing the preceding steps.

NOTE

When installing the assembly, be sure the gaskets at inlet and outlet of valve are installed and are in good condition. Replace gaskets if damaged.

12-114. ADJUSTMENT OF WASTEGATE ACTUATOR. Refer to the Manufacturer's Overhaul manual.

12-115. EXTREME WEATHER MAINTENANCE.

12-116. COLD WEATHER. Cold weather starting will be made easier by the installation of an engine primer system and a ground service receptacle. The primer system is manually operated from the cabin. Fuel is supplied by a line from the fuel strainer to the plunger. Operating the primer forces fuel to the engine. With an external power receptacle installed an external power source may be connected to assist in cold weather or low battery starting. The following may also be used to assist engine starting in extremely cold weather. After the last flight of the day, drain the engine oil into a clean container so the oil can be preheated. Cover the engine to prevent ice or snow from collecting inside the cowl. When preparing the aircraft for flight or engine run-up after these conditions have been followed, preheat the drained engine oil.

WARNING

Do not heat the oil above 121°C (250°F). A flash fire may result. Before pulling the propeller through, ascertain that the magneto switch is in the OFF position to prevent accidental firing of the engine.

After preheating the engine oil, gasoline may be mixed with the heated oil in a ratio of 1 part gasoline to 12 parts engine oil before pouring into the engine oil sump. If the free air temperature is below minus 29°C (-20°F), the engine compartment should be preheated by a ground heater. Pre-heating the engine compartment is accomplished by inducing heated air up through the cowl flap openings; thus heating both the oil and the cylinders. After the engine compartment has been preheated, inspect all engine drain and vent lines for presence of ice. After this procedure has been complied with, pull propeller through several revolutions by hand before attempting to start the engine.

CAUTION

Due to the desludging effect of the diluted oil, engine operation should be observed closely during the initial warm-up of the engine. Engines that have considerable amount of operational hours accumulated since their last dilution period may be seriously affected by the dilution process. This will be caused by the diluted oil dislodging sludge and carbon deposits within the engine. This residue will collect in the oil sump and possibly clog the screened inlet to the oil sump. Small deposits may actually enter the oil sump and be trapped by the main oil filter screen. Partial or complete loss of engine lubrication may result from either condition. If these conditions are anticipated after oil dilution, the engine should be run for several minutes at normal operating temperatures and then stopped and inspected for evidence of sludge and carbon deposits in the oil sump and oil filter screen. Future occurrence of this condition can be prevented by diluting the oil prior to each engine oil change. This will also prevent the accumulation of the sludge and carbon deposits.

Refer to Average Ambient Temperature (°F) Oil Grade chart in Section 2, for the correct grade of engine oil for the ambient temperature.

12-117. HOT WEATHER. Refer to Pilot's Operating Handbook.

12-118. SEACOAST AND HUMID AREAS. In salt water areas special care should be taken to keep the engine, accessories and airframe clean to prevent oxidation. In humid areas, fuel and oil should be checked frequently and drained of condensation to prevent corrosion.

12-119. DUSTY AREAS. Dust induced into the intake system of the engine is probably the greatest single cause of early engine wear. When operating in high dust conditions, service the induction air filters daily as outlined in Section 2. Also change engine oil and lubricate airframe items more often than specified.

MODEL P210 SERIES SERVICE MANUAL

SECTION 13

FUEL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
FUEL SYSTEM	2D5/13-1	Alternate Method	2D20/13-14
Description	2D5/13-1	Fuel Reservoir	2D23/13-17
Precautions	2D6/13-2	Description	2D23/13-17
Trouble Shooting	2D60/13-2	Removal/Installation	2D23/13-17
Fuel Bays	2D7/13-3	Auxiliary Fuel Pump	2D23/13-17
Description	2D7/13-3	Description	2D23/13-17
Leaks	2D7/13-3	Removal/Installation	2D23/13-17
Classification	2D7/13-3	Auxiliary Fuel Pump Circuit	2D23/13-17
Purging	2D7/13-3	Microswitch Rigging	2D23/13-17
Fuel Bay Sealant	2D11/13-7	Auxiliary Pump Flow	
Mixing Sealant	2D11/13-7	Adjustment	2E3/13-21
Sealing	2D11/13-7	High Boost Check	2E4/13-22
Sealing Fuel Leaks	2D11/13-7	Fuel ON-OFF Valve	2E4/13-22
Normal Cure Time	2D14/13-10	Description	2E4/13-22
Normal Work Time	2D15/13-10A	Removal/Installation	2E4/13-22
Integral Fuel Bay		Disassembly, Repair	
Quick Repair Sealant	2D15/13-10A	and Reassembly	2E4/13-22
Surface Preparation	2D15/13-10A	Fuel Strainer	2E4/13-22
Mixing Sealant	2D15/13-10A	Description	2E4/13-22
Testing Integral Fuel Bay	2D15/13-10A	Disassembly/Reassembly	2E4/13-22
Fuel Vents	2D17/13-11	Fuel Filler Caps	2E4/13-22
Description	2D17/13-11	Description	2E4/13-22
Removal/Installation	2D17/13-11	Inspection	2E8/13-24
Checking	2D17/13-11	Cleaning	2E8/13-24
Fuel Quantity Indicating	2D17/13-11	Reassembly	2E10/13-26
Description	2D17/13-11	Leak Testing Fuel Filler Caps	2E10/13-26
Fuel Selector Valve	2D17/13-11	PRIMING SYSTEM	2E11/13-27
Description	2D17/13-11	Description	2E11/13-27
Removal/Installation	2D17/13-11	Removal/Installation	2E11/13-27
Disassembly, Repair			
and Reassembly	2D20/13-14		
Leak Test	2D20/13-14		

13-1. FUEL SYSTEM. The fuel system as defined by this manual includes all components up to and including the fuel line connecting the engine driven pump inlet. Engine mounted components are covered in Section 12.

13-2. DESCRIPTION. The fuel system is essentially a gravity-flow system from the bay outlets to the selector valve and a pump augmented system from the selector valve to the engine. A fuel supply line, a vapor return line and a vent line routed down each forward door post. A fuel supply line with a vent line are routed down each rear door post. The fuel bays are vented by a crossover vent line which is also connected to the vent lines in each forward door post, wing tip vents and vented fuel caps. The fuel lines from the firewall to the strainer and the strainer to the tunnel fitting are stainless steel with insulating sleeving. The fuel hose from the fuel pumps to the check valve, and from the check valve to the firewall, and fuel pump to tunnel fitting are fire sleeved hose. The standard and extended range fuel systems are the same except for the additional fuel bay in the outer end of each wing on the extended range fuel system.

The upper segment of the three position (LEFT ON, BOTH ON, RIGHT ON) fuel selector valve handles fuel from the bays. The lower segment handles vapor, along with returned and excess fuel from the engine-driven fuel pump.

The reservoir stores fuel from the selector valve, bay drain and vent lines. The fuel flows from the reservoir through a by-pass in the auxiliary fuel pump (when the pump is not in operation) to the fuel ON-OFF valve.

The fuel ON-OFF valve provides a means of stopping fuel flow to the STRAINER and the engine driven fuel pump. The fuel ON-OFF control is mounted on the left side of the pedestal.

The fuel STRAINER, mounted on the firewall incorporates a remote drain valve. This valve is mounted on the lower, left, engine cowling at the aft end of the cowl flap. The drain valve is activated by the fuel sampler cup.

MODEL P210 SERIES SERVICE MANUAL

13-3. PRECAUTIONS. Observe the following general precautions and rules during fueling, defueling, tank or integral fuel bay purging, repairing, assembly or disassembly of system components, and electrical system checks and repairs on the airplane fuel system:

WARNING

DURING ALL FUELING PROCEDURES, FIRE-FIGHTING EQUIPMENT MUST BE AVAILABLE. TWO GROUND WIRES FROM DIFFERENT POINTS ON THE AIRPLANE TO SEPARATE APPROVED GROUND STAKES SHALL BE USED TO PREVENT ACCIDENTAL DISCONNECTION OF ONE GROUND WIRE. ENSURE THAT FUELING NOZZLE IS GROUNDED TO THE AIRPLANE.

a. Tie-down rings should be used as grounding points for all grounding wires during re-fueling procedures.

b. Plugs or caps should be placed on all disconnected hoses, lines, and fittings to prevent residual fuel drainage, thread damage, or entry of dirt or foreign material into fuel system.

c. Damage to the fuel system can occur from foreign material in system, or unprotected lines and fittings when disconnected. Caps or covers should always be used.

NOTE

Use NS-40 (RAS-4) (Snap-On-Tools Corp., Kenosha, WI 53140) or MIL-T-5544 (Thread Compound, Antiseize, Graphite Petrolatum), USP Petrolatum, or engine oil as a thread lubricant or to seal leaking connections. Apply sparingly to male threads only, omitting first two to prevent entry into fuel system. Use only a fuel soluble lubricant on fitting threads. DO NOT use lubricants or compounds on injection system fittings or threads.

13-4. TROUBLE SHOOTING.

This table to be used in conjunction with trouble shooting chart in Section 12.

TROUBLE	PROBABLE CAUSE	REMEDY
NO FUEL QUANTITY INDICATION.	Fuel bays empty.	Service with proper fuel.
	Open or defective circuit breaker.	Reset, or replace if defective.
	Open circuit due to wiring or connections.	Tighten connections or replace defective wiring.
	Defective indicator, transmitter	Refer to Section 16.
NO FUEL FLOW TO ENGINE DRIVEN PUMP.	Fuel selector or fuel ON-OFF valve turned off.	Turn ON.
	Fuel strainer plugged.	Clean strainer.
	Fuel bay outlet screen plugged.	CAUTION Drain bay. Remove and clean screens, and flush bay.
	Defective fuel selector valve.	CAUTION Drain bays. Repair or replace selector valve.
	Fuel line plugged.	CAUTION Drain bay. Remove, repair, and reinstall line.

MODEL P210 SERIES SERVICE MANUAL

13-4. TROUBLE SHOOTING (CONT).

TROUBLE	PROBABLE CAUSE	REMEDY
NO FUEL FLOW WHEN ELECTRIC PUMP OPERATED.	Defective fuel pump switch.	Replace defective switch.
	Open circuit due to broken wiring or loose connections.	Repair circuit or tighten connections.
	Defective electric fuel pump.	Replace pump.
	Defective bypass or relief valve in engine driven pump.	Remove and replace engine driven fuel pump.
FUEL STARVATION AFTER STARTING.	Plugged fuel bay vent.	Refer to paragraph 13-9.
	Water in fuel.	Drain fuel bay sumps, lines, and strainer.
	Malfunction of engine driven fuel pump or injection system.	Refer to Section 12.
FLUCTUATING FUEL PRESSURE INDICATION.	Obstructed filters or screens.	Remove, check, and clean, proceeding from most accessible to least.
	Manifold valve defective.	Replace defective valve.
	Fuel flow indicator defective.	Replace defective indicator.

13-5. FUEL BAYS. Fuel bays are those integral portions of the wet wing aircraft that form fuel cells.

13-6. DESCRIPTION. Aircraft with cantilever wings have an inboard section of each wing forward of the main spar sealed to form an integral fuel bay area. The bay consists of a front and rear fuel spar, inboard, outboard, and intermediate ribs and stringers. The extended range wing has a fuel bay between station 172.00 and station 206.00. A fuel channel connects the outboard bay with the inboard bay. A flapper valve at the outboard bay end of the channel prevents fuel from flowing from the inboard bay to the outboard bay when the aircraft is in a turn, or a low wing attitude.

On the standard range a standpipe at the bay filler acts as a visual aid, when loading fuel, to indicate quantity of fuel on board. For a reduced load, fill to bottom edge of filler collar. On the extended range a graduated marker is installed just aft of the filler, marked A, B, C.

13-7. FUEL BAY LEAKS.

13-8. CLASSIFICATION OF FUEL LEAKS. Fuel leaks which do not constitute a flight hazard are stained, seeps and heavy seeps NOT in an enclosed area. However, they should be repaired when the aircraft is grounded for other maintenance. Fuel leaks which constitute a flight hazard are running leaks in any area, seeps, heavy seeps or stains in

an enclosed area, such as the wing leading edge, the sections of wing inboard and outboard of the fuel bay and the area between the rear fuel spar and the main spar. These leaks must be repaired before that bay is used for another flight. The wet or stained spot on the wing in the area of the bay is an indication of the intensity of the leak. Fuel leak classifications are shown in figure 13-4.

NOTE

Stains and seeps that are not considered a flight hazard must be inspected after each flight to ensure that they have not grown in intensity to the point of causing a flight hazard.

Should a flight-hazard leak occur in an area where there are no adequate repair facilities, then the affected bay should be drained, the leak temporarily repaired, and the aircraft flown immediately to an adequate repair facility by using the opposite fuel supply.

13-9. FUEL BAY PURGING.

WARNING

Purge fuel bays with an inert gas prior to repairing fuel leaks, to preclude the possibility of explosion.

MODEL P210 SERIES SERVICE MANUAL




Figure 13-1. Fuel System Schematic (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL





Figure 13-1. Fuel System Schematic (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL



WARNING

ASSURE THAT ALL CONTAMINATE, INCLUDING WATER, ARE REMOVED FROM FUEL AND FUEL SYSTEM BEFORE FLIGHT. FAILURE TO ASSURE CONTAMINATE FREE FUEL, AND HEED ALL SAFETY INSTRUCTIONS AND OWNER ADVISORIES PRIOR TO FLIGHT CAN RESULT IN BODILY INJURY OR DEATH.

8702000-1

IN CLEAR VIEW OF THE PILOT

- | | |
|-------------------------|---------------------------|
| 1. Right-Hand Fuel Line | 9. ON-OFF Valve |
| 2. Crossvent Line | 10. Strainer Drain Valve |
| 3. Left-Hand Fuel Line | 11. Fuel Strainer |
| 4. Vent Line | 12. Fuel Selector Valve |
| 5. Fuel Line | 13. Vent Line Drain Valve |
| 6. Drain Line | 14. Drain Line |
| 7. Reservoir | 15. Fuel Line |
| 8. Auxiliary Fuel Pump | 16. Vent Line |

Figure 13-2. Fuel System

MODEL P210 SERIES SERVICE MANUAL

The following procedure may be used to purge the bay with argon or carbon dioxide.

- a. Ground the aircraft to a suitable ground stake.
- b. Set fuel selector or fuel ON-OFF valve handle in OFF position.
- c. Drain all fuel from bay being repaired. (Observe the precautions in paragraph 13-3.)
- d. Remove access doors and insert hose to each end of bay simultaneously.
- e. Allow inert gas to flow into bay for several minutes (time dependent upon hose size, rate of flow, etc.) to remove all fuel vapors.

Since argon and carbon dioxide are heavier than air, these gases will remain in the bay during the repair. The repair shall be made using non-sparking tools (air motors, plastic scrapers, etc.)

NOTE

Portable vapor detectors are available to determine presence of explosive mixtures and are calibrated for leaded fuel. These detectors can be used to determine when it is safe to make repairs.

13-10. FUEL BAY SEALANT. Two kinds of sealants are used, one to seal fuel bay area and the other to seal access doors and fuel quantity transmitter adapter. The access door sealant is more pliable and will not adhere to metal as firmly as the bay sealant does. This permits access doors and fuel quantity-transmitter adapter to be removed without damage to them. Service Kits SK210-56 (6-ounce tube) and SK210-101 (2.5-ounce tube), which are available from the Cessna Supply Division, contain these sealants with proper quantity of accelerators for each sealant. The sealants can be identified by color. The bay sealant is white and its accelerator is a black paste. The access door sealant is grey and its accelerator is a clear liquid.

WARNING

Keep sealants away from heat and flame. Use only in a well ventilated area. Avoid skin and eye contact. WEAR EYE SHIELDS. In case of eye contact, flush generously with clean water, and secure prompt medical attention.

13-11. MIXING SEALANT. Mix sealant according to service kit instructions.

13-12. SEALING. (Refer to Section 18 for repair procedures).

CAUTION

Protect drains and fuel outlet screens when applying sealants. DO NOT plug drain channels in hat section stiffeners.

Any repair that breaks the fuel bay seal will necessitate resealing of that area of the bay. Repair parts that need sealing must be installed and riveted during the sealing operation. All joints within the boundary

of the bay, but which do not provide a direct fuel path out of the bay, such as stringers and rib flanges within the bay, must be fay surface sealed only. Joints which provide a direct fuel path out of the bay area, such as fuel spar flanges and inboard and outboard rib flanges, must be fay surface sealed and fillet sealed on the fuel side. Fay surface sealing is applying sealant to one mating part before assembly. Enough sealant must be applied so it will squeeze out completely around the joint when the parts are riveted or fastened together. The fillet seal is applied after the point is fay surface sealed and riveted or fastened together. Fillet sealing is applying sealant to the edge of all riveted joints, joggles, bend reliefs, voids, rivets or fasteners through the boundary of the bay and any place that could produce a fuel leak. The fay sealant need not be cured before the fillet seal is applied, but the squeezed out sealant, to which the fillet sealant is applied, must be free of dirt and contamination. Fillets laid on intersecting joints shall be joined together to produce a continuous fillet. Filler sealant must be pressed into the joint, working out all entrapped air. The best method of applying sealant is with an extrusion gun. Then work the sealant into the joint with a small paddle, being careful to eliminate all air bubbles.

NOTE

During structural repair, parts must be pre-drilled, countersunk or dimpled and cleaned before being sealed and positioned for final installation.

- a. Remove all existing sealant from area to be sealed, leaving a taper on the remaining sealant. The taper will allow a scarf bond and a continuous seal when the new sealant is applied.

NOTE

The best method for removing sealant is with a chisel tool made of hard fiber. Remaining sealant is then removed with aluminum wool. Neither steelwool nor sandpaper can be used.

- b. Vacuum thoroughly to remove all chips, filings, and other foreign materials from bay areas.
- c. All surfaces and areas to be sealed shall be thoroughly cleaned by wiping with a clean cloth dampened with Methyl Ethyl Ketone (MEK), acetone or similar solvent, and dried with a clean cloth prior to solvent evaporation. Always pour the solvent on the cloth. Never use contaminated solvent. The cloth shall not be so saturated that dripping occurs.

13-13. SEALING FUEL LEAKS. First determine the source of the fuel leak. Fuel can flow along a seam or structure of the wing for several inches, making the leak source difficult to find. A stained area is an indication of the leak source. Fuel leaks can be found by testing the complete bay as described in paragraph 13-15. Another method of detecting the source of a fuel leak is to remove access doors and blow with an air nozzle from the inside of the bay in the area of the leak while soap bubble solution is applied to the outside of the bay. After the leak source

MODEL P210 SERIES SERVICE MANUAL




Figure 13-3. Fuel Bay Sealing (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL

NOTE



Refer to paragraph 13-12.

TYPICAL INSPECTION PLATE




1. Fuel Side
2. Nutplate
3. Fillet Seal
4. Faying
5. Rivet and Fastener Seal


TYPICAL FASTENER



TYPICAL RIB SECTION



TYPICAL FUEL BAY SPAR



TYPICAL END SECTION

Figure 13-3. Fuel Bay Sealing (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 13-4. Classification of Fuel Leaks

has been found, proceed as follows:

- Remove existing sealant in the area of the leak.
- Clean the area and apply a fillet seal. Press sealant into leaking area with a small paddle, working out all air bubbles.
- If leakage occurs around a rivet or bolt, restrike the rivet or loosen bolt, retorque, and reseal around nutplate.
- Apply fay surface door sealant to access doors, fuel quantity transmitters, etc., if removed, and install.
- Test fuel bay for leakage as outlined in paragraph 13-15.

13-14. **NORMAL CURE TIME.** Service Kit SK210-56 contains: (A) SP654706B2 access door sealant and (B) SP654890B2 fuel bay sealant. Cure times for (A) and (B) are 24 hours. Service Kit SK210-101 contains: (C) PR1321B 1/2 access door sealant and (D) PR1422B 1/2 fuel bay sealant. Cure time for (C) is 18 hours; cure time for (D) is 45 hours. Cure times for both kits are based on a standard condition of 77°F (25°C) and 50 percent relative humidity.

MODEL P210 SERIES SERVICE MANUAL

ACCELERATED CURING TIME

F of Sealant	Time in Hours
160	3
140	4
•130	5 1/2
120	7

•Applicable to SK210-101 only.

NOTE

Temperature shall not exceed 160°F (71°C).
Bay must be vented to relieve pressure during accelerated curing.

13-14A. NORMAL WORK TIME. Normal work time for Service Kit SK210-56 is two hours, and 0.5 hour for Service Kit SK210-101. Shelf life of these kits is approximately six months. If more rapid cure times are desired, refer to the following note and accelerated curing time chart.

13-14B. INTEGRAL FUEL BAY QUICK REPAIR SEALANT. GC-435 is a quick-repair synthetic rubber sealant for use in fuel bays when it is necessary to refill bays as soon as the repair has been made; the sealant requires no cure time. The sealant is a two-part, medium viscosity polysulfide liquid polymer and is formulated for application by brush or extrusion. GC-435 may be purchased from: Goal Chemical Sealants Corp. 3137 East 28th. Street, Los Angeles, CA 90023.

13-14C. SURFACE PREPARATION. To ensure maximum adhesion of GC-435 integral bay surfaces should be free of oil, grease, wax, dirt, etc. Pour the cleaning solvent onto the cloth and wipe the surface, then use a clean, dry cloth to wipe the solvent from the surface prior to its evaporation. Be sure the surface to be sealed is clean and dry. Observe all warnings and cautions covering preparation and application of sealants as noted in this section and the instructions included with GC-435 sealant.

WARNING

The accelerators contain heavy metal Peroxides, keep away from heat and flame. Use only in well-ventilated area, avoid skin and eye contact, and WEAR EYE SHIELDS. In case of eye contact, flush liberally with water, and get prompt medical attention.

13-14D. MIXING SEALANT. GC-435 comes in pre-measured and proportioned kits ready for use. The base compound is cream-colored, and the catalyst is black. If the entire kit is not needed, the GC-435 may be proportioned by combining (10) parts of the base compound (cream colored), with (1) part of the catalyst (black) by weight. Use an accurate scale and slowly mix the base and catalyst until a homogeneous blend of color and appearance is accomplished.

NOTE

Work life of GC-435 is approximately (15) minutes. Shelf life is at least (6) months when stored in an area where the ambient temperatures are 80° (26°C) or lower. Unless specifically noted all items relating to Integral Fuel Tank Sealants also apply to GC-435 quick-repair sealant.

13-15. TESTING INTEGRAL FUEL BAY.

- Remove vent line from vent fitting and cap fitting.
- Disconnect fuel lines from bay.
- To one of the bay fittings, attach a water manometer capable of measuring twenty inches of water.

MODEL P210 SERIES SERVICE MANUAL

- d. To the other bay fitting, connect a well regulated supply of air (1/2 PSI MAXIMUM. of 13.8 INCHES of water). Nitrogen may be used where the bay might be exposed to temperature changes while testing.
- e. Make sure filler cap is installed and sealed.

CAUTION

Do not attempt to apply pressure to the bay without a good regulator and a positive shut-off in the supply line. Do not inflate the fuel bay to more than 1/2 psi or damage may occur.

- f. Apply pressure slowly until 1/2 PSI is obtained.
- g. Apply soap solution as required.
- h. Allow 15 to 30 minutes for pressure to stabilize.
- i. If bay holds for 15 minutes, without pressure loss, bay is acceptable.
- j. Reseal and retest if any leaks are found.

13-16. FUEL VENTS.

13-17. DESCRIPTION. The fuel bay vent line extends from each fuel bay to the wing tip on the standard range wing. The line is connected to a float-type vent valve in the fuel bay. On the extended range wing the vent valve is in the outboard fuel bay and a vent line interconnects the bays. The vent valve prevents fuel drainage through the vent line, but still allows the positive pressure from expanding fuel to escape from the bays. Check all fittings and clamps for tightness and vent line for clearance to prevent chafing against inner wing structure. The fuel vent line at the trailing edge of the wing tip should be checked daily for evidence of foreign matter.

13-18. REMOVAL AND INSTALLATION. (See figure 13-5.)

- a. Remove wing tip and access covers on underside of wing as necessary for access.
- b. Disconnect vent line at valve in fuel bay and disconnect clamps attaching vent line to wing structure.
- c. Remove vent line by carefully pulling it from the outboard end of the wing.
- d. On the extended range the interconnect vent line may also be removed.
- e. To remove vent valve, remove fuel bay access cover.
- f. Remove nut and washer(s), then remove valve from inside of bay.
- g. Remove sealer on valve and access cover, and reseal per paragraph 13-12 on installation.
- h. Reverse the preceding steps for installation.

13-19. CHECKING. Field experience has demonstrated that the vents can become plugged, causing possible fuel starvation of the engine. Also, the bleed hole in the vent valve assembly could possibly become plugged, allowing pressure from expanding fuel to pressurize the bay areas. The following procedure may be used to check the vent and bleed hole in the vent valve assembly.

- a. Cover .040 drilled holes approximately 6 inches from end of vent line at trailing edges of wing tips.
- b. Attach a rubber tube to the end of the vent line at the trailing edge of one wing tip.
- c. Turn off fuel selector or fuel ON-OFF valve and check that both fuel filler caps are securely installed.
- d. Blow into tube to slightly pressurize the fuel bay. If air can be blown into bay, the vent line is open.
- e. After the fuel bay is slightly pressurized, insert end of rubber tube into a container of water and watch for a continuous stream of bubbles, which indicates the bleed hole in valve assembly is open and relieving pressure.
- f. Repeat this procedure for fuel vent at opposite wing tip.

NOTE

A plugged vent line or valve can cause fuel starvation, or pressurization of fuel bay. It is a must to correct any plugged or restricted vent before returning aircraft to service.

CAUTION

Be sure to uncover drilled holes in vent lines at wing tips after completion of check.

13-20. FUEL QUANTITY INDICATING SYSTEM.

13-21. DESCRIPTION. The system is comprised of one float type transmitter in each fuel bay, two quantity indicators located in the fuel selector valve panel, and associated wiring. The gages are magnetic type, and the float transmitters are variable resistive type. Refer to Section 16 for operation, calibration, removal and installation procedures.

13-22. FUEL SELECTOR VALVE. (See figure 13-6).

13-23. DESCRIPTION. A three position, six port fuel selector valve is located beneath the floorboard. A shaft links the fuel selector valve to a handle mounted on the pedestal structure. The positions of the handle are labeled "BOTH ON, LEFT ON, RIGHT ON". Valve repair is limited to replacement of component parts only. Figure 13-6 illustrates the proper relationship of parts and may be used as a guide during disassembly and assembly.

13-24. REMOVAL AND INSTALLATION.

- a. Drain all fuel from wing bays, reservoir, strainer and lines. (Observe precautions in paragraph 13-3.)
- b. Remove selector valve handle.
- c. Remove pedestal cover.
- d. Remove center access plate.
- e. Tag, and then disconnect or plug all six lines at valve.

MODEL P210 SERIES SERVICE MANUAL




Figure 13-5. Fuel Bay Vents (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 13-5. Fuel Bay Vents (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

NOTE

- f. Remove screws attaching elevator cable bracket to valve.
- g. Remove nuts, washers, and bolts attaching valve to its bracket.
- h. Remove valve.
- i. Reverse preceding steps for installation. Prior to reinstalling equipment removed for access, secure fuel bays and check all lines and fittings for leaks in all selector valve positions.

13-25. DISASSEMBLY, REPAIR AND REASSEMBLY.

- a. Remove pin (31) and shaft (30).
- b. Remove spring retainer (24) spring (23) packing (22) and seal (21) from each part of the lower body (20).
- c. Remove screw (2) holding upper body (4) and lower body (20) together.
- d. Remove lower body (20) with a twisting motion. Remove and tag washer(s) (16).
- e. Cover upper body (4) and detent insert (17) with a clean shop cloth.

NOTE

The shop cloth will contain ball (15) and spring (14) when detent insert (17) is removed.

- f. Carefully pry detent insert (17) from upper body (4).
- g. Remove ball (15) and spring (14) from shop cloth.
- h. Remove stop pin (3) from rotor (13).
- i. Cover upper body (4) completely with a clean shop cloth.

NOTE

The shop cloth will contain seals (12), packings (11), washers (10) and springs (9) when the rotor is removed.

- j. Push the rotor (13) out of the upper body (4).
- k. Remove the rotor (13), seals (12), packings (11), washers (10), and springs (9) from the shop cloth.
- l. Check detent holes in detent insert (17) for excessive wear.
- m. Replace all seals and packings.
- n. Insert rotor (13), in upper body (4), place detent insert (17), over rotor (13), place washer (16) in lower body (20), place lower body (20), over rotor (13) insert three screws (2) and torque to 30 lbs-in. Check end play between rotor and valve bodies.
If end play is:
 - (1) .008 or greater, add S-1358-11 and/or S-1358-12 washers to decrease end play to .001 to .007.
 - (2) .007 to .004 add (1) S-1358-12 washer.
 - (3) .003 or less, disassemble valve and reassemble with different parts, recheck end play.
- o. When end play is within tolerance disassemble, retain washers.

Reassembly of the selector valve is facilitated by mounting upper body (4) in a bench vise or equivalent bench support making certain upper body (4) is protected from damage. Fabrication of spring compressors (32), three are required.

- p. Place upper body (4) upside down in bench vise or support.
- q. Replace packing (6). Lubricate spring (14) with petrolatum and insert in rotor (13).
- r. Insert spring (9) and compress with spring compressor (32) then insert washer (10), packing (11) and seal (12). The concave portion of the seal must fit the convex surface of the rotor (13). Complete this for each port.
- s. While holding the three springs (9) with the spring compressors (32), place washers (7) and/or (8) on the shaft end of rotor (13) and insert rotor (13) into the upper body (4). The seals (12) must fit flush against the rotor (13). Release the spring compressors (32).
- t. Remove the upper body (4) from bench vise or support.
- u. Insert stop pin (3) into rotor shaft.
- v. Place detent insert (17) on rotor (13) with slots for ball (15) toward upper body (4).
- w. Place ball (15) on spring (14) align one of the slots, with the ball (15) and depress the ball (15). While pushing the detent insert (17) toward the upper body (4) as the ball (15) enters the slot the detent insert (17) may be pushed on to rotor (13) until it is flush with the upper body (4). Rotate the detent insert (17) until all four of its bolt holes align with four of the holes on the upper body (4).
- x. Roll packing (18) over end of rotor (13) and push into cutout between rotor (13) and detent insert (17). Packing (18) must not protrude beyond lip of detent insert (17). Care must be exercised to avoid damage to packing.
- y. Place packing (19) in groove on outer edge of detent insert (17).
- z. Place lower body (20) over rotor (13). The five bolt holes in the lower body (20) must align with the five bolt holes in the upper body (4).

13-26. LEAK TEST.

- a. With valve assembled remove stop pin (3).
- b. Set valve in a closed position.
- c. Apply 6-10 psi Stoddard solvent to each port separately.
- d. Maximum internal leakage 10 drops per minute. No external leakage allowed.

13-27. ALTERNATE METHOD.

- a. With valve assembled remove stop pin (3).
- b. Set valve in a closed position.
- c. Apply 6-10 psi air to each port while valve is submerged in water.
- d. Maximum internal leakage equivalent to 10 drops per minute Stoddard solvent. No external leakage allowed.
Add two drops of Loctite 242 to end of each spring retainer (24) after pressure test.

MODEL P210 SERIES SERVICE MANUAL

1. Elevator Cable Bracket
2. Screws
3. Stop Pin
4. Upper Body
5. Packing
6. Packing
7. Washer, 1358-11
8. Washer, 1358-12
9. Spring
10. Washer
11. Packing
12. Seal
13. Rotor
14. Spring
15. Ball
16. Washer, 1358-10 or -11
17. Detent Insert
18. Packing
19. Packing
20. Lower Body
21. Seal
22. Packing
23. Spring Retainer
24. Plug
25. Screw
26. Washer
27. Handle
28. Screw
29. Shaft
30. Pin
31. Pin
32. Spring Compressor







Figure 13-6. Fuel Selector Valve (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL



Fabricate spring compressor (31) from 1/16 inch diameter #1 OXWELD AC welding rod or equivalent according to dimensions shown.




Figure 13-6. Fuel Selector Valve (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

13-28. FUEL RESERVOIR. (See figure 13-7).

13-29. DESCRIPTION. There is one reservoir installed in the lower fuselage, on the pilot's side outboard of the fuel selector valve. The reservoir has four fuel line connections; one from the fuel selector valve, one from the lower right hand crossover drain line, one from the left hand crossover drain line and one to the engine by way of the auxiliary fuel pump, ON-OFF valve and fuel strainer. A drain valve is installed in the bottom of the reservoir for draining.

13-30. REMOVAL AND INSTALLATION.

- a. Drain all fuel from wing bays, reservoir, strainer and lines. Observe precautions in paragraph 13-3).
 - b. Remove carpeting and access plate.
 - c. Disconnect and cap or plug all fuel lines at the reservoir.
 - d. Remove screws securing mounting legs to fuselage.
 - e. Lift reservoir out.
 - f. Reverse the preceding steps for installation.
- Prior to replacing the access plate, secure fuel bays and check all connections for leaks.

NOTE

The clearance between the elevator cables and the drain line is .37 inch minimum and .50 maximum.

Lower Right Hand Crossover Drain Line
From Fuel Selector Valve
Left Hand Crossvent Drain Line
To Engine

13-31. AUXILIARY FUEL PUMP.

13-32. DESCRIPTION. An electric auxiliary fuel pump is located forward of the reservoir. It is connected in line with the engine driven pump, therefore, all fuel must flow through the auxiliary pump internal by-pass valve. A fuel drain safety feature that prevents accumulation of fuel in the auxiliary pump motor in case of leakage is incorporated. The auxiliary fuel pump is used for engine starting, and in place of the engine driven pump if it should fail in flight.

13-33. REMOVAL AND INSTALLATION. (See figure 13-8.)

- a. Turn fuel selector or fuel ON-OFF valve OFF.
 - b. Drain fuel from pump, lines, and strainer.
 - c. Be certain that master and pump switches are OFF.
 - d. Remove pilot's seat, carpeting, and plates at left side of pedestal as necessary for access to pump.
 - e. Disconnect, and cap or plug all fuel lines and electrical connections at pump. (Observe safety precautions in paragraph 13-3.)
 - f. Loosen two securing clamps and lift pump out.
 - g. Reverse the preceding steps for installation.
- Prior to reinstalling equipment removed for access, place selector or fuel ON-OFF valve ON, and check for leaks and proper pump operation.

13-34. AUXILIARY FUEL PUMP CIRCUIT. The auxiliary fuel pump switch is a yellow and red split-rocker type. A yellow, right half is labeled START, and has an upper ON position, which is used for normal starting and minor vapor purging during taxi. The other half, red left side, is labeled EMERG with a HI upper position, and is used in the event of engine driven pump failure during take-off or high power operation. The HI position may also be used for extreme vapor purging. With the right, yellow, half in the ON position, the pump operates at one of two speeds, depending on throttle setting. With the throttle open, the pump runs high speed/capacity, and with the throttle closed, the pump operates at a low-flow speed. This prevents an unusually rich mixture during let down, landing, or taxiing. Maximum fuel flow is produced when the left half of the switch is held in spring loaded HI position. Also in the HI position an interlock automatically turns the right side of the switch to ON, however, when released, the right side will stay ON, until manually turned OFF. When the engine-driven fuel pump is functioning and the auxiliary fuel pump is placed ON, a fuel to air ratio considerably richer than "best-power" is produced unless the mixture is leaned. If both the master and auxiliary fuel switches are placed ON, and the engine stopped, manifold flooding and eventually oil dilution will occur. A throttle shaft-operated microswitch adds resistance to the high fuel flow circuit to slow down the pump when the throttle is retarded, to prevent an excessively rich mixture.

13-35. RIGGING THROTTLE MICROSWITCHES. (Refer to figure 13-9.) These aircraft are equipped with a throttle-operated microswitch, which slows the electric fuel pump when the throttle is retarded and the auxiliary fuel pump is ON. The auxiliary pump should slow in speed/capacity as the throttle is retarded past the point when engine rpm and full rich fuel mixture produce 23 in. Hg manifold pressure when the auxiliary pump is off.


NOTE

These settings must be established during ground run-up only, because they do not apply during flight.

- a. Start engine and set throttle so manifold pressure is 23 in. Hg with auxiliary fuel pump off.
- b. Mark this position on throttle shaft, and stop engine.
- c. Adjust microswitch to activate at this throttle setting, so more resistance is placed in the circuit, to slow pump speed.
- d. With the mixture control in IDLE CUT-OFF, the aux fuel pump switch HI, and master switch ON, listen for the pump speed to change as the throttle is retarded to previously marked position, (23 in-Hg manifold pressure) with the engine stopped.

CAUTION

Prolonged fuel pump operation with engine stopped will cause manifold flooding.




1. Lower Right-Hand Crossover Drain Line
2. From Fuel Selector Valve
3. Drain Line Left-Hand Crossvent Line
4. Drain Valve
5. To Engine

Torque Drain Valve (4) 15-35 lbs-in.

Figure 13-7. Fuel Reservoir


MODEL P210 SERIES SERVICE MANUAL



- | | |
|------------------------|--------------------------|
| 1. Packing | 18. Packing |
| 2. Fitting | 19. Valve Body |
| 3. Line Assembly | 20. Spring |
| 4. Fuel Pump Bracket | 21. Washer |
| 5. Screw | 22. Packing |
| 6. Nut | 23. Seal |
| 7. Fuel Pump Vent Line | 24. Stop Pin |
| 8. Packing | 25. Hose Assembly |
| 9. Line Assembly | 26. Nut |
| 10. ON-OFF Control Arm | 27. Washer |
| 11. Washer | 28. Bolt |
| 12. Nut | 29. ON-OFF Valve Bracket |
| 13. Screw | 30. ON-OFF Control Cable |
| 14. Cover | 31. Cable Clamp |
| 15. Bell | 32. Fitting |
| 16. Spring | 33. Auxiliary Fuel Pump |
| 17. Rotor | |

Figure 13-8. Auxiliary Fuel Pump and ON-OFF Valve


MODEL P210 SERIES SERVICE MANUAL



1. Spacer
2. Fuel Pump Switch Cam
3. Fuel Pump Switch
4. Spacer
5. Arm Assembly
6. Mounting Bracket
7. Clamp Assembly
8. Cable Clamp Mount
9. Throttle Lever
10. Clamp Bolt
11. Throttle Control (Secondary)
12. Clamp Half
13. Bolt
14. Gear Warning Switch
15. Gear Warning Cam
16. Cover

Figure 13-9. Throttle-Operated Microswitches

MODEL P210 SERIES SERVICE MANUAL



1. High-Boost Resistor (#1)
2. High-Boost Resistor (#2)
3. Spacer (Typical)
4. Adjustable Slide
5. Bracket Assembly
6. Battery Box Support
7. Firewall

**BEFORE SK210-154 MODIFICATION
LOOKING AFT AT BATTERY BOX
SUPPORT STRUCTURE**

Figure 13-10. Auxiliary Fuel Pump Resistors (Sheet 1 of 2)

13-36. AUXILIARY ELECTRIC FUEL PUMP FLOW RATE ADJUSTMENT. (Refer to figure 13-10).

WARNING

During this adjustment, raw fuel will drain from the engine compartment; therefore, proper safety precautions should be taken. Conduct test in well ventilated area, use drip pans, insure airplane is properly grounded, and keep ignition source, (cigarettes, lighters, matches, etc.) away from area.

NOTE

These adjustment are to be conducted with the engine stopped and external power supplied to the airplane bus.

NOTE

Auxiliary electric (boost) fuel pump adjustment resistors were originally installed on the battery box support bracket (refer to figure 13-10, sheet 1). Dukes mandatory Service Bulletin No. 0003 directed replacement of fuel boost pump after 10 years service, and Cessna Service Kit SK210-154 provided parts and instructions to install new variable resistors for use with the replacement Dukes boost pump. In accordance with SK210-154, the adjustment resistors are mounted on the battery box (refer to figure 13-10, sheet 2).

- a. Apply an external source of 27.75 VDC \pm .25V to the airplane bus.
- b. Set mixture control at "FULL RICH".
- c. Turn master switch "ON" and fuel pump rocker switch "ON".
- d. Advance throttle to full open position.
- e. Check metered fuel pressure on ship's gauge. On 1985 and 1986 T210R airplanes (Serial 21064898 thru 21065009), fuel flow should be 100-110 pounds/hour. On all other airplanes, fuel flow should be 88-96 pounds/hour.




Figure 13-10. Auxiliary Fuel Pump Resistors (Sheet 2 of 2)

- f. Adjust high-boost resistor (#1) as required to obtain 110-110 pounds/hour (16.7-18.3 gallons/hour).
- g. Retard throttle slowly from the full "OPEN" position until the speed of the fuel pump can be audibly detected to change due to microswitch activation.
- h. Wait momentarily for the fuel flow gage to respond.
- i. The metered fuel pressure/flow on the airplane's gage should read on the low end red line to approximately one red line width above (approximately 4 PSI fuel pressure).
- j. Adjust low-boost resistor (#2) as required to obtain fuel pressure at or above 4 PSI.

MODEL P210 SERIES SERVICE MANUAL

13-37. **MAXIMUM HIGH BOOST CHECK.** To verify high position function, momentarily depress spring-loaded red rocker switch to HI, and verify a noticeable increase in indicated fuel flow on fuel pressure/flow gage.

13-38. **FUEL ON-OFF VALVE.** (See figure 13-8).

13-39. **DESCRIPTION.** The fuel ON-OFF valve is a two position valve located just forward of the auxiliary fuel pump under the pilot's floorboard. The valve control knob is located on the left lower area of the pedestal. Valve repair consists of replacement of component parts.

13-40. **REMOVAL AND INSTALLATION.** (See figure 13-8).

a. Drain all fuel from wing bays, reservoir, strainer and liner. (Observe precautions in paragraph 13-3).

- b. Remove carpeting and access plate.
 - c. Remove control cable from clamp on valve and control wire from valve arm.
 - d. Disconnect and cap or plug both the inlet and outlet fuel lines.
 - e. Remove bolts from bracket and remove valve.
 - f. Reverse the preceding steps for installation.
- Prior to replacing the access plate, service the fuel bays and check all connections for leaks. The valve must also be checked for positive on and off position.

NOTE

When installing the valve make certain the arrow on the valve points with the direction of normal fuel flow. (Toward the engine).

13-41. **DISASSEMBLY, REPAIR AND REASSEMBLY.**

- a. Remove screws (13) securing cover (14) to valve body (19); carefully remove cover.
- b. Remove ball (15) and spring (16) from rotor (17).
- c. Slowly withdraw rotor (17) from valve body (19).

NOTE

Removal of rotor (17) from valve body (19) will allow seal (23), packing (22) washer (21), and spring (20) to pop free.

- d. Remove seal (23), packing (22), washer (21), and spring (20) from valve body (19).
- e. Remove packing (18) from valve body (19).

NOTE

Reassembly of valve is facilitated by mounting in a bench vise or equivalent bench support, making sure valve body (19) is protected from damage. Fabrication of a spring compressor is recommended before reassembly. Replace packings (21) and (18) whenever rotor (17) is removed from valve body.

- f. Ensure all component parts are clean, then coat sparingly with lightweight oil.
- g. Install new packing (18) into recess at top of valve body (19).

- h. Insert spring (20) into valve body (19).
- i. With spring compressor, compress spring (20).
- j. Install washer (21), new packing (22), and seal (23) into port.
- k. Holding spring (20) compressed, carefully insert rotor (17) into valve body (19), release spring compressor, and visually inspect assembly for proper seating of seal (23) to rotor.
- l. Lubricate spring (16) and ball (15) with Petro-latum.
- m. Insert spring (16) into rotor (17).
- n. Place ball (15) on top of spring (16).
- o. Position cover (14) on valve body and turn rotor (17) as required to index one of detents in cover.
- p. Secure cover (14) to valve body (19) with screws (13).
- q. Test rotation of rotor (17) for ease of operation and positive detent engagement.

13-42. **FUEL STRAINER.** (See figure 13-11).

13-43. **DESCRIPTION.** The fuel strainer is located on the left forward side of the firewall. It is accessible through the left cowl flap opening or from above by removing the upper engine cowling. The fuel strainer incorporates a quick drain valve. The valve protrudes from the lower left side of the engine cowling.

NOTE

The fuel strainer can be disassembled, cleaned and reassembled without removing the assembly from the aircraft.

13-44. **DISASSEMBLY, REASSEMBLY.**

- a. Place ON-OFF fuel control in OFF position.
- b. Drain fuel from strainer and lines with drain valve (13).
- c. Disconnect strainer drain line (11) from strainer bowl (6) and drain valve (13).
- d. Remove nut (9), step washer (8) and O-ring (7) at bottom of bowl (6) and remove bowl (6) remove O-ring (3).
- e. Carefully unscrew Standpipe (5) and remove.
- f. Remove filter screen (4) and gasket (2). Wash filter screen and bowl in solvent (P-S-661) and dry with compressed air.
- g. Using a new gasket (2) install filter screen (4) and standpipe (5). Tighten standpipe finger tight.
- h. Using new O-rings (3) and (7) install bowl (6). The step washer (8) must be installed so that the step seats against the O-ring (7), connect drain line (11).
- i. Place ON-OFF fuel control in ON position.
- j. Check for fuel leaks.
- k. Check drain valve (13) for operation.

13-45. **VENTED FUEL FILLER CAPS.**

13-46. **DESCRIPTION.** The filler cap on the standard system is constructed of red plastic. The filler cap on the extended range system is constructed of metal. The cap assemblies incorporate a vent safety valve that provides vacuum and positive pressure relief for the fuel bay. It is important that the cap is cleaned on a as required basis, if proper filler cap sealing is to be maintained. Extra care is required

MODEL P210 SERIES SERVICE MANUAL




Figure 13-11. Fuel Strainer

MODEL P210 SERIES SERVICE MANUAL




Figure 13-12. Fuel Filler Cap (Sheet 1 of 2)

when reinstalling plastic filler caps in the fuel filler adapter assembly. An improperly installed filler cap could cause a loss of fuel from the bays during flight. Repair of the metal cap is not recommended, except replacement of O-ring seal located on cap body. However, it is important that cap assembly be wiped off with Stoddard solvent or equivalent on an as required basis to help ensure proper filler cap sealing. The plastic filler cap should be inspected and cleaned as indicated in paragraphs 13-47 and 13-48.

13-47. INSPECTION. (See figure 13-12.)

NOTE


If fuel collects in the handle well it could indicate stem O-ring leakage. Fuel collecting around perimeter of cap could indicate cap outer seal or check valve leakage.

- a. Remove fuel cap from adapter (8), remove safety chain (10) from cap and cover or plug fuel opening to keep out foreign matter.
- b. Rotate cap handle (1) to the "OPEN" position, compress cap body (2) and lock plate (6) to expose the .125 inch diameter handle pin (17).
- c. Using a small wire push out the handle pin (17).
- d. Note resilience of O-ring (13) and outer seal (3) and condition of grooves. If the O-ring (13) or the outer seal (3) have deteriorated they must be replaced.
- e. Note condition of tabs on lock plate (6) for signs of abnormal wear. If such wear is evident replace the complete cap assembly.

13-48. CLEANING.

- a. Using a cotton swab and Stoddard solvent or equivalent, gently lift edges of rubber umbrella (5) and clean stainless steel seat and umbrella removing all contaminants. Using a second swab wipe seat and

MODEL P210 SERIES SERVICE MANUAL



EXTENDED RANGE

1. Pin
2. Handle
3. Fuel Cap Body
4. Seal
5. Lock Ring
6. Doubler
7. Screw
8. Lanyard
9. Vent

Figure 13-12. Fuel Filler Cap (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

umbrella thoroughly, removing all cotton fibers. Repeat until swabs show no discoloration.

- b. If O-ring or outer seal grooves appear contaminated, clean with Stoddard solvent or equivalent and cotton swabs.
- c. Ascertain that all vent holes in check valve are unobstructed.
- d. Clean cap body and lock plate, check for defects.
- e. If the umbrella continues to leak or is deteriorated it must be replaced.
- f. To remove umbrella, lubricate the umbrella stem with (MIL-H-5606) hydraulic fluid to prevent tearing the stem.
- g. To replace umbrella, lubricate the umbrella stem with (MIL-H-5606) hydraulic fluid and use a small blunt tool to insert the retaining knob on the umbrella stem into the check valve body to prevent damaging the stem.

13-49. REASSEMBLY. (See figure 13-12.)

NOTE

If fuel was observed leaking around the cap periphery prior to disassembly and the leakage was not due to a bad O-ring or outer seal an additional split washer (16) may be added for a total of two, prior to reassembling cap. To make sure that these washers are not installed upside down, check to see that edges of the split parallel the respective sides of the cap well. The addition of a washer under the cap handle will increase the effort required to uncap the fuel tank.

- a. Install spring (15) on stem (14).
- b. Install fuel cap body (2) on stem (14).
- c. Check that three metal plates (12) on top rim of lock plate (6) are aligned with three guide bosses on fuel cap body (2).

CAUTION

It is possible to install the handle pin in the pin hole 180° out of the desired position, if the alignment procedure in step "c" is not followed. If the handle (1) is not installed properly the FWD arrow on the cap will not align with the arrow on the placard (9) when the cap is reinstalled.

- d. Compress cap body (2) and lock plate (6), install split washer(s) (16) as required.
- e. Install cap handle (1) on stem (14) so that the handle (1) will be in the open position.
- f. Insert handle pin (17) through handle (1) and stem (14).
- g. Connect fuel cap assembly to safety chain (10) and reinstall fuel cap. Make certain that the arrow on the fuel cap body (2) and the arrow on the placard (9) align.

13-50. LEAK TESTING RED PLASTIC FILLER CAPS. The following procedure may be used to detect fuel filler cap leakage.

- a. Service the aircraft with approved fuel, filling each fuel bay.
- b. Place the fuel selector in the OFF position.
- c. Plug one of the fuel bay vent lines (where it protrudes beneath the wing) with a small rubber plug or tape.
- d. Connect a rubber hose to the other vent. Then tee into this hose a pressure measuring device, such as a water manometer, manifold pressure gage or airspeed indicator.
- e. Blow into the open end of the hose. The pressure must not exceed .7 psi which equals 20 inches of water on a water manometer, or 1.43 inches Hg on a manifold pressure gage, or 174 kts on an airspeed indicator.

WARNING

Do not inhale fuel vapor while blowing into the rubber hose.

- f. It may take several applications of pressure to bring the bay to the desired pressure.

WARNING

Do not apply regulated or unregulated air pressure from an air compressor to the fuel vent. Over inflation and major structural damage will occur if more than .7 psi is applied.

- g. Pinch or close the rubber hose to sustain pressure in the fuel bay.
- h. Apply a soap solution to the fuel filler caps and inspect for leakage around the rubber seal to filler neck junction, the fuel cap vent, and the fuel cap handle stem. Load the cap sideways in all directions by pressing on the fuel cap vent housing by hand.

NOTE

No leakage is permissible. If leaks are present, replace the cap with a new unit or repair in accordance with Cessna Service Information Letter SE80-59, Supplement #1 dated, June 23, 1980.

CAUTION

Care must be exercised in removing the fuel filler caps until the system has been depressurized.

- i. After replacement of either fuel filler cap, repeat the inspection.
- j. Remove the rubber hose, unplug or remove the tape from the other fuel vent, and place the fuel selector in the desired position.

MODEL P210 SERIES SERVICE MANUAL

13-51. PRIMING SYSTEM.

13-52. DESCRIPTION. The priming system is comprised of a plunger-type manually-operated primer, which draws fuel from the strainer and forces it through a tee fitting to the aft end of each intake manifold. Injecting the fuel into each manifold primes both banks of cylinders.

13-53. REMOVAL AND INSTALLATION.

- a. With selector or fuel ON-OFF valve in OFF position, drain fuel from strainer and lines.
- b. Disconnect and cap or plug all fuel lines at primer. (Observe precautions in paragraph 13-3.)

- c. Unscrew knurled nut and remove plunger from pump body.
- d. Remove pump body from instrument panel.

NOTE

Visually inspect primer lines for crushed, kinked or broken condition. Insure proper clamping to prevent fatigue due to vibration and chafing.

- e. Reverse the preceding steps for installation. With selector or fuel ON-OFF valve in ON position, check for leaks and proper pumping action.

MODEL P210 SERIES SERVICE MANUAL

SECTION 14

PROPELLER AND GOVERNOR

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand, nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire, or a component malfunction, could cause the propeller to rotate.

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
PROPELLER	2E15/14-1	Removal	2E19/14-5
Description	2E15/14-1	Control Arm/Bearing Assembly	2E19/14-5
Repair	2E15/14-1	Removal	2F19/14-5
Trouble Shooting	2E16/14-2	Installation	2F19/14-5
Removal	2E17/14-3	High RPM Stop Adjustment	2E20/14-6
Installation	2E17/14-3	Rigging Governor Control	2E20/14-6
Time Between Overhaul (TBO)	2E17/14-3	Time Between Overhaul (TBO)	2E20/14-6
Trouble Shooting	2E17/14-3		

14-1. PROPELLER

14-2. DESCRIPTION. These aircraft are equipped with an all-metal, constant-speed, three-blade, single-action, governor-regulated propeller. A single acting propeller uses oil pressure to effect a change of pitch in one direction only, relying on spring tension and blade moment to effect a change in the opposite direction. Engine lubricating oil is boosted by this propeller governor, and supplied in the exact regulated amount to maintain preselected engine load through blade pitch. A balanced condition between the governor flyweights and speeder spring will result in a no-change blade pitch action. However, either a decrease or increase in engine RPM will be sensed by the governor fly weights, and in turn will appropriately move the pilot valve to change blade pitch so the balance is once more attained. If the throttle is opened more or if aircraft speed is increased, the engine RPM will start to increase, the governor flyweights sense this change, and position the pilot valve so oil pressure is increased on the forward side of the propeller piston. This increased pressure moves the

piston rearward, causing an increase in blade pitch and a corresponding decrease in engine RPM, thus maintaining a constant engine speed through a varying propeller load. Conversely if the throttle is closed somewhat or if aircraft speed decreases, the engine RPM will begin to decrease, again the governor senses this change, and effects a reduction in oil pressure on the forward side of the propeller piston which allows the piston return spring and the twisting moment of the propeller blades to decrease the blade pitch, which increases the engine RPM to previously selected speed.

14-3. REPAIR. Metal propeller repair first involves evaluating the damage and determining whether the repair will be a major or minor one. Federal Aviation Regulations, Part 43 (FAR 43), and Federal Aviation Agency, Advisory Circular No. 43.13 (FAA AC No. 43.13), define major and minor repairs, alterations and who may accomplish them. When making repairs or alterations to a propeller FAR 43, FAA AC No. 43.13 and the propeller manufacturer's instructions must be observed.

MODEL P210 SERIES SERVICE MANUAL

14-4. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
FAILURE TO CHANGE PITCH.	Governor control disconnected or broken.	Check visually. Connect or replace control.
	Governor not correct for propeller. (Sensing wrong.)	Check that correct governor is installed. Replace governor.
	Defective governor.	Refer to paragraph 14-9.
	Defective pitch changing mechanism inside propeller or excessive propeller blade friction.	Propeller repair or replacement is required.
FAILURE TO CHANGE PITCH FULLY.	Improper rigging of governor control.	Check that governor control arm and control have full travel. Rig control and arm as required.
	Defective governor.	Refer to paragraph 14-9.
SLUGGISH RESPONSE TO PROPELLER CONTROL.	Excessive friction in pitch changing mechanism inside propeller or excessive blade friction.	Propeller repair or replacement is required.
STATIC RPM TOO HIGH OR TOO LOW.	Improper propeller governor adjustments.	Perform static RPM check. Refer to section 12 for procedures.
ENGINE SPEED WILL NOT STABILIZE.	Sludge in governor.	Refer to paragraph 14-9.
	Air trapped in propeller actuating cylinder.	Trapped air should be purged by exercising the propeller several times prior to take-off after propeller has been reinstalled or has been idle for an extended period.
	Excessive friction in pitch changing mechanism inside propeller or excessive blade friction.	Propeller repair or replacement is required.
	Defective governor.	Refer to paragraph 14-9.
OIL LEAKAGE AT PROPELLER MOUNTING FLANGE.	Damaged O-ring and seal between engine crankshaft flange and propeller.	Check visually. Remove propeller and install O-ring seal.
	Foreign material between engine crankshaft flange and propeller mating surfaces or mounting nuts not tight.	Remove propeller and clean mating surfaces; install new O-ring and tighten mounting nuts evenly to torque value in paragraph 14-6, "e".
OIL LEAKAGE AT ANY OTHER PLACE.	Defective seals, gaskets, threads, etc., or incorrect assembly.	Propeller repair or replacement is required.

MODEL P210 SERIES SERVICE MANUAL

14-5. REMOVAL (Refer to figure 14-1.)

- a. Remove spinner attaching screws (18), and remove spinner (1), spinner support (2), and spacers (3). Retain spacers (3).
- b. Remove cowling as required for access to propeller mount nuts.
- c. Loosen all mounting nuts (11) approximately 1/4" and pull propeller (16) forward until stopped by nuts.

WARNING

Be certain the magneto is GROUNDED before rotating propeller or engine.

NOTE

If optional propeller anti-ice system is installed, the slip ring is held in place by the propeller assembly. During removal, the nine (9) slip ring wires should be disconnected at the spinner bulkhead to facilitate propeller assembly removal without slip ring attached. Caution should be used in slip ring removal from crankshaft, so brushes aren't damaged, nor slip ring scratched. See Section 15.

NOTE

As the propeller (16) is separated from the engine crankshaft flange, oil will drain from the propeller and engine cavities.

- d. Remove all propeller mount nuts (11) and pull propeller forward off the crankshaft (9).
- e. If desired the spinner bulkhead (8) can be removed by removing bolts (12) and nuts attaching spinner bulkhead to propeller.

14-6. INSTALLATION.

- a. If the spinner bulkhead (8) was removed, position bulkhead so the propeller blades will emerge from the spinner (1) with ample clearance and install spinner bulkhead attaching with bolts (12) and nuts.

CAUTION

Use care when installing the propeller over crankshaft, because metal scrapings can become wedged between the crankshaft flange and propeller causing damage or oil leakage. When installing a new spinner bulkhead, trim the inside diameter as necessary.

NOTE

If aircraft is configured with optional anti-ice system, slip ring assembly must be installed with or prior to propeller assembly. In either instance, take care not to install brushes in a manner to cause damage to them, and properly connect wiring at spinner bulkhead. See Section 15.

- b. Clean propeller hub cavity, crankshaft, and propeller mating surface.

- c. Lubricate lightly, new O-ring (7) and crankshaft pilot with clean engine oil, and install the O-ring in the propeller hub.

- d. Align propeller dowel pins with holes in crankshaft flange: push propeller carefully over crankshaft until mating surfaces are approximately 1/4 inch apart.

- e. Install propeller attaching washers and nuts (11) and move propeller as far aft on pilot as possible, tighten nuts, and torque to 660 - 780 lb-in. See figure 14-4.

- f. Install any spacers (3) used between spinner support and propeller cylinder, and install spinner support and spinners. The spacers are used as required to cause a snug fit between the spinner (1) and the spinner support (2).

14-7. TIME BETWEEN OVERHAUL (TBO).

Propeller overhaul shall coincide with engine overhaul, but shall not exceed limits specified in McCauley Bulletin 137 and all revisions and supplements thereto. Refer to Section 12 for engine overhaul periods.

14-8. GOVERNOR.

14-9. DESCRIPTION.

The propeller governor is a single-acting, centrifugal type, which boosts oil pressure from the engine, and directs it to the propeller where the oil is used to increase blade pitch. Oil pressure in a single acting governor is used to effect a change in blade pitch in one direction only. The opposing pitch change action results from spring tension working with the blade twisting moment when oil pressure is reduced. Oil pressure is boosted from engine oil to governor operating pressure by the governor oil pump. A pilot valve, speeder spring, and flyweights act correctly to direct oil flow to maintain constant engine load by changing propeller blade pitch.


NOTE

Outward physical appearance of specific governors is the same, but internal parts determine whether it uses oil pressure to increase or decrease blade pitch. The propellers used on these aircraft require governors which "sense" in a certain manner. "Sensing" is determined by the type pilot valve installed in the governor, therefore, it is important to ascertain that the governor is correct for the propeller being used.

14-10. TROUBLE SHOOTING.

When applying the isolation process, using a governor known to be in good condition will save time. If the "good" governor eliminates the trouble, the original governor was bad. If the trouble remains after installing a "good" governor, then the propeller is probably where the fault lies. Removal, replacement, rigging, high-speed stop adjustment, desludging, and gasket replacement are not major, and can be accomplished in the field. Repairs to propeller governors are classified as major by Federal Aviation Regulation, which also stipulates who may make the required repair actions.

MODEL P210 SERIES SERVICE MANUAL



1. Spinner
2. Support
3. Spacer
4. Cylinder
5. Screw
6. Stud
7. O-Ring
8. Spinner Bulkhead
9. Engine Crankshaft
10. Washer
11. Nut
12. Bolt
13. Washer
14. Dowel Pin
15. Nut
16. Propeller
17. Safety Wire
18. Screw

Figure 14-1. Propeller Installation

MODEL P210 SERIES SERVICE MANUAL




Figure 14-2. Governor Control Arm and Bearing Assembly

14-11. REMOVAL.

- Remove cowling, nose cap and engine baffles as required for access to governor.
- Disconnect governor control from governor.

NOTE

Note EXACT position of all washers so that washers may be installed in the same position on reinstallation.

- Disconnect intake manifold balance tube at front of engine and move as required for clearance.
- Remove nuts and washers securing governor to engine and pull governor from mounting studs.
- Remove gasket from between governor and engine mounting pad.

14-12. CONTROL ARM AND BEARING ASSEMBLY.

Refer to figure 14-2.

14-13. REMOVAL.

- Using a scribe, make aligning index marks on governor arm (8) and end of governor serrated shaft.

NOTE

The governor arm (8) must be installed on the governor shaft in the same serration or the governor speed will be changed approximately 200 rpm. for each serration misaligned.

- Remove safety wire from governor arm screw and from screws attaching governor head to governor.
- Remove the two screws (7) that pass through the

non-notched holes in the retainer (6).

- Loosen, but do not remove, the four remaining screws so that retainer (6) may be rotated.
- Loosen screw in governor arm (8) so that arm may be slipped toward end of serrated shaft.
- Slip governor arm toward end of serrated shaft and work retainer (6) and control arm (8) from governor (1).

NOTE

If governor arm (8) becomes disengaged from serrated shaft, align index marks and install arm on serrated shaft. The control arm spring has approximately 1-1/2 turns preload.

- Reverse the preceding steps for reinstallation.

14-14. INSTALLATION.

- Wipe governor and engine mounting pad clean.
- Install a new gasket on the mounting studs. Install gasket with raised surface of the gasket screen toward the governor.

WARNING

Be certain that magneto is GROUNDED before turning propeller.

- Position governor on mounting studs, aligning governor drive splines with splines in the engine and install mounting nuts and washers. Do not force spline engagement. Rotate engine crankshaft slightly and splines will engage smoothly when properly aligned.

MODEL P210 SERIES SERVICE MANUAL




Figure 14-3. Governor and Control Adjustments

- d. Connect governor control to governor, and rig as instructed in paragraph 14-16.
- e. Connect intake manifold balance tube, if removed. Insure all clamps are tight.
- f. Reinstall all items removed for access.

14-15. HIGH-RPM STOP ADJUSTMENT. See figure 14-3.

- a. Remove engine cowling, and left hand section of nose cap.
- b. Remove safety wire and loosen the high-speed stop screw locknut.
- c. Turn the stop screw IN to decrease maximum rpm and OUT to increase maximum rpm. One full turn of the stop screw causes a change of approximately 25 rpm.
- d. Tighten stop screw locknut, safety wire stop screw and make propeller control linkage adjustment as necessary to maintain full travel.
- e. Install cabin heater inlet air duct or plug button and install cowling.
- f. Test operate propeller and governor.

NOTE

It is possible for either the propeller low pitch (high-rpm) stop or the governor high-rpm stop to be the high-rpm limiting factor. It is desirable for the governor stop to limit the high-rpm at the maximum rated rpm for a particular aircraft. Due to climatic conditions, field elevation, low-pitch blade angle and other considerations, an engine may not reach rated rpm on the ground. It may be necessary to readjust the governor stop after test flying to obtain maximum rated rpm when airborne.

14-16. RIGGING PROPELLER GOVERNOR CONTROL.


- a. Disconnect control end (5) from governor (1).
- b. Place propeller control in cabin, full forward, then pull it back approximately 1/8 inch and lock in this position. This will allow "cushion" to assure full contact with governor high-rpm stop screw.
- c. Place governor arm against high-rpm stop screw.
- d. Loosen jam nuts and adjust control rod end until attaching holes align while governor arm is against high-rpm stop screw. Be sure to maintain sufficient thread engagement of the control and rod end. If necessary, shift control in the clamps to achieve this.
- e. Attach rod end to the governor. Be sure all washers are installed correctly.
- f. Operate the control to see that the governor arm bottoms out against the low pitch stop and bottoms out against the high pitch stop on the governor before reaching the end of control cable travel.

14-17. TIME BETWEEN OVERHAUL. (TBO).

Propeller governor overhaul shall coincide with engine overhaul. Refer to Section 12 for engine time between overhaul (TBO) intervals.

NOTE

The result of rigging is full travel of the governor arm (bottomed out against both high and low pitch stops) with some cushion at each end of control travel.



- 1. Adapter
- 2. Torque Wrench
- 3. Propeller

Figure 14-4. Propeller Torque Wrench Adapter

MODEL P210 SERIES SERVICE MANUAL

SECTION 15

UTILITY SYSTEMS

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
UTILITY SYSTEMS	2F5/15-3	Approved Repairs (Cold Patch)	2G17/15-39
Heating/Ventilation System	2F5/15-3	Approved Repairs (Damage to Tube Area)	2G17/15-39
Description	2F5/15-3	Approved Repairs (Damage to Fillet Area)	2G18/15-40
Cabin Heat	2F5/15-3	Approved Repairs (Damaged Veneer, Loose From De-Ice Boot)	2G18/15-40
Ventilating System Operation	2F5/15-3	Materials Required for Installation of De-Ice Boots	2G18/15-40
Windshield Defrosting or Defogging	2F5/15-3	Replacement of De-Ice Boots	2G19/15-41
Trouble Shooting	2F6/15-4	Timer	G206/15-42
Removal/Installation of Components	2F6/15-4	Description	2G20/15-42
Cabin Pressurization	2F6/15-4	Functional Test of Timer	2G20/15-42
Operation	2F6/15-4	Flight Into Known Icing	2G20/15-42
Pressurization Controls/Indicators	2F6/15-4	Description	2G20/15-42
Cabin Altitude Selector	2F6/15-4	Wing, Horizontal Stabilizer, and Vertical Fin De-Ice System	2G20/15-42
Cabin Pressurization Switch	2F6/15-4	Description	2G20/15-42
Dump Valve Control Handle	2F6/15-4	Trouble Shooting	2G21/15-43
Cabin Air Selector Control	2F11/15-9	System Operation	2G23/15-45
Cabin Rate-of-Climb Indicator	2F11/15-9	Removal/Installation	2G23/15-45
Cabin Altitude/Differential Pressure Indicator	2F11/15-9	Functional Check	2G23/15-45
Cabin Altitude Warning Light	2F11/15-9	Adhesion Test	2H6/15-52
Pressurization System Operation	2F11/15-9	Cleaning De-Ice Boots	2H6/15-52
Emergency Operation	2F11/15-9	Cleaning System and Components	2H6/15-52
Trouble Shooting	2F12/15-10	De-Ice/Anti-Ice Boot	
Removal/Installation of Components	2F18/15-16	Protective Products	2H7/15-53
Cabin Pressurization (Garret) Operation	2F18/15-16	Approved Repairs (Cold Patch)	2H7/15-53
Pressurization Controls and Indicators	2F18/15-16	Approved Repairs (Damage to Tube Area)	2H7/15-53
Cabin Altitude Control	2F18/15-16	Approved Repairs (Damage to Fillet Area)	2H8/15-54
Cabin Pressurization Switch	2F18/15-16	Approved Repairs (Damaged Veneer, Loose from De-Ice Boot)	2H8/15-54
Dump Valve Control Handle	2F23/15-21	Materials Required for Installation of De-Ice Boots	2H9/15-55
Cabin Air Selector Control	2F23/15-21	Replacement of De-Ice Boots	2H9/15-55
Cabin Rate-of-Climb Indicator	2F23/15-21	Timer	2H9/15-55
Cabin Altitude/Differential Pressure Indicator	2F23/15-21	Description	2H9/15-55
Cabin Altitude Warning Light	2F23/15-21	Functional Test of Timer	2H9/15-55
Pressurization System Operation	2F23/15-21	Propeller Anti-Ice System	2H10/15-56
Emergency Operation	2F23/15-21	Removal	2H10/15-56
Trouble Shooting	2F24/15-22	Trouble Shooting	2H11/15-57
Removal/Installation of Components	2G6/15-28	Installation	2H11/15-57
De-Ice/Anti-Ice Systems	2G6/15-28	Slip Ring Alignment Check	2H14/15-60
Wing/Horizontal Stabiliser	2G6/15-28	Timer Test	2H14/15-60
Three-Cycle De-Ice System	2G6/15-28	Installation/Alignment of Brush Block Assembly	2H15/15-61
Description	2G6/15-28	Heated Windshield Panel - Fixed	2H15/15-61
System Operation	2G6/15-28	Description	2H15/15-61
Trouble Shooting	2G7/15-29	Removal/Installation	2H15/15-61
Functional Check	2G15/15-37	Trapped Moisture	2H17/15-63
Adhesive Test	2G16/15-38		
Cleaning De-Ice Boots	2G16/15-38		
Cleaning System Components	2G16/15-38		
De-ice/Anti-Ice Boot			
Protective Products	2G16/15-38		

MODEL P210 SERIES SERVICE MANUAL

Ice Detector Light	2H18/15-64	Installation of Oxygen Generators and Masks	2H21/15-67
Description	2H18/15-64	Oxygen System Indicator Light Switch Adjustment	2H23/15-69
Dual Alternator System	2H18/15-64	Oxygen System (76 Cu. Ft.)	2H23/15-69
Dual Vacuum System	2H18/15-64	Description	2H23/15-69
Control Surface Discharger	2H18/15-64	Maintenance Precautions	2H23/15-69
Description	2H18/15-64	Replacement of Components	2I3/15-73
Inspection	2H18/15-64	Oxygen Cylinder General Information	2I3/15-73
Resistance Check	2H18/15-64	Oxygen Cylinder Service Requirements	2I3/15-73
Removal/Installation	2H18/15-64	Oxygen Cylinder Inspection Requirements	2I4/15-74
Electrical Bonding	2H18/15-64	Oxygen System Component Service Requirements	2I4/15-74
Description	2H18/15-64	Oxygen System Component Inspection Requirements	2I5/15-75
Pitot Tube and Stall Warning	2H18/15-64	Masks and Hose	2I5/15-75
Description	2H18/15-64	Maintenance/Cleaning	2I5/15-75
Removal/Installation	2H21/15-67	System Purging	2I5/15-75
Heated Windshield Panel (Removable)	2H21/15-67	Functional Testing	2I6/15-76
Description	2H21/15-67	System Leak Test	2I6/15-76
Removal/Installation	2H21/15-67	System Charging	2I6/15-76
Oxygen System	2H21/15-67		
Description	2H21/15-67		
Operation	2H21/15-67		
System Operational Status Check	2H21/15-67		
Removal of Oxygen Generators and Masks	2H21/15-67		

MODEL P210 SERIES SERVICE MANUAL

15-1. UTILITY SYSTEMS.

15-2. HEATING AND VENTILATING SYSTEM.

15-3. DESCRIPTION. The P210 aircraft utilizes an integrated series of ducts and valves to supply fresh air ventilation, heated or pressurized air to the cabin.

15-4. CABIN HEAT. A full control range of heated cabin air is available when using the cabin heat control. The control, CABIN HEAT, PULL ON, is mechanically connected to a valve, admitting ram air to a pressurization heat exchanger. The valve allows ram air at outside temperature or heated air from a shroud, surrounding the exhaust manifold, to pass through the heat exchanger. Since the heat exchanger governs the temperature of bleed air fed to the cabin, the setting of the cabin heat control will determine the cabin air temperature. With the cabin heat control pushed fully-in, the air entering the cabin will not be heated. However, pulling the control fully-out results in maximum system heating of incoming cabin air. Cabin heat can be selected with the pressurization system operating to pressurize the cabin or with the cabin unpressurized. To obtain heated air flow, ensure the pressurized air dump valve control is pushed fully-in; then select the desired cabin air temperature by pulling out the cabin heat control as required.

15-5. VENTILATING SYSTEM OPERATION.

(Refer to figure 15-1.) Ventilating airflow in the cabin, while in unpressurized flight, is available from any of three sources, simultaneously or individually; bleed air from the engine turbocharger compressor, ram air from an air scoop door on the lower side of each wing, or outside air from the openable window in the cabin entry door. When the aircraft is on the ground, taxiing or parked, the cabin emergency exit door can be opened to provide an additional ventilating air source.

CAUTION

The aircraft is not approved for flight with the emergency exit door open.

NOTE

Distribution of pressurization source air entering the cabin is controlled by the cabin air selector control. Ram air from the wing air scoops is directed to and controlled by the individual outlets.

A two-speed cabin ventilator fan is located above the headliner to circulate cabin air through the overhead outlets during ground operations or pressurized flight and also, to augment the ram air flow when in unpressurized flight.

Distribution of ventilating airflow, obtained from the ram air from the wing air scoops, is provided by the overhead outlet system. Maximum cabin ventilation during unpressurized flight is obtained by turning the pressurization switch off, opening the individual overhead outlets, turning the ventilation fan on HI, pushing the dump valve control handle full-in and adjusting the cabin air selector control to obtain desired airflow distribution from the forward or floor outlets. In hot weather, use of only the ram air from the wing air scoops (dump valve pulled out) will provide the coolest cabin temperatures.

Whenever bleed air is being used for cabin ventilation (dump valve control pushed full-in) with the cabin unpressurized (pressurization switch OFF), and the aircraft altitude is higher than set on the cabin altitude selector, any loss of electrical power, such as turning off the master switch, will cause the cabin to pressurize. This occurs because the safety/dump valve required electrical power to be held open. An electrical power loss for any reason allows the valve to close, causing the cabin to pressurize. Therefore, if the master switch must be turned off in flight, it is recommended that first, the dump valve control be pulled full-out or the cabin altitude selector be adjusted to a value greater than the aircraft altitude. Under these circumstances, if ventilating air to the cabin is desired, ram air from the wing air scoops to the overhead outlets should be used.

15-6. WINDSHIELD DEFROSTING OR DEFOGGING.

(Refer to figure 15-1.) The aircraft incorporates provisions for windshield defrosting or defogging. Components include a valve, ducting, windshield outlets and a separate defroster control, labeled DEFROST, PULL-ON. The defroster control is located directly above the cabin heat control, and is mechanically connected to the defroster valve. This valve is located in the duct leading to the right side floor level outlet in the cabin. When the defrost control is pulled out, the valve opens to admit bleed air to a series of fixed outlets at the base of the windshield. The volume of airflow supplied to the windshield is, therefore, controlled by the setting of the defrost control. However, the temperature of the air reaching the windshield will be the same as that sup-

MODEL P210 SERIES SERVICE MANUAL

plied to the floor level outlets, and this temperature is dependent on the setting of the cabin heat control. To obtain heated airflow to the windshield for defrosting, the cabin heat control must be pulled to the on position.

15-7. TROUBLE SHOOTING. Most of the operational troubles in the heating and ventilation systems are caused by sticking or binding air valves and their controls, or damaged air ducting. In most cases, valves or controls can be freed by proper lubrication. Damaged or broken parts should be repaired or replaced. When checking controls, be sure valves respond freely to control movement, that they move in the correct direction, and that they move through their full range of travel and seal properly. Check that hoses are properly secured and replace hoses that are burned, frayed or crushed.

15-8. REMOVAL AND INSTALLATION OF COMPONENTS.

a. Figure 15-1 can be used as a guide for removal and installation of system components.

15-9. CABIN PRESSURIZATION.

15-10. OPERATION. When the pressurized mode is selected, the bleed air from the aircraft engine turbo-charger compressor is ducted through a sonic venturi (flow limiter) to a heat exchanger. At the heat exchanger, the bleed air is either heated or cooled, depending on the position of the cabin heat control on the instrument panel. If cool, pressurized air is desired (cabin heat control pushed full-in), ram air from left side of the engine is directed through the heat exchanger, cooling the bleed air. If heated air is desired, the cabin heat control is pulled out. This action closes the heat exchanger to cool ram air flow, and instead, allows heated air, passing through a shroud over the engine left exhaust manifold, to pass through the heat exchanger. Bleed air is heated by this air as it flows through the heat exchanger. From the heat exchanger, the bleed air is ducted to a dump valve chamber on the engine side of the firewall. This chamber houses the pressurization system dump valve and the cabin pressure check valve. In order for pressurized bleed air to enter the cabin from the dump valve chamber, the dump valve control handle on the left side of the instrument panel must be pushed fully-in, closing the valve. Otherwise, with the dump valve handle pulled out (dump valve open), bleed air will dump from the chamber to the inside of the engine compartment, flowing overboard through the cowl flaps. The other component of the dump valve chamber, the cabin pressure check valve, closes to prevent a sudden loss in cabin pressure, such as when the dump valve is opened, or the engine fails to provide sufficient pressurized air flow. A cabin air selector valve chamber is located on the cabin side of the dump valve chamber. The air selector valve allows selection of either a pair of forward outlets or a pair of floor level fixed outlets, or both systems, depending upon the position of the air selector control, located on the lower right side of the instrument panel. Cabin pressure is controlled by two dual-purpose valves on the aft cabin bulkhead. One valve functions

as an outflow valve, and begins to regulate air flow from the cabin as the aircraft climbs through the altitude selected for pressurization to begin. The outflow valve will continue to regulate air flow until maximum cabin differential pressure is reached, at which point, the valve will maintain this pressure differential. The other valve is a safety dump valve that contains an electric solenoid which, when the pressurization switch is placed in the OFF position, activates and opens the valve, dumping cabin pressure overboard. Both valves have as an integral part, differential pressure valves. The one in the outflow valve prevents cabin differential pressure from exceeding 2.35 PSI. In the event this valve fails, another one, incorporated into the safety/dump valve, will actuate and prevent the cabin differential pressure from exceeding 3.50 PSI. Anytime the cabin is not pressurized, outside air from the wing leading edge intakes may be vented into the cabin through the overhead outlets. When the cabin is pressurized, the flow of outside air is stopped by two pressure check valves, located in the wing roots.

15-11. PRESSURIZATION CONTROLS AND INDICATORS. (See figure 15-1.)

15-12. CABIN ALTITUDE SELECTOR. A cabin altitude selector, labeled ALT SEL, is mounted on the lower left side of the instrument panel. This control is used in selecting the altitude at which pressurization will begin and be maintained by controlling the outflow valve. The selector control knob has an outer scale marked SL, indicating sea level, and additional positions marked 1 through 10, indicating thousands of feet. An inner scale is included on this knob, which reflects the cabin altitude in relation to the cabin altitude selected on the outer scale at maximum cabin pressure differential.

15-13. CABIN PRESSURIZATION SWITCH. A detent-equipped switch, adjacent to the cabin altitude selector, turns the pressurization system on or off, depending on its position. The detent requires that the switch be pulled out before repositioning, thus preventing inadvertent actuation. The two-position switch is labeled PRESSURE, and is ON in the up position, and OFF in the down position. When the switch is placed in the ON position, electrical power to a solenoid in the safety/dump valve is removed and the valve will close to permit pressurization. In the OFF position, electrical power is applied to the safety/dump valve solenoid, and the valve will open to prevent pressurization. Loss of electrical power, for any reason, will cause the safety/dump valve to close.

15-14. DUMP VALVE CONTROL HANDLE. A T-handle, labeled CABIN PRESSURE, PULL TO DUMP, is located on the lower left side of the instrument panel, adjacent to the master switch. This handle is mechanically connected to the dump valve, located in the dump valve chamber, on the engine side of the firewall. When the handle is pulled, the dump valve opens and allows pressurization air to flow overboard. With the handle pushed in, pressurized air flows to the cabin through the selector valve.

MODEL P210 SERIES SERVICE MANUAL




Figure 15-1. Heating, Ventilating and Pressurization System (Sheet 1 of 4)

MODEL P210 SERIES SERVICE MANUAL






Figure 15-1. Heating, Ventilating and Pressurization System (Sheet 2 of 4)


MODEL P210 SERIES SERVICE MANUAL




Detail E



Detail F



Detail G



Detail H

- 31. Defroster Valve
- 32. Shutoff Valve
- 33. Interconnect Rod
- 34. Defroster Valve
- 35. Defroster Vent
- 36. Cabin Air Check Valve
- 37. Air Inlet Duct Assembly
- 38. Overhead Air Control
- 39. Bellcrank
- 40. Pushrod
- 41. Door Assembly Air-Inlet
- 42. Cover Assembly

Figure 15-1. Heating, Ventilating and Pressurization System (Sheet 3 of 4)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-1. Heating, Ventilating and Pressurization System (Sheet 4 of 4)

MODEL P210 SERIES SERVICE MANUAL

15-15. CABIN AIR SELECTOR CONTROL. A push-pull type control labeled FWD AIR/PUSH, FLOOR DEFROST/PULL, permits incoming pressurized air to be directed to the two forward air outlets or to the two floor level outlets. With the cabin air selector control pushed fully in, pressurized air passes to the forward outlets. With the control pulled fully out, all airflow is diverted to the floor level outlets. A push-button type lock on the cabin air selector control allows positioning the control to any intermediate setting between full in and full out, which results in pressurized airflow to both pairs of outlets.

15-16. CABIN RATE-OF-CLIMB INDICATOR. A cabin rate-of-climb indicator is located on the left side of the instrument panel above the dump valve control handle. The instrument is vented directly to the cabin and senses changes in pressure within the cabin to show cabin rate-of-climb or descent.

15-17. CABIN ALTITUDE/DIFFERENTIAL PRESSURE INDICATOR. This instrument located adjacent to the cabin rate-of-climb indicator, shows both cabin altitude and differential pressure. It has two dials and two pointers. The outside dial indicates cabin altitude, and the inside dial indicates the pressure differential between cabin pressure and atmospheric pressure. The instrument is vented to the aircraft cabin and the static air source.

15-18. CABIN ALTITUDE WARNING LIGHT. Anytime the cabin altitude exceeds $12,400 \pm 100$ feet, a barometric switch closes and illuminates a red press-to-test warning light labeled CABIN ALTITUDE. The light, located on the upper left corner of the instrument panel, indicates that cabin altitude is too high and corrective action must be taken. Oxygen should be employed, if available. If oxygen is not available, the aircraft should be flown to a lower altitude. When the aircraft descends to a cabin altitude of approximately 11,700 feet, the barometric switch opens and the warning light turns off.

15-19. PRESSURIZATION SYSTEM OPERATION. Refer to the Pilot's Operating Handbook for a complete pressurization system operation description.

15-20. EMERGENCY OPERATION. In the event of contamination of the pressurized air from oil, smoke or exhaust fumes in the pressurized air system, it is possible to dump the pressurized air overboard by pulling the dump control full aft. A check valve, located on the cabin side of the firewall, will close, preventing rapid loss of cabin pressure. Cabin altitude will then rise to aircraft altitude.

MODEL P210 SERIES SERVICE MANUAL

15-21. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
CABIN DOES NOT PRESSURIZE. (Turbocharger operating within limits outlined in Section 12 of this manual.)	Safety valve will not close.	Check position of pressurization switch; should be ON.
		Check vent screen; if dirty, clean.
		Check circuitry to valve solenoid.
	Outflow valve will not control.	Check setting of cabin altitude controller.
		Check screen on altitude controller. if obstructed, clean.
	Insufficient air supply.	Check position of pressurized air dump controls; "Push in" for pressurization. Check venturi, ducting, connections, valving and rigging for leaks; repair.
CABIN PRESSURE WILL NOT GO TO MAXIMUM DIFFERENTIAL. (Turbocharger operating within limits outlined in Section 12 of this manual.)	Insufficient air supply.	Check position of pressurized air dump controls; "Push in" for pressurization. Check venturi, ducting, connections, valving and rigging for leaks; repair.
	Excessive cabin leakage.	Locate leakage areas and repair as required.
	Outflow valve not regulating properly.	Replace valve.
	Cabin differential gage not indicating properly.	Replace gage.
	Fresh air check valve not sealing.	Inspect valves. Clean or repair as required.
CABIN PRESSURE EXCEEDS MAXIMUM DIFFERENTIAL.	Outflow valve not regulating properly.	Replace valve.
	Cabin differential gage not indicating properly.	Replace gage.
	Safety valve not regulating properly.	If more than 3.5 psi, replace valve.
CABIN PRESSURE GOES TO MAXIMUM DIFFERENTIAL INDEPENDENT OF AIRCRAFT ALTITUDE.	Outflow valve controlling immediately.	Control line plumbing leaking or ruptured.
		Leak in casting of outflow valve; replace.

MODEL P210 SERIES SERVICE MANUAL

15-21. TROUBLE SHOOTING (Cont):

TROUBLE	PROBABLE CAUSE	REMEDY
CABIN ALTITUDE OVER-SHOOTS ALTITUDE ON SELECTOR.	Poppet valve is sticking in closed position.	Replace selector.


CABIN PRESSURE FLUCTUATION ON FULL DIFFERENTIAL.

Safety Valve Discrepant

Replace Safety Valve.

If volume of shop air is adequate and aircraft can be pressurized on the ground, then cabin leak down rate can be checked as follows:

- a. Connect shop air to hose (2) between heat exchanger and firewall.
- b. Connect a mercury manometer to the small connection (1) located on the right hand side of the firewall.
- c. Disconnect hose (5) between cabin altitude controller (3) and outflow valve (4).
- d. Turn master switch on and turn cabin pressure switch on.
- e. Close cabin windows and door and lock from outside with key.
- f. Apply shop air through a control valve to permit gradual flow.



MODEL P210 SERIES SERVICE MANUAL

15-21. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
<p>g. Increase cabin pressure to 6.5" of mercury and turn off air control valve.</p> <p>h. Start timing when manometer descends through 6" of mercury.</p> <p>i. Note time manometer reaches 4" of mercury.</p> <p>j. Leak down rate is acceptable, if time noted between steps "h" and "i" is no less than 10 seconds.</p> <p>P210 CABIN PRESSURE LEAK CHECK POINTS.</p> <ol style="list-style-type: none"> 1. Cabin door seal 2. Emergency door seal 3. Landing gear bulkhead (forward channel) 4. Downlock actuator boot (Check for leaks with gear retracted) 5. Nose gear steering boot 6. Base of hat section channels on aft pressure bulkhead (at floorboard) 7. Hat section stringers running through aft pressure bulkhead outboard of overhead windows (plug inside of stringer) 8. Seals around carry-thru spar 9. Fresh air check valves in wing roots 10. Water drain check valves 11. Tunnel area under pedestal up to firewall 12. Forward firewall (wire bundle and engine control holes) 13. Forward firewall upper outboard corners 14. Seals on floorboard covers (aft of landing gear bulkhead) 		
<p>CABIN ALTITUDE INCREASES WITH REDUCED POWER.</p>	<p>Faulty turbocharger controller.</p>	<p>Troubleshoot turbocharger per Section 12 of this manual.</p>
<p>CABIN DEPRESSURIZES SUDDENLY OR INTERMITTENTLY.</p>	<p>Switch inadvertently turned to OFF.</p>	<p>Place switch ON; check switch, wiring or solenoid valve in safety valve for operation and security.</p>
<p>CABIN PRESSURIZATION AIR NOT COOLING</p>	<p>Obstruction in heat exchanger ram air duct.</p>	<p>Remove obstruction.</p>

MODEL P210 SERIES SERVICE MANUAL




Figure 15-2. Cabin Air Flow Schematic (Sheet 1 of 3)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-2. Cabin Air Flow Schematic (Sheet 2 of 3)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-2. Cabin Air Flow Schematic (Sheet 3 of 3)

MODEL P210 SERIES SERVICE MANUAL

15-22. REMOVAL AND INSTALLATION OF COMPONENTS (Refer to figure 15-1.)

a. Remove and install safety valve and/or outflow valve as follows:

1. Peel cover from forward side of pressure bulkhead and disconnect wires and tubes from valve.
2. Working through aft baggage compartment, cut safety wire from attaching bolts; remove bolts.
3. Remove valves from pressure bulkhead.

NOTE

Use all new gaskets when installing safety valve or outflow valve. The rubber portion of the valves may be cleaned with dish washing detergent or isopropyl alcohol.

4. To install valve, have an assistant hold valve in place from inside cabin while bolts are being started.

5. Snug bolts down evenly and torque bolts (alternating from side-to-side and top-to-bottom) to value specified in figure 15-1.

6. Install new safety wire through bolts and reconnect wires and tubes to valve(s).

7. Replace bulkhead cover.

b. Figure 15-1 may be used as a guide while removing and installing remaining components.

15-22A. CABIN PRESSURIZATION. (GARRETT SYSTEM).

15-22B. OPERATION. When the pressurized mode is selected, the cabin pressure switch is in the pressurized position, dump valve control is pushed full in and the cabin outflow valve controller set approximately 500 to 1000 ft. above field elevation. This allows air from the compressor section of the engine turbocharger to pressurize the cabin. Bleed air from the engine turbocharger compressor section flows to the induction section and also through a venturi (flow meter) through a dual pass heat exchanger and firewall diverter valve into the cabin when the air pressure climbs above the set altitude. At the dual pass heat exchanger, pressurized air can be cooled or heated as desired. For cooling, outside air is directed from above the baffles on the left side of the cowling, through the heat exchanger and then dumped overboard. When heating of pressurized air is required, air under the baffles is pulled through shroud around the left-hand exhaust stack assembly, routed through the heat exchanger and then dumped overboard. Ambient and heated air can be mixed to provide a range of cabin air temperatures. In the cabin, pressurized air flows from the diverter valve on the firewall, through a duct to outlets on the forward doorposts. The pressurized air can also be directed to outlets on the firewall. In the event of contamination of the pressurized air from oil, smoke, or exhaust fumes in the pressurization air system, it is possible to dump the pressurized air overboard by pulling the dump valve control full aft. A check valve located on the cabin side of the firewall will close preventing rapid loss of cabin pressure. Cabin elevation will then raise to aircraft altitude.

The system consists of an outflow valve controller, an outflow valve, a safety valve, an auxiliary volume tank, two differential pressure controllers, a solenoid air valve and a switch. The system has a differential pressure of 3.35 PSI. This differential provides a 12,127 foot cabin at an airplane operating altitude of 23,000 feet, a 10,000 foot cabin at an airplane altitude of 20,000 feet, and a 4,000 foot cabin at an airplane altitude of 12,000 feet. Cabin pressure as well as rate of change of the cabin pressure is controlled with the outflow valve controller. The cabin altitude selector knob on the outflow valve controller allows the selection for cabin pressurization to start anywhere between sea level and 10,000 feet. The smaller knob on the outflow valve controller controls cabin pressure rate of change.

Two valves are mounted on the aft bulkhead. The right-hand valve is connected to the controller by a .25 dia. plastic tube and controls cabin pressure up to maximum differential. The left-hand valve, called a safety valve, provides means for the pilot to initiate pressurization or to dump cabin pressure. A panel-mounted switch is wired to the solenoid air valve. The solenoid air valve is plumbed into a .25 dia. plastic tube which runs between the safety valve and the airplane vacuum system. Both the outflow and safety valve incorporate an automatic negative pressure relief. A differential pressure controller is plumbed into both the outflow and safety valves. These controllers, located next to each valve, control maximum differential pressure. The outflow valve differential pressure controller is set at $3.35 + .10, -.05$ PSI and the safety valve differential pressure controller is set at $3.40 \pm .10$.

15-22C. PRESSURIZATION CONTROLS AND INDICATORS (See figure 15-2A.)

15-22D. CABIN ALTITUDE CONTROL. A cabin altitude control, labeled ALT SEL, is mounted on the lower left side of the instrument panel. The cabin outflow valve controller is used to select the desired altitude from 500 feet below sea level to 10,500 feet at which pressurization begins. The selector control knob rotates a dual scale below a fixed window. The outer scale marked SL, indicating sea level and additional positions marked 1 through 10, indicating thousands of feet. An inner scale reflects the aircraft altitude in relation to the cabin altitude selected on the outer scale at maximum normal cabin pressure differential. A second knob on the lower left hand side of the cabin altitude control is labeled, RATE CONTROL. This knob controls the size of an orifice, vented to cabin pressure, at the back of the unit. The size of the orifice, determines the rate at which the cabin altitude control changes the cabin pressure.

15-22E. CABIN PRESSURIZATION SWITCH. A detent-equipped switch, adjacent to the cabin altitude selector, turns the pressurization system on or off, depending on its position. The detent requires that the switch be pulled out before reposition-

MODEL P210 SERIES SERVICE MANUAL




Figure 15-2A. Heating, Ventilating and Pressurization System (Sheet 1 of 4)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-2A. Heating, Ventilating and Pressurization System (Sheet 2 of 4)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-2A. Heating, Ventilating and Pressurization System (Sheet 3 of 4)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-2A. Heating, Ventilating and Pressurization System (Sheet 4 of 4)

MODEL P210 SERIES SERVICE MANUAL

ing, thus preventing inadvertent actuation. The two-position switch is labeled PRESSURE, and is ON in the up position, and OFF in the down position. When the switch is placed in the ON position, electrical power to a solenoid in the safety/dump valve is removed and the valve will close to permit pressurization. In the OFF position, electrical power is applied to the safety/dump valve solenoid, and the valve will open to prevent pressurization. Loss of electrical power, for any reason, will cause the safety/dump valve to close.

15-22F. DUMP VALVE CONTROL HANDLE. A T-handle, labeled CABIN PRESSURE, PULL TO DUMP, is located on the lower left side of the instrument panel, adjacent to the master switch. This handle is mechanically connected to the dump valve, located in the dump valve chamber, on the engine side of the firewall. When the handle is pulled, the dump valve opens and allows pressurization air to flow overboard. With the handle pushed in, pressurized air flows to the cabin through the selector valve.

15-22G. CABIN AIR SELECTOR CONTROL. A push-pull type control labeled FWD AIR/PUSH, FLOOR DEFROST/PULL, permits incoming pressurized air to be directed to the two forward air outlets or to the two floor level outlets. With the cabin air selector control pushed fully in, pressurized air passes to the forward outlets. With the control pulled fully out, all airflow is diverted to the floor level outlets. A push-button type lock on the cabin air selector control allows positioning the control to any intermediate setting between full in and full out, which results in pressurized airflow to both pairs of outlets.

15-22H. CABIN RATE-OF-CLIMB INDICATOR. A cabin rate-of-climb indicator is located on the left side of the instrument panel above the dump valve

control handle. The instrument is vented directly to the cabin and senses changes in pressure within the cabin to show cabin rate-of-climb or descent.

15-22I. CABIN ALTITUDE/DIFFERENTIAL PRESSURE INDICATOR. This instrument located adjacent to the cabin rate-of-climb indicator, shows both cabin altitude and differential pressure. It has two dials and two pointers. The outside dial indicates cabin altitude, and the inside dial indicates the pressure differential between cabin pressure and atmospheric pressure. The instrument is vented to the aircraft cabin and the static air source.

15-22J. CABIN ALTITUDE WARNING LIGHT. Anytime the cabin altitude exceeds 12,325 ± 175 feet, a barometric switch closes and illuminates a red press-to-test warning light labeled CABIN ALTITUDE. The light, located on the upper left corner of the instrument panel, indicates that cabin altitude is too high and corrective action must be taken. Oxygen should be employed, if available. If oxygen is not available, the aircraft should be flown to a lower altitude. When the aircraft descends to a cabin altitude of approximately 11,700 feet, the barometric switch opens and the warning light turns off.

15-22K. PRESSURIZATION SYSTEM OPERATION. Refer to the Pilot's Operating Handbook for a complete pressurization system operation description.

15-22L. EMERGENCY OPERATION. In the event of contamination of the pressurized air from oil, smoke or exhaust fumes in the pressurized air system, it is possible to dump the pressurized air overboard by pulling the dump control full aft. A check valve, located on the cabin side of the firewall, will close, preventing rapid loss of cabin pressure. Cabin altitude will then rise to aircraft altitude.

MODEL P210 SERIES SERVICE MANUAL

15-22M. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
CABIN DOES NOT PRESSURIZE. (Turbocharger operating within limits outlined in Section 12 of this manual.)	Safety valve will not close.	Check position of pressurization switch; should be ON.
		Check vent screen; if dirty, clean.
		Check circuitry to valve solenoid.
	Outflow valve will not control.	Check setting of cabin altitude controller.
		Check screen on altitude controller, if obstructed, clean.
	Insufficient air supply.	Check position of pressurized air dump controls; "Push in" for pressurization. Check venturi, ducting, connections, valving and rigging for leaks; repair.
CABIN PRESSURE WILL NOT GO TO MAXIMUM DIFFERENTIAL. (Turbocharger operating within limits outlined in Section 12 of this manual.)	Insufficient air supply.	Check position of pressurized air dump controls; "Push in" for pressurization. Check venturi, ducting, connections, valving and rigging for leaks; repair.
	Excessive cabin leakage.	Locate leakage areas and repair as required.
	Outflow valve not regulating properly.	Replace valve.
	Cabin differential gage not indicating properly.	Check with HG monometer. Replace gage.
	Fresh air check valve not sealing.	Inspect valves. Clean or repair as required.
CABIN PRESSURE EXCEEDS MAXIMUM DIFFERENTIAL.	Differential Pressure Controller Valve not regulating properly.	Replace valve.
	Cabin differential gage not indicating properly.	Check with HG monometer. Replace gage.
	Differential Controller not regulating properly.	If more than 3.5 psi, replace valve.
CABIN PRESSURE GOES TO MAXIMUM DIFFERENTIAL INDEPENDENT OF AIR-CRAFT ALTITUDE.	Outflow valve controlling immediately.	Control line plumbing leaking or ruptured.
		Leak in casting of outflow valve; replace.

MODEL P210 SERIES SERVICE MANUAL

15-22M. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
CABIN ALTITUDE OVER-SHOOTS ALTITUDE ON SELECTOR.	Poppet valve is sticking in closed position.	Replace selector.


CABIN PRESSURE FLUCTUATION ON FULL DIFFERENTIAL.

Safety Valve Discrepant

Replace Safety Valve.

If volume of shop air is adequate and aircraft can be pressurized on the ground, then cabin leak down rate can be checked as follows:

- a. Connect shop air to hose (2) between heat exchanger and firewall.
- b. Connect a mercury manometer to the small connection (1) located on the right hand side of the firewall.
- c. Disconnect hose (5) between cabin altitude controller (3) and outflow valve (4).
- d. Turn master switch on and turn cabin pressure switch on.
- e. Close cabin windows and door and lock from outside with key.
- f. Apply shop air through a control valve to permit gradual flow.



MODEL P210 SERIES SERVICE MANUAL

15-22M. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
<p>g. Increase cabin pressure to 6.5" of mercury and turn off air control valve.</p> <p>h. Start timing when manometer descends through 6" of mercury.</p> <p>i. Note time manometer reaches 4" of mercury.</p> <p>j. Leak down rate is acceptable, if time noted between steps "h" and "i" is no less than 10 seconds.</p> <p>P210 CABIN PRESSURE LEAK CHECK POINTS.</p> <ol style="list-style-type: none"> 1. Cabin door seal 2. Emergency door seal 3. Landing gear bulkhead (forward channel) 4. Downlock actuator boot (Check for leaks with gear retracted) 5. Nose gear steering boot 6. Base of hat section channels on aft pressure bulkhead (at floorboard) 7. Hat section stringers running through aft pressure bulkhead outboard of overhead windows (plug inside of stringer) 8. Seals around carry-thru spar 9. Fresh air check valves in wing roots 10. Water drain check valves 11. Tunnel area under pedestal up to firewall 12. Forward firewall (wire bundle and engine control holes) 13. Forward firewall upper outboard corners 14. Seals on floorboard covers (aft of landing gear bulkhead) 		
CABIN ALTITUDE INCREASES WITH REDUCED POWER.	Faulty turbocharger controller.	Troubleshoot turbocharger per Section 12 of this manual.
CABIN DEPRESSURIZES SUDDENLY OR INTERMITTENTLY.	Switch inadvertently turned to OFF.	Place switch ON; check switch, wiring or solenoid valve in safety valve for operation and security.
CABIN PRESSURIZATION AIR NOT COOLING	Obstruction in heat exchanger ram air duct.	Remove obstruction.

MODEL P210 SERIES SERVICE MANUAL




Figure 15-2B. Cabin Air Flow Schematic (Sheet 1 of 3)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-2B. Cabin Air Flow Schematic (Sheet 2 of 3)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-2B. Cabin Air Flow Schematic (Sheet 3 of 3)

MODEL P210 SERIES SERVICE MANUAL

15-22N. REMOVAL AND INSTALLATION OF COMPONENTS (See figure 15-2A)

a. Remove and install safety valve and/or outflow valve as follows:

1. Peel cover from forward side of pressure bulkhead and disconnect wires and tubes from valve.
2. Working through aft baggage compartment, remove nuts.
3. Remove valves from pressure bulkhead.

NOTE

Use all new gaskets when installing safety valve or overflow valve. The plastic portion of the valves may be cleaned with dishwashing detergent or isopropyl alcohol.

4. To install valve, have an assistant hold valve in place from inside cabin while nuts are being started.

5. Snug nuts down evenly and torque bolts (alternating from side-to-side and top-to-bottom) to 10-12 lbs. inch.

6. Install new safety wire through bolts and reconnect wires and tubes to valve(s).

7. Replace bulkhead cover.

b. Figure 15-1 may be used as a guide while removing and installing remaining components.

15-23. DE-ICE AND ANTI-ICE SYSTEMS.

15-24. WING AND HORIZONTAL STABILIZER THREE-CYCLE DE-ICE SYSTEM. (See figure 15-3.)


15-25. DESCRIPTION. The system consists of pneumatically-operated boots, dual engine-driven vacuum pumps, an annunciator light to monitor system operation, system controls and the hardware necessary to complete the system.

15-26. SYSTEM OPERATION. The boots expand and contract, using pressure or vacuum from the engine-driven vacuum pumps. Normally, vacuum is applied to all boots to hold them against the leading edge surfaces. When a de-icing cycle is initiated, the vacuum is removed and pressure is applied to

"inflate" the boots. Ice on the boots will then be removed by normal in-flight air forces. Controls for the system consist of a spring-loaded on-off rocker switch on the left switch and control panel, a pressure indicator light on the upper left side of the instrument panel, and a 5-amp "pull-off" type circuit breaker on the left sidewall circuit breaker panel. The two-position de-icing switch, labeled DE-ICE PRESS, is spring-loaded to the normal off (lower) position. When pushed to the ON (upper) position and released, it will activate one de-icing cycle. Each time a cycle is desired, the switch must be pushed to the ON position and released. If necessary, the system can be stopped at any point in the cycle (deflating the boots) by pulling out the circuit breaker labeled WING, DE-ICE. During a normal de-icing cycle, the boots will inflate according to the following sequence: first, the horizontal stabilizer boots will inflate for approximately six seconds, then the inboard boots inflate for the next six seconds, followed by the outboard wing boots for another six seconds. The total time required for one cycle is approximately 18 seconds. The pressure indicator light, labeled DE-ICE PRESSURE, should illuminate when the horizontal stabilizer boots reach proper operating pressure. At lower altitudes, it should come on within one to two seconds after the cycle is initiated and remain on for approximately 17 seconds if the system is operating properly. At higher altitudes, the light will come on initially within three seconds and will go off for one to three seconds during sequencing. The system may be recycled six seconds after the light goes out. The absence of illumination during any one of the three sequences of a cycle indicates insufficient pressure for proper boot inflation and effective de-icing ability. An ice detector light is also installed to facilitate detection of wing ice at night or during reduced visibility. The ice detector light system consists of a light installed on the left side of the cowl deck forward of the windshield which is positioned to illuminate the leading edge of the wing, and a rocker-type switch, labeled DE-ICE LIGHT, located on the left switch and control panel.


MODEL P210 SERIES SERVICE MANUAL

15-27. TROUBLE SHOOTING



MODEL P210 SERIES SERVICE MANUAL

15-27. TROUBLE SHOOTING (Cont.)



MODEL P210 SERIES SERVICE MANUAL




Figure 15-3. Wing and Horizontal Stabilizer De-Icing System (Sheet 1 of 5)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-3. Wing and Horizontal Stabilizer De-Icing System (Sheet 2 of 5)

MODEL P210 SERIES SERVICE MANUAL





Figure 15-3. Wing and Horizontal Stabilizer De-Icing System (Sheet 3 of 5)

MODEL P210 SERIES SERVICE MANUAL



- 23. Plug
- 28. Vacuum Hold-Down Line
- 29. Hose - To Pressure Regulator Valve
- 31. Pressure Regulator Valve
- 32. Bracket
- 33. De-Ice Flow Valve
- 34. Hose - To Pressure Switch
- 35. Hose - To Right Hand Stabilizer Boot
- 36. Pressure Switch
- 37. Electrical Leads
- 38. Hose - To Left Hand Stabilizer Boot
- 39. Wing De-Ice Circuit Breaker
- 40. Circuit Breaker Panel
- 41. Stall Heat Circuit Breaker
- 42. Pitot Heat Circuit Breaker
- 43. Windshield Anti-Ice Circuit Breaker
- 44. Prop Anti-Ice Circuit Breaker

Figure 15-3. Wing and Horizontal Stabilizer De-Icing System (Sheet 4 of 5)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-3. Wing and Horizontal Stabilizer De-Icing System (Sheet 5 of 5)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-4. Surface De-Ice System Components Schematic

MODEL P210 SERIES SERVICE MANUAL

15-28. DE-ICE SYSTEM FUNCTIONAL CHECK.

(See figure 15-3.)

- a. Electrical Controls Check:
 1. Check wing de-ice circuit breaker (39) closed.
 2. Check de-ice pressure switch (50) off (spring-loaded to off position).
 3. Turn master switch on.
 4. Press de-ice pressure light (46) to check light circuit and bulb. Make sure dimming shutter is open.
 5. Turn master switch off.
- b. Vacuum Relief Valve(s) Adjustment.
 1. Refer to Section 16 of this manual for vacuum relief valve(s) adjustment.
- c. Preflight System Check:
 1. With vacuum relief valve(s) adjusted and engine running from 2200 to 2500 rpm, check both buttons on the suction gage are retracted out of sight and vacuum is normal.
 2. Place de-ice pressure switch (50) on, and release.
 3. Check that de-ice pressure light (46) comes on within one second, remains on for 18 seconds, then shuts off.
 4. Check boots for inflation during 18 second cycle as follows: First six seconds tail section boots, then inboard wing boots for next six seconds. finally the outboard wing boots inflate for six seconds completing one cycle.
 5. The absence of or slow illumination of the de-ice pressure light during any one of the three sequences of a cycle indicates insufficient pressure for proper system operation.
- d. Timer Check:
 1. Refer to paragraph 15-41 for timer checks.
- e. Air Pressure Check:

NOTE

This check may be performed in the engine compartment.

1. Disconnect both pressure hoses (1) and (6) from pressure control valves (9).
2. Connect a source of clean regulated dry air pressure (21 ±1psig) fitted with a hand-operated valve or check valve and an in-line air pressure gauge to right pump pressure hose (1).

NOTE

A test kit (#343) for testing vacuum and pneumatic de-ice system is available from Airborne, 711 Taylor Street, Elyria, Ohio 44035, or the Cessna Supply Division. This kit contains the necessary equipment and supplemental instructions to perform this check.

3. Disconnect left and right vacuum inlet hoses from left and right vacuum pumps (8).
4. Disconnect electrical leads from pressure control valves (9).

CAUTION

Do not attempt air pressure check with de-ice timer module connected into the circuit.

5. Connect a vacuum source (5.6 in. Hg minimum) to right pump vacuum hose.
6. Connect a switched 28 VDC electrical source to right pressure control valve.
7. Insert pressure probe equipped with vacuum/pressure gage into the rubber hose connecting tail boots with tail boot flow valve.
8. Turn on pressure and vacuum sources. Verify that pressure flow is being vented overboard at right pressure control valve and no flow is present either in or out of disconnected hoses at left vacuum pump. Pressure gage on probe should read 4.5-4.6 in. Hg vacuum.
9. Switch on electrical power to right pressure control valve and actuate tail boot flow control manually.

NOTE

Flow valves can be actuated mechanically by depressing the solenoid plunger inward using the fingers. This procedure eliminates the necessity of disconnecting and reconnecting electrical leads.

10. Overboard flow at pressure control valve should stop and pressure air should inflate tail boots. Pressure gage should show 18 ±.5 psi with audible venting of pressure air from pressure regulator valve (31) evident. Recheck for absence of airflow out of left pressure control valve.

11. With pressure control valve energized turn off pressure source using hand-operated valve. Pressure leak-down as shown by probe pressure gage should be 2 psi per minute or less. Use soap and water solution to locate leaks, turn off power to left pressure control valve, repair leaks and retest until leak-down rate is within tolerance.

12. Insert pressure probe into hose connecting outboard wing boots with outboard boot flow control valve and repeat steps 8 thru 11 noting leaks.

13. Insert pressure probe into hose connecting inboard wing boots with inboard boot flow control valve and repeat steps 8 thru 11 noting leaks.

14. Disconnect pressure and vacuum sources from right vacuum pump hoses and connect to left pump hoses.

15. Turn on pressure and vacuum sources. Verify that pressure flow is being vented overboard at left pressure control valve and no flow is present either in or out of disconnected hoses at right pump. Probe pressure gage should read 4.5-5.6 in. Hg vacuum.

16. Switch on electrical power to left pressure control valve. Overboard flow at pressure control valve should stop. Check for no airflow from right pressure control valve and audible venting of pressure air from pressure regulator valve (31) evident.

MODEL P210 SERIES SERVICE MANUAL

17. With probe air pressure gauge inserted into hose connecting any flow valve with its associated de-ice boot, actuate flow valve manually, and recheck probe air pressure gauge reads 18 ± 5 psi.

18. Disconnect test equipment and reconnect pressure and vacuum lines to vacuum pumps.

19. Reconnect wiring to pressure control valves.

15-29. ADHESION TEST.

a. Using excess material trimmed from ends of any wing or empennage de-ice boot, prepare one test specimen for each de-ice boot installed.

b. This specimen should be one-inch wide and four or more inches long.

c. Cement specimen to installation surface adjacent to installed de-ice boot, following the identical procedure used for boot installation.

d. Leave one-inch of the strip uncemented to attach a clamp.

e. Four hours or more after de-ice boot installation, attach a spring scale to uncemented end of each strip and measure force required to remove the strip at a rate of one-inch per minute. The pull shall be applied 180° to the surface. (Strip doubled back on itself).

f. A minimum of five pounds tension (pull) shall be required to remove test strip.

NOTE

If less than five pounds is required acceptability of the de-ice boot adhesion shall be based on carefully lifting one corner of the de-ice boot in question sufficiently to attach a spring clamp and attaching a spring scale to this clamp. Pull with force 180° to the surface, and in such a direction that the de-ice boot tends to be removed on the diagonal. If a force of five pounds per inch of width can be exerted under these conditions, the installation shall be considered satisfactory. Width increases as corner peels back.

g. Re-cement corner following installation procedure.

CAUTION

Failure to achieve five pounds adhesion per inch of width requires reinstallation of the de-ice boot.

NOTE

Possible reasons for failure are: dirty surfaces, cement not mixed thoroughly. Corrosion of metal skin may occur if good adhesion is not attained, especially around rivet heads and metal skin splices. If these adhesion requirements are met, the aircraft may be flown immediately. Do not inflate de-ice boots within 48 hours of installation.

15-30. CLEANING DE-ICE BOOTS.

CAUTION

Use only the following instructions when cleaning de-ice/anti-ice boots. Disregard instructions which recommend petroleum base liquids (MEK, non-leaded gasoline, etc.) which can harm boot material.

a. Clean boots with mild soap and water. then rinse thoroughly with clean water.

NOTE

Isopropyl alcohol can be used to remove grime which cannot be removed using soap. If isopropyl alcohol is used for cleaning, wash area with mild soap and water, then rinse thoroughly with clean water.

15-31. CLEANING SYSTEM AND COMPONENTS. Follow procedures as outlined in Section 16 of this manual for removal and installation. In general, low pressure, dry compressed air should be used in cleaning vacuum system components. Suction relief valve should be washed with Stoddard solvent, then dried with low-pressure air blast.

CAUTION

Never apply compressed air to lines or components installed in aircraft. The excessive pressures will damage gyros. If an obstructed line is to be blown out, disconnect at both ends and blow from instrument panel out.

15-32. DE-ICE AND ANTI-ICE BOOT PROTECTIVE PRODUCTS. Two rubber treatment products, Age Master #1, and Icx are approved for use on de-ice boots and anti-ice boots of Cessna aircraft. Age Master #1 protects the rubber against deterioration from ozone, sunlight weathering, oxidation and pollution. Icx helps retard ice adhesion and keeps the boots looking new longer; both products are produced and recommended by B. F. Goodrich. Age Master #1 (part #74-451-127) and Icx (part # ICEx) are available from the Cessna Supply Division.

a. Mask surrounding areas before applying Age Master #1 to clean, dry boot surfaces. Apply with a cheesecloth swab. DO NOT SPRAY this product; a rubbing or brushing action is required for the protective agent to penetrate the rubber surfaces. Apply three or more coats allowing a 5 to 10 minute drying period between applications. However, the total amount applied should not exceed 0.3 to 0.4 ounce per square foot of boot surface.

b. Mask surrounding areas before applying a light coat of Icx with a cheesecloth swab to clean, dry boot surfaces. A heavy coat of Icx will result in a

MODEL P210 SERIES SERVICE MANUAL

sticky surface which collects dust and dirt. One quart of Icx will cover approximately 500 square feet. If boots have been treated with Age Master #1, allow it to dry for a minimum of 24 hours before applying the Icx. Apply Icx Spanwise in a single continuous back and forth motion.

CAUTION

Protect adjacent areas, clothing, and wear plastic or rubber gloves during application. Age Master stains clothing and Icx contains silicone which makes paint touch-up nearly impossible. Waterless hand cleaner is beneficial for cleaning hands, equipment and clothing.

Age Master #1 and Icx coatings last approximately 150 hours on wing and stabilizer boots and 15 hours on propeller boots.

15-33. APPROVED REPAIRS. (Cold Patch for Scuff or Surface Damage.)

NOTE

Surface coatings and surface refurbishing kits will not repair leaks. Use repair kit materials.

NOTE

When repairing de-ice boots and replacement layers are being installed, exercise care to prevent trapping air beneath the replacement layers. If air blisters appear after material is applied, they may be removed with a hypodermic needle. Should air blisters appear after boots have been installed for a length of time, it is permissible to cut a slit in the de-ice boot, apply adhesive and repair in accordance with the following cold patch repair procedures. An alternate method of repair is to peel the de-ice boot back using Toluol and reapply using 1300L cement.

- a. Select a patch of ample size to cover damaged area.
- b. Clean area to be repaired with a cloth slightly dampened with cleaner.
- c. Buff area around damage with steel wool so that area is moderately but completely roughened.
- d. Wipe buffed area clean with a cloth slightly dampened with cleaner to remove all loose particles.
- e. Apply one even, thorough coat of 1300L cement to the patch and to the corresponding damaged area of the de-ice boot. Allow cement to set until it becomes tacky.
- f. Apply patch to the de-ice boot with an edge or the center adhering first, then work remainder of patch down, being careful to avoid trapping air pockets.
- g. Roll patch thoroughly with a stitcher roller, and allow to set for ten or fifteen minutes.

h. Wipe patch and surrounding area from center of patch outward with a cloth slightly dampened with MEK.

i. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

NOTE

Satisfactory adhesion should be obtained in four hours; however, if the patch is allowed to cure for a minimum of twenty minutes, the de-ice boots may be inflated to check the repair.

15-34. APPROVED REPAIRS. (Damage to Tube Area.)

NOTE

This type of damage consists of cuts, tears or ruptures to the inflatable tube area, and a fabric-reinforced patch must be used.

- a. Select a patch of ample size to extend at least 5/8-inch beyond the damaged area.

NOTE

If the correct size patch cannot be obtained, one may be cut to the size desired from a larger patch. If this is done, the edges should be beveled by cutting with the shears at an angle. These patches are manufactured so they will stretch in one direction only. Be sure to cut the patch selected so that the stretch is in the width-wise direction of the inflatable tube.

- b. Clean the area to be repaired with a cloth slightly dampened with cleaner.
- c. Buff the area around damage with steel wool so that area is moderately but completely roughened.
- d. Wipe buffed area clean with a cloth slightly dampened with cleaner to remove all loose particles.
- e. Apply one even thorough coat of 1300L cement to the patch and to the corresponding damaged area of the de-ice boot. Allow cement to set until it becomes tacky.
- f. Apply patch to de-ice boot with the stretch in the width-wise direction of the inflatable tubes, sticking edge of patch in place first, and working remainder down with a very slight pulling action so the rupture is closed. Use care not to trap air between patch and de-ice boot.
- g. Roll patch thoroughly with a stitcher roller and allow to set for ten or fifteen minutes.
- h. Wipe patch and surrounding area, from the center of patch outward with a cloth slightly dampened with cleaner.
- i. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

MODEL P210 SERIES SERVICE MANUAL

NOTE

Satisfactory adhesion of patch to de-ice boot should be reached in four hours; however, if patch is allowed to cure for a minimum of twenty minutes, de-ice boots may be inflated to check the repair.

15-35. APPROVED REPAIRS. (Damage to Fillet Area.)

NOTE

This damage includes any tears or cuts to the tapered area aft of the inflatable tubes.

- a. Trim damaged area square and remove excess material. Cut must be sharp and clean to permit a good butt joint of the inlay.
- b. Cut inlay from tapered fillet B. F. Goodrich part number 74-451-21) to match cut out area.
- c. Using Toluol, loosen edges of de-ice boot around area approximately one and one-half inches from all edges.
- d. Clean area to be repaired with a cloth slightly dampened with cleaner.
- e. Lift back edges of cutout and apply one coat of 1300L cement to underneath side of loosened portion of de-ice boot.
- f. Apply one coat of 1300L cement to wing skin underneath loosened edges of de-ice boot and extending one and one-half inches beyond edges of de-ice boot into cutout area.
- g. Apply second coat of 1300L cement to underneath side of de-ice boot as outlined in step (e).
- h. Apply one coat of 1300L cement to one side of a two-inch wide neoprene-coated fabric tape (B. F. Goodrich part number 74-451-22), allow to dry and trim to size.
- i. Reactivate cemented surfaces with Toluol and apply reinforcing tape to wing skin, exercising care to center tape under all edges of cutout.
- j. Roll down tape on wing skin with stitcher roller to assure good adhesion, being careful to avoid creating air pockets.
- k. Apply one coat of 1300L cement to top surface of tape and allow to dry approximately five to ten minutes.
- l. Reactivate cemented surfaces with toluol. Working toward cutout, roll down edges of loosened de-ice boot, being careful to avoid creating air pockets. Edges should overlap on tape approximately one inch.
- m. Roughen back surface of inlay repair material, previously cut to size, clean with cleaner and apply one coat of 1300L cement.
- n. Apply one coat of 1300L cement to wing skin inside of cutout area and allow to dry.
- o. Apply second coat of 1300L cement to back side of inlay material and allow to dry.
- p. Reactivate cemented surfaces with Toluol and carefully insert inlay material with feathered edge aft. Working from wing leading edge aft, roll down inlay material carefully to avoid trapping air.

q. Roughen area on outer surface of de-ice boot and inlay with steel wool, one and one-half inches on each side of splice. Clean with cleaner and apply one coat of 1300L cement to this area.

r. Apply one coat of 1300L cement to one side of two-inch wide neoprene-coated fabric tape, trim to size and center tape over splice on all three sides.

s. Roll down tape on de-ice boot with stitcher roller to assure good adhesion, being careful to avoid creating air pockets.

t. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

15-36. APPROVED REPAIRS. (Damaged Veneer, loose from De-Ice Boot.)

a. Peel and trim loose veneer to the point where adhesion of veneer to de-ice boot is good.

b. Roughen area in which veneer is removed, with steel wool, rubbing parallel to cut edge of veneer ply to prevent loosening it.

c. Taper edges of veneer down to tan rubber ply by rubbing parallel to edges with steel wool and MEK.

d. Cut a piece of veneer Material (B. F. Goodrich part number 74-451-23) to cover damaged area and extend at least one-inch beyond, in all directions.

e. Mask off an area one-half inch larger in length and width than size of veneer patch.

f. Apply one coat of 1300L cement to damaged area, and one coat to veneer ply. Allow cement to set until it becomes tacky.

g. Roll veneer ply to de-ice boot with a two-inch rubber roller, applying a slight tension on veneer ply when applying, to prevent trapping air.

h. Wipe patch and surrounding area from center of patch outward with a cloth slightly dampened with cleaner.

i. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

NOTE

B. F. Goodrich Repair Kit No. 74-451-C for repairing de-ice boots is available from the Cessna Supply Division.

15-37. MATERIALS REQUIRED FOR INSTALLATION OF DE-ICE BOOTS.

1. No. EC-1300L (EC-1403) Cement, Minnesota Mining & Manufacturing Company.
2. Methyl-Isobutyl Ketone (MIBK).
3. Cleaning Solvent - Toluol.
4. Cleaning Solvent - Hexane.
5. Clean, lint-free cleaning cloths.
6. Four yards clean, heavy canvas duck fabric 48 inches wide.
7. Several empty tin cans.
8. Three-inch paint brushes.
9. Two-inch rubber hand rollers.
10. 1/4-inch metal hand stitcher roller. B. F. Goodrich Company (Part Number 3306-10).
11. Carpenters' chalk line.

MODEL P210 SERIES SERVICE MANUAL




Figure 15-5. Wing and Horizontal Stabilizer De-Ice System Timer

12. One-inch masking tape.
13. Steel measuring tape.
14. Sharp knives.
15. Fine sharpening stone.
16. No. EC-539 Sealing Compound, Minnesota Mining & Manufacturing Company.
17. No. A-56-B Cement, B. F. Goodrich Company (Part Number 3306-15).
18. GACO-700-A Coating, Gates Engineering Co., Wilmington, Delaware 19889.

15-38. **REPLACEMENT OF DE-ICE BOOTS.** To remove or loosen installed de-ice boots, use toluol or toluene to soften the "cement" line. Apply a minimum amount of this solvent to the cement line as tension is applied to peel back the boot. Removal should be slow enough to allow the solvent to undercut the cement so that parts will not be damaged. To install a wing de-icer boot, proceed as follows:

a. Clean the metal surfaces and the bottom side of the de-icer thoroughly with Methyl Ethyl Ketone or Methyl Isobutyl Ketone. This shall be done by wiping the surfaces with a clean, lint-free rag soaked with

the solvent and then wiping dry with a clean, dry, lint-free rag before the solvent has time to dry.

b. Place one inch masking tape on wing to mask off boot area allowing 1/2 inch margin. Take care to mask accurately so that clean-up time will be reduced.

c. Stir EC-1300L cement thoroughly before using. Brush one even, light coat onto leading edge and to rough side of boot, brushing well into rubber. Allow cement to air dry until cement does not transfer to fingers when touched. Then apply a second coat to each of the surfaces and allow to dry. Apply a vacuum to the boots when they are installed to help smooth out wrinkles.

d. Place a straight line along the leading edge line and a corresponding line on the inside of the de-icer boot if it does not have a centerline. Securely attach hoses to de-icer connections. Position centerline of boot with leading edge line, using a clean, lint-free cloth, heavily moistened with toluol, reactivate surface of cement on wing and the boot in small, span-wise areas approximately 6-inches wide. Avoid excessive rubbing of cement, which would remove it

MODEL P210 SERIES SERVICE MANUAL

from the surface of the wing. Utilize enough help to hold boot steady during installation, and caution them against handling cemented surfaces. Roll boot firmly against leading edge, being careful not to trap any air between boot and leading edge surface. Always roll parallel to the inflatable tubes. Should the boot attach "off course", pull it up immediately with a quick motion, and reposition properly. Avoid twisting or sharp bending of boot. Finally, roll the entire surface of the boot parallel to tubes, applying pressure. Use the metal stitcher roller between tubes and around connections. Should an air pocket be encountered, carefully insert a hypodermic needle and allow air to escape. Do not puncture the inflatable tubes at any time. Fill any gaps between adjoining boots with GACO N-700-A Neoprene coating (Gates Engineering Co., Wilmington, Delaware 19899). Apply a coat of the Neoprene coating along trailing edge of boot to the surface of the skin to form a neat, straight filler.

e. Remove masking tape and clean surfaces with toluol.

15-39. **TIMER.** (See figure 15-5.)

15-40. **DESCRIPTION.** The timer is located on the glove box and controls the length of time, in seconds, that the de-ice boots are inflated during a de-icing cycle.

15-41. **FUNCTIONAL TEST OF TIMER.**
(See figure 15-5.)

- a. Connect timer as shown in the wiring schematic.
- b. Set voltage at 28 VDC, control switch to MOM-ON position and release to none position.
- c. Record the time each light is on.
- d. The recorded times shall match those shown in the timing chart $\pm 10\%$ at 28 VDC.
- e. The timer output shall complete the cycle and then shut off all outputs.

NOTE

Reactivation of the control switch during a cycle will not interrupt that cycle or cause the unit to reset until the existing cycle is completed.

- f. Vary the voltage from 22-31 VDC and repeat step e. Timer must continue to operate at these voltages within the time frame shown in the chart.

NOTE

Do not check voltage levels without a load attached, since readings may be erroneous.

15-42. **FLIGHT INTO KNOWN ICING EQUIPMENT AND SYSTEMS.**

15-43. **DESCRIPTION.** A flight into known icing equipment package may be installed on the airplane. For operations in known icing conditions as defined by the FAA, the following Cessna (drawing number 2101070) and FAA approved equipment must be installed and operational:

1. Wing horizontal stabilizer and vertical fin leading edge pneumatic de-ice boots.
2. Propeller anti-ice boots.
3. Windshield anti-ice panel.
4. Heated pitot tube (high capacity).
5. Heated stall warning transducer (high capacity).
6. Ice detector light.
7. Dual 60-amp alternators.
8. Control surface static dischargers.
9. Dual vacuum pumps.


Service information on this equipment when installed on known icing certified aircraft is contained in the following paragraphs.

15-44. **WING, HORIZONTAL STABILIZER AND VERTICAL FIN DE-ICE SYSTEM.**

15-45. **DESCRIPTION.** The system consists of two engine-driven vacuum pumps, two pressure control valves, two vacuum relief valves, flow control valves, pressure switch, timer and a boot mounted on the leading edge of each wing, on the leading edge of each horizontal stabilizer and on the leading edge of the vertical fin. The dual vacuum pumps are utilized by the aircraft vacuum system, and the relief valve adjustment should be maintained in accordance with the procedures outlined in the applicable paragraph in Section 16 of this manual. A vacuum gage, located on the left side of the instrument panel is equipped with two plungers labeled L, R and source. In case of a vacuum pump failure, a red band will become visible on the plunger corresponding to the failed pump.


MODEL P210 SERIES SERVICE MANUAL

15-46. TROUBLE SHOOTING



MODEL P210 SERIES SERVICE MANUAL

15-46. TROUBLE SHOOTING (Cont.)



MODEL P210 SERIES SERVICE MANUAL

15-47. **SYSTEM OPERATION.** The boots expand and contract, utilizing pressure or vacuum from the engine-driven vacuum pumps. Normally, vacuum holds all the boots against the leading edge surfaces. When a de-icing cycle is initiated, the vacuum is removed and pressure is applied to expand the boots, thus cracking the ice which is removed by the in-flight air moving over the leading edges and surfaces of the wings and stabilizers. Controls for the de-ice system consist of a two-position rocker-type de-ice switch located on the left switch panel, a pressure indicator light on the upper left side of the instrument panel, and a 5-amp circuit breaker on the left side-wall circuit breaker panel. The de-ice switch, labeled DE-ICE PRESS, is spring-loaded to the off position. When the switch is pushed to the ON (upper) position and released, it will activate one de-ice cycle. The system may be stopped at any point in the cycle (boots deflated) by pulling the WING DE-ICE circuit breaker to the off position. The boots inflate in the following sequence: Horizontal and vertical stabilizer boots inflate for approximately 6 seconds, inboard wing boots, 6 seconds and outboard wing boots, 6 seconds. The total time required for one de-ice cycle is approximately 18 seconds. The pressure indicator light, labeled DE-ICE PRESSURE, should light when the tail section boots inflate. When ground-checking the system, it should light within one to two seconds after the cycle is initiated, and remain on for approximately 17 seconds. The system may be recycled within six seconds after the light goes off. An ice detector light is also included in the system, refer to paragraph 15-74 for its location and operating instructions.

15-48. **REMOVAL/INSTALLATION OF DE-ICE SYSTEM.** Refer to figure 15-6.

15-49. **KNOWN ICING DE-ICE SYSTEM FUNCTIONAL CHECK.** (See figure 15-6.)

- a. **Electrical Controls Check:**
 1. Check wing de-ice circuit breaker (39) closed.
 2. Check de-ice pressure switch (50) off (spring-loaded to off position).
 3. Turn master switch on.
 4. Press de-ice pressure light (46) to check light circuit and bulb. Make sure dimming shutter is open.
 5. Turn master switch off.
- b. **Vacuum Relief Valve(s) Adjustment.**
 1. Refer to Section 16 of this manual for vacuum relief valve(s) adjustment.
- c. **Preflight System Check:**
 1. With vacuum relief valve(s) adjusted and engine running from 2200 to 2500 rpm, check both buttons on the suction gage are retracted out of sight and vacuum is normal.
 2. Place de-ice pressure switch (50) on, and release.
 3. Check that de-ice pressure light (46) comes on within one second, remains on for 18 seconds, then shuts off.

4. Check boots for inflation during 18 second cycle as follows: first six seconds tail section boots, then inboard wing boots for next six seconds, finally the outboard wing boots inflate for six seconds completing one cycle.

5. The absence of or slow illumination of the de-ice pressure light during any one of the three sequences of a cycle indicates insufficient pressure for proper system operation.

d. **Timer Check:**

1. Refer to paragraph 15-62 for timer checks.

e. **Air pressure Check:**

NOTE

This check may be performed in the engine compartment.

1. Disconnect both pressure hoses (1) and (6) from pressure control valves (9).

2. Connect a source of clean regulated dry air pressure (21 ± 1 psig) fitted with a hand-operated valve or check valve and an in-line air pressure gauge to right pump pressure hose (1).

NOTE

A test kit (#343) for testing vacuum and pneumatic de-ice systems is available from Airborne, 711 Taylor Street, Elyria, Ohio 44035, or the Cessna Supply Division. This kit contains the necessary equipment and supplemental instructions to perform this check.

3. Disconnect left and right vacuum inlet hoses from left and right vacuum pumps (8).

4. Disconnect electrical leads from pressure control valves (9).

CAUTION

Do not attempt air pressure check with de-ice timer module connected into the circuit.

5. Connect a vacuum source (5.6 in. Hg minimum) to right pump vacuum hose.


6. Connect a switched 28 VDC electrical source to right pressure control valve.

7. Insert pressure probe equipped with vacuum/pressure gage into the rubber hose connecting tail boots with tail boot flow valve.

8. Turn on pressure and vacuum sources. Verify that pressure flow is being vented overboard at right pressure control valve and no flow is present either in or out of disconnected hoses at left vacuum pump. Pressure gage on probe should read 4.5-4.6 in. Hg vacuum.

9. Switch on electrical power to right pressure control valve and actuate tail boot flow control manually.

MODEL P210 SERIES SERVICE MANUAL



Detail A

- 1. Hose - To Pressure Control Valve
- 2. Firewall
- 3. Relief Valves
- 4. Vacuum Hold-Down Line
- 5. Vacuum Manifold
- 6. Hose - To Pressure Control Valve
- 7. Cooling Hoses
- 8. Vacuum Pumps

Figure 15-6. Wing, Horizontal Stabilizer and Vertical Fin De-Icing System (Sheet 1 of 5)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-6. Wing, Horizontal Stabilizer and Vertical Fin De-Icing System (Sheet 2 of 5)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-6. Wing, Horizontal Stabilizer and Vertical Fin De-Icing System (Sheet 3 of 5)

MODEL P210 SERIES SERVICE MANUAL





Figure 15-6. Wing, Horizontal Stabilizer and Vertical Fin De-Icing System (Sheet 4 of 5)

MODEL P210 SERIES SERVICE MANUAL



Detail M

Detail N

Detail O

- 45. Propeller De-Ice Gage
- 46. De-Ice Pressure Light
- 47. Ice Detector Light Switch
- 48. Propeller Anti-Ice Switch
- 49. Windshield Anti-Ice Switch
- 50. De-Ice Pressure Switch
- 51. Pitot Heat Switch
- 52. Stall Heat Switch
- 53. Lamp
- 54. Bracket Assembly
- 55. Doubler
- 56. Skin - Cowl Deck
- 57. Lens
- 58. Cover
- 59. Screw
- 60. Socket

Figure 15-6. Wing, Horizontal Stabilizer and Vertical Fin De-Icing System (Sheet 5 of 5)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-7. Surface De-Ice System Components Schematic.

MODEL P210 SERIES SERVICE MANUAL

NOTE

Flow valves can be actuated mechanically by depressing the solenoid plunger inward using the fingers. This procedure eliminates the necessity of disconnecting and reconnecting electrical leads.

10. Overboard flow at pressure control valve should stop and pressure air should inflate tail boots. Pressure gage should show $18 \pm .5$ psi with audible venting of pressure air from pressure regulator valve (31) evident. Recheck for absence of airflow out of left pressure control valve.

11. With pressure control valve energized turn off pressure source using hand-operated valve. Pressure leak-down as shown by probe pressure gage should be 2 psi per minute or less. Use soap and water solution to locate leaks, turn off power to left pressure control valve, repair leaks and re-test until leak-down rate is within tolerance.

12. Insert pressure probe into hose connecting outboard wing boots with outboard boot flow control valve and repeat steps 8 thru 11 noting leaks.

13. Insert pressure probe into hose connecting inboard wing boots with inboard boot flow control valve and repeat steps 8 thru 11 noting leaks.

14. Disconnect pressure and vacuum sources from right vacuum pump hoses and connect to left pump hoses.

15. Turn on pressure and vacuum sources. Verify that pressure flow is being vented overboard at left pressure control valve and no flow is present either in or out of disconnected hoses at right pump. Probe pressure gauge should read 4.5-5.6 in. Hg vacuum.

16. Switch on electrical power to left pressure control valve. Overboard flow at pressure control valve should stop. Check for no airflow from right pressure control valve and audible venting of pressure air from pressure regulator valve (31) evident.

17. With probe air pressure gauge inserted into hose connecting any flow valve with its associated de-ice boot, actuate flow valve manually, and recheck probe air pressure gauge reads $18 \pm .5$ psi.

18. Disconnect test equipment and reconnect pressure and vacuum lines to vacuum pumps.

19. Reconnect wiring to pressure control valves.

15-50. ADHESION TEST.

a. Using excess material trimmed from ends of any wing or empennage de-ice boot, prepare one test specimen for each de-ice boot installed.

b. This specimen should be one-inch wide and four or more inches long.

c. Cement specimen to installation surface adjacent to installed de-ice boot, following the identical procedure used for boot installation.

d. Leave one-inch of the strip uncemented to attach a clamp.

e. Four hours or more after de-ice boot installation, attach a spring scale to uncemented end of each strip and measure force required to remove the strip at a rate of one-inch per minute. The pull shall be applied 180° to the surface. (Strip doubled back on itself).

f. A minimum of five pounds tension (pull) shall be required to remove test strip.

NOTE

If less than five pounds is required acceptability of the de-ice boot adhesion shall be based on carefully lifting one corner of the de-ice boot in question sufficiently to attach a spring clamp and attaching a spring scale to this clamp. Pull with force 180° to the surface, and in such a direction that the de-ice boot tends to be removed on the diagonal. If a force of five pounds per inch of width can be exerted under these conditions, the installation shall be considered satisfactory. Width increases as corner peels back.

g. Re-cement corner following installation procedure.

CAUTION

Failure to achieve five pounds adhesion per inch of width requires reinstallation of the de-ice boot.

NOTE

Possible reasons for failure are: dirty surfaces, cement not mixed thoroughly. Corrosion of metal skin may occur if good adhesion is not attained, especially around rivet heads and metal skin splices. If these adhesion requirements are met, the aircraft may be flown immediately. Do not inflate de-ice boots within 48 hours of installation.

15-51. CLEANING DE-ICE BOOTS.

CAUTION

Use only the following instructions when cleaning de-ice/anti-ice boots. Disregard instructions which recommend petroleum base liquids (MEK, non-leaded gasoline, etc.) which can harm the boot material.

a. Clean boots with mild soap and water, then rinse thoroughly with clean water.

NOTE

Isopropyl alcohol can be used to remove grime which cannot be removed using soap. If isopropyl alcohol is used for cleaning, wash area with mild soap and water, then rinse thoroughly with clean water.

15-52. CLEANING SYSTEM AND COMPONENTS. Follow procedures as outlined in Section 16 of this manual for removal and installation. In general, low pressure, dry compressed air should be used in cleaning vacuum system components. Suction relief valve should be washed with Stoddard solvent, then dried with low-pressure air blast.

MODEL P210 SERIES SERVICE MANUAL

CAUTION

Never apply compressed air to lines or components installed in aircraft. The excessive pressures will damage gyros. If an obstructed line is to be blown out, disconnect at both ends and blow from instrument panel out.

15-53. DE-ICE AND ANTI-ICE BOOT PROTECTIVE PRODUCTS. Two rubber treatment products, Age Master #1, and Icx are approved for use on de-ice boots and anti-ice boots of Cessna aircraft. Age Master #1 protects the rubber against deterioration from ozone, sunlight weathering, oxidation and pollution. Icx helps retard ice adhesion and keeps the boots looking new longer; both products are produced and recommended by B. F. Goodrich. Age Master #1 (part #74-451-127) and Icx (part # ICEX) are available from the Cessna Supply Division.

a. Mask surrounding areas before applying Age Master #1 to clean, dry boot surfaces. Apply with a cheesecloth swab. DO NOT SPRAY this product; a rubbing or brushing action is required for the protective agent to penetrate the rubber surfaces. Apply three or more coats allowing a 5 to 10 minute drying period between applications. However, the total amount applied should not exceed 0.3 to 0.4 ounce per square foot of boot surface.

b. Mask surrounding areas before applying a light coat of Icx with a cheesecloth swab to clean, dry boot surfaces. A heavy coat of Icx will result in a sticky surface which collects dust and dirt. One quart of Icx will cover approximately 500 square feet. If boots have been treated with Age Master #1, allow it to dry for a minimum of 24 hours before applying the Icx. Apply Icx Spanwise in a single continuous back and forth motion.

CAUTION

Protect adjacent areas, clothing, and wear plastic or rubber gloves during application. Age Master stains clothing and Icx contains silicone which makes paint touch-up nearly impossible. Waterless hand cleaner is beneficial for cleaning hands, equipment and clothing

Age Master #1 and Icx coatings last approximately 150 hours on wing and stabilizer boots and 15 hours on propeller boots.

15-54. APPROVED REPAIRS. (Cold Patch for Scuff or Surface Damage.)

NOTE

Surface coatings and surface refurbishing kits will not repair leaks. Use repair kit materials.

NOTE

When repairing de-ice boots and replacement layers are being installed, exercise care to prevent trapping air beneath the replacement layers. If air blisters appear after material is applied, they may be removed with a hypodermic needle. Should air blisters appear after boots have been installed for a length of time, it is permissible to cut a slit in the de-ice boot, apply adhesive and repair in accordance with the following cold patch repair procedures. An alternate method of repair is to peel the de-ice boot back using Toluol and reapply using 1300L cement.

- a. Select a patch of ample size to cover damaged area.
- b. Clean area to be repaired with a cloth slightly dampened with cleaner.
- c. Buff area around damage with steel wool so that area is moderately but completely roughened.
- d. Wipe buffed area clean with a cloth slightly dampened with cleaner to remove all loose particles.
- e. Apply one even, thorough coat of 1300L cement to the patch and to the corresponding damaged area of the de-ice boot. Allow cement to set until it becomes tacky.
- f. Apply patch to the de-ice boot with an edge or the center adhering first, then work remainder of patch down, being careful to avoid trapping air pockets.
- g. Roll patch thoroughly with a stitcher roller, and allow to set for ten or fifteen minutes.
- h. Wipe patch and surrounding area from center of patch outward with a cloth slightly dampened with MEK.
- i. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

NOTE

Satisfactory adhesion should be obtained in four hours; however, if the patch is allowed to cure for a minimum of twenty minutes, the de-ice boots may be inflated to check the repair.

15-55. APPROVED REPAIRS. (Damage to Tube Area.)

NOTE

This type of damage consists of cuts, tears or ruptures to the inflatable tube area, and a fabric-reinforced patch must be used.

- a. Select a patch of ample size to extend at least 5/8-inch beyond the damaged area.

MODEL P210 SERIES SERVICE MANUAL

NOTE

If the correct size patch cannot be obtained, one may be cut to the size desired from a larger patch. If this is done, the edges should be beveled by cutting with the shears at an angle. These patches are manufactured so they will stretch in one direction only. Be sure to cut the patch selected so that the stretch is in the width wise direction of the inflatable tube.

- b. Clean the area to be repaired with a cloth slightly dampened with cleaner.
- c. Buff the area around damage with steel wool so that area is moderately but completely roughened.
- d. Wipe buffed area clean with a cloth slightly dampened with cleaner to remove all loose particles.
- e. Apply one even, thorough coat of 1300L cement to the patch and to the corresponding damaged area of the de-ice boot. Allow cement to set until it becomes tacky.
- f. Apply patch to de-ice boot with the stretch in the width-wise direction of the inflatable tubes, sticking edge of patch in place first, and working remainder down with a very slight pulling action so the rupture is closed. Use care not to trap air between patch and de-ice boot.
- g. Roll patch thoroughly with a stitcher roller and allow to set for ten or fifteen minutes.
- h. Wipe patch and surrounding area, from the center of patch outward with a cloth slightly dampened with cleaner.
- i. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

NOTE

Satisfactory adhesion of patch to de-ice boot should be reached in four hours; however, if patch is allowed to cure for a minimum of twenty minutes, de-ice boots may be inflated to check the repair.

15-56. APPROVED REPAIRS. (Damage to Fillet Area.)

NOTE

This damage includes any tears or cuts to the tapered area aft of the inflatable tubes.

- a. Trim damaged area square and remove excess material. Cut must be sharp and clean to permit a good butt joint of the inlay.
- b. Cut inlay from tapered fillet (B. F. Goodrich part number 74-451-21) to match cut out area.
- c. Using Toluol, loosen edges of de-ice boot around area approximately one and one-half inches from all edges.
- d. Clean area to be repaired with a cloth slightly dampened with cleaner.

e. Lift back edges of cutout and apply one coat of 1300L cement to underneath side of loosened portion of de-ice boot.

f. Apply one coat of 1300L cement to wing skin underneath loosened edges of de-ice boot and extending one and one-half inches beyond edges of de-ice boot into cutout area.

g. Apply second coat of 1300L cement to underneath side of de-ice boot as outlined in step (e).

h. Apply one coat of 1300L cement to one side of a two-inch wide neoprene-coated fabric tape (B. F. Goodrich part number 74-451-22), allow to dry and trim to size.

i. Reactivate cemented surfaces with Toluol and apply reinforcing tape to wing skin, exercising care to center tape under all edges of cutout.

j. Roll down tape on wing skin with stitcher roller to assure good adhesion, being careful to avoid creating air pockets.

k. Apply one coat of 1300L cement to top surface of tape and allow to dry approximately five to ten minutes.

l. Reactivate cemented surfaces with toluol. Working toward cutout, roll down edges of loosened de-ice boot, being careful to avoid creating air pockets.

Edges should overlap on tape approximately one inch.

m. Roughen back surface of inlay repair material, previously cut to size, clean with cleaner and apply one coat of 1300L cement.

n. Apply one coat of 1300L cement to wing skin inside of cutout area and allow to dry.

o. Apply second coat of 1300L cement to back side of inlay material and allow to dry.

p. Reactivate cemented surfaces with Toluol and carefully insert inlay material with feathered edge aft. Working from wing leading edge aft, roll down inlay material carefully to avoid trapping air.

q. Roughen area on outer surface of de-ice boot and inlay with steel wool, one and one-half inches on each side of splice. Clean with cleaner and apply one coat of 1300L cement to this area.

r. Apply one coat of 1300L cement to one side of two-inch wide neoprene-coated fabric tape, trim to size and center tape over splice on all three sides.

s. Roll down tape on de-ice boot with stitcher roller to assure good adhesion, being careful to avoid creating air pockets.

f. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

15-57. APPROVED REPAIRS. (Damaged Veneer, loose from De-ice Boot.)

a. Peel and trim loose veneer to the point where adhesion of veneer to de-ice boot is good.

b. Roughen area in which veneer is removed, with steel wool, rubbing parallel to cut edge of veneer ply to prevent loosening it.

c. Taper edges of veneer down to tan rubber ply by rubbing parallel to edges with steel wool and MEK.

d. Cut a piece of veneer material (B. F. Goodrich part number 74-451-23) to cover damaged area and extend at least one-inch beyond, in all directions.

MODEL P210 SERIES SERVICE MANUAL

- e. Mask off an area one-half inch larger in length and width than size of veneer patch.
- f. Apply one coat of 1300L cement to damaged area, and one coat to veneer ply. Allow cement to set until it becomes tacky.
- g. Roll veneer ply to de-ice boot with a two-inch rubber roller, applying a slight tension on veneer ply when applying, to prevent trapping air.
- h. Wipe patch and surrounding area from center of patch outward with a cloth slightly dampened with cleaner.
- i. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

NOTE

B. F. Goodrich Repair Kit No. 74-451-C for repairing de-ice boots is available from the Cessna Supply Division.

15-58. MATERIALS REQUIRED FOR INSTALLATION OF DE-ICE BOOTS.

1. No. EC-1300L (EC-1403) Cement, Minnesota Mining & Manufacturing Company.
2. Methyl-Isobutyl Ketone (MIBK).
3. Cleaning Solvent - Toluol.
4. Cleaning Solvent - Hexane.
5. Clean, lint-free cleaning cloths.
6. Four yards clean, heavy canvas duck fabric 48 inches wide.
7. Several empty tin cans.
8. Three-inch paint brushes.
9. Two-inch rubber hand rollers.
10. 1/4-inch metal hand stitcher roller, B. F. Goodrich Company (Part Number 3306-10).
11. Carpenters' chalk line.
12. One-inch masking tape.
13. Steel measuring tape.
14. Sharp knives.
15. Fine sharpening stone.
16. No. EC-539 Sealing Compound, Minnesota Mining & Manufacturing Company.
17. No. A-56-B Cement, B. F. Goodrich Company (Part Number 3306-15)
18. GACO-700-A Coating, Gates Engineering Co., Wilmington, Delaware 19899.

- 15-59. REPLACEMENT OF DE-ICE BOOTS. To remove or loosen installed de-ice boots, use toluol or toluene to soften the "cement" line. Apply a minimum amount of this solvent to the cement line as tension is applied to peel back the boot. Removal should be slow enough to allow the solvent to undercut the cement so that parts will not be damaged. To install a wing de-icer boot, proceed as follows:
- a. Clean the metal surfaces and the bottom side of the de-icer thoroughly with Methyl Ethyl Ketone or Methyl Isobutyl Ketone. This shall be done by wiping the surfaces with a clean, lint-free rag soaded with the solvent and then wiping dry with a clean, dry, lint-free rag before the solvent has time to dry.
 - b. Place one inch masking tape on wing to mask off boot area allowing 1/2 inch margin. Take care to mask accurately so that clean-up time will be reduced.

c. Stir EC-1300L cement thoroughly before using. Brush one even light coat onto leading edge and to rough side of boot, brushing well into rubber. Allow cement to air dry until cement does not transfer to fingers when touched. Then apply a second coat to each of the surfaces and allow to dry. Apply a vacuum to the boots when they are installed to help smooth out wrinkles.

d. Place a straight line along the leading edge line and a corresponding line on the inside of the de-icer boot if it does not have a centerline. Securely attach hoses to de-icer connections. Position centerline of boot with leading edge line, using a clean, lint-free cloth, heavily moistened with toluol, reactivate surface of cement on wing and the boot in small span-wise areas approximately 6-inches wide. Avoid excessive rubbing of cement, which would remove it from the surface of the wing. Utilize enough help to hold boot steady during installation, and caution them against handling cemented surfaces. Roll boot firmly against leading edge, being careful not to trap any air between boot and leading edge surface. Always roll parallel to the inflatable tubes. Should the boot attach "off course", pull it up immediately with a quick motion, and reposition properly. Avoid twisting or sharp bending of boot. Finally, roll the entire surface of the boot parallel to tubes, applying pressure. Use the metal stitcher roller between tubes and around connections. Should an air pocket be encountered, carefully insert a hypodermic needle and allow air to escape. Do not puncture the inflatable tubes at any time. Fill any gaps between adjoining boots with GACO N-700-A Neoprene coating (Gates Engineering Co., Wilmington, Delaware 19899). Apply a coat of the Neoprene coating along trailing edge of boot to the surface of the skin to form a neat, straight fillet.

e. Remove masking tape and clean surfaces with toluol.

15-60. TIMER. (See figure 15-8.)

15-61. DESCRIPTION. The timer is located on the glove box and controls the length of time, in seconds, that the de-ice boots are inflated during a de-icing cycle.

15-62. FUNCTIONAL TEST OF TIMER. (See figure 15-8.)

- a. Connect timer as shown in the wiring schematic.
- b. Set voltage at 28 VDC, control switch to MOM-ON position and release to none position.
- c. Record the time each light is on.
- d. The recorded times shall match those shown in the timing chart $\pm 10\%$ at 28 VDC.
- e. The timer output shall complete the cycle and then shut off all outputs.

NOTE

Reactivation of the control switch during a cycle will not interrupt that cycle or cause the unit to reset until the existing cycle is completed.

MODEL P210 SERIES SERVICE MANUAL




Figure 15-8. Wing, Horizontal Stabilizer and Vertical Fin De-Ice System Timer.

f. Vary the voltage from 22-31 VDC and repeat step e. Timer must continue to operate at these voltages within the time frame shown in the chart.

NOTE

Do not check voltage levels without a load attached, since readings may be erroneous.

15-63. PROPELLER ANTI-ICE SYSTEM. The electrothermal system includes an inboard and an outboard heating element on each propeller blade, a brush block and a slip ring assembly to distribute electrical energy to the heating elements, an ammeter to monitor system operation, a switch and a circuit breaker. The anti-ice system heats the areas of the propeller blades where ice generally accumulates. The heat, centrifugal force of the rotating blades, and the air blast combine to remove the ice build-up. When the switch is turned on, the timer cycles current to the outboard elements for 20 ± 1 seconds, and to the inboard elements for 20 ± 1 seconds, thus completing one cycle. Heating may begin at any phase in the cycle, depending upon timer position when the switch was previously turned

off. Ground checkout of the system may be performed without the engine running. The propeller must be removed before the system components, except the brush block, can be installed or removed.

15-64. REMOVAL (See figure 15-9.)

WARNING

Be certain magneto is grounded before turning propeller.

- a. Remove spinner attaching screws (18) and remove spinner (19), spinner support (17) and spacers (16). Retain spacers (16).
- b. Remove engine cowling and nose cap for access to propeller mounting nuts.
- c. Loosen all propeller mounting nuts (26) approximately 1/4-inch and pull propeller forward until stopped by mounting nuts (26).

NOTE

As propeller is separated from engine crankshaft flange, oil will drain from propeller and engine cavities.

MODEL P210 SERIES SERVICE MANUAL

CAUTION

Use caution when removing propeller. Removing propeller without the de-ice slip ring requires disconnecting nine wires at the spinner bulkhead, since the slip ring is mounted to the bulkhead. Wires should be identified according to wiring diagrams to facilitate reassembly. During removal, installation or other maintenance, use care to prevent damaging slip ring and brushes.

- d. Remove sta-strap (21).
- e. Remove nuts and washers securing electrical lead (11) to slip ring (8).
- f. Remove all propeller mounting nuts (26) and washers (25) and pull propeller forward to remove from engine crankshaft (24).
- g. Remove slip ring (8).

- h. Remove screw and nut securing clamp (10) to spinner bulkhead (23).
- i. Remove bolts and washers securing spinner bulkhead (23) to propeller (13) and remove bulkhead.
- j. Remove screws and nuts securing clamps (12) to brackets (15).
- k. Remove nuts, washers, screws, and insulators securing electrical leads (11) to brackets (15).
- l. Remove electrical leads (11) and grommets (20).



15-66. INSTALLATION. (See figure 15-9.)

- a. Connect electrical leads (11) to brackets (15) using insulators, screws, washers, and nuts.
- b. Install clamps (12) over electrical leads (11) and install on brackets (15) using screws, washers, and nuts.
- c. Install grommets (20) over electrical leads (11) and install grommets in notches in propeller flange.
- d. Position spinner bulkhead (23) on propeller (13) and secure with bolts, washers, and nuts.

15-65. TROUBLE SHOOTING - PROPELLER ANTI-ICE SYSTEM.

TROUBLE	PROBABLE CAUSE	REMEDY
ELEMENTS DO NOT HEAT.	Circuit breaker out or defective.	Reset circuit breaker. If it pops out again, determine cause and correct. Replace defective parts.
	Defective wiring.	Repair or replace wiring.
	Defective switch.	Replace switch.
	Defective timer.	Replace timer.
	Defective brush-to-slip ring connection.	Check alignment. Replace defective parts.
SOME ELEMENTS DO NOT HEAT.	Incorrect wiring.	Correct wiring.
	Defective wiring.	Repair or replace wiring.
	Defective timer.	Replace timer.
	Defective brush-to-slip ring connection.	Check alignment. Replace defective parts.
	Defective element.	Replace element.
CYCLING SEQUENCE NOT CORRECT OR NO CYCLING.	Crossed connections.	Correct wiring.
	Defective timer.	Replace timer.
RAPID BRUSH WEAR, FREQUENT BREAKAGE, SCREECHING OR CHATTERING.	Brush block or slip ring out of alignment.	Align properly.

MODEL P210 SERIES SERVICE MANUAL



- 1. Spacer
- 2. Support
- 3. Timer

Detail A

Apply ice-repellant (MI-903) (Glidden Mfg. Co.) to leading edge surfaces, landing light covers and windshield to retard ice build-up.

Figure 15-9. Propeller De-Ice System (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-9. Propeller De-Ice System (Sheet 2 of 2)

Timer P/N	Power Input Pin & Socket	Ground Pin	Output Sequence, Time, Voltage	Time Repeat Cycle Time (sec)
C165020-0101	B (28VDC) (24-32)	G (28VDC)	C, D 20 seconds each	40

MODEL P210 SERIES SERVICE MANUAL




Figure 15-10. Brush Face Alignment and Projection and Angular Brush Alignment

- e. Install clamps (10) over electrical leads (11) and secure to spinner bulkhead (23) with screws, washers, and nuts.
- f. Install sta-strap (21) over electrical leads (11).
- g. Lightly lubricate O-ring (22).
- h. Position slip ring (8) and propeller (13) on engine crankshaft (24) and install washers (25) and nuts (26). Do not tighten.
- i. Connect electrical leads (11) to slip ring (8) using washers and nuts.
- j. Tighten propeller mounting nuts (26) to a torque of 55 to 60 lb-ft.
- k. Install spacers (16), spinner support (17) and spinner (19) and install screws (18) securing spinner (19) to spinner bulkhead (23).

15-67. SLIP RING ALIGNMENT CHECK. After installation, slip ring must be checked for run-out.

NOTE

Excessive slip ring run-out will result in severe arcing between slip ring and brushes, and cause rapid brush wear. If allowed to continue, this condition will result in rapid deterioration of slip ring and brush contact surfaces, and lead to the eventual failure of the propeller de-icing system.

- a. Securely attach a dial indicator gage to the engine and place the pointer on the slip ring.
- b. Rotate the propeller slowly by hand, noting the deviation of the slip ring from a true plane as indicated on the gage.

- c. Check that the total run-out does not exceed 0.010 inch (± 0.005 inch), and that the total is not exceeded within any four inches of slip ring rotation.

NOTE

Care must be taken to exert a uniform push or pull on the propeller to avoid a considerable error in the readings caused by loose fitting thrust bearings.

- d. If slip ring run-out is within the limits specified, no corrective action is required. If the run-out is not within limits specified, the slip ring will have to be removed and returned to the claims department of the Cessna Supply Division, and a new part ordered.

15-68. TIMER TEST.

- a. Remove connector plug of wire harness from timer and jump power input socket of wire harness to timer input pins. (Refer to chart following this step for pin identification.)
- b. Jump timer ground pin to ground.
- c. Turn on De-Icing System
- d. Check timer operation per the chart preceding step "b." (Use a voltmeter.)
- e. Check volts to ground in each case. If engine is not running, and auxiliary power is not used, voltage will be battery voltage and cycle time may be slightly longer than indicated.
- f. Hold voltmeter probe on the pin until the voltage drops to 0. Move the probe to the next pin in the sequence shown in the chart. Check voltage at each pin in sequence. When correctness of the cycling sequence

MODEL P210 SERIES SERVICE MANUAL

is established, turn propeller De-Icing switch off at the beginning of one of the on-time periods, and record the letter of the pin at which the voltage supply is present.

NOTE

Timers do not home to pin "C" when turned off.

15-69. INSTALLATION AND ALIGNMENT OF BRUSH BLOCK ASSEMBLY. (See figure 15-10.)

NOTE

Installation of the brush block should be deferred, when possible, until after the slip ring, propeller, and related components are installed. However, the brush block assembly may be replaced without removing the propeller. To avoid breakage when installing the brush block assembly, keep brushes retracted in brush block until slip ring and propeller assemblies have been installed.

CAUTION

Make sure that slip ring run-out has been corrected before attempting to align brushes on slip ring.

a. In order to get smooth, efficient and quiet transfer of electric power from the brushes to the slip ring, brush alignment must be checked and adjusted, if necessary to meet the following requirements.

1. Projection must be such that the distance between the brush block and the slip ring is $.06'' \pm .03''$.

2. The brushes must be lined up with the slip ring so that the entire face of each brush is in contact with the slip ring throughout the full 360° of slip ring rotation.

3. The brushes must contact the slip ring at an angle of approximately 2° from perpendicular to the slip ring surface, measured toward the direction of rotation of the slip ring.

b. Brush projection can normally be adjusted by loosening hardware attaching the brush block and holding the brushes in the desired location while re-tightening the hardware. Slotted holes are provided.

c. One method for face alignment is described in step "b". Another is to use shims between brush block and bracket. Laminated metal shims are generally provided. Layers of metal $.003''$ are used to make up shims which are approximately $0.20''$ thick overall. Shims may be fabricated locally.

d. Loosen mounting bolts and twist block while tightening to attain proper angular adjustment.

CAUTION

Use care not to disturb other adjustments when adjusting angular alignment.

15-70. HEATED WINDSHIELD PANEL-FIXED. (See figure 15-11.)

15-71. DESCRIPTION. An optional heated panel is provided to prevent ice formation on the windshield. The system consists of an electrically heated panel attached to the windshield, a controller and a relay mounted on the glove box. The system is controlled by a rocker type switch on the pilot's switch panel. A circuit breaker on the circuit breaker panel protects the system.

15-72. REMOVAL AND INSTALLATION. (See figure 15-11.)

a. Panel Removal

1. Ensure aircraft electrical power is "OFF".
2. Disconnect housing plug and cap, located forward of instrument panel on the left hand side.
3. Remove screws securing cover and gasket to deck skin, then pull housing plug up through skin.
4. Remove screws from retainers at top and bottom of heated panel.
5. Remove heated panel, retainers and shims at top and bottom of panel.
6. Remove any sealer that may have parted sticking to the windshield. A sharpened (Wood) spatula may be used, exercising care.

CAUTION

Do Not use any tool, abrasive or cleaner which may damage the windshield.

b. Panel Installation.

1. Apply a strip of masking tape on the LH windshield, from top to bottom, with outboard edge of tape located 6.60 inches to the left and parallel with the windshield centerline, as viewed looking forward.

2. Apply a strip of masking tape at the bottom of heated panel location with edge running parallel with, and $.55$ inch below the center of the three open fastener locations. However, this dimension may vary as lower edge of heated panel may be trimmed to match aircraft contours. A minimum of $.35$ inch edge margin must be maintained.


3. Locate heated panel with lower end and in-board side against edge of masking tape. Using a hole finder, locate and mark the four hole locations at the lower end of the panel.

4. Drill four $.172$ holes on the lower end of the panel where marked.

5. Place lower spacer in position and temporarily secure the lower end of heated panel with four screws.

6. Press the heated panel to the windshield contour working up from the bottom so that panel seal is compressed against windshield, firmly tape heated panel to windshield.

MODEL P210 SERIES SERVICE MANUAL



- 1. Controller
- 2. Relay
- 3. Screw
- 4. Panel
- 5. Retainer
- 6. Shim
- 7. Lead
- 8. Cover
- 9. Gasket
- 10. Deck Skin
- 11. Housing Cap
- 12. Housing Plug

Detail A

Detail C

Detail B

Figure 15-11. Windshield Anti-Ice Panel Installation (Fixed)

MODEL P210 SERIES SERVICE MANUAL

NOTE

The inner and outer lip of the heated panel seal should be in positive contact with the surface of the windshield over the full periphery of the panel. It is permissible to vary thickness of the spacers to facilitate proper sealing.

7. Using a hole finder, mark the center hole location at the upper end of panel.

CAUTION

Protect aircraft structure. Slip a thin metal shield between heated panel and windshield retainer to guard against drill bit thrust when penetrating heated panel.

8. Drill a (.172) hole located .10 inch down from the mark on the heated panel.

9. Remove drilling shield.

10. Use a pointed aligning tool (ice pick) through hole in heated panel and open hole in windshield retainer. pull panel up to align holes.

NOTE

Take precaution to prevent damage to windshield and/or doubler nutplates when tightening heated panel on windshield.

11. Using a hole finder, mark the remaining holes at the upper end of the panel.

12. Place the drilling shield between heated panel and windshield retainer and drill (.172) holes at the marked locations.

13. Place the upper spacer in position between heated panel and windshield and temporarily secure using four screws.

14. Check the temporary installation to ensure that heated panel is in proper relation to the windshield. Check to see if panel seal is in contact with windshield.

15. Remove the masking tape applied to windshield for locating heated panel. Apply new strips of masking tape on each side of the panel with edge aligned with and against outer lip of seal to facilitate final installation. Also apply strips of tape to upper and lower edge of heated panel.

16. Remove heated panel and deburr all parts.

17. Remove protective cover from the heated panel. Do not remove masking tape aligning guides. Clean thoroughly with a soft cloth or sponge. Wash with a mild soap and water. a 50/50 solution of isopropanol and water, or aliphatic naphtha types. Do not use any abrasive materials, strong acid or base, methanol or methyl-ethyl-ketone. After cleaning, rinse thoroughly and dry.

18. After cleaning, plastic surfaces may be polished by applying a thin coat of hard polishing wax. Rub lightly with a soft cloth using a circular motion.

19. Apply a bead of RTV108 sealer to the groove of heated panel.

NOTE

Do not allow the RTV108 sealer to be pressed out of the seal upon installation. If this happens, remove the heated panel, wipe the sealer off the windshield and the seal on the heated panel with isopropyl alcohol. Reapply RTV108 sealer in grooves, correcting the amount of bead, and reinstall the heated panel.

20. Install heated panel on windshield exercising care to prevent smearing of sealer.

21. Ensure proper location of spacers at upper and lower ends of heated panel. (See note after step 5).

22. Apply RTV-108 sealer to screws.

23. Install screws at top and bottom of heated panel.

24. Route heated panel electrical leads through the deck skin and gaskets then connect.

25. Install cover and apply a strip of tape around opening to keep sealer off of deck skin. Apply RTV 108 sealer, putting wire bundle in cover.

NOTE

Allow 24 hours for full cure of RTV108 sealer.

26. Remove all tape around heated panel and lead cover.

27. Operational check the heated panel as follows:
a. Turn windshield de-ice switch momentarily ON, check ammeter for discharge.

15-73. TRAPPED MOISTURE. To eliminate moisture trapped between the heated windshield panel and the windshield, proceed as follows:

a. Fabricate two probes from .125 diameter tube approximately three inches long. Cut one end of tubes off at approximately a 30° or less angle. File to a sharp edge.

b. Insert one tube through the upper outboard corner of the heated panel and the other through the lower inboard corner. Move lower tube to the outboard corner as required to release all trapped water. Insert tubes through the rubber seal.

c. Connect upper tube to a source of low pressure dry air, or bottled nitrogen. Flow air between the heated panel and windshield until all visible moisture is gone. Activate heated panel for short periods to accelerate removal of moisture.

d. Apply soap and water mixture to edges of the heated panel. Restrict exit air, note and mark leakage from under panel. (Do not over pressure; use no more than 2.0 psi.)

e. Clean windshield and edge of heated panel with mild soap and water, a 50/50 solution of isopropyl alcohol and water. Wipe dry and apply masking tape along leak area approximately .06 from seal. Lift edge of seal and insert RTV. Fill gap at upper and lower ends of heated panel between panel seal and the windshield retainer with RTV if leak is in this area. Remove tubes from windshield; fill holes with RTV and remove masking tape. Use clear RTV-108 sealer only.

MODEL P210 SERIES SERVICE MANUAL

15-74. ICE DETECTOR LIGHT. (See figure 15-6.)

15-75. DESCRIPTION. An optional ice detector light may be installed on the left hand side of the fuselage, forward of the cabin door. The ice detector light will illuminate the leading edge of the left wing so the pilot can visually detect ice formation on the wing. A push-button switch, located below the master switch, controls the ice detector light.

15-76. DUAL ALTERNATOR SYSTEM. (See Section 17 of this manual.)

15-77. DUAL VACUUM SYSTEM. (See Section 16 of this manual.)

15-78. CONTROL SURFACE DISCHARGERS.

15-79. DESCRIPTION. Wick-type static dischargers are installed on the trailing edge surfaces of the ailerons, elevators and rudder of the airplane. These dischargers are used to reduce the stored voltage that is the result of electrostatic charging. The buildup of static electricity on the airframe is a consequence of flying through haze, dust, rain, snow or ice crystals.

Reduction of stored potential (voltage) is necessary to prevent undesirable electrostatic currents that could cause unacceptable radio noise or electrical insulation failures.

The wick is attached to the base by a threaded fitting, and may be replaced without removing the base from the airplane.

15-80. INSPECTION. Static wicks and their bases should be checked for physical condition. The majority of failures will be due to "hangar rash" or lightning damage, be certain to inspect the airframe itself for damage. Wick-type dischargers are functional as long as any material is present and their resistance is within the range given in paragraph 15-80A. Static dischargers lose their effectiveness with age and exposure to static electricity; therefore, they should have a resistance check when installed or every 200 hours or annually; whichever occurs first.

15-80A. RESISTANCE CHECK. Perform the following resistance checks on each control surface discharger and replace those which do not conform to the resistance requirements.

NOTE

A GOOD airframe ground must be established in order to perform RELIABLE resistance checks on the control surface dischargers.

- a. Check the resistance from the base to a good airframe ground using a low voltage ohmmeter. The resistance should not exceed 1.0 ohm maximum.

WARNING

Do not bend the wick during the following step since wicks have a higher resistance when bent.

- b. Using a "megger", connect the EARTH terminal to the base of the discharger and check the resistance at the tip of the wick. The resistance should check between 1 to 100 megohms.

NOTE

A "megger" is a 500 to 1000 volt capacity megohmmeter and is available from the James G. Biddle Co., Plymouth Meeting, PA. 19462.

15-80B. REMOVAL/INSTALLATION.

- a. Remove discharger wick from base. Discard lockwasher.
- b. To remove base drill out rivets taking care not to distort holes in skin.
- c. Installing the mounting base.
 1. Use fine grit sandpaper and remove any paint that is around the attaching holes or under the mounting base footprint.
 2. With a 500 or 600 grit emery cloth, break the aluminum oxide in the footprint (new oxide will form within minutes, do not delay performing steps 3. and 4.
 3. Clean the mating surface of the airplane's skin with solvent.
 4. Brush the cleaned skin with Alumina Prep 1201 alodine and wait until it is dry before proceeding.
 5. Install the new base using an appropriate size blind rivet.
 6. Primer and paint may be used as desired on the airplane skin (cover any attached discharger with paper or rag; do not use tape). Screw threads in the base should be protected with a lightly inserted wooden plug.
- d. Installing the discharger wick.
 1. Remove the plastic lockwasher retainer from the new discharger and discard (do not lose the new lockwasher).
 2. Screw the new static discharger into the base only tight enough to compress the lockwasher; do not overtorque.

15-80C. ELECTRICAL BONDING.

15-80D. DESCRIPTION. Individual electrically conductive components and structures of the airplane must be electrically bonded together. This bonding is necessary to ensure that all conductive material on the airplane is at the same electric potential. If electrical bonding is not maintained, crew members or passengers may encounter electrical shocks, radio and other avionic system interference or even damage will result and corrosion between dissimilar materials may occur.


Bond resistance between structures should not exceed 0.003 ohms unless otherwise specified in specific installations. After major repair and/or replacement of components or control surfaces an electrical bonding check is required.

15-81. PITOT TUBE AND STALL WARNING.

15-82. DESCRIPTION. A special pitot tube with a larger inlet and higher capacity heating element and a higher capacity heated stall warning transducer are installed in the left wing to assure proper airspeed

MODEL P210 SERIES SERVICE MANUAL

COMBINED OPERATION OF THE PITOT HEAT, WINDSHIELD AND PROPELLER ANTI-ICING SYSTEMS WILL CAUSE THE COMPASS DEVIATIONS TO EXCEED 10° ON NORTHERLY AND SOUTHERLY HEADINGS.



1. Control Surface Discharges
2. Squat Switch
3. Bracket
4. Pitot Tube
5. Union
6. Receptacle
7. Heater Element
8. Stall Warning Unit

Figure 15-12. Known Icing Equipment

MODEL P210 SERIES SERVICE MANUAL




Figure 15-13. Windshield Anti-Ice Panel Installation (Removable)

MODEL P210 SERIES SERVICE MANUAL

indications and stall warning in the event icing conditions are encountered. These systems are designed to prevent ice formation rather than remove it after it forms. Both systems are controlled by separate rocker switches labeled, PITOT HEAT and STALL HEAT. The pitot tube heater is protected by a 10-amp circuit breaker labeled, PITOT HEAT. The stall warning heater is protected by a 5-amp circuit breaker labeled, STALL HEAT. When the aircraft is on the ground, a resistor is introduced into the stall warning heater circuit by the nose wheel squat switch in order to prevent overheating. In addition, thinner static port buttons are used with the special pitot tube in order to maintain the standard airspeed calibrations.

15-83. REMOVAL AND INSTALLATION. (See figure 15-12.)

15-84. HEATED WINDSHIELD PANEL (REMOVABLE.) (See figure 15-13.)

15-85. DESCRIPTION. The panel is constructed of two sheets of plate glass covering a layer of vinyl. Imbedded in the vinyl is a fine resistance wire which provides the heat for windshield de-icing. The lower edge of the panel is mounted on the deck skin just forward of the windshield. The upper end of the panel is supported by a rubber bumper which holds the panel off the windshield. The lower mounting bracket is hinged for easy cleaning between the panel and windshield. The hinge pins are spring loaded so the panel may be easily removed. Power to the windshield panel is provided through a plug located in a housing assembly just left of the lower support bracket. A drain tube is provided for the housing assembly also a plug button, painted the same color as the deck skin, to plug the connector hole when the anti-ice assembly is removed. A circuit breaker switch located on the instrument panel is a off-on switch and a circuit breaker to protect the system.

15-86. REMOVAL AND INSTALLATION. (See figure 15-13.) Use the figure as a guide for removal and installation of components.

15-87. OXYGEN SYSTEM.

15-88. DESCRIPTION. The solid-state emergency oxygen system consists of oxygen generators and masks located in the overhead console. One generator is provided for the pilot, co-pilot and 3rd seat passenger and a second generator is provided for the 4th, 5th and 6th seat passengers. The generators contain solid chemicals, which when activated, provide an oxygen supply for approximately 15 minutes from each oxygen generator. A lanyard is provided in each stowage compartment to activate the chemical process in the generator. After the chemical reaction has been initiated, the flow of oxygen will continue until the generator is entirely expended. Once expended, they must be replaced. Amber lights are located in the overhead console to indicate that oxygen is being supplied by the generator or has been expended. Flow indicators are provided in the lines. A green color indicates an adequate supply of oxygen.

A red color indicates an inadequate or no oxygen flow. Disposable partial rebreathing type masks are provided.

15-89. OPERATION.

- a. Open mask compartment (located in overhead console) and remove mask from bag being careful not to destroy the printed instructions on bag.
- b. Put on mask following instructions on bag.
- c. Adjust metallic nose strap for snug fit.
- d. Pull lanyard.
- e. Check flow indicator for green indication.
- f. Reduce cabin altitude to 10,000 feet or lower before the 15-minute oxygen supply is depleted. (Refer to Pilot's Operating Handbook.)

WARNING

For safety reasons, no smoking should be allowed in aircraft while oxygen is being used.

15-90. SYSTEM OPERATIONAL STATUS CHECK. Determine operational condition of oxygen system as follows:

- a. Turn master switch on.
- b. Observe oxygen warning lights. Amber lights indicate that oxygen has been depleted and, therefore, requires a new generator.

CAUTION

Oxygen system checkout should be performed prior to each flight since the oxygen generators may have been expended on the previous flight.

15-91. REMOVAL OF OXYGEN GENERATORS AND MASKS. (See figure 15-14.)

- a. Open mask compartment and remove bag and mask from tube. Remove placard from lanyard; save placard.
- b. Remove screws holding overhead console in place and remove consoles. (This will require disconnecting two ram air hoses from forward end of aft console. (Refer to figure 15-1.)
- c. Note routing of mask tubes then remove tubes from clamps along routing and pull away from ports on oxygen generator.
- d. Working through zipper opening in headliner, remove screws attaching bottom plate to generator mounting bracket. Remove bottom plate and spread sides of mounting bracket to free generator mounting pins. Remove generator.

15-92. INSTALLATION OF OXYGEN GENERATORS AND MASKS. (See figure 15-14.)

CAUTION

Do not remove safety cap from generator until after installation is complete.

- a. Working through zipper opening in headliner, spread sides of generator mounting bracket and install generator. Insure that mounting pins on side of

MODEL P210 SERIES SERVICE MANUAL




Figure 15-14. Emergency Oxygen System.

generator engage pin holes in bracket then install bottom plate on mounting bracket.

b. Cut pin off of old lanyard and tape ends of new lanyards to old one. Pull new lanyard through routing tube by pulling on the placard end of the old one. Remove old lanyard and discard.

c. Set spring-loaded ignitor firing mechanism to loaded position and connect indicator light mechanism. (Refer to figure 15-14 and paragraph 15-93.)

CAUTION

Do not remove safety cap from generator ignitor until after installation is complete.

d. Cut off lower corner of mask bag and pull tube out of bag. (Do not remove cap from end of tube.)

e. Have an assistant hold the overhead console directly below it's source location and route mask

MODEL P210 SERIES SERVICE MANUAL

tubes through hole in upper left hand corner of mask compartment and through clamps along original routing.

f. Remove caps from end of mask tubes and install tubes on generator; tighten all clamps.

g. Push lanyard through hole in forward end of mask compartment and attach placard with square knot.

h. Reconnect ram air hoses to ports on overhead console. (Aft console only.)

i. Remove safety cap from generator ignitor.

j. Install overhead console on aircraft.

k. Push mask tubes back into bag until bag hangs approximately 12 inches below mask compartment. Tape bag to tube at this point with clear or transparent tape.

l. Install mask bags and lanyard in mask compartment and install cover on compartment. (Recheck square knot in lanyard before installing cover.)

m. Working through zipper opening in headliner, recheck to see that mask tubes are firmly in place on generator.

n. Close zipper opening.

15-93. OXYGEN SYSTEM INDICATOR LIGHT SWITCH ADJUSTMENT. (See figure 15-14.)

When lanyard (2) is pulled, pin (3) will be drawn out of bracket on oxygen generator (4), disconnecting spring (1). This action releases spring (14) which will snap back and contact actuator of switch (10).

When springs (14) and (1) are connected and hooked over pin (3), switch (10) actuator should be adjusted to clear (below) spring (14). Switch (10) should be adjusted in slotted holes in bracket (8), with screws (11).

15-94. OXYGEN SYSTEM. (76 CU. FT.) (See figure 15-15.)

WARNING

Under No circumstances, turn the ON-OFF control to the "ON" position with the outlet (low pressure) ports open to atmosphere. This action will induce serious damage to the regulator, with the following results:

1. Loss of outlet set pressure.
2. Loss of oxygen flow through the regulator which will result in inadequate oxygen being fed through the aircraft system.
3. Internal leakage of oxygen through regulator.

Opening of the control lever with the outlet ports open to atmosphere, results in an "overshoot" of the regulator metering device due to the extreme flow demand through the regulator. After overshooting, the metering poppet device goes into oscillation, creating serious damage to the poppet seat and diaphragm metering probe. This condition can occur even by turning the control lever on and then turning it quickly off.

A potential hazard exists to aircraft in the field where inexperienced personnel might remove the cylinder and regulator assembly from the aircraft

and for some reason, attempt to turn the regulator to the "ON" position with the outlet ports open. Unfortunately, after the units have been improperly operated as noted, there is no outward appearance indicating that damage has occurred.

Testing these regulators should be accomplished only after installation in the aircraft, with the "downstream" low pressure line attached.

15-95. DESCRIPTION. The system is comprised of an oxygen cylinder and regulator assembly, filler valve, pressure gage, pressure lines, outlets and mask assemblies. The oxygen cylinder is mounted aft of the baggage compartment. Locations of system components are shown in figure 15-15. The pilot's supply line is designed to receive a greater flow of oxygen than the passengers. The pilot's mask is equipped with a microphone, keyed by a switch button on the pilot's control wheel. The filler valve is located on the aft baggage curtain and access is gained through the baggage door.

WARNING

Oil, grease or other lubricants in contact with high-pressure oxygen, create a serious fire hazard and such contact should be avoided. Do not permit smoking or open flame in or near aircraft while work is performed on oxygen systems.

15-96. MAINTENANCE PRECAUTIONS.

If maintenance is performed on the airplane oxygen system, or on any other system in the airplane requiring removal of an oxygen system component, strict adherence to the following procedures and precautions is required.

WARNING

Do not permit smoking or open flame near airplane while maintenance is being performed on the oxygen system. Assure all electrical power is disconnected and that airplane is properly grounded. In addition, oils, grease, and solvents may burn or explode spontaneously when contacted by oxygen under pressure.

CAUTION

Oxygen cylinders and regulators are furnished as assemblies by Cessna Parts Distribution (CPD 2). Attempting to remove, repair, and reinstall oxygen regulators in the field provides opportunity for contaminants to enter the system. Faulty regulators or regulators otherwise in need of disassembly should be exchanged for replacement oxygen bottle and regulator assemblies through CPD 2. Regulator and cylinder assembly shall be disassembled, repaired, inspected, cleaned, hydrostatically tested, reassembled, and serviced by manufacturer or other FAA-approved facility.

MODEL P210 SERIES SERVICE MANUAL




Figure 15-15. Oxygen Installation (Sheet 1 of 3)

a. Working area, tools and hands must be clean.
 b. Keep oil, grease, water, dirt, dust and all other foreign matter from system.
 c. Keep all lines dry and capped until installed.
 d. Use only MIL-T-5542 thread compound or teflon lubricating tape on threads of oxygen valves, tubing connectors, fittings, parts of assemblies which might under any conditions, come in contact with oxygen. The thread compound must be applied sparingly and carefully to only the first three threads of the male fitting. No compound shall be used on aluminum flared fittings or on the coupling sleeves or on the outside of the tube flares. The teflon tape shall be used in accordance with the instructions listed following this step. Extreme care must be exercised to prevent the contamination of the thread compound or teflon tape with oil, grease or other lubricant.

1. Place tape on threads close to end of fitting. Wrap clockwise on RH threads, counterclockwise on LH threads.
2. Apply enough tension while winding so tape forms into thread grooves.

3. After wrap is complete, maintain tension and tear tape by pulling apart in direction it was applied. Resulting ragged end is the key to the tape staying in place. (If sheared or cut, tape may unwind.)
4. Press tape well into threads.
5. Make connections.
- e. Fabrication of oxygen pressure lines is not recommended. Lines should be replaced by part numbers called out in the aircraft Parts Catalog.
- f. Lines and fittings must be clean and dry. One of the following methods may be used.
 1. Clean by degreasing with stabilized trichlorethylene, conforming to Federal Specifications O-T-634 or MIL-T-27602. These items can be obtained from American Mineral Spirits of Houston, Texas.

NOTE

Most air compressors are oil lubricated, and a minute amount of oil may be carried by the airstream. If only an oil lubricated air compressors is available, drying must be accomplished by heating at a temperature of 250° to 300°F for a suitable period.

MODEL P210 SERIES SERVICE MANUAL




Figure 15-15. Oxygen Installation (Sheet 2 of 3)

MODEL P210 SERIES SERVICE MANUAL




Figure 15-15. Oxygen Installation (Sheet 3 of 3)

MODEL P210 SERIES SERVICE MANUAL

2. Flush with naphtha, conforming to Specification TT-N-95 (aliphatic naphtha). Blow clean and dry off all solvents with clean, dry, oil-free, filtered air. Flush with anti-icing fluid conforming to Specification TT-T-735 or anhydrous ethyl alcohol. Rinse thoroughly with fresh water. Dry thoroughly with a stream of clean, dry, oil-free, filtered air.

3. Flush with hot inhibited alkaline cleaner until free from oil and grease. Rinse with fresh water and dry with clean, dry, filtered air.

NOTE

Cap lines at both ends immediately after drying to prevent contamination.

15-97. REPLACEMENT OF COMPONENTS. Removal, disassembly, assembly and installation of system components may be accomplished while using figure 15-15 as a guide.

WARNING

The pressure regulator, pressure gage and line and filler valve should be removed and replaced only by personnel familiar with high-pressure fittings. Observe the maintenance precautions listed in the preceding paragraph.

NOTE

Oxygen cylinder and regulator assemblies may not always be installed in the field exactly as illustrated in figure 15-15, which shows factory installation. Important points to remember are as follows.

a. Before removing cylinder, release low-pressure line by opening cabin outlets. Disconnect push-pull control cable, filler line, pressure gage line and outlet line from regulator. **CAP ALL LINES IMMEDIATELY.**

b. If it is necessary to replace filler valve O-rings, remove parts necessary for access to filler valve. Remove line from quick-disconnect valve at the regulator, then disconnect chain, but do not remove cap from filler valve. Remove screws securing valve and disconnect pressure line. Referring to applicable figure, cap pressure line and seat. Disassemble valve, replace O-rings and reassemble valve. Install filler valve by reversing procedures outlined in this step.

c. To remove entire oxygen system, headliner must be lowered and soundproofing removed to expose lines. Refer to Section 3 for headliner removal.

15-98. OXYGEN CYLINDER GENERAL INFORMATION. The following information is permanently steel stamped on the shoulder, top head or neck of each oxygen cylinder and on a placard on the composite cylinders:

a. Cylinder specification, followed by service pressure (e.g. "ICC or DOT-3AA1800" and "ICC or DOT-3HT1850" for standard and light weight cylinders respectively and DOT-E8162-3000 on the composite

cylinder.

NOTE

Effective 1 January 1970, all newly-manufactured cylinders are stamped "DOT" (Department of Transportation), rather than "ICC" (Interstate Commerce Commission). An example of the new designation would be: "DOT-3HT1850".

b. Cylinder serial number is stamped below or directly following cylinder specification. The symbol of the purchaser, user or maker, if registered with the Bureau of Explosives, may be located directly below or following the serial number. The cylinder serial number may be stamped in an alternate location on the cylinder top head.

c. Inspector's official mark near serial number.

d. Date of manufacture: This is the date of the first hydrostatic test (such as 4-69 for April 1969). The dash between the month and the year figures may be replaced with the mark of the testing or inspection agency (e.g. 4L89).

e. Hydrostatic test date: The dates of subsequent hydrostatic tests shall be steel stamped (month and year) directly below the original manufacture date. The dash between the month and year figures can be replaced with the mark of the testing agency.

f. A Cessna identification placard is located near the center of the cylinder body.

g. Halogen test stamp: "Halogen Tested", date of test (month, day and year) and inspector's mark appears directly underneath the Cessna identification placard.

15-99. OXYGEN CYLINDER SERVICE REQUIREMENTS.

a. Hydrostatic test requirements:

1. Standard weight (ICC or DOT-3AA1800) cylinders must be hydrostatically tested to 5/3 their working pressure every five years commencing with the date of the last hydrostatic test.

2. Light weight (ICC or DOT-3HT1850) cylinders must be hydrostatically tested to 5/3 their working pressure every three years commencing with the date of the last hydrostatic test.

3. Composite (DOT-E8162) cylinders must be hydrostatically tested to 5/3 their working pressure every three years commencing with the date of the last hydrostatic test.

b. Service life requirements:

1. Standard weight (ICC or DOT-3AA1800) cylinders have no age life limitations and may continue to be used until they fail hydrostatic test.

2. Light weight (ICC or DOT-3HT 1850) cylinders must be retired from service after 24 years or 4,380 filling cycles after date of manufacture, whichever occurs first. If a cylinder is recharged more than an average of once every other day, an accurate record of the number of rechargings must be maintained.

3. Composite (DOT-E8162) cylinders must be retired from service after 15 years.

MODEL P210 SERIES SERVICE MANUAL

NOTE

Each interconnected series of oxygen cylinders is equipped with a single gage. The trailer type cascade may also be equipped with a nitrogen cylinder (shown reversed) for filling landing gear struts, accumulators, etc. Cylinders are not available for direct purchase, but are usually leased and refilled by a local compressed gas supplier.

Service Kit SK310-32 (available from Cessna Supply Division) contains an adapter, a pressure gage, hose, lines, and fittings for equipping two oxygen cylinders to service oxygen systems. As noted in the Service Kit, a tee (Part No. 11844) and a pigtail (Part No. 1243-2) should be ordered for each additional cylinder to be used in the cascade of cylinders. Be sure to ground the airplane and ground servicing equipment before use.




Figure 15-16. Typical Portable Oxygen Cascades

NOTE

These test periods and life limitations are established by the Department of Transportation Code of Federal Regulations, Title 49, Chapter 1, Para. 73-34.

15-100. INSPECTION OF OXYGEN CYLINDER-REGULATOR. (DOT-E8162)

a. A careful visual inspection of the oxygen cylinder should be performed during routine maintenance and periodic inspections. If the acceptability of the cylinder is questionable, return cylinder to manufacturer. Acceptable damage consists of such items as scratched paint or cuts and abrasions.

1. Scratches or Cuts. Cuts or scratches less than .005" (.125mm) deep are acceptable.

2. Abrasions. Minor abrasions such as scuffs, are acceptable unless the damage is deep enough to expose groups of fibers. Abrasions with isolated groups of fibers exposed or flat spots with depth less than .010" (.254mm) must be epoxy coated to avoid water entrapment. A group of fibers is defined as .010" (.254mm) thick and .125" (3.175mm) wide.

3. Paint Removal. Paint removal is not recommended. In the event that paint removal for inspection or other reasons is required, the suitability of the paint removal procedure must be verified by the cylinder manufacturer. Some chemical paint removers may damage the composite. Abrasive or other mechanical means of paint removal, such as shot blast or wire brush are prohibited.

b. Regulator shall be removed and overhauled by manufacturer or an FAA-approved facility during hydrostatic testing.

c. Actuate regulator controls and valve to check for ease of operation.

CAUTION

Damage to regulator will occur if the control of a charged oxygen cylinder is turned ON with the low-pressure side of the regulator open to the atmosphere.

d. Pressurize the system and check for leaks.

NOTE

For oxygen cylinder inspection, also refer to publication CGAC06.2, Compressed Gas Association, Inc., Arlington, VA 22202.

15-101. OXYGEN SYSTEM COMPONENT SERVICE REQUIREMENTS.

a. **PRESSURE REGULATOR.** The regulator shall be removed and overhauled by manufacturer or an FAA approved facility during hydrostatic testing.

b. **FILLER VALVE.** The valve should be disassembled, inspected and the O-ring replaced, regardless of condition, every 3 years or 3000 flight hours, whichever occurs first.

c. **QUICK-RELEASE COUPLING.** The coupling shall be functionally tested every two years and over-

MODEL P210 SERIES SERVICE MANUAL

hauled every five years or at time of hydrostatic test.

d. **PRESSURE GAGE.** The gage shall be replaced when found to be faulty. No re-conditioning or overhaul of the gage is authorized.

e. **INDIVIDUAL OUTLETS.** The outlets shall be disassembled and inspected and the O-rings replaced, regardless of condition, every 3 years or 3000 flight hours, whichever occurs first.

15-102. OXYGEN SYSTEM COMPONENT INSPECTION REQUIREMENTS.

a. Examine all parts for cracks, nicks, damaged threads or other apparent damage.

b. Actuate regulator controls and valve to check for ease of operation.

c. Determine if the gage is functioning properly by observing the pressure build-up and the return to zero when the system oxygen is bled off.

d. Replace any oxygen line that is chafed, rusted, corroded, dented, cracked or kinked.

e. Check fittings for corrosion around the threaded area where lines are joined together. Pressurize the system and check for leaks.

15-103. MASKS AND HOSE.

a. Check oxygen masks for fabric cracks and rough face seals. If the mask is a full-faced model, inspect glass or plastic for cleanliness and state of repair.

b. Flex the mask hose gently over its entirety and check for evidence of deterioration or dirt.

c. Examine mask and hose storage compartment for cleanliness and general condition.

15-104. MAINTENANCE AND CLEANING.

a. Clean and disinfect mask assemblies after use, as appropriate.

NOTE

Use care to avoid damaging microphone assembly while cleaning and sterilizing.

b. Wash mask with a mild soap solution and rinse it with clear water.

c. To sterilize, swab mask thoroughly with a gauze or sponge soaked in a water/merthiolate solution. This solution should contain 1/5 teaspoon of merthiolate per one quart of water. Wipe the mask with a clean cloth and let air dry.

d. Observe that each mask breathing tube end is free of nicks and that the tube end will slip into the cabin oxygen receptacle with ease and will not leak.

e. If a mask assembly is defective (leaks, does not allow breathing or contains a defective microphone) it is advisable to return the mask assembly to the manufacturer or a repair station.

f. Replace hose if it shows evidence of deterioration.

g. Hose may be cleaned in the same manner as the mask.

15-105. OXYGEN SYSTEM PURGING.

a. A vapor degreasing solution of stabilized trichlorethylene conforming to MIL-T-7003, followed by blowing tubing clean and dry with a jet of nitrogen

gas (BB-N411) Type 1, Class 1, Grade A or Technical Argon (MIL-A-18455).

CAUTION

MOST AIR COMPRESSORS ARE OIL LUBRICATED, AND A MINIMUM AMOUNT OF OIL MAY BE CARRIED BY THE AIR STREAM. A WATER LUBRICATED COMPRESSOR SHOULD BE USED TO BLOW TUBING CLEAN WHEN NITROGEN OR ARGON ARE NOT AVAILABLE. THE AIR MUST BE CLEAN, DRY AND FILTERED.

b. Flush with naphtha conforming to Specification TT-N-95; then blow clean and dry with clean, dry, filtered air. Flush with anti-icing fluid conforming to MIL-G-5566 or anhydrous ethyl alcohol. Rinse thoroughly with fresh water and dry with a jet of nitrogen gas (BB-N-411) Type 1, Class 1, Grade A or Technical Argon (MIL-A-18455).

c. Flush with hot inhibited alkaline cleaner until free from oil and grease. Rinse with fresh water and dry with a jet of nitrogen gas (BB-N-411) Type 1, Class 1, Grade A or Technical Argon (MIL-A-18455).

NOTE

Cap all lines immediately after drying.

d. Fabrication of pressure lines is not recommended. Lines should be replaced from the factory by part number.

e. Use only S1465 Teflon lubricating tape on the threads of the male fittings. No lubricating tape is used on coupling sleeves or outside of the flares.

f. Maintenance personnel must assure that their hands are free of dirt and grease prior to installation of oxygen tubing or fittings.

CAUTION

USE NONSPARKING TOOLS.

WARNING

WITH OXYGEN BOTTLE CHARGED, DO NOT PULL CONTROL TO "ON" POSITION WITH OUTLET PORTS (LOW PRESSURE) OPEN TO ATMOSPHERE. DAMAGE TO REGULATOR METERING POPPET MAY OCCUR.

WARNING

WHENEVER A COMPONENT OF THE OXYGEN SYSTEM HAS BEEN REMOVED, REINSTALLED, REPLACED OR SYSTEM HAS BEEN DISASSEMBLED IN ANY WAY, THE OXYGEN SYSTEM MUST BE LEAK CHECKED AND PURGED.

3. All tools used for installation of oxygen tubes or fittings must be free of dirt, grease and oils.

MODEL P210 SERIES SERVICE MANUAL

15-106. FUNCTIONAL TESTING. Whenever the regulator and cylinder assembly has been replaced or overhauled, perform the following flow and internal leakage tests to check that the system functions properly.

- a. Fully charge oxygen system in accordance with procedures outlined in paragraph 15-108.
- b. Disconnect line and fitting assembly from pilot's mask and line assembly. Insert outlet end of line and fitting assembly into cabin outlet and attach opposite end of line to a pressure gage (gage should be calibrated in one-pound increments from 0 to 100 PSI). Place control lever in ON position. Gage pressure should read 70 ± 10 PSI.
- c. Insert mask and line assemblies into all remaining cabin outlets. With oxygen flowing from all outlets, test gage pressure should still be 70 ± 10 PSI.
- d. Place oxygen control lever in OFF position and allow test gage pressure to fall to 0 PSI. Remove all adapter assemblies except the one with the pressure gage. The pressure must not rise above 0 PSI when observed for one minute. Remove pressure gage and adapter from oxygen outlet.

NOTE

If pressures specified in the foregoing procedures are not obtained, the oxygen regulator is not operating properly. Remove and replace cylinder-regulator assembly with another unit and repeat test procedure.

- e. Connect mask and line assemblies to each cabin outlet and check each mask for proper operation.
- f. Check pilot's mask microphone and control wheel switch for proper operation. After checking, return all masks to mask case.
- g. Recharge oxygen system in accordance with procedures outlined in paragraph 15-108.

15-107. SYSTEM LEAK TEST. When oxygen is being lost from a system through leakage, a sequence of steps may be necessary to locate the opening. Leakage may often be detected by listening for the distinct hissing of escaping gas. If this check proves negative, it will be necessary to soap-test all lines and connections with a castile soap and water solution or specially compounded leak-test material. Make the solution thick enough to adhere to the contours of the fittings. At the completion of the leakage test, remove all traces of the leak detector or soap and water solution.

CAUTION

Do not attempt to tighten any connections while the system is charged.

15-108. SYSTEM CHARGING.

WARNING

BE SURE TO GROUND AIRCRAFT AND GROUND SERVICING EQUIPMENT BEFORE CHARGING OXYGEN SYSTEM.

- a. Do not attempt to charge oxygen cylinders if servicing equipment fittings or filler valve are corroded or contaminated. If in doubt, clean with stabilized trichlorethylene and let air dry. Do not allow solvent to enter any internal parts.
- b. If cylinder is completely empty, do not charge. as the cylinder must then be removed, inspected and cleaned.

CAUTION

A cylinder which is completely empty may well be contaminated. The regulator and cylinder assembly must then be disassembled, inspected and cleaned by an FAA approved facility, before filling. Contamination, as used here, means dirt, dust or any other foreign material, as well as ordinary air in large quantities. If a gage line or filler line is disconnected and the fittings capped immediately, the cylinder will not become contaminated unless temperature variation has created a suction within the cylinder. Ordinary air contains water vapor which could condense and freeze. Since there are very small orifices in the system, it is very important that this condition not be allowed to occur.

- c. Connect cylinder valve outlet or outside filler valve to manifold or portable oxygen cascade.
- d. Slowly open valve on cascade cylinder or manifold with lowest pressure, as noted on pressure gage, allow pressure to equalize, then close cascade cylinder valve.
- e. Repeat this procedure, using a progressively higher pressure cascade cylinder, until system has been charged to the pressure indicated in the chart immediately following step "f" of this paragraph.
- f. Ambient temperature listed in the chart is the air temperature in the area where the system is to be charged. Filling pressure refers to the pressure to which aircraft cylinders should be filled. This table gives approximations only and assumes a rise in temperature of approximately 25°F , due to heat of compression. This table also assumes the aircraft cylinders will be filled as quickly as possible and that they will only be cooled by ambient air; no water bath or other means of cooling be used.
Example: If ambient temperature is 70°F ., fill aircraft cylinders to approximately 1,975 psi or as close to this pressure as the gage may read. Upon cooling, cylinders should have approximately 1,850 psi pressure.

TABLE OF FILLING PRESSURES

Ambient Temp. °F	Filling Press psig	Ambient Temp. °F	Filling Press. psig
0	1650	70	1975
10	1700	80	2000
20	1725	90	2050
30	1775	100	2100
40	1825	110	2150

MODEL P210 SERIES SERVICE MANUAL

SECTION 16

INSTRUMENTS AND INSTRUMENT SYSTEMS

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
INSTRUMENT AND INSTRUMENT SYSTEMS		Trouble Shooting	2J9/16-23
General	2I11/16-1	Oil Temperature Gage	2J10/16-24
Instrument Panel	2I13/16-3	Description	2J10/16-24
Description	2I13/16-3	Removal/Installation	2J10/16-24
Removal/Installation	2I13/16-3	Fuel Quantity Indicating System	2J10/16-24
Instruments	2I13/16-3	Indicators	2J10/16-24
Removal	2I13/16-3	Description	2J10/16-24
Installation	2I13/16-3	Removal/Installation	2J10/16-24
Pitot/Static Systems	2I11/16-3	Transmitter	2J10/16-24
Description	2I11/16-3	Description	2J10/16-24
Maintenance	2I11/16-3	Removal/Installation	2J10/16-24
Static System Inspection/Leakage Test	2I16/16-6	Calibration	2J12/16-26
Pitot System Inspection/Leakage Test	2I16/16-6	Trouble Shooting	2J12/16-26
Blowing Out Lines	2I18/16-8	Hourmeter	2J15/16-27
Removal/Installation	2I18/16-8	Description	2J15/16-27
Trouble Shooting	2I18/16-8	Magnetic Compass	2J16/16-28
True Airspeed Indicator	2I18/16-8	Description	2J16/16-28
Trouble Shooting	2I18/16-8	Stall Warning Horn	2J16/16-28
Trouble Shooting-Altitude	2I19/16-9	Description	2J16/16-28
Trouble Shooting-Vertical Speed Indicator	2I20/16-10	Turn Coordinator	2J16/16-28
Trouble Shooting-Pitot Heater	2I20/16-10	Description	2J16/16-28
Vacuum System	2I20/16-10	Trouble Shooting	2J16/16-28
Description	2I20/16-10	Turn-and-Slip Indicator	2J17/16-29
Trouble Shooting	2J1/16-15	Description	2J17/16-29
Trouble Shooting-Gyros	2J1/16-15	Trouble Shooting	2J17/16-29
Trouble Shooting-Pump	2J2/16-16	Cabin Pressurisation Instruments	2J18/16-30
Maintenance Practices	2J2/16-16	Cabin Altitude Rate of Change	2J18/16-30
Removal of Vacuum Pump	2J2/16-16	Description	2J18/16-30
Installation of Vacuum Pump	2J3/16-17	Trouble Shooting	2J18/16-30
Cleaning	2J3/16-17	Cabin Altitude/Differential Pressure Instrument	2J18/16-30
Relief Valve Adjustment	2J3/16-17	Description	2J18/16-30
Low-Vacuum Warning Light	2J3/16-17	Trouble Shooting	2J18/16-30
Standby Vacuum System	2J4/16-18	Electric Clock	2J19/16-31
Description	2J4/16-18	Description	2J19/16-31
Trouble Shooting	2J4/16-18	Outside Air Temperature Gage	2J19/16-31
Adjustment	2J4/16-18	Description	2J19/16-31
Removal/Installation	2J4/16-18	Turbine Inlet Temperature Gage	2J19/16-31
Engine Indicators	2J4/16-18	Description	2J19/16-31
Tachometer	2J4/16-18	Removal/Installation	2J19/16-31
Description	2J4/16-18	Turbine Inlet/Six Position EGT	2J19/16-31
Manifold Pressure/Fuel Flow	2J7/16-21	Description	2J19/16-31
Description	2J7/16-21	Removal/Installation	2J20/16-32
Trouble Shooting - Manifold Pressure Indicator	2J7/16-21	Fuel Computer/Digital Clock	2J20/16-32
Trouble Shooting - Fuel Flow Indicator	2J8/16-22	Description	2J20/16-32
Cylinder Head Temperature Gage	2J8/16-22	Operation	2J20/16-32
Description	2J8/16-22	Trouble Shooting	2J23/16-35
Trouble Shooting	2J8/16-22	Fuel Flow Transducer	2J23/16-35
Oil Pressure Gage	2J9/16-23	Fuel Flow Transducer	
Description	2J9/16-23	Installation	2J23/16-35
		Transducer Removal/Replacement	2J23/16-35
		Calibration	2J24/16-36

16-1. INSTRUMENTS AND INSTRUMENT SYSTEMS.

16-2. GENERAL. This section describes typical in-

strument installations and their respective operating systems. Emphasis is placed on trouble shooting and corrective measures only. It does NOT deal with spe-

MODEL P210 SERIES SERVICE MANUAL




Figure 16-1. Instrument Panel (Typical)

MODEL P210 SERIES SERVICE MANUAL

cific instrument repairs since this usually requires special equipment and data and should be handled by instrument specialists. Federal Aviation Regulations require malfunctioning instruments be sent to an approved instrument overhaul and repair station or returned to manufacturer for servicing. Our concern here is with preventive maintenance on various instrument systems and correction of system faults which result in instrument malfunctions. The descriptive material, maintenance and trouble shooting information in this section is intended to help the mechanic determine malfunctions and correct them, up to the defective instrument itself, at which point an instrument technician should be called in. Some instruments, such as fuel quantity and oil pressure gages, are so simple and inexpensive, repairs usually will be more costly than a new instrument. On the other hand, aneroid and gyro instruments usually are well worth repairing. The words "replace instrument" in the text, therefore, should be taken only in the sense of physical replacement in the aircraft. Whether replacement is to be with a new instrument, an exchange one, or the original instrument is to be repaired must be decided on basis of individual circumstances.

16-3. INSTRUMENT PANEL. (Refer to figure 16-1).

16-4. DESCRIPTION. The instrument panel consists of a left and right removable instrument panel, a stationary radio panel and a lower switch and controls panel. The left hand removable panel contains the flight instruments. The right hand removable panel contains the engine cluster instruments and other related instruments with additional space for radio equipment. The center stationary panel is a compartmented panel for acceptance of radio equipment. The lower stationary panel contains the aircraft systems switches and controls.

16-5. REMOVAL AND INSTALLATION.

a. Left Removable Instrument Panel.

1. Tag and disconnect wiring and plumbing connections from instruments and panel.
2. Remove the screws through face of panel and screws from bottom support angle of panel.
3. Remove screws through panel and column support bearing and bearing doubler.
4. Panel may be moved aft to the control wheel for access behind panel. If panel is to be removed completely remove the control wheel per section 6.
5. To install panel reverse the steps of procedure.

b. Right Removable Instrument Panel.

1. Removal and Installation of right panel is similar to left panel. Radio equipment, if installed, must be removed.

16-6. INSTRUMENTS. (Refer to figure 16-1).

16-7. REMOVAL. Most instruments are secured to the panel with screws inserted through the face of the panel. To remove an instrument, disconnect wiring or plumbing from instrument, remove mounting screws through panel face and remove instrument

from forward side of panel. Two instrument clusters are installed in the right removable instrument panel. Each cluster unit contains two instruments, which are individually replaceable. A cluster may be removed by removing decorative cover, removing two mounting screws and disconnecting wiring or plumbing, remove cluster unit from face of panel. Refer to figure 16-1 for replacement of individual gage. In all cases, when an instrument is removed, disconnected plumbing or wires should be protected. Cap open lines and cover pressure connections on instrument to prevent damage to threads and entrance of foreign matter. Wire terminals should be insulated or tied up to prevent accidental grounding or short-circuiting.

16-8. INSTALLATION. Generally, installation procedure is the reverse of removal procedure. Ensure mounting screw nuts are tightened firmly, but do not over-tighten, particularly on instruments having plastic cases. The same rule applies to connecting plumbing and wiring.

NOTE

All instruments (gages and indicators), requiring a thread seal or lubricant, shall be installed using teflon tape on male fittings only. This tape is available through the Cessna Supply Division.

When replacing an electrical gage in an instrument cluster assembly, avoid bending pointer or dial plate. Distortion of dial or back plate could change the calibration of gages.

16-9. PITOT AND STATIC SYSTEM. (Refer to figure 16-2).

16-10. DESCRIPTION. The pitot system conveys ram air pressure to the airspeed indicator. A pitot tube heater and stall warning heater may be installed. The heating elements are controlled by a switch on the pilots lower instrument panel and powered by the electrical system. The static system vents vertical speed indicator, altitude and airspeed indicators to atmospheric pressure through plastic tubing connected to the static ports. A static line sump is installed at each source button to collect condensation in the static system. The alternate static pressure valve, located on pilots lower switch panel, allows an alternate source of static pressure that is connected aft of the pressure bulkhead in the baggage compartment. The alternate static source is to be used only in emergency situations, when the normal system is inoperative or malfunctioning. When alternate static valve is used instrument readings may vary from normal readings due to static air source being inside of the fuselage of the aircraft. Refer to The Pilot's Operating Handbook for flight operation using alternate static source pressure.

16-11. MAINTENANCE. Proper maintenance of the pitot and static system is essential for proper operation of altimeter, vertical speed and airspeed indicators. Leaks, moisture and obstructions in the pitot system will result in false airspeed indications, while

MODEL P210 SERIES SERVICE MANUAL




Figure 16-2. Pitot Static System (Sheet 1 of 2)


MODEL P210 SERIES SERVICE MANUAL

TRUE AIRSPEED INSTALLATION


NOTE

Do not over tighten screws (16)
and do not lubricate any parts.


Use spacers (20) as required
for adequate friction on ring
assembly (18).




Detail C




Detail F



Detail D



Detail E



Detail G

Figure 16-2. Pitot Static System (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

static system malfunctions will affect the readings of all three instruments. Under instrument flight conditions, these instrument errors could be hazardous. Cleanliness and security are the principal rules for system maintenance. The pitot tube and static ports **MUST** be kept clean and unobstructed.

16-12. STATIC PRESSURE SYSTEM INSPECTION AND LEAKAGE TEST. The following procedure outlines inspection and testing of the static pressure system, assuming the altimeter has been tested and inspected in accordance with current Federal Aviation Regulations.

- a. Ensure that the static system is free from entrapped moisture and restrictions.
- b. Ensure that no alterations or deformations of the airframe surface have been made which would affect the relationship between air pressure in the static pressure system and true ambient static air pressure for any flight configuration.
- c. Seal one static source port with pressure sensitive tape. This seal must be air tight.
- d. Assure that the alternate static source valve is in the closed, normal position.
- e. Attach a source of suction to the remaining static pressure source opening. Figure 16-3 shows one method of obtaining suction.
- f. Slowly apply suction until the altimeter indicates 8,000-foot increase in altitude.

CAUTION

When applying or releasing suction, do not exceed the range of vertical speed indicator or airspeed indicator.

- g. Cut off the suction source to maintain a "closed" system for one minute. Leakage shall not exceed 160 feet of altitude loss as indicated on the altimeter.
- h. If leakage rate is within tolerance, slowly release the suction source and remove the tape from static port.

NOTE

If leakage rate exceeds the maximum allowable, first tighten all connections, then repeat leakage test. If leakage rate still exceeds the maximum allowable, use the following procedure.

- i. Disconnect the static pressure lines from airspeed indicator and vertical speed indicator. Use suitable fittings to connect the lines together so the altimeter is the only instrument still connected into the static pressure system.
- j. Repeat the leakage test to check whether the static pressure system or the bypassed instruments

are the cause of leakage. If the instruments are at fault, they must be repaired by an "appropriately rated repair station" or replaced. If the static pressure system is at fault, use the following procedure to locate leakage.

- k. Attach a source of positive pressure to the static source opening. Figure 16-3 shows one method of obtaining positive pressure.

CAUTION

Do not apply positive pressure with the airspeed indicator or vertical speed indicator connected to the static pressure system.

- l. Slowly apply positive pressure until the altimeter indicates a 500 foot decrease in altitude and maintain this altimeter indication while checking for leaks.
- m. Tighten leaking connections. Repair or replace parts found defective.
- n. Reconnect the airspeed and vertical speed indicators into the static pressure system and repeat leakage test per steps "c" through "h".

16-13. PITOT SYSTEM INSPECTION AND LEAKAGE TEST. Check the system as follows:

- a. Seal pitot openings with pressure sensitive tape. This seal must be air tight.
- b. Connect a source of pressure, (Figure 16-2 shows one method of obtaining positive pressure) to the tee fitting in the pitot line located in the wing leading edge inboard of the wing strut.
- c. Apply pressure until the airspeed indicator registers in the cruise range.

CAUTION

Do not exceed airspeed limits as damage could occur to the airspeed indicator.

- d. Close pressure source to maintain a closed system.
- e. After a few minutes recheck airspeed indicator for pressure loss.
- f. If a loss in pressure has occurred, check all connections for tightness and recheck system.
- g. After system check is complete, remove pressure source, reinstall cap on tee fitting and remove tape from pitot openings.

16-14. BLOWING OUT LINES. Although the pitot system is designed to drain down to the pitot tube opening, condensation may collect at other points in the system and produce a partial obstruction. To clear the line, disconnect it at the airspeed indicator.

CAUTION

Never blow through pitot or static lines toward instruments. Insure that (avionics) altitude sensor line is disconnected from static lines before blowing out lines, otherwise damage to the sensor may occur.

MODEL P210 SERIES SERVICE MANUAL




Figure 16-3. Static System Test Equipment

MODEL P210 SERIES SERVICE MANUAL

Using low pressure air, blow from the indicator end of line toward the pitot tube. Like the pitot lines, static pressure lines must be kept clear and connections tight. Static source sumps collect moisture and keeps system clear. However, when necessary, disconnect static line at first instrument to which it is connected, then blow the line clear with low pressure air. Open the alternate static source valve and blow line clear. Check all static pressure line connections for tightness. If hose or hose connections are used, check them for general condition and clamps for security. Replace hose which have cracked, hardened or show other signs of deterioration.

16-15. REMOVAL AND INSTALLATION OF COMPONENTS. (See figure 16-2). To remove the pitot mast, remove the four mounting screws on the side of connector (14) and pull mast out of connector far enough to disconnect pitot line (9). Electrical

connections to the heater assembly (if installed) may be disconnected through the wing access opening just inboard of mast. Pitot and static lines are removed in the usual manner, after removing wing access plates, lower wing fairing strip and upholstery as required. Installation of tubing will be simpler if a guide wire is drawn in as tubing is removed from wing and door post. Disconnect fittings at wing root and remove wing tubing through lower wing fairing opening and draw body portion down through door post.

When replacing components to pitot and static pressure systems, tighten connections firmly, but avoid over-tightening and distorting fittings. If twisting of plastic tubing is encountered when tightening fittings, VV-P-236 (UPS Petrolatum), may be applied sparingly between tubing and fittings.

16-16. TROUBLE SHOOTING--PITOT-STATIC SYSTEM.

TROUBLE	PROBABLE CAUSE	REMEDY
LOW OR SLUGGISH AIRSPEED INDICATION. Normal altimeter and vertical speed.	Pitot tube deformed, leak or obstruction in pitot line.	Straighten tube, repair or replace damaged line.
INCORRECT OR SLUGGISH RESPONSE. All three instruments.	Leaks or obstruction in static line.	Repair or replace line.
	Alternate static source valve open.	Close for normal operation.

16-17. TRUE AIRSPEED INDICATOR. A true airspeed indicator may be installed. This indicator, equipped with a conversion ring, may be rotated until pressure altitude is aligned with outside air temperature, then airspeed indicated on the instrument is read as true airspeed on the adjustable ring. Refer to figure 16-2 for removal and installation. Upon in-

stallation, before tightening mounting screws (16), calibrate the instrument as follows: Rotate ring (18) until 120 knots on adjustable ring aligns with 120 knots on indicator. Holding this setting, move retainer (17) until 15°C aligns with zero pressure altitude, then tighten mounting screws (16) and replace decorative cover (15).

16-18. TROUBLE SHOOTING.

NOTE

Refer to paragraph 16-14 before blowing out pitot or static lines.

TROUBLE	PROBABLE CAUSE	REMEDY
HAND FAILS TO RESPOND.	Pitot pressure connection not properly connected to pressure line from pitot tube.	Repair or replace damaged line, tighten connections.
	Pitot or static lines clogged.	Blow out lines.

MODEL P210 SERIES SERVICE MANUAL

16-18. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
INCORRECT INDICATION OR HAND OSCILLATES.	Leak in pitot or static lines.	Repair or replace damaged lines, tighten connections.
	Defective mechanism.	Replace instrument.
	Leaking diaphragm.	Replace instrument.
	Alternate static source valve open.	Close for normal operation.
HAND VIBRATES.	Excessive vibration caused by loose mounting screws.	Tighten mounting screws.
	Excessive tubing vibration.	Tighten clamps and connections, replace tubing with flexible hose.

16-19. TROUBLE SHOOTING -- ALTIMETER.

NOTE

Refer to paragraph 16-14 before blowing out pitot or static lines.

TROUBLE	PROBABLE CAUSE	REMEDY
INSTRUMENT FAILS TO OPERATE.	Static line plugged.	Blow out lines.
	Defective mechanism.	Replace instrument.
INCORRECT INDICATION.	Hands not carefully set.	Reset hands with knob.
	Leaking diaphragm.	Replace instrument.
	Pointers out of calibration.	Replace instrument.
HAND OSCILLATES.	Static pressure irregular.	Blow out lines, tighten connections.
	Leak in airspeed or vertical speed indicator installations.	Blow out lines, tighten connections.

MODEL P210 SERIES SERVICE MANUAL

16-20. TROUBLE SHOOTING--VERTICAL SPEED INDICATOR.

NOTE

Refer to paragraph 16-14 before blowing out pitot or static lines.

TROUBLE	PROBABLE CAUSE	REMEDY
INSTRUMENT FAILS TO OPERATE.	Static line plugged.	Blow out lines.
	Static line broken.	Repair or replace damaged line, tighten connections.
INCORRECT INDICATION.	Partially plugged static line.	Blow out lines.
	Ruptured diaphragm.	Replace instrument.
	Pointer off zero.	Reset pointer to zero.
POINTER OSCILLATES.	Partially plugged static line.	Blow out lines.
	Leak in static line.	Repair or replace damaged lines, tighten connections.
	Leak in instrument case.	Replace instrument.

16-21. TROUBLE SHOOTING--PITOT TUBE HEATER.

NOTE

Refer to paragraph 16-14 before blowing out pitot or static lines.

TROUBLE	PROBABLE CAUSE	REMEDY
TUBE DOES NOT HEAT OR CLEAR ICE.	Switch turned "OFF."	Turn switch "ON."
	Popped circuit breaker.	Reset breaker.
	Break in wiring.	Repair wiring.
	Heating element burned out.	Replace element.

16-22. VACUUM SYSTEM. (See figure 16-4.)

16-23. DESCRIPTION. A dry vacuum system is installed on the aircraft. The system utilizes a sealed bearing engine-driven vacuum pump. A discharge tube is connected to the pump to expell air from the pump overboard. A suction relief valve is used to control system vacuum and is connected between the pump inlet and the instruments. A central air filtering system is utilized. The reading of the suction gage indicates net difference in suction before and after air passes through a gyro. This

differential pressure will gradually decrease as the central air filter becomes dirty, causing a lower reading on the suction gage.

A dual pump system is available. The system plumbing and installation is illustrated in figure 16-4 sheets 3 of 4 and 4 of 4. With this system dual vacuum relief valves are utilized. Both are mounted at Station 3.85, and right or left buttock lines 8.35.

MODEL P210 SERIES SERVICE MANUAL





Figure 16-4. Vacuum System (Sheet 1 of 4)

MODEL P210 SERIES SERVICE MANUAL



- 6. Horizon Gyro
- 7. Directional Gyro
- 8. Vacuum Gage
- 9. Connector
- 10. Suction Line Connector
- 11. Central Filter
- 12. Mounting Bracket
- 13. Bolt

Figure 16-4. Vacuum System (Sheet 2 of 4)

MODEL P210 SERIES SERVICE MANUAL





Figure 16-4. Vacuum System (Sheet 3 of 4)

MODEL P210 SERIES SERVICE MANUAL



- 9. Manifold
- 10. Horizon Gyro
- 11. Directional Gyro
- 12. Vacuum Gage
- 13. Central Air Filter

Figure 16-4. Vacuum System (Sheet 4 of 4)

MODEL P210 SERIES SERVICE MANUAL

16-24. TROUBLE SHOOTING -- VACUUM SYSTEM.

TROUBLE	PROBABLE CAUSE	REMEDY
HIGH SUCTION GAGE READINGS. (Gyros function normally.)	Relief valve screen clogged, relief valve malfunction.	Clean screen, reset valve. Replace gage.
LOW SUCTION GAGE READINGS.	Leaks or restriction between instruments and relief valve, relief valve out of adjustment, defective pump.	Repair or replace lines, adjust or replace relief valve, repair or re- place pump.
	Central air filter dirty.	Replace filter.
SUCTION GAGE FLUCTUATES.	Defective gage or sticking relief valve.	Replace gage. Clean sticking valve with Stoddard solvent. Blow dry and test. If valve sticks after cleaning, replace it.

16-25. TROUBLE SHOOTING -- GYROS.

TROUBLE	PROBABLE CAUSE	REMEDY
HORIZON BAR FAILS TO RE- SPOND.	Central air filter dirty.	Replace filter.
	Suction relief valve im- properly adjusted.	Adjust or replace relief valve.
	Faulty suction gage.	Replace suction gage.
	Vacuum pump failure.	Replace pump.
	Vacuum line kinked or leaking.	Repair or replace damaged lines, tighten connections.
HORIZON BAR DOES NOT SETTLE.	Defective mechanism.	Replace instrument.
	Insufficient vacuum.	Adjust or replace relief valve.
	Excessive vibration.	Check that gyro mounting screws are secure.
HORIZON BAR OSCILLATES OR VIBRATES EXCESSIVELY.	Central air filter dirty.	Replace filter.
	Suction relief valve im- properly adjusted.	Adjust or replace relief valve.
	Faulty suction gage.	Replace suction gage.
	Defective mechanism.	Replace instrument.
	Excessive vibration.	Check that gyro mounting screws are secure.

MODEL P210 SERIES SERVICE MANUAL

16-25. TROUBLE SHOOTING GYRO'S (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
EXCESSIVE DRIFT IN EITHER DIRECTION.	Central air filter dirty.	Replace filter.
	Low vacuum, relief valve improperly adjusted.	Adjust or replace relief valve.
	Faulty suction gage.	Replace suction gage.
	Vacuum pump failure.	Replace pump.
	Vacuum line kinked or leaking.	Repair or replace damaged lines, tighten connections.
DIAL SPINS IN ONE DIRECTION CONTINUOUSLY.	Operating limits have been exceeded.	Replace instrument.
	Defective mechanism.	Replace instrument.

16-26. TROUBLE SHOOTING -- VACUUM PUMP

TROUBLE	PROBABLE CAUSE	REMEDY
OIL IN DISCHARGE.	Damaged pump drive seal.	Replace gasket.
HIGH SUCTION.	Suction relief valve screen clogged.	Clean or replace screen.
LOW SUCTION.	Relief valve leaking.	Replace relief valve.
	Vacuum pump failure.	Replace vacuum pump.

16-27. MAINTENANCE PRACTICES.

NOTE

When replacing a vacuum system component, ensure all connections are made correctly to avoid damage to gyro system. When a component is removed, cap off and identify all open lines, hoses, and fittings to prevent dirt from entering system, and to ensure proper reinstallation. Upon component replacement, check all hoses carefully to be sure they are clean and free of debris, oil, solvent, collapsed inner liners, and external damage. Replace old, hard, cracked, or brittle hoses, particularly on pump inlet, to avoid possible pump damage. On vacuum pump, where hose clearance is tight, making it difficult to re-install hoses, apply a light film of petrolatum to the fitting. Install hoses by pushing them straight on, and do not wiggle hoses from side to side as this could cause particles to be cut from inside of hose, allowing particles to enter system.

CAUTION

Do not use teflon tape, pipe dope, or thread lubricants of any type on fitting threads, and avoid over-tightening of connections. All filters in the vacuum system must be replaced when installing a new pump. Failure to do so will void pump warranty. **DO NOT CONNECT A PUMP BACKWARDS.** Since the manifold check valves provide no pressure relief, the pump will be destroyed within a matter of seconds after starting the engine.

16-28. REMOVAL OF VACUUM PUMP.

- Remove upper engine cowling in accordance with procedures in Section 12.
- Disconnect, cap off and identify hose on inlet side of vacuum pump.
- Identify and disconnect hose on outlet side of vacuum pump.
- Remove nuts, lockwashers, and flat washers securing vacuum pump to engine.

MODEL P210 SERIES SERVICE MANUAL

- e. Remove vacuum pump from mounting studs on engine.
- f. Remove elbow from pump and retain if it is reusable.

NOTE

Discard any twisted fittings or nuts with rounded corners.

16-29. INSTALLATION OF VACUUM PUMP.

- a. Before installing a new vacuum pump, purge all of the lines in the system to remove carbon particles or other pump components that may have been deposited in the lines by the previous pump.

CAUTION

The pump housing should never be placed directly in a vise, since clamping across the center housing will cause an internal failure of the carbon rotor. Protect pump mounting flange with soft metal or wood. NEVER install a vacuum pump that has been dropped.

- b. Consult the applicable Parts Catalog, the pump vendor's application list, or the PMA label on the pump box to verify that the pump is the correct model for the engine and/or system.
- c. Position the vacuum pump in a jaw-protected vise, with drive coupling downward.

NOTE

Do not use teflon tape, pipe dope, or thread lubricants of any type, and avoid over-tightening of connections.

- d. Install elbow in pump; hand-tighten only.

NOTE

Use only a box wrench to tighten fittings to desired position. Do not make more than one and one half (1-1/2) turns beyond hand-tighten position.

NOTE

Before installing vacuum pump on engine, ensure that mating surfaces are clean and free of any old gasket material.

- e. Position new mounting pad gasket on mounting studs on engine.
- f. Position vacuum pump on mounting studs.
- g. Secure pump to engine with flat washers, new

lockwashers, and nuts.

CAUTION

Always replace all lockwashers with new ones when installing a new vacuum pump. Tighten all four mounting nuts (4) to 50 to 70 pound-inches.

- h. Connect hose to inlet side of vacuum pump.
- i. Install upper engine cowling in accordance with procedures in Section 12.

16-30. **CLEANING.** In general, low pressure, dry compressed air should be used in cleaning vacuum system components.

CAUTION

Never apply compressed air to lines or components installed in aircraft. The excessive pressures will damage gyros. If an obstructed line is to be blown out, disconnect at both ends and blow from instrument panel out.

16-31. **VACUUM RELIEF VALVE ADJUSTMENT.** A suction gage reading of 5.3 inches Hg is desirable for the gyro instruments. However a range of 4.6 to 5.4 inches Hg is acceptable.

Single Pump Adjustment. Remove central air filter, run the engine to 2200 RPM, adjust relief valve to 5.3 ± .1 inches Hg.

Dual Pump Adjustment. Remove central air filter, run engine to 2200 RPM, adjust relief valves to lower end of green arc (4.6 inches Hg) with individual pump only on the line. Combined reading (both pumps on line) is not to exceed 5.4 inches Hg at 2200 RPM.

16-32. **LOW-VACUUM WARNING LIGHT.** A red low-vacuum warning light is installed on the instrument panel. This light is used in conjunction with the single pump system only. The light is controlled by a vacuum switch which is teed into the line between the suction gage and the directional gyro. The switch contacts are normally closed. The light may be checked by turning ON the master switch. With the engine running the light should illuminate when the vacuum drops below 3±.5 inches Hg.

CAUTION

Do not exceed maximum engine temperature.

Be sure the filter element is clean before installing. If reading drops noticeably, install a new filter element.

MODEL P210 SERIES SERVICE MANUAL

16-33. STANDBY VACUUM SYSTEM.

16-34. DESCRIPTION. An electrical standby vacuum system may be installed in the aircraft. The system provides suction necessary to operate the vacuum system, should the normal engine-driven pump fail in

flight. The standby pump is mounted on the right hand wing root rib, and is connected in parallel with the engine driven vacuum pump at the manifold check valve. Control and circuit protection for the pump is provided by a two-position, toggle-type switch/circuit breaker at the bottom of the circuit breaker panel.

16-35. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
PUMP FAILS TO RUN	Switch/circuit breaker will not stay in the ON position.	Check for short circuit in wiring. Repair or replace wiring.
	Improperly grounded pump motor.	Check that motor ground wire is connected and terminal is clean.
HIGH SUCTION	Suction relief valve clogged.	Replace filter.
LOW SUCTION	Relief valve leaking.	Replace relief valve.
	Vacuum pump failure.	Replace vacuum pump.

16-36. ADJUSTMENT. With engine not running adjust regulator to 5.3±.1 inHg vacuum.

16-37. REMOVAL AND INSTALLATION.

- Remove wing access plate and wing fairing for access to pump.
- Make sure master switch and standby vacuum switch are in the OFF position.
- Disconnect electrical leads from motor.
- Remove clamp and hose from pump. Cap hose so foreign matter can not enter the system.
- Remove bolts and washers securing pump and motor assembly to wing root rib, and remove pump and motor assembly.
- If only pump is to be removed, remove nuts and washers securing pump to motor and gear bos assembly.
- For installation position pump and motor assembly on wing root rib and install bolts and washers.
- Uncap hose and install on pump using clamp.
- Connect electrical leads.

16-38. ENGINE INDICATORS.

16-39. TACHOMETER.

16-40. DESCRIPTION. The tachometer is a mechanical indicator driven at half crankshaft speed by a flexible shaft. Most tachometer difficulties will be found in the drive-shaft. To function properly, the shaft housing must be free of kinks, dents and sharp bends. There should be no bend on a radius shorter than six inches and no bend within three inches of either terminal. If a tachometer is noisy or the pointer oscillates, check the cable housing for kinks, sharp bends and damage. Disconnect cable at tachometer and pull it out of housing. Check cable for worn spots, breaks and kinks.

NOTE

Before replacing a tachometer cable in the housing, coat the lower two thirds with AC Type ST-640 speedometer cable grease or Lubriplate No. 110. Insert the cable in housing as far as possible, then slowly rotate cable to make sure it is seated in the engine fitting. Insert cable in tachometer, making sure it is seated in drive shaft, then reconnect housing and torque to 50 pound-inches (at instrument).

MODEL P210 SERIES SERVICE MANUAL





Figure 16-5. Standby Vacuum System (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL



- 6. Cabin Skin
- 7. Hose (to Manifold)
- 8. Wing Root Rib
- 9. Motor and Gear Box Assembly
- 10. Relief Valve/Regulator
- 11. Vacuum Pump

Figure 16-5. Standby Vacuum System (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

16-41. MANIFOLD PRESSURE/FUEL FLOW INDICATOR.

16-42. DESCRIPTION. The manifold pressure and fuel flow indicators are in one instrument case, however, each instrument operates independently. The manifold pressure gage is a barometric instrument which indicates absolute pressure in the intake manifold in inches of mercury. The fuel flow indi-

cator is a pressure instrument calibrated in pounds per hour, indicating approximate pounds of fuel metered per hour to the engine. Pressure for operating the indicator is obtained through a hose from the fuel manifold valve. The fuel flow indicator is vented to atmospheric pressure on standard engine installations and to turbocharger outlet pressure on turbocharged engine installations.

16-43. TROUBLE SHOOTING - MANIFOLD PRESSURE INDICATOR.

TROUBLE	PROBABLE CAUSE	REMEDY
EXCESSIVE ERROR AT EXISTING BAROMETRIC PRESSURE.	Pointer shifted.	Replace instrument.
	Leak in vacuum bellows.	Replace instrument.
	Loose pointer.	Replace instrument.
	Leak in pressure line.	Repair or replace damaged line, tighten connections.
	Condensate or fuel in line.	Blow out line.
JERKY MOVEMENT OF POINTER.	Excessive internal friction.	Replace instrument.
	Rocket shaft screws tight.	Replace instrument.
	Link springs too tight.	Replace instrument.
	Dirty pivot bearings.	Replace instrument.
	Defective mechanism.	Replace instrument.
	Leak in pressure line.	Repair or replace damaged line, tighten connections.
SLUGGISH OPERATION OF POINTER.	Foreign matter in line.	Blow out line.
	Damping needle dirty.	Replace instrument.
	Leak in pressure line.	Repair or replace damaged line, tighten connections.
EXCESSIVE POINTER VIBRATION.	Tight rocker pivot bearings.	Replace instrument.
IMPROPER CALIBRATION.	Faulty mechanism.	Replace instrument.
NO POINTER MOVEMENT.	Faulty mechanism.	Replace instrument.
	Broken pressure line.	Repair or replace damaged line.

MODEL P210 SERIES SERVICE MANUAL

16-44. TROUBLE SHOOTING - FUEL FLOW INDICATOR.

TROUBLE	PROBABLE CAUSE	REMEDY
DOES NOT REGISTER.	Pressure line clogged.	Blow out line.
	Pressure line broken.	Repair or replace damaged line.
	Fractured bellows or damaged mechanism.	Replace instrument.
	Clogged snubber orifice.	Replace instrument.
	Pointer loose on staff.	Replace instrument.
POINTER FAILS TO RETURN TO ZERO.	Foreign matter in line.	Blow out line.
	Clogged snubber orifice.	Replace instrument.
	Damaged bellows or mechanism.	Replace instrument.
INCORRECT OR ERRATIC READING.	Damaged or dirty mechanism.	Replace instrument.
	Pointer bent, rubbing on dial or glass.	Replace instrument.
	Leak or partial obstruction in pressure or vent line.	Blow out dirty line, repair or tighten loose connections.

16-45. CYLINDER HEAD TEMPERATURE GAGE.

16-46. DESCRIPTION. The temperature sending unit regulates electrical power through the cylinder head temperature gage. The gage and sending unit require little or no maintenance other than cleaning, making sure lead is properly supported and all connections are clean, tight and properly insulated. The Rochester and Stewart Warner gages are connected the same,

but the Rochester gage does not have a calibration pot and cannot be adjusted. Refer to Table 2 on page 16-26B, when trouble shooting the cylinder head temperature gage.

NOTE

Torque used to tighten wire lead nut not to exceed 4 inch-pounds.

16-47. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
GAGE INOPERATIVE.	No current to circuit.	Repair electrical circuit.
	Defective gage or sender.	Repair or replace defective items.
GAGE FLUCTUATES RAPIDLY.	Loose or broken wire permitting alternate make and break of gage circuit.	Repair or replace defective wire.
GAGE READS TOO HIGH ON SCALE.	High voltage.	Check voltage supply.
	Gage off calibration.	Replace gage or sender. Check ground connection.

MODEL P210 SERIES SERVICE MANUAL

16-47. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
GAGE READS TOO LOW ON SCALE.	Low voltage.	Check voltage supply and "D" terminal.
	Gage off calibration.	Replace defective items.
	Defective gage or sender.	Replace defective items.
GAGE READS OFF SCALE AT HIGH END.	Defective gage or sender.	Replace defective items.
OBVIOUSLY INCORRECT READING.	Defective gage or sender.	Replace defective items.
	Incorrect calibration.	Replace defective items.
GAGE READS FULL SCALE WITH ENGINE COOL OR COLD. (P21000535 & ON)	Wire between sender and gage grounded.	Repair or replace wire as required.
	Defective gage or sender.	Replace defective items.
GAGE READS ZERO WHEN ENGINE IS HOT. (P21000535 & ON)	Wire between gage and sender is open or disconnected.	Repair or replace wire as required.
	Defective gage or sender.	Replace defective items.

16-48. OIL PRESSURE GAGE.

16-49. DESCRIPTION. The Bourdon tube-type oil pressure gage is a direct-reading instrument, operated by a pressure pickup line connected to the engine

main oil gallery. The oil pressure line from the instrument to the engine should be filled with kerosene, especially during cold weather operation, to attain an immediate oil indication.

16-50. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
GAGE DOES NOT REGISTER.	Pressure line clogged.	Clean line.
	Pressure line broken.	Repair or replace damaged line.
	Fractured Bourdon tube.	Replace instrument.
	Gage pointer loose on staff.	Replace instrument.
	Damaged gage movement.	Replace instrument.
GAGE POINTER FAILS TO RETURN TO ZERO.	Foreign matter in line.	Clean line.
	Foreign matter in Bourdon tube.	Replace instrument.
	Bourdon tube stretched.	Replace instrument.
GAGE DOES NOT REGISTER PROPERLY.	Faulty mechanism.	Replace instrument.

MODEL P210 SERIES SERVICE MANUAL

16-50. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
GAGE HAS ERRATIC OPERATION.	Worn or bent movement.	Replace instrument.
	Foreign matter in Bourdon tube.	Replace instrument.
	Dirty or corroded movement.	Replace instrument.
	Pointer bent and rubbing on dial, dial screw or glass.	Replace instrument.
	Leak in pressure line.	Repair or replace damaged line.

16-51. OIL TEMPERATURE GAGE.

16-52. DESCRIPTION. On some airplanes, the oil temperature gage is a Bourdon tube type pressure instrument connected by armored capillary tubing to a temperature bulb, capillary tube and gage are filled with fluid and sealed. Expansion and contraction of fluid in the bulb with temperature changes operates the gage. Checking capillary tube for damage and fittings for security is the only maintenance required. Since the tube's inside diameter is small, kinks, and small dents, which would be acceptable in larger tubing, may partially or completely close off the capillary, making the gage inoperative. Some airplanes are equipped with gages that are electrically actuated and are not adjustable. Refer to Table 1 on page 16-26A when trouble shooting the oil temperature gage.

16-53. REMOVAL AND INSTALLATION. (Refer to Figure 16-1.)

- Remove decorative cover.
- Remove (2) screws, nuts and spacers and remove cluster from the instrument panel.
- Remove cluster cover and remove rubber divider from between the gages.
- Remove gage by sliding off guide pins of circuit board.
- Install by reversing the steps of procedure.

16-54. FUEL QUANTITY INDICATING SYSTEM.

16-55. FUEL QUANTITY INDICATORS.

16-56. DESCRIPTION. A two gage fuel quantity indicator cluster, is located adjacent to the fuel selector control handle, on the lower pedestal. These electromagnetic type indicators, graduated in pounds/gallons, are used in conjunction with float operated variable-resistance transmitters.

16-57. REMOVAL AND INSTALLATION. (Refer to Figure 16-6.)

- Remove nut from fuel selector control handle and remove handle.

- Remove screws in cover plate and lift cover and gage cluster out of pedestal.

- Remove wiring, tag and protect.

- Remove two mounting screws and remove fuel quantity cluster from pedestal cover.

- Remove cluster cover and remove rubber divider from between gage faces.

- Remove gage by sliding off of guide pins of circuit board.

- Install by reversing the steps of procedure.

16-58. FUEL QUANTITY TRANSMITTERS.

16-59. DESCRIPTION. A float operated variable-resistance transmitter is located in each fuel tank. The full position of float produces a minimum resistance through transmitter, permitting maximum current flow through the fuel quantity indicator and maximum pointer deflection. As fuel level is lowered, resistance in transmitter is increased, producing a decreasing current flow through fuel quantity indicator and a smaller pointer deflection.

16-60. REMOVAL AND INSTALLATION.

- Remove access plates on the underside of wing forward of the flap bellcrank.

- Drain enough fuel from bay to lower fuel level below transmitter. (Observe precautions in paragraph 13-3.)

- Disconnect electrical lead and ground strap from transmitter.

- Remove safety wire from transmitter attaching bolts, remove bolts and carefully remove transmitter from fuel spar, DO NOT BEND FLOAT ARM.


- To install transmitter, reverse preceding steps, using a new gasket around opening in fuel bay and new sealing washers.

NOTE

Insure that transmitter is grounded per figure 16-7.

- Service fuel bay. Check for leaks and correct fuel quantity indication.

MODEL P210 SERIES SERVICE MANUAL



1. Aisle Stand
2. Fuel Gage Cluster
3. Cover Plate
4. Fuel Control Valve Handle
5. Screw
6. Spacer
7. Washer
8. Nut
9. Decorative Button
10. Gage Circuit Board
11. Gage Mounting Pin
12. Gage Divider Support
13. Replacable Gage
14. Gage Cover

Figure 16-6. Fuel Gage Installation

MODEL P210 SERIES SERVICE MANUAL

16-61. TRANSMITTER ADJUSTMENT (Refer to page 16-26A).




Figure 16-7. Fuel Transmitter Installation.

16-62. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
FAILURE TO INDICATE.	No power to indicator or transmitter. (Pointer stays below E.)	Check fuse and inspect for open circuit. Replace fuse, repair or replace defective wire.
	Grounded wire. (Pointer stays above F.)	Check for partial ground between transmitter and gage. Repair or replace defective wire.
	Low voltage.	Check voltage at indicator. Correct voltage.
	Defective indicator.	Substitute known-good indicator. Replace indicator.
OFF CALIBRATION.	Defective indicator.	Substitute known-good indicator. Replace indicator.
	Defective transmitter.	Substitute known-good transmitter. Recalibrate or replace.
	Low or high voltage.	Check voltage at indicator. Correct voltage.
STICKY OR SLUGGISH INDICATOR OPERATION.	Defective indicator.	Substitute known-good indicator. Replace indicator.
	Low voltage.	Check voltage at indicator. Correct voltage.

MODEL P210 SERIES SERVICE MANUAL

16-61. TRANSMITTER ADJUSTMENT.

WARNING

Using the following fuel transmitter calibration procedure on components other than the originally installed (Stewart Warner) components will result in a faulty fuel quantity reading.

16-61A. STEWART WARNER GAGE TRANSMITTER CALIBRATION. Chances of transmitter calibration changing in normal service is remote; however, it is possible that float arm or float arm stops may become bent if transmitter is removed from cell. Transmitter calibration is obtained by adjusting float travel. Float travel is limited by float arm stops.

WARNING

Use extreme caution while working with electrical components of the fuel system. The possibility of electrical sparks around an "empty" fuel cell creates a hazardous situation.

Before installing transmitter, attach electrical wires and place master switch in "ON" position. Allow float arm to rest against lower float arm stop and read indicator. The pointer should be on E (empty) position. Adjust the float arm against lower stop so pointer indicator is on E. Raise float until arm is against upper stop and adjust upper stop to permit indicator pointer to be on F (full). Install transmitter in accordance with paragraph 16-60.

16-61B. ROCHESTER GAGE TRANSMITTER. Do not attempt to adjust float arm or stop. No adjustment is allowed.

Table 1

NOTE

Select the oil temperature sending unit part number that is used in your aircraft from the left column and the temperature from the column headings. Read the ohms value under the appropriate temperature column.

Part Number	Type	72°F	120°F	165°F	220°F	250°F
S1630-1	Oil Temp				46.4	
S1630-3	Oil Temp		620.0			52.4
S1630-4	Oil Temp		620.0			52.4
S1630-5	Oil Temp			192.0		
S2335-1	Oil Temp	990.0				34.0

MODEL P210 SERIES SERVICE MANUAL

Table 2

NOTE

Select the cylinder head temperature sending unit part number that is used in your aircraft from the left column and the temperature from the column headings. Read the ohms value under the appropriate temperature column.

Part Number	Type	200°F	220°F	450°F	475°F
S1372-1	CHT		310.0	34.8	
S1372-2	CHT		310.0	34.8	
S1372-3	CHT			113.0	
S1372-4	CHT			113.0	
S2334-3	CHT	745.0			38.0
S2334-4	CHT	745.0			38.0

MODEL P210 SERIES SERVICE MANUAL

16-61C. FUEL QUANTITY INDICATING SYSTEM OPERATIONAL TEST.

WARNING: REMOVE ALL IGNITION SOURCES FROM THE AIRPLANE AND VAPOR HAZARD AREA. SOME TYPICAL EXAMPLES OF IGNITION SOURCES ARE STATIC ELECTRICITY, ELECTRICAL POWERED EQUIPMENT (TOOLS OR ELECTRONIC TEST EQUIPMENT - BOTH INSTALLED ON THE AIRPLANE AND GROUND SUPPORT EQUIPMENT), SMOKING AND SPARKS FROM METAL TOOLS.

WARNING: OBSERVE ALL STANDARD FUEL SYSTEM FIRE AND SAFETY PRACTICES.

1. Disconnect all electrical power from the airplane. Attach maintenance warning tags to the battery connector and external power receptacle stating:

DO NOT CONNECT ELECTRICAL POWER, MAINTENANCE IN PROGRESS.

2. Electrically ground the airplane.
3. Level the airplane and drain all fuel from wing fuel tanks. Refer to Section 2, Ground Handling, Servicing, Cleaning, Lubrication, And Inspection as required.
4. Gain access to each fuel transmitter float arm and actuate the arm through the transmitter's full range of travel.
 - A. Ensure the transmitter float arm moves freely and consistently through this range of travel. Replace any transmitter that does not move freely or consistently.

WARNING: USE EXTREME CAUTION WHILE WORKING WITH ELECTRICAL COMPONENTS OF THE FUEL SYSTEM. THE POSSIBILITY OF ELECTRICAL SPARKS AROUND AN "EMPTY" FUEL CELL CREATES A HAZARDOUS SITUATION.

- B. While the transmitter float arm is being actuated, apply airplane battery electrical power as required to ensure that the fuel quantity indicator follows the movement of the transmitter float arm. If this does not occur, troubleshoot, repair and/or replace components as required until the results are achieved as stated.

NOTE: Rochester fuel quantity indicating system components are not adjustable, only component replacement or standard electrical wiring system maintenance practices are permitted.

5. With the fuel selector valve in the "OFF" position, add unusable fuel quantity to each fuel tank.
6. Apply electrical power as required to verify the fuel quantity indicator indicates "EMPTY".
 - A. If "EMPTY" is not indicated, adjust, troubleshoot, repair and/or replace fuel indicating components as required until the "EMPTY" indication is achieved.

NOTE: Rochester fuel quantity indicating system components are not adjustable, only component replacement or standard electrical wiring system maintenance practices are permitted.

7. Fill tanks to capacity, apply electrical power as required and verify fuel quantity indicator indicates "FULL".
 - A. If "FULL" is not indicated, adjust, troubleshoot, repair and/or replace fuel indicating components as required until the "FULL" indication is achieved.

NOTE: Rochester fuel quantity indicating system components are not adjustable, only component replacement or standard electrical wiring system maintenance practices are permitted.
8. Install any items and/or equipment removed to accomplish the Fuel Quantity Indicating System Operational Test, remove maintenance warning tags and connect the airplane battery.

MODEL P210 SERIES SERVICE MANUAL

16-62. TROUBLE SHOOTING (CONT).

TROUBLE	PROBABLE CAUSE	REMEDY
ERRATIC READINGS.	Loose or broken wiring on indicator or transmitter.	Inspect circuit wiring. Repair or replace defective wire.
	Defective indicator or transmitter.	Substitute known-good component. Replace indicator or transmitter.
	Defective master switch.	Replace switch.

16-63. HOURMETER.

NOTE

16-64. DESCRIPTION. The hourmeter is an electrically operated instrument, actuated by a pressure switch in the oil pressure gage line. Electrical power is supplied through a one-amp fuse from the electrical clock circuit, and therefore will operate independent of the master switch. A diode incorporated into the meter prevents interruption of avionics operation. This type hourmeter is identified by a white + above the positive terminal.

When installing the hourmeter, the positive (red) wire must be connected to the white + terminal. Connecting wires incorrectly will damage the meter.




Figure 16-8. Magnetic Compass

MODEL P210 SERIES SERVICE MANUAL

16-70. MAGNETIC COMPASS. (See figure 16-8.)

16-71. DESCRIPTION. The magnetic compass is liquid-filled, with expansion provisions to compensate for temperature changes. It is equipped with compensating magnets adjustable from the front of the case. The compass is internally lighted, controlled by the instrument lights rheostat switch. No maintenance is required on the compass except an occasional check on a compass rose and replacement of the lamp. Access to the compass lamp and the compensating magnets is provided by removing the compass case cover bezel.

16-72. STALL WARNING HORN AND TRANSMITTER.

16-73. DESCRIPTION. The stall warning horn is contained in the dual warning unit mounted on the right hand wing root rib. It is electrically operated and controlled by a stall warning transmitter mounted on the leading edge of the left wing. For further information on the warning horn and transmitter, refer to Section 17.

16-74. TURN COORDINATOR.

16-75. DESCRIPTION. The turn coordinator is an electrically operated, gyroscopic, roll-turn rate indicator. Its gyro simultaneously senses rate of motion roll and yaw axis which is projected on a single indicator. The gyro is a non-tumbling type requiring no caging mechanism and incorporates an ac brushless spin motor with a solid state inverter.

16-76. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
INDICATOR DOES NOT RETURN TO CENTER.	Friction caused by contamination in the indicator dampening.	Replace instrument.
	Friction in gimbal assembly.	Replace instrument.
DOES NOT INDICATE A STANDARD RATE TURN (TOO SLOW).	Low voltage.	Correct voltage.
	Inverter frequency changed.	Replace instrument.
NOISY MOTOR.	Faulty bearings.	Replace instrument.

MODEL P210 SERIES SERVICE MANUAL

16-76. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
ROTOR DOES NOT START.	Faulty electrical connection.	Correct voltage or replace faulty wire.
	Inverter malfunctioning.	Replace instrument.
	Motor shorted.	Replace instrument.
	Bearings frozen.	Replace instrument.
IN COLD TEMPERATURES, HAND FAILS TO RESPOND OR IS SLUGGISH.	Oil in indicator becomes too thick.	Replace instrument.
	Insufficient bearing end play.	Replace instrument.
	Low voltage.	Correct voltage.

16-77. TURN-AND-SLIP INDICATOR.

operates ONLY when the master switch is on. Its circuit is protected by an automatically-resetting circuit breaker.

16-78. DESCRIPTION. The turn-and-slip indicator is operated by the aircraft electrical system and

16-79. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
INDICATOR POINTER FAILS TO RESPOND.	Automatic resetting circuit breaker defective.	Replace circuit breaker.
	Master switch "OFF" or switch defective.	Replace defective switch.
	Broken or grounded lead to indicator.	Repair or replace defective wiring.
	Indicator not grounded.	Repair or replace defective wire.
	Defective mechanism.	Replace instrument.
HAND SLUGGISH IN RETURNING TO ZERO.	Defective mechanism.	Replace instrument.
	Low voltage.	Correct voltage.
POINTER DOES NOT INDICATE PROPER TURN.	Defective mechanism.	Replace instrument.
HAND DOES NOT SIT ON ZERO.	Gimbal and rotor out of balance.	Replace instrument.
	Hand incorrectly sits on rod.	Replace instrument.
	Sensitivity spring adjustment pulls hand off zero.	Replace instrument.

MODEL P210 SERIES SERVICE MANUAL

16-79. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
IN COLD TEMPERATURES, HAND FAILS TO RESPOND OR IS SLUGGISH.	Oil in indicator becomes too thick.	Replace instrument.
	Insufficient bearing end play.	Replace instrument.
	Low voltage.	Correct voltage.
NOISY GYRO.	High voltage.	Correct voltage.
	Loose or defective rotor bearings.	Replace instrument.

16-80. CABIN PRESSURIZATION INSTRUMENTS.

16-81. CABIN ALTITUDE RATE OF CHANGE.

16-82. DESCRIPTION. The cabin altitude rate of change instrument is mounted in the lower left side

16-83. TROUBLE SHOOTING.

of the instrument panel. The instrument tells the rate in feet per minute at which the cabin altitude is changing. It is calibrated in 100 fpm increment to 1000 feet and 1000 fpm increments from 1000 feet to 6000 feet. The instrument is vented to cabin pressure at the back of the instrument.

TROUBLE	PROBABLE CAUSE	REMEDY
POINTER FAILS TO RESPOND.	Defective instrument.	Replace instrument.
	Hole in vent plug obstructed.	Remove plug and clean out obstruction.

16-84. CABIN ALTITUDE AND DIFFERENTIAL PRESSURE INSTRUMENT.

16-85. DESCRIPTION. The cabin altitude and differential pressure instrument is mounted on the lower left side of the pilot's instrument panel. Instrument is

vented to cabin pressure and to static pressure through plastic tubing connected to the static line. It is a dual purpose instrument which indicates cabin altitude to 35,000 feet and differential cabin pressure in psi between cabin and atmosphere. The differential pressure has a red line at 3.35 psi.

16-86. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
ERRONEOUS INDICATIONS.	Defective instrument.	Replace instrument.
	Hole in vent plug obstructed.	Remove plug and clean out obstruction.
	Static line obstructed.	Blow out line.

MODEL P210 SERIES SERVICE MANUAL

16-87. ELECTRIC CLOCK.

16-88. DESCRIPTION. The electric clock is connected to the battery through a one-ampere fuse mounted adjacent to the battery box. The electrical circuit is separate from the aircraft electrical system and will operate when the master switch is "OFF!"

16-89. OUTSIDE AIR TEMPERATURE GAGE. MECHANICAL.

16-90. DESCRIPTION. The aircraft is equipped with a mechanical outside air temperature gage. The gage is mounted through the right windshield at upper out-board corner. Refer to figure 16-8 for removal and installation information.




Figure 16-9. Outside Air Temperature Gage

16-91. TURBINE INLET TEMPERATURE GAGE.

16-92. DESCRIPTION. The standard turbine inlet temperature gage indicates exhaust gas temperature at the turbocharger inlet. This is accomplished by means of a thermocouple installed in the exhaust stack crossover tube. The gage is supplied electrical power from the CABIN LTS circuit breaker.

If the gage fails to indicate the fault will be either the thermocouple, wiring, gage or CABIN LTS circuit breaker. The gage must have electrical power to function.

16-93. REMOVAL AND INSTALLATION. Removal of the gage is accomplished by removing the decorative cover and the four screws that secure the gage to the panel. Carefully remove the gage from the panel, tag and remove the leads. Installation is a reversal of the preceding procedure.

16-94. TURBINE INLET/SIX-POSITION EXHAUST GAS TEMPERATURE INDICATOR.

16-95. DESCRIPTION. A combination turbine inlet temperature (TIT)/ six-position exhaust gas temperature (EGT) indicator. The system is supplied electrical power from the CABIN LTS circuit breaker. The system consists of a panel-mounted dual indicator incorporating a selector switch, thermocouple probes (one for each cylinder and one at the turbine inlet) and a wiring harness connecting the probes to the indicator

The exhaust gas temperature (EGT) portion of the system is indicated by the left scale of the indicator and is graduated in 25°F increments. Individual cylinder exhaust gas temperatures are selectable according to selector switch position number as aligned with the white index dot on the indicator face. Each selector switch number corresponds to an engine cylinder number. The EGT needle adjustment potentiometer is located on the face of the instrument below the TIT scale.

MODEL P210 SERIES SERVICE MANUAL




Figure 16-10. Turbine Inlet/Six-Position Exhaust Gas Temperature Indicator

The turbine inlet temperature (TIT) portion of the system (right scale of the indicator) indicates the absolute temperature in degrees F of the exhaust gases entering the turbine. This temperature indication is not affected by EGT selector switch position.

If either or both segments fail to indicate the fault will be either, The CABIN LTS circuit breaker, a thermocouple, wiring or the gage.

16-96. REMOVAL AND INSTALLATION. Removal of the indicator is accomplished by removing the decorative cover and the three screws that secure the indicator to the panel. Carefully remove the indicator from the panel, tag and remove the leads. Installation is a reversal of the preceding procedure.

16-97. FUEL COMPUTER/DIGITAL CLOCK.

16-98. DESCRIPTION. The Astro Tech FT-2 is a dual function instrument providing a complete fuel management system and a multi-purpose time keeping device in a single instrument with each function sharing a common display panel. The instrument may be used as a replacement for the digital or electric clock, and may be mounted in the same location on the instrument panel.

The fuel computer portion of the instrument displays the following selections; fuel flow as measured by an engine mounted transducer, total fuel used, current fuel remaining and time remaining based on fuel remaining at the current flow rate. Fuel quantities are displayed in pounds with a gallon display available by utilizing a push button located below and to the right of the display. When time remaining at the current flow rate reaches 45 minutes or less, the display will be blanked from one-tenth to three-tenths of a second per second in all of the selections.

The digital clock portion of the instrument displays the following selections; current time of day in either local (LCL) or Greenwich Mean Time (GMT) in hours and minutes, cumulative flight time in minutes and seconds (first hour) and hours and minutes (up to 100 hours) whenever fuel flow is greater than 25 to 30 pounds per hour (PPH) and elapsed time in minutes and seconds (first hour) and hours and minutes (up to 100 hours).

Fuel selections and time selections are made by utilizing a rotary-type selector switch common to both functions. Two pushbuttons, located below the display, are used to program the fuel computer digital clock.

16-99. FUEL COMPUTER OPERATION. The fuel computer contains five selections. They are selected by rotating the selector switch to the positions labeled ADD, FLOW, LB USD, LB REM, and TIME REM. These selections, when used in proper sequence with the programming buttons, will correctly program the computer.

The fuel quantity added during servicing of the airplane must be entered in the computer so that the LB REM position accurately represents the correct amount of usable fuel on board for each flight. The fuel quantity added is entered in the computer as follows:

To enter fill-up:

- a. Rotate the selector switch to the ADD position.
- b. Press left and right programming buttons together until display panel reads FULL.
- c. Rotate the selector switch to LB REM position to display the usable fuel quantity in pounds on board.

MODEL P210 SERIES SERVICE MANUAL

NOTE

The usable fuel quantity for each airplane is programmed into the instrument at the factory. A battery disconnect or other power interruption will not alter this quantity.

To enter less than fill-up:

- a. Rotate the selector switch to the ADD position.
- b. Press right programming button, labeled GAL, until the right digit represents the correct units of gallons of fuel added.
- c. Press left programming button, labeled RST, until the left two digits represent the correct tens and hundreds of gallons of fuel added.
- d. Rotate the selector switch to LB REM position to display the correct usable fuel quantity in pounds on board.

If an error has been made, resulting in an incorrect display of LB REM, the correct amount may be entered as follows:

- a. Leave the selector switch in the ADD position.
- b. Enter the corrected fuel quantity in gallons.
- c. Rotate the selector switch to FLOW, then press and hold the left programming button.
- d. While holding the left button pressed, slowly rotate the selector switch to the LB REM position. The set-in amount in gallons, multiplied by six, will now appear as LB REM.

When the selector switch is placed in the FLOW position, the display indicates the current fuel flow rate in pounds per hour (PPH). Press the GAL programming button to display the flow rate in gallons per hour (GPH).

Placing the selector switch in the LB USD position displays the current fuel quantity used (in pounds) since the last addition of fuel to the airplane. Press the GAL programming button to display the fuel used in gallons.

NOTE

Any entry of additional fuel to LB REM will reset the LB USD to zero.

The LB REM position displays the current total remaining fuel (in pounds) on board the airplane, based on the takeoff amount minus the fuel used as computed using fuel flow rates. Press the GAL programming button to display the remaining fuel in gallons.

NOTE

When the display is changed from pounds to gallons in the FLOW, LB USD, and LB REM positions, the gallons shown are computed on the ratio of 6 pounds per gallon and no volumetric correction for temperature change is made. Therefore maximum accuracy may be obtained by referring to the gallons functions.

The TIME REM position displays the flight time remaining in hours and minutes as computed using the current fuel flow rate and fuel remaining amounts. Since this displayed value is dependent upon flow rate, a reduction in engine power will show an increase in time remaining.

NOTE

With the selector switch in the TIME REM position, power settings of less than 25 to 30 PPH flow rate will cause the word OFF to be displayed.

If it is desired to test the display, rotate the selector switch to TIME REM position, then press the right programming button. This will cause all 8's to be shown, thereby testing each segment of each digit.

Any power interruption that might alter a memory value or activation of the reset switch will erase a line of dashes to be displayed in all selector switch positions. Pressing the right programming button will clear the dashes from the display and show the current selector switch position. All memory values will be erased and must be re-entered. However, the usable fuel quantity will not be altered, since it is permanently entered in the instrument.

NOTE

If an abnormally low voltage condition should occur, such as during a cold weather engine start or if power is interrupted during programming sequences, such as the reset sequence, it is possible for the instrument to enter a "locked up" condition in which the display will not change with selector switch selection. Should this occur, it will be necessary to clear the condition by pressing the reset switch with a pencil or similar small diameter tool. The reset switch is in a small diameter hole located between the words "EL TIME" and "FLT TIME" near the outer periphery of the instrument face. The instrument should now operate normally, but will have to be reprogrammed.

16-100. DIGITAL CLOCK OPERATION. The digital clock contains four selections. They are selected by rotating the selector switch to the positions labeled SET, EL TIME, FLT TIME, and LCL/GMT. These selections, when used in proper sequence with the programming buttons, will correctly program the digital clock.

NOTE

Some models may have an unmarked detent position between the ADD and SET positions. This position performs the same function as the SET position.

MODEL P210 SERIES SERVICE MANUAL




Figure 16-11. Fuel Computer/Digital Clock.

The digital clock may be set to the local (LCL) and Greenwich Mean Time (GMT) as follows:

- a. Rotate the selector switch to the SET position.
- b. Press the left programming button until local hours advance to the correct value.
- c. Press both programming buttons together until Greenwich Mean Time hours advance to the correct value.
- d. Press right programming button until minutes advance to correct value. This action sets and holds seconds to zero.
- e. Rotate selector switch from SET to start seconds from zero hold.

To display the local time-of-day in hours and minutes, rotate the selector switch to LCL/GMT. If a minutes and seconds display is desired, press the right programming button, labeled SEC. If Greenwich Mean Time in hours and minutes is desired, press the left programming button, labeled GMT.

NOTE

Local or Greenwich Mean Time hours may be changed without resetting the minutes and seconds.

To display accumulated flight time, rotate the selector switch to FLT TIME. After the first hour, if a minutes and seconds display is desired in place of the hours and minutes display, press the right (SEC) programming button. Flight time may be reset to zero by pressing the left (RST) programming button.

NOTE

Accumulated flight time may be zeroed only when the instrument is not counting (whenever fuel flow is less than 25-30 PPH) to prevent accidentally zeroing flight time in the air.

Elapsed time (since pressing the RST button) is displayed by rotating the selector switch to the EL TIME position. After the first hour, if a minutes and seconds display is desired in place of the hours and minutes display, press the right (SEC) programming button. Elapsed time may be reset to zero by pressing the left (RST) programming button.

MODEL P210 SERIES SERVICE MANUAL

16-101. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
FUEL COMPUTER FUNCTION INOPERATIVE	Faulty wiring from transducer to instrument. Faulty transducer	Repair or replace wiring. Replace transducer
NO DISPLAY	Faulty wiring or open fuse.	Repair or replace wiring. Replace fuse.
DISPLAY WILL NOT CHANGE WITH SELECTOR SWITCH SELECTION	Low voltage or power interruption.	Correct low voltage condition. Connect power supply. Depress reset switch to reset instrument.

16-102. FUEL FLOW TRANSDUCER. The fuel flow transducer, located in the engine fuel line, measures the fuel flow rate (in pounds or gallons) to the throttle body metering unit. Fuel flow rate is measured by a turbine within the unit, mounted tangentially to the inlet port. Liquid fuel follows a helical flow path through the turbine and exits vertically to the outlet port, thereby venting any trapped vapor bubbles. The rotating turbine emits current pulse signals to the fuel computer section of the fuel computer/digital clock where they are displayed in pounds or gallons.

16-103. FUEL FLOW TRANSDUCER INSTALLATION. (See figure 16-12). A filter should be located upstream of the inlet port to prevent dirt from entering the turbine bearings. There should be a reasonable length of straight line between the inlet port and a valve, elbow or other turbulence producing device. Since upstream turbulence affects the performance of the instrument, turbulence should be held to a minimum. Be sure to install the transducer in a horizontal position with the wire leads or tabs UP and the turbine totally immersed in fuel.

NOTE

Whenever a transducer is installed it must be calibrated. See paragraph 16-105 for calibration procedures.

16-104. TRANSDUCER REMOVAL AND REPLACEMENT (See figure 16-12.)

CAUTION

When performing any maintenance on the fuel system, the precautions in Section 13 must be observed.


- Place the fuel selector in the OFF position.
- Remove the fuse from the clock fuse holder mounted on the battery contactor bracket.
- Disconnect the electrical connector, connecting the transducer to the instrument.
- Disconnect and cap both fuel lines (1 and 7).
- Remove nuts (5), washers (4), bolts (9) and remove transducer (3).
- Reverse these steps for reinstallation.

NOTE

When replacing the inlet and outlet pipe fittings they are to be turned 3 times past hand tight or torqued to 25-30 lbs-ft whichever occurs first.

The transducer must be mounted horizontally with the electrical leads on top.


MODEL P210 SERIES SERVICE MANUAL



1. Line to Flow Divider
2. Adapter
3. Transducer
4. Washers
5. Nuts
6. Adapter
7. Line to Throttle Body
Metering Unit
8. Vertical Baffle
9. Bolts

Figure 16-12. Fuel Flow Transducer


MODEL P210 SERIES SERVICE MANUAL



● Torque to 25-30 Lbs/Ft.

TRANSDUCER

* This letter determines the specific setting of the 3 switches on the back of the fuel computer/digital clock.



FUEL COMPUTER/DIGITAL CLOCK

1. Fuel Computer/Digital Clock
2. Fuel Computer/Digital Clock Switches
3. Transducer
4. Wire Leads

* As an example, the setting shown on the fuel computer/digital clock switches (2) would be correct if the boss on top of the transducer (3) had an "F" stamped on it.

Figure 16-13. Transducer Markings and Fuel Computer/Digital Clock Switches

16-105. FUEL TRANSDUCER CALIBRATION. (See figures 16-13 and 16-14.) The fuel computer/digital clock (1) has a 3-section switch (2) located on the back of the unit under a tape cover. Remove the cover and set the switches as shown on the fuel transducer table, figure 16-14. The fuel transducer (3) may have one or two letters (stamped or raised), located on the boss adjacent to the inlet

port. If the boss contains two letters, DISREGARD the first letter. The second letter, near the mounting bolt hole, is the calibration "K" factor letter and determines the switch setting on the fuel computer/digital clock. After setting the 3 switches to the transducer marking designation, replace the tape cover.

TRANSDUCER "K" FACTOR (PULSES PER GALLON)	SWITCH #1	SWITCH #2	SWITCH #3	TRANSDUCER MARKING DESIGNATION
81,500 - 82,375	ON	ON	ON	A
82,376 - 83,250	OFF	ON	ON	B
83,251 - 84,125	ON	OFF	ON	C
84,126 - 85,000	OFF	OFF	ON	D
85,001 - 85,875	ON	ON	OFF	E
85,876 - 86,750	OFF	ON	OFF	F
86,751 - 87,625	ON	OFF	OFF	G
87,626 - 88,500	OFF	OFF	OFF	H

Figure 16-14. Fuel Transducer Table.

MODEL P210 SERIES SERVICE MANUAL

SECTION 17

ELECTRICAL SYSTEMS

	Page No.		
TABLE OF CONTENTS	Aerofiche/Manual		
ELECTRICAL SYSTEMS	3A4/17-2	Alternator Contactors and	
General	3A4/17-2	Shunts	3A20/17-18
Electrical Power Supply		Description	3A20/17-18
System	3A4/17-2	Removal/Installation	3A20/17-18
Description	3A4/17-2	Volt Ammeter	3A20/17-18
Split Bus Bar	3A4/17-2	Description	3A20/17-18
Description	3A4/17-2	Alternator Restart System	3B4/17-26
Removal/Installation	3A4/17-2	Aircraft Lighting System	3B4/17-26
Master Switch	3A4/17-2	Description	3B4/17-26
Description	3A4/17-2	Switches	3B4/17-26
Ammeter	3A4/17-2	Description	3B4/17-26
Description	3A4/17-2	Trouble Shooting	3B6/17-28
Battery Power System	3A6/17-4	Landing/Taxi Lights	3B10/17-32
Battery	3A6/17-4	Description	3B10/17-32
Description	3A6/17-4	Removal/Installation	3B10/17-32
Trouble Shooting	3A6/17-4	Navigation Lights	3B10/17-32
Removal/Installation	3A7/17-5	Description	3B10/17-32
Cleaning the Battery	3A7/17-5	Removal/Installation	3B10/17-32
Adding Electrolyte or		Anti-Collision Strobe Lights	3B10/17-32
Water to Battery	3A7/17-5	Description	3B10/17-32
Testing the Battery	3A7/17-5	Trouble Shooting	3B10/17-32
Charging the Battery	3A7/17-5	Removal/Installation	3B10/17-32
Battery Box	3A10/17-8	Vertical Tail Flood Light	3B13/17-35
Description	3A10/17-8	Description	3B13/17-35
Removal/Installation	3A10/17-8	Removal/Installation	3B13/17-35
Maintenance	3A10/17-8	Flashing Beacon Light	3B13/17-35
Battery Contactor	3A10/17-8	Description	3B13/17-35
Description	3A10/17-8	Removal/Installation	3B13/17-35
Removal/Installation	3A10/17-8	Instrument Lighting	3B13/17-35
Battery Contactor Closing		Description	3B13/17-35
Circuit	3A10/17-8	Removal/Installation	3B13/17-35
Ground Service Receptacle	3A10/17-8	Removal/Installation of	
Description	3A10/17-8	Overhead Console Instrument	
Trouble Shooting	3A12/17-10	Panel Lights	3B13/17-35
Removal/Installation	3A13/17-11	Flood Light	3B13/17-35
Alternator Power System	3A13/17-11	Description	3B13/17-35
Description	3A13/17-11	Electroluminescent Panel	
Alternator	3A13/17-11	Lighting	3B13/17-35
Description	3A13/17-11	Description	3B13/17-35
Alternator Reverse Volt-		Transistorized Light Dimming	3B13/17-35
age Damage	3A13/17-11	Description	3B13/17-35
Trouble Shooting	3A14/17-12	Removal/Installation	3B13/17-35
Removal/Installation	3A16/17-14	Pedestal Lights	3B13/17-35
Alternator Control Unit	3A20/17-18	Description	3B13/17-35
Description	3A20/17-18	Removal/Installation	3B13/17-35
Removal/Installation	3A20/17-18	Oxygen Light	3B13/17-35
Over-Voltage Sensor/		Description	3B13/17-35
Warning Light	3A20/17-18	Removal/Installation	3B13/17-35
Description	3A20/17-18	Courtesy Lights	3B13/17-35
Removal/Installation	3A20/17-18	Description	3B13/17-35
Rigging Throttle-Operated		Removal/Installation	3B19/17-41
Microswitch	3A20/17-18	Baggage Compartment Light	3B19/17-41
Auxiliary Fuel Pump		Description	3B19/17-41
Flow Rate Adjustment	3A20/17-18	Removal/Installation	3B19/17-41
Dual Alternator System	3A20/17-18	Interior Lighting	3B19/17-41
Description	3A20/17-18	Description	3B19/17-41
Alternators	3A20/17-18	Removal/Installation	3B19/17-41
Description	3A20/17-18	Control Wheel Map Light	3B19/17-41
Removal/Installation	3A20/17-18	Description	3B19/17-41
Alternator Control Units	3A20/17-18	Removal/Installation	3B19/17-41
Description	3A20/17-18	Compass Radio Dial Lighting	3B19/17-41
Removal/Installation	3A20/17-18	Description	3B19/17-41

MODEL P210 SERIES SERVICE MANUAL

Stall Warning Unit	3B19/17-41
Description	3B19/17-41
Removal/Installation	3B19/17-41
Stall Warning Switch	3B19/17-41
Description	3B19/17-41
Removal/Installation	3B23/17-45
Pitot/Stall Warning Heaters	3B23/17-45
Description	3B23/17-45
Removal/Installation	3B23/17-45
Landing Gear Indicator Lights	3B23/17-45
Description	3B23/17-45
Removal/Installation	3B23/17-45
Emergency Locator Transmitter	3B23/17-45
Description	3B23/17-45

Operation	3B23/17-45
Operational Test of Emergency Locator Transmitter	3B24/17-46
Removal/Installation of Transmitter	3C2/17-48
Removal/Installation of Antenna	3C2/17-48
Removal/Installation of Battery Pack	3C2/17-48
Trouble Shooting	3C3/17-49
Electrical Load Analysis Chart	3C4/17-50

17-1. ELECTRICAL SYSTEMS.

17-2. GENERAL. This section contains service information necessary to maintain the Aircraft Electrical Power Supply System, Battery and External Power Supply System, Alternator Power System, Aircraft Lighting System, Pitot Heater, Stall Warning, Cigar Lighter, and Electrical Load Analysis.

17-3. ELECTRICAL POWER SUPPLY SYSTEM.

17-4. DESCRIPTION. Energy for the aircraft is supplied by a 28-volt, direct-current, single wire, negative ground electrical system. A 24-volt battery supplies power for starting and furnishes a reserve in event of alternator failure. An alternator is the normal source of power during flight and maintains a battery charge controlled by an alternator control unit. An external power source receptacle may be installed to supplement the battery alternator system for starting and ground operation.

17-5. SPLIT BUS BAR.

17-6. DESCRIPTION. Electrical power is supplied through two bus bars located on the left hand cabin side forward of the cabin door. One bus bar supplies power to the electrical equipment. The other bus bar powers the electronic equipment. This bus bar is connected to the electrical bus through an avionics master switch installed on the electronics bus.

17-7. REMOVAL AND INSTALLATION. (Refer to figure 17-1.)

17-8. MASTER SWITCH.

CAUTION

Prior to turning the master switch on or off, starting the engine or applying an external power source, the avionics power switches, labeled AVN PWR, should be turned off to prevent any harmful transient voltage from damaging the avionics equipment.


17-9. DESCRIPTION. The operation of the battery and alternator systems is controlled by a master switch. On the standard installation the master switch is a split-rocker type switch labeled MASTER and is ON in the up position and off in the down position. The right half of the switch, labeled BAT,

controls electrical power to the airplane through the primary bus bar. The left half, labeled ALT, controls the alternator. Normally, both sides of the master switch should be used simultaneously; however, the BAT side of the switch could be turned on separately to check equipment while on the ground. To check or use avionics equipment or radios while on the ground, an avionics power switch must also be turned on. The ALT side of the switch, when placed in the off position, removes the alternator from the electrical system. With this switch in the off position, the entire electrical load is placed on the battery. Continued operation with the alternator switch in the off position will reduce battery power low enough to open the battery contactor, remove power from the alternator field, and prevent alternator restart. On the Optional dual alternator system, the switch is labeled MASTER, ALT ON and BAT ON with the individual alternator sections labeled 1 and 2. Additional field and output circuit breakers, a battery isolation (ISOL) circuit breaker, and a pushbutton alternator restart switch, labeled ALT RESTART PUSH ON, are located on the left sidewall circuit breaker panel. The ALT RESTART switch is used in conjunction with a drycell battery pack, located under the floor access panel below the pilot's seat, to provide alternator restart capability in the event of a failure in the airplane battery system. Additional system monitoring capability is provided by two warning lights, located below the LOW VOLT light on the upper left side of the instrument panel. The lights, labeled ALT 1 OFF and ALT 2 OFF, are the press-to-test type and contain dimming shutters for night operation. The bulbs are interchangeable with the landing gear indicator bulbs. A volt/ammeter replaces the existing ammeter on the right side of the instrument panel. A rotary type volt/amp selector switch, adjacent to the volt/ammeter, has three AMP (amperage) positions and one VOLT (voltage) position. The amperage positions are labeled ALT 1, ALT 2, and BAT, and the voltage position is labeled VOLT, and monitors bus voltage.

17-10. AMMETER.

17-11. DESCRIPTION. The ammeter is connected between the battery and the aircraft bus. The meter indicates the amount of current flowing either to or from the battery. With a low battery and the engine operating at cruise speed the ammeter will show the full alternator output when all electrical equipment is off. When the battery is fully charged and cruise

MODEL P210 SERIES SERVICE MANUAL



VIEWED FROM THE BACK OF THE CIRCUIT BREAKER PANEL (TYPICAL INSTALLATION)

Detail A

- | | |
|--|---|
| 1. Gear Lights Circuit Breaker | 18. Gear Pump Circuit Breaker |
| 2. Alternator Low Voltage Circuit Breaker | 19. Trim Circuit Breaker |
| 3. Stall & Gear Horn Circuit Breaker | 20. Isolation Circuit Breaker |
| 4. Radio & Instrument Circuit Breaker | 21. Flap Circuit Breaker |
| 5. Cabin Lights Circuit Breaker | 22. Cabin Pressure Circuit Breaker |
| 6. Instrument Flood Lights Circuit Breaker | 23. Bus Bar |
| 7. Navigation Lights Circuit Breaker | 24. Air Condition Fan Circuit Breaker |
| 8. Strobe/Flood Lights Circuit Breaker | 25. Prop Anti-Ice Circuit Breaker |
| 9. Flashing Beacon Light Circuit Breaker | 26. Windshield Anti-Ice Circuit Breaker |
| 10. Taxi Light Circuit Breaker | 27. Pitot Heat Circuit Breaker |
| 11. Landing Light Circuit Breaker | 28. Stall Heat Circuit Breaker |
| 12. Cabin Fan Circuit Breaker | 29. Fuel Pump Circuit Breaker |
| 13. Alternator 2 Regulator Circuit Breaker | 30. Engine Instrument Circuit Breaker |
| 14. Alternator 1 Regulator Circuit Breaker | 31. Turn Coordinator Circuit Breaker |
| 15. Alternator 2 Circuit Breaker | 32. Fuel Quantity Circuit Breaker |
| 16. Alternator 1 Circuit Breaker | 33. Bus Bar |
| 17. Wing De-Ice Circuit Breaker | |

Figure 17-1. Bus Bar and Circuit Breaker Installation

MODEL P210 SERIES SERVICE MANUAL

RPM is maintained with all electrical equipment off the ammeter will show a minimum charging rate. For removal and installation refer to Section 16.

17-12. BATTERY POWER SYSTEM.

17-15. TROUBLE SHOOTING.

17-13. BATTERY

17-14. DESCRIPTION. A 24-volt battery with an approximate 12.75 ampere-hour capacity on the standard battery and 15.5 ampere-hour capacity on the optional battery is utilized. The battery is mounted on the forward left side of the firewall and is equipped with non-spill type filler caps.

TROUBLE	PROBABLE CAUSE	REMEDY
BATTERY WILL NOT SUPPLY POWER TO BUS OR IS INCAPABLE OF CRANKING ENGINE	Battery discharged.	1. Measure voltage at "BAT" terminal of battery contactor with master switch and a suitable load such as a taxi light turned on. Normal battery will indicate 23 volts. If voltage is low proceed to step 2. If voltage is normal proceed to step 3.
	Battery faulty.	2. Check fluid level in cells and charge at 28 volts for approximately 30 minutes or until battery voltage rises to 28 volts. If tester indicates a good battery, the malfunction may be assumed to be a discharged battery. If tester indicates a faulty battery, replace the battery.
	Faulty contactor or wiring between contactor and master switch.	3. Measure voltage at master switch terminal (smallest) on contactor with master switch closed. Normal indication is zero volts. If voltage reads zero, proceed to step 4. If a voltage reading is obtained, check wiring between contactor and master switch. Also check master switch.
	Open coil on contactor.	4. Check continuity between "BAT" terminal and master switch terminal of contactor. Normal indication is 50-70 ohms. If ohmmeter indicates an open coil, replace contactor. If ohmmeter indicates a good coil, proceed to step 5.
	Faulty contactor contacts.	5. Check voltage on "BUS" side of contactor with master switch closed. Meter normally indicates battery voltage. If voltage is zero or intermittent, replace contactor. If voltage is normal, proceed to step 6.
	Faulty wiring between contactor and bus.	6. Inspect wiring between contactor and bus. Repair or replace wiring.

MODEL P210 SERIES SERVICE MANUAL

17-16. REMOVAL AND INSTALLATION OF THE BATTERY. (Refer to figure 17-2.)

- a. To gain access to the battery, remove the upper left half of cowling.
- b. Remove the battery box lid and disconnect the battery ground cable.

CAUTION

Always remove the ground cable first and connect it last to prevent accidentally shorting the battery to the airframe with tools.

- c. Disconnect the positive cable from the battery and remove the battery from the aircraft.
- d. To install a battery, reverse this procedure.

17-17. CLEANING THE BATTERY. For maximum efficiency, the battery and connections should be kept clean at all times.

- a. Remove the battery in accordance with preceding paragraph.
- b. Tighten battery cell filler caps to prevent the cleaning solution from entering the cells.
- c. Wipe battery cable ends, battery terminals and entire surface of the battery with a clean cloth moistened with solution of bicarbonate of soda (baking soda) and water.
- d. Rinse with clear water, wipe off excess water and allow battery to dry.
- e. Brighten up cable ends and battery terminals with emery cloth or a wire brush.
- f. Install the battery according to the preceding paragraph.
- g. Coat the battery terminals and the cable ends with petroleum jelly.

17-18. ADDING ELECTROLYTE OR WATER TO THE BATTERY. A battery being charged and discharged with use will decompose the water from the electrolyte by electrolysis. When the water is decomposed, hydrogen and oxygen gases are formed which escape into the atmosphere through the battery vent system. The acid in the solution chemically combines with the plates of the battery during discharge or is suspended in the electrolyte solution during charge. Unless the electrolyte has been spilled from a battery, acid should not be added to the solution. The water will decompose into gases and should be replaced regularly. Add distilled water as necessary to maintain the electrolyte level even with the horizontal baffle plate inside the battery. When "dry charged" batteries are put into service, fill as directed with electrolyte. However, as the electrolyte level falls below normal with use add only distilled water to maintain the proper level. The battery electrolyte contains approximately 25% sulphuric acid by volume. Any change in this volume will hamper the proper operation of the battery.

CAUTION

Do not add any type of "battery rejuvenator" to the electrolyte. When acid has been spilled from a battery, the acid balance may be adjusted by following instructions published

by the Association of American Battery Manufacturers.

17-19. TESTING THE BATTERY. The specific gravity check method of testing the battery is preferred when the condition of the battery is in a questionable state-of-charge. However, when the aircraft has been operated for a period of time with an alternator output voltage which is known to be correct, the question of battery capability may be answered more correctly with a load type tester. If testing the battery is deemed necessary, the specific gravity should be checked first and compared with the following chart.

BATTERY HYDROMETER READINGS

1.280 Specific Gravity	100% Charged
1.250 Specific Gravity	75% Charged
1.220 Specific Gravity	50% Charged
1.190 Specific Gravity	25% Charged
1.160 Specific Gravity	Practically Dead

NOTE

All readings shown are for an electrolyte temperature of 60° Fahrenheit. For higher temperatures the readings will be slightly lower. For cooler temperatures the readings will be slightly higher. Some hydrometers have a built-in temperature compensation chart and a thermometer. If this type tester is used, disregard this chart.

If the specific gravity reading indicates the battery is not fully charged the battery should be charged at approximately 10 amperes for 30 minutes or until the battery voltage rises to 28-volts.

17-20. CHARGING THE BATTERY. When the battery is to be charged, the level of electrolyte should be checked and adjusted by adding distilled water to cover the tops of the internal battery plates. The battery cables and connections should be clean. Remove the battery from the aircraft and place in a well ventilated area for charging.

WARNING

When a battery is charging, hydrogen and oxygen gases are generated. Accumulation of these gases can create a hazardous explosive condition. Always keep sparks and open flame away from the battery. Allow unrestricted ventilation of the battery area during charging.

The main points of consideration during a battery charge are excessive battery temperature and violent gassing. Under a reasonable rate of charge, 15 amperes or less, the battery temperature should not rise over 120° F, nor should gassing be so violent that acid is blown from the vents.

MODEL P210 SERIES SERVICE MANUAL




Figure 17-2. Battery and Electrical Equipment Installation (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 17-2. Battery and Electrical Equipment Installation (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

17-21. BATTERY BOX.

17-22. DESCRIPTION. The battery is completely enclosed in a box which is painted with acid proof paint. The box has a vent tube which protrudes through the bottom of the aircraft allowing battery gases and spilled electrolyte to escape. The battery box is riveted to the left forward side of the firewall.

17-23. REMOVAL AND INSTALLATION. (Refer to figure 17-2). The battery box is riveted to the firewall. The rivets must be drilled out to remove the box. When a battery box is installed and riveted into place, all rivets and scratches inside the box should be painted with acid-proof lacquer, Part No. CES1054-381, available from the Cessna Supply Division.

17-24. MAINTENANCE. The battery box should be inspected and cleaned periodically. The box and cover should be cleaned with a strong solution of bicarbonate of soda (baking soda) and water. Hard deposits may be removed with a wire brush. When all corrosive deposits have been removed from the box, flush it thoroughly with clean water.

WARNING

Do not allow acid deposits to come in contact with skin or clothing. Serious acid burns may result unless the affected area is washed immediately with soap and water. Clothing will be ruined upon contact with battery acid.

Inspect the cleaned box and cover for physical damage and for areas lacking proper acid proofing. A badly damaged or corroded box should be replaced. If the box or lid require acid proofing, paint the area with acid-proof black lacquer, Part No. CES1054-381, available from the Cessna Supply Division.

17-25. BATTERY CONTACTOR.

17-26. DESCRIPTION. The battery contactor is bolted to the firewall below the battery box. The contactor is a solenoid plunger type, which is actuated by turning the master switch on. When the master switch is off, the battery is disconnected from the electrical system. A silicon diode is used to eliminate spiking of the transistorized radio equipment. The cathode (+) terminal of the diode connects to the battery terminal of the battery contactor. The anode (-) terminal of the diode connects to the same terminal of the diode on the contactor as the master switch wire. This places the diode directly across the contactor solenoid coil so that inductive spikes originating in the coil are clipped when the master switch is opened. (Refer to figure 17-2).

17-27. REMOVAL AND INSTALLATION. (Refer to figure 17-2.)

- a. Open battery box and disconnect ground cable from negative battery terminal. Pull cable clear of battery box.
- b. Cut sta-straps and remove cover from contactor.
- c. Remove nuts and washers securing cables to the contactor.

d. Remove the bolt, washer and nut securing each side of the contactor. Then remove contactor.

e. To install, reverse this procedure using new sta-straps on the cover.

17-28. BATTERY CONTACTOR CLOSING CIRCUIT. (Refer to figure 17-3). This circuit consists of a 5-amp fuse, a resistor and a diode mounted on the ground service receptacle bracket. This serves to shunt a small charge around the battery contactor so that ground power may be used to close the contactor when the battery is too dead to energize the contactor by itself.

17-29. GROUND SERVICE RECEPTACLE.

17-30. DESCRIPTION. A ground service receptacle is installed to permit the use of external power for cold weather starting or when performing lengthy electrical maintenance. A reverse polarity protection system is utilized whereby ground power must pass through an external power contactor to be connected to the bus. A silicon junction diode is connected in series with the coil on the external power contactor so that if the ground power source is inadvertently connected with a reversed polarity, the external power contactor will not close. This feature protects the diodes in the alternator, and other semiconductor devices used in the aircraft, from possible reverse polarity damage.

NOTE

Maintenance of the electronic installations cannot be performed when using external power. Application of external power opens the relay supplying voltage to the electronics bus. For lengthy ground testing of electronic systems, connect a well regulated and filtered power supply directly to the battery side of the battery contactor. Adjust the supply for 28 volts and close the master switch.

NOTE

When using ground power to start the aircraft, close the master switch before removing the ground power plug. This will ensure closure of the battery contactor and excitation of the alternator field.

CAUTION

Failure to observe polarity when connecting an external power source directly to the battery or directly to the battery side of the battery contactor, will damage the diodes in the alternator and other semiconductor devices in the aircraft.

MODEL P210 SERIES SERVICE MANUAL




Figure 17-3. Ground Service Receptacle Installation.

MODEL P210 SERIES SERVICE MANUAL

17-31. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
GROUND POWER WILL NOT CRANK ENGINE.	Ground service connector wired incorrectly.	1. Check for voltage at all three terminals of external power contactor with ground power connected and master switch off. If voltage is present on input and coil terminals but not on the output terminal, proceed to step 4. If voltage is present on the input terminal but not on the coil terminal, proceed to step 2. If voltage is present on all three terminals, check wiring between contactor and bus.
		2. Check for voltage at small terminal of ground service receptacle. If voltage is not present, check ground service plug wiring. If voltage is present, proceed to step 3.
	Open or mis-wired diode on ground service diode board assembly.	3. Check polarity and continuity of diode on diode board at rear of ground service receptacle. If diode is open or improperly wired, replace diode board assembly.
	Faulty external power contactor.	4. - Check resistance from small (coil) terminal of external power contactor to ground (master switch off and ground power unplugged). Normal indication is 50-70 ohms. If resistance indicates an open coil, replace contactor. If resistance is normal, proceed to step 5.
	Faulty contacts in external power contactor.	5. With master switch off and ground power applied, check for voltage drop between two large terminals of external power (turn on taxi light for a load). Normal indication is zero volts. If voltage is intermittently present or present all the time, replace contactor.

MODEL P210 SERIES SERVICE MANUAL

17-32. REMOVAL AND INSTALLATION. (Refer to figure 17-3.)

- a. Open the battery box and disconnect the ground cable from the negative terminal of the battery and pull the cable free of the box.
- b. Remove the nuts, washers, ground strap, bus bar and diode board from the studs of the receptacle and remove battery cable.
- c. Remove the screws and nuts holding the receptacle, ground strap will then be free from bracket.
- d. To install a ground service receptacle, reverse this procedure.

17-33. ALTERNATOR POWER SYSTEM.

17-34. DESCRIPTION. The alternator system consists of an engine driven alternator, a voltage regulator and a circuit breaker located on the instrument panel. The system is controlled by the left hand portion of the split rocker, master switch labeled ALT. An over-voltage sensor switch and red warning light, labeled HIGH VOLTAGE are incorporated to protect

the system. The aircraft battery supplies the source of power for excitation of the alternator.

17-35. ALTERNATOR.

17-36. DESCRIPTION. The 60-ampere alternator used on the aircraft is three-phase, delta connected with integral silicon diode rectifiers. The alternator is rated at 28-volts at 60-amperes continuous output. A optional 28-volt, 95 ampere alternator may be installed.

17-37. ALTERNATOR REVERSE VOLTAGE DAMAGE. The alternator is very susceptible to reverse polarity damage due to the very low resistance of the output windings and the low resistance of the silicon diodes in the output. If a high current source, such as a battery or heavy duty ground power cart is attached to the aircraft with the polarity inadvertently reversed, the current through the alternator will flow almost without limit and the alternator will be immediately damaged.

MODEL P210 SERIES SERVICE MANUAL

17-38. TROUBLE SHOOTING THE ALTERNATOR SYSTEM.

a. ENGINE NOT RUNNING.

TROUBLE	PROBABLE CAUSE	REMEDY
<p>AMMETER INDICATES HEAVY DISCHARGE OR ALTERNATOR CIRCUIT BREAKER OPENS. (Battery Switch ON, Alternator Switch OFF, all other electrical switches OFF.)</p>	Shorted diode in alternator.	Turn off Battery Switch and remove "B" Lead from alternator. Check resistance from "B" Terminal of alternator to alternator case. Reverse leads and check again. Resistance reading may show continuity in one direction but should show an infinite reading in the other direction. If an infinite reading is not obtained in at least one direction, repair or replace alternator.
<p>ALTERNATOR REGULATOR CIRCUIT BREAKER OPENS WHEN BATTERY AND ALTERNATOR SWITCHES ARE TURNED ON.</p>	Short in alternator control unit.	Disconnect Over-Voltage sensor plug and recheck. If circuit breaker stays in replace Over-Voltage Sensor.
	Short in alternator field.	Disconnect alternator control unit plug and recheck. If circuit breaker stays in, replace alternator control unit.
		Disconnect "F" terminal wire and recheck. If circuit breaker stays in, replace alternator.
<p>b. ENGINE RUNNING.</p> <p>ALTERNATOR CIRCUIT BREAKER OPENS WHEN BATTERY AND ALTERNATOR SWITCHES ARE TURNED ON. LOW-VOLTAGE LIGHT DOES NOT COME ON.</p>	Defective circuit breaker.	Replace circuit breaker.
<p>ALTERNATOR REGULATOR CIRCUIT BREAKER OPENS WHEN BATTERY AND ALTERNATOR SWITCHES ARE TURNED ON. LOW-VOLTAGE LIGHT MAY OR MAY NOT COME ON.</p>	Shorted field in alternator.	Check resistance from "F" terminal of alternator to alternator case, if resistance is less than 5 ohms repair/replace.

CAUTION

This malfunction may cause a shorted alternator control unit, which will result in an over-voltage condition when system is again operated.

MODEL P210 SERIES SERVICE MANUAL

17-38. TROUBLE SHOOTING THE ALTERNATOR SYSTEM (Cont.)
 b. ENGINE RUNNING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ALTERNATOR MAKES ABNORMAL WHINING NOISE.	Shorted diode in alternator.	Turn off Battery Switch and remove "B" Lead from alternator. Check resistance from "B" Terminal of alternator to alternator case. Reverse leads and check again. Resistance reading may show continuity in one direction but should show in infinite reading in the other direction. If an infinite reading is not obtained in one direction, repair or replace alternator.
LOW-VOLTAGE LIGHT DOES NOT GO OUT WHEN ALTERNATOR AND BATTERY SWITCHES ARE TURNED ON.	Shorted alternator control unit.	Replace alternator control unit.
	Defective low-voltage sensor.	Replace alternator control unit.
AFTER ENGINE START WITH ALL ELECTRICAL EQUIPMENT TURNED OFF CHARGE RATE DOES NOT TAPER OFF IN 1-3 MINUTES.	Alternator control unit faulty or high resistance in field circuit.	With engine not running turn off all electrical loads and turn on battery and alternator switches. Measure bus voltage to ground, then measure voltage from terminal of alternator to ground. If there is more than 2 volts difference check field circuit wiring shown in alternator system wiring diagram in Section 19. Clean all contacts. Replace components until there is less than 2 volts difference between bus voltage and field voltage.
<p>NOTE</p> <p>Also refer to battery power system trouble shooting chart.</p>		
ALTERNATOR SYSTEM WILL NOT KEEP BATTERY CHARGED.	Alternator output voltage insufficient.	1. Connect voltmeter between D. C. Bus and ground. Turn off all electrical loads. Turn on Battery Switch, start engine and adjust for 1500 RPM. Voltage should read approximately 24 volts. Turn on alternator switch. Voltage should read between 28.4 and 28.9 volts. Ammeter should indicate a heavy charge rate which should taper off in 1-3 minutes. If charge rate tapers off very quickly and voltage is normal, check battery for malfunction. If ammeter shows a low charge rate or any discharge rate, and voltage does not rise when alternator switch is turned on proceed to Step 2.

MODEL P210 SERIES SERVICE MANUAL

17-38. TROUBLE SHOOTING THE ALTERNATOR SYSTEM (Cont.) b. ENGINE RUNNING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ALTERNATOR SYSTEM WILL NOT KEEP BATTERY CHARGED. (Cont.)	Alternator output voltage insufficient (cont.)	<p>2. Stop engine, turn off all switches. Connect voltmeter between "F" terminal of alternator and ground. Do NOT start engine. Turn on battery switch and alternator switch. Battery voltage should be present at "F" terminal, less 1 volt drop thru regulator, if not refer to Step 3.</p> <p>3. Starting at "F" terminal of alternator, trace circuit to alternator control unit at Pin 1 (Blue Wire). Trace circuit from Pin 3 (Red Wire) to master switch, to Bus Bar. Trace circuit from alternator control unit Pin 2 (Orange Wire) to alternator "BAT" terminal. Check connections and replace component which does not have voltage present at output. Refer to alternator system wiring diagram in Section 19.</p>
	Alternator field winding open.	<p>1. If voltage is present turn off alternator and battery switches. Check resistance from "F" terminal of alternator to alternator case, turning alternator shaft during measurement. Normal indication is 12-20 ohms. If resistance is high or low, repair or replace alternator. If OK refer to Step 2.</p>
	Alternator output voltage insufficient.	<p>2. Check resistance from case of alternator to airframe ground. Normal indication is very low resistance. If reading indicates no, or poor continuity, repair or replace alternator ground wiring.</p>

17-39. REMOVAL AND INSTALLATION. (Refer to figure 17-4).

- Make sure that master switch remains in the off position or disconnect negative lead from battery.
- Disconnect the wiring from the alternator.
- Remove the safety wire from the upper adjusting bolt and remove the bolt from the alternator.
- Remove the nut and washer from the lower mounting bolt.
- Remove the alternator drive belt and lower mounting bolt to remove the alternator.
- To replace alternator, reverse this procedure.
- Adjust belt tension to obtain 3/8" deflection at the center of the belt when applying 12 pounds of

pressure to the belt. After the belt is adjusted and the bolt is safety wired, tighten the bottom bolt to 100-140 lb.-in. torque on the 60 ampere alternator and 450-500 lb.-in. torque on the 95 ampere alternator to remove any play between the alternator mounting foot and the U-shaped support assembly.

CAUTION

On new aircraft or whenever a new belt is installed, belt tension should be checked within 10 to 25 hours of operation.

MODEL P210 SERIES SERVICE MANUAL





Figure 17-4. Alternator Installation (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL



● 165 ± 10 IN LBS
★ 450 - 500 IN LBS

NON-SHOCKMOUNTED
95 AMP ALTERNATOR

- 1. Arm-Adjusting
- 2. Washer
- 3. Bolt
- 4. Safety Wire
- 5. Drive Belt
- 6. Support
- 7. Nut
- 8. Alternator

Figure 17-4. Alternator Installation (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 17-5. Alternator Control Unit Installation

MODEL P210 SERIES SERVICE MANUAL

NOTE

When tightening the alternator belt, apply pry bar pressure only to the end of the alternator nearest to the belt pulley.

17-40. ALTERNATOR CONTROL UNIT.

17-41. DESCRIPTION. The alternator control unit is a solid state voltage regulator with an over-voltage sensor and a low-voltage sensor incorporated in the unit. The control unit is not adjustable and is a remove and replace item. A Cessna Alternator Charging System Test Box Assembly (P/N 9870005-1) is available through the Cessna Supply Division for use in isolating failures in the 28-volt alternator control units (C611005-0101 and C611005-0102) and the 28-volt alternator.

17-42. REMOVAL AND INSTALLATION. (Refer to figure 17-5.)

- a. Remove upper half of engine cowl.
- b. Place master switch in the "OFF" position.
- c. Disconnect negative lead from the battery.
- d. Disconnect housing plug from the alternator control unit.
- e. Remove screws securing the control unit to the firewall.
- f. To install control unit reverse the preceding steps. Be sure the connections for grounding are clean and bright before assembly. Otherwise faulty voltage regulation and/or excessive radio noise may result.

17-43. OVER-VOLTAGE SENSOR AND WARNING LIGHT.

17-44. DESCRIPTION. The over-voltage sensor is contained within the alternator control unit. The unit also contains a low-voltage sensor. A red warning light labeled "LOW VOLTAGE" is installed on the instrument panel. When an over-voltage condition occurs the over-voltage sensor turns off the alternator and the voltage in the system drops. When system voltage drops below 24.8 volts the low-voltage sensor turns on the low-voltage light indicating a drain on the battery and the ammeter will show a discharge. Turn off both sections of the master switch to recycle the over-voltage sensor. If the over-voltage condition was transient, the normal alternator charging will resume and no further action is necessary. If the over-voltage tripoff recurs, then a generating system malfunction has occurred such that the electrical accessories must be operated from the aircraft battery only. Conservation of electrical energy must be practiced until the flight can be terminated. The over-voltage light filament may be tested at any time by turning off the "Alternator" portion of the master switch and leaving the battery portion on. This test does not induce an over-voltage condition on the electrical system.

17-45. REMOVAL AND INSTALLATION. (Refer to figure 17-5 and paragraph 17-42.)

17-46. RIGGING THROTTLE-OPERATED MICRO-SWITCH. (Refer to Section 13.)

17-47. AUXILIARY FUEL PUMP FLOW RATE ADJUSTMENT. (Refer to Section 13.)

17-48. DUAL ALTERNATOR SYSTEM.

17-49. DESCRIPTION. The dual alternator system consists of two belt-driven, 28 volt, 60 amp alternators, two alternator control units, two shunt and fuse assemblies, two line contactors, two alternator switches, two circuit breakers, a volt ammeter, a three light indicating system and a alternator restart system.

17-50. ALTERNATORS.

17-51. DESCRIPTION. The alternators are belt-driven, 28 volt, 60 amp, three-phase, Delta connected stator windings with integral silicon diode rectifiers and a stator tap.

NOTE

Alternators are equal in function & capability, and normally operate under equal loads. Each may operate independently, but should not be thought of or operated as, a primary and secondary (or standby) system.

17-52. REMOVAL AND INSTALLATION. (See figure 17-5.)

17-53. ALTERNATOR CONTROL UNITS.

17-54. DESCRIPTION. The alternator control units are solid state voltage regulators with low voltage sensing internal paralleling circuitry in the alternator control units controls load sharing between the alternators.

17-55. REMOVAL AND INSTALLATION. (See figure 17-6.)

17-56. ALTERNATOR CONTACTORS AND SHUNTS.

17-57. DESCRIPTION. Each alternator is equipped with a contactor and shunt. The shunt directs power through two fuses to the alternator control unit remote sensing and current sensing circuits. The shunt is also connected through fuses to the volt-ammeter selector switch which enables the pilot to monitor the electrical system operation.

17-58. REMOVAL AND INSTALLATION. (See figure 17-6.)

17-59. VOLT-AMMETER.

17-60. DESCRIPTION. The volt-ammeter is mounted on the left side of the instrument panel. A selector switch is provided for the pilot to monitor the electrical system operation. The selector switch allows the pilot to monitor the current supplied by each alternator, the battery charge or discharge current, or the system voltage.




Figure 17-6. Dual Alternator System Installation (Sheet 1 of 7)

MODEL P210 SERIES SERVICE MANUAL





Figure 17-6. Dual Alternator System Installation (Sheet 2 of 7)

MODEL P210 SERIES SERVICE MANUAL

● TORQUE 450 - 500 IN-LBS

* TORQUE 160 - 190 IN-LBS

* TORQUE 155 - 175 IN-LBS




Detail B

- 20. Bolt
- 21. Mount
- 22. Belt
- 23. Noise Filter
- 24. Nut
- 25. Washer
- 26. Bolt
- 27. Adjustment Bracket
- 28. Nipple
- 29. Wire (Alternator Shunt)
- 30. Wire (Field)
- 31. Wire (Remote Sense)
- 32. Wire (Ground)
- 33. Bolt
- 34. Wire (Alt OFF Sense)
- 35. Resistor
- 36. Insulator
- 37. Resistor
- 38. Washer
- 39. Screw
- 40. Safety Wire

Figure 17-6. Dual Alternator System Installation (Sheet 3 of 7)

MODEL P210 SERIES SERVICE MANUAL



- 41. Cover
- 42. Wire (Circuit Breaker)
- 43. Contactor (Alternator No. 2)
- 44. Bracket
- 45. Bus Bar
- 46. Shunt (Alternator No. 2)
- 47. Shunt (Alternator No. 1)
- 48. Wire (to Alternator No. 1)
- 49. Wire (to Alternator No. 2)
- 50. Wire (Circuit Breaker)

Figure 17-6. Dual Alternator System Installation (Sheet 4 of 7)

MODEL P210 SERIES SERVICE MANUAL




Figure 17-6. Dual Alternator System Installation (Sheet 5 of 7)

MODEL P210 SERIES SERVICE MANUAL





Figure 17-6. Dual Alternator System Installation (Sheet 6 of 7)

MODEL P210 SERIES SERVICE MANUAL



Detail J

- 71. Clamp
- 72. Housing Cap
- 73. Housing Plug
- 74. Spacer
- 75. Bracket
- 76. Cover
- 77. Battery Holder
- 78. Battery Holder
- 79. Plate
- 80. Grommet

Figure 17-6. Dual Alternator System Installation (Sheet 7 of 7)

MODEL P210 SERIES SERVICE MANUAL

17-61. ALTERNATOR RESTART SYSTEM. The alternator restart system consists of a battery pack and a switch. When the restart switch, on the circuit breaker panel is actuated, power is directed from the battery pack through the restart switch to the alternator switch. With the alternator switch closed power is directed to the alternator control unit then to the alternator field for excitation of the alternator.

NOTE

Batteries should be changed at yearly intervals or sooner if function test shows need. Correct polarity must be observed when installing batteries. No. 814 Ray-O-Vac or No. MN1400 Mallory or equivalent to No. E-93 Everready Batteries are recommended.

WARNING

Do not rely on contact between battery holder (78) and plate (79) to maintain spring contact on batteries. If required, end plates of the battery holder may be reformed inward slightly to increase contact pressure on batteries. Check continuity of battery pack before installation with battery pack suspended from plate and with curvature of plate reversed as in normal installation.


17-62. AIRCRAFT LIGHTING SYSTEM.

17-63. DESCRIPTION. The aircraft lighting system consists of landing and taxi lights, navigation lights, flashing beacon light, anti-collision strobe lights, interior and instrument panel flood lights, electroluminescent panel lighting, instrument post lighting, pedestal lights, oxygen lights, courtesy lights, de-ice light, control wheel map light, baggage compartment light, compass and radio dial lights.

17-64. SWITCHES.

17-65. DESCRIPTION. The instrument panel switches used are snap-in type rocker switches. These switches have a design feature which permits them to snap into the panel from the panel side and can subsequently be removed for easy maintenance. These switches also feature spade type slip-on terminals.

MODEL P210 SERIES SERVICE MANUAL



Detail A

NOTE

Shim between bracket (3) and retainer (6) with a equal number of AN960-10L washers (5) at all six locations as required so bottom of retainer (6) is 0.00 to 0.30 aft of cover (1).

- | | |
|---------------------|--------------------|
| 1. Cover | 8. Gasket |
| 2. Screw | 9. Lamp |
| 3. Bracket | 10. Cover Assembly |
| 4. Bracket Assembly | 11. Screw |
| 5. Washer | 12. Screw |
| 6. Retainer | |
| 7. Spacer | |

Figure 17-7. Landing and Taxi Light Installation

MODEL P210 SERIES SERVICE MANUAL

17-66. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
LANDING AND TAXI LIGHTS OUT.	Short circuit in wiring.	1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	2. Test each circuit separately until short is located. Repair or replace wiring.
	Defective switch.	3. Check voltage at lights with master and landing and taxi light switches ON. Should read battery voltage. Replace switch.
LANDING OR TAXI LIGHT OUT.	Lamp burned out.	1. Test lamp with ohmmeter or new lamp. Replace lamp.
	Open circuit in wiring.	2. Test wiring for continuity. Repair or replace wiring.
FLASHING BEACON DOES NOT LIGHT.	Short circuit in wiring.	1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	2. Test circuit until short is located. Repair or replace wiring.
	Lamp burned out.	3. Test lamp with ohmmeter or a new lamp. Replace lamp. If lamp is good, proceed to step 4.
	Open circuit in wiring.	4. Test circuit from lamp to flasher for continuity. If no continuity is present, repair or replace wiring. If continuity is present, proceed to step 5.
	Defective switch.	5. Check voltage at flasher with master and beacon switch on. Should read battery voltage. Replace switch. If voltage is present, proceed to step 6.
	Defective flasher.	6. Install new flasher.
FLASHING BEACON CONSTANTLY LIT.	Defective flasher.	1. Install new flasher.

MODEL P210 SERIES SERVICE MANUAL

17-66. TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ALL NAV LIGHTS OUT.	Short circuit in wiring.	1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	2. Isolate and test each nav light circuit until short is located. Repair or replace wiring.
	Defective switch.	3. Check voltage at nav light with master and nav light switches on. Should read battery voltage. Replace switch.
ONE NAV LIGHT OUT.	Lamp burned out.	1. Inspect lamp. Replace lamp.
	Open circuit in wiring.	2. Test wiring for continuity. Repair or replace wiring.
<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">WARNING</div> <p>The anti-collision system is a high voltage device. Do not remove or touch tube assembly while in operation. Wait at least 5 minutes after turning off power before starting work.</p>		
BOTH ANTI-COLLISION STROBE LIGHTS WILL NOT LIGHT.	Open circuit breaker.	1. Check, if open reset. If circuit breaker continues to open proceed to step 2.
		2. Disconnect red wire between aircraft power supply (battery/external power) and strobe power supplies, one at a time. If circuit breaker opens on one strobe power supply, replace strobe power supply. If circuit breaker opens on both strobe power supplies proceed to step 3. If circuit breaker does not open proceed to step 4.
		3. Check aircraft wiring. Repair or replace as necessary.
		4. Inspect strobe power supply ground wire for contact with wing structure.

MODEL P210 SERIES SERVICE MANUAL

17-66. TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
<p>CAUTION</p> <p>Extreme care should be taken when exchanging flash tube. The tube is fragile and can easily be cracked in a place where it will not be obvious visually. Make sure the tube is seated properly on the base of the nav light assembly and is centered in the dome.</p> <p>NOTE</p> <p>When checking defective power supply and flash tube, units from opposite wing may be used. Be sure power leads are protected properly when unit is removed to prevent short circuit.</p>		
<p>ONE ANTI-COLLISION STROBE LIGHT WILL NOT LIGHT.</p>	<p>Defective Strobe Power Supply, or flash tube.</p>	<p>1. Connect voltmeter to red lead between aircraft power supply (battery/external power) and strobe power supply, connecting negative lead to wing structure. Check for 12/24 volts. If OK proceed to step 2. If not, check aircraft power supply (battery/external power).</p>
		<p>2. Replace flash tube with known good flash tube. If system still does not work, replace strobe power supply.</p>
<p>DOME LIGHT TROUBLE.</p>	<p>Short circuit in wiring.</p>	<p>1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.</p>
	<p>Defective wiring.</p>	<p>2. Test circuit until short is located. Repair or replace wiring.</p>
	<p>Lamp burned out.</p>	<p>3. Test for open circuit. Repair or replace wiring. If no short or open circuit is found, proceed to step 4.</p>
	<p>Defective switch.</p>	<p>4. Test lamp with ohmmeter or new lamp. Replace lamp.</p>
		<p>5. Check for voltage at dome light with master and dome light switch on. Should read battery voltage. Replace switch.</p>

MODEL P210 SERIES SERVICE MANUAL

17-66. TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ELECTROLUMINESCENT PANELS WILL NOT LIGHT.	Short circuit in wiring.	1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	2. Test circuit until short is located. Repair or replace wiring.
		3. Test for open circuit. Repair or replace wiring. If no open or short circuit is found, proceed to step 4.
	Defective resistor.	4. Check resistor for continuity. (Located in line between rheostat and invert-a-pak.) Replace resistor.
	Defective rheostat.	5. Check input voltage at invert-a-pak with master switch on. Voltmeter should give a smoothly varied reading over the entire control range of the rheostat. If no voltage is present or voltage has a sudden drop before rheostat has been turned full counterclockwise, replace rheostat.
Defective invert-a-pak.	6. Check output voltage at invert-a-pak with ac voltmeter. Should read about 125 volts ac with rheostat set for full bright. Replace invert-a-pak.	
INSTRUMENT LIGHTS WILL NOT LIGHT.	Short circuit wiring.	1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	2. Test circuit until short is located. Repair or replace wiring.
		3. Test for open circuit. Repair or replace wiring. If no short or open circuit is found, proceed to step 4.
	Faulty section in dimming potentiometer.	4. Lights will work when control is placed in brighter position. Replace potentiometer.
	Faulty light dimming transistor.	5. Test both transistors with new transistor. Replace faulty transistor.
Faulty selector switch.	6. Inspect. Replace switch.	

MODEL P210 SERIES SERVICE MANUAL

17-66. TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
INSTRUMENT LIGHTS WILL NOT DIM.	Open resistor or wiring in minimum intensity end of potentiometer.	1. Test for continuity. Replace resistor or repair wiring.
	Shorted transistor.	2. Test transistor by substitution. Replace defective transistor.
CONTROL WHEEL MAP LIGHT WILL NOT LIGHT.	Nav light switch turned off.	1. Nav light switch has to be ON before map light will light.
	Short circuit in wiring.	2. Check lamp fuse on terminal board located on back of stationary panel with ohmmeter. If fuse is open, proceed to step 3. If fuse is OK, proceed to step 4.
	Defective wiring.	3. Test circuit until short is located. Repair or replace wiring. 4. Test for open circuit. Repair or replace wiring. If a short or open circuit is not found, proceed to step 5.
	Defective map light assembly.	5. Check voltage at map light assembly with master and nav switches on. If battery voltage is present, replace map light assembly.

17-67. LANDING AND TAXI LIGHTS.

17-68. DESCRIPTION. The landing and taxi lights are mounted in the lower nose cap. Both lamps are used for landing and only the left hand for taxi. The lamps are controlled by two rocker switches with a diode assembly installed across the switches which enables the landing light switch to turn on both the landing and taxi lamps. The taxi light switch will turn on only the taxi lamp.

17-69. REMOVAL AND INSTALLATION. (Refer to figure 17-7.)

1. Remove screws (12) and remove cover (1).
2. Remove screws (2) and note position of washers (5) and or spacers (7) for installation.
3. Remove screws (11) then remove retainer (6) and gasket (8).
4. Pull lamp (9) from cover (10) and disconnect electrical leads.
5. Install new lamp and reassemble making sure washers (5) and or spacers (7) are in the proper position.

17-70. NAVIGATION LIGHTS.

17-71. DESCRIPTION. The navigation lights are located on each wing tip and the stinger. Operation of the lights is controlled by a single two position switch. A plastic light detector on each wing tip

allows the pilot to determine if the lamps are working properly during flight.

17-72. REMOVAL AND INSTALLATION. Refer to figure 17-8 for removal and installation of navigation light components.

17-73. ANTI-COLLISION STROBE LIGHTS.

17-74. DESCRIPTION. A white strobe light may be installed on each wing tip with the navigation light. These lights are vibration resistant and operate on the principle of a capacitor discharge into a xenon tube, producing an extremely high intensity flash. Each strobe light has its own power supply mounted on the wing tip ribs.

17-75. TROUBLE SHOOTING. Refer to paragraph 17-66 for trouble shooting of the anti-collision strobe lights.

17-76. REMOVAL AND INSTALLATION. Refer to figure 17-8 for removal and installation of strobe light components.

- a. Remove wing tip disconnecting navigation and strobe light wires.
- b. Disconnect power supply wires.
- c. Remove the four mounting screws and remove power supply.
- d. To reinstall reverse the preceding steps.

MODEL P210 SERIES SERVICE MANUAL





Figure 17-8. Navigation, Flood and Anti-Collision Strobe Lights Installation (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL



- 1. R. H. Light Assembly
- 2. L. H. Light Assembly
- 3. Switch & Circuit Breaker
- 4. Lens
- 5. Connector
- 6. Ground Wire
- 7. Clamp
- 8. Doubler
- 9. Gasket

Figure 17-8. Navigation, Flood and Anti-Collision Strobe Lights Installation (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

17-77. VERTICAL TAIL FLOOD LIGHTS.

17-78. DESCRIPTION. A flood light assembly is mounted on each end of the stabilizer, on the upper side. These lights are used to illuminate the vertical tail. A switch on the switch panel controls the lights and a circuit breaker on the breaker panel protects the circuit.

17-79. REMOVAL AND INSTALLATION. Refer to figure 17-8, for removal and installation.

17-80. FLASHING BEACON.

17-81. DESCRIPTION. The flashing beacon light is attached to the vertical fin tip. The flashing beacon has an iodine-vapor lamp electrically switched by a solid-state flasher assembly. The flasher assembly is mounted inside the fin tip. The switching frequency of the flasher assembly operates at approximately 45 flashes per minute. A resistor is installed and connected to the unused flasher lead to eliminate a pulsing effect on the cabin lighting and ammeter.

17-82. REMOVAL AND INSTALLATION. Refer to figure 17-9 for removal and installation of flashing beacon components.

17-83. INSTRUMENT LIGHTING.

17-84. DESCRIPTION. The instrument panel lighting consists of two separate sections. The lower two-thirds of the panel is illuminated by two lights mounted in the overhead console. The lighting for the upper one-third of the panel is provided by four lights mounted in the under side of the instrument glare shield. The intensity of the lighting is controlled by the instrument light dimming rheostat located on the switch panel.

17-85. REMOVAL AND INSTALLATION. Refer to figure 17-10 for removal and installation of instrument brow lights.

17-86. REMOVAL AND INSTALLATION OF OVERHEAD CONSOLE INSTRUMENT PANEL LIGHTS. (Refer to figure 17-11.)

- a. Unscrew cabin flood light lens and remove.
- b. Loosen set screw and remove cabin flood light control knob.
- c. Unscrew two air outlets at forward end of console.
- d. Remove screws from the over-head console cover and remove cover.
- e. Twist lamp for removal from socket assembly.
- f. For installation, reverse the preceding steps.

17-87. FLOOD LIGHT.

17-88. DESCRIPTION. A cabin flood light is mounted on the over-head console. The lamp is controlled by a rheostat switch mounted adjacent to the light. For removal refer to figure 17-11.

17-89. ELECTROLUMINESCENT PANEL LIGHTING.

17-90. DESCRIPTION. The electroluminescent lighting consists of two "EL" panels; the switch panel and comfort control panel. The AC voltage required to drive the "EL" panels is supplied by a small invert-a-pack (power supply) located behind the instrument panel on the right hand side. The navigation light switch must be on to supply power to the invert-a-pack. The intensity of the "EL" panel lighting is controlled by a rheostat located on the instrument panel. The "EL" panels have an expected life of over 16,000 hours and no replacement should be necessary during the life of the aircraft.

17-91. TRANSISTORIZED LIGHT DIMMING.

17-92. DESCRIPTION. The light dimming circuit consists of a three-circuit transistorized dimming assembly. System is controlled by two controls on the lower left hand side of the panel. The right hand control is a dual rheostat with a concentric knob arrangement. A three-circuit transistorized dimming assembly is installed with post lighting. The controls go from three to four. The center portion of the left control controls the post lights, the outer portion controls flood lights, the center portion of the right hand control controls EL panel lighting and the outer portion controls engine and radio lighting.

17-93. REMOVAL AND INSTALLATION. For removal and installation of transistorized dimming, refer to figure 17-12.

17-94. PEDESTAL LIGHTS.

17-95. DESCRIPTION. The pedestal lights consist of three post type lights mounted on the pedestal to illuminate the fuel selector handle, rudder and elevator trim controls. The pedestal lights are controlled by the instrument light rheostat.

17-96. REMOVAL AND INSTALLATION. For removal and installation of pedestal lamps, slide the cap and lens assembly from the base. Slide the lamp from the socket and replace.

17-97. OXYGEN LIGHT.


17-98. DESCRIPTION. The oxygen light consists of an indicator light installed aft of the oxygen access door on the overhead console. The light will illuminate when oxygen is in use.

17-99. REMOVAL AND INSTALLATION. For removal of lamp, unscrew lens assembly and pull lamp from assembly. Insert new lamp; reinstall lens assembly.

17-100. COURTESY LIGHT.

17-101. DESCRIPTION. The lights consist of one light located on the underside of the wing to provide ground lighting around the cabin area. The courtesy light has a clear lens and is controlled by a single slide switch labeled "Utility Light," located on the left rear door post.

MODEL P210 SERIES SERVICE MANUAL



Detail A

Detail B

CAUTION

When inserting lamp into socket always use a handkerchief or a tissue to prevent getting fingerprints on the lamp.

NOTE

Fingerprints on lamp may shorten the life of the lamp.

- | | | |
|-------------------|-----------------------|-----------------------------|
| 1. Dome | 7. Mounting Plate | 13. Housing - Plug |
| 2. Gasket | 8. Socket | 14. Housing - Cap |
| 3. Lamp | 9. Tip Assembly - Fin | 15. Ground Wire |
| 4. Screw | 10. Flasher Assembly | 16. Stabilizer Skin - Upper |
| 5. Baffle | 11. Connector | 17. Resistor |
| 6. Clamp Assembly | 12. Fin Assembly | 18. Washer |

Figure 17-9. Flashing Beacon Installation (Sheet 1 of 2)

NOTE
When installing lamp be sure socket assembly is installed in mounting plate so lamp may be installed with filament perpendicular to the longitudinal axis of the aircraft.




Figure 17-9. Flashing Beacon Installation (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL





Figure 17-10. Instrument Panel Glare Shield Light Installation

MODEL P210 SERIES SERVICE MANUAL



- 1. Rheostat
- 2. Bracket
- 3. Screw
- 4. Washer
- 5. Light Assembly
- 6. Control Knob
- 7. Socket Assembly
- 8. Lamp
- 9. Tinnerman Nut
- 10. Ground Wire
- 11. Tinnerman Screw
- 12. Adjustment Knob
- 13. Overhead Console
- 14. Plate

Figure 17-11. Lighting - Overhead Console

MODEL P210 SERIES SERVICE MANUAL




Figure 17-12. Transistorized Light Dimming and Electroluminescent Inverter Installation

MODEL P210 SERIES SERVICE MANUAL




Figure 17-13. Courtesy Light Installation

17-102. REMOVAL AND INSTALLATION. Refer to figure 17-13 for removal and installation of courtesy light.

17-103. BAGGAGE COMPARTMENT LIGHT.

17-104. DESCRIPTION. The baggage compartment is illuminated by a lamp mounted in the top of the baggage compartment. The light is controlled by the "Utility Lights" switch located on the left door post.

17-105. REMOVAL AND INSTALLATION. (Refer to figure 17-15.)

- a. Ensure that the master switch is "OFF".
- b. To gain access to the baggage compartment lamp, remove the screws attaching the retainer and lens to the reflector assembly.
- c. Twist the lamp from the socket.
- d. To replace the bulb, reverse this procedure.

17-106. INTERIOR LIGHTING.

17-107. DESCRIPTION. Interior lighting consists of a dome light installed in the overhead console aft of rear wing spar. A slide switch located forward of the light controls the lamp.

17-108. REMOVAL AND INSTALLATION.

- a. Snap lens out of cover.
- b. Remove lamp and replace with new lamp.
- c. Reinstall lens.

17-109. CONTROL WHEEL MAP LIGHT.

17-110. DESCRIPTION. The control wheel map light is internally mounted in the control wheel. A rheostat on the lower left hand side of the wheel controls the light.

17-111. REMOVAL AND INSTALLATION. (Refer to figure 17-14.) To remove lamp, push upward on the lamp and turn. The lamp and reflector are replaced as a unit.

17-112. COMPASS AND RADIO DIAL LIGHTS.

17-113. DESCRIPTION. The compass and radio dial lights are contained within the individual units. The light intensity is controlled by the instrument light dimming rheostat mounted on the lower left side of the instrument panel.

17-114. STALL WARNING UNIT.


17-115. DESCRIPTION. A solid state warning unit is installed on the cabin top skin at Sta. 60.40. The warning signal is transmitted through the radio speaker in the overhead console.

17-116. REMOVAL AND INSTALLATION. Refer to figure 17-16 for removal and installation.

17-117. STALL WARNING SWITCH.

17-118. DESCRIPTION. The stall warning switch is installed in the leading edge of the left wing and is actuated by airflow over the surface of the wing. The switch will close as a stall condition is approached, actuating the stall warning horn. The horn should sound at approximately five to ten miles per hour above the actual stall speed. Initial installation of the switch should be with the lip of the warning switch approximately one sixteenth of an inch below the center line of the wing skin cutout. Test fly the aircraft to determine if the horn sounds at the desired speed. If the horn sounds too soon, move the unit down slightly; if too late, move the unit up slightly.


MODEL P210 SERIES SERVICE MANUAL



1. Control Tube Assembly
2. Cover
3. Adapter
4. Map Light Rheostat
5. Control Wheel
6. Map Light Socket
7. Lamp
8. Knob (Map Light)

Figure 17-14. Control Wheel Map Light Installation

MODEL P210 SERIES SERVICE MANUAL




- 1. Screw
- 2. Grommet
- 3. Sta. 138 Bulkhead
- 4. Bracket

- 5. Nutplate
- 6. Reflector
- 7. Nut

- 8. Retainer
- 9. Lens
- 10. Lamp
- 11. Socket

Figure 17-15. Baggage Compartment Light Installation

MODEL P210 SERIES SERVICE MANUAL



- 1. Cover
- 2. Bracket
- 3. Nutplate
- 4. Speaker
- 5. Screw
- 6. Dual Warning Unit
- 7. Adjustment Pots
- 8. RH Wing Root Rib
- 9. Screw
- 10. Cover

Figure 17-16. Stall Warning Unit




Figure 17-17. Stall Warning Switch

17-119. REMOVAL AND INSTALLATION. Refer to figure 17-17 for removal and installation.

17-120. PITOT AND STALL WARNING HEATERS.

17-121. DESCRIPTION. Electrical heater units are incorporated in some pitot tubes and stall warning switch units. The heaters offset the possibility of ice formation on the pitot tube and stall warning actuator switch. The heaters are integrally mounted in the pitot tube and stall warning actuator switch. Both heaters are controlled by the pitot heat switch.

17-122. REMOVAL AND INSTALLATION. Refer to figures 17-17 and 17-18 for removal and installation.

17-123. LANDING GEAR INDICATOR LIGHTS.

17-124. DESCRIPTION. The position of the landing gear is indicated by two press-to-test lamp assemblies mounted on the right side of the switch panel. The green light is on when all the wheels are down and locked; the amber is on when all the wheels are up and locked. If any wheel assumes an intermediate position of neither up and locked or down and locked both lights will be dark. The hood of each light is removable for bulb replacement, and has a dimming shutter.

17-125. REMOVAL AND INSTALLATION.

a. Remove the hood on either light by unscrewing counterclockwise. The lamp bulb is in the hood and may be replaced by pulling it out and inserting a new lamp.

b. To remove the lamp socket assembly, remove the nut from the assembly on the front side of the panel.

c. Tag and unsolder the wires from the socket assembly.

d. To replace a lamp socket assembly, reverse the above procedure.

17-126. EMERGENCY LOCATOR TRANSMITTER.

17-127. DESCRIPTION. The ELT is a self-contained, solid-state unit, having its own power supply with an externally mounted antenna. The unit is mounted in the tailcone, aft of the baggage curtain on the right hand side. The transmitters are designed to provide a broadcast tone that is audio modulated in a swept manner over the range of 1600 to 300 Hz in a distinct, easily recognizable distress signal for reception by search and rescue personnel and others monitoring the emergency frequencies. The ELT exhibits line of sight transmission characteristics which correspond approximately to 100 miles at a search altitude of 10,000 feet. C589512-0103 transmitter is used on all aircraft.

The C589512-0103 transmits on 121.5 and 343.0 MHz at 75 mw rated power output for 48 continuous hours in the temperature range of -4° F to +131° F (-20° C to +55° C).

Power is supplied to the transmitter by a battery-pack. The C589512-0107 alkaline battery-packs have the replacement date and date of installation on the top of the transmitter.

17-128. OPERATION. A three position switch on the forward end of the unit controls operation. Placing the switch in the ON position will energize the unit to start transmitting emergency signals. In the OFF position, the unit is inoperative. Placing the switch in the ARM position will set the unit to start transmitting emergency signals only after the unit has received a 5g (tolerances are +2g and -0g) impact force, for a duration of 11-16 milliseconds.

CAUTION

Do not leave the emergency locator transmitter in the ON position longer than 1 second (3 sweeps of the warble tone) or

MODEL P210 SERIES SERVICE MANUAL




Figure 17-18. Pitot Heater

you may activate downed aircraft procedures by C. A. P., D. O. T. or F. A. A. personnel.

17-129. CHECKOUT INTERVAL.

100 HOURS.

- a. Turn aircraft master switch ON.
- b. Turn aircraft transceiver ON and set frequency on receiver to 121.5 MHz.
- c. Remove the ELT's antenna cable from the ELT unit.
- d. Place the ELT's function selector switch in the ON position for 1 second or less. Immediately replace the ELT function selector switch in the ARM position after testing ELT.
- e. Test should be conducted only within the time period made up of the first five minutes after any hour.

CAUTION

Tests with the antenna connected should be approved and confirmed by the nearest control tower. The FAA/DOT allows free space transmission tests from the aircraft anytime within five minutes after each hour. The test time allowed is generally three sweeps of the warble tone, or approximately one second. The control tower should be notified that a test is about to be performed.

NOTE

Without its antenna connected, the ELT will produce sufficient signal to reach your receiver, yet it will not disturb other communications or damage output circuitry.

NOTE

After accumulated test or operation time equals 1 hour, battery-pack replacement is required. Do Not use substitute battery packs.

- f. Check calendar date for replacement of battery-pack. This date is supplied on a sticker attached to the outside of the ELT case and to each battery.


17-130. REMOVAL AND INSTALLATION OF TRANSMITTER. (Refer to figure 17-19.)

- a. Remove baggage curtain to gain access to the transmitter and antenna.
- b. Disconnect co-axial cable from end of transmitter.
- c. Remove the two #10 screws from the baseplate of the ELT and remove ELT.
- d. To reinstall transmitter, reverse preceding steps.

CAUTION

Ensure that the direction of flight arrows (placarded on the transmitter) are pointing towards the nose of the aircraft.

MODEL P210 SERIES SERVICE MANUAL



APPLIES TO AIRCRAFT WITH PITCH ACTUATOR BEGINNING WITH P2100082

ELT IS LOCATED BEHIND THIS SURFACE

PLACARD LOCATED ON RIGHT HAND SIDE OF TAILCONE ADJACENT TO ELT. ON CANADIAN AIRCRAFT.

Detail A
BEGINNING WITH P2100812



PLACARD LOCATED ON UPPER R.H. CORNER OF BAGGAGE CURTAIN

Detail C
ROTATED 180°

Figure 17-19. Emergency Locator Transmitter Installation

MODEL P210 SERIES SERVICE MANUAL

- (3) Using either radiated signal test method described above, verify that the G-switch has been activated and ELT is transmitting.
- (4) Reset the G-switch, and restore other disturbed switches to normal.
- (5) Reinstall ELT in airplane.
- d. Operational test of the TSO-C91a ELT G-switch.
 - (1) Remove ELT in airplane.
 - (2) While holding ELT firmly in one hand, make a throwing motion followed by a sudden reversal of the transmitter.
 - (3) Using either radiated signal test method described above, verify that the G-switch has been activated and ELT is transmitting.
 - (4) Reset the G-switch, and restore other disturbed switches to normal.
 - (5) Reinstall ELT in airplane.
- e. Check calendar date for replacement of battery pack. This date is supplied on a sticker attached to the outside of the ELT case and to each battery.

17-130. REMOVAL AND INSTALLATION OF TRANSMITTER. (Refer to figure 17-19.)

- a. Remove baggage curtain to gain access to the transmitter and antenna.
- b. Disconnect co-axial cable from end of transmitter.
- c. Remove the two #10 screws from the baseplate of the ELT and remove ELT.
- d. To reinstall transmitter, reverse preceding steps.

CAUTION

Ensure that the direction of flight arrows (placarded on the transmitter) are pointing towards the nose of the aircraft.

17-131. REMOVAL AND INSTALLATION OF ANTENNA. (Refer to figure 17-19.)

- a. Disconnect co-axial cable from base of antenna.
- b. Remove the nut and lockwasher attaching the antenna base to the fuselage and the antenna will be free for removal.
- c. To reinstall the antenna, reverse the preceding steps.

CAUTION

The C589511-0111 and C589511-0119 co-axial cable must be installed as indicated on the cable sleeve. Cable end marked "TO ANT" must be connected to the ELT antenna, and the end marked "TO ELT" must be connected to the C589511-0113/-0117 and C589511-0103/-0104 transmitters.

NOTE

Upon reinstallation of antenna, cement rubber boot (14) using RTV 102, General Electric Co., or equivalent, to antenna whip only; do not apply adhesive to fuselage skin or damage to paint may result.

17-132. REMOVAL AND INSTALLATION OF BATTERY PACK. (Refer to figure 17-20.)

NOTE

Transmitters equipped with the C589511-0105 or C589511-0106 battery packs can be replaced with a C589511-0114 after modification by SK185-20 has been completed.

CAUTION

Lithium battery pack must be replaced with alkaline battery packs per SK185-20.

- a. After the transmitter has been removed from aircraft in accordance with para. 17-130, place the transmitter switch in the OFF position.
- b. Remove the four screws attaching the cover to the case and then remove the cover to gain access to the battery pack.
- c. Disconnect the battery pack electrical connector and remove battery pack.
- d. Place new battery pack in the transmitter with four batteries as shown in the case in figure 17-20.
- e. Connect the electrical connector as shown in figure 17-20.

NOTE

Before installing the C589511-0105 pack, check to ensure that its voltage is 7.5 volts or greater.

- f. Replace the transmitter baseplate on the unit and pressing the baseplate and unit together attach baseplate with four nylok patch screws.
- g. Stamp the new replacement date on the outside of the ELT. The date should be noted on the switching nameplate on the side of the unit as well as on the instruction nameplate on the top of the unit.

WARNING

The battery pack has pressurized contents. Do not recharge, short circuit or dispose of in fire.

CAUTION

Be sure to enter the new battery pack expiration date in the aircraft records. It is also recommended this date be placed in your ELT Owner's Manual for quick reference.




Figure 17-20. Battery Pack Installation

MODEL P210 SERIES SERVICE MANUAL

17-133. TROUBLE SHOOTING. Should your Emergency Locating Transmitter fail the 100 Hours performance checks, it is possible to a limited degree to isolate the fault to a particular area of the equipment. In performing the following trouble shooting.

procedures to test peak effective radiated power, you will be able to determine if battery replacement is necessary or if your unit should be returned to your dealer for repair.

TROUBLE	PROBABLE CAUSE	REMEDY
*POWER LOW	Low battery voltage.	<ol style="list-style-type: none"> 1. Set toggle switch to off. 2. Disconnect the battery pack from the transmitter and connect a Simpson 260 model voltmeter and measure voltage. If the battery pack transmitters are 7.5 volts or less, the battery pack is below specification.
	Faulty transmitter.	<ol style="list-style-type: none"> 3. If the battery pack voltage meets the specifications in step 2, the battery is O.K. If the battery is O.K., check the transmitter as follows: <ol style="list-style-type: none"> a. Reconnect battery pack to the transmitter. b. By means of E.F. Johnson 105-0303-001 jackplugs and 3 inch maximum long leads, connect a Simpson Model 1223 ammeter to the jack. c. Set the toggle switch to AUTO and observe the ammeter current drain. If the current drain is in the 15-25 ma range, the transmitter or the coaxial cable is faulty.
	Faulty coaxial antenna cable	<ol style="list-style-type: none"> 4. Check coaxial antenna cable for high resistance joints. If this is found to be the case, the cable should be replaced.

*This test should be carried out with the coaxial cable provided with your unit.

MODEL P210 SERIES SERVICE MANUAL

ELECTRICAL LOAD ANALYSIS CHART

STANDARD EQUIPMENT (RUNNING LOAD)	AMPS 1985	AMPS 1986
Battery Contactor33	.33
Clock	†	.05
Engine Instruments10	.10
Flashing Beacon	7.0	7.0
Instruments Lights	1.0	1.0
EL Panel	0.3	.3
Position Lights	2.8	2.8
*Turn Coordinator	0.3	.3
*Turn & Bank Indicator (Optional)	0.24	.24
Pressurization System90	.90
Lamp-Gear Up or Gear Down04	.04
Alternator Control Unit	2.00	2.00
OPTIONAL EQUIPMENT (RUNNING LOAD)		
Heated Pitot and Stall Warning Heaters	5.8	5.8
Windshield Anti-Ice	4.4	4.4
Wing De-Ice	3.0	3.0
Propeller Anti-Ice	18.0 ●	18.0 ●
Strobe Lights	2.0	2.0
Internal Instrument Lights		
Prop. De-Ice Ammeter02	.02
Encoding Altimeter08
Radio Magnetic Indicator (RMI)04	.04
TIT/EGT04	.04
Terrz TRA 2500 Radar Altimeter Indicator05	.05
ADF Indicator (Type IN-346A)08	.08
VOR/LOC/ARC Nav Indicator (Type IN-480AC)03	.03
VOR/LOC/ILS/ARC Nav Indicator (Type IN-481AC)03	.03
VOR/LOC/RNAV/ARC Nav Indicator (Type IN-482AC)03	.03
VOR/LOC/ILS/RNAV/ARC Nav Indicator (Type IN-483AC)03	.03
High Altitude Encoder (Blind)01	.01
Cessna Audio Control Panel	0.16	0.16
Stereo Avionics West (Type EC-100)	1.0	1.0
Sunair HF Xcvr (Type ASB-125)	2.5 ☆	2.5 ☆
Weather Radar - Blk & Wht (Type RDR-160)	3.5	3.5
Weather Radar - Color (Type RDR-160)	3.5	3.5
Weather Radar - (Type Primus 100 WX)	2.0	2.0
Sperry SDM-77A DME (Type RT-377A)30
Sperry 300 ADF (Type R-546E)	1.0	1.0
Sperry 300 Nav/Com (Type RT-385A)	1.0 ☆	1.0 ☆
Sperry 400 ADF (Type R-446A)	1.6	1.6
Sperry 400 Area Navigation System (Type RN-478A)	0.5	
Sperry 400 Area Navigation System (Type RN-479A)	1.0	1.0
Sperry 400 DME (Type R-476A)	2.5	
Sperry 400 DME (Type R-477A)	1.50	1.50
Sperry 400 Glide Slope (Type R-443B)	0.50	0.50
Sperry 400 Marker Beacon (Type R-402A) (R-402B)	0.1	0.10
Sperry 400 Nav/Com (Type RT-485B)	1.6 ☆	1.6 ☆
Sperry 400 Transponder (Type RT-459A)	2.0	2.0
Sperry 400B IFCS (Type IF-55A) (Includes Slaved HSI - Type IG-832A and Flight Director Indicator - Type G-550A)	6.0	6.0

MODEL P210 SERIES SERVICE MANUAL

ELECTRICAL LOAD ANALYSIS CHART

OPTIONAL EQUIPMENT (RUNNING LOAD) (CONT)	AMPS 1985	AMPS 1986
Sperry 400B Navomatic Autopilot (Type AF-55A)		
a. Includes Unslaved DG Type G-503A and Horizon Gyro Type G-549A Without Course Datum	5.0	5.0
b. Includes Slaved DG Type G-504A and Horizon Gyro Type G-549A With Course Datum	5.4	5.4
c. Includes Slaved HSI Type IG-832A and Horizon Gyro Type G-549A With Course Datum	6.0	6.0
Sperry 800 Encoding Altimeter (Type EA-801A) and Altitude Alerter (Type AA-801A)	0.6	0.6
King Airborne Radio Telephone (Type KT-96)	3.0	3.0
King Area Navigation System (Type KNS-71)	0.50	0.50
King Audio Control System (Type KMA-24)	0.16	0.16
King Digital ADF (Type KR-87)43	.43
King Digital Comm (Type KY-196)	0.4 ☆	0.4 ☆
King DME (Type KN-63)	0.60	0.60
King Nav/Comm (Type KX-165) With Optional Integral Glide Slope	0.4 ☆	0.4 ☆
King Radar Altimeter (Type KRA-10A)20	.20
King Radio Magnetic Indicator (Type KI-229)	1.00	1.00
King Transponder (Type KT-79A)36	.36
King Weather Radar (Type KWX-56)	3.0	3.0
ITEMS NOT CONSIDERED AS PART OF RUNNING LOAD		
King Nav/Com (Type KX-165) With Optional Integral Glide Slope	4.5 Ⓢ	4.5 Ⓢ
King Digital Comm (Type KY-196)	5.0 Ⓢ	5.0 Ⓢ
King Airborne Radio Telephone (Type KT-96)	3.0 Ⓢ	3.0 Ⓢ
Sperry 300 Nav/Com (RT385A)	2.3 Ⓢ	2.3 Ⓢ
Sperry 400 Nav/Com (RT-485B)	2.3 Ⓢ	2.3 Ⓢ
Sunair HF Xcvr (Type ASB-125)	7.5 Ⓢ	7.5 Ⓢ
Auxiliary Fuel Pump	3.0	3.0
Flap Motor	1.8	1.8
Landing Lights (Each)	3.60	3.60
Stall Warning Horn40	.40
Wing Courtesy Light & Cabin Lights	1.50	1.50
Ice Detector Light	1.50	1.50
Electrohydraulic Power Pack	14.0	14.0
Electric Elevator Trim50	.50
Map Light10	.10
Recognition Lights	3.60	3.60
Air Conditioning	22.80	22.80
Standby Vacuum System	13.0	13.0
<p>* Only one or the other may be used at one time</p> <p>† Negligible</p> <p>● In flight running load</p> <p>Ⓢ Transmit</p> <p>☆ Receive</p>		

MODEL P210 SERIES SERVICE MANUAL

SECTION 18

STRUCTURAL REPAIR

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
STRUCTURAL REPAIR	3C12/18-2	ELEVATORS AND RUDDER	3C14/18-4
Criteria	3C12/18-2	Negligible Damage	3C14/18-4
EQUIPMENT AND TOOLS	3C12/18-2	Repairable Damage	3C14/18-4
Support Stands	3C12/18-2	Replacement	3C14/18-4
Repair Jigs	3C12/18-2	Balancing	3C14/18-4
Fuselage	3C12/18-2	FIN AND STABILIZER	3C14/18-4
Wings	3C12/18-2	Negligible Damage	3C14/18-4
MATERIALS	3C12/18-2	Repairable Damage	3C14/18-4
WING TWIST	3C12/18-2	Replacement	3C14/18-4
WING	3C12/18-2	BONDED DOORS	3C14/18-4
Description	3C12/18-2	Repairable Damage	3C14/18-4
WING SKIN	3C12/18-2	FUSELAGE	3C14/18-4
Negligible Damage	3C12/18-2	Description	3C14/18-4
Repairable Damage	3C12/18-2	Negligible Damage	3C14/18-4
Replacement	3C13/18-3	Repairable Damage	3C15/18-5
Wing Stringers	3C13/18-3	Replacement	3C15/18-5
Negligible Damage	3C13/18-3	BULKHEADS	3C15/18-5
Repairable Damage	3C13/18-3	Landing Gear	3C15/18-5
Replacement	3C13/18-3	Repair Hard Landing	3C15/18-5
WING SPAR	3C13/18-3	Firewall Damage	3C15/18-5
Negligible Damage	3C13/18-3	Fasteners	3C15/18-5
Repairable Damage	3C13/18-3	Replacement of Hi-Shear	
Replacement	3C13/18-3	Rivets	3C15/18-5
WET WING SPARS AND RIBS	3C13/18-3	Rivets	3C16/18-6
Negligible Damage	3C13/18-3	Baffles	3C18/18-8
Repairable Damage	3C13/18-3	ENGINE COWLING	3C18/18-8
Replacement	3C13/18-3	Repair	3C18/18-8
AILERONS	3C13/18-3	Reinforcement Angles	3C19/18-9
Negligible Damage	3C13/18-3	Fiberglass Components	3C19/18-9
Repairable Damage	3C13/18-3	CLEANING MATERIALS	3D2/18-16
Replacement	3C13/18-3	Procedures	3D2/18-16
Balancing	3C13/18-3	Application Sequence	3D2/18-16
WING FLAPS	3C14/18-4	Mixing Sealants	3D2/18-16
Negligible Damage	3C14/18-4	SEALANTS APPLICATION	3D2/18-16
Repairable Damage	3C14/18-4	Fay Sealing	3D2/18-16
Replacement	3C14/18-4	Injection Sealing	3D3/18-17
WING LEADING EDGE	3C14/18-4	Fillet Sealing	3D3/18-17
Negligible Damage	3C14/18-4	Fastener Sealing	3D4/18-18
Repairable Damage	3C14/18-4	Window Sealing	3D4/18-18
Replacement	3C14/18-4	Electrical Sealing	3D4/18-18
		Adding Wires	3D5/18-19

MODEL P210 SERIES SERVICE MANUAL

18-1. STRUCTURAL REPAIR.

18-2. REPAIR CRITERIA. Although this section outlines repair permissible on structure of the aircraft, the decision of whether to repair or replace a major unit of structure will be influenced by such factors as time and labor available and by a comparison of labor costs with the price of replacement assemblies. Past experience indicates that replacement, in many cases, is less costly than major repair. Certainly, when the aircraft must be restored to its airworthy condition in a limited length of time, replacement is preferable. Restoration of a damaged aircraft to its original design strength, shape and alignment involves careful evaluation of the damage, followed by exacting workmanship in performing the repairs. This section suggests the extent of structural repair practicable on the aircraft and supplements Federal Aviation Regulation, Part 43. Consult the factory when in doubt about a repair not specifically mentioned here.

18-3. EQUIPMENT AND TOOLS.

18-4. SUPPORT STANDS. Padded, reinforced sawhorse or tripod type support stands, sturdy enough to support any assembly placed upon them, must be used to store a removed wing or tailcone. Plans for local fabrication of support stands are contained in figure 18-1. The fuselage assembly, from the tailcone to the firewall, must NOT be supported from the underside, since the skin bulkheads are not designed for this purpose. Adapt support stands to fasten to the wing-attach points or landing gear attach-points when supporting a fuselage.

18-5. FUSELAGE REPAIR JIGS. Whenever a repair is to be made which could affect structural alignment, suitable jigs must be used to assure correct alignment of major attach points, such as fuselage, firewall, wing and landing gear. These fuselage repair jigs are obtainable from the factory.

18-6. WING JIGS. These jigs serve as a holding fixture during extensive repair of a damaged wing, and locates the root rib, leading edge and tip rib of the wing. These jigs are also obtainable from the factory.

18-7. REPAIR MATERIALS. Thickness of a material on which a repair is to be made can easily be determined by measuring with a micrometer. In general, material used in Cessna aircraft covered in this manual is made from 2024 aluminum alloy, heat treated to a -T3, -T4, or -T42 condition. If the type of material cannot readily be determined, 2024-T3 may be used in making repairs, since the strength of -T3 is greater than -T4 or -T42 (-T4 and -T42 may be used interchangeably, but they may not be substituted for -T3. When necessary to form a part with a smaller bend radius than the standard cold bending radius for 2024-T4, use 2024-0 and heat treat to 2024-T42 after forming. The repair material used in making a repair must equal the gauge of the material being repaired unless otherwise noted.

It is often practical to cut repair pieces from service parts listed in the Parts Catalog. A few components (empennage tips, for example) are fabricated from thermo-formed plastic or glass fiber constructed material.

18-8. WING TWIST AND STABILIZER ANGLE-OF-INCIDENCE. Wing twist (washout) and stabilizer angle of incidence are shown below. Stabilizers do not have twist. The cantilever wing has a uniform twist from the root rib to the tip rib. Refer to figure 18-3 for wing twist measurement.

WING	
Twist (Washout)	3°
STABILIZER	
Angle-of-incidence	-3° ± 15'

18-9. WING.

18-10. DESCRIPTION. The wing is sheet-metal constructed, with a single main spar, two fuel spars, formed ribs and stringers. The front fuel spar also serves as an auxiliary spar and is the forward wing attaching point. An inboard section forward of the main spar is sealed to form an integral fuel bay area. The main spar consists of milled spar caps and attaching fittings joined by a web section. The aft fuel spar is a formed channel. The front fuel spar is a built-up assembly consisting of a formed channel, doubler, attach strap and support angle. Stressed skin, riveted to the ribs, spars and stringers, completes the wing structure. Access openings (hand holes with removable cover plates) are located in the underside of the wing between the wing root and tip section. These openings afford access to the flap and aileron bellcranks, flap drive pulleys, flap actuator in left wing, flap and aileron control cable disconnect points, fuel adapter plate, air scoop connectors and electrical wiring.

18-11. WING SKIN.

18-12. NEGLIGIBLE DAMAGE. Any smooth dents in the wing skin that are free from cracks, abrasions and sharp corners, which are not stress wrinkles and do not interfere with any internal structure or mechanism, may be considered as negligible damage in any area of the wing. Outboard of wing station 40.00 in areas of low stress intensity, cracks, deep scratches or sharp dents, which after trimming or stop drilling can be enclosed by a two-inch circle, can be considered negligible if the damaged area is at least one diameter of the enclosing circle away from all existing rivet lines and material edges. The area on the lower surface of the wing between the two stringers adjacent to the main spar is not considered low stress intensity. Stop drilling is considered a temporary repair and a permanent repair should be made as soon as practicable.

18-13. REPAIRABLE DAMAGE. Repairs must not be made to the upper or lower wing skin inboard of station 40.00 without factory approval. However, an

MODEL P210 SERIES SERVICE MANUAL

entire skin may be replaced without factory approval. Refer to Section 1 for wing station locations. Figure 18-18 outlines typical repairs to be employed in patching skin. Before installing a patch, trim the damaged area to form a rectangular pattern, leaving at least a one-half inch radius at each corner and deburr. The sides of the hole should lie span-wise or chord-wise. A circular patch may also be used. If the patch is in an area where flush rivets are used, make a flush patch type of repair; if in an area where flush rivets are not used, make an overlapping type of repair. Where optimum appearance and airflow are desired, the flush patch may be used. Careful workmanship will eliminate gaps at butt-joints; however, an epoxy type filler may be used at such joints.

18-14. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If a skin is badly damaged, repair must be made by replacing an entire skin panel, from one structural member to the next. Repair seams must be made to lie along existing structural members and each seam must be made exactly the same in regard to rivet size, spacing and pattern as the manufactured seams at the edges of the original sheet. If the manufactured seams are different, the stronger must be copied. If the repair ends at a structural member where no seam is used, enough repair panel must be used to allow an extra row of staggered rivets, with sufficient edge margin, to be installed.

18-15. WING STRINGERS.

18-16. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-17. REPAIRABLE DAMAGE. Figure 18-12 outlines a typical wing stringer repair. Two such repairs may be used to splice a new section of stringer material in position, without the filler material.

18-18. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If a stringer is so badly damaged that more than one section must be spliced, replacement is recommended.

18-19. WING RIBS.

18-20. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-21. REPAIRABLE DAMAGE. Figure 18-19 illustrates typical wing rib repairs.

18-22. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Any wing rib damaged extensively should be replaced. However, due to the necessity of disassembling so much of the wing in order to replace a rib, especially in the fuel bay area which involves sealing, wing ribs should be repaired if practicable.

18-23. WING SPAR.

18-24. NEGLIGIBLE DAMAGE. Due to the stresses which the wing spar encounters, very little damage can be considered negligible. Smooth dents, light

scratches and abrasions may be considered negligible.

18-25. REPAIRABLE DAMAGE. All cracks, stress wrinkles, deep scratches and sharp dents must be repaired. However, repairs must not be made to the main wing spar inboard of wing station 155.00 without factory approval. Refer to Section 1 for wing station locations. Figure 18-20 outlines a typical main wing spar repair.

18-26. DAMAGE NECESSITATING REPLACEMENT OF PARTS. An entire wing spar may be replaced without factory approval.

18-27. WING FUEL BAY SPARS AND RIBS.

18-28. NEGLIGIBLE DAMAGE. Any smooth dents in the fuel spars that are free from cracks, abrasions and sharp corners, which are not stress wrinkles and do not interfere with any internal structure or mechanism, may be considered as negligible damage in any area of the spar.

18-29. REPAIRABLE DAMAGE. The type of repair outlined in figure 18-20 also applies to fuel bay spars outboard of wing station 124.0. Inboard of station 124.0, factory approval of proposed repairs is required. Refer to Section 13 for sealing procedures when working in fuel bay areas.

18-30. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Due to the amount of fuel bay sealant which must be removed from fuel bay components to facilitate repair, individual parts are not available to replace fuel bay spars or ribs. The entire fuel bay area must be replaced as a unit.

18-31. AILERONS.

18-32. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-33. REPAIRABLE DAMAGE. The repair shown in figure 18-21 may be used to repair damage to aileron leading edge skins. The flush type skin patches shown in figure 18-18 may be used to repair damage to the remaining skins. Following repair, the aileron must be balanced. Refer to paragraph 18-35 and figure 18-2 for balancing the aileron.

18-34. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If the damage would require a repair which could not be made between adjacent ribs, complete skin panels must be replaced. Ribs and spars may be repaired, but replacement is generally preferable. Where extensive damage has occurred, replacement of the aileron assembly is recommended. After repair or replacement, balance aileron in accordance with paragraph 18-35 and figure 18-2.

18-35. AILERON BALANCING. Following repair, replacement or painting, the aileron must be balanced. Complete instructions for fabricating balancing fixtures and mandrels and their use are given in figure 18-2.

MODEL P210 SERIES SERVICE MANUAL

18-36. WING FLAPS.

18-37. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-38. REPAIRABLE DAMAGE. Flap repairs should be similar to aileron repairs discussed in paragraph 18-33. A flap leading edge repair is shown in figure 18-22.

18-39. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Flap repairs which require replacement of parts should be similar to aileron repairs discussed in paragraph 18-34. Since the flap is not considered a movable control surface, no balancing is required.

18-40. WING LEADING EDGE.

18-41. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-42. REPAIRABLE DAMAGE. A typical leading edge skin repair is shown in figure 18-21. Also wing skin repairs, outlined in paragraph 18-13, may be used to repair leading edge skins, although the flush-type patches should be used. Extra access holes, described in paragraph 18-10, must not be installed in the wing without factory approval. Where extreme damage has occurred, replace complete skin panels.

18-43. DAMAGE NECESSITATING REPLACEMENT OF PARTS. An entire leading edge skin may be replaced without factory approval.

18-44. ELEVATORS AND RUDDER.

18-45. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12. The exception to negligible damage on the elevator surfaces is the front spar, where a crack appearing in the web at the hinge fittings or in the structure which supports the overhanging balance weight is not considered negligible. Cracks in the overhanging tip rib, in the area at the front spar intersection with the web of the rib, also cannot be considered negligible.

18-46. REPAIRABLE DAMAGE. Skin patches illustrated in figure 18-18 may be used to repair skin damage. Following repair, the elevators and rudder must be balanced. Refer to paragraph 18-48 and figure 18-2 for balancing the elevators and rudder. If damage would require a repair which could not be made between adjacent ribs, see the following paragraph.

18-47. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If the damaged area would require a repair which could not be made between adjacent ribs, complete skin panels must be replaced. Ribs and spars may be repaired, but replacement is generally preferable. Where extensive damage has occurred, replacement of the entire assembly is recommended. After repair and/or replacement, balance elevators and rudder in accordance with paragraph 18-48 and figure 18-2.

18-48. ELEVATOR AND RUDDER BALANCING. Following repair, replacement or painting, the elevators and rudder must be balanced. Complete instructions for fabricating balancing fixtures and mandrels and their use are given in figure 18-2.

18-49. FIN AND STABILIZER.

18-50. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-51. REPAIRABLE DAMAGE. Skin patches illustrated in figure 18-18, may be used to repair skin damage. Access to the dorsal area of the fin may be gained by removing the horizontal closing rib at the bottom of the fin. Access to the internal fin structure is best gained by removing skin attaching rivets on one side of the rear spar and ribs, and springing back the skin. Access to the stabilizer structure may be gained by removing skin attaching rivets on one side of the rear spar and ribs, and springing back the skin. If the damaged area would require a repair which could not be made between adjacent ribs, or a repair would be located in an area with compound curves, see the following paragraph.

18-52. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If the damaged area would require a repair which could not be made between adjacent ribs, or the repair would be located in an area with compound curves, complete skin panels must be replaced. Ribs and spars may be repaired, but replacement is generally preferable. Where damage is extensive, replacement of the entire assembly is recommended.

18-52A. BONDED DOORS.

18-52B. REPAIRABLE DAMAGE. Bonded doors may be repaired by the same methods used for riveted structure. Rivets are a satisfactory substitute for bonded seams on these assemblies. The strength of the bonded seams in doors may be replaced by a single 3/32, 2117-AD rivet per running inch of bond seam. The standard repair procedures outlined in AC43.13-1 are also applicable to bonded doors.

18-53. FUSELAGE.

CAUTION

Repairs must not be made to the main wing spar carry-thru section of the cantilever wing without factory approval.

18-54. DESCRIPTION. The fuselage is of semi-monocoque construction consisting of formed bulkheads, longitudinal stringers, reinforcing channels and skin platings.

18-55. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12. Mild corrosion appearing upon alclad surfaces does not necessarily indicate incipient failure of the base metal. However, corrosion of all types must be carefully considered and approved remedial action taken. Small cans appear in the skin structure of all metal aircraft. It is strongly recommended,

MODEL P210 SERIES SERVICE MANUAL

however, that wrinkles which appear to have originated from other sources, or which do not follow the general appearance of the remainder of the skin panels, be thoroughly investigated. Except in the landing gear bulkhead area, wrinkles occurring over stringers which disappear when the rivet pattern is removed may be considered negligible. However, the stringer rivet holes may not align perfectly with the skin holes because of a permanent "set" in the stringer. If this is apparent, replacement of the stringer will usually restore the original strength characteristics of the area.

NOTE

Wrinkles occurring in the skin of the main landing gear bulkhead areas must not be considered negligible. The skin panel must be opened sufficiently to permit a thorough examination of the lower portion of the landing gear bulkhead and its tie-in structure.

Wrinkles occurring on open areas which disappear when the rivets at the edge of the sheet are removed, or a wrinkle which is hand removable, may often be repaired by the addition of a 1/2 x 1/2 x .060 inch 2024-T4 extruded angle, riveted over the wrinkle and extended to within 1/16 to 1/8 inch of the nearest structural members. Rivet pattern must be identical to the existing manufactured seam at the edge of the sheet.

18-56. REPAIRABLE DAMAGE. Fuselage skin repairs may be accomplished in the same manner as wing skin repairs outlined in paragraph 18-13. Stringers, formed skin flanges, bulkhead channels and similar parts may be repaired as shown in figures 18-13 or 18-15.

18-57. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Fuselage skin major repairs may be accomplished in the same manner as wing skin repairs outlined in paragraph 18-14. Damaged fittings must be replaced.

18-58. BULKHEADS.

18-59. LANDING GEAR BULKHEADS. Since these bulkheads are highly stressed members irregularly formed to provide clearance for control lines, actuators, fuel lines, etc., patch type repairs will be, for the most part, impractical. Minor damage consisting of small nicks or scratches may be repaired by dressing out the damaged area, or by replacement of rivets. Any other such damage must be repaired by replacing the landing gear support assembly as an aligned unit.

18-60. REPAIR AFTER HARD LANDING. Buckled skin or floorboards and loose or sheared rivets in the area of the main gear support will give evidence of damage to the structure from an extremely hard landing. When such evidence is present, the entire support structure must be carefully examined and all support forgings must be checked for cracks, using a dye penetrant and proper magnification. Bulkheads in the area of possible damage must be

checked for alignment and a straightedge must be used to determine deformation of the bulkhead webs. Damaged support structure, buckled floorboards and skins and damaged or questionable forgings must be replaced.

18-61. FIREWALL DAMAGE. Firewalls may be repaired by removing the damaged material and splicing in a new section. The new portion must be lapped over the old material, sealed with Pro-Seal #700 (Coast Pro-Seal Co., Chemical Division, 2235 Beverly Blvd., Los Angeles, California) compound, or equivalent and secured with MS16535 (steel) or MS-20613 (corrosion-resistant steel) rivets. The heater valve assembly is attached with MS16535 and MS-20613 rivets. Firewall plates, firewall doublers, and nutplates are attached to the firewall with MS-20470 (aluminum) rivets. Damaged or deformed angles and stiffeners may be repaired as shown in figure 18-23, or they may be replaced. A severely damaged firewall must be replaced as a unit.

18-62. FASTENERS. Fasteners used in the aircraft are generally solid aluminum rivets, blind rivets, and steel-threaded fasteners. Usage of each is primarily a function of the loads to be carried, accessibility, and frequency of removal. Rivets used in aircraft construction are usually fabricated from aluminum alloys. In special cases, monel, corrosion-resistant steel and mild steel, copper, and iron rivets are used.

18-63. RIVETS. Standard solid-shank MS rivets are those generally used in aircraft construction. They are fabricated in the following head types: roundhead, flathead, countersunk head, and brazier head. Flathead rivets are generally used in the aircraft interior where head clearance is required. MS20426 countersunk head rivets are used on the exterior surfaces of the aircraft to minimize turbulent airflow. MS20470 brazier head rivets are used on the exterior surfaces of the aircraft where strength requirements necessitate a stronger rivet head than that of the countersunk head rivet. Both the brazier head and the countersunk head rivets are used on the exterior of the aircraft where head clearance is required. Hi-shear rivets are special, patented rivets having a hi-shear strength equivalent to that of standard AN bolts. They are used in special cases in locations where hi-shear loads are present, such as in spars, wings, and in heavy bulkhead ribs. This rivet consists of a cadmium-plated pin of alloy steel. Some have a collar of aluminum alloy. Some of these rivets can be readily identified by the presence of the attached collar in place of the formed head on standard rivets. Blind rivets are used, where strength requirements permit, where one side of the structure is inaccessible, making it impossible or impractical to drive standard solid-shank rivets.

18-64. REPLACEMENT OF HI-SHEAR RIVETS. Replacement of hi-shear rivets with close-tolerance bolts or other commercial fasteners of equivalent strength properties is permissible. Holes must not be elongated, and the hi-shear substitute must be a smooth, push-fit. Field replacement of main landing gear forgings on bulkheads may be accomplished by

MODEL P210 SERIES SERVICE MANUAL

using the following fasteners.

- a. NAS464P-* bolt, MS21042-* nut and AN960-* washer in place of Hi-shear rivets for forgings with machined flat surfaces around attachment holes.
- b. NAS464P-* bolt, ESNA2935-* mating base washer and ESNA RM52LH2935-* self-aligning nut for forgings (with draft angle of up to a maximum of 8°) without machined flat surfaces around attachment holes.

*Dash numbers to be determined according to the size of the holes and the grip lengths required. Bolt grip length should be chosen so that no threads remain in the bearing area.

18-65. SUBSTITUTION OF RIVETS.

a. Solid-shank rivets (MS20426AD and MS20470AD). When placing rivets in installations which require raised head rivets, it is desirable to use rivets identical to the type of rivet removed. Countersunk-head

rivets (MS20426) are to be replaced by rivets of the same type and degree of countersink. When rivet holes become enlarged, deformed, or otherwise damaged, use the next larger size rivet as a replacement. Replacement shall not be made with rivets of lower strength material.

b. Hi-shear Rivets. When hi-shear rivets are not available, replacement of sizes 3/16-inch or greater rivets shall be made with bolts of equal or greater strength than the rivet being replaced, and with self-locking nuts of the same diameter.

c. The following pages contain approved solid-shank and hi-shear rivet substitutions.

Replace	In thickness (or thicker)	With
MS20470AD3	.025	NAS1398B4, NAS1398D4 NAS1738B4, NAS1738D4, NAS1768D4, CR3213-4, CR3243-4
	.020	
MS20470AD4	.050	NAS1398B4, NAS1398D4 NAS1398B5, NAS1398D5, NAS1738B4, NAS1738E4, NAS1768D4, CR3213-4 NAS1738B5, NAS1738E5, NAS1768D5, CR3213-5, CR3243-4 CR3243-5
	.040	
	.032	
	.025	
MS20470AD5	.063	NAS1398B5, NAS1398D5 NAS1398B6, NAS1398D6, NAS1398B5, NAS1738E5, CR3213-5 NAS1738B6, NAS1738E6, NAS1768D5, CR3213-6, CR3243-5 CR3243-6
	.050	
	.040	
	.032	
MS20470AD6	.080	NAS1398B6 NAS1398D6 NAS1738B6, NAS1738D6, NAS1768D6, CR3213-6 CR3243-6
	.071	
	.063	
	.050	

MODEL P210 SERIES SERVICE MANUAL

Replace	In thickness (or thicker)	With
MS20426AD3 (Countersunk)	.063	NAS1399B4, NAS1399D4
	.040	NAS1769D4, CR3212-4
(See Note 1)	.025	NAS1769B4, NAS1739E4, CR3242-4
MS20426AD3 (Dimpled)	.063	NAS1399B4, NAS1399D4
	.050	CR3212-4
	.040	NAS1739B4, NAS1739D4, NAS1769D4, CR3242-4
MS20426AD4 (Countersunk)	.080	NAS1399B4, NAS1399D4
	.063	NAS1739B4, NAS1739D4, CR3212-4
	.050	NAS1769D4
	.040	CR3242-4
(See Note 1)	.050	CR3212-5
	.040	NAS1739B5, NAS1739D5, NAS1769D4
	.032	CR3242-5
MS20426AD4 (Dimpled)	.063	NAS1739B4, NAS1739D4
	.090	NAS1399B5, NAS1399E5
	.071	CR3212-5
	.063	NAS1739B5, NAS1399D5, NAS1769D5
	.050	CR3242-5
MS20426AD5 (Countersunk)	.090	NAS1399B5, NAS1399D5
	.080	CR3212-5
	.071	NAS1739B5, NAS1739E5
	.063	NAS1769D5
	.050	CR3242-5
(See Note 1)	.063	NAS1739B6, NAS1739D6, NAS1769D6, CR3212-6
	.040	CR3242-6
	.032	AN509-10 Screw with MS20365 Nut
MS20426AD5 (Dimpled)	.071	NAS1739B5, NAS1739D5
	.090	NAS1739B6, NAS1739D6, CR3212-6
	.080	NAS1769D6
	.071	CR3242-6
	.032	AN509-10 Screw with MS20365 Nut
MS20426AD6 (Countersunk)	.090	NAS1739B6, NAS1739D6, CR3212-6
	.071	NAS1769D6
	.063	CR3242-6
	.032	AN509-10 Screw with MS20365 Nut
MS20426AD6 (Dimpled)	.090	NAS1739B6, NAS1739D6
	.032	AN509-10 Screw with MS20365 Nut

NOTE 1: Rework required. Countersink oversize to accommodate oversize rivet.

MODEL P210 SERIES SERVICE MANUAL

REPLACE		DIAMETER	WITH	
Fastener	Collar		Fastener	Collar
<ul style="list-style-type: none"> ● NAS178 	<ul style="list-style-type: none"> NAS179 	<ul style="list-style-type: none"> (See Note 1) (See Note 1) (See Note 1) (See Notes 1 and 2) (See Note 1) (See Note 1) 	<ul style="list-style-type: none"> ● NAS1054 ● NAS14XX ● NAS529 ★ NAS1446 ★ NAS7034 □ NAS464 □ NAS1103 □ NAS1303 □ NAS6203 □ AN173 	<ul style="list-style-type: none"> NAS179, NAS528 NAS1080C, NAS1080E, NAS1080G NAS524A NAS1080C, NAS1080A6 NAS1080K AN364, MS20364, MS21042 AN305, MS20305, MS21044, MS21045
<ul style="list-style-type: none"> ● NAS1054 	<ul style="list-style-type: none"> NAS179, NAS528 	<ul style="list-style-type: none"> (See Note 2) 	<ul style="list-style-type: none"> ● NAS14XX ● NAS529 ★ NAS1446 ★ NAS7034 □ NAS464 □ NAS1103 □ NAS1305 □ NAS6203 	<ul style="list-style-type: none"> NAS1080C, NAS1080E NAS524A NAS1080C, NAS1080A6 NAS1080K AN364, MS20304, MS21042
<ul style="list-style-type: none"> ● NAS14XX 	<ul style="list-style-type: none"> NAS1080C NAS1080E NAS1080G 		<ul style="list-style-type: none"> ● NAS529 ★ NAS1446 ★ NAS7034 □ NAS464 □ NAS1103 □ NAS1303 □ NAS6203 	<ul style="list-style-type: none"> NAS524A NAS1080C, NAS1080A6 NAS1080K AN364, MS20364, MS21042
<ul style="list-style-type: none"> ● NAS529 	<ul style="list-style-type: none"> NAS524A 	<ul style="list-style-type: none"> (See Note 3) 	<ul style="list-style-type: none"> □ NAS1446 	<ul style="list-style-type: none"> NAS1080C, NAS1080A6

NOTE 1: See appropriate tables for nominal diameters available.

NOTE 2: Available in oversize for repair of elongated holes. Ream holes to provide a .001 inch interference fit.

NOTE 3: NAS1446 oversize only permitted as a replacement for NAS529.

● Steel shank fastener designed for drive-on collars.

★ Steel shank fastener designed for squeeze-on collars. Installation requires sufficient space for the tool and extended shank of the fastener.

□ Threaded fastener.

18-66. BAFFLES. Baffles ordinarily require replacement if damaged or cracked. However, small plate reinforcements riveted to the baffle will often prove satisfactory both to the strength and cooling requirements of the unit.

18-67. ENGINE COWLING.

18-68. REPAIR OF COWLING SKINS. If extensively damaged, complete sections of cowling must be re-

MODEL P210 SERIES SERVICE MANUAL




Figure 18-1. Wing and Fuselage Support Stands


placed. Standard insert-type patches, however, may be used if repair parts are formed to fit. Small cracks may be stop-drilled and dents straightened if they are reinforced on the inner side with a doubler of the same material. Bonded cowling may be repaired by the same methods used for riveted structure. Rivets are a satisfactory substitute for bonded seams on these assemblies. The strength of the bonded seams in cowling may be replaced by a single 3/32, 2117-AD rivet per running inch of bond seam. The standard repair procedures outlined in AC43.13-1 are also applicable to cowling.

18-69. REPAIR OF REINFORCEMENT ANGLES. Cowl reinforcement angles, if damaged, must be replaced. Due to their small size they are easier to replace than to repair.

18-70. REPAIR OF GLASS-FIBER CONSTRUCTED COMPONENTS. Glass-fiber constructed components on the aircraft may be repaired as stipulated in instructions furnished in SK182-12. Observe the resin manufacturer's recommendations concerning mixing and application of the resin. Epoxy resins are preferable for making repairs, since epoxy compounds are usually more stable and predictable than polyester and give better adhesion.

MODEL P210 SERIES SERVICE MANUAL

FLIGHT CONTROL SURFACE BALANCING FIXTURE KIT (PART NUMBER 5180002-1)



GENERAL NOTES

1. Balance control surfaces in a draft-free area.
2. Place hinge bolts through control surface hinges and position on knife edge balancing mandrels. Be sure hinge bolt shank rests on knife edge.
3. Make sure all control surfaces are in their approved flight configurations: painted (if applicable), trim tabs installed, all foreign matter removed from inside of control surface, elevator trim tab push-pull rod installed and all tips installed.
4. Place balancing mandrels on a table or other suitable flat surface.
5. Adjust trailing edge support to fit control surface being balanced while center of balancing beam is directly over hinge line. Remove balancing beam and balance the beam itself by moving the adjustable weight (fastened by bolt and washer). Fine balance may be accomplished by use of washers at long screw on end of beam.
6. When positioning balancing beam on control surface, avoid rivets to provide a smooth surface for the beam and keep the beam 90° to the hinge line of the control surface.

Figure 18-2. Control Surface Balancing (Sheet 1 of 5)

MODEL P210 SERIES SERVICE MANUAL

7. Paint is a considerable weight factor. In order to keep balance weight to a minimum, it is recommended that existing paint be removed before adding paint to a control surface. Increase in balance weight will also be limited by the amount of space available and clearance with adjacent parts. Good workmanship and standard repair practices should not result in unreasonable balance weight.
8. The approximate amount of weight needed may be determined by taping loose weight at the balance weight area.
9. Lighten balance weight by drilling off part of weight.
10. Make balance weight heavier by fusing bar stock solder to weight after removal from control surface. The ailerons should have balance weight increased by ordering additional weight and gang channel, listed in applicable Parts Catalog and installing next to existing inboard weight the minimum length necessary for correct balance, except that a length which contains at least two attaching screws must be used. If necessary, lighten new weight or existing weights for correct balance.




Figure 18-2. Control Surface Balancing (Sheet 2 of 5)

MODEL P210 SERIES SERVICE MANUAL





Figure 18-2. Control Surface Balancing (Sheet 3 of 5)

AILERONS



Balance aileron inverted, with trailing edge at point opposite cut-out for middle hinge .85" below hinge line horizontal plane.

DETAIL A-A

Figure 18-2. Control Surface Balancing (Sheet 4 of 5)

MODEL P210 SERIES SERVICE MANUAL

CONTROL SURFACE BALANCE REQUIREMENTS

NOTE

Balance limits for control surfaces are expressed for "Approved Flight" configuration. "Approved Flight" configuration is that condition of the control surface as prepared for flight of the airplane whether it be painted or unpainted.


"Approved Flight" limits must never be exceeded when the surface is in its final configuration for flight.

DEFINITIONS:

UNDERBALANCE is defined as the condition that exists when surface is trailing edge heavy and is defined by a symbol (+). If the balance beam sliding weight must be on the leading edge side of the hinge line (to balance the control surface), the control surface is considered to be underbalanced.




OVERBALANCE is defined as the condition that exists when surface is leading edge heavy and is defined by a symbol (-). If the balance beam sliding weight must be on the trailing edge side of the hinge line (to balance the control surface), the control surface is considered to be overbalanced.



CONTROL SURFACE	APPROVED FLIGHT CONFIGURATION BALANCE LIMITS (Inch-Pounds)
AILERON	-6.0 to 1.0
RUDDER	-4.0 to 3.0
RIGHT ELEVATOR	-6.0 to 1.0
LEFT ELEVATOR	-6.0 to 1.0

Figure 18-2. Control Surface Balancing (Sheet 5 of 5)

MODEL P210 SERIES SERVICE MANUAL



A	B	C	WING STATION
2.00	2.00	40.50	26.50
.75	2.00	25.50	205.00

ALL WING TWIST OCCURS BETWEEN STA. 26.50 AND STA. 205.00.

CHECKING WING TWIST

If damage has occurred to a wing, it is advisable to check the twist. The following method can be used with a minimum of equipment, which includes a straightedge (42" minimum length of angle or equivalent), three modified bolts and a protractor head with level.

1. Check chart for applicable dimension for bolt length (A or B).
2. Grind bolt shanks to a rounded point as illustrated, checking length periodically.
3. Tape two bolts to straightedge according to dimension C.
4. Locate inboard wing station to be checked and make a pencil mark approximately one-half inch aft of first lateral row of rivets, aft of wing leading edge.
5. Holding straightedge parallel to wing station, (staying as clear as possible from "cans"), place bolt on pencil mark and set protractor head against lower edge of straightedge.
6. Set bubble in level to center and lock protractor to hold this reading.
7. Omitting step 6, repeat procedure for outboard wing station, using dimensions specified in chart. Check to see that protractor bubble is still centered.
8. Proper twist is present in wing if protractor readings are the same (parallel). Forward or aft bolt may be lowered from wing .10 inch maximum to attain parallelism.

Figure 18-3. Checking Wing Twist.

MODEL P210 SERIES SERVICE MANUAL

18-71. CLEANING MATERIALS AND EQUIPMENT.

- a. Aliphatic Naphtha (TT-N-95) Type II.
- b. Mozels Cleaning Solvent #18, Mozel Chemical Company.
- c. Methyl-ethyl Ketone (MEK) cleaning solvent.
- d. Clean rags.
- e. Stiff bristle brushes (other than nylon).
- f. Sealant gun (Pyle #950 or equivalent). Pyle Industries Inc., Southfield, Michigan.
- g. Polyethylene nozzles for sealant gun.
- h. Polyethylene cartridges for sealant gun.
- i. Rubber gloves.

18-72. CLEANING PROCEDURES.

- a. Clean the surface immediately prior to the application of the sealing compound to insure the surface is free of dirt, grease and chips.
- b. Metal cleaning should be done with a clean, soft lintless rag moistened with Methyl-ethyl Ketone (MEK). The solvent should always be poured on the cloth to refrain from contamination of the solvent. The solvent should never be poured or sprayed on the structure due to possibility of running between layers of structure and creeping out again after cleaning, bringing contamination to surface to which the sealant is to be applied.
- c. Immediately dry the area thus cleaned with a dry, clean, lintless rag before the solvent has evaporated from the surface.
- d. If primer is removed during cleaning, it should be touched up after all sealing operations are complete.
- e. Always clean an area wider than the width of the finally applied sealant.
- f. Cleaned areas should be handled with care to prevent surface contamination.

18-73. APPLICATION SEQUENCE. In order to accomplish an adequate seal in an efficient manner, the following sealant operations shall be accomplished in the following order:

- a. Faying surface sealing as required on assembly.
- b. Fill holes and slots as required.
- c. Fill joggles and confined holes by injection as required.
- d. Fillet seal seams and joints as required.
- e. Seal fasteners as required.
- f. Faying surface sealing of close-out panels as required.

18-74. MIXING TWO PART SEALANTS.

- a. The base compound should be matched with the appropriate batch numbered accelerator.
- b. The two components must be weighed in proportions as marked on the container within a tolerance of $\pm 2\%$.
- c. If the entire preweighed kit is to be used, it is not necessary to weigh out the accelerator and base compound. Simply mix entire amount of the preweighed compounds in accordance with instructions outlined.
- d. The two components should be mixed thoroughly so that the complete mixture is of uniform color.

NOTE

Care should be exercised to preclude the trapping of air in the sealing compound during the mixing procedure.

- e. Mixed compound has a limited work life, so only enough should be mixed to satisfy the immediate requirement.

18-75. APPLICATION OF SEALING PROCEDURES.

18-76. FAYING SURFACE SEALING.

- a. Using sealant Type I, apply to one surface with a brush, spatula or roller. Spread evenly to approximately $1/32$ inch thick over the entire faying surface. The application should be accomplished with the sealing compound flowed on with minimum stroking to prevent formation of bubbles.
- b. Avoid using excess amounts of sealing compound.
- c. When the surfaces are fastened together, any extruded sealant should be faired out with a fairing tool, leaving a smooth fillet along the joint.
- d. All permanent fasteners must be installed within the work life of the sealant. Sealant extruded through hole by rivet must be wiped from end of rivet before bucking. If permanent fasteners cannot be installed, use temporary fasteners and clamps as necessary to hold the parts firmly together until the sealant has cured. Remove individual temporary fasteners and replace immediately with permanent fasteners. Fresh sealant must be applied to the fasteners.

NOTE

Any pressure testing required should not be done before the sealing compound has completely cured.




Figure 18-4 Faying Surface Sealing

MODEL P210 SERIES SERVICE MANUAL




Figure 18-5. Hole Filling




Figure 18-6. Injection Sealing

18-77. INJECTION SEALING.

a. An injection seal may be applied to provide continuity of seals where fillet seals are interrupted by holes, joggles, or structure. Force Type I sealant into one end of the cavity or injection hole, if provided, with a sealing gun until the sealing compound emerges from a prescribed opening for seal continuity.

b. When a seal is made at the bottom of a slot, the sealant should be applied to fill and have a continuous contact with the bottom and sides of the slot.

18-78. FILLET SEALING.

- a. Fillet sealing should be done with Type I sealant, using a sealing gun for application. The nozzle tip should be pointed into the seam and maintained nearly perpendicular to the line of travel. A bead of sealant will be forced ahead of the nozzle tip.
- b. Fillets may be worked into the surface with fairing tools or gun tip.
- c. Fillet shapes and dimensions should conform to dimensions given in figure 18-7 as near as possible.




Figure 18-7 Fillet Sealing

MODEL P210 SERIES SERVICE MANUAL




Figure 18-8. Fastener Sealing

18-79. FASTENER SEALING.

a. Fasteners installed through a faying surface within the work life of the sealant need no further sealing.

b. Fasteners installed through a faying plane where no faying surface sealant is used would be sealed by one of the following methods:

1. Apply Type I sealer to the fastener or hole on installation.
2. Brush the fastener with sealant after installation.

18-80. WINDOW SEALING.

a. Apply masking tape to window and outside mating skin or fairing. If window is already masked, or otherwise protected, peel off the protective coating in areas to be in contact with the sealant.

b. Clean both surfaces thoroughly. Acrylic materials should be cleaned with Aliphatic Naphtha (TT-N-95, Type II) and a clean lint-free cloth.

NOTE

Do not use ketone or any cleaner that may cause crazing of the acrylic type glass.

CAUTION

Windows are of acrylic materials and must be sealed with Type II sealant, which uses a NONCRAZING accelerator.

c. Apply sealant to surfaces as required, consistent with the type of sealing.

- d. Assemble mating surfaces allowing the sealant to extrude out the edge of the skin or fairing. Complete assembly using the appropriate fasteners and dabbing sealant into the dimpled or countersunk hole.
- e. Fair extruded sealant over the edge of the masking tape.
- f. After sealant is cured, remove masking tape.

18-81. ELECTRICAL SEALING. When the wire bundles are continuous and pass through a pressurized bulkhead, they should be sealed in accordance with one of the following alternate methods using the S45 nylon seal fitting.

a. Injection Method.

1. Clean the metal area where the seal fitting will seat. Clean the wires and seal fittings with Moxel solvent #18.

2. Pass the wire bundle through the bulkhead cutout and secure, leaving approximately two inches of slack.




Figure 18-9. Window Sealing

MODEL P210 SERIES SERVICE MANUAL

3. Bundle ties must not be placed within six inches of the seal assembly to facilitate penetration of sealant around individual wires.
4. Place the seal halves around the wire bundle on the pressure side and position in bulkhead cutout.
5. Wrap several turns of masking tape around the seal assembly ends and the wire bundle to center the bundle and retain the sealant when applied.
6. Secure the seal assembly to the bulkhead with the required fasteners
7. Puncture the tape over the injection hole in the fitting.
8. Injection sealant should be 93-004 Aerospace Sealant and should be used toward the beginning of its work life (freshly mixed) to obtain a good flow throughout the fitting and between wires leaving no voids.
9. Inject sealant using a sealant gun at a pressure of approximately 100 psi until the sealant, without visible evidence of entrapped air, emerges from both notches in the outer periphery of the seal assembly mounting flanges.
10. Remove excess sealant which extrudes from the seal assembly mounting flanges.
11. Remove the masking tape after the sealant has cured.
 - b. Pre-Pack Method.
 1. Accomplish steps 1 through 4 of injection method.

2. Place seal fitting halves around the wire bundle on the pressure side of the bulkhead.
3. Wrap several turns of masking tape around the seal assembly on the far end only to center the bundle and retain the sealant when applied.
4. Hold the seal assembly in a vertical position with the open end up and inject sealant in around the wires. Remove and reinject the nozzle at several locations within and around the bundle to fill all the voids between the wires and around the wires and the seal assembly.
5. Wrap the open end of the seal assembly with masking tape to center the bundle and retain the sealant.
6. Lay a heavy bead of sealant within the flange of the fitting so that when placed against the bulkhead, some would be extruded between the fitting and bulkhead.
7. Position fitting in the cutout and secure with the required fasteners.
8. Remove any excessive sealant which extrudes from the seal assembly mounting flanges.

18-82. ADDING WIRES TO WIRE BUNDLE.
Additional wires, approximately 18 inches in length have been added to the wire bundles at the firewalls, wing roots, etc., where additional wiring may be necessary.




Figure 18-10. Electrical Sealing

MODEL P210 SERIES SERVICE MANUAL




Figure 18-11. Over Structure Repair of Pressure Cabin

MODEL P210 SERIES SERVICE MANUAL




Figure 18-12. Typical Stringer Repair

MODEL P210 SERIES SERVICE MANUAL




Figure 18-13. Typical Stringer to Bulkhead Repair

MODEL P210 SERIES SERVICE MANUAL






Figure 18-14. Typical Cabin Skin Crack Repair

MODEL P210 SERIES SERVICE MANUAL

NOTE

* DOUBLER OF SAME GAUGE AND MATERIAL AS BULKHEAD



TYPICAL REPAIR OF CRACKED BULKHEAD



Figure 18-15. Typical Cabin Bulkhead Repair (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 18-15. Typical Cabin Bulkhead Repair (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 18-16. Typical Insert Patch in Pressure Cabin

MODEL P210 SERIES SERVICE MANUAL






Figure 18-17. Typical Circular Hole Skin Repair in Pressure Cabin

MODEL P210 SERIES SERVICE MANUAL


PATCHES AND DOUBLERS —
2024-T3 ALCLAD



PATCH REPAIR FOR 3 INCH DIAMETER HOLE



PATCH REPAIR FOR 2 INCH DIAMETER HOLE



PATCH REPAIR FOR 1 INCH DIAMETER HOLE






Figure 18-18. Skin Repair (Sheet 1 of 6)

MODEL P210 SERIES SERVICE MANUAL



SECTION THRU ASSEMBLED PATCH

A-A




- ORIGINAL PARTS
- REPAIR PARTS
- REPAIR PARTS IN CROSS SECTION

OVERLAPPING REC-TANGULAR PATCH

RIVET TABLE	
SKIN GAGE	RIVET DIA.
.020	1/8
.025	1/8
.032	1/8
.040	1/8
.051	5/32

Figure 18-18. Skin Repair (Sheet 2 of 6)


MODEL P210 SERIES SERVICE MANUAL



SECTION THRU ASSEMBLED PATCH

NOTE

For optimum appearance and airflow, use flush rivets, dimpled skin and patch and counter-sunk doubler.



- ORIGINAL PARTS
- REPAIR PARTS
- REPAIR PARTS IN CROSS SECTION

**FLUSH RECTANGULAR PATCH
(CIRCULAR FLUSH PATCH IS
SIMILAR)**

RIVET TABLE	
SKIN GAGE	RIVET DIA.
.020	1/8
.025	1/8
.032	1/8
.040	1/8
.051	5/32

Figure 18-18. Skin Repair (Sheet 3 of 6)

MODEL P210 SERIES SERVICE MANUAL




Figure 18-18. Skin Repair (Sheet 4 of 6)

MODEL P210 SERIES SERVICE MANUAL




Figure 18-18. Skin Repair (Sheet 5 of 6)

MODEL P210 SERIES SERVICE MANUAL




Figure 18-18. Skin Repair (Sheet 6 of 6)

MODEL P210 SERIES SERVICE MANUAL




Figure 18-19. Rib Repair (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 18-19. Rib Repair (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL




Figure 18-20. Wing Spar Repair

MODEL P210 SERIES SERVICE MANUAL

NOTES:

1. Dimple leading edge skin and filler material; countersink the doubler.
2. Use MS20426AD4 rivets to install doubler.
3. Use MS20426AD4 rivets to install filler, except where bucking is impossible. Use CR162-4 Cherry (blind) rivets where regular rivets cannot be bucked.
4. Contour must be maintained; after repair has been completed, use epoxy filler as necessary and sand smooth before painting.
5. On cantilever wing, vertical size is limited by ability to install doubler clear of front fuel spar or stringers outboard of spar. On flaps and ailerons, vertical size is limited by ability to install doubler clear of front spar. (Also refer to figure 18-9.)
6. Lateral size is limited to seven inches across trimmed out area.
7. Number of repairs is limited to one in each bay. On cantilever wings, consider a bay in the area forward of front fuel spar as if ribs extended to leading edge.




Figure 18-21. Leading Edge Repair

MODEL P210 SERIES SERVICE MANUAL




Figure 18-22. Flap Leading Edge Repair

MODEL P210 SERIES SERVICE MANUAL




Figure 18-23. Firewall Angle Repair

MODEL P210 SERIES SERVICE MANUAL

SECTION 19

PAINT

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
MATERIALS	3E7/19-1	Prepainting	3E8/19-2
Facility	3E8/19-2	Painting	3E9/19-3
APPLICATION	3E8/19-2	Overall	3E9/19-3
Clean-Up	3E8/19-2	Masking	3E9/19-3
Prepriming	3E8/19-2	Touch-Up	3E9/19-3
Priming	3E8/19-2	Repair of Dents	3E9/19-3

NOTE

This section contains a listing of standard factory materials, and shows the area of their application. To determine the paint number and color, refer to the aircraft trim plate and Parts Catalog. In all cases, determine the type of paint, because some types are not compatible with others. Materials can be obtained from the Cessna Supply Division.

19-1. MATERIALS LISTING.

IMRON MODIFIED URETHANE

MATERIAL	NO/TYPE	AREA OF APPLICATION
PAINT	IMRON ENAMEL	Used as corrosion proof topcoat
	IMRON 192S Activator	Catalyst for Imron Enamel
PRIMER	WASH PRIMER 2655 (Sterling)	Used to prime aircraft for Imron Enamel
REDUCER/ THINNER	IMRON Y8485S Reducer	Used to thin Imron Enamel
	Catalyst Reducer 2265 (Sterling)	Used to reduce 2655

SUPPORT MATERIALS

MATERIAL	NO/TYPE	AREA OF APPLICATION
STRIPPER	Strypeeze Stripper	Used to strip primer overspray
CLEANER	Form Tech AC	Used to clean aircraft exterior and to remove grease, bug stains, etc.
	Klad Polish	Used to clean aluminum finish
	808 Polishing Compound	Used to rub out overspray
SOLVENT	(MEK) Methyl Ethyl Ketone	Used to tack aircraft prior to topcoat
CLOTH	HEX Wiping Cloth	Used with solvent to clean aircraft exterior
FILLER	White Streak	Used to fill small dents
MASKING	Class A Solvent Proof Paper	Used to mask areas not to be painted
	Tape Y218	Used for masking small areas
	Tape Y231	Used for masking small areas

NOTE

Do not paint pitot tube, gas caps, or aileron gap seals. Also do not paint antenna covers which were not painted at the factory.

MODEL P210 SERIES SERVICE MANUAL

19-2. **FACILITY.** Painting facilities must include the ability to maintain environmental control; temperature at 65°F., and a positive pressure inside to preclude the possibility of foreign material damage. All paint equipment must be clean, and accurate measuring containers available for mixing protective coatings. Modified Urethane has a pot life of four to eight hours, depending on ambient temperature and relative humidity. Use of approved respirators while painting is a must, for personal safety. All solvent containers should be grounded to prevent static build-up. Catalyst materials are toxic, therefore, breathing fumes or allowing contact with skin can cause serious irritation. Material stock should be rotated to allow use of older materials first, because its useful life is limited. All supplies should be stored in an area where temperature is higher than 50°F., but lower than 90°F. Storage at 90°F is allowable for no more than sixty days providing it is returned to room temperature for mixing and use.

Modified urethane paint requires a minimum of seven days to cure under normal conditions, if humidity and temperature is lower, curing time will be extended a maximum of 14 days. During the curing period, indiscriminate use of masking tape, abrasive polishes, or cleaners can cause damage to finish. Desirable curing temperature for modified urethane is 60°F. for a resulting satisfactory finish.

19-3. APPLICATION.

19-4. CLEAN UP.

a. Inspect airplane for any surface defects, such as dents or unsatisfactory previous repairs, and correct according to Paragraph 19-11.

b. Wipe excess sealer from around windows and skin laps, using Form Tech AC. Mask windows. ABS parts and other areas not to be primed, with 3M tape and Class A Solvent-Proof Paper. Care must be exercised to avoid cuts, scratches or gouges by metal objects to all plexiglass surfaces, because cuts and scratches may contribute to crazing and failure of plexiglass windows.

c. Methyl Ethyl Ketone (MEK) solvent should be used for final cleaning of airplanes prior to painting. The wiping cloths shall be contaminant and lint free HEX. Saturate cloth in the solvent and wring out so it does not drip. Wipe the airplane surface with the solvent saturated cloth in one hand, and immediately dry with a clean cloth in the other hand. It is important to wipe dry solvent before it evaporates.

NOTE

Do not use MEK on plexiglass as crazing will result.

When an airplane has paint or zinc chromate overspray on the exterior, stripper may be used to remove the overspray. The stripper may be applied by brush and will require a few minutes to soften the overspray. Heavy coatings may require more than one application of the stripper. Use extreme care to prevent stripper from running into faying surfaces on corrosion proofed airplanes. After removal of the

overspray, clean the airplane with Methyl Ethyl Ketone (MEK) solvent in the prescribed manner.

NOTE

It is imperative that clean solvent be used in cleaning airplanes. Dispose of contaminated solvent immediately. Fresh solvent should be used on each airplane.

WARNING

Use explosion proof containers for storing wash solvents and other flammable materials.

19-5. PREPRIMING.

a. Corrosion proofed and standard aircraft will receive Sterling Wash Primer 2655, DuPont Imron Enamel for over all color, and for stripes.

b. Mix 1 part 2655 primer with 1 1/2 parts 2265 Catalyst Reducer, by volume. Mix in stainless steel or lined containers only. After mixing allow primer to set for 30 minutes before spraying. Pot life of the mixed primer is six (6) hours, all mixed materials should be discarded if not used within that time limit. Pot pressure during spraying should be approximately 10 ± 1 psi. Air pressure should be 40 to 50 psi at the gun. Blow loose contaminant off the airplane with clean, dry air. Check all tapes to make sure they adhere properly. Cover the flap tracks, nose gear strut tube, wheels, and shimmy dampener rod ends. ABS parts and other preprimed parts do not receive wash primer.

WARNING

AIRCRAFT SHOULD BE GROUNDED PRIOR TO PAINTING TO PREVENT STATIC ELECTRICITY BUILD-UP AND DISCHARGE.

19-6. PRIMING.

a. Apply primer in one wet even coat. Dry film thickness to be .0003 to .0005 inches. Do not topcoat until sufficiently cured. When scratching with firm pressure of the fingernail does not penetrate the coating, the primer is cured. Primer should be topcoated within four hours after application.

19-7. PREPAINTING.

a. On standard aircraft mix the required amount of Imron with Imron 192S Activator in a 3 to 1 ratio by volume. Mix thoroughly, and begin spraying immediately, because there is no induction time requirement. Imron can be thinned to spraying viscosity with Y8485S Imron Reducer. Viscosity should be checked and adjusted after four hours if necessary.

b. When applying modified urethane finishes, the painter should wear an approved respirator, which has a dust filter and organic vapor cartridge, or an air supplied respirator. All modified urethane finishes contain some isocyanate, which may cause irritation to the respiratory tract or an allergic reaction.

MODEL P210 SERIES SERVICE MANUAL

Individuals may become sensitized to isocyanates.

c. The pot life of the mixture is approximately 6-8 hours at 75°F. Pot pressure should be approximately 12 psi during application. Air pressure at the gun should be 40 to 50 psi.

d. Scuff sand the primer only where runs or dirt particles are evident. Minor roughness or grit may be removed by rubbing the surface with brown Kraft paper which has been thoroughly wrinkled. Unmask ABS and other preprimed parts and check tapes. Clean surface with a jet of low pressure-dry air.

19-8. PAINTING OVERALL.

a. Complete painting of the plane should be done with 2 or 3 wet, even coats. Dry coats will not reflow, and will leave a grainy appearance.

b. Allow 5 minute period for the finish to flash off before moving aircraft to the oven.

c. Move to the force dry oven and dry for approximately 1 1/2 hours at 120°F to 140°F.

d. Dry film thickness of the overall color should be between 1.3 and 2.0 mils, over 5.0 mils requires Control Surface Balance Check. (Refer to Section 18).

19-9. MASKING FOR STRIPES.

a. Remove airplane from the oven. Allow airplane to cool to room temperature before masking.

b. Mask stripe area using 3M Tape Y231 or 3M Tape Y218 and Class A solvent proof paper. Double tape all skin laps to prevent blow by.

c. Airplanes which will have a stripe only configuration shall be masked, cleaned, and primed, in stripe area only.

d. If the base coat is not over 72 hours old, the stripe area does not require sanding. If sanding is necessary because of age or to remove surface defects, use #400 or #600 sandpaper. Course paper will leave sand marks which will decrease gloss and depth of gloss of the finish. The use of power sanders should be held to a minimum, if used, exercise care to preclude sanding through the white base coat. Wipe surface to be striped with a tack cloth and check all tapes.

e. Stripe colors on Imron base coat will be Imron Enamel. Mix as outlined in paragraph 19-6.

f. Painting of the stripe should be done with 2 or 3 wet-even coats. Dry coats will not reflow, and will leave a grainy appearance. Stripes may be force dried or air dried. Film thickness of a stripe is approximately 1.0 mil.

g. Do not remove masking tape and paper until the paint has dried to a "dry to touch" condition. Care should be exercised in removal of the masking to prevent damage to the finish.

h. Modified urethane finishes are sensitive to moisture, therefore, should be stored out of rain until cured.

19-10. TOUCH UP.

When necessary to touch up or refinish an area, the defect should be sanded with #400 and followed by #600 sandpaper. Avoid, if possible, sanding through the primer. If the primer is penetrated over an area 1/2 inch square or larger, repriming is necessary. Avoid spraying primer on the adjacent paint as much as possible. Since urethane finishes cannot be "spotted in" repairs should be in sections extending to skin laps or stripe lines.

a. Dry overspray and rough areas may be compounded out with DuPont #808 rubbing compound.

b. Grease, bug stains, etc. may be removed from painted surfaces with Form Tech AC. Klad Polish may be used on bare aluminum to remove stains, oxides, etc.

c. Rework areas, where paint or primer removal is required, may be stripped with Strypeeze Paint Removal. All traces of stipper must be removed before refinishing.

19-11. REPAIR OF DENTS.

a. To repair dents use White Streak Filler or equivalent. Mix White Streak in the correct proportion as recommended by the manufacturer.

b. Do not apply White Streak Filler over paint. All paint shall be removed in the repair area and the aluminum surface sanded lightly to increase adhesion. Apply the White Streak to a level slightly above the surrounding skin. After drying for 10 - 15 minutes, sand the filler flush with the skin surface, using care to feather the edges.

MODEL P210 SERIES SERVICE MANUAL

SECTION 20 WIRING DIAGRAMS

	Page No.		
TABLE OF CONTENTS	Aerofiche/Manual		
Circuit Function/Specific Circuit Code Letters	3E16/20-2	Dome, Courtesy, Baggage & Oxygen Lights	3G18/20-50B
D.C. POWER		Dome, Courtesy, Baggage & Oxygen Lights	3G19/20-51
Ground Service	3E18/20-4	Flood Light	3G20/20-52
Battery Circuit	3E19/20-5	Console/Compass Lights	3G21/20-53
Alternator System-60 AMP	3E20/20-6	Console/Compass Lights	3G23/20-55
Dual Alternators	3E21/20-7	Vertical Tail Illumination Light	3G24/20-56
Dual Alternators	3E22/20-9	Flood, Engine Instrument & Radio Lights	3H1/20-56A
Dual Alternators	3F1/20-11	Flood, Instruments & Radio Lights	3H3/20-57
Battery Circuit with Dual Alternators	3F2/20-12	Map Light-Control Wheel	3H4/20-58
Alternator System-85 AMP	3F4/20-14	Internal Instrument Lighting	3H5/20-59
Circuit Breakers	3F5/20-15	Internal Instrument Lighting	3H6/20-60
Circuit Breakers	3F6/20-16	Landing Gear Control System	3H8/20-62
Volt-Ammeter	3F7/20-17	Landing Gear Control System	3H9/20-63
IGNITION		HEATING, VENTILATING & DE-ICING	
Magneto System	3F8/20-18	Light, Ice Detector	3H10/20-64
ENGINE CONTROLS		Windshield Anti-Ice System	3H11/20-65
Starter System	3F9/20-19	Prop De-Icing System, 3 Blade	3H12/20-66
FUEL AND OIL		Heated Pitot Tube/Heated Stall Warning-Known Icing	3H14/20-68
Fuel Pump System	3F10/20-20	Heated Pitot Tube/Heated Stall Warning-Known Icing	3H15/20-69
ENGINE INSTRUMENTS		Heated Pitot Tube/Heated Stall Warning-Known Icing	3H16/20-70
Hourmeter	3F12/20-22	Windshield Anti-Ice System Known-Icing	3H17/20-71
Hourmeter	3F13/20-23	Wing & Stabilizer De-Ice System-3 Cycle	3H18/20-72
Fuel Gages	3F14/20-24	Wing & Stabilizer De-Ice System-3 Cycle	3H19/20-73
Fuel Gages	3F15/20-25	Cabin Ventilation Blower	3H21/20-75
Fuel Gages with Long-Range Fuel Tanks	3F16/20-26	Air Conditioner	3H22/20-76
Fuel Totalizer/Clock	3F17/20-27	Air Conditioner	3H23/20-77
Oil Temp & Cyl Head Temp	3F18/20-28	Heated Pitot Tube/Heated Stall Warning System	3H29/20-78
Turbine Inlet Temp Gage	3F19/20-29	CONTROL SURFACE	
Indicator-EGT & Turbine Inlet Temp	3F20/20-30	Wing Flaps	3I1/20-79
FLIGHT INSTRUMENTS		Electric Elevator Trim	3I2/20-80
Turn Coordinator	3F21/20-31	Electric Elevator Trim	3I3/20-81
OTHER INSTRUMENTS		WARNING AND EMERGENCY	
Clock	3F22/20-32	Dual Warning System	3I5/20-83
Digital Clock	3F23/20-33	Dual Warning System	3I7/20-85
Ammeter	3F24/20-34	Dual Warning Unit	3I8/20-86
LIGHTING		Dual Warning Unit	3I9/20-87
Landing Lights	3G1/20-35	Low-Vacuum Warning Light	3I10/20-88
Navigation Lights	3G2/20-36	Cabin Pressure Dump Valve & Barometric Pressure Switch	3I11/20-89
Eyebrow Lights	3G3/20-37	Standby Vacuum Pump Model 210/P210	3I12/20-90
Wing Tip Strobe Lights	3G5/20-39		
Wing Tip Strobe Lights	3G6/20-40		
Wing Tip Strobe Lights	3G7/20-41		
Flashing Beacon Light	3G8/20-42		
Flashing Beacon Light	3D10/20-44		
Instruments Lights	3G11/20-45		
Instruments Lights	3G13/20-47		
Electroluminescent Panel	3G14/20-48		
Electroluminescent Panel	3G15/20-49		
Post Lighting (OPT)	3G16/20-50		
Post Lighting (OPT)	3G17/20-50A		

NOTE

Effectivity of diagrams are designated as follows: Eff thru (SRxxxx) denotes effectivity to the serial number prior to the (SRxxxx) serial. Ser (SRxxxx) & on denotes effectivity for the (SRxxxx) serial and on. Diagrams and/or portions of, may be individually serialized and not designated by a (SRxxxx) number.

MODEL P210 SERIES SERVICE MANUAL

CIRCUIT FUNCTION AND SPECIFIC CIRCUIT CODE LETTERS

- A - Armament
- B - Photographic
- C - Control Surface
 - CA - Automatic Pilot
 - CC - Wing Flaps
 - CD - Elevator Trim
- D - Instrument (Other Than Flight or Engine Instrument)
 - DA - Ammeter
 - DB - Flap Position Indicator
 - DC - Clock
 - DD - Voltmeter
 - DE - Outside Air Temperature
 - DF - Flight Hour Meter
- E - Engine Instrument
 - EA - Carburetor Air Temperature
 - EB - Fuel Quantity Gage and Transmitter
 - EC - Cylinder Head Temperature
 - ED - Oil Pressure
 - EE - Oil Temperature
 - EF - Fuel Pressure
 - EG - Tachometer
 - EH - Torque Indicator
 - EJ - Instrument Cluster
 - EK - Turbine Inlet Temperature
- F - Flight Instrument
 - FA - Bank and Turn
 - FB - Pitot Static Tube Heater and Stall Warning Heater
 - FC - Stall Warning
 - FD - Speed Control System
 - FE - Indicator Lights
- G - Landing Gear
 - GA - Actuator
 - GB - Retraction
 - GC - Warning Device (Horn)
 - GD - Light Switches
 - GE - Indicator Lights
- H - Heating, Ventilating and De-Icing
 - HA - Anti-icing
 - HB - Cabin Heater
 - HC - Cigar Lighter
 - HD - De-ice
 - HE - Air Conditioners
 - HF - Cabin Ventilation
- J - Ignition
 - JA - Magneto
- K - Engine Control
 - KA - Starter Control
 - KB - Propeller Synchronizer
- L - Lighting
 - LA - Cabin
 - LB - Instrument
 - LC - Landing
 - LD - Navigation
 - LE - Taxi
 - LF - Rotating Beacon
 - LG - Radio
 - LH - De-ice
 - LJ - Fuel Selector
 - LK - Tail Floodlight
 - LL - Recognition Lights
- M - Miscellaneous
 - MA - Cowl Flaps
 - MB - Electrically Operated Seats
 - MC - Smoke Generator
 - MD - Spray Equipment
 - ME - Cabin Pressurization Equipment
 - MF - Chem O₂ - Indicator
- P - D. C. Power
 - PA - Battery Circuit
 - PB - Generator Circuits
 - PC - External Power Source
 - PH - Anti-Ice Power Source
- Q - Fuel and Oil
 - QA - Auxilliary Fuel Pump
 - QB - Oil Dilution
 - QC - Engine Primer
 - QD - Main Fuel Pumps
 - QE - Fuel Valves
- R - Radio (Navigation and Communication)
 - RA - Instrument Landing
 - RB - Command
 - RC - Radio Direction Finding
 - RD - VHF
 - RE - Homing
 - RF - Marker Beacon
 - RG - Navigation
 - RH - High Frequency
 - RJ - Interphone
 - RK - UHF
 - RL - Low Frequency
 - RM - Frequency Modulation
 - RP - Audio System and Audio Amplifier
 - RR - Distance Measuring Equipment (DME)
 - RS - Airborne Public Address System
- S - Radar
- U - Miscellaneous Electronic
 - US - Identification - Friend or Foe
- W - Warning and Emergency
 - WA - Flare Release
 - WB - Chip Detector
 - WC - Fire Detection System
- X - A. C. Power

● "Dev+" and "Dev-" circuits are for use in Nav-o-matic 300 autopilots and any associated omni indicator circuit to which it connects.

MODEL P210 SERIES SERVICE MANUAL

CROSS REFERENCE LISTING OF SERIAL REQUEST NUMBERS LISTED ON DIAGRAMS VS. AIRCRAFT SERIAL NUMBERS.

SR.	AIRCRAFT SERIAL NO.	SR.	AIRCRAFT SERIAL NO.
SR6755	*21059503	SR9361	P21000151
SR7038	*21059720	SR9427	* P21062969, P21000120
SR7381	*21060090	SR9556	*21063953, *T21067300, & P21000405
SR7473	*21059882	SR9583	*21063547, P21000344
SR7486	*21029852	SR9634	*21064136
SR7650	*21060540	SR9635	P21000591
SR7913	*21061040	SR9711	*21064064, P21000535
SR7997	*21060526, *T21060544	SR9808	*21064110, P21000570
SR8115	*21061134	SR9860	*21064567, P21000772
SR8143	*21061574	SR9884	*21064150, P21000606
SR8297	*21061103	SR9953	*21064536
SR8298	*21061142	SR9954	P21000761
SR8426	*21061296	SR10101	*21064773
SR8464	*21062274	SR10102	P21000812
SR8465	P21000001 thru P21000150	SR10148	*21064198, P21000692
SR8482	*21061230	SR10250	*21064559, P21000771
SR8656	*21061627	SR10396	*21064773, P21000812
SR8863	*21062274 thru 21062593 P21000001 thru P21000150	SR10420	*21064895
SR8938	*21062250	SR10421	P21000835
SR9080	*21062699, P21000031	SR10563	*21064805, P21000822
SR9114	*21063641	SR10641	P21000835
SR9115	P21000386	SR10659	*21064904, P21000835
SR9187	*21062955, P21000151	SR10660	*21064904, P21000835
SR9221	*21063477, P21000345	SR10662	*21064898, P21000835
SR9310	*T21063641, P21000386	SR10680	P21000835
		SR10713	*21064904, P21000835
		SR10734	*21064904, P21000835
		SR10790	*21064898, P21000835
		SR10855	P21000864


*Not Applicable to P210

MODEL P210 SERIES SERVICE MANUAL

NOTES:

1 PLACE 35.00 IN LENGTH OF S-292-14 SLEEVING OVER WIRE BEFORE INSTALLING WIRE TERMINATION.

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD DETAIL A BLK (PA 40) S-2527(1 L-2) (SR10101)(SR10102)	MKT 1-27-82	JAS VHD JRS
B	BY REV: ADD S-2593-2 SWITCH (SR10101)(SR10102)	JWH 4-27-82	JRS



DETAIL A
THRU SER (SR10101)(SR10102)

02-00916
01-00916

PART NO.	DESCRIPTION	QUANTITY
8	S-2593-2 MASTER SWITCH	
7	S-2527-2 GND CONNECTOR	
6	S-2527-1 LH GND BLOCK	
5	S-2443-1 CONTACTOR	
4	S-1994-1-1 SWITCH	
3	S-2475-1 CONTACTOR	
2	0770728 DIODE ASSY	
1	C614001-0105 BATTERY ASSY	

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK (PA 40)	22	-22-0		S2099-4 S-1493-1	SR10101(SR10102)
PA 35	2	S-1562-2-9	52.3	S-1367-7-13 S-1367-7-13	
PA 32	2	S-1562-2-9	21.7	S-1367-7-12 S-1367-7-13	
PA 33	2	S-1562-2-9	10.9	S-2447-2 S-1367-7-13	
PA 17	22			S-1367-1-10 S-1493-1	
PA 6	22			S-1493-1 S-1367-1-8	THRU SER (SR10101)(SR10102)

CONTRACT NO:			WIRE TABLE		
DESIGN	NAME	DATE	Cessna AIRCRAFT CO.		
	TJADEN	1-22-80	PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS		
GROUP	W. H. H. H.	3-5-80	WIRING DIAGRAM - BATTERY CIRCUIT		
DRAWN	LEVERENZ	3-10-80	TITLE		
CHECK	BORLESKE	3-11-80	DESIGN		
STRESS			DRAWN		
PROJ	J. MOORE	3-27-82	SIZE	CODE IDENT. NO.	DWG NO
APPD	JRS		C	71379	1270709
OTHER			SCALE	NONE (SR 9634)	PAGE: 4-16

EQUIPMENT TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-1000 OR CN1000-CESNA STD. NO.	SUPERSEDES: 1270709 P 4 12 SUPERSEDED BY:


(SR 9635)

MODEL P210 SERIES SERVICE MANUAL

NOTES:

1. PART OF BASIC AVIONICS KIT

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV. ADD BLK(PB148) S-2527-1 & -2 & DETAIL A" (SR10101) (SR10102)	MKT 1-27-82	JAB:WHM APB
B	BY REV. ADD DETAIL B SER OUT PB 37 ADD S-2593-2 SWITCH (SR10101) (SR10102)	WHM 4-22-82	WHM APB



02-00916
01-00916

DETAIL 13
THRU SER(SR10101)
(SR10102)

DETAIL A
THRU SER(SR10101) (SR10102)

16	S-2593-2	MASTER SWITCH
15	S-2527-2	GND CONNECTOR
14	S-2527-1	LH GND BLOCK
13	S-1232-60	CIRCUIT BREAKER
12	C611005-0102	ALT CONTROL UNIT (ALTERNATE)
11	0570315	TERMINAL BOARD
10	S-1707-60	CIRCUIT BREAKER
9	S-1360-54	CIRCUIT BREAKER
8	MS25041-2	INDICATOR LIGHT
7	MS25237-327	LAMP
6	S-1994-1-1	MASTER SWITCH
5	S-1915-1	CAPACITOR
4	C611503-0102	ALTERNATOR ASSY
3	S-2373-2	CONNECTOR
2	S-2373-1	CONNECTOR
1	C611005-0101	ALT CONTROL UNIT

WIRE	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK(PB148)	22	-22-0		SOLDER	S-2099-4 SER(SR10101) (SR10102) ON
RED(PB87)	20	-20-2		S-2099-6	S-1493-1
YEL(PB86)	20	-20-4		SOLDER	S-2099-6
BLK(PB88)	16	-16-6		S-2099-8	S-1367-210
PB84	20			S-2099-6	S-1367-110
ORN(PB83)	20	20-3		S-2099-6	S-1367-1-4
PB82	8	S-1562-8-9		S-1943-1	S-2484-1
PB81	8	S-1562-8-9		S-1943-2	S-1943-1
PB67	8	S-1562-8-9		S-1943-2	S-1367-4-6
PB56	22			S-1367-1-6	SOLDER
PB46	22			SOLDER	S-1367-1-8 THRU SER(SR10101) (SR10102)
PB38	22			S-1367-1-6	S-1493-1
PB37	22			S-1367-1-6	S-1367-1-6 THRU SER(SR10101) (SR10102)

WIRE TABLE

PART NO.	DESCRIPTION
EQUIPMENT TABLE	

CONTRACT NO:		
DESIGN	NAME	DATE
ABRAHAM		3-31-80
GROUP	William Lee	3-3-80
DRAWN	S. BURRIS	3-31-80
CHECK	R.C. HAIR	3-31-80
STRESS		
PROJ	1270709	4-1-80
APPRO	APB	
OTHER		

Cessna AIRCRAFT CO.
 PAWNEE DIVISION
 3800 E. PAWNEE
 WICHITA, KANSAS

**WIRING DIAGRAM —
 ALTERNATOR SYSTEM
 60 AMP**

SCALE: NONE (SR 9634) (SR 9635) PAGE: 4-17

SIZE: C
 CODE IDENT. NO.: 71379
 DWG NO.: 1270709

CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-XXXX-CESBNA SPEC. NO.
 S-XXX OR CNXXXX-CESBNA
 STD. NO.

SUPERSEDES:
 1270709 PG. 4-9-0

SUPERSEDED BY:

MODEL P210 SERIES SERVICE MANUAL

REVISION				REVISION				
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD	
C	BY REV: ADD S2527-2, S2527-1, PB17, PB18, PB19, PB15, PB15, PB15, S2593-2 ADD PAGE 4.19.2 SER OUT PB112, PB113, PB128, PB129, PB141, PB142, PB143 (SR1010)(SR1010)	1-27-82 MK1 RNJ		A	BY REV: FN DAIS (REF) WAS FN-PB108 FN DA 4 (REF) WAS FN-PB107 FN-DA12 (REF) WAS FN-PB104 & FN-DA12 (REF) WAS FN-PB105. DELETE FN-DA12. FN-PB109 FN-PB105 & FN-PB107 WIRE FROM WIRE TABLE. FN-PB102 & PB103 WIRE FROM DELETED S2447-6. FN-PB112 & PB113 WIRES SOLDER WAS S2447-6. S1367-16 WAS S1367-16 ON PB128 & PB129 WIRE S1367-16. FN-DA12. ADD 2 CCA JUMPERS AT ALT. TEST START ON ON PB105 WIRE SOLDER WAS S2447-6. S1367-16 DELETE 217004 FROM EQUIPMENT TABLE (SR9953)(SR9954)	4-8-81 WHH		WHH RNJ
D	BY REV: ADD DETAIL "C" (SR1010)(SR1010)	4-22-82 WHH						
E	BY REV: FN-DA22 (REF) WAS FN-DA4 (REF) FN-DA22 (REF) WAS FN-DA15 (REF) FN-DA25 (REF) WAS FN-DA12 (REF) FN-DA25 (REF) WAS FN-DA15 (REF) R-6 K1 (SR1073A)	WHH 01-83		B	BY REV: ADD NUM OF KTS ON TERMINALS/ MS25041-2 & MS25041-4. ADD MS25041-4; PB117/S1367-16 WAS S2099-4, PB135/S1367-16 WAS SOLDER (SR9953)(SR9954)	16-51 MKT 10-6-81	WHH RNJ	
F	SEE PAGE 4.19.2 FOR REVISIONS							

▷ TO AMMETER SEL SW

21	S2593-2	SWITCH							
20	S2527-2	GND CONNECTION							
19	S2527-1	LN GND BLOCK							
18	MS25041-4	LIGHT ASSY							
17	2101055	BATTERY ASSY							
16	MS25237-327	LAMP							
15	MS25041-2	LIGHT ASSY							
14	S2349-1	CONNECTOR							
13	C611007-0101	ALT CONTROL UNIT							
12	S1790-2-1	SWITCH							
11	C611503-0104	ALTERNATOR							
10	S2035-2	PLUG							
9	32-0057	RESISTOR							
8									
7	S1830-1	SWITCH							
6	20H3P	DIODE							
5	S2558-1	SHUNT							
4	2170027	BUS BAR							
3	S1360-5L	CKT BREAKER							
2	S1232-60	CKT BREAKER							
1	S2475-1	CONTACTOR							
	PART NO.	DESCRIPTION							
EQUIPMENT TABLE									
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESBNA SPEC. NO. S-XXX OR CXXXX-CESBNA STD. NO.			SUPERSEDES:		WIRE TABLE CONTRACT NO: NAME: Cessna AIRCRAFT CO. DATE: DESIGN TITLE: GROUP: <i>011111</i> DATE: <i>3-24-81</i> DRAWN: <i>ACKERSON</i> DATE: <i>3-24-81</i> CHECK: <i>BORLESKE</i> DATE: <i>3-24-81</i> STRESS: PROJ: <i>...</i> APPD: <i>...</i> OTHER:				
			SUPERSEDED BY:						
			SIZE: C	CODE IDENT. NO.: 71379	DWG NO.: 1270709		PAVNEE DIVISION 3800 E. PAVNEE WICHITA, KANSAS		
			NONE (SR9953)(SR9954) PAGE: 4.19.0						


MODEL P210 SERIES SERVICE MANUAL

PB165	20			S1367-12	S2099-4	SER(SR10680TSR10420) ON
PB164	20			S1367-10	S2099-4	SER(SR10680TSR10420) ON
PB163	185			S1943-4	S2099-4	SER(SR10680TSR10420) ON
PB162	6			S2AAT-6	S1367-5-12	SER(SR10680TSR10420) ON
BLK(PB157)	22	-22-0		SOLDER	S2099-4	SER(SR1000)(SR1002) ON
BLK(PB156)	22	-22-0		SOLDER	S2099-4	SER(SR1000)(SR1002) ON
BLK(PB155)	22	-22-0		SOLDER	S2099-4	SER(SR1000)(SR1002) ON
BLK(PB146)	20			S1367-10	S1367-12	SER(SR10680) & ON
PB150	20			S1493-1	S2099-4	SER(SR1000)(SR1002) ON
PB149	20			S1493-1	S2099-4	SER(SR1000)(SR1002) ON
PB148	20			SOLDER	S1493-1	SER(SR1000)(SR1002) ON
PB147	20			SOLDER	S1493-1	SER(SR1000)(SR1002) ON
PB146	6			S1943-4	S1943-5	
PB145	20			SOLDER	SOLDER	
PB144	20			S1361-1-8	SOLDER	
PB143	22			SOLDER	S1367-1-8	THRU SER(SR1010)(SR1002)
PB142	22			SOLDER	S1367-1-8	THRU SER(SR1010)(SR1002)
PB141	22			SOLDER	S1367-1-8	THRU SER(SR1010)(SR1002)
PB140	22			SOLDER	S2099-4	
PB139	22			SOLDER	SOLDER	
PB138	22			SOLDER	SOLDER	
PB137	22			S2099-4	SOLDER	
PB136	22			S2099-4	SOLDER	
PB135	22			S2099-4	S1367-1-6	
PB134	20			S2099-4	S1367-1-8	
PB133	20			S1367-1-8	S2099-4	
PB132	20			S2099-4	S2099-4	
PB131	20			S2099-4	S2099-4	
PB130	20			S2099-4	S2099-4	
PB129	20			S1367-1-6	S2099-4	THRU SER(SR1000)(SR1002)
PB128	20			S1367-1-6	S2099-4	THRU SER(SR1000)(SR1002)
PB127	185			S1943-4	S2099-4	
PB126	20			S1367-1-8	S2099-4	
PB125	20			S1367-1-10	S2099-4	

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
WIRE TABLE					
CONTRACT NO:			PAWNEE DIVISION 3600 E. PAWNEE WICHITA, KANSAS		
NAME		DATE		Cessna AIRCRAFT CO.	
DESIGN	TITLE		WIRING DIAGRAM — DUAL ALTERNATOR		
GROUP	3-24-81				
DRAWN	ACKERSON 3-24-81				
CHECK	BORLESKE 3-24-81				
STRESS					
PROJ	SIZE	CODE IDENT. NO.	DWG NO.		
APPD	C	71379	1270709		
OTHER	PAGE: 4-19-0				

MODEL P210 SERIES SERVICE MANUAL

See Sheet 1



See Sheet 1


1	1	FIELD EXCITATION
2	2	+REMOTE SENSE
3	3	+POWER IN
4	4	LOW VOLT ANNUN
5	5	-REMOTE SENSE
6	6	ALT OFF ANNUN
7	7	ALT OFF SENSE
8	8	LOW VOLT SENSE
9	9	LINE CONTACTOR
10	10	-CURRENT SENSE
11	11	EQUALIZER
12	12	POWER GND

CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE					
GROUP	<i>W. J. Hadden</i>	<i>3-24-51</i>	WIRING DIAGRAM - DUAL ALTERNATOR					
DRAWN	<i>ACKERSON</i>	<i>3-24-51</i>						
CHECK	<i>BORLESKE</i>	<i>3-24-51</i>						
STRESS								
PROJ	<i>74.11002/A</i>	<i>1-25-51</i>	SIZE	CODE IDENT. NO.	DWG NO.			
APPO	<i>pb</i>	<i>3/26</i>	C	71379	1270709			
OTHER			SCALE: NONE			PAGE: 9.19.1		


Dual Alternator (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL


REVISION			
LET	DESCRIPTION	DATE	APPD
F	BY REV: ADD DETAILS "D" & "E" (SR10420) & (SR10680)	UWAH 10-1-84	REH WOOD JRS M
G	BY REV: ADD FF166 REF (SR10420) (SR10680)	TMS 2-26-85	LEH WOOD MRS G




DETAIL A
THRU SER (SR 10101) (SR 10102)




DETAIL B
THRU SER (SR 10101) (SR 10102)




DETAIL C
THRU SER (SR10101) (SR10102)



DETAIL D
APPLIES TO P210
SER (SR10680) & ON
APPLIES TO T210
SER (SR10420) & ON



DETAIL E
APPLIES TO P210
SER (SR 10680) & ON
APPLIES TO T210
SER (SR 10420) & ON



CONTRACT NO:			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	Cessna AIRCRAFT CO.		
GROUP	W. H. H. H. H.	3-30-82	TITLE WIRING DIAGRAM DUAL ALTERNATOR		
DRAWN	M. THOMPSON	1-27-82	SIZE		
CHECK	BOKLESKE	1-28-82	CODE IDENT.		
STRESS			DWG NO		
PROJ	J. H. H. H. H.	3-30-82	C 71379 - 1270709		
APPD	J. H. H. H. H.		SCALE: NONE		
OTHER			(SR10101) (SR10102) PAGE: 4.19.2		

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: FN-PA38 WAS FN-PA17(REF) FN-PA39 WAS FN-PA6(REF) (SR9953)(SR9954)	WHH 4-9-81	REH JRS
B	BY REV: S-2558-2 WAS S-2558-1 ADD FN-PB117 BATTERY SHUNT (SR9953)(SR9954)	MKT 10-6-81	REH JRS
C	BY REV: ADD DETAIL 'A' S2527-2, S2527-1, BLK(FN-PA44); SER OUT FN-PA39, FN-PA38, S1790-1; ADD S2593-2, FN-PA17 (SR1010)(SR1010Z)	MKT 1-27-82 RNJ	REH JRS
D	BY REV: CHANGE PICTURE OF S-2593-2 MASTER SWITCH TO SHOW PROPER LOCATION OF WTI PALT 2. (SR1010)(SR1010Z)	WHH 4-27-82	REH JRS
E	BY REV: ADD DETAIL 'B' & 'C' CIRCUIT BREAKER (SR1010)(SR1010Z)	WHH 5-26-82	REH JRS
F	BY REV: DA17(REF) WAS DA16(REF); DA16(REF) WAS DA17(REF); FUSE WAS RESISTOR TO CONNECTION 2 OF S-2558-2 (SR9953)(REF)(SR9954)(REF)	GLS 7-14-82	REH JRS
G	BY REV: FN-DA20(REF) WAS FN-DA17(REF) FN-DA21(REF) WAS FN-DA16(REF) (SR10734)	WHH 10-17-83	REH JRS

08 000716 116000 04


10	S-2593-2	MASTER SWITCH
9	S2527-2	GND CONNECTOR
8	S2527-1	LH GND BLOCK
7	S-2558-2	SHUNT BATTERY
6	S-1232-60	CIRCUIT BREAKER
5	S-2443-1	CONTACTOR
4	S-1790-1	MASTER SWITCH
3	S-2475-1	CONTACTOR
2	071072B	DIODE ASSY
1	CG14001-0109	BATTERY ASSY

FN-PA17	22		S1367-10	S-1493-1	SER(SR1010)(SR1010Z) CON
FN-PA39	22	-22-0	S1367-16	S2099-4	SER(SR1010)(SR1010Z) CON
FN-PA38	22		S1367-16	S1367-18	THRU SER(SR1010)(SR1010Z)
FN-PA37	G	S-1562-6-9	S1367-110	S1367-16	
FN-PA36	G	S-1562-6-9	S1367-513	S1367-512	

PART NO.	DESCRIPTION
EQUIPMENT TABLE	

WIRE TABLE					
WIRE CODE NO.	G.A.	MATERIAL	LG	TERMINALS	SERIALS
CONTRACT NO:					
DESIGN			NAME		
GROUP			DATE		
DRAWN			TITLE		
CHECK			WIRING DIAGRAM -		
STRESS			BATTERY CIRCUIT-OPT		
PROJ			(WITH DUAL ALTERNATORS)		
APPO			SIZE		
OTHER			CODE IDENT. NO.		
			DWG NO		
			C 71379 1270709		
			NONE SR9953(SR9954) page: 4 21		

MODEL P210 SERIES SERVICE MANUAL




CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE					
GROUP	<i>W. J. H. J.</i>	<i>3-24-51</i>	WIRING DIAGRAM —					
DRAWN	<i>JARDEN</i>	<i>3-24-51</i>	BATTERY CIRCUIT—OPT					
CHECK	<i>DORLES</i>	<i>3-29-51</i>	(WITH DUAL ALTERNATORS)					
STRESS			SIZE	CODE IDENT. NO.	DWG NO			
PROJ	<i>J. H. H. COLE</i>	<i>3-21-51</i>	C	71379	1270709			
APPD	<i>SKK</i>		NONE			62953 (SR95A) PAGE: 4 21		
OTHER								

MODEL P210 SERIES SERVICE MANUAL

NOTES:

- 1 PART OF BASIC AVIONICS KIT
- 2 PB63 WIRE USED ON P210 ONLY AFTER SER (SR1000)
- 3 PB91 WIRE USED ON 210 & 210 SER (SR1000) & ON

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: ADD DETAIL A # S-2593-2 SWITCH (SR1001)(SR1012)	WHH 4-22-82	REL JRG
B	BY REV: BLU (PB92) WAS BLU (PB87) (SR9953)(REF)(SR9954)(REF)	GLS 9-4-82	REL JRG



02-00916
01-00916

DETAIL A
SER (SR1010)(SR1012)

6	S-2593-2	MASTER SWITCH						
15	S-2527-2	GND CONNECTOR						
14	S-2527-1	LH GND BLOCK						
13	C611005	ALT CONTROL UNIT (ALTERNATE)	PB91	4	S-1562-4-9	S-2402-2	S-2402-2	<3
12	0570315	TERMINAL BOARD	BLU (PB92)	18	-18-6	S-2099-8	S-2376-1	
11	S-2326-1	CIRCUIT BREAKER	PB66	4	S-1562-4-9	S-1367-6-12	S-1367-6-10	
10	S-1360-5L	CIRCUIT BREAKER	PB65	4	S-1562-4-9	S-2402-2	S-2402-1	
9	S-1994-1-1	MASTER SWITCH	PB63	4	S-1562-4-9	S-2402-2	S-2402-2	<2
8	MS25091-2	INDICATOR LIGHT	PB62	4	S-1562-4-9	S-2402-2	S-1367-6-12	
7	MS25237-327	LAMP						
6	S-1915-1	CAPACITOR						
5	D20844409-KA	CONNECTOR						
4	C611505	ALTERNATOR ASSY						
3	S-2373-2	CONNECTOR						
2	S-2373-1	CONNECTOR						
1	C611005	ALT CONTROL UNIT						

WIRE TABLE

CONTRACT NO:			NAME		DATE
DESIGN			GROUP		DATE
DRAWN			CHECK		DATE
STRESS			OTHER		

Cessna AIRCRAFT CO.
 PAWNEE DIVISION
 5800 E. PAWNEE
 WICHITA, KANSAS

TITLE
**WIRING DIAGRAM --
 ALTERNATOR SYSTEM
 95 AMP (OPT)**

CES1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-XXXX-CESSNA SPEC. NO.
 S-XXX OR CMXXXX-CESSNA
 STD. NO.

SUPERSEDED BY:
 1270709 P4.10


SUPERSEDED BY:

PROJ J.H. MORSE 5/4/82
 APPD JRG
 OTHER

SIZE C
 CODE IDENT NO 71379
 DWG NO 1270709
 MATERIAL NONE (SR1010)(SR1012) PAGE: 4, 22

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD



DETAIL **A**
 APPLIES WITH 95 AMP ALT SYSTEM (OPT)

07-00816


CONTRACT NO.		PAWNEE DIVISION 3900 E. PAWNEE WICHITA, KANSAS	
NAME	DATE	Cessna AIRCRAFT CO.	
DESIGN	WARDEN 4-23-82	TITLE	
GROUP	W. H. Anderson 4-23-82	WIRING DIAGRAM -	
DRAWN	M. THOMPSON 4-28-82	CIRCUIT BREAKERS	
CHECK	R. YOUNGERS 4-28-82		
STRESS			
PROJ	... 4-29-82	SIZE	CODE IDENT
APPD	RS	C	71379
OTHER		DWG NO.	1270709
		SCALE	NONE
		(SR1010)(SR10102)	PAGE 4.23.1

MODEL P210 SERIES SERVICE MANUAL

NOTES:

- 1 APPLIES TO P210 ONLY
- 2 S-1360-15L CKT BKR REQD WITH KNOWN ICING W/ICE SYSTEM
- 3 S-1360-10L CKT BKR REQD WITH KNOWN ICING PITOT HEAT SYSTEM & STALL WARN HEAT SYSTEM.
- 4 WIRE CUT LENGTH TOLERANCE OF ± .10 INCH MUST BE MAINTAINED. REFER TO WIRE TABLE FOR PB158, PB159, PB160, AND PB161 WIRE LENGTHS.

REVISION			
LET	DESCRIPTION	DATE	APPD
A	SEE PG 4.23.0 FOR REV		



PART NO.	DESCRIPTION	QTY	WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
11	2170035	BUS BAR						
10	S-1232-35	CIRCUIT BREAKER	FN-PB161	10	S-1562-10-9	6.25	S-1367-3-6	S-1367-3-6 (OPT)
9	M525306-222	SWITCH	FN-PB159	10	S-1562-10-9	8.0	S-1367-3-6	S-1367-3-6 (OPT)
8	S-2326-1	CIRCUIT BREAKER	FN-PB158	10	S-1562-10-9	8.0	S-1367-3-6	S-1367-3-6 (OPT)
7	S-1360-20L							
6	S-1232-60							
5	S-1232-15							
4	S-1232-5							
3	S-1232-2							
2	S-1360-10L							
1	S-1360-5L	CIRCUIT BREAKER						

PART NO.	DESCRIPTION
11	2170035 BUS BAR
10	S-1232-35 CIRCUIT BREAKER
9	M525306-222 SWITCH
8	S-2326-1 CIRCUIT BREAKER
7	S-1360-20L
6	S-1232-60
5	S-1232-15
4	S-1232-5
3	S-1232-2
2	S-1360-10L
1	S-1360-5L CIRCUIT BREAKER

WIRE TABLE

CONTRACT NO: _____

Cessna AIRCRAFT CO. PAWNEE DIVISION
3800 E. PAWNEE WICHITA, KANSAS

DESIGN: _____ NAME: _____ DATE: _____

GROUP: (W.H. Hender) 8-23-82

DRAWN: G. STAMM 8/20/82

CHECK: R. YOUNGERS 8-23-82

STRESS: _____

PROJ: J.H. MUMFORD 5-1-82

APPD: DRG

OTHER: _____

TITLE: **WIRING DIAGRAM — CIRCUIT BREAKERS**

SIZE: C CODE IDENT NO: 71379 OWG NO: 1270709

SCALE: NONE (S-1360-5L) PAGE: 4 23.2

CEB-1000 IS APPLICABLE VENDOR CODES PER S-1400 CEB-1000-CESNA SPEC. NO. S-1001 OR CHECKOUT-CESNA STD. NO.


SUPERSEDED BY: _____

MODEL P210 SERIES SERVICE MANUAL

NOTES:

1. ALTERNATOR SHUNT & FUSE ASSYS ARE PART OF 2170024 MODULE ASSY

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD SWITCH DECK DESIGNATIONS. ON FIRST DECK 1 THRU 4 WAS 6 THRU 9 (SR 10734)	12/11/83	KEL/WH/MS



WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
RED (2)	22	-22-2		SOLDER	S-2391-1
WHT (2)	22	-22-9		SOLDER	S-2391-1
VIO (2)	22	-22-7		SOLDER	S-2391-1
GRY (2)	22	-22-8		S-2391-1	SOLDER
BLU (2)		-22-6			
GRN (2)		-22-5			
ORN (2)		-22-3			
YEL (2)		-22-4			
BRN (2)		-22-1		S-2391-1	SOLDER
BLK (FN-DA20)		-22-0		S-2415-1	S-367-110
RED (FN-DA26)		-22-2			S-367-110
FN-DA25					S-367-110
FN-DA24					
FN-DA23					
FN-DA22					
FN-DA21					
FN-DA20	22			S-2415-1	S-367-110

ITEM NO.	PART NO.	DESCRIPTION
6	S-2558-1	SHUNT: BATTERY
5	S-2558-1	SHUNT: ALTERNATOR
4	C669563	INSTR. CLUSTER
3	S-2549-A	HOUSING
2	S-2550-G	HOUSING
1	2570100	SELECTOR SW ASSY

CONTRACT NO:			NAME		DATE
			Cessna		10-17-83
			SPENCER		10-17-83
			REHARZ		10-19-83
			STRESS		

EQUIPMENT TABLE	
CES-1000 IS APPLICABLE	SUPERSEDES: PG. 9.20
VENDOR CODES PER S-1400	SUPERSEDED BY:
CES-XXXX-CESSNA SPEC. NO.	
S-XXX OR CMXXXX-CESSNA	
STD. NO.	

PROJ	APPRO	OTHER	SIZE	CODE IDENT. NO.	DWG NO
1114002	MS		C	71379	1270709

WIRE TABLE

Cessna AIRCRAFT CO.

PAWNEE DIVISION
3800 E. PAWNEE
WICHITA, KANSAS

WIRING DIAGRAM -
VOLT-AMMETER (OPT)


NONE (SR10734; SR10715) | PAGE: 4.24

MODEL P210 SERIES SERVICE MANUAL

NOTES:

- ① S-1367-1-G FOR CENTER CONDUCTOR
- S-1367-2-G FOR SHIELDING
- ② S-1367-1-10 FOR CENTER CONDUCTOR
- S-1367-3-10 FOR SHIELDING

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: SER OUT C292501-0101; SER IN C292501-0105 (SR1726)	RLY 2-29-72	NEW 7/7W
B	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	JLO 5-3-73	BY NEW No.
C	BY REV: S1360-5L WAS S1360-8L (SR8143)	GDS 5-12-76	BY NEW No.
D	BY REV: ADD DETAIL "A" & SER # F-JAB (SR 8464)	REG 4-28-77	BY NEW No.
E	BY REV: ADD DETAIL "A" & SER (SR 9114) (SR 9115)	HMG 2-12-79	BY NEW No.



DETAIL A
SER (SR 8464) THRU SER (SR 9114) (SR 9115)

DETAIL A
THRU SER (SR 8464)

② THRU SER 21059852
④ SER 21059853 & ON ALL SPARES

14-0710
15-0716

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-JAB	20				S-1367-1-G S-1367-4-G SER (SR 8464) & ON
F-JA7	183	G6			
F-JA5	183	G5			
F-JA4	20				
F-JA3	20				THRU SER (SR 8464)

ITEM NO	PART NO.	DESCRIPTION	VENDOR
4	C292501-0105	IGNITION SWITCH	
3	SLICK 7662	MAGNETO (09033)	
2	C292501-0101	SWITCH	
1	S-1360-5L	CIRCUIT BREAKER	

CONTRACT NO:		
DESIGN	NAME	DATE
VR SIPS		1-28-71
GROUP	W.W.U.	2-26-71
DRAWN	VR SIPS	2-18-71
CHECK	L.K. WHITE	2-24-71
STRESS		
PROJ		
APPD		
OTHER		

WIRING DIAGRAM — MAGNETO SYSTEM

Cessna AIRCRAFT CO. COMMERCIAL AIRCRAFT DIV.
5800 E. PAWNEE WICHITA, KANSAS

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESSNA SPEC. NO.
S-XXX OR CMXXXX-CESSNA
STD. NO.

SUPSEDES:
12210-1073

SUPSEDED BY:

SIZE: C

CODE IDENT. NO: 71379

DWG NO: 1270709

SCALE: NONE


PAGE: 5, 1.

(SR 6755) X
21059503

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD DETAIL A (SR9114)(SR9115)	DDH 12-9-78	JAB JK
B	BY REV: ADD JA12 • JA13; DELETE JA9 • JA11 (SR 9221)	PSM 1-19-79	JAB JK
C	BY REV: S-1367-6-13 WAS S-1367-7-13/ PA 29 (NOW SHOP PRACTICE)	HHG 8-1-79	AB JK
D	BY REV: SER OUT JA12 JA13; ADD JA14 DETAIL B (MER P210 E0870) (SR9634)(SR9635)	DFS 7-14-80	JAB JK

STARTER



WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
JA-14	20			S-1367-1-6 S1367-1-10	SER(SR9634)(SR9635) (ON)
N-JA-13	20			S-1367-1-6 S1367-1-10	THRU SER (SR9635)
F-JA12	20			S-1367-1-6 S1367-1-10	THRU SER (SR9634)
F-PA31	22			S-1367-1-0 S1367-1-10	
F-PA29	4	S-1562-4-9		S-2447-4 S-1367-6-13	

EQUIPMENT TABLE		WIRE TABLE	
PART NO.	DESCRIPTION	CONTRACT NO.	TITLE
S	C292501-0106 IGNITION SWITCH		Cessna AIRCRAFT CO. COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS WIRING DIAGRAM — STARTER SYSTEM
4	S-2443-1 STARTER CONTACTOR		
J	S-1360-5L CIRCUIT BREAKER		
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXXX OR CMXXXX-CESSNA STD. NO.		SUPERSEDES: 1270709 P 6.1 SUPERSEDED BY:	
		DESIGN WHITSON 12-14-78 GROUP Willhuden 12-17-78 DRAWN LAULI 12-9-78 CHECK BORLESKE 12-12-78 STRESS PROJ <i>JK</i> 7-26-78 APPD <i>JK</i> OTHER	SIZE C CODE IDENT NO. 71379 DWG NO. 1270709 SCALE: NONE SR9221 PAGE: 6.2

MODEL P210 SERIES SERVICE MANUAL

REVISION (CON'T)				REVISION			
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD
L	BY REV: ADD DETAIL 'C' & SER & F-QD33 (SR8464)	REG	4-28-77	A	BY REV: ADDED NOTE 1	3-9-73	DLT
				B	BY REV: 'F' PREFIX WAS 'H', ADD F-QC21(REF), FGL12(REF) & 250706 (NOW SHOP PRACTICE)	6-20-73	DLT
				C	BY REV: S-1370-1/QD31 WAS SEE QD24, SOLDER/QD24 WAS S-1370-1 (MER E0034) (NOW SHOP PRACTICE)	2-8-74	DEF
				D	BY REV: S-1856-1 WAS 1250706-1 F-GC22(REF) WA. F-GC12(REF) (SR7997)	6-25-74	DLT
				E	BY REV: DELETE NOTE 1; ADD NOTE 2 & 3; ADD JUMPERS AT RESISTOR AMOR-20-10 (SR8082)	11-25-74	BLA
				F	BY REV: ADD S-1637-1 & -2 TO QD24 & QD31, ALL WIRE LENGTHS; S-1635-1/QD31 & S-1636-1/QD24 WERE SOLDER (NOW SHOP PRACTICE) MER E0408	2-28-75	TMS
				G	BY REV: REVISE NOTE 2 AND ADD DETAIL 'A' (SR8297)	7-30-75	GN
				H	BY REV 2LM-E WAS S-1856-1, ADD DETAIL B Q132 & SER MER 207E0436 (SR8115, SR8426)	1-14-76	JMS
				J	BY REV: 20GA WAS 18GA/F-QD23 THRU F-QD32 & JUMPER WIRES (SR8143)	5-6-76	GDS
				K	BY REV S-2035-1 WAS S-1637-1; S-1635-2 WAS S-1637-2 (NOW SHOP PRACTICE) MER E0525	8-27-76	PH

NOTES:

1. PLACE YELLOW ROCKER SWITCH IN HIGH BOOST POSITION. ADJUST RESISTORS WITH ENGINE OFF & 27.5 VDC APPLIED TO BUS. OPEN TO FULL THROTTLE & ADJUST 1ST RESISTOR TO PRODUCE 125 LBS/HR INDICATION ON FUEL FLOW METER. ADJUST 2ND RESISTOR WITH THROTTLE CLOSED TO PRODUCE 40 LBS/HR INDICATION ON FUEL FLOW METER. RESISTORS ARE IN SERIES WHEN THROTTLE IS CLOSED.

▶ ADJUST AMOR-20-10 TO 3.5 ± .5 OHMS PRIOR TO INSTALLATION

▶ READJUST RESISTANCE AS REQUIRED AFTER INSTL TO COMPLY WITH FUEL FLOW REQUIREMENTS PER CES 1243

F-QD33	20				S-1367-1-6	S-1493-1		SER (SR8464) & ON
F-QD32	20		60	S-1493-1	S-1635-1			SER (SR8426) & ON
F-QD31			54	S-1635-1	S-1370-1			
F-QD30			60	S-1635-1	SOLDER			
F-QD29			12	SOLDER	S-1636-1			
F-QD28			60	S-1635-1	SOLDER			
F-QD27			12	SOLDER	S-1636-1			
F-QD26			12	S-1635-1	SOLDER			
F-QD25			90	S-1493-1	S-1636-1			
F-QD24			60	S-1493-1	S-1636-1			THRU SER (SR8426)
F-QD23	20		17	S-1367-1-6	S-1493-1			THRU SER (SR8464)


9	S-2035-2	HOUSING					
8	S-2035-1	HOUSING					
7	C291504-Q201	PUMP					
6	AMOR20-10	RESISTOR					
5	2-LM-E	SWITCH					
4	S-1637-1	HOUSING					
3	S-1637-2	HOUSING					
2	S-1846-3-2	SWITCH					
1	S-1360-5L	CHT BKR					

WIRE TABLE		
CONTRACT NO:		COMMERCIAL AIRCRAFT DIV. 3800 E. PAWNEE WICHITA, KANSAS
DESIGN	NAME	TITLE
VR 51PES		WIRING DIAGRAM — FUEL PUMP SYSTEM
GROUP	DATE	
H W ser	11-30-72	
DRAWN	DATE	
RAPE	12-28-72	
CHECK	DATE	
R. YOUNGLES	12-30-72	
STRESS		
PROJ	DATE	SIZE
H W ser	11-3-73	C
APPD	DATE	CODE IDENT NO
PLH		71379
OTHER		OWG NO
		1270709
SCALE: NONE		PAGE: 7.1.1

<p>CEB-4000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXX OR CNXXXX-CESSNA STD. NO.</p>	<p>SUPERSEDES: P 7.1</p> <p>SUPERSEDED BY:</p>
---	--

MODEL P210 SERIES SERVICE MANUAL

				REVISION			
LET	DESCRIPTION	DATE	APPO	LET	DESCRIPTION	DATE	APPO
G	BY REV: ADD DFT # SER SER OUT DFI (SR8464)(REF), (SR8465)(REF)	DLP 2-9-77	JAS/WHF	A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	2LO 5-3-73	JAS/WHF
H	BY REV: C664503-0101 WAS C664502-0101; ADD DFB, NOTE 1, SIG 57-1, 2, C664511-0101, 51360-5L, DETAIL B & PG B.2.1 (SR2080)(REF) (SR2187)	CMK 7-13-78	JAS/WHF	B	BY REV: C664502-0101 WAS C664501-0103 ADD 5-2023-1 (SR 7913)(REF)	2-10-76 GDS	JAS/WHF
J	BY REV: ADD DETAIL C & C664511-0102 (SR9583)	H HG 2-13-80	JAS/WHF	C	BY REV: 22 GA WAS 20GA / F-DF1, F-DF3 F-DF4 (SR8143)	GDS 5-6-76	JAS/WHF
K	BY REV: ADD DETAIL D; S2527-2, S2527-1, BLK (FN-DF9), BLK (F-DC13)(REF) WAS BLK (F-DC11)(REF) BLK (F-DC12)(REF) WAS DC3 (REF) (SR1010)(SR1012)	MKT 1-27-82	JAS/WHF	D	BY REV: RED (F-DF3) WAS F-DF3 (SR2656)	PH 9 21 76	JAS/WHF
L	BY REV: 51367-1-B / DFI, DF3, DF5, DF7, DFB WAS 51367-1-G (NOW SHOP PRACTICE) (MER 152E0967)	GW 7-8-82	JAS/WHF	E	BY REV: ADD RED (F-DF5), F-DF6 & DETAIL A & SER (SR8464)	GLR 4-18-77	JAS/WHF
				F	BY REV: ADD PCB REF (SR2465)	GDS 6-6-77	JAS/WHF



NOTES:
1. REQD ONLY WHEN OPT DIGITAL CLOCK C664511 IS INSTALLED

ITEM NO	QTY	DESCRIPTION	REF	WIRE CODE	GA	MATERIAL	LG	TERMINALS	SERIALS
15	1	S2527-2 GND CONNECTOR	BLK (FN-DF9)	22	-22-0	51493-1	52099-4		SR (SR1010)(SR1012) ELN
14	1	C664511-0102 DIGITAL CLOCK	REF	22	-22-2	51367-1-B	51635-2		
13	1	S-1360-5L CIRCUIT BREAKER	F-DF7	22		51367-1-G	51367-1-B		SER (SR8464) XSR846511 ON
12	1	C664511-0101 DIGITAL CLOCK	F-DF6	22		51493-1	51367-1-B		SER (SR8464) THRU (SR1010)(SR1012)
11	1	S-1637-2 HOUSING	RED (F-DF5)	22	-22-2	51367-1-B	51493-1		SER (SR8464) ON
10	1	S-1637-1 HOUSING	F-DF4	22		15	S-1637-1	51367-1-B	THRU SER (SR8464)
9	1	C664508-2101 CLOCK	RED (F-DF3)	22	-22-2	50	S-1367-1-B	S-1637-1	THRU SER (SR8464)
8	1	S-2023-1 ADAPTOR	F-DF1	22		80	SOLDER S-1367-1-B		THRU SER (SR8464)
7	1	C6645030101 HOURMETER							
6	1	0770288-1 DIODE ASSY							
5	1	S-1711-1 OIL PRESS. SWITCH							
4	1	S-1580-1 BATTERY CONTACTOR							
3	1	S-2527-1 LN GND BLOCK							
2	1	S-1091-1 FUSE							
1	1	S-1090-22 FUSEHOLDER							

WIRE TABLE

CONTRACT NO:			Cessna AIRCRAFT CO.		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	VR SIZES	1-28-71	WIRING DIAGRAM — HOURMETER (OPT)			
GROUP	H. White	2-26-71				
DRAWN	VR SIZES	2-18-71				
CHECK	L.X. WHITE	2-24-71				
STRESS			SIZE	CODE IDENT. NO.	DWG NO	
PROJ	H. White	2-7-71	C	71379	1270709	
APPO	JAS		SCALE	NONE	210 P210	PAGE: 8.2.0
OTHER						


CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXX OR CMXXXX-CESSNA STD. NO.

SUPERSEDES: 12210-1073
SUPERSEDED BY:


(SR 6755) 28

MODEL P210 SERIES SERVICE MANUAL


REVISION			
LET	DESCRIPTION	DATE	APPO
K	SEE PG 8.2.0 FOR REVISION		



DETAIL 13
(REQD WHEN OPT DIGITAL CLOCK IS INSTALLED)



DETAIL 12
THRU SER (SR9583)






DETAIL 11
THRU SER (SR10101) (SR10102)

02-00916
01-00916

CONTRACT NO.		PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	G STAMM	DATE	72-78
GROUP	SR Smith	DATE	7-24-78
DRAWN	C KING	DATE	7-13-78
CHECK	CORLESKE	DATE	7-14-78
STRESS			
PROJ	SR Smith	DATE	8-1-78
APPD			
OTHER			
Cessna AIRCRAFT CO.		TITLE	
		WIRING DIAGRAM - HOURMETER (OPT)	
SIZE	C	CODE IDENT. NO.	71379
DWG NO.			1270709
SCALE	NONE	(SR9187)	PAGE: 8.2.1

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
C	SEE PAGE B.B.0 FOR REVISION		




02-00916
02-00916

CONTRACT NO.		PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	Cessna AIRCRAFT CO.
GROUP	WHITSON	3-6-81	TITLE: WIRING DIAGRAM - FUEL GAGES
DRAWN	BORLESKE	2-5-81	
CHECK		3-6-81	
STRESS			
PROJ			SIZE CODE IDENT DWG NO.
APPD			C 71379 1270709
OTHER			SCALE NONE (SR10148) PAGE: B.B.1

MODEL P210 SERIES SERVICE MANUAL

NOTES:
 1. TERMINATE 22 GA JUMPER WITH S-1636-1

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD JUMPER WIRE 9A0TE1; S-1370-1 WAS S-1636-1 / BLK (DC17) (SR9953XREF)(SR9954)(REFXMER210E0477) ADD S-2527-145-25272; SER IN BLK (DC21) SER OUT BLK (DC18) (SR10101)(SR10102)	GLS 1-27-82	JAD/BAH JLG
B	BY REV: ADD DETAIL 13 (SR10420) (SR10641)	TMS 2-8-84	JEM



DETAIL 13
 THRU SER (SR10101)(SR10102)

DETAIL 13
 APPLIES TO P210
 SER(SR10641) & ON
 & 210 W/OPT INT US

20-00516
41-00516

ITEM NO.	PART NO.	DESCRIPTION	GA	MATERIAL	LG	TERMINALS	SERIALS
15	S-2527-3	TERMINAL BLOCK	22	S-1636-1	S-1829-1		SER(SR10641) & ON
14	S-2527-2	GND CONNECTOR	22	-22-0	SEE BLK(17) S-2099-4		SER(SR10101)(SR10102) & ON
13	S-2527-1	LH GND BLOCK	22	-22-0	SEE BLK(17) S1367-1-B		THRU SER(SR1000)(SR10102)
12	C913001	FLOW TRANSDUCER	22S	S1461-22-9	S1370-1	S1370-1	
11	CG62060	INDICATOR	22	22-2	S1636-1	S1370-1	
10	S1641-6	HOUSING	22	-22-2-9	S1636-1	S1636-1	
9	S1640-6	HOUSING	22	-22-4	S1636-1	S1829-1	
8	S2475-1	BATT. CONTACTOR	22	-22-2-5	S1367-F6	S1636-1	
7	0T10728	DIODE ASSY					
6	S1090-22	FUSE HOLDER					
5	S1091-1	FUSE					
4	S1637-1	HOUSING					
3	S1637-2	HOUSING					
2	34004-818	TERMINAL BLOCK					
1	S1360-5L	CIRCUIT BREAKER					

CONTRACT NO.:			Cessna AIRCRAFT CO.		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE			
GROUP	WHITSON	4-20-81	WIRING DIAGRAM -			
DRAWN	WHITSON	4-28-81	FUEL TOTALIZER/CLOCK			
CHECK	REHAR	4-28-81	(OPT)			
STRESS						
PROJ	SR9953XSR9954	4-28-81	SIZE	CODE IDENT.	DWG NO	
APPO			C	71379	1270709	
OTHER						

EQUIPMENT TABLE		SUPERSEDES:	
CES-1000 IS APPLICABLE			
VENDOR CODES PER S-1400			
CES-100X-CESNA SPEC. NO.			
S-100X OR CM100X-CESNA			
STD. NO.			


N/A 2101057

MODEL P210 SERIES SERVICE MANUAL

NOTES:

- 1 MATERIAL IS ALPHA 5857-7 OR BELDEN 83009-1
- 2 CRIMP S-4636-5 TERMINAL AROUND WIRE INSULATION. BEND .25 OF STRIPPED WIRE BACK OVER CRIMP & SOLDER PER CES1040. USE MOLEX HT-1921 CRIMPING TOOL ONLY
- 3 MATERIAL IS ALPHA 5857-6 (VENDOR CODE 92194) OR BELDEN 83009-6 (VENDOR CODE 70903)
- 4 GROUND AT ENGINE ACCESSORY COVER THRU (SR10420)(SR10421) GROUND AT ENGINE BOLT AT LH REAR OF PROP DE-ICE TERM BLOCK BKT (SR10420)(SR10421) THRU (SR10466). GROUND AT ENGINE BOLT AT RH REAR OF PROP DE-ICE TERM BLOCK BKT (SR10466) & ON.
- 5 MATERIAL IS ALPHA 5857-2 (VENDOR CODE 92194) OR BELDEN 83009-10 (VENDOR CODE 70903)

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD NOTE G; BRN (EC6) WAS BRN (EC5) (SR9954) (REF)	GLS 11-2-81	<i>[Signature]</i>
B	BY REV: DELETE NOTE G; BRN (EC5) WAS BRN (EC6) (SR9954) (REF)	GLS 1-18-82	<i>[Signature]</i>
C	BY REV: REVISE NOTE 4 (SR10420) (REF) (SR10421) (REF) (SR10466)	TMS 2-1-85	<i>[Signature]</i>



54-00916
53-00916

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK(EE12)	18	▲	5-1367-4	5-1367-12	
BLK(EE11)	18	▲	5-1367-1-B	5-1367-12	
BLU(EE9)	18	▲	5-1367-1-10	5-1367-1-10	
BLU(EE10)	18	▲	5-1367-1-10	5-1367-1-10	
EE8	22		5-1367-1-10	5-1367-1-10	
EE7	22		5-1967-6	5-1367-1-10	
BRN(EC4)	18	▲	5-1367-1-10	5-1636-5	▲ 2
BRN(EC5)	18	▲	5-1367-1-10	5-1636-5	▲ 2

PART NO.	DESCRIPTION
5	S-1637-4 HOUSING
4	S-2334-4 XMTR
3	S-2335-1 XMTR
2	CL69361-0102 INST CLUSTER
1	S-1360-54 CIRCUIT BREAKER

WIRE TABLE

CONTRACT NO: _____

Cessna AIRCRAFT CO.
FAWNEE DIVISION
3808 E. FAWNEE
WICHITA, KANSAS

DESIGN: _____ NAME: _____ DATE: _____

GROUP: HARDEN 9-1-81

DRAWN: M. THOMPSON 9-2-81

CHECK: BORLESKE 9-4-81

STRESS: _____

PROJ: _____ 9-4-81

APPRO: *[Signature]*

OTHER: _____

TITLE
WIRING DIAGRAM —
OIL TEMP & CYL HEAD TEMP

SIZE: C CODE IDENT. NO. 71379 DWG NO. 1270703



SCALE: NONE 210 P210 PAGE: 8 10

EQUIPMENT TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CHXXXX-CESNA STD. NO.	SUPERSEDED BY: PG. 8.7
	SUPERSEDED BY:

(SR9953)(SR9954)

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD DETAIL "A", BLK(N-EK3), S2527-2 & -1; SER OUT N-EK2 (SR10102)	M.T 1-27-82	SAE LW APD
B	BY REV: EKI(N-EK3) WAS BLK(N-EK3) (SR10102)	SLS 6-29-82	SAE LW APD



02-00916

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK(N-EK3)	22	-22-0		S-1367185-2099-1	SER(SR10102) ON
N-EK2	22			S-1367185-13671-8	THRU SER(SR10102)
N-EK1	22			S-1367165-13671-8	


PART NO.	DESCRIPTION
4	S 2527-2 GND CONNECTOR
5	S 2527-1 LH GND BLOCK
2	S-1360-5L CIRCUIT BREAKER
1	C66B501 T.I.T GAGE

EQUIPMENT TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CMXXXX-CESNA STD. NO.	SUPERSEDED BY:

CONTRACT NO:			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE		
GROUP	W. H. H. 1	10-2-81	WIRING DIAGRAM - TURBINE INLET TEMP GAGE		
DRAWN	G. STAMM	10-9-81	GAGE		
CHECK	BORLESKE	10-9-81			
STRESS					
PROJ	OFFICEL	10-12-81	SIZE	CODE IDENT. NO.	DWG NO
APPD	WPS		C	71379	1270703
OTHER			SCALE NONE (SR9954) PAGE: 8.11 (REF)		

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO



02-00916

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
N-EKS	22	-22-9		54636-1	5-2099-4
BLK(REF)				54635-1	
RED(REF)				54635-1	
N-EK4	22	-22-9		513674-6	54636-1

PART NO.	DESCRIPTION
6	5-1360-5L CIRCUIT BREAKER
5	5-2527-2 GND CONNECTOR
4	5-2527-1 LH GND BLOCK
3	5-2035-2 CONNECTOR
2	5-2035-1 CONNECTOR
1	C668501 INDICATOR-EGT/TIT




WIRE TABLE		
CONTRACT NO:		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS
DESIGN	NAME	DATE
GROUP	<i>W. H. ...</i>	<i>4-20-82</i>
DRAWN	G. STAMM	<i>4-20-82</i>
CHECK	<i>E. DUNGER</i>	<i>4-20-82</i>
STRESS		
PROJ	<i>111100</i>	<i>4709?</i>
APPO	<i>MS</i>	
OTHER		
TITLE		SIZE
WIRING DIAGRAM — INDICATOR-EGT & TURBINE INLET TEMP (OPT)		CODE IDENT. NO.
		DWG NO
		1270709
C		71379
PAGE: 3/12		

CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-1000-CESNA SPEC. NO.
 S-1000 OR C1000-CESNA
 STD. NO.

SUPERSEDES:
 SUPERSEDED BY:

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD WIRE LENGTHS (NOW SHOD PRACTICE)	DLO 5-3-73	<i>[Signature]</i>
B	BY REV: 22 GA WAS 20/ FA3, FA4 (SR8143)	GDS 5-6-76	<i>[Signature]</i>
C	BY REV: ADD DETAIL A & SER. & FA5 (SR8464)	REG 4-28-77	<i>[Signature]</i>
D	BY REV: ADD DETAIL 'B' 3252 (1:2) BLK (FN-FA6) SER. CUT FA4 (SR10101)(SR10102)	MKT 1-27-82	<i>[Signature]</i>



DETAIL A
THRU SER (SR8464)

02-00916
01-00916

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
FA5	22	SOLDER	52079-8	SER (SR10101)(SR10102) & ON	
FA4	22	SOLDER	S1367-B	SER (SR8464) & ON	
FA4	22	20 SOLDER	S-1367-B	THRU SER (SR10101)(SR10102)	
FA3	22	16 S1367-B SOLDER		THRU SER (SR8464)	

ITEM NO	PART NO.	DESCRIPTION
5	S2527-2	GND CONNECTION
4	S2527-1	LH GND BLOCK
3	CG61003-050	TURN COORDINATOR
2	M53106A105L3	CONNECTOR
1	S-1360-SL	CIRCUIT BREAKER

EQUIPMENT TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXX OR CMXXX-CESSNA STD. NO.	SUPERSEDES: 12210-1073 SUPERSEDED BY:

CONTRACT NO:		NAME		DATE	COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	VR SIPES	2-18-71			Cessna AIRCRAFT CO. WIRING DIAGRAM — TURN COORDINATOR	
GROUP	H. White	2-25-71				
DRAWN	VR SIPES	2-18-71				
CHECK	L.V. WHITE	2-24-71				
STRESS						
PROJ	M. White	2-27-71	SIZE	CODE IDENT.	DWG NO	
APPRO	WKB		C	71379	1270709	
OTHER			SCALE	NONE	Z10	PAGE: 9.2


(SR6755) II (21059503)

MODEL P210 SERIES SERVICE MANUAL



NOTES:

CAUTION: POWER WIRE MUST BE CONNECTED TO "BATT" TERMINAL OF CLOCK OTHERWISE INTERNAL DAMAGE TO UNIT WILL RESULT

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	DLO 5-3-75	2-17 VW NWT
B	BY REV: 22 GA WAS 20/ F-DC3, F-DC4 F-DC5 (SR8143)	GDS 5-6-76	5-10-84 11-75
C	BY REV ADD P210 (SR8465)	DLP 6-6-77	JAB/WH 11-75
D	BY REV: ADD NOTE 1, RED(F-DC7), RED F-DC8, S-1637-1, -2 # DETAIL A; SER OUT F-DC6; C664508-0102 WAS C664508-0101 (SR9195)	BGK CMK 7-13-78	JAB/WH 11-75
E	BY REV: ADD DETAIL B BLK(F-N-DC19), S2527(-1-2); SER OUT F-DC3 F-PA35(REF) WAS F-PA15(REF) S-2475-1 WAS S-1580-1. (NOW SHOP PRACT)(SR10101)(SR10102)	MKT 1-27-82	JAB/WH 11-75



DETAIL A
THRU SER (SR9195)



DETAIL 13
THRU SER(SR10101)(SR10102)

02 00916
01-00916

ITEM	QUANTITY	DESCRIPTION	UNIT	TERMINALS	SERIALS
22	-22-0	WIRE	5-1367-6	S2099-9	SER(SR10101)(SR10102)
22	-22-2	F-DC8	5-1636-1	5-1367-1-6	SER(SR9195)EON
22	-22-2	F-DC7	SOLDER	5-1635-1	SER(SR9195)10W
22	-22-2	F-DC6	64 SOLDER	5-1367-1-6	THRU SER(SR9195)
22	-22-5	F-DC4	6 SOLDER	5-1367-1-6	
22	-22-5	F-DC3	18 SOLDER	5-1367-1-6	THRU SER(SR10101)(SR10102)

QTY	PART NO.	DESCRIPTION
9	S-2527-2	GND CONN. F-DC
8	S-2527-1	LH GND BULL
7	S-1637-1	HOUSING
6	S-1637-2	HOUSING
5	S-2475-1	BATTERY CONTACTOR
4	C664508-0102	CLOCK
3	S-1091-1	FUSE
2	S-1090-22	FUSE HOLDER
1	0770728	DIODE ASSY

CONTRACT NO:			WIRE TABLE		
DESIGN	NAME	DATE	SIZE	CODE IDENT. NO.	DWG NO.
VR SIPS		1-28-71	C	71379	1270709
GROUP	H W L W	2-26-71	TITLE: WIRING DIAGRAM - CLOCK		
DRAWN	VR SIPS	2-13-71	SCALE: NONE		
CHECK	L K WHITE	2-24-71	210 7210 PAGE: 10.1		
STRESS			(SAG 755) J		
PROJ	2-21-71				
APPRO	-E				
OTHER					


EQUIPMENT TABLE		SUPERSEDES:	
PART NO.	DESCRIPTION	12210-1073	
		SUPERSEDED BY:	

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CMXXXX-CESNA STD. NO.

MODEL P210 SERIES SERVICE MANUAL

D	BY REV: ADD DETAIL B S2527(-24-1), BLK(DC20; SER OUT BLK(DC11); S-2475-1 WAS S-1580-1 (NOW SHOP PRCT) (SR1010)(SR10102)	MKT	1-27-82	JAS/MS
E	BY REV: PIN 'H' WAS 1/6 GND BLK; ADD DETAIL 'B'	TMS	8-2-83	JAS/MS

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: WHITE (REF) WAS RED (REF); RED (REF) WAS BLU (REF); RED (DC7) WAS BLU (DC8); GRN (DC9) (REF) WAS GRN (DC9); DC11 WAS DC7 (SR9187)	CMK	7-13-78
B	BY REV: ADD DETAIL A; C664511-0102 (SR9583)	HHG	2-13-80
C	BY REV: (DC7) RED (REF) WAS (DC7) RED; (DC4) GRN WAS (DC9) GRN (NOW SHOP PRCT)	MKM	8-18-80



- NOTES:
- 1 ▷ INSTALL S-1636-1 ON VENDOR WIRE
 - 2 ▷ INSTALL S-1635-1 ON VENDOR WIRE

ITEM NO.	PART NO.	DESCRIPTION
10	S2527-2	GND CONNECTOR
9	S2527-1	LH GND BLOCK
8	C664511-0102	DIGITAL CLOCK
7	S-2475-1	CONTACTOR
6	S-1091-1	FUSE
5	S-1090-22	FUSEHOLDER
4	S-1360-SL	CIRCUIT BREAKER
3	S-1637-1	HOUSING
2	S-1637-2	HOUSING
1	C664511-0101	DIGITAL CLOCK

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK (DC11)	18	18-0		S-1635-1 S-1637-3	SER(SR1010) SER(SR10102) ON
BLK (REF)				S-1636-1 S-1636-1	THRU SER(SR9583)
WHIT (REF)					
RED (REF)					THRU SER(SR9583)
BLK (DC20)	18	18-0		S-1635-1 S-1637-8	THRU SER(SR1010) SER(SR10102) ON


CONTRACT NO:			Cessna AIRCRAFT CO.		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN GROUP	NAME	DATE	TITLE			
	G STALL	4-7-78	WIRING DIAGRAM -			
	R. Youngers	4-11-78	DIGITAL CLOCK (OPT)			
	BORLESKE	4-11-78				
PROJ	PUNDRUK	4-14-78	SIZE	CODE IDENT. NO.	DWG NO.	
APPO	JAS		C	71379	1270709	
OTHER			SCALE: NONE	(SR9187)	PAGE: 10.4	

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CMXXXX-CESNA STD. NO.

SUPERSEDES:
SUPERSEDED BY:

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD DETAIL A; DAT; SER OUT DAE (SR9114)(SR9115)	WHG 12-12-78	JAB WWH JRS
B	BY REV: ADD C669560-C102 (SR9711)	SEB 11-1-79	JAB WWH JRS
C	BY REV: SER OUT DAB, DA9; SER IN DA10, DA11; ADD DETAIL B (MER P210E0870) (SR9634)(SR9635)	DFS 7-14-80	JAB WWH JRS



DETAIL A
THRU SER(SR9114)(SR9115)

DETAIL B
THRU SER(SR9634)(SR9635)

15-0916
14-0916

WIRE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
DA11	B	S-1562-B-9	S-1367-4-10	S-1367-4-10	SER(SR9634) CON
DA10	B	S-1562-B-9	S-1367-4-10	S-1367-4-10	SER(SR9635) CON
DA9	B	S-1562-B-9	S-2447-B	S-1367-4-10	THRU SER(SR9634)
DAB	B	S-1562-B-9	S-2447-B	S-1367-4-10	THRU SER(SR9635)
DA7	B	S-1562-B-9	S-1367-4-10	S-1367-4-8	SER(SR9114)(SR9115) CON
DA5	B	S-1562-B-9	S-1367-4-10	S-1367-4-10	THRU SER(SR9114)(SR9115)

WIRE TABLE

+	PART NO.	DESCRIPTION
3	C669527-0101	INST CLUSTER
2	S-2443-1	STARTER CONTACTOR
1	S-707-60	CIRCUIT BREAKER

EQUIPMENT TABLE

CES-000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESSNA SPEC. NO.
S-XXX OR CMXXXX-CESSNA
STD. NO.





SUPERSEDES:
1270709 D 10.3
SUPERSEDED BY:

CONTRACT NO.:		
DESIGN	NAME	DATE
WHITSON		12-14-78
GROUP	WILLIAMS	12-17-78
DRAWN	HAUN	12-9-78
CHECK	BORLESKE	12-12-78
STRESS		
PROJ	12-20-78	
APPD	JRS	
OTHER		

Cessna AIRCRAFT CO.		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
TITLE		DWG NO	
WIRING DIAGRAM - AMMETER		1270709	
SIZE	CODE IDENT. NO.	DWG NO	
C	71379	1270709	
SCALE: NONE		SR9221	PAGE: 10 E

MODEL P210 SERIES SERVICE MANUAL

REVISION (CONT)				REVISION			
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD
E	BY REV: ADD DETAIL "B" & SER, F-LC17, F-LC18 & F-LC19 (SRB464)	REG 4-28-77	JAB	A	BY REV: DELETE S-2094-1; GRAY, TAN, BLK (3) & BLK (4); 16GA WAS 18 GA / F-LC 3 & F-LC 4; 16GA WAS 14GA / F-LC 15; S-1367-2-B WAS S-1493-3 / F-LC 13, F-LC 14, BLK (1) & BLK (2) (SRG755)	RLY 9-2-71	RLY
F	BY REV: 18GA WAS 16GA / BLK (2); F-LC18 TO LDG WAS TAXI; F-LC17 TO TAXI WAS LDG (SRB464)(SRB465)	JJB 8-29-77	JAB W/APP	B	BY REV: ADD S-2160-1; 1270082-1 & SER; SER OUT S-1846-13. SER (S27486)	JLP 1-9-73	JLP
				C	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	JLO 5-3-73	JLO
				D	BY REV: ADD F-LC 16, S1360-5L; 20 GA WAS 16 GA / F-LC 13, BLK (1); S-1493-1 WAS S-1493-2, 1367-1-B WAS 1367-2-B / LC13; S1367-1-B WAS S-1367-2-B / BLK (1); SER OUT 14GA JUMPER WIRE (SRB143)	GDS 5-6-76	GDS



WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-LC 19	18			S-1493-1 S-1367-1-B	SER (SRB464) & ON
F-LC 18	18			S-1493-1 S-1367-1-B	SER (SRB464) & ON
F-LC 17	20			S-1493-1 S-1367-1-B	SER (SRB464) & ON
F-LC 16	20			S-1493-1 S-1367-1-B	SER (SRB464) THRU SER (SRB464)
BLK (2)	18	-18-0	16	S-1367-2-B S-1367-2-B	
BLK (1)	20	-20-0	16	S-1367-1-B S-1367-1-B	
F-LC 15	16		6	S-1493-2 S-1367-2-B	THRU SER (SRB464)
F-LC 14	16		175	S-1493-2 S-1367-2-B	THRU SER (SRB464)
F-LC 13	20		175	S-1493-1 S-1367-1-B	

PART NO.	DESCRIPTION
7	S-1360-10L CIRCUIT BREAKER
6	S-1360-5L CIRCUIT BREAKER
5	1270082-1 DIODE ASSY
4	S-1846-1-3 SWITCH
3	GE 4591 LIGHT
2	S-2160-1 SWITCH
1	S-1360-15L CIRCUIT BREAKER

EQUIPMENT TABLE		WIRE TABLE	
CONTRACT NO:	NAME	DATE	COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS
DESIGN	VR SIPES	1-28-71	Cessna AIRCRAFT CO. WIRING DIAGRAM - LANDING LIGHTS
GROUP	H. W. J.	2-28-71	
DRAWN	VR SIPES	2-18-71	
CHECK	L.K. WHITE	2-24-71	
STRESS			
PROJ	A. G. T.	2-21-71	SIZE
APPD			CODE IDENT.
OTHER			DWG NO.
			C 71379
			1270709
			SCALE: NONE
			210 P210 PAGE: 11.9

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESSNA SPEC. NO.
S-XXX OR CMXXXX-CESSNA
STD. NO.

SUPERSEDES:
12210-1073


SUPERSEDED BY:

(SRG755) II
21059502


65-0916
64-0916

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: 5-2099-7 WAS 66331-5/RED (N-LD57) & RED(N-LD56); 5-2353-2 WAS 66332-5/ N-LD54 & N-LD53 (SR8465)	JJB 8-29-77	JJB WIK JJB
B	BY REV: ADD DETAIL D, & SER, ADD 205841-1 & 205838-1, LD65, LD66 20 GA WAS 22 GA/LD56, LD57 & LD66 (SR9427)	CS 4-10-78	JJB WIK JJB 240
C	BY REV: (SR9427) WAS (SR8063)/REV 'B'; DETAIL 'D', LD54, LD56, LD65 & LD66 (SR9427)	GDA 10-2-78	JJB WIK JJB V35



DETAIL D
THRU SER(SR9427)



65-0916

13	205841-1	CONNECTOR	
12	205838-1	CONNECTOR	
11	52160-1	SWITCH	
10	5-2350-2	CONNECTOR	
9	5-2349-2	CONNECTOR	
8	5-2350-1	CONNECTOR	
7	5-2349-1	CONNECTOR	
6	51637-2	HOUSING	
5	51637-1	HOUSING	
4	34003-817	TERM BLOCK	
3	C622001-0202	LIGHT ASSY	
2	C622001-0102	LIGHT ASSY	
1	51360-3L	CIRCUIT BREAKER	

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
RED (LD66)	20	-20-2		5-1636-1 5-2341-1	SER(SR9427) & ON
LD65	22			5-1829-1 5-2415-1	SER(SR9427) & ON
RED (LD57)	20	-20-2		5-1636-1 5-2099-7	
RED (LD56)	20	-20-2		5-1636-1 5-2099-7	THRU SER(SR9427)
N-LD55	20			5-1829-1 5-1636-1	
N-LD54	22			5-1829-1 5-2353-2	THRU SER(SR9427)
N-LD53	22			5-1829-1 5-2353-2	

WIRE TABLE

CONTRACT NO:		
DESIGN	NAME	DATE
	SPENCER	6-20-77
GROUP	W. H. W. D. W.	6-23-77
DRAWN	SCHWIFELBEIN	6-6-77
CHECK	BORLESKE	6-7-77
STRESS:		
PROJ	PL H. R. D. R. C. K.	6-24-77
APPO	JJB	
OTHER:		

PAWNEE DIVISION
1806 E. PAWNEE
WICHITA, KANSAS

Cessna AIRCRAFT CO.

**WIRING DIAGRAM —
NAVIGATION LIGHTS**

SIZE	CODE IDENT. NO.	DWG NO
C	71379	1270709

EQUIPMENT TABLE

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-1000-CESNA SPEC. NO.
S-1001 OR C1000X-CESNA
STD. NO.

SUPERSEDES:
SUPERSEDED BY:

MODEL P210 SERIES SERVICE MANUAL

REVISION				REVISION			
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD
J	BY REV. ADD DETAIL 'C' S2527-2; -1) BLK (FN-LB163), SER OUT BLK (FN-LB88) (SR1010)(SR1002)	MKT 1-27-82	JAS INH JRS	A	BY REV: ADD WIRE LENGTHS & ORIENT. TERM BLOCK (NOW SHOP PRACTICE)	DLO 7-22-72	DLP HND D
				B	BY REV: ADD RH10-10, HF-10-10, S-1637-1, S-1637-2, F-LB111, F-LB108, F-LB109 & F-LB110 (SR7650)II	MEM 5-17-74	DLO JRS D D
				C	BY REV. 34003-55 WAS 34002-55; SER (SR 7913)	CJM 11-27-74	SCY JRS D
				D	BY REV. 34003-817 WAS 34003-55. INBOARD TERM BLOCK / DETAIL 'A' WAS OUTBOARD TERM BLOCK: ADD SER S TO LB, LB9, LB10, LB11 (SR1650)(REF): (NOW SHOP PRACTICE) (SR7913)	GW 9-17-75	JRS D
				E	BY REV. 22 GA WAS 18 GA / F-LB88, F-LB111 F-LB108, F-LB109, F-LB110; S-1636-1 WAS S-1636-2 (SR 8143)	GDS 5-6-76	JRS D
				F	BY REV: ADD F-LB140, DETAIL 'B'; SER OUT F-LB108, F-LB109, F-LB110 & F-LB111, RH-10-10, HF-10-10, S-1637-1, S-1637-2 (SR8464)(SR8465)	JJB 8-29-77	JAS INH JRS D
				G	BY REV 1213319 (S) WAS (A) (SR8464)(REF)(SR8465) (REF)	DLP 7-9-77	JAS INH JRS D
				H	BY REV: ADD RED LB145; BLK FLB 99 WAS F-LB88, MER 210E0667 (NOW SHOP PRACTICE)	HG 2-21-79	JRS D

02-003/6

GA	MATERIAL	LG	TERMINALS	SERIALS
22	-22-0	S-1370-1	S2099-1	SER(SR1010)(SR1002)CON
22	-22-2	S-1370-1	SEE LB140	
22		S-1829-1	S-1370-1	(SR8464)CON
22		S-1370-1	S-1635-1	(SR7650)THRU(SR8464)
22		6	SOLDER	(SR7650)THRU(SR8464)
22		6	S-1636-1	(SR7650)THRU(SR8464)
22		S-1636-1	S-1829-1	(SR7650)THRU(SR8464)
22	-22-0	30	S-1370-1	THRU SER(SR1010)(SR1002)
18		30	S-1370-1	THRU SER 210E0667

9	S2527-2	GND CONNECTOR	
8	S2527-1	LH GND BLOCK	
7	34003-817	TERMINAL BLOCK	
6	S-1637-2	HOUSING-SOCKET	
5	S-1637-1	HOUSING	
4	HF-10-10	RESISTOR (OMNI)	ALTERNATE
3	RH-10-10	RESISTOR (DALE)	
2	34002-55	TERMINAL BLOCK	
1	1213319	LIGHT ASSY	


EQUIPMENT TABLE				WIRE TABLE			
PART NO.		DESCRIPTION		CONTRACT NO:		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS	
				DESIGN	VR SIPS	1-28-71	Cessna AIRCRAFT CO. WIRING DIAGRAM - EYEBROW LIGHTS
				GROUP	X	2-26-71	
				DRAWN	VR SIPS	2-18-71	
				CHECK	AK WHITE	7-24-71	
				STRESS			
				PROJ	Wichita	1-27-71	SIZE
				APPD	JRS		CODE IDENT. NO.
				OTHER			DWG NO
							C 71379 - 1270709
							SCALE: NONE
							210 P210 PAGE: 11.8

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESSNA SPEC. NO.
S-XXX OR CMXXXX-CESSNA
STD. NO.

SUPERSEDES:
12210-1073

SUPERSEDED BY:

MODEL P210 SERIES SERVICE MANUAL



CONTRACT NO:		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS	
NAME	DATE	Cessna AIRCRAFT CO.	
DESIGN	VR SIPS 1-28-71	TITLE	
GROUP	X W 2-25-71	WIRING DIAGRAM —	
DRAWN	VR SIPS 2-18-71	EYEBROW LIGHTS	
CHECK	A.K WHITE 2-28-71		
STRESS			
PROJ	111-10-71	SIZE	CODE IDENT
APPD	11-8	C	71379
OTHER		DWG NO	1270709
		SCALE: NONE	210 P210 PAGE: 11.8

(SR 6755) (21059503)

Eyebrow Lights (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

REVISION				REVISION			
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD
F	BY REV: ADD DETAIL B; LD53 WAS LD41 (SR8464)(SR8465)	DLP 6-6-77	JAB WHT JRS	A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	DLO	JRS
G	BY REV: RED/WHT LD62 (LD61 WAS LD45 (LD44, LD60 WAS LD43, LD59 WAS LD42, LD58 WAS LD53; 5-2099-7 WAS 66331-9 RED/WHT LD62 (LD61; 5-2353-2 WAS 66332-5/ LD59 (LD60 (SR8464)(SR8465)	JJB 8-29-77	JAB WHT JRS	B	BY REV: REACTIVATE DWG (SR7913)	GW 6-12-75	JRS
N	REV. CONT. ON P. 11.12.1			C	BY REV: 22 GA WAS 18GA LD36 THRU LD40 5-1635-1 WAS 5-1635-2, 5-1636-1 WAS 5-1636-2 (SR8143)	GDS 5-6-76	JRS
				D	BY REV: ADD (RED/WHT) TO LD39 (LD40 (NOW SHOP PRACTICE)	PH 8-25-76	JRS
				E	BY REV: ADD DETAIL "A" & SER (SR8464)	REG 4-28-77	JRS

NOTES:

- 1. 5-1360-5L CKT.BKR. REPLACED WITH 5-1360-10L CKT.BKR. WHEN TAIL FLOODLIGHT IS INSTALLED.

91600-20 91600-10

21	5-2350-9	CONNECTOR		LD 78	18	-18-2-9	5-2099-7	5-1636-1		
20	5-2349-9	CONNECTOR		LD69	18		5-1636-1	5-2353-1		
19	5-1640-9	HOUSING		LD63	18	-18-2-9	5-1636-1	5-2391-1		SER(SR9427) & ON
18	5-1641-9	HOUSING		LD63	18		5-1636-1	5-2415-1		SER(SR9427) & ON
17	6622008-004	CABLE ASSY		LD63	18	-18-2-9	5-2099-7	5-1636-1	STD	
16	6622008-0101	POWER SUPPLY		LD61	20	-20-2-9	5-2099-7	5-1636-1	STD	THRU SER(SR9427)
15	5-1360-10L	CIRCUIT BREAKER		LD60	18		5-1493-1	5-2353-1		
14	205841-1	CONNECTOR		LD59	20		5-1493-1	5-2383-1		THRU SER(SR9427)
13	205835-1	CONNECTOR		LD58	18		5-1367-6	5-1493-1		SER(SR8464) & ON
12	5-2349-2	CONNECTOR		LD40	18	-18-2-9	5-1636-1	5-1635-1	STD	
11	5-2350-2	CONNECTOR		LD59	18	-18-2-9	5-1636-1	5-1635-1	STD	
10	5-2349-1	CONNECTOR		LD38	18		100 5-1635-1	5-1493-1		
9	5-2350-1	CONNECTOR		LD37	18		200 5-1635-1	5-1493-1		
8	6622006-007	LAMP ASSY		LD36	22		18 5-1367-6	5-1493-1		THRU SER(SR8464)
7	6622008-0102	POWER SUPPLY								

WIRE TABLE

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th>PART NO.</th> <th>DESCRIPTION</th> </tr> <tr> <td>5</td> <td>5-1637-2 HOUSING</td> </tr> <tr> <td>4</td> <td>5-1640-6 HOUSING</td> </tr> <tr> <td>3</td> <td>5-1641-6 HOUSING</td> </tr> <tr> <td>2</td> <td>5-2160-1 SWITCH</td> </tr> <tr> <td>1</td> <td>5-1360-5L CIRCUIT BREAKER</td> </tr> </table>	PART NO.	DESCRIPTION	5	5-1637-2 HOUSING	4	5-1640-6 HOUSING	3	5-1641-6 HOUSING	2	5-2160-1 SWITCH	1	5-1360-5L CIRCUIT BREAKER	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">CONTRACT NO:</td> </tr> <tr> <td>DESIGN</td> <td>VR SIPES 3/25/72</td> </tr> <tr> <td>GROUP</td> <td>H. Hill 5-22-72</td> </tr> <tr> <td>DRAWN</td> <td>VR SIPES 5/22/72</td> </tr> <tr> <td>CHECK</td> <td>L.K. WHITE 5-17-72</td> </tr> <tr> <td>STRESS</td> <td></td> </tr> <tr> <td>PROJ</td> <td>1171(a-t) 5-23-72</td> </tr> <tr> <td>APPD</td> <td></td> </tr> <tr> <td>OTHER</td> <td></td> </tr> </table>	CONTRACT NO:		DESIGN	VR SIPES 3/25/72	GROUP	H. Hill 5-22-72	DRAWN	VR SIPES 5/22/72	CHECK	L.K. WHITE 5-17-72	STRESS		PROJ	1171(a-t) 5-23-72	APPD		OTHER		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: center;">Cessna AIRCRAFT CO.</td> <td colspan="2" style="text-align: right; font-size: small;">COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS</td> </tr> <tr> <td colspan="4" style="text-align: center;">WIRING DIAGRAM - WING TIP STROBE LIGHTS (OPT)</td> </tr> <tr> <td>SIZE</td> <td>CODE IDENT.</td> <td colspan="2">DWG NO</td> </tr> <tr> <td>C</td> <td>71379</td> <td colspan="2">1270709</td> </tr> <tr> <td colspan="2">SCALE: NONE</td> <td>210 P210</td> <td>PAGE: 11.12.0</td> </tr> </table>	Cessna AIRCRAFT CO.		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		WIRING DIAGRAM - WING TIP STROBE LIGHTS (OPT)				SIZE	CODE IDENT.	DWG NO		C	71379	1270709		SCALE: NONE		210 P210	PAGE: 11.12.0
PART NO.	DESCRIPTION																																																			
5	5-1637-2 HOUSING																																																			
4	5-1640-6 HOUSING																																																			
3	5-1641-6 HOUSING																																																			
2	5-2160-1 SWITCH																																																			
1	5-1360-5L CIRCUIT BREAKER																																																			
CONTRACT NO:																																																				
DESIGN	VR SIPES 3/25/72																																																			
GROUP	H. Hill 5-22-72																																																			
DRAWN	VR SIPES 5/22/72																																																			
CHECK	L.K. WHITE 5-17-72																																																			
STRESS																																																				
PROJ	1171(a-t) 5-23-72																																																			
APPD																																																				
OTHER																																																				
Cessna AIRCRAFT CO.		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS																																																		
WIRING DIAGRAM - WING TIP STROBE LIGHTS (OPT)																																																				
SIZE	CODE IDENT.	DWG NO																																																		
C	71379	1270709																																																		
SCALE: NONE		210 P210	PAGE: 11.12.0																																																	


CESS-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CESS-1000-CESSNA SPEC. NO.
S-1000 OR CM1000-CESSNA
STD. NO.

SUPERSEDES:
PG 11.11

SUPERSEDED BY:

(SE 7038) (21 059720)

MODEL P210 SERIES SERVICE MANUAL




CONTRACT NO.			COMMERCIAL AIRCRAFT DIV. 3800 E. PAWNEE WICHITA, KANSAS		
NAME	DATE	TITLE			
DESIGN	VR SIPES	3/25/72	WIRING DIAGRAM — WING TIP STROBE LIGHTS (OPT)		
GROUP	<i>H. White</i>	5-22-72			
DRAWN	VR SIPES	5/22/72			
CHECK	L.K. WHITE	5-17-72			
STRESS					
PROJ	<i>H.M. Galt</i>	5-23-72	SIZE	CODE IDENT. NO.	DWG NO
APPO			C	71379	1270709
OTHER			SCALE: NONE	210 P210	PAGE: 11.12.0

(SR 7038) (21 059720)


Wing Tip Strobe Lights (OPT) (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
H	BY REV: C622006-0107 WAS -0102 C622008-0102 WAS C622007-0103; ADD DETAIL C SER, ADD 205838-1, 205841-1, LD63, LD64, P 11.12.1 (SR9427) XSR8938(REF) 20 GA WAS 22 GA/LD37, LD38, LD39, LD40, LD58, LD59, LD60, LD61, LD62, LD63, LD64	C S 4-10-78 DLP	SAT WHT APC 11/1/8
J	BY REV: (SR9427) WAS (SR8863)/REVH; DETAIL "C", LD59, LD61, LD63 & LD64 (SR9427)	GDA 10-4-78	RSP WHT APC
K	BY REV: ADD FLAG NOTE 1. ON BUS BAR STROBE FLOOD WAS STROBE IN WIRE TABLE. 18 GA WAS 20 GA (SR10101 & SR10102)	WHA 5-26-82	RE W WGT/WHT P
L	BY REV: ADD DETAIL "D", C622008-0109, C622009-0101 (SR10662)	TMS 0-5-83	RE W WHT APC
M	BY REV: ADD 5-1641-9 & 5-1640-9, LH WING (NOW SHOP PRACTICE) DELETE DETAIL "D" (SR10662) ADD NEW DETAIL "D" & SERIALS SER OUT DETAIL "B" (SR10855)	KWL 8-21-84	RE W WHT APC P
N	BY REV: LD69 WAS LD67; LD70 WAS LD68; 5-1636-1 WAS 5-2341-1 (NOW SHOP PRACTICE)	KWL 2-6-85	RE W WHT APC



DETAIL C P 11.12.0
THRU SER (SR9427)



DETAIL D
(APPLIES TO P210)
SER (SR10855) & ON

SHEET 20 OF 20

CONTRACT NO.		Cessna AIRCRAFT CO.		PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE WIRING DIAGRAM— WING TIP STROBE LIGHTS (OPT)		
GROUP	SPENCER	4-17-78			
DRAWN	C SHAVER	4-10-78			
CHECK	RE HAIR	5-27-82			
STRESS					
PROJ	2-14-11-11	5-2-79	SIZE	CODE IDENT.	DWG NO.
APPO	APC		C	71379	1270709
OTHER			SCALE: NONE	(SR9427)	PAGE: 11.12.1

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD RED, YEL, GEN, BLK & SER: SER OUT LF10, LF11, LF12, LF13 & LF14. ADD NOTE 1 (SR7073)	DLP 1-10-73	BY NEW
B	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	DWD 5-3-73	BY NEW
C	BY REV: ADD DETAIL 'A' & SER'S: SER OUT LFG & LF7. SER IN LF15 (SR7913)	GW 9-17-75	BY NEW
D	BY REV: EFF OF DET 'A' WAS THRU (SR7913) (SR8482)	JCS 3-15-76	BY NEW
E	BY REV: 18 GA WAS 16 GA / LF15, BUR(LF14), BLK(LF13), GRN(LF12), YEL(LF11), RED(LF10), LF5; S-1367-1 WAS S-1367-2-8, S-1493-1 WAS S-1493-2 (SR8443)	TMS 5-21-76	BY NEW
F	BY REV: C594502-0102 WAS C594502-0101 (SR8552)	GDS 8-2-76	BY NEW
G	BY REV: ADD DETAIL 'B' & SER, LF16 & S-1360-10L (SR8464)	REG 4-28-77	BY NEW
H	BY REV: ADD WIRE LF17/P210 (SR8465)	GDS 6-6-77	BY NEW
J	BY REV: ADD PAGE 11.13.1, 16 GA JUMPER S-1640-6, S-1641-6 & FLAG NOTE 2; SER OUT LF13 & LF14; SER IN LF18, LF19, LF20 & LF21 (SR9310)	LWF 2-15-79	BY NEW
M	(CONTINUED ON PAGE 11.13.1)		

LF24	18			S-1635-1	S-1635-2	3	SER(SR10657) & ON
LF23	18			S-1635-2	S-1636-2	3	SER(SR10657) & ON
LF22	18			S-1636-2	S-1493-1	3	SER(SR10657) & ON
LF21	18	-18-0		SEE LFG	S-1493-1	3	SER(SR10657) & ON
LF20	18	-18-0		S-1636-3	S-1367-1-8	3	SER(SR9310) & ON
LF19	18	-18-0		S-1635-1	S-1636-3	3	SER(SR9310) THRU (SR10657)
LF18	18	-18-0		S-1635-3	S-1493-1	3	SER(SR9310) THRU (SR10657)
LF17	18			S-1493-1	S-1636-2	3	SER(SR8464) & ON
LF16	18			S-1367-2-6	S-1493-1	3	SER(SR8464) & ON
LF15	18			S-1493-1	S-1636-2	3	SER21061230 & ON
LF14	18	-18-0		S-1635-2	S-1367-1-8	3	SER21059887 THRU (SR9310)
LF13	18	-18-0		S-1493-1	S-1367-1-8	3	SER21059887 THRU (SR9310)
LF12	18	-18-0		S-1636-2	S-1493-1	3	SER21059887 THRU (SR9310)
LF11	16			75 S-1636-2	S-1635-2	3	SER21059887 THRU (SR9310)
LF10	16			75 S-1636-2	S-1635-2	3	SER21059887 THRU (SR9310)
LF7	16			75 S-1635-2	S-1636-2	3	SER21059887 THRU (SR9310)
LF6	16			125 S-1493-2	S-1635-2	3	SER21059887 THRU (SR9310)
LF5	18			7 S-1367-2-6	S-1493-1	3	SER21059887 THRU (SR9310)
LF4	16			S-1635-2	S-1367-2-8	3	THRU SER21059887
LF3	16			S-1493-2	S-1367-2-8	3	THRU SER21059887
LF2	16			S-1636-2	S-1493-2	3	THRU SER21059887
LF1	16			S-1636-2	S-1635-2	3	THRU SER21061229
LF0	16			S-1493-2	S-1635-2	3	THRU SER21061229
LF	18			7 S-1367-2-6	S-1493-1	3	THRU SER(SR8464)

9/60-97


13	S-2035-1	HOUSING-PLUG
12	S-2035-2	HOUSING-CAP
11	S-1360-10L	CIRCUIT BREAKER
10	C621001-0102	LIGHT ASSY
9	C594502-0102	FLASHER ASSY
8	OR95-6	RESISTOR
7	S-1638-1	HOUSING-PLUG
6	S-1637-1	HOUSING-CAP
5	S-1637-2	HOUSING-PLUG
4	1270705	CABLE ASSY
3	S-1638-2	HOUSING-CAP
2	S-2160-1	SWITCH
1	S-1360-8L	CIRCUIT BREAKER

WIRE TABLE			
WIRE CODE NO	GA	MATERIAL	LG

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXXX OR CMXXXX-CESNA STD. NO.		SUPERSEDES: PG 11.3		SUPERSEDED BY:	
CONTRACT NO:		NAME DATE		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN V R S I P E S 3/25/72		GROUP H. W. W. 5-22-72		TITLE WIRING DIAGRAM - FLASHING BEACON LIGHT	
DRAWN V R S I P E S 5-22-72		CHECK W H I P E 5/22/72		SIZE C	
PART NO. DESCRIPTION		PROJ H. W. W. 5-22-72		CODE IDENT. 71379	
EQUIPMENT TABLE		APPO		DWG NO 1270709	
OTHER		SCALE: NONE		210 P210 PAGE: 11.13.0	

(SR7038) & (21059720)

MODEL P210 SERIES SERVICE MANUAL



DETAIL A
EFF THRU SER (SR8482)
(2104129)

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 8800 E. PAWNEE WICHITA, KANSAS		
DESIGN	VR SIPS	3/25/72	 WIRING DIAGRAM— FLASHING BEACON LIGHT		
GROUP	N. Ward	3-22-72			
DRAWN	VR SIPS	5-22-72			
CHECK	WHITE	5-22-72			
STRESS			PROJ	APPO	OTHER
PROJ	Mini-Cat	5-23-72	SIZE	CODE IDENT. NO.	DWG NO
			C	71379	1270709
			SCALE: NONE	210 P210	PAGE: 11,13.0

Flashing Beacon Light (Sheet 2 of 2)


(SR 7038) (21059720)

MODEL P210 SERIES SERVICE MANUAL


NOTES:

1. COLORED WIRES BEARING CES 1100 CODING IN PARENTHESIS SHALL NOT BE STAMPED. CES 1100 CODING ON THESE WIRES IS FOR PARTS LIST USE ONLY
2. **INTERTWINE (LF19) WITH (LF11), (LF18) WITH (LF12) & (LF20) WITH (LF10) FROM COMPONENTS TO S-1641-6 HOUSING PLUG, INTERTWINE (LF21) WITH (LF15) & (LF17) P210**
3. **INTERTWINE (LF19) WITH (LF11), (LF18) WITH (LF12) & (LF20) WITH (LF10); INTERTWINE (LF21) WITH (LF15) & (LF17) P210. INTERTWINE (LF23) & (LF24) & (LF11), (LF25) & (LF26)**

REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED
K	BY REV: DELETE NOTE 2. ADD NOTE 3; BLK N-LF22 WIRE. S-2035-2 WAS S-1640-6 & S-2035-1 WAS S-1641-6. BLK WIRES (LF18), (LF19), (LF20), & (LF21) WERE WHT WIRES. (SR9310)	7-31-79	JAC MDR
L	BY REV: ADD DETAIL 'D'; REVISE NOTE 3 ADD LF 23 & LF 24 WIRES (SR10659)		WAAH TJP JAC
M	BY REV: REVISE DETAIL 'D'; S-K30-1 & S-K35-1 & -2 / TAIL; S-K36-3 WAS S-K35-1 / LF21 & LF22; SEE LF21 WAS S-K36-3 / LF23; S-K36-2 WAS S-K35-2 / LF24; ADD LF25 & LF26; REVISE NOTE 3 (SR10659)	2-13-81	TMS TJP JAC PR



DETAIL C
THRU SER (SR 9310)



DETAIL D
THRU SER (SR10659)

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	Cessna AIRCRAFT CO.		
GROUP	LW FINE	2-15-79	TITLE		
DRAWN	LW FINE	2-15-79	WIRING DIAGRAM—		
CHECK	C KING	2-15-79	FLASHING BEACON		
STRESS			LIGHT		
PROJECT			SIZE	CODE IDENT. NO.	OWG NO.
APPO			C	71379	1270709
			SCALE: NONE	Z10 PZ10	PAGE: 11.13.1

MODEL P210 SERIES SERVICE MANUAL

LET	DESCRIPTION	DATE	APPD	REVISION	DATE	APPD
J	CONTINUED ON PAGE 11-17.1					
<p>NOTES:</p> <p>1. TERMINATE VENDOR FURNISHED WIRE WITH S-1367-1-B</p> <p>2. S1493-1 TERMINAL REPLACES S1829-1 WITH OPT/POST LIGHTS ARE INSTALLED</p> <p>3. REQD ONLY WHEN OPT DIGITAL CLOCK C669511 IS INSTALLED</p>						
A	BY REV: BLK(LB128) WAS BLK(REF) (SR8465) (SR8464)			GDS	6-20-77	JAB WHT
B	BY REV: F-LB71 TO 34004-818 WAS 1270479-13; F-LB12 TO MS25231-1829 WAS 34004-818; RED/BLU(LA-116) WAS (LA-95); BLK(LA-111) WAS (LA-96); WHT(REF) WAS WHT/BLK(LB118); BLK(REF) WERE BLK(LB115), RED/BLU(LB116), RED(LB114); CHASSIS GND/MS25231-1829 WAS BLK(LB128) & BLK(LB117); ADD NOTE 1 (SR8464)(SR8465)			JJB	8-29-77	JAB WHT
C	BY REV: ADDED F-LB100, F-LB101, N-LB130, BLK(N-LB142), C660501-0102 COMPASS ASSY; NOTE 2; ADD LB143, NOTE 3, S2413-1 & MS25231-1819 (SR9187)			TFS CMK	7-13-78	JAB
D	BY REV: DELETE NOTE 2, BLK(N-LB142), N-LB130, F-LB101, F-LB100, C660501-0102 COMPASS ASSY (SR8464)(REF)			LSS	8 10 78	JAB
E	BY REV: ADD RED(F-LA123), BLK(F-LA124), RED(F-LA118) WAS RED/BLU(LA116); ON FLAGO WIRE: S-1370-1 WAS SOLDER; BLK(F-LA91) WAS LA91 & S-1370-1 WAS SOLDER (NOW SHOP PRACTICE) ADD A/C (OPT); RED(F-LA121), BLK(F-LA122) (SR9114)(SR9115)			MDR	4-6-79	JAB

20-516
41-0916


FN-LB151	22		S-1367-1-B	S-1367-1-B	SER(SR8711) 40W
FN-LB152	22		S-1367-1-B	S-1829-1	SER(SR8711) 40W
FN-LB153	22		S-1829-1	S-1370-1 (OPT)	3
RED (F-LA118)	22	-22-0	SOLDER	SELF-1491 (OPT)	SER(SR8711) 40W
RED (F-LA121)	22	-22-2	SOLDER	SELF-1490 (OPT)	
RED (F-LA123)	22	-22-0	SOLDER	SELF-1491 (OPT)	
RED (F-LA123)	22	-22-2	SOLDER	SELF-1490 (OPT)	SER(SR8711) 40W

14	S-2567-3	TERMINAL BOARD	
13	C669562	INST. CLUSTER	
12	C669561-0102	INST. CLUSTER	
11	C669561-0102	INST. CLUSTER	
10	S-2413-1	SOCKET	3
9	MS25231-1819	LIGHT	3
8			
7	MS25231-1829	LAMP	
6	S-1899-7	LIGHT ASSY	
5	34004-818	TERMINAL BOARD	
4	C669526-0101	INST. CLUSTER	
3	C669527-0101	INST. CLUSTER	
2	C669526-0101	INST. CLUSTER	
1	1270479-13	LIGHT ASSY	

RED (F-LA118)	22	-22-2	SEE L812	S-1370-1	
RED (F-LA118)	22	-22-2	SOLDER	SOLDER (OPT)	
RED (F-LA117)	22	-22-0	25	SOLDER	SOLDER (OPT)
RED (F-LA121)	22	-22-0	10	S-1370-1	S-1867-1-B (OPT)
RED (F-LA123)	22	-22-0	190	S-1829-1	S-1370-1 (OPT)
				S-1829-1	S-1870-2
				SEE L812	S-1829-1
				S-1829-1	S-1829-1
				SEE L270479	1270479
				SEE L270479	1270479

WIRE TABLE		
CONTRACT NO:		Cessna AIRCRAFT CO. 3800 E. PAWNEE WICHITA, KANSAS
DESIGN	WHITSON 4-22-77	
GROUP	W.D. HADSON 4-21-77	
DRAWN	G.L. RYAN 4-21-77	
EQUIPMENT TABLE		WIRING DIAGRAM - INSTRUMENT LIGHTS
PART NO.	DESCRIPTION	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CMXXXX-CESNA STD. NO.		TITLE WIRING DIAGRAM - INSTRUMENT LIGHTS
SUPERSEDES: PG 11.2 & 11.2.1		DWG NO 1270709
SUPERSEDED BY:		SIZE C
OTHER		CODE IDENT. NO. 71379
SCALE: NONE		DWG NO 1270709

MODEL P210 SERIES SERVICE MANUAL





CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 1900 E. PAWNEE WICHITA, KANSAS		
DESIGN	WHITSON	4-22-77	TITLE WIRING DIAGRAM— INSTRUMENT LIGHTS					
GROUP	W. H. H. H.	4-21-77						
DRAWN	G. L. RYAN	4-21-77						
CHECK	J. YOUNG	4-22-77						
STRESS								
PROJ	PLH & ORICE	4-24-77	SIZE	CODE IDENT. NO.	DWG NO			
APPO			C	71379	1270709			
OTHER			SCALE: NONE			210 P210 PAGE: 11.17 C		

(SRD464)


Instrument Lights (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL


REVISION			
LET	DESCRIPTION	DATE	APPO
F	BY REV: FN-LB153 WAS LB143 (SR9187)(REF) ADD DETAIL A, C669560-0102 & C669561-0102 (SR9711) FN-LB70 WAS F-LB70, FN-LB71 WAS F-LB71, FN-LB72 WAS F-LB72, FN-LB112 WAS F-LB112, RD (FN-LB114) WAS RD(LB114) (NOW SHIP PRACTICE)	SA 11-21-79	<i>SA</i> <i>11-21-79</i>
G	BY REV: ADD SER (SR 9556) A ON TO LA123, LA124, LA121 & LA122 WIRES (SR 9556)	WHH 1-28-80	<i>WHH</i> <i>1-28-80</i>
H	BY REV: ADD DETAIL 'B' & SERIALS (SR10148)	GW 3-5-81	<i>GW</i> <i>3-5-81</i>
J	BY REV: ADD DETAIL 'C' & SERIALS (SR10420) (SR 10641)	WHH 3-2-84	<i>WHH</i> <i>3-2-84</i>



DETAIL B
EFF THRU SER (SR10148)



DETAIL A
F. 11170
THRU SER (SR 9711)



DETAIL C
APPLIES TO P210
SER (SR 10641) & ON
APPLIES TO 210/T210 WITH OPT. INT. IGT
SER (SR 10420) & ON


WIRE	GA	MATERIAL	LG	TERMINALS	SERIALS
LB154	22		SEE LB112	51367-1-B	SER (SR 100148) CON

CONTRACT NO:			PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS		
DESIGN	ABRAHAM	12-11-79	Cessna AIRCRAFT CO. TITLE: WIRING DIAGRAM - INSTRUMENT LIGHTS		
GROUP					
DRAWN	ABRAHAM	11-21-79			
CHECK	BORLESKE	12-8-79			
STRESS					
PROJ			SIZE	CODE IDENT. NO.	DWG NO.
APPO	<i>SA</i>		C	71379	1270709
OTHER			SCALE: NONE	210 P210	PAGE: 11.17.1

(SR 9711)

MODEL P210 SERIES SERVICE MANUAL


REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD DETAIL A, LB144 & SER, 2470003 (SR9114)	DLP 2-20-79	JAB
B	BY REV: BLK LB150 WAS BLK LB144 (SR9114)(SR9115)	HFG 5-21-79	JAB
C	BY REV: ADD DETAIL "B", "C"; RG1118, BLK(FN-LB169), BLK(FN-LB165), BLK(FN-LB166), S2527-2 & -1, SER OUT BLK(2) & BLK(1) (SR10101)(SR10102)	MKT 1-27-82	JAB



DETAIL A
THRU SER (SR9114)

NOTES:

1. THESE WIRES VENDOR FURNISHED
2. RESISTOR WIRE IS TERMINATED WITH S1367-1-14 TERMINAL & INSTALLED ON BUSHING OF THE TANDEM POT ASSY
3. WHEN ELECTROLUMINESCENT PANELS ARE INSTALLED, S2091-3 POT ASSY REPLACES S1904-2 POT ASSY



WIRE CODE NO.	GA	MATERIAL	LS	TERMINALS	SERIALS
BLK(FN-LB144)	22	-22-0	51370-1	S2099-4	SER(SR10101)(SR10102)
BLK(FN-LB144)	22	-22-0	51370-1	S2099-4	SER(SR10101)(SR10102)
BLK(FN-LB144)	22	-22-0	85969-6	S2099-4	SER(SR10101)(SR10102)
BLK(LB150)	22	-22-0	85969-6	S1367-1-8	SER(SR10101)(SR10102)
ORN(F-LB113)	22	-22-3	51370-1	85969-6	
BLK(2)	22	-22-0	51367-1-8		THRU SER(SR10101)(SR10102)
BLK(1)	22	-22-0	51367-1-8		THRU SER(SR10101)(SR10102)
F-LB14	22		62	51370-1	SEE ORN
F-LB15	22		63	51370-1	SOLDER
RED(F-LB121)	22	-22-2	65	51829-1	51370-1

PART NO.	DESCRIPTION
11	S2527-2 GND CONNECTOR
10	S2527-1 LN GND BLOCK
9	2470003 AUDIO CONTROL PNL
8	87149-1 CONNECTOR
7	0570442 AUDIO CONTROL PNL
6	1213782 PANEL ASSY
5	2113027 PANEL ASSY
4	VAL-5-6000 RESISTOR
3	S2091-3 POT ASSY
2	C613001-0101 POWER SUPPLY
1	34-003-817 TERM. BLOCK

EQUIPMENT TABLE			WIRE TABLE		
CONTRACT NO:			Pawnee DIVISION 5000 E. PAWNEE WICHITA, KANSAS		
DESIGN	W.L. HALDEN	2-25-77	TITLE		
GROUP	W.L. HALDEN	4-21-77	WIRING DIAGRAM -		
DRAWN	G.L. RYAN	4-21-77	ELECTROLUMINESCENT PANEL		
CHECK	J. YOUNG	4-22-77	(OPT)		
STRESS					
PROJ	PLH/FR/DRK	4-26-77	SIZE	CODE IDENT.	DWG NO
APPD			C	71379	1270709
OTHER			SCALE: NONE	210	PAGE: 11.18.0

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-XXX OR CXX000-CESNA STD. NO.

SUPERSEDES: PG 11.1.0 & 11.1.1

SUPERSEDED BY:


(SR8464)

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
C	SEE PAGE 11.18.0 FOR REVISION		



DETAIL **13** PG 11.18.0
THRU SER (SR10101)(SR10102)



DETAIL **6** PG 11.18.0
THRU SER (SR10101)(SR10102)





02-009/6
01-009/6

CONTRACT NO:		Cessna AIRCRAFT CO.		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE: WIRING DIAGRAM ELECTROMINESCENT PANEL (OPT)		
GROUP					
DRAWN	M THOMPSON	1-27-62			
CHECK	BORLESKE	1-28-62			
STRESS					
PROJ	J. L. MORRIS	3-26-62	SIZE	CODE IDENT.	DWG NO.
APPO	AR		C	71379	1270709
OTHER			SCALE NONE		PAGE: 11.18.1

(SR10101)(SR10102)

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
B	SEE PAGE 11.19.2 FOR REVISION		



THIS DIAGRAM APPLIES TO P210 THRU SER (5210641)

40-00916
91-00916


CONTRACT NO:			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE			TITLE
GROUP	SPENCER	4-25-77	WIRING DIAGRAM - POST LIGHTING (OPT)		
DRAWN	<i>E. Youngers</i>	4-18-77			
CHECK	<i>J. Youel</i>	4-19-77			
STRESS					
PROJ	<i>40-00916</i>	<i>3-21-77</i>	SIZE	CODE IDENT. NO.	UWG NO.
APPO	<i>Steve</i>		C	71379	1270709
OTHER			SCALE: NONE	(52844) (52845)	PAGE: 11.19.1

MODEL P210 SERIES SERVICE MANUAL

NOTES:

1. WHEN POST LT OPTION IS INSTALLED 1570301-1 DIMMING ASSY REPLACES 1570166 & S-2091-7 POT ASSY REPLACES S-1904-2
2. THIS POT IS PART OF S-2091-7 DUAL POT ASSY WHEN OPTIONAL EL LIGHTING IS INSTALLED

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV. ADD DETAIL "A" & "B", S2527(1,2), BLK(FN-LB167), BLK(FN-LB168), SER OUT LB125 & LB127 (SR111)(SR112)	MKT 1-27-82	JAB LONN 9RS
B	BY REV. ADD SER. & MODEL APPL. TO FACE OF DWG. (S10641)	WJH 3-2-84	COY 1/15



22-000016
22-000016

REF	QTY	DESCRIPTION	TERMINALS	SERIALS
LB139	22	-22-0	S-1635-1 S2099-4	SER(SR1001)SR1010/11/12/13/14/15/16/17/18/19/20/21/22
LB133	22	-22-0	S-1635-1 S2099-4	SER(SR1001)SR1002/13/14/15/16/17/18/19/20/21/22
LB138	1		S-1635-1 S-1829-1	
LB122	1		S-1635-1 SOLDER	
LB123	1		S-1635-1 S-1829-1	
LB125	1		S-1636-1 S-1367-1-8	THRU SER(SR1010)SR1012
LB127	1		S-1636-1 S-1367-1-8	THRU SER(SR1010)SR1012
BLK(2)	-22-0		SOLDER SOLDER	
BLK(LB)	-22-0		SOLDER S-1636-1	
RED(2)	-22-2		SOLDER SOLDER	
RED(LB)	-22-2		SOLDER S-1635-1	
LB126	1		S-1829-1 S-1636-1	
LB124	22		S-829-1 S-1636-1	

PART NO.	DESCRIPTION
14	S2527-2 GND CONNECTOR
13	S2527-1 LN GND BLOCK
12	S-2000C201J RESISTOR
11	1513837 POST LT ASSY
10	S-1637-1 HOUSING
9	S-1637-2 HOUSING
8	S-2091-7 POT ASSY
7	S-1904-2 POT ASSY
6	S-1360-5L CIRCUIT BREAKER
5	34004-A18 TERMINAL BLOCK
4	34003-A17 TERMINAL BLOCK
3	S-1640-9 HOUSING
2	S-1641-9 HOUSING
1	1570301 DIMMER ASSY


WIRE TABLE			CONTRACT NO.:	
DESIGN	NAME	DATE	Cessna, AIRCRAFT CO.	
DESIGN	SPENCER	2-14-79	PAWNEE DIVISION 5000 E. PAWNEE WICHITA, KANSAS	
GROUP	Dillard	2-2-79	WIRING DIAGRAM - POST LIGHTING (OPT)	
DRAWN	H. JAZAMAN	2-12-79		
CHECK	BORLESKE	2-13-79		
STRESS			SIZE	CODE IDENT. DWG NO
PROJ	7-5-79		C	71379 1270709
APPD			SCALE: NONE (SR 914)(SR 915) PAGE: 11, 19, 2	
OTHER				

EQUIPMENT TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-300X OR C10000-CESNA STD. NO.	SUPERSEDES: PAGE 11, 19, 0 SUPERSEDED BY:

MODEL P210 SERIES SERVICE MANUAL

B	BY REV ADD BLK(LA119),S1637-14-2; S1-35-1 WAS DISC7-1-8/LA112 (MER P210 80688)	BGR 10-25-78	JAS 1/83
C	BY REV: ADD DETAIL A (PAGE 11.22.1) (SR9115)	HMG 2-2-79	JAS 1/83

LET	DESCRIPTION	DATE	APPO
A	BY REV: S-2099-7/GRN(LA103) WAS 66331-5, S-2353-2/LA101 WAS 66332-5 LA106 WAS TO CNT BKR; SEE LA105/LA106 WAS S-1637-1-6 (SR8465)	JJB 8-29-77	JAS 1/83



WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
22	-22-0	S-1635-1	S1367-1-8		
22	-22-0	SOLDER	S-1636-1		
22		S-1635-1	SOLDER		
22		S-1635-1	SOLDER		
		SEE LA107	S-1636-1		
		SEE LA107	S-1636-1		
		S-1830-1	S-1370-2		
		SEE LA105	S-1830-1		
22		S-1367-1-6	S-1370-2	OPT	
22		S-1635-1	S-1367-1-8	OPT	
22		S-2099-7	S-1636-1		
22		SOLDER	S-1636-1	OPT	
22		SEE LA107	S-2353-2	OPT	
22		SEE LA105	SOLDER	OPT	
22		S-1635-1	S-1367-1-8	OPT	
		BELDEN 8529	SOLDER	S-1636-1	
		BELDEN 8529	S-1635-1	SOLDER	
			SOLDER	S-1636-1	
		SEE LA105	SOLDER		
			S-1635-1	S-1367-1-8	
		BELDEN 8529	SOLDER	S-1636-1	
		BELDEN 8529	S-1635-1	SOLDER	
			SOLDER	S-1636-1	
		SEE LA105	SOLDER	OPT	

PART NO.	DESCRIPTION
10	S-2349-1 CONNECTOR
9	S-2350-1 CONNECTOR
8	S-1884-2 LIGHT ASSY
7	1115M42 SWITCH
6	GE 313 LAMP
5	S-1831-1 SWITCH
4	S-1637-1 HOUSING
3	S-1637-2 HOUSING
2	S-1360-5L CIRCUIT BREAKER
1	122103-2 LIGHT ASSY

EQUIPMENT TABLE			WIRE TABLE		
CONTRACT NO:			Cessna AIRCRAFT CO.		
DESIGN	SPENCER	6-20-77	PAWNEE DIVISION 3600 E. PAWNEE WICHITA, KANSAS		
GROUP	W. H. Haden	6-23-77	TITLE		
DRAWN	SCHIFFELBEIN	6-6-77	WIRING DIAGRAM - DOME, COURTESY, BAGGAGE & OXYGEN LIGHTS		
CHECK	BOHLE SKE	6-1-77			
STRESS					
PROJ	P111 128 100	6-24-77	SIZE	CODE IDENT.	DWG NO
APPO	JAS		C	71379	1270709
OTHER			SCALE	NONE	P210 PAGE: 11.22.0


CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-1000-CESNA SPEC. NO.
S-1001 OR C10000-CESNA
STD. NO.

SUPERSEDES:
SUPERSEDED BY:

(SR8465)

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
C	SEE P 11.22.0 FOR REV.		




DETAIL A
(APPLIES WHEN AIR CONDITIONING OPTION IS INSTALLED)

15-091G

CONTRACT NO. 1			PAWNEE DIVISION 8800 E. PAWNEE WICHITA, KANSAS		
Cessna AIRCRAFT CO.			TITLE: WIRING DIAGRAM DOME, COURTESY, BAGGAGE & OXYGEN LIGHTS		
DESIGN	SPENCER	2-5-79			
GROUP	<i>W.H. Hand</i>	2-6-79			
DRAWN	HGHAZARIAN	2-2-79			
CHECK	BORLESKE	2-2-79			
STRESS			SIZE	CODE IDENT. NO.	DWG NO.
PROJ	<i>F. J. ...</i>	2-12-79	C	71379	1270709
APPO	<i>APB</i>		SCALE: NONE		(SR 9115)
OTHER			PAGE: 11.22 !		

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: ADD LA118 S-1637-1 & S-1637-2; KR 6479 WAS R12Y2 (SR8465) (REF)	DLP 12-9-77	JAB/WH
B	BY REV: ADD BLK (LA120) S-1637-1 & S-1636-1 WAS S-1367-1-B/LA115 (MEP210 EO 688)	BGL 10-25-78	JAB/WH BPS



WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
LA120	22	-22-0		S-1635-1 S-1367-1-B	
LA118	22	-22-0		S-1636-1 SOLDER	
BLK (LA115)	22	-22-0		S-1367-1-B S-1636-1	
RED (LA114)	22	-22-2		SOLDER S-1367-1-B	
LA113	22			S-1830-1 S-1635-1	

PART NO.	DESCRIPTION	QUANTITY	REMARKS
7	S-1637-2 HOUSING		
6	S-1637-1 HOUSING		
5	KRG479 RHEOSTAT	175 Ω	
4	S-1831-1 SWITCH		
3	S-1360-5L CKT BKR		
2	GE1495 BULB		
1	2393 LIGHT ASSY		

WIRE TABLE			
CONTRACT NO.	NAME	DATE	TITLE
	SPENCER	6-20-77	WIRING DIAGRAM — FLOOD LIGHT (OPTIONAL)
	PAPE	6-7-77	
	BORLESKE	6-7-77	
	DRILL	6-21-77	
APPO			
OTHER			

Cessna AIRCRAFT CO. PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS	SIZE: C CODE IDENT. NO.: 71379 DWG NO.: 1270709
SCALE: NONE	P210 PAGE: 11.23

EQUIPMENT TABLE	
PART NO.	DESCRIPTION

CESS-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CESS-1000-CESSNA SPEC. NO.
 S-100 OR CESSNA-CESNA
 STD. NO.

(SR8465)

MODEL P210 SERIES SERVICE MANUAL

- 1. TERMINATE VENDOR FURNISHED WIRES WITH S-1635-1
- 2. TERMINATE VENDOR FURNISHED WIRES WITH S-1367-1-B
- 3. TERMINATE VENDOR FURNISHED WIRE W/S1636-1

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD BLK TO(N-LB141) (SR8464)(REF)(SR8465)(REF)	LSS 8-10-78	JAB WJK
B	BY REV: ADD BLK(L888)(REF), WHT(REF) WAS BLK(REF), BLK(REF) WAS WHT(REF) LB103 WAS RED LB103, LB104 WAS RED LB104, S-1370-1 WAS S-1636-1 MER 210 EOG 67	HGG 3-21-79	JRS
C	BY REV: ADD 2315-1, GE1495. F-LB146, N-LB147, BLK(FN-LB148), DETAIL 'A'. (SR9114)(SR9115)	MDR 4-6-79	EIF
D	BY REV: DO DETAIL A. SER(SR9556) AND WAL SER(SR9514) (SR9115) 1-Y (SR9556)	WHH 1-28-80	WHH JRS JRS
D	BY REV: ADD DETAIL B. ADD-LB155 THRU-LB162 WIRES. ADD (R2061) (R2062) BLK(119) BLK(121) WIRES. ADD POST LTS FOR TACH, TWO KAO10 IND. & SECOND ALT AS STANDARD. (SR9553)(SR9554)	WHH 3-24-81	JRS JRS
H	SEE PAGE 11.24.1 FOR REVISION		


2800916 8/1-00916

FLK(1)	22	-22-0	SOLDER	SOLDER	SER(SR9953)(SK9954) & ON
FLK(1)		-22-0	S-1636-1	SOLDER	
(R212)		-22-2	SOLDER	SOLDER	
(R212)		-22-2	S-1636-1	SOLDER	SER(SR9953)(SK9954) & ON
N-LB162			S-1635-1	S-1637-1-B	SER(SR9554) THRU SER(SR10107)
F-LB161			S-1635-1	S-1637-1-B	SER(SR9554) THRU SER(SR10111)
N-LB160			S-1829-1	S-1635-1	SER(SR9554) THRU SER(SR10641)
F-LB159			S-1829-1	S-1635-1	SER(SK9953) & ON
N-LB158			S-1636-1	S-1637-1-B	SER(SR9554) THRU SER(SR10102)
F-LB157			S-1636-1	S-1637-1-B	SER(SR9554) THRU SER(SR10101)
N-LB156			S-1829-1	S-1635-1	SER(SR9554) THRU SER(SR10641)
F-LB155			S-1829-1	S-1635-1	SER(SK9953) & ON
F-LB154	22	-22-0	S-1636-1	S-1637-1-B	(LOPT) SER(SR9556) & ON
N-LB147	22		S-1636-1	S-1829-1	(LOPT) SER(SR9556) & ON
F-LB146	22		S-1636-1	S-1829-1	(LOPT) SER(SR9556) & ON
F-LB145	22	-22-0	S-1635-1	S-1637-1-B	THRU SER(SR10101)(SR10102)
N-LB140			S-1636-1	S-1829-1	
N-LB129			S-1636-2	S-1829-1	
LB105			S-1829-1	S-1635-1	
LB104			SOLDER	S-1636-1	
LB103			SOLDER	S-1370-1	
F-LB102			S-1636-2	S-1829-1	
F-LB101			S-1635-1	S-1367-1-B	THRU SER(SR10101)(SR10102)
F-LB100	22		S-1329-1	S-1636-1	

PART NO.	DESCRIPTION	MATERIAL	LG	TERMINALS	SERIALS
18	S2527-2	GND CONNECTOR			
17	S2527-1	LH GND BLOCK			
16	2113026	COVER ASSY - RH			
15	1513037	POST LT. ASSY			
14	2113025	COVER ASSY - LH			
13	GE1495	BULB			
12	2315-1	LIGHT ASSY			
11	34004-018	TERMINAL BLOCK			
10	1213319	LIGHT ASSY			
9	S-1695-2	SWITCH			
8	S-1637-2	HOUSING			
7	S-1637-1	HOUSING			
6	34003-017	TERMINAL BLOCK			
5	S-2035-2	HOUSING - PLUG			
4	S-2035-1	HOUSING - CAP			
3	C660501	COMPASS ASSY			
2	MS15504-16	MINIATURE LAMP			
1	0513208	SOCKET			

EQUIPMENT TABLE			WIRE TABLE			
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-1000 OR C1000-CESNA STD. NO.			CONTRACT NO:			
			NAME		DATE	PAWNEE DIVISION 3600 E. PAWNEE WICHITA, KANSAS
			DESIGN		TITLE	
			GROUP		DRAWN	
			CHECK		STRESS	
APPRO		OTHER				
SUPERSEDES: PAGE 11.7.1			Cessna AIRCRAFT CO. WIRING DIAGRAM - CONSOLE & COMPASS LIGHTS			
SUPERSEDED BY:			PROJ	PLNDRILL	3-21-79	
			APPD	JRS		
			SIZE	C	CODE IDENT. NO.	
			DWG NO	1270709		
			SCALE	NONE	210. P210	
			PAGE	11.24.1		


MODEL P210 SERIES SERVICE MANUAL



CONTRACT NO:			Cessna AIRCRAFT CO.		PAWNEE DIVISION 1800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE			TITLE	
GROUP	SPENCER	12-1-77	WIRING DIAGRAM — CONSOLE & COMPASS LIGHTS			
DRAWN	<i>W. J. ...</i>	3-17-78				
CHECK	S. MONTKO	11-28-77				
STRESS	BORLESKE	11-29-77				
PROJ	PLHEDRICK	3-21-78	SIZE	CODE IDENT.	DWG NO	
APPD	<i>W.S.</i>		C	71379	1270709	
OTHER			SCALE: NONE	Z10. P210	PAGE: 11.24.C	


Console & Compass Lights (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL




DETAIL F
 APPLIES TO P210
 SER (SR10641) & ON
 APPLIES TO 210/T210 WITH OPT. INT. LTS.
 SER (SR10420) & ON

REVISION			
LET	DESCRIPTION	DATE	APPRO
E	BY REV. ADD 1513837(4) & PAGE 11.24.1 (SR9953)(SR9954)	MKT 8-18-81	JAB WHH / JRS
F	BY REV. ADD DETAIL C, BLK(F-LB169), BLK(N-LB170), SER OUT BLK(N-LB141), F-LB101; ADD 52527(-1-2), 6660501 WAS 6660501-0102 (SR10101) (SR10102)	MKT 1-27-82	JAB WHH / JRS
G	BY REV. ADD DETAIL D & E (SR10101) (SR10102)	GLS 6-28-82	JRS
H	BY REV. SER OUT N-LB156, N-LB160, BLK(N-LB173) & BLK(N-LB175) WIRES. ADD DETAIL F & SERIALS. (SR10420)(SR10641)	WHH 3-2-84	WHH / JRS



DETAIL A
 SER(SR9856) & ON
 (APPLIES WITH OPTIONAL AIR CONDITIONING)



DETAIL D
 THRU SER (SR10101) (SR10102)

TERMINAL	GA	MATERIAL	LG	TERMINALS	SERIALS
22	-22-0			5-1636-1 5-2099-4	SER(SR10102) THRU SER(SR10641)
22	-22-0			5-1636-1 5-2099-4	SER(SR10101) & ON
22	-22-0			5-1636-1 5-2099-4	SER(SR10102) THRU SER(SR10641)
22	-22-0			5-1636-1 5-2099-4	SER(SR10101) & ON
22	-22-0			5-1635-1 5-2099-4	SER(SR10101) & ON
22	-22-0			5-1635-1 5-2099-4	SER(SR10102) & ON

WIRE TABLE

CONTRACT NO:			Cessna AIRCRAFT CO.		
DESIGN	NAME	DATE	PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS		
GROUP	W. J. Thompson	8-24-81	TITLE WIRING DIAGRAM - CONSOLE & COMPASS LIGHTS		
DRAWN	M. J. Thompson	8-18-81	SIZE C		
CHECK	BORLESKE	8-24-81	CODE IDENT. NO. 71379		
STRESS			DWG NO. 1270709		
PROJ	JRS	4-18-81	OTHER		
APPRO			SCALE NONE		
OTHER			PAGE: 11.24.1		

PART NO.	DESCRIPTION
EQUIPMENT TABLE	
CEE-1000 IS APPLICABLE VENDOR CODES PER S-1400 CEE-1000-CESNA SPEC. NO. S-300X OR C10000-CESNA STD. NO.	
SUPERSEDES: SUPERSEDED BY:	



20 00716 91-00716

MODEL P210 SERIES SERVICE MANUAL


NOTES:

▶ INSTALL 5-1636-1 ON VENDOR WIRE

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD NOTE 1, DETAIL "A", LK7 & LK8 BLK(LK9) & BLK(LK10) (SR9884)	DEC 1-9-80	LAB/UNNA
B	BY REV: ADD DETAIL "B" (SR10101) (SR10102)	UNNA 2-26-82	UNNA



DETAIL A
THRU SER(SR9884)



DETAIL B
THRU SER(SR10101) (SR10102)

02-00916
01-00916

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK(LK10)	18	-18-0		5-1367-4 5-1367-8	SER(SR9884) (ON CALL SPARES)
BLK(LK9)	18	-18-0		5-1367-4 5-1367-8	
LK8				5-1635-1 SEE LK7	
LK7				5-1635-1 5-1636-3	SER(SR9884) (ON CALL SPARES)
BLK(LK6)		-18-0		5-1367-16 5-1367-1-8	THRU SER(SR9884)
BLK(LK5)		-18-0		5-1367-1-8	
LK4				SEE LK3	
LK3				5-1367-1-6 5-1636-3	THRU SER(SR9884)
LK2				5-1493-1 5-1635-1	
LK1	18			5-1367-1-6 5-1493-1	

PART NO.	DESCRIPTION
6	00033092 LIGHT ASSY
5	5-1637-2 HOUSING
4	5-1637-1 HOUSING
3	5-1360-101 CKT BKR
2	00033051 LIGHT ASSY
1	5-2160-1 SWITCH

EQUIPMENT TABLE

CEB-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CEB-1001-CESSNA SPEC. NO.
S-1331 OR C13000-CESSNA
STD. NO.

SUPERSEDES:
SUPERSEDED BY:

WIRE TABLE

CONTRACT NO:

NAME: Spencer DATE: 2-14-79

DESIGN: Spencer DATE: 2-14-79

GROUP: Will Haden DATE: 3-3-79

DRAWN: H. GHAZARIAN DATE: 2-9-79

CHECK: BOLESKE DATE: 2-12-79

STRESS:

PROJ: [Signature] DATE: 3-1-79

APPRO: [Signature]

OTHER:

CESSNA AIRCRAFT CO. PAWNEE DIVISION
3600 E. PAWNEE WICHITA, KANSAS


**WIRING DIAGRAM —
VERTICAL TAIL
ILLUMINATION LIGHT (OPT)**

SIZE: C CODE IDENT. NO: 71379 DWG NO: 1270709

SCALE: NONE (SR 914) (SR 915) PAGE: 11, 25

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD MODEL APPLICATION & SEE TO FIELD OF DWG. ADD R1126.1 (SR 10641)	WMA 3-2-84	281 WMA JRS M



41-0916

N-LB137	22	S-1635-1	SOLDER
F-LB12	22	S-1635-1	SOLDER
N-LB135	18	S-1829-1	S-1635-1
F-LB5	18	S-1829-1	S-1635-1
N-LB136	22	S-1635-1	SOLDER
F-LB11	22	S-1635-1	SOLDER
N-LB134	22	SEE N-LB13	SOLDER
F-LB10	22	SEE F-LB13	SOLDER
N-LB132	18	S-1635-3	S-1367-4
F-LB131	18	S-1635-3	S-1367-4
N-LB133	18	S-1635-1	S-1829-1
F-LB13	18	S-1635-1	S-1829-1
N-LB145	22	SEE N-LB43	SOLDER
F-LB44	22	SEE F-LB42	SOLDER
N-LB143	18	S-1635-3	S-1367-4
F-LB142	18	S-1635-3	S-1367-4

11	S-2091-7	POT ASSY
10	S-1570301	DIMMING ASSY
9	S-2567-3	TERMINAL BLOCK
8	S-2000020W	RESISTOR
7	E-1904-2	POT ASSY
6	34003-817	TERMINAL BLOCK
5	S-1360-5L	CIRCUIT BREAKER
4	34004-818	TERMINAL BLOCK
3	S-1640-6	HOUSING-PIN
2	S-1641-6	HOUSING-SOCKET
1	S-1570166	DIMMING ASSY

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
---------------	----	----------	----	-----------	---------


PART NO.	DESCRIPTION
----------	-------------

EQUIPMENT TABLE	
-----------------	--

CONTRACT NO:			Cessna AIRCRAFT CO.		PAWNEE DIVISION 3000 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE			
SPENCER		2-19-79	WIRING DIAGRAM - FLOOD, ENGINE INST & RADIO LIGHTS			
GROUP	<i>D. H. Hasler</i>	3-2-79				
DRAWN	<i>AGHAZARIAN</i>	2-12-79				
CHECK	<i>BORLESKE</i>	2-12-79				
STRESS						
PROJ	<i>J. J. ...</i>	3-1-79	SIZE	CODE IDENT. NO.	DWG NO	
APPD	<i>JRS</i>		C	71379	1270709	
OTHER			SCALE: NONE	SR914(SR915)	PAGE: 11. 26	

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD



THIS DIAGRAM APPLIES TO P210 SER (SR10641) & ON


CONTRACT NO:			Cessna AIRCRAFT CO.		PAWNEE DIVISION	
					5800 E. PAWNEE	
DESIGN	WARDEN	2-17-84	TITLE: WIRING DIAGRAM- FLOOD, INSTRUMENTS & RADIO DIAL LIGHTS			
GROUP	W.H.H. dew	2-17-84				
DRAWN	WARDEN	2-17-84				
CHECK	R E HUB	3-2-84				
STRESS						
PROJ	AR Smith	3-2-84	SIZE	CODE IDENT. NO	DWG NO.	
APPD			C	71379	1270709	
OTHER						
			SCALE: NONE	(SR10641)	PAGE: 11, 26-1	

MODEL P210 SERIES SERVICE MANUAL

NOTES:

- 1. MATERIAL IS RCF5130B COIL CORD
VENDOR CODE (086906)
- 2. NOT REQUIRED WHEN INSTALLED WITH
OPT. ELECTRIC TRIM. REFER TO PG. 11.13.1

REVISION			
LET	DESCRIPTION	DATE	APPD



QTY	PART NO.	DESCRIPTION	WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
12	5-1985-1	MIKE SWITCH						
11	24RB	LAMP	FN-LB176	22			5-2099-9	5-2099-9
10	4157-001	SOCKET	FN-LB177	22			5-2099-9	5-1825-1
9	3859A161-52A	RHEOSTAT	BLK	22			5-1570-1	SOLDER
8	5-2527-2	GND CONNECTOR	WHT/RED	24	1		SOLDER	5-2353-2
7	5-2527-1	GND BLOCK						
6	5-2399-1	HOUSING						
5	5-2350-3	HOUSING						
4	2270030	CABLE ASSY						
3	34003-817	TERMINAL BLOCK						
2	5-2160-1	SWITCH						
1	5-1360-5L	CKT BKR						

WIRE TABLE

CONTRACT NO:					PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	SPENCER	9-8-83	TITLE			
GROUP	W.H. Gardner	5-22-83	WIRING DIAGRAM -- MAP LIGHT-CONTROL WHEEL			
DRAWN	SPENCER	7-8-83				
CHECK	RE HAIR	7-12-83				
STRESS						

CES-1000 IS APPLICABLE
VENDOR CODES PER 8-1400
CES-1000-CESNA SPEC. NO.
8-1001 OR C81000-CESNA
STD. NO.

SUPERSEDES:
PG. 11.27
SUPERSEDED BY:

PROJ: *PRC 10-1-83*
APPD: *[Signature]*
OTHER:

SIZE: C
CODE IDENT. NO.: 71379
DWG NO.: 1270709
SCALE: NONE (SR10713) | PAGE: 11.28

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD LB207, LB208, LB209, LB210, LB211, LB212, LB213, LB214, LB215 ADD PARTS 11, 12, 2 (SR10420X SR10641)	KWL 1-7-85	<i>234 JH</i> <i>1100 JRS</i>

NOTES:


- 1 THIS IS THE ALTERNATE LOCATION FOR THE ALTIMETER WHEN THE ENCODING ALTIMETER IS INSTALLED. THE S-2055-2 HOUSING FOR INTERNAL INSTRUMENT LIGHTING IS TO BE INSTALLED AS STANDARD AT THIS LOCATION.
- 2 THE PRODIGE AMMETER & RMI ARE OPTIONAL. HOWEVER THE S-2055-2 HOUSING FOR INTERNAL INSTRUMENT LIGHTING IS TO BE INSTALLED AS STANDARD AT THESE LOCATIONS.

FNLB215	22	SEE LB208	S1636-2
F-LB214		S-1829-1	SEE LB203
F-LB213		S-1829-1	S-1636-2
F-LB212		SEE LB195	S1636-2
F-LB211		S-1829-1	SEE LB183
FNLB210		SEE LB198	S-1636-2
FNLB209		SEE LB210	S-1636-2
FNLB208		SEE LB186	S-1636-2
N-LB207		S-1829-1	S-2055-2
FNLB206		SEE LB200	S1636-1
FNLB205		SEE LB186	S1636-1
N-LB204		S1829-1	S1636-0
FNLB203		S1636-2	S1636-1
FNLB202		SEE LB200	SEE LB201
FNLB201		S-1829-1	S1636-2
FNLB200		SEE LB199	S1636-2
	199	SEE LB199	S1636-2
	198	SEE LB197	
	197	SEE LB196	
	196	SEE LB195	
FNLB195		S1636-2	S1636-2
N-LB194		SEE LB193	SEE LB195
N-LB193		SEE LB192	S1636-2
N-LB192		S-1829-1	S-1636-2
FNLB191		S1636-2	S1636-1
FNLB190		SEE LB187	SEE LB191
FNLB189		S-1829-1	S1636-2
FNLB188		SEE LB187	S1636-2
	187	SEE LB186	S1636-2
	186	SEE LB185	S1636-2
	185	SEE LB184	
	184	SEE LB183	
FNLB183		S1636-2	S1636-2
N-LB182		SEE LB181	SEE LB183
N-LB181		SEE LB180	S1636-2
N-LB180	22	S-1829-1	S-1636-2

7	S-2527-2	GND. CONNECTOR						
6	S-2527-1	GND. BLOCK						
5	S1636-1	HOUSING						
4	S-2055-2	HOUSING						
3	CM2990G1	LIGHT ASSY.						
2	S-2567-B	TERMINAL BLOCK						
1	34004-B1B	TERMINAL BLOCK						
EQUIPMENT TABLE								
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-100X OR C1000X-CESNA STD. NO.		SUPERSEDES: SUPERSEDED BY:						
CONTRACT NO.: DESIGN: WARDEN 3-3-84 GROUP: WARDEN 3-3-84 DRAWN: WARDEN 3-3-84 CHECK: REHAR 3-2-84 STRESS: PROJ: RPS 3-2-84 APPD: JF OTHER:		WIRE TABLE WIRE CODE NO. GA MATERIAL LG TERMINALS SERIALS						
SIZE: C CODE IDENT. NO.: 71379 DWG NO.: 1270709 NONE (SR10641)		PANTEE DIVISION 3400 E. PANTEE WICHITA, KANSAS Cessna AIRCRAFT CO. TITLE: WIRING DIAGRAM - INTERNAL INSTRUMENT LIGHTING PAGE: 11.25.0						

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO




See Sheet 2

CONTRACT NO:			PAWNEE DIVISION 3600 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE			
W-100	WARDEN	3-3-84	WIRING DIAGRAM- INTERNAL INSTRUMENT LIGHTING		
GROUP	W. H. WARDEN	3-3-84			
DRAWN	WARDEN	3-3-84			
CHECK	RE HAWK	3-2-84			
STRESS					
PROJ	W. H. WARDEN	3-2-84	SIZE	CODE IDENT.	DWG NO.
APPO			C	71379	1270709
OTHER			SCALE: NONE (SR10641)		PAGE: 11.29.1

Internal Instrument Lighting (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL

LH INSTRUMENT PANEL



CONTRACT NO.			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
NAME			Cessna AIRCRAFT CO.		
DATE			TITLE		
DESIGN	WARDEN	3-3-84	WIRING DIAGRAM- INTERNAL INSTRUMENT LIGHTING		
GROUP	W. H. WARDEN	3-3-84			
DRAWN	WARDEN	3-3-84			
CHECK	RE HAIR	3-2-84			
STRESS					
PROJ	W. H. WARDEN	3-2-84	SIZE	CODE IDENT. NO.	DWG NO.
APPD			C	71379	1270709
OTHER			SCALE	NONE	(SR10641)
			PAGE: 11.29.1		

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: GE13 WAS GE9, G067 WAS G026 & G068 WAS G038 (SR10101XSR10102)	JWH 4-22-82	KEN JRS JWH
B	BY REV: MS27212-1-B WAS MS27212-1-A OBSOLETE G068 & G069 IN WIRE. REVISE DETAIL A. ON G063 WIRE. S1367-1-6 WAS S1370-1 ADD NOTE 5 ADD N-G063 WIRE. (SR10101XSR10102)	GLS JWH 6-30-82	JRS JWH

NOTES:

1. SYSTEM SHOWN WITH LANDING GEAR DOWN & LOCKED.
ACFT ON GROUND, & POWER OFF
2. PRESSURE SWITCH OPENS WHEN GEAR IS UP &
HYDRAULIC PRESSURE BUILDS UP TO PROPER LEVEL
3. INSTALL 1270717 DIODE ASSY WITH MARKING BAND
ON DIODE TO POSITIVE TERMINAL ON PUMP MOTOR
4. USE S-1699-5-0.8 SHRINKABLE TUBING OVER S-1830-1 TERMINAL
5. TERMINATE VENDOR FURNISHED WIRE WITH S-1367-1-6 TERMINAL

N-G062	22		S-1367-1-6	S-1367-1-6	
G063	22		S-1367-1-6	S-1367-1-6	
G067	22		S-1367-1-6	S-1367-1-6	
GE13	22		S-1367-1-6	S-1367-1-6	
GA3	10	S-1562-10-9	S-1367-3-2	S-1367-3-8	
N-G064	22		S-1367-1-6	SOLDER	
N-G063	22		S-1367-1-6	S-1367-1-6	
GA2	10	S-1562-10-9	S-1367-3-2	S-1367-3-8	
GE10	10	S-1562-10-9	S-1367-3-2	S-1367-3-8	
N-G064	22		S-1367-1-6	S-1367-1-6	
F-G043	1		S-1367-1-6	S-1367-1-6	
N-G042	1		SOLDER	S-1370-1	
F-G041	22		S-1367-1-6	SOLDER	
G062	22		S-1367-1-6	SOLDER	
F-G061	1		S-1367-1-6	S-1367-1-6	
F-G060	1		S-1367-1-6	S-1367-1-6	
F-G059	1		S-1367-1-6	S-1367-1-6	
F-G058	1		S-1367-1-6	S-1367-1-6	
F-G057	1		SOLDER	S-1367-1-6	
G056	1		S-1367-1-6	S-1367-1-6	
G055	1		S-1367-1-6	SOLDER	
WIRE	22	-22-6-4	S-1367-1-6	S-1367-1-6	
WIRE	1	-22-6-4	S-1367-1-6	S-1830-1	
G048	1		S-1367-1-6	S-1367-1-6	
G047	22		S-1367-1-6	S-1367-1-6	
G039	1		S-1367-1-6	S-1367-1-6	
N-G035			S-1370-1	S-1370-1	
N-G033			S-1367-1-6	S-1370-1	
G029			S-1367-1-6	S-1367-1-6	
F-G017			S-1367-1-6	S-1367-1-6	
GE4			SOLDER	SOLDER	
GE2			SOLDER	SOLDER	
WIRE	22	-22-0	SOLDER	S-2079-4	

02-00916
01-00916


19					
18	S2527-2	GND CONNECTOR			
17	S2527-1	LH GND BLOCK			
16	MS25041-2	LIGHT ASSY			
15	15700-43	DIODE ASSY			
14	S-1232-35	CIRCUIT BREAKER			
13	9800710	PRESSURE SWITCH	<2		
12	S-1586-1	SWITCH-UP LOCK			
11	9801141	MOTOR			
10	1270717	DIODE ASSY			
9	S-1577-1	POWER PACK CONT			
8	VM920M-3	LIGHT			
7	MS27212-1-5	TERMINAL BOARD			
6	MS27212-1-B	TERMINAL BOARD			
5	S-1377-2	SWITCH			
4	1270034	SQUAT SWITCH			
3	S-1637-1	HOUSING			
2	S-1637-2	HOUSING			
1	S-1360-5L	CIRCUIT BREAKER			

WIRE TABLE				SERIALS	
CONTRACT NO:	NAME		DATE	Pawnee Division 3800 E. Pawnee Wichita, Kansas	
DESIGN	TITLE		Cessna Aircraft Co.		
GROUP	WIRING DIAGRAM -				
DRAWN	LANDING GEAR				
CHECK	CONTROL SYSTEM				
STRESS					
PROJ	J. J. MOORE	4-2-82	SIZE	CODE IDENT.	DWG NO
APPRO	S. R. W. W. W.	4-2-82	C	71379	1270709
OTHER			SCALE	NONE (SR10101XSR10102) PAGE: 12.6-0	

EQUIPMENT TABLE	
PART NO.	DESCRIPTION
CES-1000 IS APPLICABLE	SUPERSEDES: P12.6-0
VENDOR CODES PER S-1400	1270709 P12.6-2
CES-1000-CESNA SPEC. NO.	SUPERSEDED BY:
S-1001 OR C10000-CESNA	
STD. NO.	

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
B	SEE PG 12.6.0 FOR REV		




02-00916
01-00916


DETAIL **A**
(APPLIES TO P210 ONLY)

CONTRACT NO:		PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS			
DESIGN	NAME	DATE	TITLE		
GROUP	<i>W. Thompson</i>	<i>2-2-82</i>	WIRING DIAGRAM LANDING GEAR CONTROL SYSTEM		
DRAWN	<i>M. THOMPSON</i>	<i>2-2-82</i>			
CHECK	<i>BORLESKE</i>	<i>2-2-82</i>			
STRESS					
PROJ	<i>J.W. MOORE</i>	<i>4.2.82</i>	SIZE	CODE IDENT.	DWG NO.
APPO	<i>PS</i>		C	71379	1270709
OTHER			SCALE: NONE	<i>(SR100)</i> <i>(SR100)</i>	PAGE: 12.6.1


MODEL P210 SERIES SERVICE MANUAL



REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	200 5-2-73	WJ WJ
B	BY REV: 22 GA WAS 18GA / HA31, HA32, HA33 (SR8143)	GDS 5-6-76	SLUW JRS
C	BY REV ADD DETAIL "A" (SER (5465)(SR8464)	LSS 6-6-77	JAD WLF JRS
D	BY REV: S-2160-3 WAS S-2160-1 (SR8464)(REF)(SR8465)(REF)	OLP 2-9-77	JAD WLF JRS
E	BY REV: ADD DETAIL "B", S-2527-2 (1), BLK(F-HA113); SER OUT F-HA33 (SR1101)(SR1012)	MKT 1-27-82	JAD WLF JRS
F	BY REV: BLK(FN-HA25) WAS BLK(FN-HA113) (SR1010)(SR1012)	RNJ 5-3-82	WLF JRS



DETAIL 13
THRU SER(SR1010)(SR1012)



DETAIL A
EFF THRU SER(SR8464)

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
HA 25	22	-22-0		S1367+6 S2099-4	SER(SR1010)(SR1012) ON
HA 71	22			S-1370-1 S-1493-1	SER(SR8464) ON
HA 70	22			S-1367+6 S-1493-1	SER(SR8464) ON
F-HA33	22		12	S-1367-1A S-1367-1A	THRU SER(SR1010)(SR1012)
F-HA32	22		24	SOLDER	THRU SER(SR8464)
F-HA31	22		18	S-1367-1G SOLDER	THRU SER(SR8464)

PART NO.	DESCRIPTION	VENDOR
7	S2527-2 GND CONNECTOR	
6	S2527-1 LH GND BLOCK	
5	S-2160-3 SWITCH	
4	MS2533B-7079 LAMP	
3	#11-225 LAMPHOLDER (95263)	
2	S-1284-1 SWITCH	
1	S-1360-6L CIRCUIT BREAKER	

CONTRACT NO.		COMMERCIAL AIRCRAFT DIV.	
NAME	DATE	3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	VR SIPS 1-28-71	Cessna AIRCRAFT CO. TITLE WIRING DIAGRAM — LIGHT, ICE DETECTOR(OPT)	
GROUP	N W 2-26-71		
DRAWN	VR SIPS 2-18-71		
CHECK	L. WHITE 2-24-71		
STRESS		SIZE	CODE IDENT.
PROJ	Wichita 2-27-71	C	71379
APPO		DWG NO	1270709
OTHER		SCALE: NONE	210 P210 PAGE: 13.5

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-1111-CESNA SPEC. NO.
S-1111 OR CM1111-CESNA
STD. NO.


SUPERSEDES:
2210-1073

SUPERSEDED BY:

(SR6755) II
21059503

9/6-00-916
01-000916
20-00-10

MODEL P210 SERIES SERVICE MANUAL



REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: SER OUT HD1, HD2, HD3 & 112-507-101 SER IN S-382-2 ADD HD4, HD5, HD6, S-1360-8L S-382-2 (SR8143)	RS 4-1-76	JAY APD
B	BY REV: ADD DETAIL A, SER (SR8143) THRU SER (SR8464), HD7 & HD8 (SR8464) (SR8465)	LSS 6-6-77	JAY APD
C	BY REV: REACTIVATE DWG (SR878A) (SR878B)	CMK 7-6-78	JAY APD
D	BY REV: ADD DETAIL "B," S-527-21-1 BLK (FN-HD20), SER OUT HD-6 (SR10101) (SR10102)	MKT 1-27-82	JAY APD

DETAIL A
SER (SR8143) THRU SER (SR8464)

DETAIL A
THRU SER (SR8143)
(21061573)

DETAIL B
THRU SER (SR8143) (SR10102)

QTY	PART NO.	DESCRIPTION
9	52527-2	GND CONNECTOR
8	52527-1	LH GND BLOCK
7	S-1360-5L	CIRCUIT BREAKER
6	S-2160-1	SWITCH
5	S-382-2	SWITCH
4	S-1360-8L	CKT BREAKER
3	1513460	HEATER
2	KPT07EB-25	RECEPTACLE
1	S-382-2	CIRCUIT BREAKER SW

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK (FN-HD20)	20	-20-0	SOLDER	S2099-4	SER (SR10101) (SR10102) (SR10103)
HD8	20		SOLDER	S-1493-1	SER (SR8143) & ON
HD7	20		S-1367-1-6	S-1493-1	SER (SR8143) & ON
HD6	20		SOLDER	S-1367-1-10	SER (SR8143); THRU SER (SR10101) (SR10102)
HD5	20		S-1367-1-6	SOLDER	SER (SR8143) THRU SER (SR8464)
HD4	20		S-1367-1-6	S-1367-1-6	SER (SR8143) THRU SER (SR8464)
HD3	18		SOLDER	S-1367-1-6	THRU SER (SR8143)
HD2	18		S-1367-1-6	SOLDER	THRU SER (SR8143)
HD1	18		S-1367-1-6	S-1367-1-6	THRU SER (SR8143)

EQUIPMENT TABLE		CONTRACT NO:		WIRE TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-100X OR CES-1000-CESNA STD. NO.		SUPERSEDED BY: PG. 13.12		COMMERCIAL AIRCRAFT DIV. Cessna AIRCRAFT CO. 3000 E. PAWNEE WICHITA, KANSAS	
DESIGN VP SIFES 12-11-74 GROUP WJ Handman 12-12-74 DRAWN CJ HESSMAN 12-3-76 CHECK J YOMEL 12-10-76 STRESS		TITLE WIRING DIAGRAM — WINDSHIELD ANTI-ICE SYSTEM (OPT)		SIZE CODE IDENT. DWG NO C 71379 1270709	
PROJ H. M. Carter 12-18-74 APPD J. L. 2.4 OTHER		SCALE: NONE 210 (SR 7913) PAGE: 13.7		P210 (21061040)	

9160020 91600 10 00016 020016

MODEL P210 SERIES SERVICE MANUAL

NOTES:

1. FOR COMPLETE INSTL (3) THREE EACH OF THESE WIRES ARE REQUIRED
2. THESE WIRES TO BE PER MIL-W-81044/12-18-9
3. THESE WIRES PART OF 2170206 CABLE ASSY

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD DETAIL "A", F-HA66, F-HA67, S-2160-1; SER; C662503 0103 WAS C622503-0106 (L27K7)(SRB464)	LSS 6-6-77	JAB WHT JRS
B	BY REV: ADD F-HA79, ADD F-HA39, C662503-0103 (22-370-20/DETAIL "B"; F-HA79 WAS F-HA39; SER OUT 1201080 (SRB464)(SRB465)	JJB 8-29-77	JAB WHT JRS
C	BY REV: S-1367-2-6 WAS S-1367-2-13/HA41, HA42 & HA43 (NOW SHOP PRACTICE)	HGG 2-20-79	JAB WHT JRS
D	BY REV: ADD RED(F-HA106), BLK(F-HA107), S-1637-1, & S-1637-2. RED(F-HA66) WAS HA66 & BLK(F-HA67) WAS HA67. S-1367-2-B & S-1636-2 WAS SOLDER/HA66 & HA67 (MER 206 E0770) HA6A WAS 22 GA/HA66, HA67, HA107, HA106.(USE AS IS PARTS IN WORK, & FINISHED PARTS)	MDR 5-22-79	JAB WHT JRS
E	BY REV: ADD DETAIL "B" (NOW SHOP PRACTICE)	RLY 8-7-80	JAB WHT JRS
F	BY REV: ADD DETAIL "C" & NOTE 3 (SR10680)	TMS 4-26-84	JAB WHT JRS

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-HA107	14	-14-0		SOLDER	S-1635-2
RED F-HA106	14	-14-2		SOLDER	S-1635-2
F-HA79	14			S-1367-2-4	SOLDER
S-HA87	14	-14-0		S-1367-2-8	S-1636-2
RED F-HA66	14	-14-2		S-1367-2-8	S-1636-2
F-HA73	14			S-1367-2-12	S-1493-2
F-HA72	14			S-1367-2-14	S-1493-2
F-HA36	18	2.		S-1367-1-6	S-1367-1-6
F-HA35	18	2.		S-1367-1-6	S-1367-1-6
F-HA34	18	2.		S-1367-1-6	S-1367-1-6
F-HA43	14			S-1367-2-10	S-1367-2-10
F-HA42	14		105	SOLDER	S-1367-2-11
F-HA41	14		105	SOLDER	S-1367-2-11
F-HA40	14		25	SOLDER	S-1367-2-8
F-HA39	14		70	S-1367-2-12	SOLDER
F-HA38	14		27	S-1367-2-10	S-1367-2-12
F-HA37	14		32	S-1367-2-10	S-1367-2-10

15	C40055	BRUSH BLOCK
14	C40057	BRACKET
13	S-1637-2	CONNECTOR
12	S-1637-1	CONNECTOR
11	S-2160-1	SWITCH
10	D40106	SLIP RING ASSY
9	C40010	BRUSH BLOCK ASSY
8	C165020-0101	TIMER
7	M53106AD20-155	PLUG
6	M53057-12A	CLAMP
5	1201080	CABLE ASSY
4	22-370-2D	SHUNT
3	C662503-0103	AMMETER
2	S-382-2	SWITCH
1	S-1360-201	CHT BREAKER


EQUIPMENT TABLE		CONTRACT NO:		WIRE TABLE	
PART NO.	DESCRIPTION	NAME	DATE	SIZE	CODE IDENT. NO.
				C	71379
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-1000 OR CH1000-CESNA STD. NO.		DESIGN		DWG NO	1270709
		GROUP	JRS	4-28-76	
SUPERSEDES: PG. 13. 4 SUPERSEDED BY:		DRAWN	SWANSON	4-1-76	
		CHECK	YONEL	4-7-76	
		STRESS			
		PROJ	21061574	SCALE: NONE	SRB143
		APPRO	JRS	PAGE: 13. 8	
		OTHER			

COMMERCIAL AIRCRAFT DIV.
8800 E. PAWNEE
WICHITA, KANSAS

Cessna AIRCRAFT CO.

TITLE
**WIRING DIAGRAM —
PROP DE-ICING SYSTEM
3 BLADE (OPTIONAL)**

MODEL P210 SERIES SERVICE MANUAL



CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 8800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE			
GROUP	ORS	4-27-76	WIRING DIAGRAM —		
DRAWN	SWANSON	5-1-76	PROP DE-ICING SYSTEM		
CHECK	YEWEL	4-7-76	3 BLADE (OPTIONAL)		
STRESS					
PROJ	PLUMBILL	4-28-76	SIZE	CODE IDENT. NO.	DWG NO
APPD	775		C	71379	1270709
OTHER			SCALE: NONE	SRB143	PAGE: 13. B

Prop De-Icing System, 3 Blade (Optional) (Sheet 2 of 2)

21061574 (210) (P210)

MODEL P210 SERIES SERVICE MANUAL

NOTES.

1. HEATER CIRCUIT SHOWN ONLY. FOR STALL WARNING CIRCUIT SEE PAGE 15 S
2. TERMINATE VENDOR LEAD WITH S-1635-1
3. TERMINATE VENDOR LEAD WITH S-1367-1-6
4. S-1557-2 CAP UNUSED VENDOR LEADS FROM SWITCH
5. INTERTWINE HA 105, HA 102 & HA 110 WITH HA 53, HA 54, HA 55 & HA 60 PER P210. INTERTWINE HA 111, HA 112 & HA 110 WITH HA 52, N-HAG+ & NHA 69 PER P20

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: S-2099-5 / ORN (N-HA74) WAS 66100-7, S-2353-1 / N-HAG 8 WAS 66098-7 (SR846)(SR8465)	JJB 8-29-77	JAC with 6-23-77
B	BY REV: 186-9 WAS S-1672-9 (NOW SHOP PRACTICE)	PSM 12-6-78	JAC with 1/8
C	BY RE: SER OUT DETAIL A, DETAIL B: SER IN DETAIL A, HA 100, HA 101, HA 102 HA 103, HA 104; ADD FLAGNOTE 3 & PG 13-11-2 (SR9310)	LWF 2-15-79	CMK AB
D	BY REV: MS27212-1-7 WAS MS27212-1-6. REWIRE SQUAT SWITCH & RESISTOR. S-1367-2-6 WAS SOLDER/HA 55. S-1367-2-6 WAS S-1370-2/HA 56. S-1367-2-6 WAS S-1370-2/HA 57. S-1367-2-6 WAS SOLDER/HA 58. S-1367-2-8 WAS SOLDER/HA 68. S-1367-2-8 WAS SOLDER/HA 103. REVISE PIN #'S/ S-1640-9, S-1641-9, S-2349-1, S-2350-1 (SR8863)(REF)	MDR 6-22-79	JAC with 1/8
E	BY REV: HA-108 WAS HA-100, HA 109 WAS HA-101, HA 110 WAS HA-102, HA-111 WAS HA-103, HA-112 WAS HA-104. (SR 9310/REF)	MKM 8-1-80	JAC with 1/8
F	BY REV: ADD DETAIL C & SERIALS. ADD HA 113 WIRE & STALL WARN HEAT SWITCH & CIRCUIT BREAKER (SR 10356)	WHA 1-15-82	JAC with 1/8
G	BY REV: MS27212-1-8 WAS MS27212-1-7 / ITEM 12 (SR1011)(SR1012)	GLS 6/28/82	JAC with 1/8

01-000-6, 02-000-10

HA 113	16		S-1367-2-6	S-1635-2		SER (SR 10356) & ON
HA 112	16		S-1636-2	S-2099-5	< 5	SER (SR 9310) & ON
HA 111	16		S-1367-2-8	S-2553-1	< 5	SER (SR 9310) & ON
HA 110	16		S-1635-2	SOLDER	< 5	SER (SR 9310) & ON
HA 103	16		S-1635-2	S-1636-2	< 5	SER (SR 9310) & ON
HA 102	16		S-1367-2-8	S-1636-2	< 5	SER (SR 9310) & ON
N-HAG 8	16		S-1367-2-6	S-2353-1		
BRN (N-HA74)	16	-16-3	S-1636-2	S-2099-5		
SLY (NAG 7)	20	-20-0	S-1636-2	S-1367-1-8		
BLU (NAG 8)	16	-16-6	S-1635-2	S-1636-2		
BLK (NAG 1)	20	-20-0	SOLDER	S-1367-1-8		THRU SER (SR 9310)
HAG 0	16		S-1635-2	SOLDER	< 5	
HA 59			S-1635-2	S-1636-2	< 5	
HA 58			S-1367-2-6	S-1636-2		
HA 57			SOLDER	S-1367-2-6		
HA 56			SOLDER	S-1367-2-6		
HA 55			SEE HA 54	S-1367-2-6		
HA 54			S-1493-2	S-1636-2	< 5	
HA 53	16		S-1367-2-4	S-1493-2	< 5	

17	S-1560-10L	CIRCUIT BREAKER
16	S-2349-1	CONNECTOR
15	S-2350-1	CONNECTOR
14	S-1641-6	HOUSING - PIN
13	S-1640-6	HOUSING - PIN
12	MS27212-1-8	TERMINAL BOARD
11	1CH1-6	SQUAT SWITCH
10	S-2091-50-15	RESISTOR
9	186-9	HEATED STALL DETECTOR
8	AN 5812-1	HEATED PITOT TUBE
7	AN 3115-1	RECEPTACLE
6	S-1637-1	HOUSING - CAP
5	S-1637-2	HOUSING - PLUG
4	S-1640-9	HOUSING - PIN
3	S-1641-9	HOUSING - SOCKET
2	S-2160-1	SWITCH
1	S-1360-15L	CIRCUIT BREAKER

WIRE TABLE			
CONTRACT NO:	NAME	DATE	TITLE
	SPENCER	6-20-77	HEATED PITOT TUBE & HEATED STALL WARNING SYSTEM - KNOWN ICING (OPT)
	W.H. H. dim	6-23-77	
	L. STORBY	6-6-77	
	BOKLESKE	6-7-77	
	PLANNING	6-2-77	
	JRS		

EQUIPMENT TABLE	
PART NO.	DESCRIPTION

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-1001 OR C10000-CESNA STD. NO.

SUPERSEDER:
SUPERSEDED BY:

PROJ: PLANNING
APPRO: JRS
OTHER:

FAWEE DIVISION
3600 E. FAWEE
WICHITA, KANSAS

Cessna AIRCRAFT CO.

WIRING DIAGRAM -
HEATED PITOT TUBE & HEATED STALL WARNING SYSTEM - KNOWN ICING (OPT)



SIZE: C CODE IDENT. NO.: 71379 DWG NO: 1270709

SCALE: NONE 210 P210 PAGE: 13-11-0

(SR8863)

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
F	SEE PAGE 13.11.0		




DETAIL A
(APPLIES TO P210)
THRU SER (SR9310)

CONTRACT NO:			Cessna AIRCRAFT CO.		PAWNEE DIVISION 8600 E. PAWNEE WICHITA, KANSAS	
DESIGN	SPENCER	6-20-77	TITLE			
GROUP	<i>D. H. Anderson</i>	6-23-77	WIRING DIAGRAM			
DRAWN	L. STOREY	6-6-77	HEATED PITOT TUBE & HEATED STALL			
CHECK	BORLESKE	6-7-77	WARNING SYSTEM - KNOWN ICING (OPT)			
STRESS						
PROJ	PLHFRILK	6-29-77	SIZE	CODE IDENT. NO.	DWG NO.	
APPO	<i>APPEL</i>		C	71379	1270709	
OTHER			SCALE: NONE	210 P210	PAGE: 13.11.1	


(SR8863)

MODEL P210 SERIES SERVICE MANUAL


REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED
F	SEE PAGE 13.11.0		




DETAIL A
(APPLIES TO P210)
SER (SR9310) & ON



DETAIL A
(APPLIES TO 210 & T210)
THRU SER (SR9310)



DETAIL B
THRU SER (SR9310)



DETAIL C
THRU SER (SR1059)


CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 3500 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE			
GROUP			WIRING DIAGRAM HEATED PITOT & HEATED STALL WARNING SYSTEM-KNOWN KING (OPT)		
DRAWN					
CHECK					
STRESS					
PROJECT					
APPD			SIZE	CODE IDENT. NO.	DWG NO.
			C	71379	1270709
			SCALE: NONE	T210 P210 PAGE: 13.11.2	

MODEL P210 SERIES SERVICE MANUAL

NOTES:

- 1. TERMINATE VENDOR FURNISHED WIRES WITH S-1635-2
- 2. TERMINATE VENDOR FURNISHED WIRES WITH S-1635-1
- 3. INTERTWINE HD19 WITH HD16 & HD12 FROM POINT OF ORIGIN TO TERMINATION POINT

REV	DESCRIPTION	DATE	APPRO
A	BY REV: ADD S-1638-4, S-1638-5, NOTES 1 & 2, ADD HD15, HD16, HD17 & HD18; NPM43501 WAS SK2567; IN TITLE BLOCK: KNOWN ICING WAS "SERVING" (SAB863)	CRS 11-22-77	JAS JAS
B	BY REV: ADD FLAGNOTE 3; SER OUT HD16; SER IN HD19 (SR8810)	LWF 2-15-79	JAS JAS
C	BY REV: ADD DETAIL "B" & SER (SR 9806)	NRL 8-8-80	JAS JAS
D	BY REV: DELETE DETAIL "B" & THRU SER(SR9806) "NEW SHOP PRACTICE"	DES 7-21-81	JAS JAS
E	BY REV: ADD S-2527-1(1-2), S-2094-4 WAS S-1367-2-10/HAS & HALL (SR1001)(SR1002) (SR1003) (SR1004) (SR1005) (SR1006) (SR1007) (SR1008) (SR1009) (SR1010) (SR1011) (SR1012) (SR1013) (SR1014) (SR1015) (SR1016) (SR1017) (SR1018) (SR1019) (SR1020) (SR1021) (SR1022) (SR1023) (SR1024) (SR1025) (SR1026) (SR1027) (SR1028) (SR1029) (SR1030) (SR1031) (SR1032) (SR1033) (SR1034) (SR1035) (SR1036) (SR1037) (SR1038) (SR1039) (SR1040) (SR1041) (SR1042) (SR1043) (SR1044) (SR1045) (SR1046) (SR1047) (SR1048) (SR1049) (SR1050) (SR1051) (SR1052) (SR1053) (SR1054) (SR1055) (SR1056) (SR1057) (SR1058) (SR1059) (SR1060) (SR1061) (SR1062) (SR1063) (SR1064) (SR1065) (SR1066) (SR1067) (SR1068) (SR1069) (SR1070) (SR1071) (SR1072)	TWE 7-21-83	JAS JAS



DETAIL A
THRU SER (SF 9310)

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
HD19	16			S-1636-2 S-1367-2-8	SER(SA8510) & ON
HD18	22			S-1367-2-8 S-1636-1	
HD17	22			S-1367-2-8 S-1636-1	
HD16	16			S-1636-2 S-1367-2-10	THRU SER(SF9310)
HD15	16			S-1367-2-8 S-1636-2	
HD14				S-1493-2 S-1367-2-8	
HD13				S-1367-2-6 S-1493-2	
HD12				S-1367-2-6 S-1367-2-8	
HD11				S-1367-2-8 S-2094-4	
HD10	16			S-1367-2-8 S-1367-2-8	
HD9	16			S-1367-2-8 S-2094-4	

10	S-2527-2	GND CONNECTOR
9	S-2527-1	LH GND BLOCK
8	NPM43501	PANEL
7	S-1638-4	HOUSING - CAP
6	S-1638-5	HOUSING - PLUG
5	1N-2070	DIODE
4	KRP3DH	RELAY
3	9910216	CONTROLLER
2	S-2160-1	SWITCH
1	S-1360-15L	CIRCUIT BREAKER


CONTRACT NO.:			Cessna AIRCRAFT CO.		PAWNEE DIVISION 3600 E. PAWNEE WICHITA, KANSAS
DESIGN	SPENCER	6-20-77	TITLE: WINDSHIELD ANTI-ICE SYSTEM - KNOWN ICING (OPT)		
GROUP	W. H. Good	6-23-77			
DRAWN	L. STOREY	6-6-77			
CHECK	BORLESKE	6-7-77			
STRESS:					
PROJ	PLH/DRL/LL	6-24-77	SIZE	CODE IDENT. NO.	DWG NO.
APPRO	JAS		C	71379	1270709
OTHER			SCALE: NO ME 210 P210 PAGE: 13/12		

PART NO.	DESCRIPTION
EQUIPMENT TABLE	

CESS-1000 IS APPLICABLE VENDOR CODES PER S-1400 CESS-1000-CESNA SPEC. NO. S-1001 OR CESSNA-CESNA STD. NO.


SUPERSEDES:
SUPERSEDED BY:
PG 13-16

MODEL P210 SERIES SERVICE MANUAL




REVISION			
LET	DESCRIPTION	DATE	APPD
F	SEE SHT 13.13.0 FOR REV		

See Sheet 2



DETAIL C
APPLIES TO P210
THRU SER (SR10655)





DETAIL A
THRU SER (SR1001)(SR10102)

CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	SPENCER	12-1-77	TITLE WING & STABILIZER DE-ICE SYSTEM - 3 CYCLE (OPT)					
GROUP	W. H. HANSEN	1-14-78	SIZE C					
DRAWN	C. SHAWER	11-22-77						
CHECK	DORLESKE	11-30-77	CODE IDENT. NO. 71379			DWG NO. 1270709		
PROJ	P. H. DRIZIC	1-17-78	SCALE: NONE			(SR9427)		
APPD	APR 2					PAGE: 13,13,1		
OTHER								


3/8/88-78

MODEL P210 SERIES SERVICE MANUAL

See Sheet 1



DETAIL 13
SER(SR9953)(SR9954) THRU SER(SR10396)



DETAIL 13
THRU SER(SR9153)(SR9954)


CONTRACT NO:			CESSNA AIRCRAFT CO.			PAWNEE DIVISION 8800 E. PAWNEE WICHITA, KANSAS		
DESIGN	SPENCER	12-1-77	TITLE					
GROUP	<i>W. W. Spencer</i>	1-19-78	WING & STABILIZER DE-ICE SYSTEM - 3 CYCLE (OPT)					
DRAWN	G. SHAWER	11-22-77						
CHECK	BORLESKE	11-30-77						
STRESS								
PROJ	P. WEDRICK	1-17-78	SIZE	CODE IDENT.	DWG NO.			
APPD	<i>[Signature]</i>		C	71379	1270709			
OTHER			SCALE: NONE			(SR9927)		PAGE: 13.13.1

MODEL P210 SERIES SERVICE MANUAL

NOTES:

- 1. TERMINATE VENDOR LEADS WITH S-1635-1
- 2. INTERTWINE HFS & HFG WITH HF3 & HF1.

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ALL FLGNOTE 2; SER OUT HF4; SER IN HFS & HFG, S1637-2 & S1637-1 (SR9310)	LWF 2-15-79	CMK <i>[Signature]</i>
B	BY REV: ADD DETAIL 'D' (SK9954)	GW 4-30-81	<i>[Signature]</i>



DETAIL A
THRU SER (SR9310)

DETAIL B
[F1 THRU SER (SR9310)]

54-00916

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
HF6	20	S-4635-1	S-1636-1	1	SER (SR9310) EON
HF5	20	S-1636-1	S-1367-8	1	SER (SR9310) EON
HF1	20	S-1367-4	S-1367-4	1	
HF2	20	S-1367-4	S-1636-1	1	
HF3	20	S-1367-4	S-1636-1	1	
BLK (HF4)	20	-20-0	S-1636-1	S-1367-8	THRU SER (SR9310)

PART NO.	DESCRIPTION
7	S-1637-1 HOUSING - CAP
6	S-1637-2 HOUSING - PLUG
5	S-1360-5L CIRCUIT BREAKER
4	S-382-1 SWITCH
3	S-1638-1 HOUSING
2	S-1638-2 HOUSING
1	C414003-0101 BLOWER ASSY

CONTRACT NO:			Cessna AIRCRAFT CO.	
DESIGN	NAME	DATE	TITLE	
	SPENCER	8-23-78	WIRING DIAGRAM - CABIN VENTILATION BLOWER - P210	
GROUP	<i>[Signature]</i>	8-25-78		
DRAWN	SHEFFIELD	8-10-78		
CHECK	BORLESKE	8-16-78		
STRESS				

EQUIPMENT TABLE

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-1000 OR C414003-CESNA STD. NO.

SUPERSEDES:

SUPERSEDED BY:

PROJ	APPD	OTHER	SIZE	CODE IDENT. NO.	DWG NO.
	<i>[Signature]</i>		C	71379	1270709
			SCALE: NONE	(SR9361)	PAGE: 13, 14

MODEL P210 SERIES SERVICE MANUAL

NOTES:

- 1. REMOVE & DISCARD VENDOR FURNISHED TERMINALS. TERMINATE WITH S-1636-2 TERMINALS.
- 2. TERMINATE VENDOR FURNISHED WIRE WITH S-1635-2 TERMINAL
- 3. TERMINATE VENDOR FURNISHED WIRE WITH S-1636-1 TERMINAL
- 4. INTERTWINE HE21 WITH HE9/210, HE22 WITH HE20/P210, HE16 WITH HE2, HE3, HE4, & HE1/210, HE17 WITH HE2, HE3, HE4, & HE18/P210, HE15 WITH HE12, HE13, & HE14

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: TITLE BLOCK SERIALS WERE (SR9114)(SR9115) (SR9556)	H H G 8-9-79	JAB WPA
B	BY REV: HE 10 WAS CONN TO PIN 4 / S-1917-2. HE 6 & HE 19 WAS CONN TO PIN 1 / S-2035-1, S-1493-1 WAS SEE HE 10 / F-HE 6 & N-HE 19 NOW SHOP PRACTICE (MER 210 FOR 811) (SR 9556)	SEB 1-25-80	JAB WPA PRG
C	BY REV ADD DETAIL 'A' (DL9334)	GW 4-30-81	JAB WPA PRG

54-00916


N-HE22	16	-16-0	S-1636-2	S-1367-2-8	
F-HE21	16	-16-0	S-1636-2	S-1367-2-8	
N-HE20	16		S-1493-2	S-1635-2	
N-HE19	18		S-1493-1	S-1493-1	
N-HE18	18		S-1367-1-6	S-1493-1	
N-HE17	18	-18-0	SEE HE15	S-1367-1-8	
F-HE16	18	-18-0	SEE HE15	S-1367-1-8	
N-HE15	18	-18-0	S-1635-1	S-1635-1	
HE14			S-1635-1	SEE HE4	
HE13			S-1635-1	SEE HE3	
HE12			S-1635-1	SEE HE2	
HE11			S-1493-1	S-1367-1-8	
HE10	18		S-1635-1	S-1493-1	
F-HE9	16		S-1493-2	S-1635-2	
HE8	16		S-1367-2-6	S-1493-2	
HE7	18		S-1635-1	S-1635-1	
F-HE6	18		S-1493-1	S-1493-1	
HE5			S-1493-1	S-1493-1	
HE4			S-1635-1	S-1493-1	
HE3			S-1635-1	S-1493-1	
HE2			S-1635-1	S-1493-1	
F-HE1	18		S-1367-1-6	S-1493-1	

10	S-1917-2	RELAY	
14	0882362	HIGH PRESSURE SW	
13	5D57-1	COMPRESSOR	
12	S-2035-2	HOUSING	
11	S-2035-1	HOUSING	
10	6303-1	COOLING FAN	
9	S-1637-2	HOUSING	
8	S-1627-1	HOUSING	
7	S-1360-15L	CKT BKR	
6	S-1360-10L	CKT BKR	
5	1247200	TEMPERATURE SW (ARA)	
4	0882590	SWITCH (ARA)	
3	S-1638-4	HOUSING	
2	S-1638-5	HOUSING	
1	2101020	BLOWER	

EQUIPMENT TABLE		WIRE TABLE		CONTRACT NO:		Cessna AIRCRAFT CO.		TITLE	
PART NO.	DESCRIPTION	WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS	NAME	DATE
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-3001 OR CXXXX-CESNA STD. NO.		SUPERSEDED BY:		DESIGN SPENCER 3-2-79		DRAWN HIGAZARIAN 2-12-79		CHECK BORLESKE 2-14-79	
SUPERSEDED BY:		PROJ Spencer 3-2-79		APPO PRG		OTHER /		SIZE CODE IDENT. DWG NO	
				C 71379		1270709		SCALE: NONE (SR 9556) PAGE: 13.15.0	

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV. AVU DETAIL "B" S2527-2-1) BLK(FN CC33) SER OUT CC24 (SR10101)(SR10102)	MKT 1-27-82	JAB:MM JRS



DETAIL A
(APPLIES TO P210 ONLY)

02-007316
01-007316

DETAIL 13
THRU SER(SR10101)(SR10102)

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
ORN(CC35)	16	-16-0	5-1367-2-4	5-2099-3	SER(SR10101)(SR10102) 10M
ORN(CC45)	16	-16-3	5-1493-2	5-2099-5	
BLU(CC44)		-16-6	5-1493-2	5-2099-5	
CC43			5-1367-2-4	5-2353-1	
CC40			5-1367-2-4	5-2353-1	
CC50			5-1367-2-4	5-1367-2-4	
VIO(CC37)		-16-7	5-1493-2	5-1367-2-8	
VIO(CC38)		-16-7		5-1367-2-8	
GRN(CC51)		-16-5		5-1636-2	
RED(CC43)		-16-2	5-1493-2	5-1636-2	
ORN(CC35)		-16-3	5-1635-2	5-1493-2	
BLU(CC34)		-16-6	5-1635-2	5-1493-2	
CC49			5-1367-2-4	5-1367-2-4	
CC33			5-1367-2-4	5-1636-2	
CC27				5-1636-2	
CC25				5-1636-2-4	
CC24	16		5-1367-2-4	5-1367-2-8	THRU SER(SR10101)(SR10102)

WIRE TABLE

QTY	PART NO.	DESCRIPTION
	12	S2527-2 GND CONNECTOR
	11	S2527-1 LH GND BLOCK
	10	S-2349-1 CONNECTOR
	9	S-2350-1 CONNECTOR
	8	C301002-0202 FLAP MOTOR
	7	S-1906-2 SWITCH
	6	S-1638-2 HOUSING
	5	S-1638-1
	4	S-1640-6
	3	S-1641-6 HOUSING
	2	S-1906-1 SWITCH
	1	S-1360-10L CIRCUIT BREAKER

EQUIPMENT TABLE

CEB-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CEB-1000-CEBNA SPEC. NO.
S-100X OR CN1000-CEBNA
STD. NO.


SUPERSEDES:
1270709 PGS 41.0 & 41.1

SUPERSEDED BY:

CONTRACT NO.:		Cessna AIRCRAFT CO.	
DESIGN	NAME	DATE	WIRING DIAGRAM - WING FLAPS
GROUP	W. J. Henderson	2-2-79	
DRAWN	HGN AZARIAN	2-9-79	
CHECK	BORLESKE	2-12-79	
STRESS			
PROJ	J. E. E. E.	2-15-79	SIZE
APPD	JRS		CODE IDENT. NO.
OTHER			DWG NO.
			1270709
			SCALE: NONE
			(SR911)(SR915) PAGE: 14, 12

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
	SEE PG. 14.13.0 FOR REVISION		




See Sheet 2

CONTRACT NO:			Cessna AIRCRAFT CO.		PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	SPENCER	8-2-83	WIRING DIAGRAM - ELECTRIC ELEVATOR TRIM (OPT)			
GROUP	<i>Willard</i>	<i>8-4-83</i>				
DRAWN	SPENCER	8-2-83				
CHECK	<i>R. E. Hill</i>	<i>8-3-83</i>				
STRESS						
PROJ	<i>JR</i>	<i>8-17-83</i>	SIZE	CODE IDENT. NO.	DWG NO.	
APPD			C	71379	1270709	
OTHER			SCALE: NONE	SRI0660	PAGE: 14.13.1	

Electric Elevator Trim (OPT) (Sheet 1 of 2)

MODEL P210 SERIES SERVICE MANUAL



CONTRACT NO:			PAWNEE DIVISION 5000 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE WIRING DIAGRAM- ELECTRIC ELEVATOR TRIM (OPT)		
GROUP	<i>Willard</i>	<i>8-6-83</i>			
DRAWN	SPENCER	8-2-83			
CHECK	<i>R.E. Hill</i>	<i>8-3-83</i>			
STRESS					
PROJ	<i>J.R. Smith</i>	<i>8-17-83</i>	SIZE	CODE IDENT. NO.	DWG NO.
APPD			C	71379	1270709
OTHER			SCALE: NONE	SRI0660	PAGE: 14.13.1

Electric Elevator Trim (OPT) (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: 22 GA WAS 20GA/GC 21 THRU GC 25 BLUE (GC 26), BLK (GC 27), FCS, BLK (FC 7) (SR B143)	GDS 5-6-76	JRS
B	BY REV: ADD S-2035-1; S-2035-2; S-1850-1 WAS S-1445-1; S-1636-1 WAS S-1635-1/GC 24, S-1635-1 WAS S-1636-1/ GC 24 (NOW SHOP PRACTICE) SEE E0523	PH 8-16-76	JRS
C	BY REV: ADD DETAILS A, B, C, D, P 15.5.1, S-2349-1, S-2350-1, WIRES TAN (FC 9), TAN (FC 10), FC 11, TAN (FC 12), GC 29, BLU GC 30, GC 31/GC 32; SER OUT GC 25; SER IN GC 28; GE (REF) WAS GE (REF), GE (REF) WAS GE (REF), GE (REF) WAS GE (REF) ADD S-1672-4 (SR B464/SRB465)	LSS GDS 6-6-77	JRS
D	BY REV: S-2099-3 WAS G6100-7/TAN (FC 12) TAN (FC 10); S-2353-2 WAS G6332-5/U-FC 11 (SR B464/SRB465)	JJB 8-29-77	JRS
E	BY REV: 1270733 WAS 1270733-1 (NOW SHOP PRACTICE)	NTL 8-28-79	JRS
F	BY REV: ADD DETAIL E & F, WIRES BLU (GC 33), BLU (GC 34), BLK (GC 35) (S-2035-1, S-2035-2. (SR 9860)	SEB 7-31-80	JRS
J	SEE PAGE 15.5.1 FOR REVISION		

GC 40	22		S-1637-1	S-1636-1	SER(SR1002) CON
GC 39	22		S-1637-1	S-1636-1	SER(SR1001) CON
GC 37	22		S-1635-1	SOLDER	SER(SR 7753) CON
FC 13	18	-18-10	S-1636-1	S-2099-3	SER(SR 7753) E LN
GC 38	22		S-1636-1	S-1636-1	SER(SR 7753) CON
GC 36	22		S-1367-1	S-1636-1	SER(SR 7753) (THRU SER(SR 9860))
BLK (GC 35)	22	-22-0	S-1637-1	SOLDER	SER(SR 9860) CON
BLU (GC 33)	22	-22-6	S-1636-1	SOLDER	SER(SR 9860) CON
GC 29	22	-22-6	S-1635-1	S-1636-1	SER(SR 9860) CON
TAN (FC 12)	18	-18-10	S-1636-1	S-2099-3	
N-FC 11	22		S-2353-2	S-1636-1	
TAN (FC 10)	18	-18-10	S-1367-1	S-2099-3	
N-GC 32	22		S-1636-1	S-1636-1	
N-GC 31	22		S-1636-1	SOLDER	
BLU (GC 34)	22	-22-6	S-1636-1	S-1830-1	THRU SER(SR 9860)
N-GC 29	22		S-1367-1	S-1636-1	THRU SER(SR 1002)
F-GC 28	22		S-1367-1	S-1636-1	THRU SER(SR 9953)

18	S-2527-2	GND CONNECTOR				
17	S-2427-1	LH GND BLOCK				
16	S-2349-1	PLUG				
15	S-2350-1	RECEPTACLE				
14	S-1672-4	STALL DETECTOR				
13	S-2035-2	HOUSING - PIN				
12	S-2035-1	HOUSING - PIN				
11	S-1252-5	CIRCUIT BREAKER				
10	S-1672-1	STALL DETECTOR				
9	S-1641-9	HOUSING - SOCKET				
8	S-1640-9	HOUSING - PIN				
7	VM920M-3	LIGHT ASSY				
6	S-1360-5L	CIRCUIT BREAKER				
5	S-1641-6	HOUSING - SOCKET				
4	S-1640-6	HOUSING - PLUG				
3						
2	S-1856-1	SWITCH				
1	1270733	WARNING UNIT ASSY				


PART NO.	DESCRIPTION	MATERIAL	LG	TERMINALS	SERIALS

EQUIPMENT TABLE		
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESBNA SPEC. NO. S-1001 OR CEM1000-CESBNA STD. NO.		
SUPERSEDES:		
SUPERSEDED BY:		
OTHER		

WIRE TABLE		
CONTRACT NO:		
DESIGN	NAME	DATE
GROUP	JRS	11-18-74
DRAWN	G. WHITSON	11-11-74
CHECK	J. YOWEL	11-12-74
STRESS		
PROJ	WML/PLM	11-21-74
APPO		
TITLE WIRING DIAGRAM - DUAL WARNING SYSTEM		
SIZE	CODE IDENT. NO.	DWG NO
C	71379	1270709
SCALE: NONE		210 P210
PAGE: 15.5.0		

(SR 7913)(210G1040)

MODEL P210 SERIES SERVICE MANUAL




CONTRACT NO.			COMMERCIAL AIRCRAFT DIV. 3800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	 WIRING DIAGRAM — DUAL WARNING SYSTEM		
GROUP	URS/MS	11-9-74			
DRAWN	G. WHITSON	11-11-74			
CHECK	J. YOWEL	11-17-74			
STRESS					
PROJ	WML/PLM	11-21-74	SIZE	CODE IDENT. NO.	DWG NO.
APPD			C	71379	1270709
OTHER			SCALE: NONE	210 P210	PAGE: 15.5.0

(SR 79131)(210G1040)



Dual Warning System (Sheet 2 of 2)

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
G	BY REV. F-FC12 WAS F-FC5; F-GC36 WAS F-GC29; F-GC30 WAS F-GC24; GC37 WAS F-GC23 (REF) (SR1010152102)	MLV 10-2-81	<i>[Signature]</i>
H	BY REV. N-GE12 (REF) WAS GE1 (REF) (SR1101) (SR1102)	AKT 1-27-82	<i>[Signature]</i>
J	BY REV. ADD DETAIL H & DETAIL J SER OUT GC29 & GC36 SER IN GC39 & GC40 (SR1010152102)	UMH 4-22-82	<i>[Signature]</i>




DETAIL B
THRU SER (SR8464)




DETAIL D
(APPLIES TO P210 ONLY)

DETAIL A
(APPLIES WHEN HIGH CAPACITY HEATED STALL DETECTOR IS INSTALLED)

DETAIL C
(APPLIES TO P210 ONLY)




DETAIL E
THRU (SR 9860)



DETAIL F
THRU (SR 8784) (SR 8785)



DETAIL H
THRU SER (SR1001) (SR10102)




DETAIL J
THRU SER (SR10101) (SR10102)

02-009/6
01-009/6

CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 8800 E. PAWNEE WICHITA, KANSAS		
DESIGN	SPENCER	6-21-77	TITLE: WIRING DIAGRAM - DUAL WARNING SYSTEM					
GROUP	<i>[Signature]</i>	6-23-77						
DRAWN	SCHTELBEIN	6-6-77						
CHECK	BORLESKE	6-7-77						
STRESS								
PROJ	PLAF ORLIK	4-24-77	SIZE	CODE IDENT. NO.	DWG NO.			
APPD	<i>[Signature]</i>		C	71379	1270709			
OTHER			SCALE: NONE			210 P210	PAGE: 15.5.1	
(SR8464) (SR8465)								

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
A	SEE PAGE 15.7.0 FOR REVISIONS		




CONTRACT NO:		CESSNA AIRCRAFT CO. PAWNEE DIVISION 8800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME		
GROUP	DATE	SCHEMATIC - DUAL WARNING UNIT	
DRAWN	ACKER JUN 7-23-81	SIZE	CODE IDENT. NO.
CHECK	BORLESKE 7-31-81	C	71379
STRESS		DWG NO.	1270709
PROJ	125-1117-1	SCALE	(SR10250)
APPO	SEP 20 1981	PAGE:	15.7.1
OTHER			

MODEL P210 SERIES SERVICE MANUAL

NOTES:

1. VACUUM SWITCH CONTACTS ARE NORMALLY CLOSED.

REVISION			
LET	DESCRIPTION	DATE	APPO



02-00916

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK (N-WE9)	22	.22-0		SOLDER	5-2044-4
N-WE8					5-1444-1 5-1367-1-B
N-WE7					5-2044-7 5-1443-1
N-WE6				SOLDER	5-2353-2
N-WE5	22			5-1767-1-6	SOLDER

PART NO.	DESCRIPTION
7	5-2527-Z GND CONNECTOR
6	5-2527-1 LH GND BLOCK
5	5-2371-1 VACUUM SWITCH
4	5-2349-1 CONNECTOR
3	5-2350-1 CONNECTOR
2	MS25041-2-327 LAMP ASSY
1	5-1360-5L CIRCUIT BREAKER

CONTRACT NO:			Cessna AIRCRAFT CO.		PAWNEE DIVISION 5600 E. PAWNEE WICHITA, KANSAS
DESIGN	NAME	DATE	TITLE		
	G STAMM	3/15/82	WIRING DIAGRAM -		
	DA HAN	3-24-82	LOW VACUUM WARNING		
	G STAMM	3/15/82	LIGHT (OPT)		
	R HAN	3-15-82			

EQUIPMENT TABLE	
CEB-1000 IS APPLICABLE VENDOR CODES PER S-1400 CEB-1000-CESSNA SPEC. NO. S-100X OR C10000-CESSNA STD. NO.	SUPERSEDES: SUPERSEDED BY:

PROJ	APPD	OTHER	SIZE	CODE IDENT. NO.	DWG NO
J.H. MORSE			C	71379	1270709


(SR10102)

MODEL P210 SERIES SERVICE MANUAL

NOTES:

- 1. TERMINATE VENDOR FURNISHED WIRE WITH 5-1635-1
- 2. TERMINATE VENDOR FURNISHED WIRE WITH 5-1636-1

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD 05E10-1, NOTE 2 & DETAIL A' & SER DELETE 88000-4 (SR8824)(SR8465)	JJB 8-29-77	JADWHR JRS
B	BY REV: MS25041-6 WAS MS25041-4 (SR8465)(REF)	KLL 5-5-78	Good J... JRS
C	BY REV: ADD 5-2203-4 "NOW SHOP PRACTICE"	AKT 3-20-79	PLT... JRS
D	BY REV: ADD BLK(N-ME-10), 5-2527-1 & DETAIL "B"	MKT 1-27-82	JRS JRS



PART NO.	DESCRIPTION	QUANTITY	MATERIAL	LG	TERMINALS	SERIALS
10	5-2527-2		GND CONNE. TOR			
9	5-2527-1		L.H GND BLOCK			
8	5-2203-4		SWITCH-BARO PRESSURE(ALT)			
7	05E10-1		SAFETY VALVE			
6	MS 25041-6		IND-CABIN PRESS.			
5	MTL-106D		SWITCH-CABIN PRESS.			
4	5-1637-2		HOUSING - PLUG			
3	5-1637-1		HOUSING - CAP			
2	5-2203-3		SWITCH-BARO PRESSURE			
1	5-1360-5L		CIRCUIT BREAKER			

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK (N-ME-10)	22			SOLDER 5-2099-6	SER(SR10102) ON
N-ME9	22			SEE N-ME1 SOLDER	
BLK (N-ME8)	22	-22-0		SOLDER 5-1367-1-B	THRU SER(SR10102)
N-ME7	22			5-1636-1 SOLDER	
BLK (N-ME6)	20	-22-0		5-1635-1 5-1367-1-B	
BLK (N-ME5)	20	-22-0		5-1367-1-6 5-1636-1	THRU SER (SR8824)
N-ME4	20			5-1635-1 5-1367-1-6	THRU SER (SR8824)
N-ME3	20			SOLDER 5-1636-1	
N-ME2	20			SEE N-ME1 SOLDER	
N-ME1	20			5-1367-1-6 5-1636-2	


EQUIPMENT TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESBNA SPEC. NO. S-XXXX OR CXXXX-CESBNA STD. NO.	SUPERSEDED BY: SUPERSEDED BY:

WIRE TABLE		
CONTRACT NO:		Cessna AIRCRAFT CO. PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS
DESIGN	NAME	
GROUP	DATE	
DRAWN		
CHECK		
TITLE WIRING DIAGRAM - CABIN PRESSURE DUMP VALVE & BAROMETRIC PRESSURE SWITCH		
PROJ	PLN DRN	DATE
APPD	JRS	6-21-77
OTHER		
SIZE	CODE IDENT. NO.	DWG NO.
C	71379	1270709
SCALE: NONE	P210	PAGE: 16 2

(SR8465)

MODEL P210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO



WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
MG 3	16	S-2589	S-1367-2-8	S-1367-2-6	
MG 2	16	S-2589	S-1367-2-8	S-867-2-8	
MG 1	16	S-2589	S-1367-3-8	S-1367-3-8	

WIRE TABLE

CONTRACT NO:	
NAME	DATE
DESIGN	
GROUP	W. H. HANSEN 1-7-85
DRAWN	KEN LUNDY 12-19-84
CHECK	R.E. HARR 12-21-84
STRESS	
PROJ	ICHEL 1-28-85
APPO	MSP 1-8-85
OTHER	

		PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS
TITLE		
WIRING DIAGRAM — STANDBY VACUUM PUMP MODEL 210/P210		
SIZE	CODE IDENT. NO.	DWG NO
C	71379	1270709
SCALE: NONE		(SR 10790) Page: 16.3

PART NO.	DESCRIPTION
EQUIPMENT TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-100X OR CM1000-CESNA STD. NO.	
SUPERSEDES: SUPERSEDED BY:	